

YW5698A (2024 version)

manual



SHENZHEN YOUNG WIN TECHNOLOGY CO., LTD

Add: Room 1609, Building 4th, Phase 2nd, Tian'anyungu industrial zone, No. 2018
Xuegang road, Bantian street, Longgang district, Shenzhen, China

Features




- 1, fully laminated and full-viewing angle 11.6-inch high-definition LCD screen
- 2, intel 12 N100 CPU
- 3, DDR5 8GB memory 128 nvme solid state drive
- 4, USB3.0, HDMI, network port and other interfaces
- 5, Windows 11 64-bit system
- 6, built-in 16M high pixel imaging system
- 7, 2.4G WIFI wireless, Gigabit wired network port
- 8, 11.6 inches 1920 * 1080 screen
- 9, built-in S-EYE2.0 powerful measurement and analysis software system

Introduction

- 1、 Connect the product to DC-12V power supply first.
- 2、 After connecting the power supply, press the power button, the product's blue light is always on after switching on.
- 3、 Double click the S-EYE software on the desktop.
- 4、 Conduct the test according to the actual needs (whether to connect the monitor)
- 5, click on the 'open video source' in the S-EYE software, and click on the YW1600
- 6, Enter the required measurements and adjustments

SHENZHEN YOUNG WIN TECHNOLOGY CO., LTD


Add: Room 1609, Building 4th, Phase 2nd, Tian'anyungu industrial zone, No. 2018
Xuegang road, Bantian street, Longgang district, Shenzhen, China



SHENZHEN YOUNG WIN TECHNOLOGY CO., LTD


Add: Room 1609, Building 4th, Phase 2nd, Tian'anyungu industrial zone, No. 2018
Xuegang road, Bantian street, Longgang district, Shenzhen, China

S-EYE introduction



Resolution and image format


1. Click the arrow beside the Video option, and choose the resolution you need(8 types of resolution)
2. After selecting the resolution, click the Lock icon on the right and lock it. If needing to reselect the resolution, please click the Lock icon first to unlock it then choose it.
3. After locking the resolution, the video and image resolution will keep the same.
4. Image format supports YUV and Motion JPEG



SHENZHEN YOUNG WIN TECHNOLOGY CO., LTD

Add: Room 1609, Building 4th, Phase 2nd, Tian'anyungu industrial zone, No. 2018
Xuegang road, Bantian street, Longgang district, Shenzhen, China

Exposure, Gain and White balance adjustment



SHENZHEN YOUNG WIN TECHNOLOGY CO., LTD

Add: Room 1609, Building 4th, Phase 2nd, Tian'anyungu industrial zone, No. 2018
Xuegang road, Bantian street, Longgang district, Shenzhen, China

1. Exposure

1.1 : If needing auto exposure, please select Auto. Under auto exposure, the exposure time and gain can't be adjusted.

1.2 : If needing manually adjustment, please use the mouse to adjust the exposure time and Gain.

1.3 : Please set the exposure based on your requirements.

2. White balance

2.1 : Support one key White blance

2.2 : Support to use the mouse to adjust the color temperature

2.3 : Default is system's default setting.

SHENZHEN YOUNG WIN TECHNOLOGY CO., LTD

Add: Room 1609, Building 4th, Phase 2nd, Tian'anyungu industrial zone, No. 2018
Xuegang road, Bantian street, Longgang district, Shenzhen, China

Color adjustment



1. Color mode: color/Mono/Invert.
2. Contrast, Saturation, Gamma, Sharpness and denoise can be adjusted based on the requirement(Use the mouse to click up/down key to adjust it.)
3. Default: The factory default

SHENZHEN YOUNG WIN TECHNOLOGY CO., LTD

Add: Room 1609, Building 4th, Phase 2nd, Tian'anyungu industrial zone, No. 2018
Xuegang road, Bantian street, Longgang district, Shenzhen, China

Flip, Miscellaneous



1. Flip

1.1 : Support Mirror, click the mirror icon.

1.2 : Support image flip, click the flip.

2. Miscellaneous: Choose the right frequency (50Hz, 60Hz and Auto)

SHENZHEN YOUNG WIN TECHNOLOGY CO., LTD

Add: Room 1609, Building 4th, Phase 2nd, Tian'anyungu industrial zone, No. 2018
Xuegang road, Bantian street, Longgang district, Shenzhen, China

Others:



Snap : Click the icon and capture the image and save it to the computer.



Video : Click icon to start record, and click again to finish record and save the video to the computer.



Preview : Click the icon will direct to the file that saving the image and video.




Setting : Click the icon and direct to setting menu.

SHENZHEN YOUNG WIN TECHNOLOGY CO., LTD

Add: Room 1609, Building 4th, Phase 2nd, Tian'anyungu industrial zone, No. 2018
Xuegang road, Bantian street, Longgang district, Shenzhen, China

Appearance




1. Interface

- 1.1. Language : Simplified Chinese, Traditional Chinese, English, French, German, Bahasa Indonesia, Japanese, Korean and Russian
- 1.2. Theme : Support Default and dark blue.

2. Keyboard

- 2.1. Can set the full screen shortcuts based on your own requirement
- 2.2. Can set the image capture shortcuts based on your own requirement




Files

1. Can choose pop-up dialog.
2. Can set a pre-defined path
3. File saved format supports jpg, bmp, png and tif
4. After setting, click Apply and then click OK to save it.

SHENZHEN YOUNG WIN TECHNOLOGY CO., LTD

Add: Room 1609, Building 4th, Phase 2nd, Tian'anyungu industrial zone, No. 2018
Xuegang road, Bantian street, Longgang district, Shenzhen, China




Measurement

1. Default tool attributes : Including General tool, calibration scale, Annotation tool, Calculation tool, Plotting scale
2. After selecting the tool, can adjust the line color, width, frame width, text color, text frame color, text background color, font etc.
3. After setting, click Apply and OK to save it

SHENZHEN YOUNG WIN TECHNOLOGY CO., LTD

Add: Room 1609, Building 4th, Phase 2nd, Tian'anyungu industrial zone, No. 2018
Xuegang road, Bantian street, Longgang district, Shenzhen, China




Report

1. Can choose the pop-up dialog

2. Can set pre-defined path.

Others:

Can select Show scale bar by default based on your requirement.



标注编辑

Miscellaneous



1. Can use one push white balance based on your need.
2. When exit, it needs to confirm.
3. Maximize the main window.
4. After setting, if needing to reselect, it has to restart the S EYE.

SHENZHEN YOUNG WIN TECHNOLOGY CO., LTD


Add: Room 1609, Building 4th, Phase 2nd, Tian'anyungu industrial zone, No. 2018
Xuegang road, Bantian street, Longgang district, Shenzhen, China

Calibration edit

Before measurement, please check the microscope magnification and image preview resolution



1. Click the “+” to start the calibration.
2. Choose the corresponding magnification in the Title option
3. Use the mouse to drag the middle line of screen, and adjust it to the actual length. (in following picture is 766.00px)
4. Input the number in the Actual length option based on the actual length, and select the length unit. (The picture is 4.000nm)
5. Calibration will calculate the ratio based on the actual length and pixel length.
6. After confirming, click “OK”



Click the Edit button beside the Calibration, you can delete the set calibration

SHENZHEN YOUNG WIN TECHNOLOGY CO., LTD

Add: Room 1609, Building 4th, Phase 2nd, Tian'anyungu industrial zone, No. 2018
Xuegang road, Bantian street, Longgang district, Shenzhen, China

Measurement tool



Drag : When mouse click the button, can drag the picture displayed on the screen.



Select : When click this button, can select and move the position of the edited line of the picture on the screen.



Delete : When click this button, it has two options-Delete and Delete all. When choose Delete, it will delete the selected item. When choose Delete All, it will delete all items on the screen.



Counter : When click this button, can sort items on the screen by order.



Straight line : Can click anywhere on the screen as start point, and click again to determine the distance between the start and end.



Broken line : Click anywhere on the screen as a start, and click again to determine the distance between start and end, and the second point also is the start of the new line...The measurement is the



Rectangle : Click anywhere on the screen to determine the right-angle, and click again to determine the rectangle area. The result is the rectangle area



Polygon : Click anywhere to determine one angle, and it will increase one angle when click each time.

SHENZHEN YOUNG WIN TECHNOLOGY CO., LTD

Add: Room 1609, Building 4th, Phase 2nd, Tian'anyungu industrial zone, No. 2018
Xuegang road, Bantian street, Longgang district, Shenzhen, China




Parallel lines :Click anywhere to determine the start point, and click again to determine straight line.

Click again to determine the parallel line. , Measure the distance between parallel lines.



Vertical line : Click anywhere as a start point, click again to determine the straight line. Click again to

determine the vertical distance between point and straight line



Angle : Click anywhere as a start point, click again to determine the straight line. Click third time to determine

the second line. Measure the angle between two lines.



Arc : Click anywhere as a start point, click again to determine the line. The third point and second point

determine the second line. When goes through three radians, measure the length of the arc.



Center +Radius : Click anywhere to determine the center of a circle, click again to determine the

distance to center Measure the radius



Two points define a circle :Click any point in the interface to determine the point on the circle. And

then click to determine the diameter distance between two points and the value is the radius.



Three points define a circle :Click any point in the interface to determine the point on the circle. And then click the distance between the diameter and the point. Thirdly, click the distance between the circle

and the second point. The value is the radius.

SHENZHEN YOUNG WIN TECHNOLOGY CO., LTD

Add: Room 1609, Building 4th, Phase 2nd, Tian'anyungu industrial zone, No. 2018

Xuegang road, Bantian street, Longgang district, Shenzhen, China



Two circles radius : Concentric circle: Click to determine the center of the circle at any point

in the interface. Secondly, click to determine the distance between the center of two circles.

Thirdly, click to determine the distance between the center of two circles. Then measuring the radius of the two circles



Center +Radius: Click anywhere to determine the center, click again to determine the circle.

Click third

time to determine another distanced center. Click fourth time to determine another circle.

Measure the



Two points circle : Click anywhere to determine a point of the circle, click again to determine diameter

distance. Click third time to determine the point of another circle, and click fourth time to determine the



Three points circle : Click anywhere to determine a point of a circle, click again to determine the diameter distance. Click on the circle to determine the distance with second point. Repeat the steps above to draw another circle. Measure the distance between two centers of two circles.



Text : After clicking the button, the dialog box will pop up for annotation

SHENZHEN YOUNG WIN TECHNOLOGY CO., LTD

Add: Room 1609, Building 4th, Phase 2nd, Tian'anyungu industrial zone, No. 2018
Xuegang road, Bantian street, Longgang district, Shenzhen, China

FCC Warning Statement:

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement

The antennas used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter.

SHENZHEN YOUNG WIN TECHNOLOGY CO., LTD

Add: Room 1609, Building 4th, Phase 2nd, Tian'anyungu industrial zone, No. 2018
Xuegang road, Bantian street, Longgang district, Shenzhen, China