

# QUICK START GUIDE

## Detail

- > Material: Silicone+ABS
- > Model: Massager
- > Noise: Less than 58db
- > Output voltage current:1A
- > Output Power: 3.7V

1. Long press power button or vibration button 3 seconds to turn on/off and the motor are in the first mode.
2. Short press power button or vibration button to switch frequency when item is turned on.
3. The indicator light flashes when charging, and it is always on after a full charge.

## Cleaning

- > Clean:please clean product with warm water or antibacterial soap
- > Wipe:Dry the product with clean cloth or towel
- > Store:Keep the product in a cool, dry, clean please
- > Attention: Never clean this product with organic cleaner containing alcohol gasoline or acetone, Avoid direct sunlight

## Safety

- > Do not use it at temperature over 167°F/75°C
- > Stop using it when any discomfort occurs
- > It is recommended to use it with water-based lubricant
- > Do not use it if you find the product unsmooth or damaged Keep out of reach or children

## FCC warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction