

FOREWORD


This instruction sheet includes some functions which are usable only when they are preset by your dealer. Ask your dealer for details.

See the operating instructions for details of other functions, and IDAS™ NXDN™ system operations. Ask your dealer for details.


Icom, Icom Inc. and the Icom logo are registered trademarks of Icom Incorporated (Japan) in Japan, the United States, the United Kingdom, Germany, France, Spain, Russia and/or other countries.
IDAS and the IDAS logo are trademarks of Icom Incorporated.
NXDN is a trademark of Icom Incorporated and JVC Kenwood Corporation.
All other products or brands are registered trademarks or trademarks of their respective holders.

Thank you for choosing the IC-F3360DT/IC-F3360DS VHF DIGITAL TRANSCEIVERS or IC-F4360DT/IC-F4360DS UHF DIGITAL TRANSCEIVERS.
READ ALL INSTRUCTIONS carefully and completely before using your transceiver.

SUPPLIED ACCESSORIES



PANEL DESCRIPTION



The illustration is of the 10-key type transceivers.

* Dealer assignable


◇ About the LED indicator

- Lights red while transmitting.
- Lights green while receiving a signal, or when the squelch is open.
- Blinks red when the battery is exhausted.

◇ About the Multi-connector

CAUTION: Attach the connector cover when an optional accessory is not used.

FUNCTION DISPLAY



① SIGNAL STRENGTH INDICATOR

Displays the relative receive signal strength.

② LOW POWER ICON

Appears when low output power is selected.

- When the battery charge decreases to a specified level, low power is automatically selected.

③ AUDIBLE ICON

- Appears when the channel is in the 'audible' (unmute) mode.
- Appears when a matched signal is received.

④ SCRAMBLER ICON

Appears when the Voice Scrambler function is ON.

⑤ SCAN ICON

Appears while scanning.

⑥ MESSAGE ICON

- Appears when a received message (Short Data Message or Status Message) is stored in the stack memory.
- Blinks when an unread message is in the stack memory.

⑦ BELL ICON

Appears when a matched signal is received, depending on the presetting.

⑧ GPS ICON

Appears when position data is received.

⑨ BATTERY ICON

Appears or blinks when the battery charge decreases to a specified level.

Indication				
Battery level	Full	Mid	Charging required	Exhausted Battery

blinks when the battery is over charged.

blinks when the battery is exhausted.

- This icon may not be displayed, depending on the presetting.

⑩ SCAN TARGET CHANNEL ICON

Appears when the scan target channel is selected.

⑪ VOX ICON

Appears when the VOX function is ON.

⑫ ALPHANUMERIC READOUT

Displays the operating channel number, channel name, Menu contents, DTMF code, and so on.

- The display mode automatically switches between one line and two lines.

⑬ KEY ICONS

Displays the assigned function of the [P0], [P1], [P2] and [P3] front panel keys.

⑭ SCAN TARGET ZONE ICON

Appears when the scan target zone is selected.

BASIC OPERATION

◇ Turning power ON

- Before using the transceiver for the first time, the battery pack must be fully charged for optimum life and operation.
- See the back page of this sheet.

- Rotate [VOL] to turn ON the power.

◇ Receiving and Transmitting

Receiving:

- Select a channel.
 - Rotate [Selector].
 - Push [CH U] or [CH D].
 - Push one of the direct channel select keys, [DR 1] to [DR 5].
 - Push the ([1] to [9] or [0]) digit keys to enter the channel number when the Channel Entry function is assigned to the keypad, or after pushing [CHEN].
- When receiving a call, rotate [VOL] to adjust the audio output level to a comfortable listening level.

For your reference:

- [CHEN]: Channel Entry
- [CH U]: CH/GID Up [CH D]: CH/GID Down
- [DR 1]: Direct CH/GID 1 [DR 5]: Direct CH/GID 5
- See the operating instructions for details.

Transmitting:

CAUTION: Attach an antenna before transmitting. Transmitting without an antenna may damage the transceiver.

Wait until the channel is clear to avoid interference.

- While holding down [PTT], speak at a normal voice level.
- Release [PTT] to receive.

IMPORTANT:

To maximize the readability of your signal:

- After pushing [PTT], pause briefly before you start speaking.
- Hold the microphone 5 to 10 cm (2 to 4 inches) from your mouth, then speak at a normal voice level.

BATTERY CHARGING

◆ Charging with the BC-160/BC-171

You can rapidly charge the Li-ion battery pack with the BC-160, or regularly charge the pack with the BC-171.


• Charging time

BC-160: Approximately 3.5 hours for the BP-232WP

BC-171: Approximately 11 hours for the BP-232WP

The following items are additionally required:

- A power adapter (may be supplied with the charger, depending on the charger version) or the OPC-515L/CP-23L DC power cable.




◆ Rapid charging with the BC-119N+AD-106

You can rapidly charge the Li-ion battery pack with the optional BC-119N.

Charging time: Approximately 3.5 hours for the BP-232WP

The following items are additionally required.


- AD-106 charger adapter (purchase separately)
- A power adapter (may be supplied with BC-119N, depending on the charger version) or the OPC-515L/CP-23L DC power cable.



◆ AD-106 installation

You must install the AD-106 CHARGER ADAPTER into the BC-119N DESKTOP CHARGER or BC-121N MULTI-CHARGER before charging any batteries.

- ① Connect the AD-106 and the BC-119N/BC-121N.
- ② Install the AD-106 into the holder space of the BC-119N/BC-121N with the supplied screws.



This illustration shows the BC-119N.


◆ Rapid charging with the BC-121N+AD-106

You can charge up to 6 battery packs with the optional BC-121N.

Charging time: Approximately 3.5 hours for the BP-232WP

The following items are additionally required. (purchase separately)

- Six AD-106 charger adapters
- BC-157S power adapter or the OPC-656 DC power cable



BATTERY CHARGING (Continued)

IMPORTANT: Battery charging caution


Ensure the guide tabs on the battery pack are correctly aligned with the guide rails inside the charger adapter. This illustration is for the BC-160.

CAUTION:

When using the OPC-656 DC power cable

NEVER reverse the polarity when connecting the OPC-656 to a power source. This will ruin the battery charger.

OPC-656: Red line: ⊕, Black line: ⊖



OPTIONS

◆ BATTERY PACKS

• BP-232WP Li-ion BATTERY PACK

Voltage: 7.4 V, Capacity: 2250 mAh (min.) 2300 mAh (typical)

Battery life: (Digital mode) Approximately 14.5 hours

(Analog mode) Approximately 13 hours

When the power save function is set to "Short," and the operating periods are calculated under the following conditions:

TX:RX:standby = 5:5:90

• BP-240 BATTERY CASE

Battery case for six AAA (LR03) alkaline batteries

• BP-261 BATTERY CASE

Battery case for six AA (LR6) alkaline batteries

◆ DC CABLES

• CP-23L CIGARETTE LIGHTER CABLE

Used when charging battery packs through a 12 V cigarette lighter socket. For use with the BC-119N/BC-160/BC-171 chargers.

• OPC-515L/OPC-656 DC POWER CABLES

Used when charging battery packs using a 13.8 V DC power source instead of the power adapter.

OPC-515L: For the BC-119N

OPC-656: For the BC-121N

◆ CHARGERS

• BC-119N DESKTOP CHARGER + AD-106 CHARGER ADAPTER

+ BC-145S POWER ADAPTER

For rapidly charging of battery packs.

A power adapter may be supplied, depending on the charger's version.

Charging time: Approximately 3.5 hours

• BC-121N MULTI-CHARGER + AD-106 CHARGER ADAPTER (6 pcs.)

+ BC-157S POWER ADAPTER

For rapidly charging of up to 6 battery packs simultaneously.

Six AD-106s are required.

A power adapter or a DC power source must be purchased separately.

Charging time: Approximately 3.5 hours

• BC-160 DESKTOP CHARGER + BC-145S POWER ADAPTER

For rapidly charging of battery packs.

A power adapter may be supplied, depending on the charger's version.

Charging time: Approximately 3.5 hours

• BC-171 DESKTOP CHARGER + BC-147S POWER ADAPTER

For regularly charging of battery packs.

A power adapter may be supplied, depending on the charger's version.

Charging time: Approximately 11 hours

◆ BELT CLIPS

• MB-93 SWIVEL BELT CLIP

• MB-94/MB-94R BELT CLIP

Alligator-type belt clip.

• MB-96N/MB-96F LEATHER BELT HANGER

◆ ANTENNAS

• FA-SC56VS/FA-SC57VS/FA-SC73US STUBBY ANTENNAS

Shorter VHF or UHF antennas.

FA-SC56VS: 150–162 MHz FA-SC57VS: 160–174 MHz

FA-SC73US: 450–490 MHz

• FA-SC25V/FA-SC55V/FA-SC25U/FA-SC57U/FA-SC72U FLEXIBLE ANTENNAS

VHF or UHF antennas.

FA-SC25V: 136–150 MHz FA-SC55V: 150–174 MHz

FA-SC25U: 400–430 MHz FA-SC57U: 430–470 MHz

FA-SC72U: 470–520 MHz

• FA-SC61VC/FA-SC61UC CUT ANTENNAS

FA-SC61VC: 136–174 MHz FA-SC61UC: 380–520 MHz

• FA-SC62V/FA-SC63V HIGH GAIN ANTENNAS

FA-SC62V: 150–160 MHz FA-SC63V: 155–165 MHz

◆ OTHERS

• AD-118 ACC ADAPTER

Allows you to connect an accessory. See the AD-118 instruction sheet for details of recommended accessories.

CAUTION: The AD-118 does not have waterproof protection. When it is connected, **NEVER** expose the adaptor and the transceiver to rain, snow or any liquids.

• HM-184/HM-184H SPEAKER MICROPHONE

Rugged type speaker microphone.

The HM-184 and HM-184H meet IP67 requirements for waterproof protection.

• VS-4MC PTT SWITCH CABLE + HS-94/HS-95/HS-97 HEADSET

VS-4MC: Used to connect a headset to a transceiver.

HS-94: Ear-hook type

HS-95: Neck-arm type

HS-97: Throat microphone

The VS-4MC meets IP54 requirement for splash resistance. When it is connected, the transceiver corresponds to IP54.

• MB-130 VEHICLE CHARGER BRACKET

Mounts the BC-160 DESKTOP CHARGER in variety of places in the vehicle.

Approved Icom optional equipment is designed for optimal performance when used with an Icom transceiver.

Icom is not responsible for the destruction or damage to an Icom transceiver in the event the Icom transceiver is used with equipment that is not manufactured or approved by Icom.

Some options may not be available in some countries. Please ask your dealer for details.