

IC-V8 ADJUSTMENT PROCEDURES

5-1 PREPARATION

When adjusting the contents on page 4 or 5, SOFTWARE ADJUSTMENT, a CS-V8 ADJ ADJUSTMENT SOFTWARE (Rev. 1.0 or later), OPC-478 CLONING CABLE and a JIG CABLE are required.

■ REQUIRED TEST EQUIPMENT

EQUIPMENT	GRADE AND RANGE	EQUIPMENT	GRADE AND RANGE
DC power supply	Output voltage : 7.2 V DC Current capacity : 5 A or more	Audio generator	Frequency range : 300–3000 Hz Output level : 1–500 mV
RF power meter (terminated type)	Measuring range : 1–10 W Frequency range : 120–500 MHz Impedance : 50 Ω SWR : Less than 1.2 : 1	Attenuator	Power attenuation : 40 or 50 dB Capacity : 10 W or more
Frequency counter	Frequency range : 0.1–500 MHz Frequency accuracy : ± 1 ppm or better Sensitivity : 100 mV or better	Standard signal generator (SSG)	Frequency range : 120–500 MHz Output level : 0.1 μ V–32 mV (–127 to –17 dBm)
FM deviation meter	Frequency range : DC–500 MHz Measuring range : 0 to ± 5 kHz	DC voltmeter	Input impedance : 50 k Ω /V DC or better
Digital multimeter	Input impedance : 10 M Ω /V DC or better	Oscilloscope	Frequency range : DC–20 MHz Measuring range : 0.01–20 V
		AC millivoltmeter	Measuring range : 10 mV–10 V

■ SYSTEM REQUIREMENTS

- IBM PC compatible computer with an RS -232C serial port (38400 bps or faster).
- Microsoft Windows 95 or Windows 98
- Intel i486DX processor or faster (Pentium 100 MHz or faster recommended)
- At least 16 MB RAM and 10 MB of hard disk space
- 640×480 pixel display (800×600 pixel display recommended)

■ ADJUSTMENT SOFTWARE INSTALLATION

- ① Boot up Windows.
- Quit all applications when Windows is running.
- ② Select 'Run' from the [Start] menu.
- ③ Type the setup program name using the full path name, then push the [Enter] key. (For example; D:\ setup)
- ④ Follow the prompts.
- ⑤ Program group 'CS-V8 ADJ' appears in the 'Programs' folder of the [Start] menu.

■ STARTING SOFTWARE ADJUSTMENT

- ① Connect IC-V8 and PC with the optional OPC-478 and the JIG cable.
- ② Boot up Windows, and turn the transceiver power ON.
- ③ Click the program group 'CS-V8 ADJ' in the 'Programs' folder of the [Start] menu, then CS-V8 ADJ's window is appeared.
- ④ Click 'Connect' on the CS-V8 ADJ's window, then appears IC-V8's up-to-date condition.
- ⑤ Set or modify adjustment data as desired.

WARNING: After finished adjustments, IC-V8 must be operated as follow operation. Otherwise, the transceiver does not work properly.

- ①: Turn power OFF.
- ②: Push and hold the [D] and MONI keys, and then turn power ON.


IBM is a registered trademark of International Bussiness Machines Corporation in the U.S.A. and other countries. Microsoft and Windows are registered trademarks of Microsoft Corporation in the U.S.A. and other countries. Screen shots produced with permission from Microsoft Corporation. All other products or brands are registered trademarks or trademarks of their respective holders.

5-2 PLL ADJUSTMENT

ADJUSTMENT		ADJUSTMENT CONDITIONS	MEASUREMENT		VALUE	ADJUSTMENT	
			UNIT	LOCATION		UNIT	ADJUST
PLL LOCK VOLTAGE	1	- Operating frequency : 145.000 MHz - Receiving	MAIN	Connect a digital multi meter to check point LV.	2.7 V	MAIN	L33

5-3 SOFTWARE ADJUSTMENT

Select an operation using [↑] / [↓] keys, then set specified value using [←] / [→] keys on the connected computer keyboard.

ADJUSTMENT		ADJUSTMENT CONDITION	MEASUREMENT		VALUE
			UNIT	LOCATION	
REFERENCE FREQUENCY [TXF]	1	- Operating frequency : 145.000 MHz - High/Low switch : Low - Connect the RF power meter or 50 Ω dummy load to the antenna connector. - Transmitting	Top panel	Loosely couple a frequency counter to the antenna connector.	145.00000 MHz
OUTPUT POWER [POWER(HI)]	1	- Operating frequency : 146.000 MHz - High/Low switch : High - Transmitting	Top panel	Connect an RF power meter to the antenna connector.	5.5 W
NOTE: Low power is adjusted automatically when High power' adjustment is finished.					
FM DEVIATION [MOD]	1	- Operating frequency : 146.000 MHz - High/Low switch : Low - Connect the audio generator to the [MIC] jack and set as: 1.0 kHz/150 mVrms - Set the FM deviation meter as: - HPF : OFF - LPF : 20 kHz - De-emphasis : OFF - Detector : (P-P)/2 - Transmitting	Top panel	Connect an FM deviation meter to the antenna connector through the attenuator.	± 4.2 kHz
DTCS WAVE FORM [DTCS BAL]	1	- Operating frequency : 146.000 MHz - High/Low switch : Low - No audio applied to the [MIC] jack. - DTCS code : 007 - Transmitting	Top panel	Connect an FM deviation meter with an oscilloscope to the antenna connector through an attenuator.	Set to flat wave form 

SOFTWARE ADJUSTMENT – continued

Select an operation using [$\uparrow$] / [$\downarrow$] keys, then set specified value using [$\leftarrow$] / [$\rightarrow$] keys on the connected computer keyboard.

ADJUSTMENT	ADJUSTMENT CONDITION		MEASUREMENT		VALUE
			UNIT	LOCATION	
RX SENSITIVITY (BPF T1 – BPF T3) [BPF Low]	1	- Operating frequency : 136.000 MHz - Connect a standard signal generator to the antenna connector and set as: Frequency : 136.000 MHz Level : 1 μV* (–107 dBm) Modulation : 1 kHz Deviation : ±3.5 kHz - Receiving	Top panel	Connect a SINAD meter with an 8Ω load to the [SP] jack.	Minimum distortion level
[BPF Mid]	2	- Operating frequency : 136.000 MHz - Set the SSG's frequency as: 136.000 MHz - Receiving			Minimum distortion level
[BPF High]	3	- Operating frequency : 174.000 MHz - Set the SSG's frequency as: 174.000 MHz - Receiving			Minimum distortion level
CONVENIENT: The BPF T1–BPF T3 can be adjusted automatically. ①-1: Set the cursor to “BPF ALL” on the adjustment program and then push [ENTER] key. ①-2: The connected PC tunes BPF T1–BPF T3 to peak levels. or ②-1: Set the cursor to one of BPF T1, T2, or T3 as desired. ②-2: Push [ENTER] key to start tuning. ②-3: Repeat ②-1 and ②-2 to perform additional BPF tuning.					
SQUELCH LEVEL [SQL]	1	- Operating frequency : 146.000 MHz - Squelch level : 1 - Connect a standard signal generator to the antenna connector and set as: Frequency : 146.000 MHz Level : 0.11 μV* (–126 dBm) Modulation : 1 kHz Deviation : ±3.5 kHz - Receiving	Top panel	Connect a SINAD meter with an 8Ω load to the [SP] jack.	12 dB SINAD
	2	Receiving			At the point where the audio signals just appears.
S-METER [S-METER]	1	- Operating frequency : 146.000 MHz - Connect a standard signal generator to the antenna connector and set as: Frequency : 146.000 MHz Level : 0.4 μV* (–115 dBm) Modulation : 1 kHz Deviation : ±3.5 kHz - Receiving	S-METER is adjusted automatically by CS-V8 ADJ.		

*The output level of the standard signal generator (SSG) is indicated as the SSG's open circuit.