



Full Screen

- 1 Drag and drop an app to the top end of the screen to change the app to the full screen size.





- 2 Drag and drop the app again to a different location to return to its original size.

Screen Split into Two



- 1 Drag and drop an app to the right end or left end to reduce the size by half.



The screen is split according to the guideline.



2 Select a running app displayed in the preview on the split screen.




3 Drag and drop the app again to a different location to return to its original size.

Screen Split into Four

- 1 Drag and drop an app to the left corner to reduce the app to 1/4 size of the screen.





The screen is split according to the guideline.



2 You can use this method to place up to four apps on the screen.

ENGLISH



3 Drag and drop the app again to a different location to return to its original size.

Using the Store

You can purchase apps or get free apps from Windows Store.



TIP

If a local account is being used, a window to switch to a **Microsoft** account appears while using Windows Store. Follow the instructions on the screen to switch the local account to a **Microsoft** account.

You can also do so by selecting [Start menu] > [Account] > [Change Account Settings].


If you switch to a **Microsoft** account, your PC settings (background, user settings, etc.) may be changed to the previous settings.

- 1 Press the  button to move to the Start menu and select the **[Microsoft Store]** tile.




TIP

Press the  key or [Ctrl] + [Esc] to display the Start menu.



- 2 Select the app or use the search function on the store screen to install the desired app.




Switching to Tablet Mode

If you are using Windows on a tablet PC, you can easily switch to the tablet mode.


- 1 Press the Action Center [] icon on the right side of the taskbar.



- 2 Select **[Tablet mode]** to switch Windows to tablet mode.



- 3 Select **[Tablet mode]** again to deactivate the mode.



Unlocking the Screen

If the PC is not used for an extended period, it goes into a locked state.

When the PC is used again, a lock screen appears for security purposes and may be unlocked by using the following method.

- 1 From the lock screen, press any key on the keyboard or drag up while you click and hold the mouse button.



- 2 When the login window appears, enter the password and click [Enter].
(If no password is set, press the login button to immediately unlock the screen.)

Setting the PC

Windows 10 supports various functions so that the user can change the PC setting easily and quickly.

Using Action Center

You can use the Action Center to easily change the settings for tablet mode, display, media connection and network settings.

The functions supported by the Action Center may differ depending on the model.

- 1 Press the Action Center [] icon on the right side of the taskbar.



2 Change the PC settings as needed.

TIP

If the tile does not appear, press the [Expand] menu.


[Rotation lock] tile is activated when in the tablet PC mode.




CAUTION

Using the **Reader Mode** and the **Night light** at the same time can cause color distortion.

If color distortion occurs, deactivate the **Reader Mode** or the **Night light**.




- 3 To change the detailed settings of the PC, press the **[All settings]** tile.




Using the Start Menu

- 1 Press the  button and select the **[Settings]** menu.



- 2 When the screen for PC's detailed settings appears, select and change the settings as needed.




Windows Shutdown Option

In Windows 10, you can use the Windows shutdown option by following these steps:

- 1 Click the  button and select the **[Power]** menu.

TIP

Press the  key or [Ctrl] + [Esc] to display the Start menu.



- 2 Select a Windows shutdown option.

TIP

On the Desktop screen, press [Alt] + [F4] to use the Windows shutdown option.
(Pressing [Alt] + [F4] on a running app may end the app.)

Using the PC

Charging the Product / Using the Tablet PC Mode

Connect the AC adapter to power and charge the product.

TIP

The power cable and the AC adapter type may differ per model type and country and there is no difference in functionality.

This product has a built-in battery pack.

The internal battery should not be arbitrarily disassembled or replaced. Arbitrarily disassembling the product may void the warranty.

If you need to disassemble or replace the battery, please visit the designated LG Electronics Service Center.

We charge a fee for removing or replacing the battery.

Using an AC Adapter

An AC adapter of 100 V to 240 V can be used.

- 1 Connect the AC adapter to a power outlet.
- 2 Connect the AC adapter to the PC.
- 3 Adjust the LCD to the most comfortable angle.
- 4 Press the PC's power button to turn on the system.



CAUTION

Do not leave a liquid container on the PC.

- The system may be short-circuited and damaged.

**WARNING**

Please use an AC adapter certified by LG Electronics Inc.


- Uncertified batteries may explode.
- It may cause a problem in battery charging or system operation.

When you use an AC adapter, follow the below directions.


- 140 °F or more high-humidity spaces, for example, inside cars or saunas, should be avoided when you use or store it.
- Do not disassemble or modify the AC adapter.
- Do not twist the AC adapter plug.
- When you connect the AC adapter, do not forcefully push the plug.

Using Tablet PC Mode

- 1 Unfold the notebook and rotate the LCD as shown in the picture to use it as a tablet PC.



- 2 When the 'Switching to tablet mode' message appears on the Windows screen, press [Yes] to switch to tablet mode.

**CAUTION**

- When packing or moving the product, close the LCD panel to protect it.
- Be careful not to pinch your fingers between the PC main body and the LCD panel.
- Do not rotate the LCD panel with excessive force. This may damage the hinge connecting the PC body and the LCD panel.
- In tablet PC mode, the keyboard faces the bottom of the product. Clean around the product to prevent the keyboard and PC body from being damaged.

TIP

- In tablet PC mode, the screen is automatically rotated according to the current screen angle.
- To leave sleep mode (LCD off), press the power button or sleep button ().

**Checking the Battery State**

- 1 Connect the AC adapter to the power port in the PC.



- 2 Open the LCD and check the charging state.
When the AC adapter lamp is blinking, charge it fully with the AC adapter before using it.

**CAUTION**

Use batteries certified and acknowledged by LG Electronics Inc.

- Uncertified batteries may explode.

**WARNING**

The battery may explode or cause a fire due to excessive heat. For a safe and efficient use of the battery, follow the directions below.

- Do not short-circuit the battery.
- Keep the battery out of reach of children.
- A visible swelling of the battery pack indicates a possible danger. When this occurs, contact your local vendor or service center immediately.
- Use only a certified and designated recharger.
- Keep the battery pack away from heat. (Never put it in a microwave.)
- Do not leave inside a car under the summer heat.
- Do not leave or use at a hot and humid place like a sauna.
- Do not use the machine placed on a heating blanket or other heat reserving materials.
- Do not leave the machine turned on inside a closed space.
- Make sure that the battery ports are not touched by any metallic objects like a key, coin, necklace, and watch.
- Use only a lithium secondary battery certified and guaranteed by mobile device manufactures.
- Do not disassemble or modify the battery. Do not compress or pierce the battery.
- Do not apply shock to the battery. For example, do not drop the battery from a high place.
- Keep the room temperature between 23 °F and 104 °F. Do not expose the PC to heat hotter than 140 °F.
- Keep the machine dry.
- Do not discard the battery arbitrarily as you are requested to follow the local procedure for discarding the battery.
- Before using this machine, read this guide carefully.

**TIP****When the PC is not to be used for a long period of time, refer to the following:**

- Check the battery charge level on a regular basis and keep it at 50 %. This allows you to extend the battery life.
- If the battery is left fully charged for an extended period of time, the battery capacity and battery running time may be reduced.
- Keeping battery fully discharged for an extended period of time may cause the battery to become over discharged, thereby making charging unavailable.

For more efficient use of the battery, read the following carefully.

- The battery runs low naturally even if it is kept unused.
- To increase battery lifespan, use the battery for a while before charging it rather than keeping the battery completely charged.
- If you don't use the product for a long time with the battery completely charged, the battery lifespan may decrease.

The battery capacity may change due to chemical reactions during charge and discharge.

- LG Notebook frequently checks the charge level of its battery based on usage conditions, and then calculates and correctly indicates the actual remaining level of the battery.
- The battery is wearable goods and thus the life span may become shorter with use. The battery running time may also become shorter accordingly.
- When the battery is fully charged, the machine stops recharging. It resumes recharging when the battery charge rate drops below 95%. This feature secures the safe and efficient use of the battery.
- When the temperature of the battery drops below 50 °F, it is charged in a low current to protect the battery cells. In this case, charging time may stretch to up to 32 hours.

If you use the system at a low temperature, refer to the following:

- The battery capacity may be reduced depending on the chemical characteristics of the battery and the system may not be turned on after it freezes or it is turned off.
- If the system freezes or if it is not turned on, connect the AC adapter to the system and charge the battery fully before use.
- If there is any error in the indication of the battery capacity, charge and discharge the battery two or three times at room temperature to return to the normal operation.

Operation Status Lamps



1 AC Adapter Lamp

- On: The AC adapter is connected.
- Off: The AC adapter is not connected.

If you try to turn on the system that has entered the Hibernate mode or been turned off after a low-battery alarm, the system will not be turned on but the lamp will blink three times. If this is the case, connect the AC adapter and charge the battery sufficiently before using it.

2 Storage Device (HDD, SSD, eMMC) Indicator Lamp

- When the PC accesses the storage device, the indicator lamp turns on.

Do not turn off the power forcibly while the storage device indicator lamp is on or blinking. Otherwise, the disk or its data may get damaged.

3 Power Lamp

- On: The system is on and running by the AC adapter or battery.
- Off: When the system is turned off or in Hibernate mode
- Blinking: The system is in the standby mode.

4 Caps Lock Lamp

- On: When the **Caps Lock** is activated
- Off: When the **Caps Lock** is deactivated

5 Touchpad Lamp

- On: When the touchpad is activated
- Off: When the touchpad is deactivated

6 Reader Mode Lamp

- On: When reader mode is activated
- Off: When reader mode is deactivated

7 Webcam Operation Status Lamp

- On: When the webcam is operating
- Off: When the webcam is not operating

Keyboard

The keyboard allows the user to input data or give commands.

The keyboard may differ in appearance and color depending on your country.



CAUTION

- Spilling a watery substance like coffee or juice on the keyboard may cause a fault, malfunction, or electric shock.
- The keys may not work properly when you use several keys at the same time while playing a PC game.
- Either change the key combination settings according to the combinations necessary for the game play or use an external keyboard dedicated for the game which supports infinite simultaneous inputs.

Using Hot Keys

You can use the hot keys shown below to use the PC conveniently.

Fn + F1	Executes LG Control Center .
Fn + F2	Decreases LCD brightness, which can have eleven different levels.
Fn + F3	Increases LCD brightness, which can have eleven different levels.
Fn + F4	Runs the mode defined in Windows Sleep Mode . (Example: Standby Mode, Hibernate Mode)
Fn + F5	Every time you press [Fn] + [F5], the mode switches between Touchpad Off (touchpad is disabled) and Touchpad On (touchpad is enabled). To set Touchpad Auto (touchpad is disabled when an external USB mouse is inserted), press the  button and disable [Turn on touchpad when a mouse is connected] under [Settings] > [Device] > [Touchpad]. Every time you press [Fn] + [F5], the mode switches between Touchpad Off and Touchpad Auto.  TIP Since it takes about 1 to 2 seconds to initialize after switching to the touchpad function, we recommend you to use the device after initialization is completed.
Fn + F6	Airplane Mode ON/OFF (Wireless LAN and Bluetooth OFF/ON)
Fn + F7	Switches between monitor and projector.

Fn + F8	Switches the Keyboard Backlight mode.
Fn + F9	Switching to Reader Mode
Fn + F10	Mute
Fn + F11	Turns down the volume.
Fn + F12	Turns up the volume.
Fn + Prt Sc	Works as the Scroll Lock [Scr Lk] key.
Fn + Delete	Works as the [Insert] key.
Fn + Ctrl	Works as the [Pop-up Window] key.
Fn + ◀	Works as the [Home] key.
Fn + ▶	Works as the [End] key.
Fn + ▲	Works as the [Page Up] key.
Fn + ▼	Works as the [Page Down] key.

Shortcut Keys

TIP

- To change the input mode temporarily, you can press the [Shift] key together with the letter you want to enter. By doing so, you can enter an uppercase letter when the **Caps Lock** key is not pressed and a lowercase letter when it is pressed.

To use Windows more conveniently, remember the following Windows key combinations:

-  + R
Displays an input window for program execution.
-  + Tab
Displays the running desktop in the preview.
-  + M
Minimizes the current window.

Keyboard Backlight

You can set the **Keyboard Backlight** function to use the product in a dark environment.

The figures herein are subject to change without prior notice.



OPTION

This only applies to the products that have the **Keyboard Backlight** function.

Configuring Keyboard Backlight




TIP


You can use hot keys to use the **Keyboard Backlight** function more conveniently.

- Each time you press the [Fn] + [F8] keys, the status changes to **KBD Backlight Off**, **KBD Backlight Low**, and then **KBD Backlight High** in the specified order.

- Select the [Windows] button > [LG Software] to run [LG Control Center].
- On the **LG Control Center** screen, select the [System Settings] menu.



- 3 Go to **Keyboard Backlight** and select your desired options.



Adjusting Screen Brightness and Volume

LG PC allows you to use the hot keys to easily adjust the screen brightness and volume.



TIP

According to the model type, a button for volume control (mute, volume up / down, DTS, etc.) may be available.

Function	Hot Keys	Description
Screen Brightness	[Fn] + [F2], [F3]	Press the [F2] key to darken the screen or the [F3] key to brighten it. Press the Action Center  icon on the right side of taskbar to run the Action Center. Press the  tile to adjust the screen brightness.
Volume	[Fn] + [F11], [F12]	Press the [F11] key to lower the volume or [F12] key to increase the volume. Press the  icon on the right side of the taskbar to adjust the volume.
Mute	[Fn] + [F10]	Press the button to turn on or off the mute feature. Press the  icon on the right side of the taskbar to mute the sound.

Locking / Unlocking Screen Rotation

- 1 Press the Action Center [] icon on the right side of the taskbar.




- 2 Press **[Rotation lock]** tile to lock the screen rotation.



TIP

[Rotation lock] tile is activated when in the Tablet PC mode.



Hearing Protection Feature

The product is equipped with a hearing protection function to protect your ears from high sound volume while using an earphone or headphone.

The hearing protection function is set to OFF by default. You can turn on/off the hearing protection function as follows:

- 1 Click [] button > [SmartAudio 2] button to execute **SMART Audio**.

 TIP

It may take 2 to 5 minutes to execute the function for the first time due to the initial settings.



- 2 If an earphone or headphone is connected, the picture on the screen changes to a picture of headphone.



- 3 Whenever you touch the headphone image, the hearing protection function turns on or off.
- Hearing protection function OFF



- Hearing protection function ON




**TIP**

When the hearing protection function is on, a warning message appears if the sound is set to a high volume.

Using the Touchpad

The built-in touchpad provides the same functionality as an external mouse. You can use the touchpad and USB mouse simultaneously.



- 1 Touchpad
 - Moves the cursor.
- 2 Left button
 - Use to select or execute programs.
- 3 Right button
 - Functions as the right button of a mouse in most cases. However, the usage may differ depending on programs.




TIP

Scroll function is offered through gestures. Refer to the description about touch pad gestures below.


Moving the Cursor (Pointer) on the Screen

Place a finger on the touchpad and glide the finger.

**Click (Select)**

Press and release the left button swiftly with a finger. (Or tap the touchpad once.)

Do this, for example, to select a menu or icon and to place the cursor to type on a word processor file.




or

**Double-click (Execute)**

Press the left button twice consecutively and release the button. (Or tap the touchpad twice.)

Do this, for example, to run a program after selecting its execution file (or icon).



CAUTION


Notes on Using the Touchpad

- Do not use a sharp object such as a pen on the pad nor peel the cover. It may cause an impairment.
- Do not place more than one finger, and do not use while wearing a glove or when the hand is wet. The Touchpad will not work properly. Oil or dirt at the fingertip can also cause an impairment.
- The touchpad is sensitive. Do not impose excessive force or maintain an uncomfortable position. Otherwise, it may result in a finger or wrist injury.

Right button

Press and release the right button swiftly.

Functions as the right button of a mouse, but the usage may differ depending on programs.




Drag & Drop

To drag, click and hold an icon, and move it to another location.

To drop, release the dragged icon in the location you want.

To move a file icon to another folder or to **Recycle Bin**, place the cursor (or the pointer) on the icon, press and hold the left button, and glide another finger on the touchpad until the icon reaches the aimed location. After reaching the destination, release the left button.



1 Drag

- Glide one finger on the pad with another finger pressing and holding the left button.

2 Drop

- Release the left button to drop it into the **Recycle Bin**. (By using this, you can drop a file into the **Recycle Bin** at will.)

ClickLock


When activated, this feature allows you to drag/scroll without pressing and holding the left button.

- 1 Click the [] button and select the Settings menu.


**TIP**

Press the [] key or [Ctrl] + [Esc] to display the Start menu.


ENGLISH




- 2 When the [Settings] screen appears, select [Devices].




- 3 Select [Mouse] > [Additional mouse options].




- 4 When [Mouse Properties] screen appears, select [Turn on ClickLock].




- 5 Press [Settings] to set the time for the ClickLock.



- 6 Press the left button of the touchpad and release it to change the button into the pressed state.



- 7 Move on the touchpad to use the drag/scroll feature.



- 8 Press the left mouse button to turn off the ClickLock.


Touchpad Gesture

The touchpad gesture feature allows you to use Windows programs more easily by utilizing multi-touch functions.


In Windows 10, touchpad gestures allow you to use the PC more easily.

The touchpad gesture feature may not be supported in some models.

- Place two fingers on the touchpad and move up/down/left/right to scroll the screen.
(It operates only on an app or screen which scrolling is available.)



- Place two fingers on the touchpad and widen or narrow them to zoom out or in.



Setting Touchpad


You can change the touchpad features or enable/disable the gesture feature.

The figures herein may differ by language selection and are subject to change without prior notice.


- 1 Click the [] button and select the Settings menu.

TIP


Press the [] key or [Ctrl] + [Esc] to display the Start menu.



- 2 When the [Settings] screen appears, select [Devices].



- 3 Change the settings as needed on the [Touchpad] menu.




Using Touch Panel

Use the touch panel for a faster and more convenient use of the PC. All gestures provided by Windows 10 can be used.


For more details about the Windows 10 gestures, refer to Windows help.

Basic Usage


- 1 **Touching Once:** Touch the panel once to use as left mouse button.




- 2 **Touching Twice:** Touch the panel twice to use as double-click.



- 3 **Drag:** After touching the start point, finger movement can be used instead of the mouse.




- 4 **Touching Longer:** Touch the panel for a longer time to use as right mouse button.



Using the Touch Keyboard

- 1 Right-click the task bar and select [Show touch keyboard button].


- 2 Press the [] icon on the right side of taskbar to display the [Keyboard] screen as shown below.



Using Stylus Pen

If you use a **Stylus Pen** for 14T990 model, you can perform more precise touch control than when using fingers.

Name of Each Part



1 Pen tip

- Performs the same function as a mouse cursor.

2 Left mouse button

- Use to select or execute programs.

3 Right mouse button

- Performs the same function as a right mouse button.

4 Pen cap

How to Use

Buttons on the **Stylus Pen** basically have the same functions as mouse buttons and their functions may change depending on the program used.


TIP

The **Stylus Pen** requires some pressure to work.


The **Stylus Pen** automatically enters the sleep mode if the pen is not used for more than 10 minutes or the **pen tip** is pressed for more than 4 minutes.

To leave sleep mode, simply touch the screen with the **Stylus Pen** or click any of the mouse buttons.


- 1 **Click:** Touch a screen with the **Stylus Pen** once to use it as a left mouse click.



- 2 **Double Click:** Touch a screen with the **Stylus Pen** twice to use it as a double click.




- 3 **Drag:** Move the **Stylus Pen** while pressing the screen with it to use it as a mouse drag function.




Drawing a Picture

You can draw a picture with a **Stylus Pen** using the **Paint** program, which is supplied with Windows 10, or a painting app that you purchased separately.

- 1 Click [] button > **[Paint 3D]** to execute the program.



- 2 Select a brush type and size in the **Paint** app and draw a picture freely just like drawing a picture with a pencil.



Inserting and Replacing Batteries

1.5V batteries of an **AAAA** size is provided with the product. Insert the batteries before using the pen as follows.

TIP

If the battery level is low, the pen operation may be interrupted or the pen may not be recognized.

If the batteries have not been replaced for a long time, replace the batteries before using the pen.

AAAA-size batteries can be purchased through an on-line shopping mall.



CAUTION

If a battery of incorrect specifications or a rechargeable battery is used, the normal operation is not guaranteed.

If the pen is not used for a long period of time, store the pen after removing the batteries. Otherwise, the battery liquid may leak and cause a failure.

If excessive force is applied when inserting the batteries, the pen may get damaged.



If the pen is stored or moved with the **pen tip** pressed, it may cause the batteries to discharge quickly.

If you apply excessive shock to the pen or drop it, it may cause a failure.

- 1 Hold the **pen cap** and turn it in the direction of the arrow to disassemble it.





- 2 After inserting batteries in the correct direction, close the **pen cap** by turning it in the direction of the arrow.
 - When replacing batteries, remove the existing batteries and do the same as above.



Inserting a Rubber Ring

A **rubber ring** prevents the **Stylus Pen** from rolling on a flat surface such as a desk. Insert a **rubber ring** as described below if necessary.

- 1 Insert a **rubber ring** in the direction of the arrow on a place you desire.




Replacing the Pen Tip

A replacement **pen tip** is provided with the product. You can replace the **pen tip** using the method described below.

TIP

If the **pen tip** wears out, replace it.


- 1 Use a **tweezer** to grab the end of the **pen tip**, and pull toward the direction of the arrow to separate it from the **Stylus Pen**.



- 2 Insert a replacement **pen tip** to the **Stylus Pen**.

**CAUTION**

If you push the **pen tip** with excessive force or insert it in the opposite direction, it may cause a failure.



Connecting to External Display

Connecting to the HDMI Port

HDMI is a high-speed multimedia interface that can transfer uncompressed full digital audio and video signals.

In some models, DTS Audio may not work when you use HDMI.



TIP

Ensure the monitor power is off before connecting the external monitor to the PC.

- 1 Connect the HDMI cable to the PC and the external device (TV, monitor) that supports HDMI.
- 2 HDMI port transfers both video and audio simultaneously. Hence, there is no need for a separate audio connection.



- 3 On the PC, press [Fn] + [F7] to display monitor (projector) toggling screen. Select the desired screen output.



TIP

- Every time [] + [P] keys are pressed, the screen output option changes. Release the keys to display the selected screen output.

**CAUTION**

- If you do not set Speaker as the default value after disconnecting the HDMI cable, the system may not produce any sound.
- If a program was running already, you must exit and restart the program to produce sound.

Connecting to Wireless Display

The wireless display feature connects the PC screen and sound to a display (TV, projector, etc.).



OPTION

- To use the wireless display feature, the display device must support this feature.
- To connect to the display device that does not support wireless display, you must separately purchase a wireless display connection device.
- Once the wireless display connection is established, no additional procedures and searching are necessary the next time you try to connect.

Connecting to Wireless Display


- 1 Press the Action Center [] icon on the right side of the taskbar.




2 When the Action Center screen appears, press the **[Connect]** tile.




If the tile does not appear, press the [Expand] menu.



3 Search for wireless display devices in the proximity.



- 4 If the device is connected as shown below, the PC screen and sound are produced on the wireless display device.



Connecting an External USB-C™ Device

The USB-C™ port mounted on this product supports USB 3.1 Gen 2 standards.

Use the USB-C™ port to connect USB devices or to output a screen to an external display.

Connecting a USB Device

If a USB device is connected to a USB-C™ port, the port works as an ordinary USB port.



TIP

To use a conventional USB device, a separate conversion adapter should be used.
(Conversion adapters may be purchased separately.)

Outputting to an External Display

By connecting a display that supports USB-C™ Alternate Mode, you can use the USB-C™ port to output a screen to an external display.



TIP

The Alternate mode allows you to use the DP (Display Port) and HDMI display outputs through the USB-C™ port.

We support DP (Display Port) interface standards.



CAUTION

You must use a cable that supports **Alternate Mode** to output a screen to another display.

If you use USB-C™ accessories (cables, interface adapters, etc.) that are used for other products, you may have compatibility problems (no screen output or a malfunction).

Using USB-C™ Charging Function

You can connect a USB-C™ device to charge a notebook PC battery or other external devices.

- To charge a notebook PC battery, the external device (USB PD charger, notebook PC, etc.) should support USB Power Delivery 10 W (5 V / 2 A) or higher profile.
- The external devices that use the USB-C™ port can be charged at 10 W (5 V / 2 A), 15 W (5 V / 3 A), and 18 W (9 V / 2 A).
- A USB PD (Power Delivery) device supports charging at 15W (5V / 3A) or 18W (9V / 2A) when connected, whereas a regular USB device supports charging at 10W (5V / 2A).
- If the remaining battery level of the notebook PC is 10% or less, both USB PD device and regular USB device only support charging at 10W (5V / 2A).
- Always-On Charging is supported only with USB-C™ ports, but not with the regular USB ports.
- If you connect an AC adapter while the notebook PC is being used to charge an external device, it may take more time to charge the notebook PC.

Using the Charging Function

LG Control Center can be used to set one of the three charging functions: Automatic, Sink and Source.



TIP

For information on how to use **LG Control Center**, refer to [Using Software] > [].

1 Automatic

The operation mode is automatically selected depending the charge settings of the connected device.

- When the connected device is set to Automatic (Charging the notebook PC or a connected device. Charging the notebook PC by using the mobile phone is not supported.)



- When the connected device is set to Source (the notebook PC is charged.)



- When the connected device is set to Sink (the connected device is charged.)



2 Sink

The connected device is used to charge the notebook PC.



TIP

If the connected device is set to Sink, the charging function does not work.



3 Source

The notebook PC is used to charge the connected device.



TIP

If the connected device is set to Source, the charging function does not work.



TIP

The charging status of the external device being charged is not displayed on the notebook PC. If you connected a smartphone, you should select "Charge mobile phone" on the smartphone screen to charge the phone battery.



CAUTION

When you set the charging function for a USB-C™ port in **LG Control Center**, beware of the following:

- If you changed the charge setting, it is recommended that you remove the USB-C™ cable and re-connect it.
- If you restart the system or turn off the power, the charge setting is changed to [Automatic].
- If the charge setting is set to [Sink], some of the devices connected to the USB-C™ port may not work properly.
- Always-On Charging only supports the ON (automatic) and OFF options.
- If the power consumption of the notebook PC is larger than the power supply from the external device, the battery may be consumed gradually.

Bluetooth

Bluetooth allows the user to access wirelessly various devices such as camera, cell phone, headset, printer, and GPS receiver that support Bluetooth . It can also establish a network and exchange data with other Bluetooth -enabled PC or smartphone.

OPTION

The Bluetooth device is optional, and it may not be available in some models.


The figures herein may differ by language selection and are subject to change without prior notice.

For details on connecting a Bluetooth device, refer to the user manual that came with the Bluetooth device.


- 1 Click the  button and select the Settings menu.

TIP



Press the  key or [Ctrl] + [Esc] to display the Start menu.



2 When the [Settings] screen appears, select [Devices].




- 3 Select **[Bluetooth & Other Devices]** > **[Add Bluetooth or other device]** > **[Bluetooth]** to search for Bluetooth devices.



4 Select a device to connect to.

ENGLISH



5 Complete the Bluetooth connection as directed.

Wired LAN

LAN is the network environment that users can connect to by using a cable to connect to their internet providers or the company's network.

Using Wired LAN

LAN is installed with an automatic IP (DHCP) as default value.

Please refer to the following instructions for details on setting up an automatic IP (DHCP) or manual IP.

- 1 Connect the LAN adapter to the USB-C™ port on the PC.

**TIP**

The recommended network cable for the optimal network environment is CAT5 or higher.
The network (LAN) cable may be connected when the LAN adapter is used.



- 2 Connect the wired LAN cable to the LAN port.




- 3 Press the [] button and select the **Settings** menu.

**TIP**



Press the [] key or [Ctrl] + [Esc] to display the Start menu.

ENGLISH




4 Select [Network & Internet] > [Status] > [Change adapter options].


ENGLISH




- 5 Right-click **[Ethernet]** and select the **[Properties]** menu.



- 6 Select **[Internet Protocol Version 4 (TCP/IPv4)]** and then click **[Properties]**.



- 7 To use an automatic IP(DHCP), select **[Obtain an IP Address Automatically]**. If you wish to use a static IP, select **[Use Following IP Address]** to enter the address.
Contact the network service provider or administrator to use a static IP.



- 8 Press **[OK]** to complete the network setup.
- 9 Click the Web Browser icon to check whether the internet is connected properly.

Wireless LAN

The wireless network (Wireless LAN) is the network environment that connects a PC with the internet provider or company network through an Access Point (wireless or regular router).

Turning On/Off **Airplane Mode**

Prior to using the wireless LAN, press [Fn] + [F6] to turn off **Airplane Mode**.

Pressing [Fn] + [F6] keys will turn on or off the **Airplane Mode**. If you are not going to use the product for a while, keep the **Airplane Mode** turned on to reduce the battery power consumption.

Using the Wireless LAN


If an Access Point (wired or wireless router) is in the vicinity of the PC, the wireless LAN can easily be accessed.

During the search for a wireless network (Wireless LAN), various Access Points may be found according to the location where the PC is used.



In case there are no accessible wireless networks (Wireless LAN) near the PC, no Access Points may be found

A password protected Access Point cannot be accessed without knowing the right password.

- 1 Press the Action Center [] icon on the right side of the taskbar.




- 2 Press the **[Network]** tile to search for a nearby Access Point.




TIP


If **Wi-Fi** is turned off, press the **[Wi-Fi]** tile.



3 Select the Access Point you want to connect to and press [Connect].



- 4 If a connection is established, [Connected] appears below the Access Point name.



- 5 Click the Web Browser icon to check whether the internet is connected properly.

Using a Wired/Wireless Router

A wireless / regular router connects several PCs and mobile devices to one internet line and enables the use of internet and the network.

A wireless / regular router has to be bought separately. Refer to the manual provided by the manufacturer for instructions.

Connecting a Wireless or Regular Router

If one internet line is used with a wired / wireless router and several devices are connected, this may result in a slower connection.

In case of a wireless LAN, it is recommended to change the network name and security settings for a more secure connection.

Network speed can differ according to operation environment and specifications.

- 1 Connect the internet cable of the modem that was provided by your internet provider to the router's WAN port.
- 2 Connect all devices (PC, IPTV, internet phone, etc.) with a LAN cable to LAN ports 1 to 4 of the router.

The number of LAN ports can vary for each router model.

- 3 Please refer to the manual provided by the router manufacturer for setup of the network and internet.

Micro SD Slot

Checking Available Memory Card

This model supports Micro SD memory cards.

- Directly applicable memory cards



micro SD

Mounting and Using Memory Card

This product supports one **Micro SD** slot.

Check the direction and insert the **Micro SD** into the multi-card slot until it is locked in place as shown in the following figure.

**TIP**

- When the memory card is formatted, the data stored in the memory card will be deleted. Check whether there are important data before formatting the memory stick.
- To format a memory card, right-click the memory card drive and select Format. When the Format window appears, press Start to continue.
- If the write protection tab of memory card is locked, the user cannot format the memory stick nor write or delete the data.
- SD™ memory cards can be used only as storage devices and do not support the copyright protection feature.

Removing Memory Card

Push the card with your finger to make the card spring out of the slot. Remove the memory card.

TIP**To safely remove a memory card:**

The figures herein may differ by language selection and are subject to change without prior notice.

- 1 Click **Safely Remove Hardware and other Media** icon on the right side of the taskbar.



- 2 Select **Remove Multi-Card USB Device** to safely remove hardware.

Using Software

ENGLISH

LG Control Center

LG Control Center is a software that helps you change PC Settings, Power Settings, Windows Security Settings, etc. as well as check current system information.




TIP

The menus displayed in **LG Control Center** and its supported functions may differ depending on the model.

The figures herein are subject to change without prior notice.

Executing LG Control Center

Select the [] button > [LG Software] to run [LG Control Center].




1 Minimize/Exit Button: Minimizes the size of the window, or exits the software.

2 help/info Button: Runs Help or displays information about the software.

- 3 **System Settings:** Sets the device settings such as the screen brightness, sound, and external display.
- 4 **Power Management:** Sets the USB-C™ charging function, battery status and battery life extension function.
- 5 **Windows Security:** Sets User Account Control settings and Firewall settings.
- 6 **Instant Booting:** You can set the system to automatically boot whenever you open the notebook PC.
- 7 **System Information:** Displays the PC OS in use, processor information and other system information.

System Settings Screen

You can use this screen to configure various devices in your PC.




- 1 **Screen:** Allows you to adjust the system brightness. (This function is not supported in a model that does not provide the brightness settings in Windows.)
- 2 **Sound:** Allows you to adjust the volume of the sound or use the mute function.

- 3 **Touchpad:** Allows you to set whether to use the touchpad.
- 4 **Color Temperature:** The screen color can be set to cold (with a bluish tint) or warm (with a reddish tint).
- 5 **Keyboard Backlight:** Allows you to configure the Keyboard backlight.
- 6 **Touch Screen:** Allows you to set whether to use the touch screen.
- 7 **External Display:** Allows you to configure the connection mode of an external display connected to the PC.
- 8 **Airplane Mode:** Allows you to set the Airplane mode. (It turns off the wireless LAN).
- 9 **Silent Mode:** Allows you to set the fan to the Silent mode.

Power Management Screen

You can check or change the settings related to PC USB-C™ port or battery.




- 1 **Set USB-C™ Charging**
 - **Set Always-On Charging:** Allows you to set the USB-C™ port so that you can perform charging using the USB-C port even when the PC is turned off.
 - **Set Charging Function:** Allows you to set the charging function for a USB-C™ port (Automatic, Sink, or Source).
- 2 **Battery Statate:** Allows you to measure the battery lifespan so that you can replace it timely.

- 3 **Extend Battery Life:** Allows you to increase the battery lifespan by lowering the battery charging level to 80% of the battery capacity.

Windows Security Screen


You can change the User Account Control and firewall settings in Windows.



- 1 **User Account Control Settings:** Allows you to change the User Account Control settings in Windows.
- 2 **Firewall:** Turns on/off the Windows firewall. (It may not work if other vaccine software is installed in the PC.)

Instant Booting

You can set the system to automatically boot whenever you open the notebook PC.



FAQ

Q: Battery status displays "Warning".

- The battery is a consumable item and its lifespan may decrease depending on the usage frequency and environment. It is recommended that you visit the LG Electronics service center to have the battery replaced.

LG Update Center

LG Update Center allows you to install various PC drivers, applications easily.

TIP

It may not work properly depending on user preferences (security tools, etc.) and the network status.


You can use the **LG Update Center** to quickly install the latest drivers, or reinstall any deleted drivers.

Use **LG Update Center** to keep your system current and optimized.

The figures herein are subject to change without prior notice.

Executing **LG Update Center**

Select the  button > **[LG Software]** to run **[LG Update Center]**.




- 1 **Minimize/Exit Button:** Minimizes the size of the window, or exits the software.
- 2 **help/info Button:** Runs Help or displays information about the software.
- 3 **Required Update:** Installs critical items that must be applied to the system.

- 4 **All List:** Displays and installs all required items for the system.
- 5 **Notification Setting:** Sets up notifications for online updates for installed items.


Required Update

You can install essential updates and drivers that are necessary for the system.

- 1 Select the [Required Update] menu.



- 2 When the **Required Update** list appears, select the updates to install and press the [Installation] button.




TIP

All items are selected by default.


All List

You can install all updates and drivers that can be installed in the system.

- 1 Select [All List] > [Update needed].



- 2 Select a device to install and press the [Installation] button.



TIP

All items are selected by default.

Notification Settings


You can check the critical updates to set whether to display the notifications for update installation.




TIP

The Auto Update Search function is set to [ON] by default. If you set it to [OFF], the notifications are not displayed.


- 1 Select the [Notification Settings] menu.



- 2 Set [Auto Update Search] to [ON] or [OFF].



3 Set the [Cycle].



4 Select [Notification List Setup] menu to turn on/off the notification for each item.

FAQ

Q: Is there a way that I can install the drivers and applications easily?

- You can select [Required Update] or [All List] menu in **LG Update Center** to automatically install the drivers and applications that you want.

Q: The server connection status is not displayed in the program.

- Check if your PC is properly connected to the wired or wireless LAN.
- Check if Internet connection works properly.

Q: I want to hide the update notifications.

- Select the [Notification Settings] menu and set the [Auto Update Search] to [OFF].
- Select [Notification List Setup] menu to turn on/off the notification for each item.

Q: How can I update the items that are excluded from the notification list?

- You can also install the items that are excluded from the notification list by using the [Required Update] or [All List] menu.

LG Reader Mode

LG Reader Mode prevents the users from eyestrain and helps them to read the PC screen comfortably by displaying the screen just like a printed paper.



TIP

LG Reader Mode is offered through a UWP app. You can reinstall it through **Microsoft Store** if it was deleted. If you want to delete and reinstall the application, access **Microsoft Store**, search for **LG Reader Mode**, and install it.

When you delete and reinstall it, it needs to be executed manually once at first. Select the [



] button > **[LG Reader Mode]**.

Using **LG Reader Mode**



CAUTION

Using the **Reader Mode** and the **Night light** at the same time can cause color distortion. When you use the **Reader Mode**, turn off the **Night light**.

- Press the [] icon to the right of the taskbar to run the **Action Center** and press the **[Night light]** tile to turn on/off the **Night light**.




TIP

You can use hot keys to use the **Reader Mode** function more conveniently.

- Press the [Fn] + [F9] keys to switch the PC screen to **reader mode**. Press them again to turn off **reader mode**.


- 1 Press the [] icon on the taskbar.



- 2 Select the **[Reader Mode On]** menu to switch to **reader mode** as shown in the figure.



Select **[Reader Mode Off]** to turn off the **reader mode**.




Using **Advanced Settings**


- 1 Select the **[Advanced Settings]** menu as shown in the figure.



The **[Advanced Settings]** menu is activated when **Reader Mode** is on.



- 2 The **[Advanced Settings]** window appears as shown below.



- a **System Brightness:** System brightness can be adjusted.
- b **Color Adjustment:** Color and its **brightness, contrast and gamma** can be adjusted.
- c **Reset:** Settings are reset to the default settings.

DTS Headphone: X/DTS Studio Sound

DTS Headphone: X/DTS Studio Sound provides rich, sonorous sound when you listen to music, watch videos or play games in the PC.

DTS Headphone: X/DTS Studio Sound may not be applied depending on the model.

The figures herein are subject to change without prior notice.



CAUTION


As 3D Fx is a sound effect optimized for watching movies, it may cause sound distortion when you listen to music in this mode.

Please disable this mode when you use music content.

Executing **DTS Headphone: X/DTS Studio Sound**


- 1 Press the [] button to execute [DTS HeadphoneX v1].
- 2 Default is **DTS Studio Sound** and **DTS Headphone: X** operates when the earphone is connected.

DTS Headphone: X Tour



- 1 **Power:** Turns on/off the **DTS Headphone: X** power.
- 2 **Earbuds:** Allows you to select the connected earphone.
- 3 **Content Mode:** Allows you to select entertainment/game/sport and provides optimum setting for each content.
- 4 **Stereo Default Settings:** Provides settings for stereo including wide/front/traditional.

DTS Studio Sound Tour



- 1 **Power:** Turns on/off the **DTS Studio Sound** power.
- 2 **Bass Boost:** Boosts the lowest frequencies for enhanced bass sound.
- 3 **Volume Leveling:** Increases audio level without distortion of sound.
- 4 **Surround Sound:** Sets up surround sound effects through the PC's embedded speakers.
- 5 **3D Fx:** Sets up 3D sound effects through the PC's embedded speakers.
- 6 **Equalizer:** Sets the equalizer.
- 7 **Advanced Levels:** Provides the advanced options menu for **DTS Studio Sound**.

**TIP**

If you want to remove Audio Driver or DTS Headphone: X/DTS Studio Sound, remove [DTS HeadphoneX v1] and [Synaptics SmartAudio HD Audio Driver] in the order specified and restart the system.

If you want to reinstall Audio Driver or DTS Headphone: X/DTS Studio Sound, remove [DTS HeadphoneX v1] and [Synaptics SmartAudio HD Audio Driver] in the order specified and install [Synaptics SmartAudio HD Audio Driver]. Then restart the system and install [DTS HeadphoneX v1].

- If you do not remove or install them in the order specified, an error may occur.

Restoring the System

Restoring the System

If the system has an error, you can use Windows 10's recovery function to recover or restore the system to its initial pre-purchase state.




CAUTION


If you have deleted the restoration data in the protected area of the disk, or have arbitrarily installed another operating system, the restore function may not work.

To recover the system, the AC adapter must be connected.


- 1 Click the  button and select the Settings menu.




- 2 When the [Settings] screen appears, select [Update & Security].



- 3 Select the [Recovery] menu and press [Get Started] in the **Reset this PC** menu.




- 4 If the following screen appears, select a desired option to proceed with recovery.



- **Keep my files:** Recovers the PC without losing any personal files.
PC settings are reset to default and any user-installed Desktop app will be deleted.
- **Remove everything:** Removes all items from the system and restores the system to its initial pre-purchase state.

1. When the following screen appears, select [Yes].



2. Select the options you want to proceed with the recovery.



- **Just remove my files:** Factory-resets the drive where Windows is installed (for example: Drive C).
- **Remove files and clean the drive:** Resets all partitions and drives in the system.

**CAUTION**

All data is lost during the initialization, so you must backup all critical data in advance.
It may take about 5 hours or longer depending on the system conditions.


Setup and Upgrade

Installing the Driver

The figures herein may differ by language selection and are subject to change without prior notice.

Using **LG Update Center** to install the Driver

- 1 Select the  button > [LG Software] to run [LG Update Center].



- 2 Select [Required Update] or [All List] to install the driver.



TIP

You can use the **LG Update Center** to quickly install the latest drivers, or reinstall any deleted drivers.

Use **LG Update Center** to keep your system current and optimized.

Downloading **LG Update Center**

You can download **LG Update Center** from the LG Electronics website (www.lg.com).

Starting System Setup

System setup means storing the hardware configuration information of the PC in the flash memory. Through system setup, the PC retrieves various information including current date and time, memory capacity, and hard disk capacity and type.

You setup the system when you set passwords, change the boot order, and add new peripheral devices to the machine.

Items displayed on the Setup screen may differ by model type and specification. Refer to

- Refer to .
- Refer to .
- Refer to .

TIP

To use the system setup (F2), booting device selection (F10), you need to restart the system (click [Restart] in the system power menu) and then immediately press the corresponding function key due to the fast booting speed.




CAUTION

- Do not change the system setup unless necessary. Incorrect system setup may cause errors during system operation. Use caution when changing the system setup.
- For performance improvement, the system setup menu configuration and the initial setup status may be changed and may become different from images included in the user manual.

- 1 Reboot the system and press [F2].



- 2 In a few moments, the system setup screen appears.



Keys Used in System Setup

Keys	Function
Enter	Selects the current item.
Esc	To deselect the current item or to move to the previous screen.
▲, ▼, ◀, ▶ (Arrow keys)	Moves the cursor up, down, left, and right.
F5, F6	Increases or decreases the item value.
F10	Saves the new settings or exits the system setup.

Setting the Password

This process is to set a password so that other people cannot use the PC or change the settings.

The user can set a password while booting the system or setting up the system.

The model in the example can differ from actual models and is subject to change for performance improvements, without prior notice.




CAUTION

- Without the registered password, access to the system will be denied. Write down and keep the password in a safe place.


Set Supervisor Password

The password prevents unauthorized people from accessing the PC. By default, no password is set for the machine. If an unauthorized person changes the password in the System Setup, you will be unable to access the system.

- After opening the system setup screen, use the arrow keys to move to **[Security]**.
- When the following screen shows up, click **[Set Supervisor Password]** by using the arrow keys and press **[Enter]**.




- 3 When the following message appears on the screen, enter the password and press [Enter]. The password should not exceed 20 characters and should consist of English letters (A - Z), numbers (0 - 9), and special characters or a combination of them.



- 4 When the following message shows up on the screen, enter the password again and press [Enter].



- 5 To save the changes in the system setup, press [F10].
- 6 When the following message appears, select [Yes] and press [Enter]. The PC will restart.


**TIP**

- With **Supervisor Password**, you are authorized to set all items in the System Setup and to set **[Power on Passward]**. In case other people also use the PC, it is recommended to set the **User Password**.


Set User Password

The password set by the **Set User Password** process is lower than that set by the **[Set Supervisor Password]** process, and so the user can use the **[Set User Password]** only after setting a password in the **[Set Supervisor Password]** menu.

- 1 After opening the system setup screen, use the arrow keys to move to **[Security]**.
- 2 When the following screen appears, select **[Set User Password]** and press **[Enter]**.




- 3 When the following message appears on the screen, enter the password and press **[Enter]**. The password should not exceed 20 characters and should consist of English letters (A - Z), numbers (0 - 9), and special characters or a combination of them.



- 4 When the following message shows up on the screen, enter the password again and press [Enter].



- 5 To save the changes in the system setup, press [F10].
- 6 When the following message appears, select [Yes] and press [Enter]. The PC will restart.



TIP


- **[User Password]** allows only limited access to the items in the System Setup when compared with the items that can be set with **[Supervisor Password]**.

Power on Password


Power on Password protects the system by requesting **[Set Supervisor Password]** or **[Set User Password]** during boot up.

- 1 After opening the system setup screen, use the arrow keys to move to **[Security]**.

- 2 When the following screen appears, set [Set Supervisor Password] only or both [Set Supervisor Password] and [Set User Password].



- 3 The popup screen will show up, after selecting [Power on Password] and press [Enter]. Select [ON] and press [Enter] to finish setting the [Power on Password].



Set SSD Password


SSD Password is to set a password in the SSD separately from the **Supervisor Password**.

For a model equipped with two **SSD** devices, the menu name may be displayed as **SSD1**, **SSD2**, etc.


If you set **SSD Password** as well, the password input screen appears twice during system booting.

If you set **SSD Password** as well, the password input screen appears according to the order of [Boot priority order] under the [Boot] menu.

- 1 After opening the system setup screen, use the arrow keys to move to **[Security]**.
- 2 When the following screen shows up, click **[Set SSD1 Password]** by using the arrow keys and press [Enter].




- 3 When the following message appears on the screen, enter the password and press [Enter]. The password should not exceed 32 characters and should consist of English letters (A - Z), numbers (0 - 9), and special characters or a combination of them.



- 4 When the following message shows up on the screen, enter the password again and press [Enter].



- 5 To save the changes in the system setup, press [F10].
- 6 When the following message appears, select **[Yes]** and press [Enter]. The PC will restart.

**CAUTION**

If you forget SSD Password, you cannot restore the SSD.

- The replacement of SSD due to a forgotten **SSD Password** is not covered by the warranty.


Changing or Deleting the Password

You can delete or change the password only after entering the current password.

The model in the example can differ from actual models and is subject to change for performance improvements, without prior notice.

Changing the Password


- 1 Execute System Setup, enter the password, and click [Enter].




- 2 Change the password in the same way as setting one.

Deleting the Password


- 1 Execute System Setup, enter the password, and press [Enter].




- 2 After moving **[Security]** by using the arrow keys from the setup start screen, click **[Set Supervisor Password]** and press **[Enter]**.




- 3 Type the current password and press Enter.




- 4 When the following message appears on the screen, press **[Enter]**.



- 5 When the following message appears, select **[Yes]** and press [Enter]. The PC will restart.




- 6 To save the changes in the system setup, press [F10].
- 7 When the following message appears, select **[Yes]** and press [Enter]. The PC will restart.



Deleting the Password (**Set SSD Password**)

- 1 Execute System Setup, enter the password, and press [Enter].




- 2 After moving **[Security]** by using the arrow keys from the setup start screen, click **[Set SSD1 Password]** and press **[Enter]**.




TIP

Depending on the model, the menu name may be displayed as **SSD Password**, etc.

For a model equipped with two **SSD** devices, the menu name may be displayed as **SSD1**, **SSD2**, etc.




- 3 Type the current password and press Enter.




- 4 When the following message appears on the screen, press [Enter].



- 5 When the following message appears, select **[Yes]** and press [Enter]. The PC will restart.



- 6 To save the changes in the system setup, press [F10].
- 7 When the following message appears, select **[Yes]** and press [Enter]. The PC will restart.




Restoring the Factory Default Settings


If you have changed the system setup by mistake, you can restore the default settings.

The model in the example can differ from actual models and is subject to change for performance improvements, without prior notice.

- 1 After opening the system setup screen, use the arrow keys to move to **[Exit]**.
- 2 Click **[Load Setup Defaults]** by using the arrow keys and pressing **[Enter]**.




- 3 When the following message appears, select **[Yes]** and press **[Enter]**. The settings will be reset to the factory default.



- 4 To save the changes in system setup, press **[F10]**.

- 5 When the following message appears, select **[Yes]** and press [Enter]. The PC will restart.

**TIP**

- When you press [F9], you can use **[Load Setup Defaults]**.

Changing the Boot Order

The user can change the boot order according to his or her needs, or select a boot device

The model in the example can differ from actual models and is subject to change for performance improvements, without prior notice.

TIP

To use the system setup (F2), booting device selection (F10), you need to restart the system (click **[Restart]** in the system power menu) and then immediately press the corresponding function key due to the fast booting speed.


Changing the Boot Order

- 1 Reboot the system and press [F2].




- 2 Move to the **[Boot]** menu when the system setup screen appears.

- 3 Go to **[Boot priority order]** and press **[F5]** or **[F6]** to change the booting order.



- 4 When you press **[F10]** and the following screen appears, select **[Yes]** and press **[Enter]**.




- 5 The changes are saved and the system reboots.

Selecting a Booting Device to Use

- 1 Reboot the system and press [F10].



- 2 When the Select Booting Device screen appears, select the device.



- 3 Boots using the selected device.

Windows 10 Auto Scaling


The Windows 10 **Auto Scaling** feature for user's convenience may partially blur the screen or display some icons and texts larger.

Refer to the following information to change the DPI scaling to suit your needs.

- 1 Press the  button and select the **[Settings]** menu.


TIP

Press the  key or [Ctrl] + [Esc] to display the Start menu.




2 Select [System] > [Display].

ENGLISH




- 3 Modify the **[Change the size of text, apps, and other items]** value to change the Auto Scaling settings.



TIP


After changing the auto scaling settings, it is recommended that you click **[Sign out now]** and log on to Windows again.



Using Instant Booting

Instant Booting allows the system to boot automatically when the notebook PC cover is opened, so that you can use the system without pressing the power button.

- 1 Select the [] button > [LG Software] to run [LG Control Center].
- 2 On **LG Control Center** screen, set the [Instant Booting] to [ON].



- 3 Shutdown the system and close the notebook PC cover.
- 4 When the cover is opened, the notebook PC turns on and the system starts to boot automatically.


FAQ

FAQ Content

Using Instant Booting

Instant Booting allows the system to boot automatically when the notebook PC cover is opened, so that you can use the system without pressing the power button.

- 1 Select the [Windows] button > [LG Software] to run [LG Control Center].
- 2 On **LG Control Center** screen, set the [Instant Booting] to [ON].



- 3 Shutdown the system and close the notebook PC cover.
- 4 When the cover is opened, the notebook PC turns on and the system starts to boot automatically.

Windows 10 Auto Scaling


The Windows 10 **Auto Scaling** feature for user's convenience may partially blur the screen or display some icons and texts larger.

Refer to the following information to change the DPI scaling to suit your needs.


- 1 Press the  button and select the **[Settings]** menu.

 **TIP**


Press the  key or [Ctrl] + [Esc] to display the Start menu.



2 Select [System] > [Display].




3 Modify the [Change the size of text, apps, and other items] value to change the Auto Scaling settings.



 TIP

After changing the auto scaling settings, it is recommended that you click [Sign out now] and log on to Windows again.



Restoring the System

If the system has an error, you can use Windows 10's recovery function to recover or restore the system to its initial pre-purchase state.




CAUTION


If you have deleted the restoration data in the protected area of the disk, or have arbitrarily installed another operating system, the restore function may not work.

To recover the system, the AC adapter must be connected.


- 1 Click the [] button and select the Settings menu.




- 2 When the [Settings] screen appears, select [Update & Security].



- 3 Select the [Recovery] menu and press [Get Started] in the **Reset this PC** menu.




- 4 If the following screen appears, select a desired option to proceed with recovery.



- **Keep my files:** Recovers the PC without losing any personal files.
PC settings are reset to default and any user-installed Desktop app will be deleted.
- **Remove everything:** Removes all items from the system and restores the system to its initial pre-purchase state.

1. When the following screen appears, select [Yes].



2. Select the options you want to proceed with the recovery.



- **Just remove my files:** Factory-resets the drive where Windows is installed (for example: Drive C).
- **Remove files and clean the drive:** Resets all partitions and drives in the system.

**CAUTION**

All data is lost during the initialization, so you must backup all critical data in advance.
It may take about 5 hours or longer depending on the system conditions.

Connecting to External Display

Connecting to the HDMI Port

HDMI is a high-speed multimedia interface that can transfer uncompressed full digital audio and video signals.

In some models, DTS Audio may not work when you use HDMI.



TIP

Ensure the monitor power is off before connecting the external monitor to the PC.

- 1 Connect the HDMI cable to the PC and the external device (TV, monitor) that supports HDMI.
- 2 HDMI port transfers both video and audio simultaneously. Hence, there is no need for a separate audio connection.



- 3 On the PC, press [Fn] + [F7] to display monitor (projector) toggling screen. Select the desired screen output.



TIP

- Every time [] + [P] keys are pressed, the screen output option changes. Release the keys to display the selected screen output.

**CAUTION**

- If you do not set Speaker as the default value after disconnecting the HDMI cable, the system may not produce any sound.
- If a program was running already, you must exit and restart the program to produce sound.

Using a Wired/Wireless Router

A wireless / regular router connects several PCs and mobile devices to one internet line and enables the use of internet and the network.

A wireless / regular router has to be bought separately. Refer to the manual provided by the manufacturer for instructions.

Connecting a Wireless or Regular Router

If one internet line is used with a wired / wireless router and several devices are connected, this may result in a slower connection.

In case of a wireless LAN, it is recommended to change the network name and security settings for a more secure connection.

Network speed can differ according to operation environment and specifications.

- 1 Connect the internet cable of the modem that was provided by your internet provider to the router's WAN port.
- 2 Connect all devices (PC, IPTV, internet phone, etc.) with a LAN cable to LAN ports 1 to 4 of the router.

The number of LAN ports can vary for each router model.

- 3 Please refer to the manual provided by the router manufacturer for setup of the network and internet.

Wireless LAN

The wireless network (Wireless LAN) is the network environment that connects a PC with the internet provider or company network through an Access Point (wireless or regular router).

Turning On/Off **Airplane Mode**

Prior to using the wireless LAN, press [Fn] + [F6] to turn off **Airplane Mode**.

Pressing [Fn] + [F6] keys will turn on or off the **Airplane Mode**. If you are not going to use the product for a while, keep the **Airplane Mode** turned on to reduce the battery power consumption.

Using the Wireless LAN


If an Access Point (wired or wireless router) is in the vicinity of the PC, the wireless LAN can easily be accessed.

During the search for a wireless network (Wireless LAN), various Access Points may be found according to the location where the PC is used.



In case there are no accessible wireless networks (Wireless LAN) near the PC, no Access Points may be found

A password protected Access Point cannot be accessed without knowing the right password.

- 1 Press the Action Center [] icon on the right side of the taskbar.




2 Press the **[Network]** tile to search for a nearby Access Point.




TIP


If **Wi-Fi** is turned off, press the **[Wi-Fi]** tile.



- 3 Select the Access Point you want to connect to and press [Connect].



- 4 If a connection is established, [Connected] appears below the Access Point name.



- 5 Click the Web Browser icon to check whether the internet is connected properly.