

Winterm 3000 Series Windows®-based Terminal

Reference Guide



WYSE
._._._.



Winterm 3000 Series Windows®-based Terminal Reference Guide

883590-08 Rev. A
August 1999

Wyse Technology Inc.
3471 North First Street
San Jose, CA 95134-1803

Copyright Notice

© 1999 ALL RIGHTS RESERVED.

This manual and the software and firmware described in it are copyrighted. You may not reproduce, transmit, transcribe, store in a retrieval system, or translate into any language or computer language, in any form or by any means, electronic, mechanical, magnetic, optical, chemical, manual or otherwise, any part of this publication without express written permission.

Trademarks

WYSE is a registered trademark and Winterm is a trademark of Wyse Technology Inc.

ICA 3 is a registered trademark and MetaFrame is a trademark of Citrix Systems Inc.

Microsoft and Windows are registered trademarks of Microsoft Corporation.

All other products are trademarks and/or registered trademarks of their respective companies.

The Energy Star emblem does not represent endorsement of any product or service.

Specifications subject to change without notice.

Restricted Rights Legend

Use, duplication, or disclosure by the Government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at 252.227-7013.

Ordering Information

For availability, pricing, and ordering information in the United States and Canada, call 1-800-GET-WYSE (1-800-438-9973). In all other countries, contact your sales representative.

Wyse Technology Inc.
3471 North First Street
San Jose, CA 95134-1803 U.S.A.

FCC Statement

This equipment has been tested and found to comply with the limits for either Class A or Class B digital devices (refer to “Terminal Requirements Compliance”), pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



Caution

Changes or modifications not covered in this manual must be approved in writing by the manufacturer's Regulatory Engineering department. Changes or modifications made without written approval may void the user's authority to operate the equipment.

Terminal Requirements Compliance

Models 3315SE, 3320SE, 3350SE, 3515SE, 3715SE, and 3720SE terminals meet Class B requirements.

Canadian DOC Notices

Refer to the previous section, “Terminal Requirements Compliance,” to find out what model terminal each of the statements below refers to.

Class A

This digital apparatus does not exceed the Class A limits for radio noise emissions from digital apparatus set out in the Radio Interference Regulations of the Canadian Department of Communications.

Le présent appareil numérique n’émet pas de bruits radioélectriques dépassant les limites applicables aux appareils numériques de la classe A prescrites dans le Règlement sur le brouillage radioélectrique édicté par le Ministère des Communications du Canada.

Class B

This digital apparatus does not exceed the Class B limits for radio noise emissions from digital apparatus set out in the Radio Interference Regulations of the Canadian Department of Communications.

Le présent appareil numérique n’émet pas de bruits radioélectriques dépassant les limites applicables aux appareils numériques de la classe B prescrites dans le Règlement sur le brouillage radioélectrique édicté par le Ministère des Communications du Canada.

IEC/EN Notice

This product conforms to the requirements of IEC950 and EN60950.

This product conforms to requirements of EN55022 for Class A equipment or EN55022 for Class B equipment (refer to “Terminal Requirements Compliance”).

Cable Notice

The use of shielded I/O cables is required when connecting this equipment to any and all optional peripheral or host devices. Failure to do so may cause interference and violate FCC and international regulations for electromagnetic interference.

License Agreement

YOU SHOULD CAREFULLY READ THE FOLLOWING TERMS AND CONDITIONS BEFORE USING THIS EQUIPMENT WHICH CONTAINS SOFTWARE IN A NON-VOLATILE FORMAT AND CERTAIN OTHER INTELLECTUAL PROPERTY (HEREAFTER "FIRMWARE"). USING THIS EQUIPMENT INDICATES YOUR ACCEPTANCE OF THE FOLLOWING TERMS AND CONDITIONS.

Grant

You may use the Firmware in or in conjunction with the Equipment as provided to You. You may transfer ownership of the Equipment, including the right to use the Firmware to another party so long as that party agrees to accept these terms and conditions.

YOU MAY NOT USE, COPY, MODIFY, TRANSLATE OR TRANSFER THE FIRMWARE, OR MODIFICATION THEREOF, IN WHOLE OR IN PART, EXCEPT AS EXPRESSLY PROVIDED FOR IN THIS LICENSE. YOU MAY NOT DECOMPILE, REVERSE ENGINEER OR OTHERWISE DECODE OR ALTER THE SOFTWARE CONTAINED IN THE FIRMWARE.

Limited Software Warranty and Disclaimer

WYSE warrants that, for a period of ninety (90) days from the date of shipment, the Firmware will, under normal use, be free from defects in materials and workmanship in the EPROM (or similar storage device). The foregoing warranty shall not apply to any Firmware which has been used in violation of this Agreement. During this limited warranty period WYSE will provide support by phone on a best-efforts basis. WYSE may, in addition to the above, replace any defective Firmware with a functionally equivalent product. The foregoing shall be Your exclusive remedy for any breach of warranty hereunder. You assume responsibility for choosing the Equipment containing the Firmware to achieve your intended results, and for the installation, use and results obtained from the Equipment and Firmware.

EXCEPT FOR THE ABOVE EXPRESS LIMITED WARRANTIES, WYSE MAKES AND YOU RECEIVE NO WARRANTIES ON THE FIRMWARE, EXPRESS, IMPLIED, OR STATUTORY, OR IN ANY OTHER PROVISION OF THIS AGREEMENT OR COMMUNICATION WITH YOU, AND WYSE DISCLAIMS ANY IMPLIED WARRANTIES OF MERCHANTABILITY, NON-INFRINGEMENT AND FITNESS FOR ANY PARTICULAR PURPOSE. WYSE DOES NOT WARRANT

THAT THE FUNCTIONS CONTAINED IN THE PRODUCT WILL MEET YOUR REQUIREMENTS OR THAT THE OPERATION WILL BE UNINTERRUPTED OR ERROR FREE.

SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS. YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM STATE TO STATE.

Limit of Liability

UNDER NO CIRCUMSTANCES SHALL WYSE BE LIABLE FOR LOSS OF DATA, COST OF COVER, OR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES, HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY. THESE LIMITATIONS SHALL APPLY EVEN IF WYSE OR ITS RESELLER HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, AND NOTWITHSTANDING ANY FAILURE OF ESSENTIAL PURPOSE OF ANY LIMITED REMEDY PROVIDED HEREIN.

YOU AGREE THAT THESE ARE THE ONLY APPLICABLE TERMS OF AGREEMENT BETWEEN US COVERING FIRMWARE AND THAT THEY SUPERSEDE ANY OTHER COMMUNICATIONS (ORAL OR WRITTEN) BETWEEN US RELATING TO THE FIRMWARE.

U.S. Government Restricted Rights

The Firmware is provided with RESTRICTED RIGHTS. Use, duplication or disclosure by the Government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technological Data and computer software clause at DFARS 252.227-7013 or in subparagraphs (c)(1) and (2) of the Commercial Computer Software-Restricted Rights at 8 C.F.R. 52-227-19 as applicable. Contractor/Licenser is WYSE Technology Inc.

EULA for Microsoft® Windows® CE Operating System for Windows-based Terminal Devices

IMPORTANT—READ CAREFULLY

This End User License Agreement (EULA) is a legal agreement between you (either an individual or a single entity) and the manufacturer (MANUFACTURER) of the special purpose computing device (SYSTEM) you acquired which includes certain Microsoft software product(s) installed on the SYSTEM and/or included in the SYSTEM package (SOFTWARE). The SOFTWARE includes computer software, the associated media, any printed materials, and any online or electronic documentation. By installing, copying or otherwise using the SOFTWARE, you agree to be bound by the terms of this EULA. If you do not agree to the terms of this EULA, MANUFACTURER and Microsoft Licensing, Inc. (MS) are unwilling to license the SOFTWARE to you. In such event, you may not use or copy the SOFTWARE, and you should promptly contact MANUFACTURER for instructions on return of the unused product(s) for a refund.

Software License

The SOFTWARE is protected by copyright laws and international copyright treaties, as well as other intellectual property laws and treaties. The SOFTWARE is licensed, not sold.

1. Grant of License

SOFTWARE includes software already installed on the SYSTEM (SYSTEM SOFTWARE) and, if included in the SYSTEM package, software contained on the CD-ROM disk and/or floppy disk(s) labeled “Desktop Software for Microsoft Windows CE” (DESKTOP SOFTWARE). This EULA grants you the following rights to the SOFTWARE:

- **SYSTEM SOFTWARE**

You may use the SYSTEM SOFTWARE only as installed in the SYSTEM.

- **DESKTOP SOFTWARE**

DESKTOP SOFTWARE might not be included with your SYSTEM. If DESKTOP SOFTWARE is included with your SYSTEM, you may install and use the component(s) of the DESKTOP SOFTWARE in accordance with the terms of the end user license agreement provided with such component(s). In the absence of a separate end user license agreement for particular component(s) of the DESKTOP SOFTWARE, you may install and use only one (1) copy of such component(s) on a single computer with which you use the SYSTEM.

- **Use of Windows CE Operating System for Windows-based Terminal Devices with Microsoft Windows NT Server, Terminal Server Edition**

If the SOFTWARE is Windows CE operating system for Windows-based Terminal devices, the following special provisions apply. In order to use the SYSTEM in connection with Windows NT Server, Terminal Server Edition, you must possess (1) a Client Access License for Windows NT Server, Terminal Server Edition and (2) an end user license for Windows NT Workstation or an end user license agreement for Windows NT Workstation for Windows-based Terminal Devices (please refer to the end user license agreement for Windows NT Server, Terminal Server Edition for additional information).

MANUFACTURER may have included a Certificate of Authenticity for Windows NT Workstation for Windows-based Terminal Devices with the SYSTEM. In that case, this EULA constitutes an end user license for the version of Windows NT Workstation for Windows-based Terminal Devices indicated on such Certificate of Authenticity.

- **Back-up Copy**

If MANUFACTURER has not included a back-up copy of the SYSTEM SOFTWARE with the SYSTEM, you may make a single back-up copy of the SYSTEM SOFTWARE. You may use the back-up copy solely for archival purposes.

2. **Description of Other Rights and Limitations**

- **Speech/Handwriting Recognition**

If the SYSTEM SOFTWARE includes speech and/or handwriting recognition component(s), you should understand that speech and handwriting recognition are inherently statistical processes; that recognition errors are inherent in the processes; that it is your responsibility to provide for handling such errors and to monitor the recognition processes and correct any errors. Neither MANUFACTURER nor its suppliers shall be liable for any damages arising out of errors in the speech and handwriting recognition processes.

- **Limitations on Reverse Engineering, Decompilation and Disassembly**

You may not reverse engineer, decompile, or disassemble the SYSTEM SOFTWARE, except and only to the extent that such activity is expressly permitted by applicable law notwithstanding this limitation.

- **Single SYSTEM**

The SYSTEM SOFTWARE is licensed with the SYSTEM as a single integrated product. The SYSTEM SOFTWARE installed in Read Only Memory (ROM) of the SYSTEM may only be used as part of the SYSTEM.

- **Single EULA**

The package for the SYSTEM SOFTWARE may contain multiple versions of this EULA, such as multiple translations and/or multiple media versions (e.g., in the user documentation and in the software). Even if you receive multiple versions of the EULA, you are licensed to use only one (1) copy of the SYSTEM SOFTWARE.

- **Rental**

You may not rent or lease the SOFTWARE.

- **Software Transfer**

You may permanently transfer all of your rights under this EULA only as part of a sale or transfer of the SYSTEM, provided you retain no copies, you transfer all of the SOFTWARE (including all component parts, the media, any upgrades or backup copies, this EULA and, if applicable, the Certificate(s) of Authenticity), and the recipient agrees to the terms of this EULA. If the SOFTWARE is an upgrade, any transfer must include all prior versions of the SOFTWARE.

- **Termination**

Without prejudice to any other rights, MANUFACTURER or MS may terminate this EULA if you fail to comply with the terms and conditions of this EULA. In such event, you must destroy all copies of the SOFTWARE and all of its component parts.

3. Upgrades

If the SYSTEM SOFTWARE and this EULA are provided separate from the SYSTEM by MANUFACTURER and the SYSTEM SOFTWARE is on a ROM chip, CD ROM disk(s) or floppy disk(s), and labeled “For ROM Upgrade Purposes Only” (“ROM Upgrade”), you may install one copy of the ROM Upgrade onto the SYSTEM as a replacement copy for the SYSTEM SOFTWARE originally installed on the SYSTEM and use it in accordance with Section 1 of this EULA.

4. Copyright

All title and copyrights in and to the SOFTWARE (including but not limited to any images, photographs, animations, video, audio, music, text and “applets,” incorporated into the SOFTWARE), the accompanying printed materials, and any copies of the SOFTWARE, are owned by MS or its suppliers (including Microsoft Corporation). You may not copy the printed materials accompanying the SOFTWARE. All rights not specifically granted under this EULA are reserved by MS and its suppliers (including Microsoft Corporation).

5. Product Support

Product support for the SOFTWARE is not provided by MS, its parent corporation, Microsoft Corporation, or their affiliates or subsidiaries. For product support, please refer to MANUFACTURER's support number provided in the documentation for the SYSTEM. Should you have any questions concerning this EULA, or if you desire to contact MANUFACTURER for any other reason, please refer to the address provided in the documentation for the SYSTEM.

6. Export Restrictions

You agree that you will not export or re-export the SOFTWARE to any country, person, or entity subject to U.S. export restrictions. You specifically agree not to export or re-export the SOFTWARE: (i) to any country to which the U.S. has embargoed or restricted the export of goods or services, which as of March 1998 include, but are not necessarily limited to Cuba, Iran, Iraq, Libya, North Korea, Sudan and Syria, or to any national of any such country, wherever located, who intends to transmit or transport the products back to such country; (ii) to any person or entity who you know or have reason to know will utilize the SOFTWARE or portion thereof in the design, development or production of nuclear, chemical or biological weapons; or (iii) to any person or entity who has been prohibited from participating in U.S. export transactions by any federal agency of the U.S. government.

If the SOFTWARE is labeled "North America Only Version" above, on the Product Identification Card, or on the SOFTWARE packaging or other written materials, then the following applies: The SOFTWARE is intended for distribution only in the United States, its territories and possessions (including Puerto Rico, Guam, and U.S. Virgin Islands) and Canada. Export of the SOFTWARE from the United States is regulated under "EI controls" of the Export Administration Regulations (EAR, 15 CFR 730-744) of the U.S. Commerce Department, Bureau of Export Administration (BXA). A license is required to export the SOFTWARE outside the United States or Canada. You agree that you will not directly or indirectly, export or re-export the SOFTWARE (or portions thereof) to any country, other than Canada, or to any person or entity subject to U.S. export restrictions without first obtaining a Commerce Department export license. You warrant and represent that neither the BXA nor any other U.S. federal agency has suspended, revoked or denied your export privileges.

7. Note on Java Support

The SYSTEM SOFTWARE may contain support for programs written in Java. Java technology is not fault tolerant and is not designed, manufactured, or intended for use or resale as on-line control equipment in hazardous environments requiring fail-safe performance, such as in the operation of nuclear facilities, aircraft navigation or communication systems, air traffic control, direct life support machines, or weapons systems, in which the failure of Java technology could lead directly to death, personal injury, or severe physical or environmental damage.

8. Limited Warranty

• Limited Warranty

MANUFACTURER warrants that the SOFTWARE will perform substantially in accordance with the accompanying written materials for a period of ninety (90) days from the date of receipt. Any implied warranties on the SOFTWARE are limited to ninety (90) days. Some states/jurisdictions do not allow limitations on duration of an implied warranty, so the above limitation may not apply to you.

• Customer Remedies

MANUFACTURER'S and its suppliers' entire liability and your exclusive remedy shall be, at MANUFACTURER'S option, either (a) return of the price paid, or (b) repair or replacement of the SOFTWARE that does not meet the above Limited Warranty and which is returned to MANUFACTURER with a copy of your receipt. This Limited Warranty is void if failure of the SOFTWARE has resulted from accident, abuse, or misapplication. Any replacement SOFTWARE will be warranted for the remainder of the original warranty period or thirty (30) days, whichever is longer.

• No Other Warranties

EXCEPT AS EXPRESSLY PROVIDED IN THE LIMITED WARRANTY SECTION ABOVE, THE SOFTWARE IS PROVIDED TO THE END USER "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, WARRANTIES OF NON-INFRINGEMENT, MERCHANTABILITY, AND/OR FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK OF THE QUALITY AND PERFORMANCE OF THE SOFTWARE IS WITH YOU.

• No Liability for Consequential Damages

MANUFACTURER OR MANUFACTURER'S SUPPLIERS, INCLUDING MS AND ITS SUPPLIERS, SHALL NOT BE HELD TO ANY LIABILITY FOR ANY DAMAGES SUFFERED OR INCURRED BY THE END USER (INCLUDING, BUT NOT LIMITED TO, GENERAL, SPECIAL, CONSEQUENTIAL OR INCIDENTAL DAMAGES INCLUDING DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, LOSS OF BUSINESS INFORMATION AND THE LIKE), ARISING FROM OR IN CONNECTION WITH THE DELIVERY, USE OR PERFORMANCE OF THE SOFTWARE.

If you acquired this EULA in the United States, this EULA is governed by the laws of the State of Washington.

If you acquired this EULA in Canada, this EULA is governed by the laws of the Province of Ontario, Canada. Each of the parties hereto irrevocably attorns to the jurisdiction of the courts of the Province of Ontario and further agrees to commence any litigation which may arise hereunder in the courts located in the Judicial District of York, Province of Ontario.

If this EULA was acquired outside the United States, then local law may apply.

Should you have any questions concerning this EULA, please contact the MANUFACTURER of your SYSTEM.

U.S. GOVERNMENT RESTRICTED RIGHTS

The SOFTWARE and documentation are provided with RESTRICTED RIGHTS. Use, duplication, or disclosure by the Government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.227-7013 or subparagraphs (c)(1) and (2) of the Commercial Computer Software—Restricted Rights at 48 CFR 52.227- 19, as applicable. MANUFACTURER is Microsoft Corporation/One Microsoft Way/Redmond, WA 98052-6399.



Contents

Product Overview

1 About the Reference Guide

- Overview 3
- Guide Conventions 4
 - Text Format 4
 - UI Menu Control 5

2 Introducing the 3000 Series Windows-based Terminals

- Model 3000 Terminals 7
- Models Summary 7
 - Models 3315SE/3320SE Terminals 8
 - Model 3350SE Terminal 9
 - Models 3515SE, 3715SE, and 3720SE Terminals 10

3 General Terminal Information

- Using the General Properties Sheet 11
 - Resetting to Factory Defaults 12
- Using the SysInfo Properties Sheet 13
- Using the About Properties Sheet 14

4 Terminal Features

- Terminal Features 15

5 Terminal Specifications

- Terminal Specifications 17

Installation Procedures

6 Models 3315SE/3320SE Terminal Installation

- Locating the Terminal 27
- Connecting the Terminal 27
- Mounting the Terminal 31
 - Freestanding Desktop Mounting 31
 - Wall Mounting 32
- Cable Retaining Clip and Shroud Installation 34
- Turning On the Terminal 36

7 Model 3350SE Terminal Installation

- Locating the Terminal 37
- Connecting the Terminal 37
- Mounting the Terminal 40
 - Freestanding Desktop Mounting 40
 - Permanent Desktop Mounting 41
 - Wall Mounting 41
- Shroud Attachment 43
- Turning On the Terminal 44

8 Models 3515SE/3715SE/3720SE Terminal Installation

- Locating the Terminal 45
- Connecting the Terminal 45
- Turning On the Terminal 47
 - Display Adjustments 48

9 Modem Card Installation

- About Modem Cards 53
- Installation and Removal 54
 - Installation 54
 - Removal 57
- Configuration 58
 - Modem Initialization Strings 58

10 Noise Suppressor Installation

- Noise Suppressor Installation 59

Terminal Management

11 Initial Terminal Setup

Using the Setup Wizard 63

12 Changing Terminal Properties

Using the Terminal Properties Dialog Box 72

13 Display Configuration

Using the Display Properties Sheet 74

14 Input Configuration

Using the Input Properties Sheet 76

15 Network Configuration

Using the Network Properties Sheet 80

16 Connections Management

Using the Connections Properties Sheet 84

Using the Configure Properties Sheet 85

17 ICA Client Settings

Setting the Default Hotkeys 87

Setting Terminal Preferences 89

Setting the Server Location 91

18 Multiple Sessions

Starting Multiple Sessions 93

Manipulating Multiple Sessions 94

19 Additional Applications

Using the Apps Properties Sheet 96

20 Shutting Down the Terminal

Using the Shutdown Window Dialog Box 99

Using the Terminal Settings Change Dialog Box 100

Connection Configuration

21 Creating New Connections

- Choosing a Connection Protocol 103
- Using the Startup Function 104
- Startup Options 105

22 ICA Connections

- Using the Specify Connection Type Dialog Box 107
- Network Connections 108
- Dial-In Connection 112

23 Dial-Up Connections

- Using the Dial-Up Configuration Wizard 113

24 Using the Dialing Properties and Configure Command Buttons

- Using the Dialing Properties Dialog Box 118
- Using the Device Properties Dialog Box 119
 - Port Settings 120
 - Call Options 120

25 Using the TCP/IP Settings and Security Command Buttons

- Using the TCP/IP Settings Dialog Box 123
- Using the Security Settings Dialog Box 125

26 RDP Connections

- Using the WTS Connection Wizard 127

27 Terminal Emulation Connections

- Using the TE Client Connection Wizard 131
 - Using the TCP/IP Telnet Configuration Dialog Box 136
 - Using the Modem Settings Dialog Box 139
 - Using the Configuration of Serial Cable on Com1 Dialog Box 140

28 Editing Connections

- Using the Properties Dialog Box 142
 - Using the Net Connections Properties Sheet 142
 - Using the Application Properties Sheet 144

29 Modem Connection Configuration

- Using the Devices Properties Sheet 148
 - ISDN Settings 149
 - Adding or Changing Modems 151

Terminal Firmware Upgrades

30 Cable Firmware Upgrades

- Setup 155
- Flash Parallel Download Procedure 156
 - Manual Download 156
 - Auto Download 157
- Cable Pinouts 158
 - Parallel Download Cable Pinouts 158

31 FTP Pull Firmware Upgrades

- Using the Upgrade Properties Sheet 162
 - FTP and Bootstrap.exe 163
- The Upgrade Process 163

32 Administering Terminals Using SNMP

- Using the SNMP Network Administration Dialog Box 168

33 SNMP Upgrades

- Manual SNMP Firmware Upgrades 171

34 Changing DHCP Option IDs

- Using the Change DHCP Option IDs Dialog Box 174

35 DHCP Firmware Upgrades

- Automatic DHCP Firmware Upgrades 177
- Manual DHCP Firmware Upgrades 178

Client Security

- 36 Security Properties**
 - Using the Security Properties Sheet 182
- 37 Terminal Accounts**
 - Guest Accounts 185
 - User Accounts 186
 - Administrator Accounts 186
 - Using Terminal Accounts 186
- 38 Creating Terminal Accounts**
 - Using the Add User Account Dialog Box 188
- 39 Modifying and Deleting Terminal Accounts**
 - Using the Modify User Account Dialog Box 192
 - Deleting Terminal Accounts 194
- 40 Terminal Login**
 - Logging Into the Terminal 197
 - Autologin and Autoconnect 198
 - Autologin 198
 - AutoStart 198
 - Single Button Connect 199
- 41 Failover**

Getting Help

- 42 Troubleshooting Your Terminal**
- 43 Terminal Port Pin Assignments**
 - Serial and Parallel Ports 209
- 44 Terminal Connector Pin Assignments**
 - 10Base-T and 100Base-T Connector 211
 - VGA Connector 212
 - USB Connector 213
- 45 Null Modem Cable Pin Assignments**
- 46 Modem AT Commands**

Glossary

Index

List of Figures

- 2-1 3315SE/3320SE Terminal 8
- 2-2 3350SE Terminal 9
- 2-3 3515SE/3715SE/3720SE Terminal 10
- 3-1 General Properties Sheet 11
- 3-2 System Settings Change Dialog Box 12
- 3-3 SysInfo Properties Sheet 13
- 3-4 About Properties Sheet 14
- 6-1 3315SE/3320SE Terminal Back Panel Connectors 28
- 6-2 3315SE/3320SE Freestanding Desktop Mounting 31
- 6-3 3315SE/3320SE Optional Wall Mount Configuration 32
- 6-4 3315SE/3320SE Cable Retaining Clip Installation 34
- 6-5 3315SE/3320SE Shroud Installation 35
- 6-6 3315SE/3320SE Power Management Button 36
- 7-1 3350SE Terminal Back Panel Connectors 38
- 7-2 3350SE Wall Mount Configuration 42
- 7-3 3350SE Power Management Button 44
- 8-1 3515SE/3715SE/3720SE Terminal Back Panel Connectors 46
- 8-2 3515SE/3715SE/3720SE Terminal Front Panel 48
- 8-3 3515SE/3715SE OSD (On-Screen Display) Menu 49
- 8-4 3515SE/3715SE/3720SE Recall Mode 51
- 9-1 Modem Card 53
- 9-2 Installing the Modem Card 55
- 9-3 Connecting the Modem Card Cable 56
- 9-4 Inserting the Plug 58
- 10-1 Noise Suppressor 59
- 11-1 Welcome Dialog Box 64
- 11-2 EULA (End User License Agreement) Dialog Box 65
- 11-3 IP Address Dialog Box 66
- 11-4 Specify an IP Address Dialog Box 67
- 11-5 Optional Information Dialog Box 68
- 11-6 Desktop Area and Refresh Frequency Dialog Box 69
- 11-7 Finish Dialog Box 70
- 12-1 Terminal Properties Dialog Box 71
- 13-1 Display Properties Sheet 73
- 15-1 Network Properties Sheet 79
- 16-1 Winterm Connection Manager Dialog Box 83
- 16-2 Configure Properties Sheet 85

17-1	Default Hotkeys Properties Sheet	87
17-2	Preferences Properties Sheet	89
17-3	Server Location Properties Sheet	91
19-1	Apps Properties Sheet	95
20-1	Shutdown Window Dialog Box	99
20-2	Terminal Settings Change Dialog Box	100
21-1	New Connection Dialog Box	103
21-2	Connection Startup Dialog Box	104
22-1	Specify Connection Type Dialog Box	107
22-2	Citrix Search Message	108
22-3	Select a Citrix Server or Published Application Dialog Box	108
22-4	Server Location Dialog Box	109
22-5	Add Server Address Dialog Box	109
22-6	Specify an Application Dialog Box	109
22-7	Specify Logon Information Dialog Box	110
22-8	Select Window Options Dialog Box	110
22-9	Compression, Cache, and Sound Dialog Box	111
22-10	Select a Title for the ICA Connection Dialog Box	111
22-11	Dial-In Devices Dialog Box	112
23-1	Dial-Up Configuration Wizard 1	113
23-2	Dial-Up Configuration Wizard 2	114
23-3	Dial-Up Configuration Wizard 3	115
24-1	Dialing Properties Dialog Box	117
24-2	Device Properties Dialog Box	119
24-3	Call Options Properties Sheet	120
25-1	TCP/IP Settings Dialog Box	123
25-2	Security Settings Dialog Box	125
26-1	WTS Connection Wizard 1	127
26-2	WTS Connection Wizard 2	128
26-3	WTS Connection Wizard 3	129
26-4	WTS Connection Wizard 4	130
27-1	TE Client Connection Wizard - Connection Information	131
27-2	TE Client Connection Wizard - Host Information	133
27-3	TE Client Connection Wizard - Automate Login Process	134
27-4	TE Client Connection Wizard - Printer Port Settings	135
27-5	TCP/IP Telnet Configuration Dialog Box	136
27-6	Modem Settings Dialog Box	139
27-7	Configuration of Serial Cable on Com1 Dialog Box	140
28-1	Properties Dialog Box	141
28-2	Application Properties Sheet	144
29-1	Devices Properties Sheet	147
29-2	ISDN Settings Dialog Box	149
29-3	Add or Change Modem Dialog Box	151
30-1	Download Utility Dialog Box	156
30-2	Parallel Download Cable Connectors	159

31-1	Upgrade Properties Sheet	161
31-2	Firmware Upgrade Dialog Box 1	164
31-3	Firmware Upgrade Dialog Box 2	164
31-4	Firmware Upgrade Dialog Box 3	165
32-1	SNMP Network Administration Dialog Box	167
34-1	Change DHCP Option IDs Dialog Box	173
35-1	Obtain an IP Address From DHCP Sever Radio Button	177
35-2	DHCP Automatic Update Enable Check Box	177
36-1	Security Properties Sheet	181
39-1	Modify User Account Dialog Box	191
39-2	Delete User Account Confirmation Dialog Box	195
40-1	Terminal Login Dialog Box	197
40-2	Autologin Dialog Box	198
40-3	Single Button Connect Dialog Box	199
41-1	Failover Message Box	202
41-2	Failover Log Window Dialog Box	202
43-1	Serial Port	209
43-2	Parallel Port (EPP/SPP)	210
44-1	10Base-T and 100Base-T Connector	211
44-2	VGA Connector	212
44-3	USB Connector	213

List of Tables

1-1	Text Format Conventions	4
1-2	UI Menu Control	5
4-1	Terminal Features	15
5-1	Specifications for the 3315SE, 3320SE, and 3350SE Terminals	17
5-2	Specifications for the 3515SE, 3715SE, and 3720SE Terminals	21
6-1	3315SE/3320SE Terminal Back Panel Connectors	29
7-1	3350SE Terminal Back Panel Connectors	38
8-1	3515SE/3715SE/3720SE Terminal Back Panel Connectors	46
8-2	3515SE/3715SE/3720SE Terminal Front Panel	49
8-3	3515SE/3715SE/3720SE OSD Menu	50
13-1	Display Properties Sheet	74
14-1	Input Properties Sheet	76
15-1	Network Properties Sheet	80
16-1	Connections Properties Sheet	84
16-2	Configure Properties Sheet	86
17-1	Default Hotkeys Properties Sheet	88
17-2	Preferences Properties Sheet	90
17-3	Server Location Properties Sheet	91
19-1	Apps Properties Sheet	96
20-1	Shutdown Window Dialog Box	100

24-1	Dialing Properties Dialog Box	118
24-2	Port Settings Properties Sheet	120
24-3	Call Options Properties Sheet	121
25-1	TCP/IP Settings Dialog Box	124
25-2	Security Settings Dialog Box	125
27-1	Terminal Emulation and Terminal Type	132
27-2	TCP/IP Telnet Configuration	136
27-3	Modem Settings Dialog Box	139
27-4	Configuration of Serial Cable on Com1 Dialog Box	140
28-1	Net Connections Properties Sheet	143
28-2	Application Properties Sheet	145
29-1	Devices Properties Sheet	148
29-2	ISDN Settings Dialog Box	150
29-3	Add or Change Modem Dialog Box	152
30-1	Parallel Download Cable Pinouts	158
31-1	Upgrade Properties Sheet	162
32-1	SNMP Network Administration Dialog Box	168
34-1	Change DHCP Option IDs Dialog Box	174
36-1	Security Properties Sheet	182
38-1	Add User Account Dialog Box	188
39-1	Modify User Account Dialog Box	192
42-1	Troubleshooting Your Terminal	205
45-1	Null Modem Cable Pin Assignments	215
46-1	AT Commands with No Lead-in Character	217
46-2	AT Commands Beginning with "&"	218
46-3	AT Commands Beginning with "\"	219
46-4	AT Commands Beginning with "%"	219



Product Overview

- 1 About the Reference Guide**
- 2 Introducing the 3000 Series Windows-based Terminals**
- 3 General Terminal Information**
- 4 Terminal Features**
- 5 Terminal Specifications**

1

About the Reference Guide

Overview

The *Wyse Winterm 3000 Series Windows-based Terminal Reference Guide* contains the information you will need to install, configure, connect, and troubleshoot a WBT (Windows-based Terminal). This guide is written for both users and administrators, and covers the Models 3315SE, 3320SE, 3350SE, 3515SE, 3715SE, and 3720SE terminals.

The reference guide consists of the following sections:

- Product Overview
- Installation Procedures
- Terminal Management
- Connection Configuration
- Terminal Firmware Upgrades
- Client Security
- Getting Help

This guide contains information about:

- Terminal features, specifications, installation, and management
- The UI (User Interface)
- Physical and network connections, and protocols used
- Firmware upgrades
- Terminal security
- Getting help



Note

The Adobe Acrobat version of this guide features a link to the Wyse home page at www.wyse.com.

Guide Conventions

Text Format

Table 1-1 lists the text format conventions used in this document.

Table 1-1 Text Format Conventions

Convention	Where Used
<i>Italic</i>	New term, book title or emphasis.
Bold	Screen display, keycaps, and user input.
 Note	Indicates a note. A note adds information.
 Caution	Indicates a caution. A caution indicates actions that may cause damage to equipment, erase files, or destroy data.
+	Keystroke sequences such as: Ctrl+Alt+Del
	Instructions about invoking a menu such as: Network SNMP Network Location

UI Menu Control

Table 1-2 describes the command buttons used for UI menu control on a 3000 series WBT.

Table 1-2 UI Menu Control

Command Button	Function
X	Found in the upper right corner of a dialog box. Click on this command button to quit a dialog box or properties sheet without saving changes.
OK	Found in dialog boxes and on properties sheets. Click on this command button to save your changes and quit a dialog box or properties sheet.
Cancel	Found in dialog boxes and on properties sheets. Click on this command button at any time to quit a dialog box or properties sheet without saving changes.
Apply	Sometimes not activated and found in dialog boxes and on properties sheets. Click on this command button to save changes without quitting a dialog box or properties sheet.
Next or Accept	Found in wizards. Click on these command buttons to display the next dialog box in the sequence.
Back	Found in wizards. Click on this command button to return to the previous dialog box.
Finish	Found in wizards. Click on this command button to return to finish the wizard.



2

Introducing the 3000 Series Windows-based Terminals

Model 3000 Terminals

Winterm 3000 series WBTs (Windows-based Terminals) are designed to connect to WTS (Windows Terminal Server) servers via RDP (Remote Desktop Protocol), to Windows NT applications servers via ICA (Independent Computing Architecture), or to various terminal emulations. RDP is the Windows CE-based protocol for connecting to Windows terminal servers. ICA is a distributed presentation services protocol for Windows NT servers, allowing an application's user interface to execute on a Windows-based terminal while the application's logic executes on the server.

Models Summary

There are six models of Winterm 3000 series terminals:

- Modular type, Models 3315SE, 3320SE, and 3350SE
- Integrated-CRT type, Models 3515SE, 3715SE, and 3720SE

Models 3315SE/3320SE Terminals

The Models 3315SE and 3320SE terminals are standard modular-type 3000 series terminals. The connections for peripherals such as the monitor, keyboard, and mouse are on the back of the terminal. The following figure shows a modular terminal.

Figure 2-1 3315SE/3320SE Terminal



The following items are provided with the Models 3315SE and 3320SE terminals:

- Power supply and power cord
- Desktop mounting stand (an optional wall-mount bracket is also available; for more information call 1-800-800-WYSE (9973))
- Cable shroud and cable clip
- Keyboard (with domestic versions only) and mouse
- Installation and user information

Model 3350SE Terminal

The Model 3350SE terminal is the enhanced modular type 3000 series terminal. The connections for peripherals such as the monitor, keyboard, and mouse are on the back of the terminal. The following figure shows a Model 3350SE terminal.

Figure 2-2 3350SE Terminal



The following items are provided with the Model 3350SE terminal:

- Power supply and power cord
- Cable shroud
- Keyboard (with domestic versions only) and mouse
- Installation and user information
- An optional wall-mount bracket is also available. For more information call 1-800-800-WYSE (9973).

Monitors are not provided with Models 3315SE, 3320SE, and 3350SE terminals. You must provide the standard VGA monitor and video interface cable for your monitor. The cable must have a 15-pin plug connector to attach to the video connector on the back of the terminal.

Models 3515SE, 3715SE, and 3720SE Terminals

Models 3515SE, 3715SE, and 3720SE, the terminals described below, are the integrated-CRT 3000 series terminals. The connections for peripherals such as keyboard and mouse are on the back of the terminal. The following figure shows an integrated-CRT terminal.

Figure 2-3 3515SE/3715SE/3720SE Terminal



The following items are provided with the 3315SE, 3715SE, and 3720SE terminals:

- Power cord
- Keyboard (with domestic versions only) and mouse
- Installation and user information


3

General Terminal Information

There are three properties sheets in the UI that provide general terminal information. They are the **General** properties sheet (Figure 3-1), the **SysInfo** properties sheet (Figure 3-2), and the **About** properties sheet (Figure 3-3).

Using the General Properties Sheet

Figure 3-1 General Properties Sheet



**Note**

The amount of RAM that is available depends on the model of terminal in use.

The **General** properties sheet displays information that includes the name of the product and information about the current software.


Invoke this properties sheet from the **Winterm Connection Manager** by pressing the **F2** key. The **Terminal Properties** dialog box displays. The **General** properties sheet is the default sheet for the **Terminal Properties** dialog box. Read the information on this sheet.

Resetting to Factory Defaults

There is one function on the General properties sheet, **Reset the Terminal Factory Default Property Settings**. To use this function to reset the terminal to factory default settings:

1. Click on the **Reset the Terminal Factory Default Property Settings** check box. Figure 3-2 shows the dialog box that displays.
2. Click on **Yes** to return to the **Terminal Properties** dialog box.
3. Click on **OK** in the **Terminal Properties** dialog box. (The **Terminal Settings Change** dialog box displays. See “Shutting Down the Terminal” for more information about this dialog box).
4. Click on **Restart** in the **Terminal Settings Change** dialog box to reset to factory defaults.

Figure 3-2 System Settings Change Dialog Box



Using the SysInfo Properties Sheet

Figure 3-3 SysInfo Properties Sheet

The screenshot shows a window titled "Terminal Properties" with a close button (X) in the top right corner. Below the title bar is a tabbed interface with the following tabs: General, Input, Display, Network, Upgrade, Security, Apps, Devices, SysInfo (selected), and About. The SysInfo tab is active and displays the following settings:

Network Card	
MAC Address:	XX:XX:XX:XX:XX:XX
Serial Number:	XX:XX:XX:XX

DHCP Settings	
DHCP:	Enable
Lease:	30 min
Elapsed:	2 min

TCP/IP Settings	
IP Address:	132.237.14.93
Subnet Mask:	255.255.255.0
Gateway:	132.237.14.1
DNS:	Enable
Default Domain:	wyse.com
DNS Servers:	132.237.2.26, 132.237.2.174
WINS:	Enable
WINS Servers:	132.237.40.2

At the bottom of the dialog box are three buttons: OK, Cancel, and Apply.



Note

Addresses used in the illustration above are representative only.


The **SysInfo** properties sheet contains network information. To invoke this properties sheet:

1. Press **F2** while you are in the **Winterm Connection Manager**.
2. Click on the **SysInfo** tab in the **Terminal Properties** dialog box.

This properties sheet is informational. No user interaction is required.

Using the About Properties Sheet

Figure 3-4 About Properties Sheet



The **About** properties sheet contains copyright information about the terminal. To invoke this properties sheet:

1. Pressing **F2** while you are in the **Winterm Connection Manager**.
2. Clicking on the **About** tab in the **Terminal Properties** dialog box.

The **About** properties sheet is informational. No user interaction is required.

4 Terminal Features

Terminal Features

The following table outlines the features of the different models of 3000 Series WBTs.

Table 4-1 Terminal Features

Feature	3315SE	3320SE	3350SE	3515SE	3715SE	3720SE
Windows 3.1, Windows 95, and Windows NT applications via Windows Terminal Server	✓	✓	✓	✓	✓	✓
RDP and ICA 3.x application compliant	✓	✓	✓	✓	✓	✓
ICA server connections via serial cable	✓	✓	✓	✓	✓	✓
10Base-T network communications	✓	✓	✓	✓	✓	✓
100Base-T network communications		✓	✓			✓
Dual high-speed serial ports	✓	✓	✓	✓	✓	✓
Parallel printer port	✓	✓	✓	✓	✓	✓
Dual USB ports			✓			

Table 4-1 Terminal Features, Continued

Feature	3315SE	3320SE	3350SE	3515SE	3715SE	3720SE
Optional touch screen	✓	✓	✓	✓	✓	✓
Support for monochrome or color monitor	✓	✓	✓			
Desktop (standard) or wall-mounted (optional) housing	✓	✓	✓			
Support for PCMCIA modem	✓	✓	✓	✓	✓	✓

5 Terminal Specifications

Terminal Specifications

Table 5-1 lists the specifications for the modular terminals.

Table 5-1 Specifications for the 3315SE, 3320SE, and 3350SE Terminals

Specification	3315SE	3320SE	3350SE
Power Requirements			
Voltage	90 to 264V ac, Worldwide autosensing	90 to 264V ac, Worldwide autosensing	90 to 264V ac, Worldwide autosensing
Frequency	47-63 Hz	47-63 Hz	47-63 Hz
Power Consumption	8W operating	16W operating	16W operating
Physical Characteristics			
Height	22.6 cm (8.9 in)	22.6 cm (8.9 in)	22.6 cm (8.9 in)
Width	6.0 cm (2.36 in)	6.0 cm (2.36 in)	6.0 cm (2.36 in)
Depth	17.4 cm (6.85 in)	17.4 cm (6.85 in)	17.4 cm (6.85 in)
Net Weight	1.7 kgs (3.7 lbs)	1.7 kgs (3.7 lbs)	1.97 kgs (4.125 lbs)
Power Cord	6 ft (1.83m)	6 ft (1.83m)	6 ft (1.83m)

Table 5-1 Specifications for the 3315SE, 3320SE, and 3350SE Terminals, Continued

Specification	3315SE	3320SE	3350SE
Environmental			
Operating Temperature	0° to 40°C (32° to 104°F)	10° to 40°C (50° to 104°F)	0° to 40°C (32° to 104°F)
Nonoperating Temperature	–10° to 60°C (14° to 140°F)	–10° to 60°C (14° to 140°F)	–10° to 60°C (14° to 140°F)
Operating Humidity	10% to 95% noncondensing	20% to 80% noncondensing	80% maximum, noncondensing
Storage Humidity	95% maximum, noncondensing	80% maximum, noncondensing	95% maximum, noncondensing
Operating Altitude	0 to 10,000 ft ASL	0 to 10,000 ft ASL	0 to 10,000 ft ASL
Nonoperating Altitude	0 to 40,000 ft ASL	0 to 40,000 ft ASL	0 to 40,000 ft ASL
Cooling System	Convection, fanless	Convection, fanless	Convection, fanless
EPA			
Energy Saving	Automatic power-down sleep mode	Automatic power-down sleep mode	Automatic power-down sleep mode
Regulatory Compliance			
EMC Terminal/Power Brick	FCC B	FCC B	FCC B
Safety Power Brick	• UL1950 • CSA950 • Japan T mark	• UL1950 • CSA950 • Japan T mark	• UL1950 • CSA950 • Japan T mark

Table 5-1 Specifications for the 3315SE, 3320SE, and 3350SE Terminals, Continued

Specification	3315SE	3320SE	3350SE
Safety, terminal	• UL1950 • CSA 950 • TUV-GS approved • EN 60950 approved • NOM	• UL1950 • CSA 950 • TUV-GS approved • EN 60950 approved • NOM	• UL1950 • CSA 950 • TUV-GS approved • EN 60950 approved • NOM
RF Interference	• FCC Class B • EN55022B • CE Mark • VCCI • BCIQ	• FCC Class B • EN55022B • CE Mark • VCCI • BCIQ	• FCC Class B • EN55022B • CE Mark • VCCI • BCIQ
Ergonomics	• ZH1/618 • EN29241-3	• ZH1/618 • EN29241-3	• ZH1/618 • EN29241-3
Communications Ports			
Serial Port	• Com1 is a 16C550 (FIFO), up to 115.2 kBaud RS-423/232, DB-9M connector • Com2 is a 16C550 (FIFO), up to 115.2 kBaud RS-232, DB-9M connector	• Com1 is a 16C550 (FIFO), up to 115.2 kBaud RS-423/232, DB-9M connector • Com2 is a 16C550 (FIFO), up to 115.2 kBaud RS-232, DB-9M connector	• Com1 is a 16C550 (FIFO), up to 115.2 kBaud RS-423/232, DB-9M connector • Com2 is a 16C550 (FIFO), up to 115.2 kBaud RS-232, DB-9M connector
Parallel Port	Centronics compatible, DB-25M connector	Centronics compatible, DB-25M connector	Centronics compatible, DB-25M connector
Ethernet Port	10Base-T network	10Base-T or 100Base-T network	10Base-T or 100Base-T network

Table 5-1 Specifications for the 3315SE, 3320SE, and 3350SE Terminals, Continued

Specification	3315SE	3320SE	3350SE
USB	N/A	N/A	Type A 4-pin receptacle
Battery	N/A	CR2032 Lithium, coin-type, 3V battery (see Caution)	CR2032 Lithium, coin-type, 3V battery (see Caution)



Caution

Your terminal may contain a battery. There is a danger of explosion if the battery is incorrectly replaced. Replace the battery with only the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer’s instructions.

Table 5-2 lists the specifications for the integrated-CRT terminals.

Table 5-2 Specifications for the 3515SE, 3715SE, and 3720SE Terminals

Specification	3515SE	3715SE	3720SE
Power Requirements			
Voltage	90 to 264V ac, Worldwide autosensing	90 to 264V ac, Worldwide autosensing	90 to 264V ac, Worldwide autosensing
Frequency	47-63 Hz	47-63 Hz	47-63 Hz
Power Consumption	80W operating	80W operating	80W operating
Physical Characteristics			
Height	38.8cm (15.3 in)	38.8 cm (15.3 in)	38.8 cm (15.3 in)
Width	36.0 cm (14.2 in)	36.0 cm (14.2 in)	36.0 cm (14.2 in)
Depth	40.6 cm (16.0 in)	40.6 cm (16.0 in)	40.6 cm (16.0 in)
Net Weight	40 lbs (18.2 kgs)	48 lbs (21.8 kgs)	48 lbs (21.8 kgs)
Power Cord	6 ft (1.83m)	6 ft (1.83m)	6 ft (1.83m)
Environmental			
Operating Temperature	0 to 40°C (32 to 104°F)	10° to 40°C (50° to 104°F)	10° to 40°C (50° to 104°F)
Nonoperating Temperature	-10 to 60°C (-14 to 140°F)	-20° to 60°C (-4° to 140°F)	-20° to 60°C (-4° to 140°F)
Operating Humidity	10% to 95% noncondensing	80% maximum, noncondensing	80% maximum, noncondensing
Storage Humidity	80% maximum, noncondensing	80% maximum, noncondensing	80% maximum, noncondensing

Table 5-2 Specifications for the 3515SE, 3715SE, and 3720SE Terminals, Continued

Specification	3515SE	3715SE	3720SE
Operating Altitude	0 to 10,000 ft ASL	0 to 10,000 ft ASL	0 to 10,000 ft ASL
Nonoperating Altitude	0 to 40,000 ft ASL	0 to 40,000 ft ASL	0 to 40,000 ft ASL
Cooling System	Convection, fanless	Convection, fanless	Convection, fanless
EPA			
Energy Saving	Automatic power-down sleep mode	Automatic power-down sleep mode	Automatic power-down sleep mode
	EPA Energy Star	EPA Energy Star	EPA Energy Star
Regulatory Compliance			
EMC Terminal/Power Brick	N/A	N/A	N/A
Safety, power brick	N/A	N/A	N/A
Safety, terminal	• UL1950 • CSA 950 • TUV-GS approved • EN 60950 approved • DHHS • SEMKO • DEMKO • NEMKO • FIMKO	• UL1950 • CSA 950 • TUV-GS approved • EN 60950 approved • DHHS • SEMKO • DEMKO • NEMKO • FIMKO	• UL1950 • CSA 950 • TUV-GS approved • EN 60950 approved • DHHS • SEMKO • DEMKO • NEMKO • FIMKO
RF Interference	• FCC Class B • EN55022B • CE Mark	• FCC Class B • EN55022B • CE Mark	• FCC Class B • EN55022B • CE Mark

Table 5-2 Specifications for the 3515SE, 3715SE, and 3720SE Terminals, Continued

Specification	3515SE	3715SE	3720SE
Ergonomics	• German Zh1/618 • EN29241-3, -8 • MPR 1990:10 guidelines for low electromagnetic and low electrostatic emissions	• German Zh1/618 • EN29241-3, -8 • MPR 1990:10 guidelines for low electromagnetic and low electrostatic emissions	• German Zh1/618 • EN29241-3, -8 • MPR 1990:10 guidelines for low electromagnetic and low electrostatic emissions
Communications Ports			
Serial	• Com1 is a 16C550 (FIFO), up to 115.2 kBaud RS-423/232, DB-9M connector • Com2 is a 16C550 (FIFO), up to 115.2 kBaud RS-232, DB-9M connector	• Com1 is a 16C550 (FIFO), up to 115.2 kBaud RS-423/232, DB-9M connector • Com2 is a 16C550 (FIFO), up to 115.2 kBaud RS-232, DB-9M connector	• Com1 is a 16C550 (FIFO), up to 115.2 kBaud RS-423/232, DB-9M connector • Com2 is a 16C550 (FIFO), up to 115.2 kBaud RS-232, DB-9M connector
Parallel	Centronics compatible, DB-25M connector	Centronics compatible, DB-25M connector	Centronics compatible, DB-25M connector
Network	10Base-T network	10Base-T network	10Base-T or 100Base-T network

Table 5-2 Specifications for the 3515SE, 3715SE, and 3720SE Terminals, Continued

Specification	3515SE	3715SE	3720SE
Battery	N/A	N/A	CR2032 Lithium, coin-type, 3V battery (see Caution)



Caution

Your terminal may contain a battery. There is a danger of explosion if the battery is incorrectly replaced. Replace the battery with only the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer’s instructions.



Installation Procedures

- 6 Models 3315SE/3320SE Terminal Installation**
- 7 Model 3350SE Terminal Installation**
- 8 Models 3515SE/3715SE/3720SE Terminal Installation**
- 9 Modem Card Installation**
- 10 Noise Suppressor Installation**



6

Models 3315SE/3320SE Terminal Installation


This section discusses the procedures for installing the standard modular terminals. The terminals can be freestanding or, optionally, mounted on a wall. The following paragraphs describe how to connect and set up the terminals in both configurations.

Locating the Terminal

Position the terminal on a clean, horizontal surface that is free from vibration and out of direct sunlight. Refer to “Terminal Specifications” for environmental specifications.

Connecting the Terminal

Make all connections to the back panel before connecting the terminal to power. A shroud and cable retaining loop (described in “Shroud and Cable Retaining Loop Attachment”) can be installed after the cables are connected and the terminal is mounted in place. The following figure shows a terminal's back panel connectors.

Figure 6-1 3315SE/3320SE Terminal Back Panel Connectors**Note**

The illustration above shows the back panel of a 3315SE terminal. The back panel of a 3320SE terminal is nearly identical, except that the pull ring (located by COM 2 in the illustration above) is made of high-impact plastic.

The following table summarizes the back panel connectors' functions.

Table 6-1 3315SE/3320SE Terminal Back Panel Connectors

Connector	Description
Network Connector	LAN connector, 10Base-T (10/100Base-T for 3320SE)
Com1	Serial port 1: • Can be connected to an external modem. • Can be used for a direct connection to a local server.
Com2	Serial port 2: • Can be connected to an external modem. • Can be used for a direct connection to a local server.
Parallel Port	Local printer output
Video	Monitor interface
Keyboard	Keyboard interface
Mouse	Mouse interface
Power	Power module output cable interface
Option Slot	PCMCIA card slot
Headphone	Audio output for headphones
Microphone	Audio input for microphones

Proceed as follows to connect the terminal. (If necessary, remove the desktop mounting stand (one Phillips-head screw on the bottom.)

**Note**

Before connecting the cables, decide which mounting configuration will be used and ensure that the cables are of the correct lengths. If permanent desktop or wall-mounting configuration is to be used, drill the desktop mounting holes or install the mounting bracket wall anchors before connecting the cables.

1. Connect the monitor to the Video connector.
2. Connect the keyboard to the Keyboard connector.
3. Connect the mouse to the Mouse connector.
4. If you will be using a network connection, connect a 10Base-T or 100Base-T network cable to the Network connector. Depending on your configuration needs, connect a printer to the parallel port, and/or connect a modem/server serial cable to the serial ports, as appropriate.
5. Connect the power supply output cable to the Power connector.

**Caution**

Do not force a connector into its socket. If any undue resistance is encountered, ensure that the connector is oriented correctly to the socket.

6. Plug the AC cord into the power supply, then into an AC outlet.
7. After the cables are connected, install the terminal in its planned location, either on a desktop or mounted to a wall (see the next section “Mounting the Terminal”).


Mounting the Terminal

The terminal can be freestanding or attached to a wall (an optional wall mount kit is required). Instructions for mounting your terminal are provided in the following paragraphs; use the instructions that are appropriate for the desired method of mounting your terminal.

Freestanding Desktop Mounting

The terminal is shipped with a desktop mounting stand attached so it can immediately be put into desktop operation. The mounting stand is weighted and equipped with non-skid feet. A single screw attaches the mounting stand to the terminal housing. The following figure shows the terminal mounted on the desktop mounting stand.

Figure 6-2 3315SE/3320SE Freestanding Desktop Mounting



Wall Mounting


The terminal can be mounted on a wall using the optional wall-mounting bracket. The following figure shows the wall-mount configuration.



Note

It is best to connect the cables before mounting the terminal on a wall. However, cables can be attached at any convenient time, as long as power is disconnected.

Figure 6-3 3315SE/3320SE Optional Wall Mount Configuration



Follow these instructions to mount the terminal on a wall.

**Caution**

The following procedure has the bracket mounted to the terminal first, and then the complete assembly is placed on wall-anchor screws. If there is any risk that the terminal could be bumped from its mounting, the bracket should be securely anchored to the wall first, and then the terminal housing mounted to the bracket.

1. Use the wall-mount bracket as a template to determine the positions of the mounting holes on the wall.
2. Mark the locations of the mounting holes.

**Note**

When determining location, take into account the cable lengths of the monitor, keyboard, mouse, power supply, and peripherals.


3. Install the (user-provided) wall anchors. Any standard anchoring method may be used, such as screws, butterfly anchors, or expansion bolts. The anchor screw heads must have just enough clearance to allow the bracket to slip onto them when hanging the assembled terminal (see the Caution above).
4. Loosen (but do not remove) the two screws securing the mounting clips to the back panel. Leave enough clearance so the lower tabs of the mounting bracket can slip under the screws.
5. Insert the upper tabs of the mounting bracket into the slotted holes in the back of the terminal housing.
6. Slip the lower tabs of the mounting bracket under the two screws loosened in step 4. The tabs should go between the screw heads and the mounting clips.
7. Tighten the screws to hold the bracket firmly in place.
8. Hang the terminal assembly on the wall-anchor mounting screws.
9. Install the cable retaining loop and shroud using the procedure that follows.

Cable Retaining Clip and Shroud Installation

The plastic shroud may be installed to conceal the cable connectors at the rear of the terminal housing. A retaining loop is included to keep the cables together. Proceed as follows.


1. Attach the upper and lower shroud mounting clips as shown in figure 6-5, using the existing screws.
2. Attach the cables to their respective connectors on the back panel of the terminal (see “Connecting the Terminal”).
3. Gather the cables together and place the retaining loop over them. Insert the ends of the retaining loop into the catches on the lower shroud mounting clip (see the following figure).

Figure 6-4 3315SE/3320SE Cable Retaining Clip Installation



4. Gently pull the lower ends of the shroud apart and place it over the cables.
5. Place the slots in the lower end (split end) of the shroud under the lower shroud mounting clip, as shown in the following figure.
6. Rotate the upper end of the shroud until the top slot goes over and engages the upper mounting clip, as shown in the following figure.

Figure 6-5 3315SE/3320SE Shroud Installation



Turning On the Terminal

Once the terminal is installed and all back panel connections have been made, power it up. If the terminal is a 3315SE, press and release the power management button. If the terminal is a 3320SE, it is powered-up and operating when the power supply is connected to AC power; to toggle the display off or on, press and release the power management button.




Note

For the 3320SE, if the button is continuously depressed for 3-5 seconds, the unit will perform a hard boot.

See the following figure for the location of the power management button.

Figure 6-6 3315SE/3320SE Power Management Button



The logo will appear on the screen, followed by:

- The **Setup Wizard**, if it is the first time that you have turned on your terminal.
- The **Winterm Connection Manager** dialog box, if the **Setup Wizard** has been completed.

If desired, adjust the display's geometry and intensities to your preferences. Adjustments to the display can be made at any time, whether or not the terminal is connected to a server. See "Changing Terminal Properties" for more information.



7

Model 3350SE Terminal Installation

This section discusses the procedures for installing the 3350SE enhanced modular terminal. This terminal can be freestanding or, optionally, mounted on a wall; it can instead be permanently mounted on a desktop, if desired. The following paragraphs describe how to connect and set up the terminal in all three configurations.


Locating the Terminal

Position the terminal on a clean, horizontal surface that is free from vibration and out of direct sunlight. Refer to “Terminal Specifications” for environmental specifications.

Connecting the Terminal

Make all connections to the back panel before connecting the terminal to power. A shroud (described in “Shroud Attachment”) can be installed after the cables are connected and the terminal is mounted in place. The following figure shows the terminal’s back panel connectors.

Figure 7-1 3350SE Terminal Back Panel Connectors



The following table summarizes the back panel connectors' functions.

Table 7-1 3350SE Terminal Back Panel Connectors

Connector	Description
Network Connector	LAN connector, 10/100Base-T
Com1	Serial port 1: • Can be connected to the external modem or used for direct connection to a local server. • Can be used for the emergency download of the operating system programs from the host computer.

Table 7-1 3350SE Terminal Back Panel Connectors, Continued

Connector	Description
Com2	Serial port 2: • Can be connected to an external modem. • Can be used for a direct connection to a local server.
Parallel Port	Local printer output
Video	Monitor interface
Keyboard	Keyboard interface
Mouse	Mouse interface
Power	Power module output cable interface
Card Bus	PCMCIA card slot
Headphone	Audio output for headphones
Microphone	Audio input for microphones
USB	Universal Serial Bus

Proceed as follows to connect the terminal:

**Note**

Before connecting the cables, decide which mounting configuration will be used and ensure that the cables are of the correct lengths. If permanent desktop or wall-mounting configuration is to be used, drill the desktop mounting holes or install the mounting bracket wall anchors before connecting the cables.

1. Connect the monitor to the Video connector.
2. Connect the keyboard to the Keyboard connector.
3. Connect the mouse to the Mouse connector.
4. If you will be using a network connection, connect a CAT5 UTP cable to the Network connector. Depending on your configuration needs, connect a printer to the parallel port and/or connect a modem/server serial cable to the serial ports, as appropriate.

5. Connect the power supply output cable to the Power connector.

**Caution**

Do not force a connector into its socket. If any undue resistance is encountered, ensure that the connector is oriented correctly to the socket.

6. Plug the AC cord into the power supply, then into an AC outlet.
7. After the cables are connected, install the terminal in its planned location, either on a desktop or mounted to a wall (see the next section “Mounting the Terminal”).

Mounting the Terminal

The terminal can be freestanding, attached to a wall (an optional wall mount kit is required), or mounted permanently on a desktop. Instructions for mounting your terminal are provided in the following paragraphs; use the instructions that are appropriate for the desired method of mounting your terminal.

Freestanding Desktop Mounting

Model 3350SE terminals are built with a desktop mounting stand as part of the housing, so they can immediately be put into desktop operation. The terminal is also weighted and equipped with non-skid feet. “Terminal Features” shows the Model 3350SE terminal.

**Caution**

Always mount the terminal vertically, with the base down, to ensure proper cooling.

Permanent Desktop Mounting

If desired, the terminal can be permanently mounted on a desktop. Holes in the base plate are threaded to receive the mounting bolts. Two 6 mm (M6) mounting bolts must be provided by the user.

The mounting bolts must not protrude more than 9 mm (3/8 in) through the top of the desktop mounting surface. Damage to the terminal housing and internal components could occur if the mounting bolts protrude past the tops of the guide holes.

Follow these instructions for permanent desktop mounting:

1. Make a template of the desktop mounting holes using the bottom of the terminal, and use it to mark the desktop area where you want to mount the terminal.
2. Drill holes for the mounting bolts through the desktop mounting surface at the marked locations.
3. Place the terminal in position over the holes drilled in the desktop.
4. Insert the mounting bolts up through the holes in the desktop and into the threaded holes in the terminal base plate. Tighten the bolts until snug.


Wall Mounting

The terminal can be mounted on a wall using the optional wall-mounting bracket. The following figure shows the wall-mount configuration.



Note

For wall mounting, it is generally best to connect the cables before mounting the terminal on a wall. However, cables can be connected at any convenient time, as long as power is disconnected.

Figure 7-2 3350SE Wall Mount Configuration

Follow these instructions to mount the terminal on a wall:

**Note**

The following procedure has the bracket mounted to the terminal first, and then the complete assembly is placed on wall anchor screws.

1. Use the wall-mount bracket as a template to determine the positions of the mounting holes on the wall, then mark the locations of the mounting holes.

**Note**

When determining location, take into account the cable lengths of the monitor, keyboard, mouse, power supply, and peripherals.

2. Install the (user-provided) wall anchors. Any standard anchoring method may be used, such as screws, butterfly anchors, or expansion bolts.
3. Install the anchor screws. The anchor screw heads must have just enough clearance to allow the bracket to slip onto them when hanging the assembled terminal (see the Note above).
4. Insert the tabs at the top of the mounting bracket into the slotted holes in the back of the terminal housing.
5. Swing the mounting bracket to the side of the terminal.
6. Insert the mounting bolts up through the holes in the bottom of the mounting bracket and into the threaded holes in the terminal base plate.
7. Tighten the mounting bolts to hold the bracket firmly in place.
8. Hang the terminal assembly on the wall-anchor mounting screws.
9. Install the cable retaining loop and shroud using the procedure below.

Shroud Attachment

The plastic shroud may be installed to conceal the cable connectors at the rear of the terminal housing.


Proceed as follows:

1. Attach the cables to their respective connectors on the back panel of the terminal (see “Connecting the Terminal”).
2. Install the shroud-mounting clips.
3. Gently pull the lower ends of the shroud apart and place it over the cables.
4. Place the slots in the lower end (split end) of the shroud under the lower shroud mounting clip.
5. Rotate the upper end of the shroud until the top slot goes over and engages the upper mounting clip.

Turning On the Terminal

Once the terminal is installed and all back panel connections have been made, press and release the power management button (see the following figure) to power-up the terminal.

Figure 7-3 3350SE Power Management Button



The logo will appear on the screen followed by:

- The **Setup Wizard**, if it is the first time that you have powered-up your terminal.
- The **Winterm Connection Manager** dialog box, if the **Setup Wizard** has been completed.

If desired, adjust the display's geometry and intensities to your preferences.

Adjustments to the display can be made at any time, whether or not the terminal is connected to a server.



8

Models 3515SE/3715SE/3720SE Terminal Installation

The following section discusses installation of the integrated-CRT terminals.


Locating the Terminal

Position the terminal on a clean, horizontal surface that is free from vibration and out of direct sunlight. Allow 75 mm (3 in) of clearance on all sides of the terminal, for air circulation and movement of the tilt/swivel mechanism. Refer to “Terminal Specifications” for environmental specifications.

Connecting the Terminal

Before powering-up the terminal, connect it to all of its peripheral devices. The following figure shows the terminal’s back panel connectors.

Figure 8-1 3515SE/3715SE/3720SE Terminal Back Panel Connectors



 **Note**
The illustration above shows the back panel of a 3515SE/3715SE terminal. The back panel of a 3720SE terminal is nearly identical, except that the pull ring (located by COM 2 in the illustration above) is made of high-impact plastic.

The following table summarizes the back panel connectors’ functions.

Table 8-1 3515SE/3715SE/3720SE Terminal Back Panel Connectors

Connector	Description
Network Connector	LAN connector, 10Base-T (10/100Base-T for 3720SE)
Com1	Serial port 1: • Can be connected to the external modem or used for direct connection to a local server. • Can be used for the emergency download of the operating system programs from the host computer.
Com2	Serial port 2: • Can be connected to an external modem. • Can be used for a direct connection to a local server.

Table 8-1 3515SE/3715SE/3720SE Terminal Back Panel Connectors,

Connector	Description
Parallel Port	Local printer output
Keyboard	Keyboard interface
Mouse	Mouse interface
Power	AC power cord interface
Option Slot	PCMCIA card slot
Headphone	Audio output for headphones
Microphone	Audio input for microphones

Follow these instructions to connect the terminal to its peripheral devices:

1. Connect the keyboard to the Keyboard connector.
2. Connect the mouse to the Mouse connector.
3. Plug the AC cord into the back panel of the terminal, then into an AC outlet.
4. Connect a 10Base-T network cable to the Network connector.

The terminal is now ready for operation.

Turning On the Terminal

Once the terminal is installed and all back panel connections have been made, power it up. If the terminal is a 3515SE or 3715SE, press and release the power management button. If the terminal is a 3720SE, it is powered-up and operating when it is connected to AC power; to toggle the display off or on, press and release the power management button.

 Note

For the 3720SE, if the button is continuously depressed for 3-5 seconds, the unit will perform a hard boot.

See the figure on the following page for the location of the power management button.

The logo will appear on the screen, followed by:

- The **Setup Wizard**, if it is the first time that you have turned on your terminal.
- The **Winterm Connection Manager** dialog box, if the **Setup Wizard** has been completed.


Make sure that the display's geometry and intensities are set to your preferences. This can be done at any time, whether or not the terminal is connected to a server. If your terminal is installed with an optional touchscreen, calibrate it now. Refer to "Input Configuration" for the procedure.

Display Adjustments

The following sections explain how to adjust the screen's brightness, contrast, horizontal and vertical size and phase, pincushion, and trapezoid.

The terminal uses an OSD (on-screen display) adjustment feature. The OSD is invoked with the buttons on the front panel (see **Terminal Front Panel** below).

Figure 8-2 3515SE/3715SE/3720SE Terminal Front Panel




Instructions for using the terminal’s front panel are listed in the following table.

Table 8-2 3515SE/3715SE/3720SE Terminal Front Panel

Button	Function
MENU (OSD)	To use: 1. Press the MENU button to invoke the OSD (refer to the following figure). 2. Press the plus [+] or minus [-] SELECT buttons to select the adjustment you want to make (see the following table, OSD Alignment, for settings). 3. Press the ADJUST plus [+] or minus [-] buttons to make your adjustment. 4. Press MENU to save your adjustments and close the OSD.  Note The OSD can be invoked at any time the terminal is on, even while running an application. It automatically closes after a period of inactivity (2 minutes). If this happens before you complete your adjustments, press the MENU button to invoke the OSD again.
SELECT (Brightness)	Press the plus [+] and minus [-] buttons on the terminal’s front panel to increase or decrease the display’s brightness.
ADJUST (Contrast)	Press the plus [+] and minus [-] buttons on the terminal’s front panel to increase or decrease the display’s contrast.

Figure 8-3 3515SE/3715SE OSD (On-Screen Display) Menu




The following table describes the functions of the OSD menu.

Table 8-3 3515SE/3715SE/3720SE OSD Menu

Function	Description
H-CENTER	H-CENTER adjusts the screen's horizontal center from left to right.
H-SIZE	H-SIZE adjusts the screen's width.
V-CENTER	V-CENTER adjusts the screen's vertical center, top to bottom.
V-SIZE	V-SIZE adjusts the screen's height.
PIN	PIN (Pincushion) adjusts screen distortion, where both sides of the display sag inward toward the center or bow outward from it.
TRAPEZOID	TRAPEZOID adjusts the screen's right- and left-hand sides so they are parallel.
ROTATE	ROTATE corrects the screen's rotation. Use this function if the display tilts left or right.
RECALL MODE	Select this item to reset the display to the factory preset color temperatures (also see the following figure): RECALL MODE Preset 1 is 9300°K Preset 2 is 6550°K Preset 3 is 5500°K The color adjustments are: R This adjusts the display's red hues. G This adjusts the display's green hues. B This adjusts the display's blue hues.

Figure 8-4 3515SE/3715SE/3720SE Recall Mode



9


Modem Card Installation

This chapter contains the information you need to install a PCMCIA modem card.

About Modem Cards

The modem card option increases the capabilities of your terminal by providing additional connectivity features and functions. It connects to a telephone line for standard serial modem communications with another computing device, or network access through a server. When a modem card is plugged into the terminal, it operates as a native device. It can be configured from menus seamlessly integrated into the terminal configuration menu system. The following figure shows a modem card.

Figure 9-1 Modem Card



Modem card option kits typically include:

- Modem card and cable
- Clamp-on noise suppressor
- Installation guide or compact disc (CD)



Caution

Only modems sold by the manufacturer are known to meet regulatory compliance. Other modems may not.

Installation and Removal

The modem card can be configured to connect

- To a server via PPP
- Directly to an ICA server
- To a server with a terminal emulation



Note

This procedure assumes that the terminal is already installed and configured as described in “Terminal Installation.”



Note

This procedure is based on the modem card and cable sold by the terminal manufacturer. Installation will be similar for other modem cards and cables.

Installation

Refer to the following three figures and proceed as follows:

1. Turn off the power.
2. Remove the screw beneath the security cover.
3. Open the cover over the option slot.
4. Press down on top of the cover to release the top catches and swing the cover out and down (see the next figure).



Caution


Do not try to open the cover with the logic card assembly fully seated. The cover could be damaged.

5. Insert the modem card (with product label up) into the option slot and press it gently until it is seated in the card receptacle.




Note

If a plug is installed in the cover's rear hole, remove the plug before proceeding. Save the plug for possible future use when the card is removed (see figure 9.4).

Figure 9-2 Installing the Modem Card

6. Close the option slot cover (see the following figure).
7. Install the cover screw.
8. Install the clamp-on noise suppressor on the cable assembly. Position it as closely as possible to the modem card (may not be necessary for other vendors' cables).
9. Insert the cable-assembly modem card connector through the hole in the closed cover and into the modem card. Depress the connector tabs while inserting. Make sure the catches lock the connector in place (see the following figure).
10. Insert the cable-assembly telephone connector into a telephone jack.
11. Power-up the terminal.
12. Modify the terminal configuration settings as instructed in "Changing Terminal Properties."

Figure 9-3 Connecting the Modem Card Cable

Removal

Refer to the three figures in this section and proceed as follows:

1. Turn off the power.
2. Disconnect the cable assembly from the modem card by depressing the connector tabs and pulling the connector out of the card (see the preceding figure).
3. Remove the two screws securing the terminal back panel (part of logic card assembly), and pull the panel out approximately 1/2 inch.
4. Remove the option slot cover screw.
5. Open the option slot cover. Press down on top of the cover to release the top catches and swing the cover out and down (see the figure titled "Installing the Modem Card").



Caution


Do not try to open the cover with the logic card assembly fully seated. The cover could be damaged.

6. Pull the modem card out of the option slot.
7. Close the option slot cover (see the figure titled "Connecting the Modem Card Cable").
8. Push the logic card assembly back into the unit and reinstall the two screws removed in step 3.
9. Install the option slot cover screw.
10. Snap the plug into the option slot cover hole (see the following figure).
11. Disconnect the cable assembly from the telephone jack.



Note

Leave the clamp-on noise suppressor on the cable assembly (may not be applicable to other vendors' cables).

Figure 9-4 Inserting the Plug

Configuration

The modem card can be configured for standard serial communications, or for network access through a server that can communicate with the modem using PPP protocol. The following section provides instructions for configuring selections needed to operate the modem in the desired mode. Refer to “Terminal Management” and “Connection Configuration” for instructions about how to configure modems.

Modem Initialization Strings

The initialization string used with the modem option card provided by the manufacturer is:

`AT&F&C1&D2`

Refer to modem command sets or the initialization files for other strings.

10 Noise Suppressor Installation

Noise Suppressor Installation




Note

This installation procedure applies only to the 3350SE model WBT.

A noise suppressor (ferrite bead) must be installed on the network cable of your terminal. This installation is necessary to maintain compliance with US FCC B limits and Europe CISPR B EN55022 Class B limits. The noise suppressor is supplied by the manufacturer and should be packed in your terminal's shipping carton. The following figure shows the noise suppressor.

Figure 10-1 Noise Suppressor



1. Open the casing.
2. Fit the casing over the network cable, as close as possible to the back of the cable's connector.
3. Snap the casing shut.



Terminal Management

- 11 Initial Terminal Setup**
- 12 Changing Terminal Properties**
- 13 Display Configuration**
- 14 Input Configuration**
- 15 Network Configuration**
- 16 Connections Management**
- 17 ICA Client Settings**
- 18 Multiple Sessions**
- 19 Additional Applications**
- 20 Shutting Down the Terminal**

11 Initial Terminal Setup


Using the Setup Wizard

The **Setup Wizard** is used for initial setup of the terminal's properties. The wizard runs when:


- You power-up your terminal for the first time.
- Your terminal has been restarted with a **G** key reset (described later).
- A new image has been downloaded to your terminal but is older than the image currently in use.
- You use the **Reset the Terminal to Factory-Default Property Settings** function on the **General** properties sheet.

The **Setup Wizard** lets you set terminal network configuration and terminal display parameters. Any future changes can be made using the **Terminal Properties** dialog box. You can launch this dialog box from the **Winterm Connection Manager** by pressing the **F2** key. See "Resetting Terminal Properties."


There are seven dialog boxes that display in succession during the process. Each dialog box is self-explanatory. Some dialog boxes are informational and require no user input. Other dialog boxes will prompt you for network and display information. Following are the seven dialog boxes of the wizard.

Figure 11-1 Welcome Dialog Box

This dialog box is informational, providing product information.


Figure 11-2 EULA (End User License Agreement) Dialog Box

Read the license agreement carefully. The full text of the agreement is provided in the front of the guide as the EULA.

Figure 11-3 IP Address Dialog Box

Click on one of the two radio buttons to select a method for supplying IP addresses. The buttons are mutually exclusive, with **No, I will enter static IP information** as the default:

- If you keep the default, the **Specify an IP Address** and **Optional Information** dialog boxes will display in succession.
- If you select **Yes, use the IP information supplied by DHCP**, only the **Optional Information** dialog box will display.

Figure 11-4 Specify an IP Address Dialog Box

The dialog box is titled "Setup Wizard" in a blue header bar. On the left, there is a graphic of four computer monitors connected by a blue line. The main text area contains the title "Specify an IP Address" and a paragraph: "You must specify the following network information. If you do not know this information, ask your network administrator." Below this text is a form with three input fields labeled "IP Address:", "Subnet Mask:", and "Gateway:". At the bottom, there are three buttons: "<Back", "Next>", and "Cancel".

Setup Wizard

Specify an IP Address

You must specify the following network information. If you do not know this information, ask your network administrator.


IP Address:

Subnet Mask:

Gateway:

<Back Next> Cancel

Enter the information requested in the fields provided. By default the fields are blank.

Figure 11-5 Optional Information Dialog Box

The image shows a Windows-style dialog box titled "Setup Wizard". On the left, there is a graphic of four computer monitors connected by blue lines. The main text area says "Fill in the following optional information to configure the terminal's name resolution." Below this, there are two sections. The first section is titled "Enable DNS" with an unchecked checkbox. It contains three text input fields: "Default Domain Name:", "Primary Server IP:", and "Secondary Server IP:". The second section is titled "Enable WINS" with an unchecked checkbox. It contains two text input fields: "Primary Server IP:" and "Secondary Server IP:". At the bottom of the dialog, there are three buttons: "<Back", "Next>", and "Cancel".

Setup Wizard

Fill in the following optional information to configure the terminal's name resolution.

☐ Enable DNS

Default Domain Name:

Primary Server IP:

Secondary Server IP:


☐ Enable WINS

Primary Server IP:

Secondary Server IP:

<Back Next> Cancel

Check a box to enable name resolution. Enter the information in the field provided. If you do not know the information, ask your network administrator. By default the check boxes are unselected.


Figure 11-6 Desktop Area and Refresh Frequency Dialog Box

Select from the **Desktop Area and Refresh Frequency** scroll list to set your resolution. The default setting is **640 x 480 @ 60Hz**. Other settings are:

- **640 x 480 @ 75Hz**
- **800 x 600 @ 60Hz**
- **800 x 600 @ 75Hz**
- **1024 x 768 @ 60Hz**
- **1024 x 768 @ 75Hz**

**Note**

There may be more resolution settings in the list on your terminal.

Figure 11-7 Finish Dialog Box


This dialog box is informational.

Click on the **Finish** command button to apply your selections and quit the **Setup Wizard**. After the **Setup Wizard** closes, the **Terminal Settings Change** dialog box displays. See "Resetting Terminal Properties" for further information.

12 Changing Terminal Properties

Terminal properties can be changed at any time during normal terminal operation using the **Terminal Properties** dialog box. The following figure shows this dialog box.

Figure 12-1 Terminal Properties Dialog Box



**Note**

The amount of RAM that is available depends on the model of terminal in use.

Using the Terminal Properties Dialog Box

Invoke this dialog box by pressing the **F2** key from the **Winterm Connection Manager**.

The **Terminal Properties** dialog box consists of a total of ten properties sheets that can be invoked by clicking on their individual tabs. The following seven sheets can be used to change terminal properties:

- **Input** - discussed in “Input Configuration.”
- **Display** - discussed in “Display Configuration.”
- **Network** - discussed in “Network Configuration.”
- **Upgrade** - discussed in “FTP Pull Firmware Upgrades.”
- **Security** - discussed in “Security Properties.”
- **Apps** - discussed in “Additional Applications.”
- **Devices** - discussed in “Dial-Up Connections.”


These properties sheets are discussed in detail in the following chapters of this guide. The **General**, **SysInfo**, and **About** properties sheets are discussed in “General Terminal Information.”

When terminal properties have been changed, the **Terminal Settings Change** dialog box is used to restart the terminal. See “Shutting Down the Terminal” for more information about this dialog box.

13 Display Configuration

The **Display** properties sheet lets you configure the terminal's display screen. Figure 13-1 shows this properties sheet.

Figure 13-1 Display Properties Sheet



Using the Display Properties Sheet

To invoke this properties sheet:

- 1. Press **F2** to invoke the **Terminal Properties** dialog box.
- 2. Click on the **Display** tab.

The following table discusses the functions of this properties sheet.


Table 13-1 Display Properties Sheet

Function	Description
Desktop Area and Refresh Frequency	The scrolling list box displays the current terminal display resolution. Scroll and click on a selection to change resolution. The default is 600 x 480 @ 60 Hz .
Enable Energy Savers	Click on this check box to enable the energy saver functions. When you check this box, the three functions in the group box are activated: Screen Saver Click on this radio button to enable the screen saver. By default this function is not activated. Turn Off Monitor Click on this radio button to use this function as an energy saver. The function works by shutting off the terminal's display rather than displaying a screen saver. By default this function is not activated. When it is activated, this function is enabled. Wait Adjust the amount of time (in minutes) that elapses before the energy saver function you have selected starts. You can enter your own number or use the scrolling list. By default the function is not activated. When it is activated, the default is 12.

14 Input Configuration

The **Input** properties sheet lets you configure your terminal's keyboard and the optional touch screen. The following figure shows the properties sheet.

Figure 14-1 Input Properties Sheet



Using the Input Properties Sheet

To invoke this properties sheet:

- 1. Press **F2** to invoke the **Terminal Properties** dialog box.
- 2. Click on the **Input** tab in the **Terminal Properties** dialog box.

The following table describes the functions of this dialog box.

Table 14-1 Input Properties Sheet

Function	Description
Keyboard	Locale Use this scroll list to select a language for the keyboard:
	Belgian Dutch Belgian French Brazilian (ABNT) Canadian Eng (Multi) Canadian Fr (Multi) Canadian French Danish Dutch English (UK) English (US) (default) Finnish French German Italian Italian (142) Japanese Latin American Norwegian Portuguese Spanish Spanish Variation Swedish Swiss French Swiss German US International



Note
An IEPC keyboard is required for any language other than **English (US)**.


Table 14-1 Input Properties Sheet, Continued

Function	Description
Character Repeat	Group box used to set the character repeat parameters. Repeat Delay Use this slider control to adjust the repeat delay of keyboard characters. Repeat Delay determines how quickly the same character will appear on screen when typed more than once. Repeat Rate Use this slider control to adjust the repeat rate of a keyboard character. Repeat Rate determines how quickly the same character will appear on screen when the associated key is held down.
Touch Screen Port	Use this drop-down scroll list to name the port that your optional touch screen will be connected to. The choices are: • Disable • Serial cable on Com1 • Serial cable on Com2 The default is Disable.

15 Network Configuration

The **Network** properties sheet lets you configure your network. See Figure 15-1 for this properties sheet.

Figure 15-1 Network Properties Sheet



Using the Network Properties Sheet

To invoke this properties sheet:

- 1. Press **F2** to invoke the **Terminal Properties** dialog box.
- 2. Click on the **Network** tab.

The following table discusses the functions of the **Network** properties sheet.

Table 15-1 Network Properties Sheet

Function	Description
Obtain an Address from a DHCP Server	Click on this radio button to enable DHCP addressing. An IP address will be automatically assigned to your terminal by the DHCP server.
Specify an IP Address	Use this group box to enter a specific IP address. IP Address Enter a static IP address in this field. Subnet Mask Enter the subnet mask of the IP address. Gateway Enter the gateway of the IP address. Advanced Network  Note This command button is activated when Specify an IP Address is enabled. Click on this command button to invoke the Advanced Network Settings dialog box: Enable DNS Use this group box to set domain, primary, and secondary IP addresses for DNS. Enable WINS Use this group box to set the primary and secondary IP addresses of a WINS server.

**Note**

The **Network** properties sheet on your terminal may have an extra function. It is named **Network Speed**. The functions list for the pull-down scroll box is as follows:

- **Auto Detect**
- **10 Mbs - Half Duplex**
- **10 Mbs - Full Duplex**
- **100 Mbs - Half Duplex**
- **100 Mbs - Full Duplex**


**Note**

If you do not know your network's communication speed or whether the communication link should be half- or full-duplex, contact your system administrator.

16 Connections Management

The **Winterm Connection Manager** dialog box is designed to help you manage your terminal's network connections. The dialog box displays after the terminal's initial splash screen, and consists of the **Connections** properties sheet and the **Configure** properties sheet. Figure 16-1 shows the **Winterm Connection Manager** dialog box.

Figure 16-1 Winterm Connection Manager Dialog Box



Using the Connections Properties Sheet

The functions of the **Connections** properties sheet are used to make (launch) terminal connections. Figure 16-1 shows the **Connections** properties sheet, the default of the **Winterm Connection Manager** dialog box.

After a connection is created, it will show in the **Connection Name** list. The connection's name will be listed under **Connection Name** and the type of connection will be listed under **Type**. See "Creating New Connections" for further information.

The **Connections** properties sheet contains four functions. The following table identifies and describes each of them.


Table 16-1 Connections Properties Sheet

Function	Description
Connection Name	This box lists the connections that you have created. See "Using the Configure Properties Sheet" for information about creating connections. Default RDP Connection is the default.
Connect	Click on the Connect command button to make the highlighted connection. Click on a connection in the Connection Name list box to highlight it. You can also double-click on a selection to make a connection.
End	Click on the End command button to end the connection process. When you press the End button and the connection is active, the End Task dialog displays. This command button is enabled when a session is active.
Shut Down	Click on the Shut Down command button to: • Log off of the terminal • Shut down the terminal • Shut down and restart the terminal See "Shutting Down the Terminal" for more information.

Using the Configure Properties Sheet

The **Configure** properties sheet allows the user to add, modify, delete, and configure connections. Figure 16-2 shows the **Configure** properties sheet.

Figure 16-2 Configure Properties Sheet



Invoke this properties sheet by clicking on the **Configure** tab.



Note

If the **Hide Configure Tab** function on the **Security** properties sheet is enabled, the **Configure** tab will not show.



Note

If a **Guest** or a **User** logs in with security enabled, the **Configure** tab will not show.

After a connection is added or edited, it will appear in the **Connection Name** list. The connection's name will be listed under **Connection Name**, and the type of connection will be listed under **Type**. Also, if the connection is designated as the start-up connection, a **Yes** will display in **Startup**. The remainder of this section discusses adding connections. See “Editing Connections” and “Using the Startup Function” for further information.

The **Configure** properties sheet contains five basic functions. The following table identifies and describes each of them.

Table 16-2 Configure Properties Sheet

Function	Description
Add	The Add button allows the user to create a new connection. When this button is pressed, the New Connection dialog box displays. See “Creating New Connections” for further information about adding new connections to the Connection Name list. See “Multiple Sessions” for running more than one session at a time.
Edit	The Edit command button allows the user to edit or modify the properties of an existing connection. When this button is pressed, the Properties dialog box displays. See “Editing Connections” for more information about editing connections.
Delete	The Delete button lets you delete a connection. When you click this command button, the Confirm Connection Delete dialog box displays. Click on Yes to complete the deletion. Click on No to cancel the deletion.
Startup...	The Startup button allows the user to specify the startup behavior of a connection. See “Using the Startup Function” for more information.
Connection Name	The Connection Name list box allows the user to view and select connections for the purposes of adding, editing, and deleting connections, or for specifying the startup behavior of a connection.



Note

A connection name must be selected for the **Edit**, **Delete**, and **Startup** functions to be enabled.

17 ICA Client Settings


ICA client settings are handled in the **Global ICA Client Settings** dialog box. This dialog box is invoked through the **Apps** properties sheet found in the **Terminal Properties** dialog box. See “Additional Applications” for detailed information about the **Apps** properties sheet.

There are three properties sheets associated with the **Global ICA Client Settings** dialog box. A description of the functions of each sheet follows.

Setting the Default Hotkeys

Hotkeys can be used during ICA sessions to invoke various functions. Some hotkeys control the behavior of ICA Windows, while others emulate standard Windows hotkeys. To set hotkeys, access the **Default Hotkeys** properties sheet. It is the default properties sheet for the **Global ICA Client Settings** dialog box. The following figure shows the **Default Hotkeys** properties sheet.

Figure 17-1 Default Hotkeys Properties Sheet



Use the pull-down scroll boxes on the **Default Hotkey** properties sheet to customize default hotkey key sequences. The following table describes the hotkeys.

Table 17-1 Default Hotkeys Properties Sheet

Function	Description
Status Dialog	Displays the ICA connection status.
Close Remote Application	Disconnects an ICA client from the server and closes the client window on the local desktop. When you use this hotkey, the open session continues to run on the server. If you do not want to leave your session running in a disconnected state, log off.
Toggle Title Bar	Alternately hides and displays the client window title bar: • Use the title bar to drag the client window to different positions on the local desktop. • Remove the title bar to maximize your work space.
Ctrl+Alt+Del	Displays the Windows NT Security dialog box.
Ctrl+Esc	On WinFrame servers, pressing this key sequence displays the Remote Task List . On MetaFrame servers, pressing this key sequence displays the Windows NT Start menu.
Alt+Esc	This hotkey cycles the focus through your minimized icons and opens the associated applications.
Alt+Tab	This hotkey cycles through applications that have been opened. A window appears, displaying the programs as you cycle through them.
Alt+Backtab	This hotkey sequence cycles through applications that have been opened in a session, but in the opposite direction.


Setting Terminal Preferences

Use the **Preferences** properties sheet to change default settings. To invoke the **Preferences** properties sheet:

1. Click on the **ICA Client Settings** command button on the **Apps** properties sheet.
2. Click the **Preferences** tab.

The **Preferences** properties sheet displays. Figure 17-2 shows the **Preferences** properties sheet.

Figure 17-2 Preferences Properties Sheet



The following table describes each function of the properties sheet.

Table 17-2 Preferences Properties Sheet

Function	Description
Serial Number	This is the serial number of your ICA Client software. This field is only necessary when you are using the ICA Windows CE Client with a product such as WinFrame Host/Terminal, which requires each client to have a Citrix PC Client Pack serial number in order to connect to the server. If a serial number is required, you must enter it exactly as it appears on the serial number card. The Serial Number field is not used by MetaFrame servers.
Default Window Colors	In the Window Colors field, select 16 or 256 colors. When using a PPP connection, 16 color mode may provide better performance. If the window options specified exceed the capabilities of the client hardware, the maximum size and color depth supported by the CE operating system are used.
Enable Palette Device	This feature is not yet supported.
Client	This text box allows you to change the client name of your client device. The Citrix server uses the client name to uniquely identify resources (such as mapped printers) associated with a given client device. The client name should be unique for each computer running a copy of a Citrix ICA Client. If you do not use unique client names, device mapping and application publishing may not operate correctly. The default is WBT<mac address> .
Allow Automatic Client Updates	This feature is not yet supported.


Setting the Server Location

Use the **Server Location** properties sheet to construct a list of ICA servers. To invoke this properties sheet:

1. Click on the **ICA Client Settings** command button on the **Apps** properties sheet.
2. Click the **Server Location** tab.

The **Server Location** properties sheet displays. The following figure shows this sheet.

Figure 17-3 Server Location Properties Sheet



The following table describes each of the functions of this sheet.

Table 17-3 Server Location Properties Sheet

Function	Description
Add	Click on this command button to add a server to the list.
Delete	Use this button to delete the name of a server from the list.
Move Up	Click on this button to move the name of a server up in the list.
Move Down	Click on this button to move a server down in the list.

Table 17-3 Server Location Properties Sheet, Continued

Function	Description
	 Note Delete , Move Up , and Move Down are not activated unless there is at least one ICA server in Network Protocol: TCP/IP . See the next table entry.
Network Protocol: TCP/IP	Use this list to select an ICA server. The default is (Auto-Locate) .
Default List	Use this button to recall the previous list.

18 Multiple Sessions

Starting Multiple Sessions

To start multiple sessions:

1. From the **Winterm Connection Manager**:
 - a. Click on your first connection to create your first session.
 - b. Press **Ctrl+Alt+End** to return the **Winterm Connection Manager**.
 - c. Click on the next connection to create another session.
2. Using autologin:
 - a. Click on the **Security** tab in the **Terminal Properties** dialog box.
 - b. Click on the **Autologin Enable** function.
 - c. Go to the **User Accounts** list box and select an account that is not **Administrator** and has multiple connections associated with it.
 - d. Make a connection.
3. Using **Multiple AutoStart**:
 - a. Click on the **Security** tab in the **Terminal Properties** dialog box.
 - b. Click on the **Modify User** command button.
 - c. Click on the **Multiple AutoStart** check box.
 - d. Make a connection.

Manipulating Multiple Sessions

With a session or multiple sessions open, you can toggle between sessions. To toggle between sessions:

- Press **Ctrl+Alt+↑** to proceed to the previous session.
- Press **Ctrl+Alt+↓** to proceed to the next session.


You can also return to the **Winterm Connection Manager** by pressing **Ctrl+Alt+End**.

19 Additional Applications

Use the **Apps** properties sheet to use the following additional applications:

- ICA client settings
- RDP encryption option
- Virtual port option
- SNMP management
- DHCP options

Figure 19-1 Apps Properties Sheet



Using the Apps Properties Sheet

To invoke the **Apps** properties sheet:

- 1. Press **F2** to invoke the **Terminal Properties** dialog box.
- 2. Click on the **Apps** tab in the **Terminal Properties** dialog box.

Table 19-1 describes the functions of the **Apps** properties sheet.

Table 19-1 Apps Properties Sheet

Function	Description
Global Settings	Group box used to manage ICA sessions. ICA Client Settings Click on the ICA Client Settings command button in the Global Settings group box. See “ICA Session Management” for detailed information about ICA session management.
Virtual Ports	Group box used to set up the virtual port option. Virtual Port Server Type in the address of the virtual port server. Com1 Enable or Com2 Enable or LPT1 Enable Click on one or all of these check boxes to assign that port as a virtual port. These functions are not mutually exclusive.
RDP Encryption Enable	Click this check box to check and enable RDP encryption. By default this function is enabled.  Caution If your WTS server does not support encryption, this function must be disabled.
SNMP Update Enable	Check this box to enable terminal firmware updates through SNMP.


Table 19-1 Apps Properties Sheet, Continued

Function	Description
SNMP Network...	Use this command button to invoke the SNMP Network Administration dialog box. See “SNMP Network Administration.”
DHCP Automatic Update Enable	Check this box to enable automatic firmware upgrades. See “DHCP Firmware Upgrades” and “Changing DHCP Option IDs.”
Change DHCP Option...	Use this command button to invoke the Change DHCP Option IDs dialog box. See “DHCP Option IDs.”

20 Shutting Down the Terminal

Use the **Shutdown Window** dialog box to log off, shut down, or shut down and restart the terminal. The following figure shows the **Shutdown Window** dialog box.

Figure 20-1 Shutdown Window Dialog Box



Using the Shutdown Window Dialog Box

Click on the **Shutdown** command button in the **Winterm Connection Manager** to invoke this dialog box.

The following table describes the functions of this dialog box.

Table 20-1 Shutdown Window Dialog Box

Function	Description
Logout	Click on this radio button to invoke the Terminal Login dialog box. By default this function is not activated. You must enable the terminal's security function to activate it.
Shutdown the Terminal	Click on this radio button to shut down the terminal without restarting it. A dialog box displays after you initiate this action. It prompts you as to whether you want to continue. By default this function is activated.
Shutdown and Restart	Click on this radio button to shut down then restart the terminal. By default this function is activated.

Using the Terminal Settings Change Dialog Box

When you change terminal properties using the **Setup Wizard** or the **Terminal Properties** dialog box, you will click on either the **Finish** or **OK** command button to save your new settings and close the application. The **Terminal Settings Change** dialog box will then display. Figure 20-2 shows the **Terminal Settings Change** dialog box.

Figure 20-2 Terminal Settings Change Dialog Box



This dialog box contains the **Restart** command button. The terminal must be restarted in order for your new settings to take effect. Click on **Restart** to restart the terminal. The **Winterm Connection Manager** displays. See “Connections Management” for detailed information about configuring and making terminal connections.




Connection Configuration

- 21 Creating New Connections**
- 22 ICA Connections**
- 23 Dial-Up Connections**
- 24 Using the Dialing Properties and Configure Command Buttons**
- 25 Using the TCP/IP Settings and Security Command Buttons**
- 26 RDP Connections**
- 27 Terminal Emulation Connections**
- 28 Editing Connections**
- 29 Modem Connection Configuration**

21 Creating New Connections

The **New Connection** dialog box is used to create new connections. Figure 21-1 shows the **New Connection** dialog box.

Figure 21-1 New Connection Dialog Box



To invoke the dialog box:

1. Click on the **Configure** tab in the **Winterm Connection Manager** dialog box.
2. Click on **Add** command button on the **Configure** properties sheet.

See "Connection Management" for details about the **Winterm Connection Manager**.

Choosing a Connection Protocol

Use the scroll list shown in the dialog box above to select the type of connection protocol you want. When you choose from the list above, you are deciding which connection protocol you want use to connect to a server. Four selections are available:

- **Citrix ICA Client**

ICA (Independent Computing Architecture) protocol, which connects to an ICA (Winframe/Metaframe) server. See “ICA Connections” for further instructions about how to create this kind of connection.

- **Dial-Up Client**

Connects using a modem and PPP (Point-to-Point Protocol). See “Dial-Up Connections” for further instructions about how to create this kind of connection.

- **Microsoft Remote Desktop Client**

RDP (Remote Desktop Protocol), which connects to a WTS (Windows Terminal Server) server. See “RDP Connections” for further instructions about how to create this kind of connection.

- **Terminal Emulation**


Connects to multiple terminal emulation applications. See “Terminal Emulation Connections” for further instructions about how to create this kind of connection.

Once you have made your selection, click on **OK** to proceed with creating a connection.

Using the Startup Function

Your terminal can be set to automatically connect to a server when you turn your terminal on. This function is set using the **Connection Startup** dialog box. The following figure shows this dialog box.

Figure 21-2 Connection Startup Dialog Box



To invoke the **Connection Startup** dialog box:

1. Click on the **Configure** tab in the **Winterm Connection Manager** dialog box.
2. Click on the **Startup** command button on the **Configure** properties sheet.

Startup Options

Click on one of the two radio buttons in the **Startup Options** group box (in the **Connection Startup** dialog box above) to select a start-up option:

- **Make the Selected Connection Your Default Connection**

Enable this function to use the connection you selected in the **Winterm Connection Manager** as the default connection. The default connection is the connection that always appears in the **Connection Name** list.

- **Automatically Start the Selected Connection at Startup**

When you enable this function, your terminal will automatically use the connection you selected in the **Winterm Connection Manager**.



Note

The functions in the **Startup Options** group box are mutually exclusive.


22 ICA Connections

Use the **Specify Connection Type** dialog box to start configuring an ICA connection. ICA connects to a server running Citrix WinFrame or MetaFrame.

Using the Specify Connection Type Dialog Box

Figure 22-1 shows the **Specify Connection Type** dialog box.

Figure 22-1 Specify Connection Type Dialog Box



- **Network Connection**
 - Click on this radio button to create a network ICA connection. This type of connection requires a direct line to the network, such as 10Base-T. See "Network Connections."
- **Dial-In Connection**
 - Click on this radio button to create a serial ICA connection. This type of connection is made using a modem. See "Dial-In Connections."

Network Connections

Select **Network Connection**, then click on the **Next** button. A Citrix search message displays:

Figure 22-2 Citrix Search Message



If the connection is not found, the following sequence of dialog boxes displays. Use them to set up your network ICA connection.

Figure 22-3 Select a Citrix Server or Published Application Dialog Box



To use the **Select a Server or Published Application** dialog box:

1. Click on either **Citrix Server** or **Published Application**.
2. Select a server or an application from the drop-down scroll list, or type the information in the text entry box.




Note

The **Refresh** command button refreshes the drop-down scroll list.




Note


The **Server Location** command button invokes the **Server Location** dialog box. The server in **Server Location** will act as a master browser for creation of the **Address** list. See Figure 22-4.

Figure 22-4 Server Location Dialog Box

3. If you want to add a server address, click on the **Add** command button to invoke the **Add Server Address** dialog box.

Figure 22-5 Add Server Address Dialog Box


4. Enter the name of the Citrix server.
5. Click on **Next**.

Figure 22-6 Specify an Application Dialog Box

To use the **Specify an Application** dialog box:

1. Enter the command line and directory of the application that you intend to invoke.
2. Click on **Next**.

Figure 22-7 Specify Logon Information Dialog Box




The dialog box is titled "Specify Logon Information" in a blue header bar. Below the title, it says "If desired, you can specify logon information to be used when connecting to the remote application." To the right of this text is a small icon of a computer monitor with a green cursor arrow. Below the text are three input fields: "Username:", "Password:", and "Domain:". At the bottom, there is a "Note: If the application is an anonymous published application, any logon information that you specify here is ignored." and three buttons: "< Back", "Next >", and "Cancel".

To use the **Specify Logon Information** dialog box:

1. If needed, enter a user name, a password, and a domain for connecting to an application.
2. Click on **Next**.

Figure 22-8 Select Window Options Dialog Box




The dialog box is titled "Select Window Options" in a blue header bar. Below the title, it says "These settings specify how the application window will appear on your desktop:" To the right of this text is a small icon of a computer monitor with a green cursor arrow. Below the text is a "Window Colors" section with two radio buttons: "16" and "256". The "256" radio button is selected. At the bottom, there are three buttons: "< Back", "Next >", and "Cancel".

To use the **Select Window Options** dialog box:

1. Click on the desired number of colors to display, either **16** or **256**.
2. Click on **Next**.


Figure 22-9 Compression, Cache, and Sound Dialog Box



To use the **Compression, Cache, and Sound** dialog box:

1. Enable or disable the following functions:
 - a. **Compress Data Stream** - Applies compression
 - b. **Cache** - Not supported yet
 - c. **Sound** - **High, Medium, and Low** sound quality selectable with this function.
2. Click on **Next**.

Figure 22-10 Select a Title for the ICA Connection Dialog Box




To use the **Select a Title for the ICA Connection** dialog box, click on **Finish**.

Dial-In Connection

Choose **Dial-In Connection**, then click on the **Next** button. The following sequence of dialog boxes displays. Use them to set up your dial-in ICA connection.

Figure 22-11 Dial-In Devices Dialog Box



To use the **Dial-In Devices** dialog box:

1. From the **Dial-In Device** drop-down scroll list, select one of the following:
 - a. A modem connection such as **Hayes Compatible on Com1**.
 - b. A serial connection such as **Serial Cable on Com1**.
2. Enter the area code, the phone number, and the country code in the appropriate fields.
3. Click on **Configure** to use the **Device Properties** dialog box. (See “Using the Device Properties and Configure Command Buttons” for more information on the **Configure** command button).
4. See Figures 22-6 through 22-10 and the related text for information about the dialog boxes in this sequence.

When you are finished with the configuration, the **Winterm Connection Manager** displays, listing your new ICA connection.

23 Dial-Up Connections

Use the **Dial-Up Configuration Wizard** to configure a dial-up connection. Dial-up connections use a modem and PPP to connect to a server.

Using the Dial-Up Configuration Wizard

Following are the three dialog boxes that display in succession during this configuration process. When you are finished with the configuration, the new connection will be added to the **Connection Name** list in the **Winterm Connection Manager**.


Figure 23-1 Dial-Up Configuration Wizard 1



To use the first dialog box:


1. Enter a name for your dial-up connection.
2. Click on **Next**.

Figure 23-2 Dial-Up Configuration Wizard 2



To use the second dialog box of the wizard:

1. Select from the **Serial Port** drop-down scroll list one of the following:
 - a. A modem connection such as **Hayes Compatible on Com1**.
 - b. A cable connection (serial connection) such as **Serial Cable on Com1**.
2. Enter your information in the pertinent fields. **Country Code** and **Area Code** will activate if **Use Country Code and Area Code** is enabled.
3. See "Using the Dialing Properties and Configure Command Buttons" to get information about the **Dialing Properties** and **Configure...** command buttons.
4. See "Using the TCP/IP Settings and Security Command Buttons" for information about the **TCP/IP Settings...** and **Security** command buttons.
5. Click on **Next**.

Figure 23-3 Dial-Up Configuration Wizard 3

To use the third dialog box:


1. Enter your information in the pertinent fields. If you do not know the information, call your system administrator.
2. Click on **Finish**.

The **Winterm Connection Manager** displays, listing your new dial-up connection.

24 Using the Dialing Properties and Configure Command Buttons

The following sections provide information about some of the elements of the **Dial-Up Configuration Wizard**. This chapter covers dialing properties and device properties. Dialing properties are set using the **Dialing Properties** dialog box (Figure 24-1). Device properties are set using the **Device Properties** dialog box (Figure 24-2).

Figure 24-1 Dialing Properties Dialog Box



Using the Dialing Properties Dialog Box

Use the **Dialing Properties** dialog box to set the dialing properties for your dial-up connection. See “Dial-Up Connections” to find out how to invoke this dialog box.

The following table discusses the functions of the dialog box.

Table 24-1 Dialing Properties Dialog Box

Function	Description
Local Settings	Set local dialing locale and dialing type in this group box. Local Area Code Enter the local area code that you want to use. Local Country Code Enter the local country code of the country that you are dialing to. The default for this field is 1.  Note Refer to a phone directory for country codes. Disable Call Waiting By Dialing: - Click on the check box. - Select from the drop-down scroll list one of the following: *70, 70#, 1170, Tone Dialing Click on this radio button to enable tone dialing. Tone Dialing is the default. Pulse Dialing Click on this radio button to enable pulse dialing.


Table 24-1 Dialing Properties Dialog Box, Continued

Function	Description
Dialing Patterns	Use this group box to set your modem's dialing patterns. Local Calls Dialing Enter the local call dialing pattern. The default is 9,G . Local Long Distance Calls Dialing Enter the long distance call dialing pattern. The default is 9,1FG . International Calls Dialing Enter the international call dialing pattern. The default is 9,011,EFG .  Note An explanation of the lettering scheme for dialing patterns is located below the function International Calls Dialing .

Using the Device Properties Dialog Box

Use the **Device Properties** dialog box to configure a device (modem) for a dial-up connection.

Figure 24-2 Device Properties Dialog Box



See “Dial-Up Connections” to find out how to invoke this dialog box.

The **Device Properties** dialog box contains two properties sheets:

- **Port Settings**
- **Call Options**

The following sections discuss these properties sheets.

Port Settings


See Figure 24-2 to view the **Port Settings** properties sheet. It is the default of the **Device Properties** dialog box. The following table discusses the functions of this properties sheet.

Table 24-2 Port Settings Properties Sheet

Function	Description
Manual Dial	Click on this check box to set up for manual dialing.
Terminals	Use this group box to record terminal windowing information: • Use Terminal Window Before Dialing • Use Terminal Window After Dialing
Connection Preferences	Use this group box to set modem connection parameters.

Call Options

Figure 24-3 Call Options Properties Sheet



Click on the **Call Options** tab to invoke the **Call Options** properties sheet. The following table discusses the functions of this properties sheet.

Table 24-3 Call Options Properties Sheet

Function	Description
Call Setup	Use this group box to configure the following call parameters: Cancel the Call if Not Connected Within 1. Enter in this field the number of seconds to wait before a call is canceled. 2. Click the check box to enable the function. The default is 120 with the function enabled. Wait for Dial Tone Before Dialing Click on the check box to enable the function. The default for this function is enabled. Wait for Credit Card Tone Enter in the field the period (in seconds) of time to wait. The default is 0.
Extra Settings	Use this field for special modem commands.

 **Note**
See “Null Modem Cable Pin Assignments” for a suggested null modem cable for use with your terminal.


25 Using the TCP/IP Settings and Security Command Buttons

The following sections provide information about some of the elements of the **Dial-Up Configuration Wizard**. This chapter covers TCP/IP settings and dial-up security.

Using the TCP/IP Settings Dialog Box

Click on the **TCP/IP Settings** command button in the second dialog box of the **Dial-Up Configuration Wizard** to set TCP/IP dial-up settings. When this command button is pressed, the **TCP/IP Settings** dialog box displays. Figure 25-1 shows this dialog box.

Figure 25-1 TCP/IP Settings Dialog Box



The following table discusses the functions in this dialog box.

Table 25-1 TCP/IP Settings Dialog Box

Function	Description
Use Software Compression	Click on this check box to enable this function. By default, this function is activated and enabled.
Use IP Header Compression	Click on this check box to enable Use IP Header Compression . By default, this function is activated and enabled.
Use SLIP	Click on this check box to enable this function. SLIP is Serial Line Internet Protocol. By default, this function is activated and enabled.
Use Assigned IP Address	Click here to activate this text box. By default, the text entry box is not activated.
Use Server-Assigned IP Addresses	Click here to disable server-assigned addresses and to activate the text entry boxes for typing-in addresses. By default, the text entry box is not activated.
Use Default Gateway on Remote Network	Click on this check box to enable this function. By default, the function is activated and enabled.

Using the Security Settings Dialog Box

Click on the **Security...** command button in the second dialog box of the **Dial-Up Configuration Wizard** to configure dial-up security. When this command button is pressed, the **Security Settings** dialog box displays. Figure 25-2 shows this dialog box.

Figure 25-2 Security Settings Dialog Box



The following table discusses the functions in this dialog box.

Table 25-2 Security Settings Dialog Box

Function	Description
Accept Any Authentication Including Clear Text	Click on this radio button to set your terminal to accept any authentication including clear text. Authentication determines whether a request originated from the correct user or application.
Accept Only Encrypted Authentication	Click on this radio button to set your terminal to accept only encrypted authentication. Encryption is a method of “hiding” data that is transmitted across a network.
Accept Only Microsoft Encrypted Authentication	Click on this radio button to set your terminal to accept only Microsoft encrypted authentication.


26 RDP Connections

Use the **WTS Connection Wizard** to configure an RDP connection. RDP connects to a server running Microsoft WTS (Windows Terminal Server). See “Creating New Connections” for more information about how to invoke this wizard.

Using the WTS Connection Wizard

Following are the four dialog boxes that display in succession during the configuration process. When you are finished with the wizard, the new connection will be added to the **Connection Name** list in the **Winterm Connection Manager**.

Figure 26-1 WTS Connection Wizard 1



WTS Connection Wizard

Type a name for the new connection.
Name:

Type the name of the computer to which you want to connect.
Server:


Click Low Speed Connection if you are connecting across a slower network.
☐ Low Speed Connection

<Back Next> Cancel

To use the first dialog box:


1. Enter a name for your dial-up connection in **Name**.
2. Enter the name of the server in **Server**.
3. Check the **Low Speed Connection** check box if appropriate.
4. Click on **Next**.

Figure 26-2 WTS Connection Wizard 2




To use the second dialog box:

1. Check the **Automatic Logon** check box if appropriate.
2. Enter a user name, password, and a domain to complete the information.
3. Click on **Next**.

Figure 26-3 WTS Connection Wizard 3

To use the third dialog box in the wizard:

1. Click on either the **Desktop** or **Application File Name** radio buttons.
2. If you clicked on **Desktop**, click on **Next**.
3. If you clicked on **Application File Name**:
 - a. Enter the name of the desktop.
 - b. Enter the name of the directory where it resides.
 - c. Click on **Next**.

Figure 26-4 WTS Connection Wizard 4

To use the fourth dialog box, click on **Finish**. The **Winterm Connection Manager** displays, listing your new RDP connection.


27 Terminal Emulation Connections

Use the **TE Client Connection Wizard** to set up a terminal emulation connection. Terminal emulation connections use VT (Virtual Terminal) and Telnet to connect to servers. See “Creating New Connections” for more information about how to invoke this wizard.

Using the TE Client Connection Wizard

Following are the three dialog boxes of this wizard. When you are finished configuring a connection, the new connection will be added to the **Connection Name** list in the **Winterm Connection Manager**.

Figure 27-1 TE Client Connection Wizard - Connection Information



The screenshot shows a dialog box titled "TE Client Connection Wizard - Connection Information". It contains three input fields: "Connection Name:" with an empty text box, "Emulation:" with a dropdown menu showing "VT400 7-Bit", and "VT TerminalID:" with a dropdown menu showing "vt420". At the bottom, there are three buttons: "<Back", "Next>", and "Cancel".

To use the **Connection Information** dialog box:

- 1. Enter the connection name in **Connection Name**.
- 2. Select the emulation type in **Emulation**. Use Table 27-1 to match and select the terminal type taken from the second drop-down scroll list initially named **VT TerminalID**.
- 3. Click on **Next**.

Table 27-1 Terminal Emulation and Terminal Type

Terminal Emulation	Terminal Type
Select:	Then select from VT TerminalID :
VT52, VT100, VT400 7-Bit (default), or VT400 8-Bit	vt100, vt101, vt102, vt125, vt220, vt240, vt320, vt340, vt420 (default), vt131, or vt132
Select:	The function is deactivated.
ANSI BBS, SCO Console, IBM 3151, WY50, WY50+, TVI910, TVI920, TVI925, ADDS A2, HZ1500, or WY60	
Select:	Then select from IBM 3270 Model :
IBM3270	3278-2-E, 3278-3-E, 3278-4-E, 3278-5-E, 3279-2, 3279-3, 3279-4, 3279-5, or 3287-1
Select:	1. Select from IBM 5250 Model :
IBM5250	5291-1, 5292-2, 5251-11, 3179-2, 3196-A1, 3180-2, 3477-FC, 3477-FG, 3486-BA, 3487-HA, or 3487-HC 2. Check the Right Ctrl Acts as Enter Key , the Left Ctrl Acts as Reset Key , or the IBM5250 Monochrome check boxes if you want these functions enabled for 5250 emulation.

Figure 27-2 TE Client Connection Wizard - Host Information


The screenshot shows a dialog box titled "TE Client Connection Wizard - Host Information". It contains a "Connection Type" section with three radio buttons: "TCP/IP" (selected), "Modem", and "Serial". To the right of these are three input fields: "Host Name:" with the text "ged", "Connection Name:" with a dropdown menu showing "<New Session>", and "Connect to:" with a dropdown menu showing "Serial Cable on COM1:". Below these fields is an "Advanced..." button. At the bottom of the dialog are three buttons: "<Back", "Next>", and "Cancel".

To use the **Host Information** dialog box:

1. Click on **TCP/IP**, **Modem**, or **Serial**:
2. If you clicked on **TCP/IP**:
 - a. Enter the host name in **Host Name**.
 - b. Use the **Advanced** command button if appropriate. (See "Using the TCP/IP Telnet Configuration Dialog Box" for information about the **Advanced** command button).
 - c. Click on **Next**. The **Automate Login Process** dialog box displays. See Figure 27-3 and proceed with these instructions.

3. If you clicked on **Modem**:
 - a. Select a connection from **Connection Name**.
 - b. Use the **Configure** command button if appropriate. (See “Using the Modem Settings Dialog Box” for information about the **Configure** command button).
 - c. Click on **Next**. The **Automate Login Process** dialog box displays. See Figure 27-3 and proceed with these instructions.
4. If you clicked on **Serial**:
 - a. Make a selection from **Connect To**.
 - b. Use the **Configure** command button if appropriate. (See “Using the Configuration of Serial Cable on Com1 Dialog Box” for information about the **Configure** command button).
 - c. Click on **Next**. The **Automate Login Process** dialog box displays. See Figure 27-3 and proceed with these instructions.

Figure 27-3 TE Client Connection Wizard - Automate Login Process



To use the **Automate Login Process** dialog box:

1. Fill in the **Parameters** group box as appropriate.
2. Fill in the **Script** group box as appropriate.
3. Click on **Finish**.

Figure 27-4 TE Client Connection Wizard - Printer Port Settings

To use the **Printer Port Settings** dialog box:


1. Select the appropriate printer port from the **Printer Port** list.
2. Click on **FormFeed Terminator** or **Auto Line Feed**, if appropriate.
3. Use the **Configure** command button, if appropriate. (See "Using the Configuration of Serial Cable on Com1" dialog box for information about the **Configure** command button).
4. Click on **Finish** to finish the wizard.

The **Winterm Connection Manager** displays, listing your new terminal emulation connection.

Using the TCP/IP Telnet Configuration Dialog Box

The **Advanced** command button invokes the **TCP/IP Telnet Configuration** dialog box. Figure 27-5 shows this dialog box.

Figure 27-5 TCP/IP Telnet Configuration Dialog Box



The following table discusses the functions of a Telnet connection.


Table 27-2 TCP/IP Telnet Configuration

Function	Description
Port Number	Enter the Telnet port number. The default is 23.
Suppress	Use the functions of this group box as needed: - Echo 3270 Regime - TN3270E - TN5250E 3270 Options

Table 27-2 TCP/IP Telnet Configuration, Continued

Function	Description
----------	-------------

The following dialog box shows the **TN3270 Options** dialog box, displayed when the **3270 Options** command button is pressed.



Use this dialog box to set up 3270 options:

- **3270 LU Device Name** - This group box is used to identify the LU (Logical Unit).
- **TN3270E Options** - This group box is used to set TN3270E options. The options are **Bind**, **Responses**, and **SysReq**.



Note
Associate, **LU1 Printer**, and **LU3 Printer** are deactivated.


Table 27-2 TCP/IP Telnet Configuration, Continued

Function	Description
	TN5250 OptionsOKX Environment Device Name: User: Password: Library: Menu: Program:
	TN5250 Options OKX Environment Device Name: User: Password: Library: Menu: Program:
	Use this dialog box to set up 5250 options. They are: Device Name - Name of the device assigned to a Telnet session. User, Password, Library, and Menu - Initial entries on a standard startup screen. Program - Name of the initial program.
	Note All entries are 10 characters or less.
Telnet Name	Enter the Telnet virtual terminal name. The default depends on emulation (VT400, 7-bit, default is vt420).
Force Negotiation	Use the Binary and EOR drop-down scroll lists to configure negotiation parameters. The defaults are No and No .
Break Settings	Use the TM with Break and CR with Break check boxes to configure break settings. The default for both functions is activated but not enabled.

Using the Modem Settings Dialog Box

The **Configure** command button invokes the **Modem Settings** dialog box. Figure 27-6 shows this dialog box.

Figure 27-6 Modem Settings Dialog Box



The following table discusses the available modem settings.


Table 27-3 Modem Settings Dialog Box

Function	Description
Session	Enter the name of your session.
Select a Modem	Select a modem from the drop-down scroll list.
Configure	See “Using the Dialing Properties and Configure Command Button” for more information.
Dialing Properties	Use this list to configure: • Area Code • Country Code • Force Long Distance • Telephone Number • Dialing Properties • Force Local

Using the Configuration of Serial Cable on Com1 Dialog Box

The **Configure** command button invokes the **Configuration of Serial Cable on Com1** dialog box. Figure 27-7 shows this dialog box.

Figure 27-7 Configuration of Serial Cable on Com1 Dialog Box



The following table discusses this dialog box.


Table 27-4 Configuration of Serial Cable on Com1 Dialog Box

Function	Description
Configuration of a Serial Cable on Com1	Use these functions to configure a serial cable: • Baud Rate • Parity • Flow Control • Data Bits • Stop Bits • Transmit Limit Each is presented as a drop-down scroll list. Click on the upper-right down arrow to display the list and select a value. The defaults are listed (consecutive to the Function list to the left) as follows: • 9600 • None • Input • 8 • 1 • Unlimited
Local Echo	Click on this check box to enable local echo.

28 Editing Connections

The **Winterm Connection Manager** lets you edit individual RDP connection parameters. It is done through the **Properties** dialog box. The following figure shows the **Properties** dialog box.

Figure 28-1 Properties Dialog Box



Using the Properties Dialog Box

The **Properties** dialog box consists of two properties sheets. Depending on your connections configuration, you use one of these properties sheets to edit connection parameters. To invoke the dialog box:

1. Click on the **Configure** tab in the **Winterm Connection Manager** dialog box.
2. Click on the **Edit** command button on the **Configure** properties sheet.



Note

The functions of this dialog box are for editing RDP connections only. ICA, Dial-Up, and Terminal Emulation connections can be edited using their respective setup wizards. See “ICA Connections,” “Dial-Up Connections,” or “Terminal Emulation Connections” for further information.

Using the Net Connections Properties Sheet

The **Net Connections** properties sheet is displayed by default for the **Properties** dialog box. See Figure 28-1. Use this properties sheet to reconfigure a network connection.

The following table describes the functions of the **Net Connections** properties sheet.


Table 28-1 Net Connections Properties Sheet

Function	Description
Connection	Select a connection from the Connection Name list in the Terminal Connection Manager. Use the following functions to change the connection’s network parameters: Name Enter the name of the connection in this field. When OK is selected, your changes will be saved and Name will replace what was selected. Server Enter the address of the server in this field.
Automatic Logon	Click on this check box to enable automatic logon for your terminal. Enabling this function enables the Username, Password, and Domain fields: Username Enter your user name. Password Enter your password. Domain Enter your domain.
Connection Speed	Low Speed Connection Click on this to enable low-speed connection.

Using the Application Properties Sheet

Invoke the **Application** properties sheet by clicking on the **Application** tab in the **Properties** dialog box. The following figure shows this sheet.

Figure 28-2 Application Properties Sheet



The following table describes the functions of the **Application** properties sheet.

Table 28-2 Application Properties Sheet


Function	Description
Application to Run	Select a connection from the Connection Name list in the Terminal Connection Manager . Use the following functions to edit application types: Desktop Click on this radio button to include a desktop application in your connection parameters. File Name Click on this radio button to include a file in your connection parameters. Enter the name of the file in the field provided. Working Directory Enter the directory path to the file provided in File Name .

 **Note**
Desktop and **File Name** are mutually exclusive. **File Name** must be selected in order to use the **File Name** and **Working Directory** fields.

29 Modem Connection Configuration

The **Devices** properties sheet contains functions to change ISDN settings and add new modems. These are modem connection parameters. See Figure 29-1 for a view of the **Devices** properties sheet.

Figure 29-1 Devices Properties Sheet



Using the Devices Properties Sheet

To invoke this properties sheet,

- 1. Press **F2** to invoke the **Terminal Properties** dialog box.
- 2. Click on the **Devices** tab in the **Terminal Properties** dialog box.

The following table describes the functions of this dialog box.

Table 29-1 Devices Properties Sheet

Function	Description
ISDN Settings	Click on this command button to invoke the ISDN Settings dialog box. See the following heading “ISDN Settings.”
Add/Change Modem	Click on this command button to invoke the Adding New Modems dialog box. See the following heading “Adding New Modems.”

ISDN Settings

Use the **ISDN Settings** dialog box to set the terminal's ISDN settings. If you do not know this information, please ask your system administrator.



Note

These settings are specific to Eicon-Tech modems only.

Figure 29-2 ISDN Settings Dialog Box

ISDN Settings

Modem Name: EiCon_Technology_Corporation-DIVA_T/A-895D

Primary ISDN Parameters

Switch Type: AT & T SESS

Service Profile ID 1 (SPID 1): 0195481110

Service Profile ID 2 (SPID 2): 0195410020

Protocol: Multilink PPP

OK Cancel

To invoke the dialog box, click on the **ISDN Settings...** command button on the **Devices** properties sheet.

Table 29-2 discusses the functions of the **ISDN Settings** dialog box.


Table 29-2 ISDN Settings Dialog Box

Function	Description
Modem Name	This field displays the brand name of the modem in your system.
Primary ISDN Parameters	Use this group box to configure the following ISDN parameters: Switch Type Use this drop-down scroll list to select the switch type. The default is AT & T 5ESS. Service Profile ID 1 Use this field to enter Service Profile ID 1. This field only allows numbers. The default is 0195481110. Service Profile ID 2 Use this field to enter Service Profile ID 2. This field only allows numbers. The default is 0195410020.
Protocol	Use this drop-down scroll list to select a protocol. The default is Multilink PPP .

Adding or Changing Modems

Use the **Add or Change Modem** dialog box to add a new modem or change the parameters for a modem that has already been added.

Figure 29-3 Add or Change Modem Dialog Box



To invoke the dialog box, click on the **Add/Change Modem...** command button on the **Devices** properties sheet.

Table 29-3 discusses the functions of this dialog box.

Table 29-3 Add or Change Modem Dialog Box

Function	Description
Modem Name	This field displays the brand name of the modem in your system.
Init Commands	Enter a modem initialization command string in this field. The default is ATEOV1&C1&D1<cr> .
Flow Settings	Use this group box to set the following flow settings: Flow Hardware Enter a flow hardware command string in this field. The default is AT&K3<cr> . Flow Software Enter a flow software command string in this field. The default is AT&K4<cr> . Flow Off Enter a flow hardware command string in this field. The default is AT&K0<cr> .

 **Note**
The Hayes command set is discussed in greater detail in “Modem AT Commands.”



Terminal Firmware Upgrades

- 30 Cable Firmware Upgrades**
- 31 FTP Pull Firmware Upgrades**
- 32 Administering Terminals Using SNMP**
- 33 SNMP Upgrades**
- 34 Changing DHCP Option IDs**
- 35 DHCP Firmware Upgrades**

30 Cable Firmware Upgrades

The following section describes the cable method of firmware download. The cable method for all terminals is parallel download, using a Laplink[®] cable and the MS-DOS xfer.exe program.

Setup

The following equipment may be needed, depending on the download procedure used:

- IBM-compatible PC with a CD-ROM drive and a parallel/serial port.
- Terminal firmware upgrade diskette or CD.
- LapLink or equivalent parallel port communications cable (used only if parallel port is used for downloading).

To validate an image file before downloading, type ***check <filename.ext>*** at the DOS command line, then press **Enter**. The check utility verifies the image file.



Note

For convenience, drive D:\ is used for the CD drive. You should substitute the appropriate drive letter for your PC.

Flash Parallel Download Procedure

This procedure includes both manual and auto download instructions. The download procedure will not work unless your PC is booted to DOS.

1. Record the terminal's current configuration.



Caution

All previous settings will be lost. Upgrading the firmware defaults the current configuration to the factory default settings.


2. Turn off the terminal.
3. Connect a parallel LapLink cable from the parallel port of your PC to the parallel port of the terminal.
4. Insert the firmware upgrade CD into your PC.
5. Type **D:** at the DOS prompt to select the drive where the download files exist. Use the **dir** command to find the files.
6. Perform either "Manual Download" or "Auto Download."

Manual Download

Use the following instructions to perform a manual download.

1. Type **xfer <filename.ext>** at the DOS prompt
2. Press **Enter**, and the **Download Utility** dialog box appears. See the following figure.

Figure 30-1 Download Utility Dialog Box



3. Power-up the terminal to initiate the download.

The **Firmware Upgrade** dialog box appears, showing that the download is in progress. When the download is complete, disconnect the parallel cable. The **Setup Wizard** will appear.

**Note**

If the download dialog box remains on the screen longer than 1 minute, press the **Enter** key. A prompt to repeat or quit the operation appears. If the download fails, quit the procedure, check all cables and connections, then repeat from Step 2.

Auto Download

Use the following instructions to perform an auto download:

1. Log on to the root of the drive where the installation batch file resides (usually D:).
2. Type install at the DOS prompt, then press **Enter**. The **Download Utility** dialog box appears and the install program prompts you through the download procedures.
3. When you are finished with your download, disconnect the LapLink cable and reconnect the peripheral cables.
4. Power-up the terminal and reconfigure its communications and options settings.
5. Check the **About** dialog box to verify the download revision.

Cable Pinouts

Parallel Download Cable Pinouts

The following table lists the parallel download cable pinouts.


Table 30-1 Parallel Download Cable Pinouts

PC Side	Terminal Side
Pin 01	Pin 01
Pin 02	Pin 15
Pin 03	Pin 13
Pin 04	Pin 12
Pin 05	Pin 10
Pin 06	Pin 11
Pin 07	*
Pin 08	*
Pin 09	*
Pin 10	Pin 05
Pin 11	Pin 06
Pin 12	Pin 04
Pin 13	Pin 03
Pin 14	Pin 14
Pin 15	Pin 02
Pin 16	Pin 16
Pin 17	Pin 17
Pins 18 to 25	Pin 25 Gnd

* - Pin(s) not connected

The following figure shows the connector for the parallel download cable.

Figure 30-2 Parallel Download Cable Connectors



31 FTP Pull Firmware Upgrades

Use the **Upgrade** properties sheet to:

1. Set up a terminal for communication with an FTP server.
2. Perform FTP pull upgrades.

See Figure 31-1.

Figure 31-1 Upgrade Properties Sheet

The image shows a screenshot of the 'Terminal Properties' dialog box, specifically the 'Upgrade' tab. The dialog has a title bar with a close button. Below the title bar is a tabbed interface with tabs for General, Input, Display, Network, Upgrade (selected), Security, Apps, Devices, SysInfo, and About. The 'Upgrade' tab contains a section titled 'Local Firmware Upgrade:' with two radio buttons: 'Use ETP Information From DHCP Server' (unselected) and 'Use Local FTP Information' (selected). Below the radio buttons are two text input fields: 'Server Name:' and 'Server Directory:'. Further down are 'User ID:' (containing 'anonymous') and 'Password:' (containing '*****') fields. A 'Status:' section includes a checkbox for 'Save Password' which is unchecked. At the bottom right of the dialog is an 'Upgrade' button. At the very bottom are 'OK', 'Cancel', and 'Apply' buttons.

Using the Upgrade Properties Sheet

To invoke this properties sheet:

- 1. Press the **F2** key.
 - 2. Click on the **Upgrade** tab in the **Terminal Properties** dialog box.
- The following table describes the functions found on this properties sheet.

Table 31-1 Upgrade Properties Sheet

Function	Description
Local Firmware Upgrade	Use this group box to upgrade your terminal's firmware using an FTP server. The functions are: Use FTP Information from DHCP Server Select this function if you want to get the FTP server and directory information from a DHCP server. Click on this radio button to select the function. By default the function is enabled. Use Local FTP Information Select this function if you want to enter the FTP server you will use for the upgrade. Click on the radio button to select the function. By default the function is disabled. Server Name Enter the name or IP address of the FTP server where <i>bootstrap.exe</i> and the upgrade firmware reside. The default is blank. Server Directory Enter the directory on the FTP server where <i>bootstrap.exe</i> resides. The default is blank. User ID Enter your user account in this field. The default is Anonymous. Password Enter your password in this field. The default is *****.

Table 31-1 Upgrade Properties Sheet, Continued

Function	Description
Upgrade	Status This display box shows status information about the connection to the FTP server, and the firmware download. Connect and download errors are also reported. The default is blank.
	Save Password Check this box to save the entered password in the registry.
	Click on this command button to initiate the upgrade procedure. By default the button is disabled until an entry is made in the FTP Server field.

FTP and Bootstrap.exe

The download is initiated through the **Upgrade** command button on the **Upgrade** properties sheet. Information in the **Upgrade** properties sheet must be filled out to ensure a proper download. See “Resetting Properties” for more details about this properties sheet.

Bootstrap.exe and params.ini must be installed on your FTP server to use this method of download. To install these files, drag and drop them from the CD-ROM to the appropriate directory on your FTP server. The upgrade firmware can be obtained from manufacturer’s customer support.

The Upgrade Process

To upgrade:

1. Place bootstrap.exe, params.ini, and the new firmware file on your FTP server.
2. Press **F2** to invoke the **Terminal Properties** dialog box.
3. Click on the **Upgrade** properties sheet tab and enter the appropriate information.
4. Click on the **Upgrade** command button.


The bootstrap program uses **Server Name**, **User ID**, **Password**, and **Server Directory** from the **Upgrade** properties sheet to access the FTP server. The program performs the upgrade, checks for errors, and reboots the terminal.

**Note**

An upgrade can not be cancelled once it has started.

A series of dialog boxes displays during the upgrade.

Figure 31-2 Firmware Upgrade Dialog Box 1




This is the first dialog box that displays. Read for information and click on **Start** to upgrade, or **Cancel** to quit the process.

**Note**


If you are downloading the same version of firmware that is already on the terminal, a dialog box displays reporting that you are downloading the same version.

Figure 31-3 Firmware Upgrade Dialog Box 2



After **Start** is clicked, the download begins.

Figure 31-4 Firmware Upgrade Dialog Box 3




If your current firmware is up to date, the process will automatically stop, displaying this dialog box. Click on **Retry** to restart the upgrade. Click on **Cancel** to quit.

When the upgrade is complete, the terminal will reboot.

32 Administering Terminals Using SNMP

The **SNMP Network Administration** dialog box contains the functions that you can use to administer to the terminals on your SNMP network. See Figure 32-1.

Figure 32-1 SNMP Network Administration Dialog Box



The dialog box is titled "SNMP Network Administration" and is divided into two main sections: "SNMP Communication" and "Terminal Information".

SNMP Communication

- ☒ **Enable Authenticating Failure Trap**
- Community**
 - Get: public
 - Set: WBTADMIN
- Trap Destination**
 - Server 1: [text box]
 - Server 2: [text box]
 - Server 3: [text box]
 - Server 4: [text box]

Terminal Information

- Description**
 - Terminal Name: WBT0080640ABE34
 - Location: [text box]
 - Contact: [text box]
- Custom**
 - Field 1: [text box]
 - Field 2: [text box]
 - Field 3: [text box]

At the bottom of the dialog box are two buttons: **OK** and **Cancel**.

Using the SNMP Network Administration Dialog Box

To invoke this dialog box:

- 1. Press the **F2** key to invoke the **Terminal Properties** dialog box.
- 2. Click on the **Apps** tab to invoke the **Apps** properties sheet.
- 3. Click on the **SNMP Network Administration** command button.

The following table discusses the functions of this dialog box.

Table 32-1 SNMP Network Administration Dialog Box

Function	Description
SNMP Communication	Use this group box to set up SNMP communication using the following functions: Enable Authenticating Failure Trap Check this box to enable the authenticating failure trap. Community Use this group box to configure the network management of a community. Get This field takes the name of the community the SNMP management software will manage with read permission only. If this field is left blank, the community for that terminal will be public. The default for this field is Public. Set This field contains the name of the community the SNMP management software will manage with write permission. By default, the set community that the terminal belongs to is called WBTADMIN. The default for this field is WBTADMIN.  Note All Get and Set names are case sensitive and lower case. Trap Destination Server 1:, Server 2:, Server 3:, and Server 4: are fields that supply the names or IP addresses of the servers to which the terminal sends SNMP traps.

Table 32-1 SNMP Network Administration Dialog Box, Continued

Function	Description
Terminal Information	Use this group box to list information about terminals. Description Use this group box to describe a terminal. Terminal Name Type the name of a terminal in this field. On default, this displays the WBT and the MAC address of the product. Location Type the location of the terminal in this field. Contact Type the name of the administrator of the subject terminal in this field. Custom Use the following fields to type in any custom message associated with the subject terminal: • Field 1 • Field 2 • Field 3 Each field will take 23 characters maximum.

33 SNMP Upgrades

Manual SNMP Firmware Upgrades

1. Ensure that the Wyse custom MIB (Management Information Base) is compiled by your SNMP manager.



Note

In order to initiate an SNMP upgrade, you must know the FTP or TFTP server's IP address or machine name, and the absolute path to the image on the FTP or TFTP server.



Note

In the Wyse custom MIB the enterprise number for Wyse is 1.3.6.1.4.1.714. Therefore, in this section Wyse is equivalent to 1.3.6.1.4.1.714.

2. Enable **SNMP Update Enable** if it is not enabled.
3. Using the **SNMP/Network Administrator** dialog box, verify that the community and set community names for the terminal match the community and set community names in the SNMP manager.



Note

You can set the **Set Community** name for a terminal if you have DHCP enabled by setting DHCP Option 164 to the set community name your SNMP manager uses.

4. Using your SNMP manager:

- a. Go to Wyse 1.2.3.8.1.2 (wbt3UpDnLoadTable).
- b. Go to Wyse 1.2.3.8.1.1.2.1.2 (wbt3UpDnLoadID), user defined string.

**Note**

The above is used in traps to identify the download operation.

- c. Go to Wyse 1.2.3.8.1.1.2.1.3 (wbt3UpDnLoadOp), and set its value to 1 (Download).
- d. Go to Wyse 1.2.3.8.1.1.2.1.4 (wbt3UpDnLoadSrcFile), and set its value to the absolute path of the directory where the image file and params.ini are located.
- e. Go to Wyse 1.2.3.8.1.1.2.1.6 (wbt3UpDnLoadFileType), and set its value to 0 (Binary).
- f. Go to Wyse 1.2.3.8.1.1.2.1.7 (wbt3UpDnLoadProtocol), and set its value to 0 (FTP or TFTP).
- g. Go to Wyse 1.2.3.8.1.1.2.1.8 (wbt3UpDnLoadFServer), and set its value to the IP address or DNS name of the FTP or TFTP server.
- h. Go to Wyse 1.2.3.8.1.4 (wbt3SubmitLoadJob), and set its value to 1 (Ready).

Step 4h will initiate an SNMP upgrade to your terminal. If the download is configured properly, the new image will download and the terminal will reboot automatically to factory defaults.

34 Changing DHCP Option IDs

Use the **Change DHCP Option IDs** dialog box to set up DHCP option IDs for terminal administration and upgrade. See Figure 34-1 for a view of this dialog box.

Figure 34-1 Change DHCP Option IDs Dialog Box

Change DHCP Option IDs

Common Option IDs

Remote Server : 155

Logon User Name: 156

Domain: 157

Logon Password: 158

Command Line: 159

Working Directory: 160

FTP Option IDs

File Server: 161

File Root Path: 162

SNMP Option IDs

Trap Server IP List : 163

Set Community: 164

Terminal Emulation Option IDs

Emulation Mode : 166

Terminal ID: 167

RDP Option ID

Startup Application: 165

Virtual Port Option ID

Server: 168

OK Cancel Reset To Defaults



Note

Option 158 is not supported yet. It is reserved for future use.

Using the Change DHCP Option IDs Dialog Box

Your terminal uses DHCP and the information on the **Change DHCP Option IDs** dialog box to:

- Help establish ICA and RDP connections
- Perform automated firmware updates
- Help define terminal emulation connections
- Specify the virtual port server
- Implement remote management of SNMP parameters

To invoke this dialog box:

1. Press the **F2** key.
2. Click on the **Apps** tab.
3. Click on the **Change DHCP Option** command button.

The following table describes the functions of this dialog box.

Table 34-1 Change DHCP Option IDs Dialog Box

Function	Description
Common Option IDs	Group box used to assign DHCP option IDs to common DHCP variables. The number in each field is the DHCP option ID. The following field titles are the DHCP variables: • Remote Server • Logon User Name • Domain • Logon Password - reserved for future use • Command Line • Working Directory
RDP Option IDs	Group box used to set the following RDP option IDs: Startup Application
FTP Option IDs	Group box used to set the following FTP option IDs: • File Server • File Root Path

Table 34-1 Change DHCP Option IDs Dialog Box, Continued


Function	Description
SNMP Option IDs	Group box used to set the following SNMP option IDs: • Trap Server IP List • Set Community
Terminal Emulation Option IDs	Group box used to set the following terminal emulation option IDs: • Emulation Mode • Terminal ID
Virtual Port Option IDs	Group box used to set the following virtual port option IDs: Server
Reset To Defaults	Click on this command button to reset all option IDs to the default values.
	 Note The values shown in Figure 34-1 are the terminal default values.

35 DHCP Firmware Upgrades

Automatic DHCP Firmware Upgrades


1. Press the **F2** key for the **Terminal Properties** dialog box.
2. Click on the **Network** tab.
3. Click on the **Obtain an IP Address From DHCP Server** radio button, if the function is not enabled. See Figure 35-1.

Figure 35-1 Obtain an IP Address From DHCP Sever Radio Button



4. Click on the **Apps** tab.
5. Click on the **DHCP Automatic Update Enable** check box on the **Apps** properties sheet, if the function is not enabled. See Figure 35-2.

Figure 35-2 DHCP Automatic Update Enable Check Box



**Note**

You have now enabled the automatic DHCP function. You will also need to configure your DHCP option IDs. Make sure your DHCP options match the options on the DHCP server.

6. Click on the **Change DHCP Option...** command button.
7. Use the **Change Option IDs** dialog box to change options, then click on **OK** to save.

**Note**

Pay special attention to these FTP Option IDs functions: **File Server** (the location of the server where the firmware resides), and **File Root Path** (the location of the firmware).

8. Click on the **Upgrade** tab.
9. Click on the **Use FTP Information From DHCP Server** radio button on the **Upgrade** properties sheet.

**Note**

You will need the image and the params.ini files on the FTP server to do the upgrade.

10. Shut down the terminal. See “Shutting Down the Terminal” for more information. Your terminal will automatically upgrade itself when it is powered-up again.

Manual DHCP Firmware Upgrades

1. Follow instruction 1 through 3 and 5 through 8 in “Automatic Firmware Upgrades.”
2. Click on the **Upgrade...** command button on the **Upgrade** properties sheet.

This will initiate the firmware upgrade. Once the upgrade is complete, the terminal will reboot to the **Setup Wizard**.



Client Security

- 36 Security Properties**
- 37 Terminal Accounts**
- 38 Creating Terminal Accounts**
- 39 Modifying and Deleting Terminal Accounts**
- 40 Terminal Login**
- 41 Failover**

36 Security Properties

Use the **Security** properties sheet to access security features and global terminal functions. You can also use this sheet to set up terminal accounts. Figure 36-1 shows the **Security** properties sheet.

Figure 36-1 Security Properties Sheet

The screenshot shows the 'Terminal Properties' dialog box with the 'Security' tab selected. The dialog has a title bar with a close button. Below the title bar is a tabbed interface with tabs for General, Input, Display, Network, Upgrade, Security (selected), Apps, Devices, SysInfo, and About. The Security tab contains several sections: 'Security Enable' with a checkbox and a 'Hide Configure Tab' checkbox; 'AutoLogin Enable' with a checkbox, a 'User Name' text field, and a 'Single Button Connect' checkbox; 'FailOver Enable' with a checkbox, and 'Multiple Connect', 'PingBeforeConnect', and 'Verbose' checkboxes; 'DHCP Connection Enable' with a checkbox and a 'Connection Name and Type' dropdown menu; and 'Auto Fail Recovery' with a checkbox. Below these sections is a 'User Accounts' section with a table showing the 'Administrator' user. To the right of the table are buttons for 'Add User...', 'Modify User...', and 'Delete User...'. At the bottom of the dialog are 'OK', 'Cancel', and 'Apply' buttons.

Account Name	Privilege	AutoStart	AutoLogin
Administrator	Admin	No	No

Using the Security Properties Sheet

To invoke the **Security** properties sheet:

- 1. Press **F2** to invoke the **Terminal Properties** dialog box.
- 2. Click on the **Security** tab.

The following table describes the functions of this properties sheet.

Table 36-1 Security Properties Sheet

Function	Description
Security Enable	This group box is used to enable terminal security and connection configuration access. It contains the following functions: Security Enable Click to enable terminal security, and deactivate the Hide Configure Tab function. By default this function is disabled. Hide Configure Tab Click to enable. This function hides the Configure tab in the Winterm Connections Manager. By default this function is disabled.
Failover Enable	Use this group box to manipulate connection features. See “Failover” for more information. Failover Enable Click to enable the failover function. Enabling this function deactivates the PingBeforeConnect function, and activates Multiple Connect and Verbose functions. By default this function is disabled. Multiple Connect Click to enable this function. Failover must be enabled before you can access this function. By default this function is not activated. PingBeforeConnect Click to enable this function. Enabling this function will activate Verbose. By default this function is disabled.

Table 36-1 Security Properties Sheet, Continued

Function	Description
Failover Enable , continued	Verbose Click to enable the Verbose connection function. By default the box is not activated. This function becomes activated when either Failover or PingBeforeConnect is enabled.
AutoLogin Enable	This group box is used to configure login parameters. See “Autologin and Autoconnect” for more information about autologin. AutoLogin Enable Click to enable the function. AutoLogin is enabled only for the user name currently highlighted in the User Accounts list box. Enabling the autologin function activates Single Button Connect. By default the function is disabled. User Name This field is activated by enabling AutoLogin Enable. By default the field is blank. Single Button Connect Click to enable the function. See the chapter “Terminal Login” for more information. By default the function is not activated.
DHCP Connection Enable	Use this group box to access the DHCP connection list. DHCP Connection Enable Click to enable the function. Enabling this function activates the Connection Name and Type list. By default this function is disabled. Connection Name and Type A scroll list that displays all connections available to your terminal. You must select the connection that will use information supplied by DHCP. By default this function is not activated.

Table 36-1 Security Properties Sheet, Continued

Function	Description
Auto Fail Recovery	Click on the check box to enable the function. Auto fail recovery is a function that checks the validity of a disconnect, and closes down a connection if disconnect checks true. By default, the function is activated but not enabled.
User Accounts	A list box displaying: Account Name Lists the account names. Privilege Lists the privilege type, either Admin, User, or Guest. AutoStart Lists the autostart permission, either Yes or No. AutoLogin Lists the autologin permission, either Yes or No. For more information about user accounts see "Terminal Accounts."
Add User	See "Adding Terminal Accounts."
Modify User	See "Modifying and Deleting Terminal Accounts."
Delete User	See "Modifying and Deleting Terminal Accounts."



37 Terminal Accounts

A terminal account is a group of connection and configuration parameters organized into a file (account) and assigned to a terminal user. Terminal accounts can include specific connections, security enable, password protection, **Autologin** and/or **Autostart**, and **Single Button Connect**. The three types of accounts are:

- **Guest**
- **User**
- **Administrator**

Guest Accounts

The **Guest** account has the fewest amount of privileges. With this account you can not:

- Configure a connection
- Gain access to the password function

With this account type you can only:

- Use the **Screen Saver**, **Touch Screen**, **Character Repeat**, and **Keyboard Locale** functions
- Adjust display resolution

User Accounts

With a **User** account, you will not be able to configure the connection for the account. You will be able to access the password function. You can also:

- Use the **Network** properties sheet
- Use the **Apps** properties sheet with the exception of **SNMP** and **DHCP**
- Use the **Devices** properties sheet with the exception of **Add/Change Modem**

Administrator Accounts

The **Administrator** account has the greatest amount of privileges. With this account you can:

- Use **Enable Password Change** (change the password for an account)
- Configure or reconfigure the connection for an account
- Use all the other functions of the terminal

Using Terminal Accounts

Terminal accounts are created and managed by using the **Add User...**, and **Modify User...** command buttons. Terminal accounts are deleted using the **Delete User...** command button. These buttons are found on the **Security** properties sheet.



Note

There is a built-in account called **Administrator**. It can not be deleted or revised. The account's password can be changed and is **<blank>** by default.

For more information about terminal accounts, see:

- “Security Properties”
- “Creating Terminal Accounts”
- “Modifying and Deleting Terminal Accounts”

38 Creating Terminal Accounts

The **Add User Account** dialog box is used to create terminal accounts. The following figure shows this dialog box.

Figure 38-1 Add User Account Dialog Box

Add User Account

☐ Enable Password Change

User Name:

Password:

Confirm Password:

Account Privilege

☐ Administrator

☐ User

☒ Guest

☐ Multiple AutoStart

Available Connections	Type
Default ICA Connection	ICA
Default RDP Connection	RDP
hgfdn	DialUp
khg	ICA
NT_MECHSERVER	ICA
NT_SQA1	ICA

Assign >

Unassign <

Up >

Down >

Toggle AutoStart >

Connection Name	Type	AutoStart
-----------------	------	-----------

OK Cancel

Using the Add User Account Dialog Box

Use the **Add User Account** dialog box to set up the parameters for new terminal accounts. To invoke this dialog box:

- 1. Press **F2** while in the **Winterm Connection Manager**.
- 2. Click on the **Security** tab in the **Terminal Properties** dialog box.
- 3. Click on the **Add User...** command button.

The following table describes the functions of the **Add User Account** dialog box.

Table 38-1 **Add User Account Dialog Box**

Function	Description
Enable Password Change	Group box used to set up password functions.  Note The fields of this group box are limited to 20 characters or less. Enable Password Change Click to enable. Enabling the function will allow the user to change a password. This function is activated by assigning the account User account privilege. By default Enable Password Change is deactivated. Username Type in the new user name. By default the field is blank. Password Type in the password. By default the field is blank. Confirm Password Type in the password again. By default the field is blank.

Table 38-1 Add User Account Dialog Box, Continued

Function	Description
Available Connections	This is a list box displaying all the terminal's connections. It contains: Available Connections This list shows the connections available for terminal accounts. Type This section of the list displays the connection type for each connection: • ICA • DialUp • RDP • TEC (terminal emulation)
Assign	Click on this command button to copy a connection from Available Connections to Connection Name. You must first select (highlight) the connection you want to copy.
Unassign	Use this button to delete a connection from Connection Name. You must first select the connection you want to delete.
Up	Select a connection and click on the Up command button to move it up one place in the Connection Name list. If there is not two or more connections listed in Connection Name, the button is deactivated.
Down	Select a connection and click on the Down command button to move it down one place in the Connection Name list. If there is not two or more connections listed in Connection Name, the button is deactivated.
Toggle AutoStart	Click on this command button to toggle between Yes and No. These two choices are listed under AutoStart in Connection Name.

Table 38-1 Add User Account Dialog Box, Continued

Function	Description
Connection Name	List box displaying connections. To learn more, see the following: Connection Name This list shows the connections available to a terminal account. Type This section of the list displays the connection type of each connection. See Type above. AutoStart This section of the list displays whether the connection will or will not start automatically.
Account Privilege	Group box used to assign an account an account privilege: Administrator Click this radio button to assign the privileges of administrator to an account. If this function is enabled: • All connections in Available Connections are automatically assigned to Connection Name for use. • Enable Password Change is deactivated but enabled. Administrators will always have the ability to change their passwords. User Click this radio button to assign the privilege of user to an account. If User is enabled, Enable Password Change is activated. Administrators can give users the ability to change their password. Guest Click this radio button to assign the privilege of guest to an account. If Guest is enabled, then Enable Password Change is deactivated. Users with this account type can not change passwords.
Multiple AutoStart	Click to check this box and enable the multiple autostart function.

39 Modifying and Deleting Terminal Accounts

The **Modify User Account** dialog box is used to modify and delete terminal accounts. The **Delete** command button, discussed later in Deleting Terminal Accounts, is used to delete terminal accounts. Figure 39-1 shows the **Modify User Account** dialog box.

Figure 39-1 Modify User Account Dialog Box

Modify User Account: Administrator

☒ Enable Password Change

User Name: Administrator

Password:

Confirm Password:

Account Privilege

☒ Administrator

☐ User

☐ Guest

☐ Multiple AutoStart

Available Connections	Type
Default ICA Connection	ICA
Default RDP Connection	RDP
hgfdn	DialUp
khg	ICA
NT_MECHSERVER	ICA
NT_SQA1	ICA

Assign >

Unassign <

Up >

Down >

Toggle AutoStart >

Connection Name	Type	AutoStart
Default RDP Connection	RDP	No
Default ICA Connection	ICA	No
hgfdn	DialUp	No
NT_SQA1	ICA	No
khg	ICA	No
NT_MECHSERVER	ICA	No

OK Cancel

Using the Modify User Account Dialog Box

To invoke this dialog box:

- 1. Press **F2** from the **Winterm Connection Manager**.
- 2. Click on the **Security** tab in the **Terminal Properties** dialog box.
- 3. Highlight the account to be modified and click on the **Modify User...** command button.

The following table describes the functions of the **Modify User Account** dialog box.

Table 39-1 Modify User Account Dialog Box

Function	Description
Enable Password Change	Group box used to set up password functions. Enable Password Change Click to enable. Enabling the function will allow the user to change the password. This function is only activated for User accounts. By default Enable Password Change is disabled. Username This field can not be modified. Password Type in the new password. By default the field is the old password, represented by several asterisks. Confirm Password Retype the password. By default the field is the old password, represented by several asterisks.  Note The preceding fields are limited to 20 characters or less.
Available Connections	List box displaying connections. Available Connections This list shows all the connections available for terminal accounts. Type The section of the list that shows the connection type.

Table 39-1 **Modify User Account Dialog Box, Continued**

Function	Description
Assign	Click on this command button to copy a connection from Available Connections to Connection Name . You must first select to highlight the connection you want to copy.
Unassign	Use this button to delete a connection from Connection Name . You must first select (highlight) the connection you want to delete.
Up	Select a connection and click on the Up command button to move it up one place in the Connection Name list. If there is not two or more connections listed in Connection Name , the button is deactivated.
Down	Select a connection and click on the Down command button to move it down one place in the Connection Name list. If there is not two or more connections listed in Connection Name , the button is deactivated.
Toggle AutoStart	Click on this command button to toggle between Yes and No . These two choices are listed under AutoStart in Connection Name .
Connection Name	List box displaying connections. Connection Name This list shows the connections available for use by a terminal account. Type This is the section of the list that displays the connection type of each connection. AutoStart This is the section of the list that displays whether the connection will or the connection will not autostart.

Table 39-1 **Modify User Account Dialog Box, Continued**

Function	Description
Account Privilege	Group box used to assign an account an account privilege: Administrator Click this radio button to assign the privileges of administrator to an account. If this function is enabled: • All connections in Available Connections are automatically assigned to Connection Name for use. • Enable Password Change is deactivated but enabled. Administrators will always have the ability to change their passwords. User Click this radio button to assign the privilege of user to an account. If User is enabled, Enable Password Change is activated. Administrators can give Users the ability to change their password. Guest Click this radio button to assign the privilege of guest to an account. If Guest is enabled, then Enable Password Change is deactivated. Users with this account type can not change passwords.
Multiple AutoStart	Click to check this box and enable the multiple autostart function.

Deleting Terminal Accounts

Terminal accounts can be deleted from the **User Accounts** list on the **Security** properties sheet. To delete an account:



Caution

You can not recover a deleted account.

1. Click on the account that you want to delete in the **User Accounts** list.
2. Click on the **Delete User...** command button.

The following dialog box will display.

Figure 39-2 Delete User Account Confirmation Dialog Box



To delete the listed account, click on the **Yes** command button. The terminal account is removed from the database.




Note

You can not delete the built-in **Administrator** account.

40 Terminal Login

Terminal login is used as a terminal security measure. Only users with the correct **User Name** and **Password** will be able to log into the terminal. Figure 40-1 shows the **Terminal Login** dialog box.

Figure 40-1 Terminal Login Dialog Box

The image shows a 'Terminal Login' dialog box. It has a blue title bar with the text 'Terminal Login'. The main area is light gray and contains two text input fields. The first field is labeled 'User Name:' and the second is labeled 'Password:'. Below these fields is an 'OK' button with a small icon to its left.

Logging Into the Terminal

To use the login feature:

1. Enable security. See “Security Properties” for more details.
2. Log out of the terminal by clicking on the **Shutdown** command button in the **Winterm Connection Manager**.
3. Click on the **Logout** radio button in the **Shutdown Window** dialog box.

The **Terminal Login** dialog box displays. In this dialog box:

1. Type in the correct **User Name** and **Password**.
2. Click on **OK** to log into the terminal again.


Autologin and Autoconnect

Autologin

The autologin feature is an automatic login function that does not use a dialog box as a prompt to log you into your terminal again. Whether you restart or log off, the **AutoLogin** dialog box displays, counts five seconds, then returns you to the **Winterm Connection Manager**.

This is a global function, so it does not matter what other functions you have enabled. Autologin is associated with an account and only one account can have autologin associated with it. It will always act in the same manner. The following figure shows the **AutoLogin** dialog box.

Figure 40-2 AutoLogin Dialog Box



AutoStart

AutoStart is a function that automatically connects you once you have logged into your terminal. Autostart can be added to any defined connection in any account. Each user can have different and/or multiple autostart connections. To use the function:

1. Enable security.
2. Select the account you want Autostart added to and click on the **Modify User** command button.
3. Use the **Modify User** dialog box to add Autostart.
4. Restart or log off of your terminal.


The **Terminal Login** dialog box displays. Use it to log into your terminal. The **AutoStart** function will then automatically connect you to the connection that has autostart associated with it.

See “Shutting Down the Terminal” for more details about logging into the terminal.

Single Button Connect

The **Single Button Connect** feature is an automatic login function that uses a dialog box as a prompt to log you into your terminal again after logging out. Figure 40-3 shows this dialog box.

Figure 40-3 Single Button Connect Dialog Box



Single button connect is a global and wholly automatic function, and is not included as a terminal account parameter. This function will:

1. Log you into your terminal using the account that has autologin associated with it.
2. Make the first connection listed in the **Connection Name** list in the **Modify User Account** dialog box (unless another connection in the list has been made with Autostart).

To enable this function:

1. Press **F2** to invoke the **Terminal Properties** dialog box.
2. Click on the **Security** tab to invoke the **Security** properties sheet.
3. Highlight the user's name in **User Accounts**.
4. Click on the **Autologin Enable** check box to enable the function.
5. Click on the **Single Button Connect** check box to enable the function.
6. Click on **OK**.
7. Click on the **Shutdown** command button in the **Winterm Connection Manager**.
8. Click on the **Logout** radio button to log out of the terminal.

The **Single Button Connect** dialog box appears.

Click on **Connect** to log into the terminal again. If the connection fails, the **Winterm Connection Manager** displays.

41 Failover

Failover is a connection feature that is enabled using the **Security** properties sheet. It forces the terminal to “ping” the intended device before making a connection to it. The function operates when **Failover Enable** is enabled on the **Security** properties sheet. Failover is global and wholly automatic to the terminal. It will work regardless of what connection you are trying to make, or what type of account you are logged in using. See “Security Properties” for more information about this function and how to invoke the properties sheet.



Note


Ping (Packet Internet Groper) is a network utility. It tests communication with nodes in a network by sending a packet to each selected node. Ping then waits to receive the echo response from that selected node.

Failover operates as follows:

1. The terminal pings the intended connection, to determine whether or not it is available.
2. If pinging the intended device fails, the terminal pings each successive connection in the list.
3. For each connection:
 - a. If ping is successful, the connection is made.
 - b. If ping is not successful, the terminal pings the next connection.
 - c. If the next connection is a serial connection, ping will stop. Ping will not work on a serial connection. Failover will not continue after encountering a serial connection, but will launch the serial connection if it is valid.


If failover pings all the connections in the list and a connection is not made, the function stops. The following figure displays.

Figure 41-1 Failover Message Box



Once failover is finished, the **Failover Log Window** dialog box displays. Figure 41-2 shows this dialog box.

Figure 41-2 Failover Log Window Dialog Box



The **Failover Log Window** is a list of all the connections that were pinged. The list reports both successful and unsuccessful pings.



Getting Help

- 42 Troubleshooting Your Terminal**
- 43 Terminal Port Pin Assignments**
- 44 Terminal Connector Pin Assignments**
- 45 Null Modem Cable Pin Assignments**
- 46 Modem AT Commands**

42 Troubleshooting Your Terminal

This troubleshooting guide provides solutions to problems that may occur when making a terminal connection to a server. If you can not resolve an issue, call an authorized service center for assistance.

Table 42-1 lists some common problems and the solutions to those problems.

Table 42-1 Troubleshooting Your Terminal

Problem	Solution
When the terminal is powered-up, nothing happens.	Check the power cord. It should be plugged into an AC outlet and pushed all the way into the AC power connector on the terminal's back panel or power supply.
When the terminal is powered-up, the screen remains black. The power-on indicator light is orange.	Set the terminal to factory defaults. Factory defaults can be obtained by turning the terminal off, then on, while holding down the G key. When you see the terminal's splash screen, release the G key. The terminal's factory defaults are now restored.
When the terminal is turned on, the Winterm Connection Manager or the WBT Setup Wizard appears, but the mouse does not function.	Ensure that the mouse is plugged into the PS/2 mouse port on the terminal's back panel.  Note See the installation section of this guide for the location of the PS/2 connector.
During the terminal's Power-On Self-Test, a message is displayed: The terminal cannot detect a keyboard. The keyboard is bad, missing, or not connected properly.	Ensure that a PS/2 keyboard with a PS/2 connector is firmly connected to the keyboard connector on the terminal's back panel.

Table 42-1 Troubleshooting Your Terminal, Continued

Problem	Solution
With a serial connection already established, the mouse cursor moves, but the keyboard input and mouse clicks do not work, and all the applications are frozen.	The serial connection to the server is broken. Turn the terminal off, then on. Log into the applications server again. If your terminal sustained a disconnect time-out, the original desktop prior to the disconnect will be reestablished (if the connection was defined to do so). If you can not log in to the terminal again: 1. Verify that all cables between the terminal and the applications server are connected. 2. Check to see if any modem connections between the terminal and server open. 3. Ensure that the applications server's port that your session is connected to is working. 4. Make sure you are using a shielded cable that meets RS-232 standards, and that you are operating within RS-232 standards.
The parallel printer connected to my terminal does not respond when I try to print to it.	1. Make sure that the printer is plugged into the proper outlet and turned on. 2. Check the cable connection to the printer and to the terminal. 3. Make sure that the printer is on line. 4. Make sure that the printer is properly configured in the application server's Print Manager, and that the printer has not been paused.  Note See "Terminal Port Pin Assignments" for parallel cable pin assignments.

Table 42-1 Troubleshooting Your Terminal, Continued

Problem	Solution
The serial printer connected to the terminal will not print.	1. Ensure that the power to the printer is turned on. 2. Check the cable from the terminal to the printer for proper connection. 3. Ensure that the printer is on line. 4. Ensure that both the terminal's and the printer's serial ports are identically configured. Both must use the same handshaking protocol.  Note See the printer's user's guide for information about printing from a serial connection. 5. Ensure that the printer is configured properly in the applications server's print manager, and that the printer has not been paused.  Note Refer to "Terminal Port Pin Assignments" for serial communications pin assignments. Pin assignments must be compatible with those on your printer's serial port.

Table 42-1 Troubleshooting Your Terminal, Continued

Problem	Solution
You are not able to make a network connection using the Winterm Connections Manager .	1. Press F2 to invoke the Terminal Properties dialog box. 2. Select the Network tab. 3. Verify that the proper method for specifying the IP address is selected, DHCP or static IP. If a static IP address is selected, verify that the IP address, the subnet mask, and the gateway IP address are correct for the subnet that the terminal is connected to. 4. Verify that a cable is connected to the network connector on the back panel of the terminal. 5. Check the other end of the cable to ensure that it is connected to a hub or other network outlet. If DHCP addressing is selected, check with your network administrator to ensure that the DHCP server for your subnet is functioning properly.

If any other error messages are displayed, or you have any other problems, you should restore the terminal to its default settings and reconfigure it. Factory defaults can be restored by disconnecting the power to the terminal, then reconnecting it while holding down the **G** key. Release the **G** key when the splash screen appears (for the 3320SE and 3720SE, also press and release the power management button, then release the **G** key). The terminal's defaults will be restored.

43 Terminal Port Pin Assignments

Serial and Parallel Ports

The following two figures show the pin assignments for the serial and parallel ports. These ports are located on the back panel of your terminal. See “Terminal Features” for information about the back panel.

Figure 43-1 Serial Port





Figure 43-2 Parallel Port (EPP/SPP)



 **Note**
The parallel pin assignments are Centronics-compatible.

44 Terminal Connector Pin Assignments

10Base-T and 100Base-T Connector


The following figure shows the pin assignments for the 10Base-T and 100Base-T connector. This connector is located on the back panel of your terminal. See “Terminal Features” for information about the back panel.



Note

It is recommended that you use Category 5 twisted-pair cable to connect your terminal to a hub.


Figure 44-1 10Base-T and 100Base-T Connector



VGA Connector

The following figure lists the connector pin assignments for the terminal's VGA connector. This connector is located on the back panel of your terminal. See “Terminal Features” for information about the back panel.


Figure 44-2 VGA Connector



USB Connector

The following figure lists the connector pin assignments for the terminal's USB connectors. These connectors are located on the back panel of your terminal. See "Terminal Features" for information about the back panel.

Figure 44-3 USB Connector



45

Null Modem Cable Pin Assignments

Table 45-1 outlines the pin assignments for a 9-pin serial port to a 25-pin serial port null modem cable.

Table 45-1 Null Modem Cable Pin Assignments

25 Pin	9 Pin
2 (transmit data)	2 (receive data)
3 (receive data)	3 (transmit data)
4 (request to send)	8 (clear to send)
5 (clear to send)	7 (request to send)
6, 8 (data set ready, carrier detect)	4 (data terminal ready)
7 (ground)	5 (ground)
20 (data terminal ready)	6, 1 (data set ready, carrier detect)

46 Modem AT Commands

The tables of this section list the modem AT command sets.

Table 46-1 AT Commands with No Lead-in Character

Command	Description
B, B0	ITU-T (CCITT) V.22 mode when at 1200 bps; V.21 at 300 bps
E1	Enable character echo to terminal in command mode
H, H0	Go on-hook (hang up)
N1	Connection speed set to highest possible DCE rate, Automode
Q, Q0	Modem returns result codes (Quiet disabled)
T	Tone dialing
V1	Full-word result codes (Verbose enabled)
W2	Negotiation progress codes disabled. Result code is DCE rate.
X4	Modem recognizes dialtone and busy, CONNECT nnnn result code enabled.
Y, Y0	Disable long-space disconnect
Z, Z0	Reset modem and recall User Profile 0

Table 46-2 AT Commands Beginning with “&”

Command	Description
&B1	Disable port rate adjust
&C1	Carrier detect follows data carrier
&D2	Hang up and go to command mode during On-to-Off DTR transition
&F, &F0	Recall factory settings as active configuration
&M0	Asynchronous mode
&N, &N0	Microcom QX/4232hs-compatible numeric result codes displayed
&Q5	Error Correction Mode V.42=> MNP=> Async
&T4	Grant request from remote for remote digital loopback test
&U1	Data compression enabled
&V	View active configuration, profiles (0,1), and numbers
&W, &W0	Save active configuration as User Profile 0
&Y, &Y0	Recall User Profile 0 on power-up

Table 46-3 AT Commands Beginning with “\”

Command	Description
\A3	Maximum MNP block size = 256 characters
\G, \G0	Disable port flow control DCE to DCE
\J, \J0	Disable port rate adjust
\L, \L0	MNP stream link
\N7	Set Auto-reliable mode (LAPM with fallback to MNP, then to normal)
\Q3	Bidirectional hardware flow control
\S	Display current Configuration, Long Version
\V, \V0	Disable /REL connect codes
\X, \X0	XON/XOFF pass-through disabled

Table 46-4 AT Commands Beginning with “%”

Command	Description
%C1	Data compression requested (V.42bis in LAPM, MNP5 in MNP)
%E, %E0	Disable Auto-retrain
%L	Report Line Signal Level in -dBm
%Q	Report Line Signal Quality
%R	Display all S registers
%V	Display firmware version

Glossary

The following glossary is a list of commonly used terms in this guide.

Term	Definition
10Base-T	One of several adaptations of the Ethernet (IEEE 802.3) standard for Local Area Networks (LANs). The 10Base-T standard (also called Twisted Pair Ethernet) uses a twisted-pair cable with a maximum length of 100 meters. The cable is thinner and more flexible than the coaxial cable used for the 10Base-2 or 10Base-5 standards.
100Base-T	A networking standard that supports data transfer rates up to 100 Mbps (100 megabits per second). 100Base-T is based on the older Ethernet standard. Because it is 10 times faster than Ethernet, it is often referred to as Fast Ethernet. Officially, the 100Base-T standard is IEEE 802.3u. Like Ethernet, 100Base-T is based on the CSMA/CD LAN access method. There are several different cabling schemes that can be used with 100Base-T, including: • 100Base-TX: two pairs of high-quality twisted-pair wires • 100Base-T4: four pairs of normal-quality twisted-pair wires • 100Base-FX: fiber optic cables
Bootstrap	A technique designed to cause a circuit, stage, or operation to bring itself into a desired state by means of its own action. Used as a machine routine, the bootstrap technique involves loading the first few instructions into storage; these instructions are then used to bring in the rest of the routine--usually by entering a few manual instructions or by using a special keystroke combination.
CHAP	Challenge-Handshake Authentication Protocol. An authentication scheme used by PPP servers to validate the identity of the originator of the connection upon connection or any time later.
CRT	Cathode-Ray Tube. A large vacuum tube with a viewing face in which an electron beam is focused and controlled to form characters and other images.

CTS	Clear to Send. Control signal sent from the DCE. Indicates that the DTE may send data.
DCE	Data Communications Equipment. Devices that provide the functions required to establish, maintain, and terminate a data transmission connection, e.g., a modem.
DHCP	Dynamic Host Configuration Protocol. A protocol for assigning dynamic IP addresses to devices on a network.
DNS	Domain Name Service. A general-purpose distributed, replicated, data query service chiefly used on the Internet for translating host names into Internet addresses.
Download	To transfer data from a processing unit to an attached device. For example, from a host to the terminal.
DSR	Data Set Ready. A hardware signal sent by a communications device to indicate readiness to send and receive data.
DTE	Data Terminal Equipment. A device that acts as the source and/or destination of data and which controls the communication channel. DTE includes terminals, computers, protocol converters, and multiplexors. DTE is usually connected via an RS-232 serial line to Data Communication Equipment (DCE), typically a modem. It is necessary to distinguish these two types of devices because their connectors must be wired differently if a straight-through cable (pin 1 to pin 1, pin 2 to pin 2 etc.) is to be used. DTE should have a male connector and should transmit on pin three and receive on pin two. It is a curious fact that many modems are actually DTE according to the original standard.
DTR	Data Terminal Ready. A hardware signal sent by a terminal to indicate readiness to send and receive data.
Ethernet	A baseband local area network specification developed jointly by Digital Equipment Corp., Xerox, and Intel to interconnect computer equipment using coaxial cable and transceivers. An Ethernet LAN provides ten million bits per second of capacity for high-speed terminal-to-computer communication or computer-to-computer file transfer.
FCC	Federal Communications Commission. The Government body that regulates all telecommunications originating in the U.S., including transmission over telephone lines.
Firmware	A computer program or software stored permanently in a PROM or ROM or semi-permanently in an EPROM.

Flow control	The procedure for regulating the flow of data between two devices, flow control prevents the loss of data when one device's receiving buffer has reached its capacity.
FTP	File Transfer Protocol. FTP is a program for transferring files in TCP/IP environments such as the Internet in which a user, acting as a client, downloads files from a remote server. FTP is a core component in every TCP/IP system and is implemented at the Applications layer with respect to the OSI protocol model. Its operation is based on the Telnet program and TCP. FTP is available on a wide variety of computer systems and serves as a common protocol for transferring files between systems.
GUI	Graphical User Interface (pronounced "gooeey"). The use of pictures rather than just words to represent the input and output of a program. A program with a GUI runs under some windowing system (e.g. Microsoft Windows®). The program displays certain icons, buttons, and dialog boxes in its windows on the screen. The user mainly controls these objects by moving a pointer on the screen (typically controlled by a mouse) and selecting certain objects by pressing buttons on the mouse while the pointer is pointing at them.
Hz	Hertz. A unit of frequency equal to 1 cycle per second.
ICA	Independent Computing Architecture. A three-part server-based computing technology that separates an application's logic from its user interface and allows 100% application execution on the server.
Integrated CRT terminal	A terminal with a monitor and connections on the back for a keyboard and mouse.
Interface	A shared boundary defined by common physical interconnection characteristics, signal characteristics, and meaning of interchanged signals.
Internet	The Internet is a global web of interconnected computers and computer networks that are interconnected under a common set of network protocols that allows them to function as a single large network (see TCP/IP).
IP address	Internet Protocol Address. The 32-bit, 4-byte address assigned to machines using the Internet with TCP/IP. It is usually represented in dotted decimal notation. Provides interconnectivity among a variety of independent host systems.

ISDN	Integrated Services Digital Network. Evolving switched network standard that provides end-to-end digital voice and data communication services.
kb or kilobit	1,024 bits. Commonly referred to as 1 thousand bits.
kB or kilobyte	1,024 bytes. Commonly referred to as 1 thousand bytes.
kbps or kb/s	Kilobits per second. An abbreviation meaning thousands of bits per second.
Load Balancing Services	A management add-on to Citrix WinFrame and MetaFrame servers that allows administrators to group multiple WinFrame and/or MetaFrame servers into scalable “server farms” to deliver the best application performance and server resource utilization.
Mb or megabit	1,048,576 bits. Commonly referred to as 1 million bits.
Mbps or Mb/s	Megabits per second.
MetaFrame	The world’s first Server-based Computing software for Microsoft Windows NT 4.0 Server, Terminal Server Edition multi-user software (co-developed by Citrix).
MIB	Management Information Base. A database of managed objects accessed by network management protocols.
Modem	(Mo)dulator/(dem)odulator. Data communication equipment (DCE) devices that provide connections for computers into the public switched telephone network (PSTN). They convert (modulate) the digital signals of computers into analog signals that can be transmitted over telephone lines. A modem at the other end of the link then demodulates the signals back to digital bits.
Modular terminal	Desktop client that works with existing standard monitors.
Network	An interconnected group of nodes; a series of points, nodes, or stations connected by communications channels; the assembly of equipment through which connections are made between data stations.

Null modem	A cable, especially an RS-232 cable, for connecting serial ports on two computers directly, rather than via modems. Since, according to the specification, both computers should transmit on pin three of their RS-232 connectors and receive on pin two, a null modem cable needs to connect one computer's pin two to the other's pin three and vice versa. It also needs to have male connectors at both ends (again, according to the specification).
OSD	On Screen Display.
Packet	A group of bits (including data and call control signals) transmitted as an identifiable unit on a packet-switched network (PSN).
PAP	Password Authentication Protocol. An authentication scheme used by PPP servers to validate the identity of the originator of the connection. PAP applies a two-way handshaking procedure. After the link is established the originator sends an id-password pair to the server. If authentication succeeds the server sends back an acknowledgment; otherwise it either terminates the connection or gives the originator another chance.
Parallel port	An input/output port that allows the entire bit pattern for a single character to be sent at one time, usually used to connect a printer to a computer.
Parity check	The addition of non-information bits (specifically, parity bits) to make up a transmission block (a number of bits transmitted as unit) that ensures the total number of ones is always either even (even parity) or odd (odd parity). The parity check is used to detect transmission errors.
PCMCIA	Personal Computer Miniature Connector Interface Adapter. Hardware and software standards for credit-card-sized integrated circuit cards.
Ping	Packet InterNet Groper. A protocol used in the Transmission Control Protocol (TCP) environment to test whether a node or remote device is communicating on a local area network (LAN) or wide area network (WAN). The protocol provides for transporting an echo response from a host system, a client, or a gateway. It is a useful tool for locating problems on the network related to failed connections and software problems. One datagram is sent every second over the network and any response is displayed.

PPP	Point-to-Point Protocol. A serial communication protocol that operates over dialup or leased (dedicated) lines to provide connections into IP networks. It sets up and monitors router sessions and frames the data transmitted over the line.
Protocol	A set of formal rules describing how to transmit data, especially across a network. Low-level protocols define the electrical and physical standards to be observed, bit- and byte-ordering, and the transmission and error detection and correction of the bit stream. High level protocols deal with the data formatting, including the syntax of messages, the terminal to computer dialogue, character sets, sequencing of messages, etc.
RAM	Random-Access Memory. A mass store that provides fast access to any storage location by means of vertical and horizontal coordinates. Information is written in or read out using the same procedure. The memory cycle time is the same for any location addressed because there is no waiting or sorting time required, as there is when data items are stored sequentially.
RAS	Remote Access Services. A service provided by Windows NT that allows most of the services which would be available on a network to be accessed over a modem link. The service includes support for dialup and logon, and then presents the same network interface as the normal network drivers (albeit slightly slower). It is not necessary to run Windows NT on the client - there are client versions for other Windows operating systems.
RDP	Remote Desktop Protocol. A computing technology that separates an application's logic from its user interface and allows 100% application execution on the server.
RS-232 cable	A cable for serial interfaces between the terminal and communications devices, such as a modem. The cable connects to the 25-pin serial port at the back of the terminal. Maximum cable length is 50 feet; maximum signaling rate is 20 Kbits/sec.
RTS/CTS flow control	Request to Send/Clear to Send flow control. Enables flow control on the local serial line. RTS is pin 4 of the 25-pin RS232/423 connector. CTS is pin 5 of the connector. RTS is an output of the terminal; CTS is an input to the terminal.

Serial port	A connector on a computer to which you can attach a serial line connected to peripherals that communicate using a serial (bit-stream) protocol. The most common type of serial port is a 25-pin D-type connector carrying RS-232 signals. Smaller connectors (e.g. 9-pin D-type) carrying a subset of RS-232 are often used on personal computers.
Server	The control computer on a local area network that controls software access to workstations, printers, and other parts of the network. Under Citrix's server-based computing model, the server performs all application execution functions.
SNMP	Simple Network Management Protocol. The industry standard protocol for managing TCP/IP networks. This protocol queries agents in managed devices and passes information to the management console.
Start bit	In asynchronous transmission, the first bit of any given character used to alert the receiving system to recognize the related incoming data.
Stop bit	In asynchronous transmission, the last bit of any given character, used to alert the receiving system that transmission of the character is complete.
SVGA	Super Video Graphics Adapter. A DRAM-based VGA adapter that supports both monochrome and color high-resolution graphics and provides extended resolutions of usually 1024 x 768.
TCP/IP	Transmission Control Protocol/Internet Protocol. The de facto standard Ethernet protocols incorporated into 4.2BSD UNIX. TCP/IP was developed by DARPA for Internet working and encompasses both network layer and transport layer protocols (in the OSI model). While TCP and IP specify two protocols at specific protocol layers, TCP/IP is often used to refer to the entire DOD protocol suite based upon these, including Telnet, FTP, UDP and RDP.
Telnet	Telnet is the login and terminal emulation program for Transmission Control Protocol/Internet Protocol (TCP/IP) networks such as the Internet. Its primary function is to allow users to log into remote host systems.
Terminal	A data terminal equipment DTE device. An input/output device made up minimally of a video display, keyboard, and sometimes a central processing unit, connected to a modem, for data communications.

Terminal emulator	A program that allows a computer to act like a particular brand or type of terminal. The computer thus appears as a terminal to the host computer and accepts the same escape sequences for functions such as cursor positioning and clearing the screen.
Thin-client	A low-cost computing device that works in a server-centric computing model. Thin clients typically do not require state-of-the-art, powerful processors and large amounts of RAM and ROM because they access applications from a central server or network. Thin clients can operate in a Server-based Computing environment.
Timeout	A time interval within which certain operations must occur; for example, the time allotment for the terminal to connect to a login host. After the timeout, the process can either be repeated or discontinued.
Total Cost of Ownership (TCO)	A model that helps IT professionals understand and manage the budgeted (direct) and unbudgeted (indirect) costs incurred for acquiring, maintaining and using an application or a computing system. TCO normally includes training, upgrades, and administration as well as the purchase price. Lowering TCO through single-point control is a key benefit of Server-based Computing.
Touch screen	A type of display screen that has a touch-sensitive transparent panel that can sense when someone is touching it, and is able to furnish a computer with precise information as to exactly where on the screen the touch occurred. Touch screens are used with software that uses the information provided by the screen touch to respond to user requests.
USB	Universal Serial Bus. An external peripheral interface standard for communication between computer and external peripherals over an inexpensive cable using biserial transmission. USB is standard on current (1999) Macintosh computers and is promoted by Intel as an option for the IBM PC where it is supported by later versions of Windows 95. USB works at 12 Mbps with specific consideration for low-cost peripherals. It supports up to 127 devices and both isochronous and asynchronous data transfers. USB cables can be up to 5 meters long and include built-in power distribution for low-power devices. It supports daisy chaining through a tiered star multidrop topology.

Virtual Port	Incoming Telnet and rlogin connections are not associated with a physical port. Instead, they are associated with a virtual port, port 0, which serves for the duration of the connection. Each virtual port is created with a default set of characteristics. The Define Port commands can be used to customize a virtual port during the Telnet/Rlogin session; however, these customizations can not be saved. The port reverts to the default set of characteristics when the session is closed.
WAN	Wide Area Network. A data-communications system covering a large geographic area, usually digital circuits having moderate to high data rates (e.g., 56 to 64 kbps up to 1.5 to 2 Mbps).
Windows Terminal Server	A network device that is attached to non-network serial devices, such as terminals, printers and modems, or to an Ethernet network.
Windows-based Terminal	A fixed-function thin-client device that connects to a Citrix WinFrame or MetaFrame server and Terminal Server to provide application access. The key differentiator of a WBT from other thin devices is that all application execution occurs on the server; there is no downloading or local processing of applications at the client.
WinFrame	A multi-user Windows application server, based on Windows NT, developed under license from Microsoft.
WINS	Windows Internet Naming Service. WINS allows machines to dynamically register their name-to-address mappings. WINS is also a flat name space without the concept of hierarchy and requires each WINS server to maintain a complete database of entries through replication.
Winterm	Trademarked logo for Windows-based terminals manufactured by Wyse Technology Inc.
X-ON/X-OFF	Transmitter On/Transmitter Off. Control characters used for flow control, instructing serial devices to start transmission (X-ON) and stop transmission (X-OFF).

Index

Numerics

- 100Base-T 15
- 10Base-T 15, 47
- 3315SE/3320SE/3350SE specifications 17
- 3515SE/3715SE/3720SE specifications 21

B

- Battery, 3350SE 20, 24

C

- Card bus
 - 3350SE 39
- Category 5 twisted pair 211
- Centronics-compatible 210
- Com1
 - 3315SE 29
 - 3320SE 29
 - 3350SE 38
 - 3515SE 46
 - 3715SE 46
 - 3720SE 46
- Com2
 - 3315SE 29
 - 3320SE 29
 - 3350SE 39
 - 3515SE 46
 - 3715SE 46
 - 3720SE 46
- Command buttons
 - Add User 184, 186, 188
 - Add/Change Modem 151
 - Advanced (login options) 133
 - Change DHCP Option 97, 178
 - Configure 114, 134
 - Default (Server) List 92
 - Delete User 184, 186, 194
 - Dialing Properties 114
 - Edit (connection parameters) 142

- Finish 70, 100
- ICA Client Settings 89, 96
- ISDN Settings 149
- Modify User 93, 184, 186, 192
- Restart (terminal) 100
- Security 114, 125
- Shutdown (terminal) 197
- SNMP Network 97
- SNMP Network Administration 168
- Startup (connection) 104
- TCP/IP Settings 114, 123
- Upgrade 163, 178

Connection protocols

- Citrix ICA Client 104
- Dial-Up Client 104
- Microsoft Remote Desktop Client 104
- Terminal Emulation 104

Control keys

- Alt+Backtab 88
- Alt+Esc 88
- Alt+Tab 88
- Ctrl+Alt+Del 88
- Ctrl+Alt+Down Arrow 94
- Ctrl+Alt+End 94
- Ctrl+Alt+Up Arrow 94
- Ctrl+Esc 88
- F2 12

D

- DHCP 208
- Dialog boxes
 - About (the terminal) 157
 - Add or Change Modem 151
 - Add Server Address 109
 - Add User Account 187
 - Automate Login Process 134
 - Change DHCP Option IDs 173
 - Change Option IDs 178
 - Compression, Cache, and Sound 111
 - Connection Information 132
 - Connection Startup 104
 - Desktop Area and Refresh Frequency 69
 - Device Properties 117
 - Dialing Properties 117

- Download Utility 156
- Failover Log Window 202
- Firmware Upgrade 157
- Global ICA Settings 87
- Host Information 133
- ISDN Settings 149
- Modify User Account 191
- New Connection 103
- Port Settings 120
- Printer Port Settings 135
- Properties (connections) 141
- Security Settings 125
- Select a Server or Published Application 108
- Select a Title for the ICA Connection 112
- Select Window Options 111
- Server Location 108
- Shutdown Window 99
- SNMP Network Administration 167
- Specify an Application 110
- Specify Connection Type 107
- Specify Logon Information 110
- TCP/IP Settings 123
- TCP/IP Telnet Configuration 136
- Terminal Login 100, 197
- Terminal Properties 12
- Terminal Settings Change 70, 72, 100
- Winterm Connection Manager 13

DOS functions

- check 155
- dir 156
- xfer.exe 155

E

- Enhanced modular terminal 9
 - specifications 17

F

- Ferrite bead 59
- Firmware download
 - cable method 155
 - parallel download 155

Functions

- Accept Any Authentication Including Clear Text 125
- Accept Only Encrypted Authentication 125
- Accept Only Microsoft Encrypted Authentication 125
- Add (command button) 86, 91
- Add/Change Modem 148
- Allow Automatic Client Update 90
- Application to Run 145
- Assign (connection) 189, 193
- AutoLogin Enable 183
- Autologin Enable 93, 200
- Automatic Logon 143
- Available Connections 189
- Call Options 120
- Call Setup 121
- Character Repeat 77
- Client (ICA) 90
- Close Remote Application 88
- Common Option IDs 174
- Community 168
- Connect 84
- Connection 143
- Connection Name 84, 190
- Connection Preferences 120
- Connection Speed 143
- Default Windows Colors 90
- Delete 86
- Delete (connection) 91
- Desktop Area and Refresh Frequency 74
- DHCP Automatic Update Enable 177
- DHCP Connection Enable 183
- Dial-In Connection 107
- Dialing Patterns 119
- Edit (connection) 86
- Enable DNS 80
- Enable Energy Savers 74
- Enable Password Change 186, 188, 192
- Enable WINS 80
- Extra Settings 121
- Failover Enable 182–183, 201
- Flow Settings 152
- FTP Option IDs 174

- Get (field) 168
- Hide Configure Tab 182
- Init Commands 152
- ISDN Settings 148
- Keyboard 76
- Local Settings 118
- Logoff 100
- Logout 200
- Manual Dial 120
- Modem Name 152
- Move Down 91
- Move Up 91
- Multiple Autoconnect 190, 194
- Multiple AutoStart 93
- Multiple Connect 182
- Network Connection 107
- Obtain an Address from a DHCP Server 80
- Obtain an IP Address From DHCP Server 177
- Parameters 134
- Ping Before Connect 182
- Port Settings 120
- Pulse Dialing 118
- RDP Option IDs 174
- Repeat Delay 77
- Repeat Rate 77
- Reset To Defaults 175
- Security Enable 182
- Set (field) 168
- Shutdown 84
- Shutdown and Restart 100
- Shutdown the Terminal 100
- Single Button Connect 183
- SNMP Communication 168
- SNMP Option IDs 175
- SNMP Update Enable 96
- Startup 86
- Startup Options 105
- Status Dialog 88
- Terminal Emulation Option IDs 175
- Toggle AutoConn 189, 193
- Toggle Title Bar 88

- Tone Dialing 118
- Unassign (connection) 189, 193
- Use Assigned IP Address 124
- Use Default Gateway on Remote Network 124
- Use FTP InformationFrom DHCP Server 162
- Use IP Header Compression 124
- Use Local FTP Information 162
- Use Server-Assigned Addresses 124
- Use SLIP 124
- Use Software Compression 124
- User Accounts 184
- User Name 197
- Verbose (connection) 183
- Virtual Port Option IDs 175

G

- G key reset 63, 205

H

- Headphone jack
 - 3315SE 29
 - 3320SE 29
 - 3350SE 39
 - 3515SE 47
 - 3715SE 47
 - 3720SE 47

I

- ICA 7, 15, 174
- Image file 172
- Independant Computing Architecture 7
- Integrated-CRT model numbers
 - 3515SE 7
 - 3715SE 7
 - 3720SE 7
- Integrated-CRT terminals 7
 - specifications 21
- ISDN settings 147

K

Keyboard connector

3315SE 29
3320SE 29
3350SE 39
3515SE 47
3715SE 47
3720SE 47

L

Logging off the terminal 100

M

Management Information Base 171

MIB 171

Microphone jack

3315SE 29
3320SE 29
3350SE 39
3515SE 47
3715SE 47
3720SE 47

Modem card 53

Modem card kit 53

Modular model numbers

3315SE 7
3320SE 7
3350SE 7

Modular terminal 7

specifications 17

Mouse connector

3315SE 29
3320SE 29
3350SE 39
3515SE 47
3715SE 47
3720SE 47

N

Network connector

3315SE 29
3320SE 29
3350SE 38
3515SE 46
3715SE 46
3720SE 46

Noise suppressor 59

Null modem cable 215

O

Option slot

3315SE 29
3320SE 29
3515SE 47
3715SE 47
3720SE 47

P

Parallel port

3315SE 29
3320SE 29
3350SE 39
3515SE 47
3715SE 47
3720SE 47

Params.ini 172

PCMCIA 16, 53

Pin assignments

10Base-T and 100Base-T
connectors 211
null modem cable 215
serial and parallel ports 209
USB connectors 213
VGA connector 212

Power connector

3315SE 29
3320SE 29
3350SE 39
3515SE 47
3715SE 47
3720SE 47

PPP 54, 113

Properties sheets

- About 72
- About (the terminal) 11
- Application 144
- Apps 72, 87, 95, 168
- Call Options 121
- Configure 83, 103–104, 142
- Connections 83
- Default Hotkeys 87
- Devices 72, 147
- Display 72–73
- General 11, 72
- Input 72, 75
- Net Connections 142
- Network 72, 79
- Preferences 89
- Security 72, 181, 194, 200–201
- Server Location 91
- SysInfo 11, 72
- Upgrade 72, 161, 163

PS/2 connector 205

R

RDP 7, 15, 174

RDP encryption 95

Remote Desktop Protocol 7

RS-232 206

S

Shutting down and restarting the terminal 100

Shutting down the terminal 100

T

Telnet 131

Terminal accounts

- Administrator 93, 186, 190, 194–195
- Guest 185, 190, 194
- User 186, 190, 194

U

USB

- 3350SE 39

V

Video connector

- 3315SE 29
- 3320SE 29
- 3350SE 39

Virtual port 95

VT (DEC) 131

W

WBT 3, 7

WBT model numbers

- 3315SE 3
- 3320SE 3
- 3350SE 3
- 3515SE 3
- 3715SE 3
- 3720SE 3

Windows 3.1 15

Windows 95 15

Windows NT 7, 15

Windows Terminal Server 15

Windows-based terminal 7

Wizards

- Dial-Up Configuration 113, 117, 123
- Setup 36, 44, 48, 63, 100, 157, 178
- TE Client Connection 131
- WBT Setup 205
- WTS Connection 127

Winterm 3000 Series Windows[®]-based Terminal Reference Guide

Written and published by Wyse Technology Technical Publications
Wyse Technology Inc., August 1999

Created using FrameMaker[®], Acrobat[®], and Magellan[™]

The on-line book is provided in both PDF and HTML versions, presented on both
CD-ROM and a website