



**Product
Information
Sheet**



Easyprox™ Proximity Reader

Connections:

Terminal	Wire Color	Connection
1	Yellow	Wiegand Data "0"
2	Green	Wiegand Data "1"
3	Brown	LED Control from Panel
4	Black	- VDC (4.75-18 VDC range)
5	Red	+VDC (4.75-18 VDC range)
6	Blank	NOT USED
7	Blue	FACTORY USE ONLY

Outputs Wiegand

**26 Bit Data 0 Terminal 1
Data 1 Terminal 2**

LED

**Power up (LED flashes Red), Power on (LED Solid Red),
Tag Read indication (LED Out), LED Control from panel
(LED flashes green)**

Beeper

Tag Read indication and LED Control from panel

Mounting

#10 self tapping screws

Power is applied as shown above to power the unit. Hold one of the cards over the antenna area. The read range is @ 2". When the tag is read the red LED will go out and Wiegand data is transmitted to the control panel. When the LED Control line from the panel is detected the green LED will flash and the beeper will give audible indication for 1 second. After audible indication, the red LED will go back to solid red and another card can be read by the reader.

Call, fax or e-mail TELSOR with questions, comments, recommendations or concerns regarding the Easyprox mullion mount reader.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not in-stalled and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:—Reorient or relocate the receiving antenna.—Increase the separation between the equipment and receiver.—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.

**P.O. Box 4423 Englewood, Colorado USA 80155-4423
Telephone: 303.522.8877 Facsimile: 303.727.7683
E-Mail proximity@telsor.com**

**ALL INFORMATION IS SUBJECT TO CHANGE WITHOUT NOTICE
© 1999, TELSOR CORPORATION**