NCM1120D2

5G ODU User Manual





Table of Contents



1. In the Box

- 1.1 Device and Accessories
- 1.2 Device View

2. Getting Started - Setup

- 2.1 LED Indicators
- 2.2 Ethernet Cable
- 2.3 Connect Your Device

3. Using the System

- 3.1 Web UI Login
- 3.2 Dashboard
- 3.3 Check Network Map
- 3.4 Check Network Status
- 3.5 Manage 4G/5G settings
- 3.6 Manage LAN settings
- 3.7 Manage Wi-Fi settings
- 3.8 Security Control
- 3.9 Security
- 3.10 Diagnostic
- 3.11 System Settings
- 3.12 Firmware Update
- 3.13 NAT Forwarding




1.1 Device and Accessories





ODU Device




PSU Power Adapter



1.2 Device View















2.1 LED Indicators



LED	State	Indication	Note
5G	Strong	Green, Solid	BRSRP>=-80dBm
	Normal	Blue, Solid	-80dBm>BRSRP>=-95dBm
	Weak	Red, Solid	BRSRP<-95dBm
	No 5G Connected	off	
4G	Strong	Green, Solid	RSRP>=-80dBm
	Normal	Blue, Solid	-80dBm>RSRP>=-95dBm
	Weak	Red, Solid	RSRP<-95dBm
	No 4G Connected but SIM is ready	off	
	SIM Error	Red, Blink	
	Wi-Fi Turn Off	off	
	Wi-Fi Turn On	Green, Solid	
Wi-Fi	Wi-Fi Error	Red, Solid	
	WPS Query	Blue, Blink	Press "WPS button" equal or more than 3 seconds
	WPS Finish	Blue, Solid	Lasts 10 seconds and change to show the 'Wi-Fi turn on/off/error' status
System	System Shutdown	off	
	System Booting	Green, Blink	
	System Reset	Green, Blink	Blinking 5 seconds and light off
	System Error	Red, Solid	
	System Ready	Green, Solid	
	Firmware Upgrading	Blue, Blink	




2.2 Ethernet Cable



• Recommend to use Ethernet cable (RJ45) with CAT-6 or above for better stability of PoE.

Туре	Speed				
	(N	1b/s)	(Gb/s)		
	10	100	1	10	
CAT-5	0	0			
CAT-5e	0	0	0		
CAT-6	0	0	0	0	
CAT-6a	0	0	0	0	




2.3 Connect Your Device



Step1. Plug in AC outlet.

Step2. Connect Ethernet cable from computer to LAN port of IDU. PC should get IP from ODU.






3.1 Web UI Login




- **Step1.** Use a Web Browser to Access the ODU.
- Step2. Open URL http://192.168.1.1 to access login page.
- **Step3.** Enter Username and Password.



3.2 Dashboard




- Step1. Login Web UI
- Step2. When the network status is Connected, it will show OK internet status.
- **Step3.** Check detailed information regarding System Information.




3.3 Check Network Map



- **Step1.** Navigate to Network > **Network Map**
- **Step2.** Check information regarding Mobile-WAN, LAN and Wi-Fi icon.
- **Step3.** Navigate to Network > **Status**
- **Step4.** Check Overview information.










3.4 Check Network Status



Step5. Check detailed information regarding Internet(v4), Internet(v6), Mobile, LAN, Wireless 2.4G, Wireless 5G, Monthly Usage and Weekly Usage.







LAN	
MAC Address	D2:A8:D5:28:B4:38
IP Address	192.168.1.1
Subnet Mask	255.255.255.0
DHCP Server	On
Wireless 2.4G	
Wireless Name(SSID)	NCM1120D2_24G
Wireless Radio	On
Mode	802.11ax/n/g mixed
Channel	Auto
Channel Bandwidth	20 MHz
Wireless 5G	


Monthly Usage		
Upload	NCM1120D2_5G	
Download	On	
Total Traffic	802.11ax/n/g mixed	
Currently Usage		
Query Range	0D 00H 00M 00S	
Upload		
Download		
Total Traffic		



3.5 Manage 4G/5G settings




- **Step1.** Navigate to Network > **Mobile-WAN**
- **Step2.** The SIM status and APN (active and inactive) related settings are here.




3.6.1 Manage LAN settings



- **Step1.** Navigate to Network > **LAN**
- Step2. IPV4(and IPV6)& DHCP related settings are here.







3.6.2 Manage LAN settings



Step3. Check information regarding Client List, and DHCP Lease.







3.7.1 Manage Wi-Fi settings



- **Step1.** Navigate to Network > **Wi-Fi**
- Step2. Band Steering, Wi-Fi network related settings are here.

Note. Enabling Band steering will sync all wifi settings in the frequency list with the 5G band's ones.






3.7.2 Manage Wi-Fi settings



Step3. WPS, Radio related settings are here.


Note. ACL will only take effect when WPS is disabled.




3.8.1 Security Control



- **Step1.** Navigate to Security Control > **Devices**
- **Step2.** Security control, add devices related settings are here.









3.8.2 Security Control



- **Step3.** Navigate to Security Control > **URL Filters**
- **Step4.** URL Filters, add rules related settings are here.







3.9.1 Security



- **Step1.** Navigate to Security > **Firewall IPv4(or IPv6)**
- Step2. Firewall, Ping Request from WAN, and NET Service Filter related settings are here.







3.9.2 Security



- **Step1.** Navigate to Security > **Access Control**
- Step2. Enable Client ACL, Mode and List related settings are here.







3.9.3 Security



- **Step1.** Navigate to Security > **VPN**
- **Step2.** VPN Client List related settings are here.






3.10 Diagnostic




- **Step1.** Navigate to Security > **Diagnostic Tools**
- **Step2.** Diagnostic related settings are here.



3.11.1 System Settings




- **Step1.** Navigate to System Settings > **Admin (Password)**
- **Step2.** Username and new password settings are here.



3.11.2 System Settings



- **Step1.** Navigate to System Settings > **Backup / Restore**
- **Option1.** To save the current settings, click **Save**.
- Option2. To restore settings, Click Select file, then Update.
- Option3. To load default settings, Click Reset, then Click Apply to reboot the ODU.






3.11.3 System Settings



- **Step1.** Navigate to System Settings > **System Log**
- **Step2.** System Logs are here.







3.12.1 Firmware Update



- **Step1.** Navigate to System Settings > **Firmware Update**
- **Step2.** Tap "Download and Update", popup info will shows progress bar. When the bar shows 100%, it'll redirect to login page.






3.12.2 Firmware Update




- Step3. Select Upgrade Manually, Click Select file and open file.
- Step4. Click Update.




3.13.1 NAT Forwarding



- **Step1.** Navigate to NAT Forwarding > **DMZ or UPnP**
- **Step2.** DMZ and UPnP related settings are here.





3.13.2 NAT Forwarding



Port Forwarding Setting


Port Range


Well Known Server List

Services

Step1. Navigate to NAT Forwarding > **ALG or Virtual Servers**

Step2. ALG and Virtual Servers related settings are here.







Manufacturing Experiences.

Since 1989.