



PowerGrid-9171n

Powerline Ethernet Adapter

User Manual





Preface

This manual provides information related to the installation and operation of this device. The individual reading this manual is presumed to have a basic understanding of telecommunications terminology and concepts.

If you find the product to be inoperable or malfunctioning, please contact technical support for immediate service by email at INT-support@comtrend.com

For product update, new product release, manual revision, or software upgrades, please visit our website at <http://www.comtrend.com>

Important Safety Instructions

With reference to unpacking, installation, use, and maintenance of your electronic device, the following basic guidelines are recommended:

- Do not use or install this product near water, to avoid fire or shock hazard. For example, near a bathtub, kitchen sink or laundry tub, or near a swimming pool. Also, do not expose the equipment to rain or damp areas (e.g. a wet basement).
- To safeguard the equipment against overheating, make sure that all openings in the unit that offer exposure to air are not blocked.
- Avoid using a telephone (other than a cordless type) during an electrical storm. There may be a remote risk of electric shock from lightening. Also, do not use the telephone to report a gas leak in the vicinity of the leak.

⚠ WARNING

- Disconnect the Ethernet Adapter from the power source before servicing.

Copyright

Copyright©2015 Comtrend Corporation. All rights reserved. The information contained herein is proprietary to Comtrend Corporation. No part of this document may be translated, transcribed, reproduced, in any form, or by any means without prior written consent of Comtrend Corporation.

This program is free software: you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation, either version 3 of the License, or (at your option) any later version.

This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details.

You should have received a copy of the GNU General Public License along with this program. If not, see <http://www.gnu.org/licenses/>

NOTE: This document is subject to change without notice.



Protect Our Environment



This symbol indicates that when the equipment has reached the end of its useful life, it must be taken to a recycling centre and processed separate from domestic waste.

The cardboard box, the plastic contained in the packaging, and the parts that make up this Ethernet Adapter can be recycled in accordance with regionally established regulations. Never dispose of this electronic equipment along with your household waste; you may be subject to penalties or sanctions under the law. Instead, please be responsible and ask for disposal instructions from your local government.

FCC

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Non-modification Statement:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.



Table of Contents


Chapter 1 Product Information.....	5
1.1 Front Panel and LED indicators.....	5
1.2 Bottom Panel	6
1.3 How to understand the COVERAGE LED colors	7
1.4 Point-to-Point Network.....	8
1.5 Point to Multipoint Network	9
Chapter 2 Log In Procedure	10
2.1 Configure STATIC IP MODE.....	10
2.2 Logging In.....	11
Chapter 3 G.hn Interface	12
3.1 Basic Configuration	13
3.2 NDIM Configuration.....	13
3.3 Encryption Configuration via WEB UI	13
Chapter 4 IP Interface	14
4.1 IP config	15
Chapter 5 Ethernet Interface.....	16
Chapter 6 Device Interface	17
6.1 Hardware information	17
6.2 Software information.....	18
6.3 Security	18
6.4 SW update.....	18
Chapter 7 Multicast Interface.....	19
7.1 MCAST Configuration.....	19
Chapter 8 QoS menu.....	20
8.1 QoS Configuration.....	21
Chapter 9 VLAN Interface	24
9.1 VLAN Configuration	24
Chapter 10 G.hn spectrum Interface	25
10.1 Notches	25
Chapter 11 Log file Interface	26
11.1 Log File	26
Chapter 12 Advanced Interface	27
Chapter 13 Connecting to PG-9171nWireless-N Powerline Adapter by web browser	28
13.1 Windows 7 IP address setup.....	29
13.2 Connecting to Web Management Interface	30
13.3 Quick Setup.....	31
13.3.1 LAN Settings.....	31
13.3.2 Wireless Settings.....	32
13.3.3 Security Settings	33
13.4 Status	34
13.4.1 Device Status	34
13.4.2 System Log	35
13.4.3 Statistics	36
13.5 General Setup	37



13.5.1 Time Zone Setting	37
13.5.2 Password	38
13.5.3 TR-069 Client	39
13.5.4 LAN Settings	41
13.6 Wireless	42
13.6.1 Basic settings	42
13.6.2 Advanced settings	45
13.6.3 Security settings	47
13.6.4 Access Control	50
13.6.5 WPS	51
13.7 Tools	53
13.7.1 Configuration Tools	53
13.7.2 Firmware Upgrade	54
13.7.3 Factory Defaults	55

Chapter 1 Product Information

1.1 Front Panel and LED indicators




WPS Button: Press for 2 – 10 seconds to start the WPS function. Press for over 10 seconds to reset to factory defaults.

Power Button: Push once to power up the PG-9171n
Push once to power down the PG-9171n

LED	COLOR	MODE	Description
 Security	Green	On	Node is secure (it has either received or generated network keys)
		Off	Node is not secure, it has neither received nor generated network key parameters (domain name and encryption key)
		Blink	Node is in configuration mode (able to exchange network keys)
 COVERAGE	Green	On	The current connection (estimated throughput) is greater than 40 Mbps
		On	The current connection (estimated throughput) is greater than 20 Mbps and less than 40 Mbps
	Red	On	The current connection (estimated throughput) is between 1 and 20 Mbps per second
		Off	No PLC connection exists
		Blink	Adapter in power saving mode (blinks twice every 5 seconds)
 WLAN	Green	Off	WLAN is off
		Blink	Wireless is activity (tx/rx data and message)

WPS WPS 🔗	Green	Off	WPS function is disabled or there is no activity
		Blink	There is activity occurring
Ethernet 💻	Green	On	LAN connection established
		Off	LAN connection is not established
		Blink	Data transmitting/receiving
Power ⚡	Green	On	The device is powered up
		Off	The device is powered down

1.2 Bottom Panel



Item Name	Description
Config	<ul style="list-style-type: none"> Press more than 2 seconds ("Security" LED starts slow blinking) and released: the "One Button Security Setup" (OBUS) procedure is started and configuration period is open. Press more than 5 seconds ("Security" LED starts quick blinking) and released: security settings are set to default values. Press more than 10 seconds ("Security" LED switches off) and released: a factory reset is performed.




1.3 How to understand the COVERAGE LED colors

The COVERAGE LED displays quality of the network and provides important information that will provide solutions to common questions, such as why a High Definition (HD) movie is not showing or shows with pixels. The COVERAGE LED indicator will vary its color depending on the estimated speed of the Powerline connection. The speed is measured in Megabits Per Second (Mbps).


Color	Information
RED	The current connection has standard quality, normal Internet activities ex. 20Mbps are possible but the Powerline is unable to transmit either a Standard Movie or High Definition (HD) Movie.
ORANGE	The current connection has good quality and Internet activities ex. greater than 20Mbps and less than 40Mbps to transmit Standard Movie and HD Movie.
GREEN	The current connection has excellent quality and Internet activities ex. greater than 40Mbps to transmit multiple Standard Movies and HD Movies.

1.4 Point-to-Point Network


- **CASE 1:** Estimated throughput is less than 20 Mbps. The PLC channel is not able to transmit an SDTV channel. The COVERAGE LED will be RED as shown in the following figure:



- **CASE 2:** Estimated throughput is greater than 20 Mbps but less than 40 Mbps. The PLC channel is able to transmit an SDTV channel, but not two SDTV channels simultaneously or one HDTV channel. The COVERAGE LED will be ORANGE as shown in the following figure:




- **CASE 3:** Estimated throughput is greater than 10 Mbps. The PLC channel is able to play at least two SDTV channels or 1 HDTV. The COVERAGE LED will be GREEN as shown here:




1.5 Point to Multipoint Network

In the case where the PLC network is composed of three or more adapters, similar situations could arise as with a point-to-point network.

- **CASE 1:** The COVERAGE LED in G.hn adapter 2 and G.hn adapter 3 will show the estimated level of the PLC link receiving from G.hn adapter 1.



- **CASE 2:** The COVERAGE LED in G.hn adapter 1 will show the estimated level of the PLC link from which it is receiving the most amount of traffic at any given time. For example, if G.hn adapter 1 is receiving traffic at 50Mbps from G.hn adapter 2 and is receiving 25Mbps from G.hn adapter 3, the COVERAGE LED will show the level with reference to the G.hn adapter 2 link, as shown in the following figure.



Chapter 2 Log In Procedure

2.1 Configure STATIC IP MODE

In static IP mode, you assign IP settings to your PC manually.


Follow these steps to configure your PC IP address to use subnet 192.168.0.x.

NOTE: The following procedure assumes you are running Windows XP. However, the general steps involved are similar for most operating systems (OS). Check your OS support documentation for further details.

STEP 1: From the Network Connections window, open Local Area Connection (You may also access this screen by double-clicking the Local Area Connection icon on your taskbar). Click the **Properties** button.

STEP 2: Select Internet Protocol (TCP/IP) and click the Properties button.

STEP 3: Change the IP address to the domain of 192.168.0.x (5<x<255) with subnet mask of 255.255.255.0. The screen should now display as below.



STEP 4: Click **OK** to submit these settings.




2.2 Logging In

Perform the following steps to login to the web user interface.

STEP 1: Start the Internet browser and enter the default IP address for the device in the Web address field. For example, if the default IP address is 192.168.0.5, type <http://192.168.0.5>

STEP 2: A dialog box will appear, such as the one below. Input the default Authentication Password.

Authentication Password: **admin**

A screenshot of a web-based configuration dialog box for the PG-9171n. The title bar says "PG-9171n Web Configuration". On the left is the COMTREND logo. The main content area is titled "Authentication" and contains the following text: "This unit is password protected. Please enter the correct password to access the web pages". Below this is a password input field with the label "•Password" and "Ok" and "Cancel" buttons. A second password input field is labeled "Factory Reset*". A warning message "Warning! Current configuration will be lost" is displayed below the second field, with "Ok" and "Cancel" buttons.

Click **OK** to continue.

Note:

The Factory Reset password is: **betera**



Chapter 3 G.hn Interface

PG-9171n Web Configuration [Log Out](#)

[G.hn](#) [IP](#) [Ethernet](#) [Device](#) [Multicast](#) [QoS](#) [VLAN](#) [G.hn spectrum](#) [Log file](#) [Advanced](#)

Basic settings

- MAC address f8:8e:85:f5:09:3a
- Device ID 1
- Domain Name HomeGrid
- Force node Type AUTOMATIC
- Node type* DOMAIN_MASTER

* Node type change can take some time, please refresh page to update state

G.hn profile PLC 50MHz with MIMO

Neighboring Domain Interference Mitigation (NDIM)

- NDIM mode AUTOMATIC
- Domain ID (DOD) 4

Encryption Configuration

- Encryption is DISABLED
- Pairing password

Enable Cancel

Available Connections

Device ID	MAC Address	Phy Tx (Mbps)	Phy Rx (Mbps)
Empty list			



3.1 Basic Configuration

- **MAC Address** Displays the MAC address of the device.
- **Device ID** Device ID of this node.
- **Domain Name** string of all nodes in the network.
- **Force node Type** force the modem to have a particular role (END POINT or DOMAIN MASTER)
- **G.hn profile** of all nodes in the network: selecting which G.hn profile must be applied to the network (PLC 50MHz, PLC 50MHz with MIMO, PLC 100MHz, COAX 100MHz and PHONE 100MHz).

3.2 NDIM Configuration

- **NDIM mode** set to Automatic for enabling automatic DOD selection functionality and set to Manual for manual configuration of DOD.
- **Domain ID (DOD)** manually set the DOD number from 1 to 15 to use a different preamble seed than the default 0.

3.3 Encryption Configuration via WEB UI

- **Pairing Password** used for authentication. Write a custom password to manually create a secure domain.

Available Connections

- In this tab table, all the available **G.hn connections** are presented. Remote node DID and MAC address, transmission and reception physical speeds.

Chapter 4 IP Interface

PG-9171n Web Configuration [Log Out](#)

IPv4 configuration*

DHCP enabled	NO
IPv4 address / netmask	192.168.0.5 / 255.255.255.0
Default Gateway	192.168.0.5
DNS	192.168.0.5
Additional address #1	0.0.0.0 / 0.0.0.0
Additional address #2	0.0.0.0 / 0.0.0.0

*All changes except the DNS server will have effect after system boot

IPv6 configuration*

DHCP enabled	NO
IPv6 address / prefix	0000:0000:0000:0000:0000:0000:0000:0000/0
Default Gateway	0000:0000:0000:0000:0000:0000:0000:0000
DNS	0000:0000:0000:0000:0000:0000:0000:0000
Additional address #1	0000:0000:0000:0000:0000:0000:0000:0000/0
Additional address #2	0000:0000:0000:0000:0000:0000:0000:0000/0
Additional address #3	0000:0000:0000:0000:0000:0000:0000:0000/0
Additional address #4	0000:0000:0000:0000:0000:0000:0000:0000/0
IPv6 link-local address	fe80:0000:0000:0000:fa8e:85ff:fe5/128
IPv6 SLAAC address	0000:0000:0000:0000:0000:0000:0000:0000/0

*All changes except the DNS server will have effect after system boot

NTPv4/v6 client configuration

NTPv4/v6 client enabled	NO
Resynchronization time	30
NTP IPv4/v6 address	204.152.184.72



4.1 IP config

In the **IP configuration** tab of one G.hn node, the IPv4 and IPv6 settings can be read and changed.

IPv4 subsection:

- **DHCPv4 enabled:** in the case of choosing "**NO**" IP configuration in the following parameters, the IPv4 Address, Subnet Mask, Default Gateway and DNS should be configured; fill these fields in. In the case of choosing "**YES**" they will be filled automatically when configuration is received from the DHCPv4 server.
- **IPv4 address/netmask:** IPv4 address / netmask of this device.
- **Default Gateway:** IPv4 gateway to connect the device to other LAN segments.
- **DNS:** Domain Name Server IP (IPV4).
- **Additional address #1/2:** additional fixed IPv4 addresses that will always be configured at boot time.

IPv6 subsection:

- **DCHPv6 enabled:** in the case of choosing "**NO**" IP configuration in the following parameters, the IPv6 Address, prefix, Default Gateway and DNS should be configured; fill these fields in. In the case of choosing "**YES**" they will be filled automatically when configuration is received from the DHCPv6 server.
- **IPv6 Address / prefix:** IPv6 address / prefix of the device to read the node's DHCPv6 address in case the DHCPv6 is enabled.
- **Default Gateway:** IPv6 gateway to connect the node to other LAN segments.
- **DNS:** Domain Name Server IP (IPV6).
- **Additional address #1/2/3/4:** additional fixed IPv6 addresses that will always be configured at boot time.
- **IPv6 Link-Local Address:** to read the node's Link Local address.
- **IPv6 SLAAC address:** IPv6 address, automatically obtained by means of the SLAAC mechanism.

NTPv4/v6 subsection:

- **NTPv4/v6 client enabled:** Enable/disable NTP client.
- **Resynchronization time:** Configure re-synchronization interval time in minutes.
- **NTP IPv4/v6 address:** Hostname or IP (IPv4 or IPv6) of NTP server.



Chapter 5 Ethernet Interface

PG-9171n Web Configuration Log Out

Ethernet

External Interfaces:

Interface	Speed	Duplex	Interface Type	Mode	Internal PHY	Link
ETHA	100	FULL_DUPLEX	SSMII	MAC	YES	YES
ETHB	100	FULL_DUPLEX	SSMII	MAC	YES	NO

Powersaving

• Inactivity detection mode:

• Inactivity time(s):

The Ethernet table shows the coverage & Info of the Ethernet interface; including Interface, Speed, Duplex, Interface Type, Mode, Internal PHY & Link.

Powersaving

Ethernet powersaving can be disabled, enabled by Ethernet link or enabled by Ethernet activity; idle timer can be configured as well.



Chapter 6 Device Interface

PG-9171n Web Configuration Log Out

G.hn **IP** **Ethernet** **Device** **Multicast** **QoS** **VLAN** **G.hn spectrum** **Log file** **Advanced**

Hardware information	
•Device name	PG-9171n
•Device description	Comtrend G.hn Ethernet and Wireless to Powerline Adapter
•Device manufacturer	Comtrend
•Serial number	140569000112
•MAC address	f8:8e:85:f5:09:3a
•HW version	1_0
Software information	
•FW version	gedw362f_WorkssysEval_512M_v1_x_SPIRIT.v6_4_r398+41_cvs
•System uptime	0 days, 1h 56m 25s
Security	
•New Configuration password	<input type="password"/>
Ok Cancel	
SW update	
•Status	Ready: initial status
•Protocol	FTP
•Server IPv4/v6	<input type="text"/>
•FTP User	<input type="text"/>
•FTP Password	<input type="text"/>
•OSUP Filename	<input type="text"/>
Ok Cancel	

6.1 Hardware information

In this tab, basic information such as MAC Address and Serial Number of the selected node is shown.



6.2 Software information

Shows the FW version and system uptime.

6.3 Security

The nodes in the network: to change the configuration password string from the default ("admin") to another; decided by the user.

6.4 SW update

Current loaded firmware version is shown. Any flash section can be upgraded; the first flash section should be selected and after clicking on the "OK" button the corresponding file should be chosen. Usually, a reboot should be performed afterwards to make sure the changes are effective.

The protocol is by FTP client or TFTP client. L2 is proprietary and is reserved for future use.



Chapter 7 Multicast Interface

PG-9171n Web Configuration

[Log Out](#)

Multicast Configuration*

<ul style="list-style-type: none"> • IGMP Snooping • MLD snooping <p style="font-size: small;">*MLD and IGMP cannot be enabled at the same time</p>	<div style="display: flex; justify-content: space-between;"> <div style="width: 45%;"> <p>IGMP/MLD broadcast report</p> <p>IGMP Multicast ranges:</p> <table border="0" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 50%; text-align: left; vertical-align: top;"> <p>Minimum IP address</p> <table border="0" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 25%;"><input type="text" value="224"/></td> <td style="width: 25%;"><input type="text" value="0"/></td> <td style="width: 25%;"><input type="text" value="0"/></td> <td style="width: 25%;"><input type="text" value="0"/></td> </tr> <tr> <td><input type="text" value="0"/></td> <td><input type="text" value="0"/></td> <td><input type="text" value="0"/></td> <td><input type="text" value="0"/></td> </tr> <tr> <td><input type="text" value="0"/></td> <td><input type="text" value="0"/></td> <td><input type="text" value="0"/></td> <td><input type="text" value="0"/></td> </tr> <tr> <td><input type="text" value="0"/></td> <td><input type="text" value="0"/></td> <td><input type="text" value="0"/></td> <td><input type="text" value="0"/></td> </tr> </table> </td> <td style="width: 50%; text-align: left; vertical-align: top;"> <p>Maximum IP address</p> <table border="0" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 25%;"><input type="text" value="239"/></td> <td style="width: 25%;"><input type="text" value="254"/></td> <td style="width: 25%;"><input type="text" value="255"/></td> <td style="width: 25%;"><input type="text" value="255"/></td> </tr> <tr> <td><input type="text" value="0"/></td> <td><input type="text" value="0"/></td> <td><input type="text" value="0"/></td> <td><input type="text" value="0"/></td> </tr> <tr> <td><input type="text" value="0"/></td> <td><input type="text" value="0"/></td> <td><input type="text" value="0"/></td> <td><input type="text" value="0"/></td> </tr> <tr> <td><input type="text" value="0"/></td> <td><input type="text" value="0"/></td> <td><input type="text" value="0"/></td> <td><input type="text" value="0"/></td> </tr> </table> </td> </tr> </table></div> </div>	<p>Minimum IP address</p> <table border="0" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 25%;"><input type="text" value="224"/></td> <td style="width: 25%;"><input type="text" value="0"/></td> <td style="width: 25%;"><input type="text" value="0"/></td> <td style="width: 25%;"><input type="text" value="0"/></td> </tr> <tr> <td><input type="text" value="0"/></td> <td><input type="text" value="0"/></td> <td><input type="text" value="0"/></td> <td><input type="text" value="0"/></td> </tr> <tr> <td><input type="text" value="0"/></td> <td><input type="text" value="0"/></td> <td><input type="text" value="0"/></td> <td><input type="text" value="0"/></td> </tr> <tr> <td><input type="text" value="0"/></td> <td><input type="text" value="0"/></td> <td><input type="text" value="0"/></td> <td><input type="text" value="0"/></td> </tr> </table>	<input type="text" value="224"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<p>Maximum IP address</p> <table border="0" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 25%;"><input type="text" value="239"/></td> <td style="width: 25%;"><input type="text" value="254"/></td> <td style="width: 25%;"><input type="text" value="255"/></td> <td style="width: 25%;"><input type="text" value="255"/></td> </tr> <tr> <td><input type="text" value="0"/></td> <td><input type="text" value="0"/></td> <td><input type="text" value="0"/></td> <td><input type="text" value="0"/></td> </tr> <tr> <td><input type="text" value="0"/></td> <td><input type="text" value="0"/></td> <td><input type="text" value="0"/></td> <td><input type="text" value="0"/></td> </tr> <tr> <td><input type="text" value="0"/></td> <td><input type="text" value="0"/></td> <td><input type="text" value="0"/></td> <td><input type="text" value="0"/></td> </tr> </table>	<input type="text" value="239"/>	<input type="text" value="254"/>	<input type="text" value="255"/>	<input type="text" value="255"/>	<input type="text" value="0"/>																								
<p>Minimum IP address</p> <table border="0" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 25%;"><input type="text" value="224"/></td> <td style="width: 25%;"><input type="text" value="0"/></td> <td style="width: 25%;"><input type="text" value="0"/></td> <td style="width: 25%;"><input type="text" value="0"/></td> </tr> <tr> <td><input type="text" value="0"/></td> <td><input type="text" value="0"/></td> <td><input type="text" value="0"/></td> <td><input type="text" value="0"/></td> </tr> <tr> <td><input type="text" value="0"/></td> <td><input type="text" value="0"/></td> <td><input type="text" value="0"/></td> <td><input type="text" value="0"/></td> </tr> <tr> <td><input type="text" value="0"/></td> <td><input type="text" value="0"/></td> <td><input type="text" value="0"/></td> <td><input type="text" value="0"/></td> </tr> </table>	<input type="text" value="224"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<p>Maximum IP address</p> <table border="0" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 25%;"><input type="text" value="239"/></td> <td style="width: 25%;"><input type="text" value="254"/></td> <td style="width: 25%;"><input type="text" value="255"/></td> <td style="width: 25%;"><input type="text" value="255"/></td> </tr> <tr> <td><input type="text" value="0"/></td> <td><input type="text" value="0"/></td> <td><input type="text" value="0"/></td> <td><input type="text" value="0"/></td> </tr> <tr> <td><input type="text" value="0"/></td> <td><input type="text" value="0"/></td> <td><input type="text" value="0"/></td> <td><input type="text" value="0"/></td> </tr> <tr> <td><input type="text" value="0"/></td> <td><input type="text" value="0"/></td> <td><input type="text" value="0"/></td> <td><input type="text" value="0"/></td> </tr> </table>	<input type="text" value="239"/>	<input type="text" value="254"/>	<input type="text" value="255"/>	<input type="text" value="255"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>		
<input type="text" value="224"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>																																
<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>																																
<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>																																
<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>																																
<input type="text" value="239"/>	<input type="text" value="254"/>	<input type="text" value="255"/>	<input type="text" value="255"/>																																
<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>																																
<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>																																
<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>																																

| |

Chapter 8 QoS menu

PG-9171n Web Configuration Log Out

QoS Configuration

QoS criterion: Custom
 Type of frame: Ethernet frame
 Packet detection 1: IPv4
 Offset: 6
 Bitmask: 0xFFFF
 Pattern: 0x0800
 Packet detection 2: None
 Offset: 0
 Bitmask: 0x0000
 Pattern: 0x0000

Packet classification

Default prio: 0

PC	Offset	Bitmask	Pattern	Priority
Rule 1	7	0x00E0	0x0000	0
Rule 2	7	0x00E0	0x0020	1
Rule 3	7	0x00E0	0x0040	2
Rule 4	7	0x00E0	0x0060	3
Rule 5	7	0x00E0	0x0080	4
Rule 6	7	0x00E0	0x00A0	5
Rule 7	7	0x00E0	0x00C0	6
Rule 8	7	0x00E0	0x00E0	7

Ok Cancel

8.1 QoS Configuration

In the **QoS** configuration tab, the packet classifier can be managed to define a QoS rule for incoming Ethernet traffic, and assign a priority to be used in the G.hn network. Press the "**Ok**" button for loading the newly configured settings:

- **QoS CRITERION:** a general criterion can be chosen among "None" (no QoS), "Custom" and "802.1p".
- **Type of Frame:** with this parameter the type of Ethernet traffic being transmitted by the G.hn network should be selected. Based on this parameter, the internal offsets in the system are adjusted. In the QoS tab, Ethernet frame offsets should be set **counting number** as they appear in the sniffer SW (for instance, the same field will be in a different position if normal Ethernet frames or 802.1Q tagged frames exist).
- **Packet detection 1:** first packet detection rule can be configured (offset, bitmask and pattern). Packets which accomplish it will be sent to the classification module.
- **Packet detection 2:** if second packet detection is also enabled, both, first and second detection criteria must be accomplished to pass packets to the classification module.
- **Packet classification:** up to 8 classification rules can be defined in this section for packets which have previously been correctly detected. For 802.1p only priorities can be managed, offset, bitmask and pattern are predefined to sniff the PCP field.
- **Default priority:** select default priority; which will be applied to non classified incoming packets. Priority 7 is the highest. Priority 0 is the lowest.



Example 1

PG-9171n Web Configuration Log Out

QoS Configuration

QoS criterion	802.1p
Type of frame	Ethernet frame
Packet detection 1	None
Offset	0
Bitmask	0x0000
Pattern	0x0000
Packet detection 2	None
Offset	0
Bitmask	0x0000
Pattern	0x0000

Packet classification

PC	Offset	Bitmask	Pattern	Priority
Rule 1	0	0x0000	0x0000	0
Rule 2	0	0x0000	0x0000	1
Rule 3	0	0x0000	0x0000	2
Rule 4	0	0x0000	0x0000	3
Rule 5	0	0x0000	0x0000	4
Rule 6	0	0x0000	0x0000	5
Rule 7	0	0x0000	0x0000	6
Rule 8	0	0x0000	0x0000	7

Ok Cancel

If QoS criterion: 802.1p, all other options are grayed out, and follow the QoS rules below.
According to G.9960 specs, the priority mapping recommended by [IEEE 802.1D] subclause 7.7.3 is presented in Table III.1. for four priority queues.

PCP	Priority	Acronym	Traffic Types
1	0 (Third)	BK	Background
0	1 (lowest)	BE	Best Effort
2	2 (lowest)	EE	Excellent Effort
3	3 (Third)	CA	Critical Applications
4	4 (second)	VI	Video, < 100 ms latency and jitter
5	5 (second)	VO	Voice, < 10 ms latency and jitter
6	6 (highest)	IC	Internetwork Control
7	7 (highest)	NC	Network Control

In summary, the sequence of priority queue, (7,6) > (5,4) > (3,0) > (2,1)



Chapter 9 VLAN Interface


PG-9171n Web Configuration
Log Out

[G.hn](#)
[IP](#)
[Ethernet](#)
[Device](#)
[Multicast](#)
[QoS](#)
[VLAN](#)
[G.hn spectrum](#)
[Log file](#)
[Advanced](#)

VLAN Configuration

Enable VLAN feature	<input style="border: 1px solid #ccc; border-radius: 5px; padding: 2px 10px; font-size: 0.8em;" type="button" value="NO"/>
Set Port as VLAN Trunk	<input style="border: 1px solid #ccc; border-radius: 5px; padding: 2px 10px; font-size: 0.8em;" type="button" value="YES"/>
• PLC ports	<input style="border: 1px solid #ccc; border-radius: 5px; padding: 2px 10px; font-size: 0.8em;" type="button" value="YES"/>
• ETHA port	<input style="border: 1px solid #ccc; border-radius: 5px; padding: 2px 10px; font-size: 0.8em;" type="button" value="YES"/>
• ETHB port	<input style="border: 1px solid #ccc; border-radius: 5px; padding: 2px 10px; font-size: 0.8em;" type="button" value="YES"/>
• FW port	<input style="border: 1px solid #ccc; border-radius: 5px; padding: 2px 10px; font-size: 0.8em;" type="button" value="YES"/>
• SDIO port	<input style="border: 1px solid #ccc; border-radius: 5px; padding: 2px 10px; font-size: 0.8em;" type="button" value="YES"/>
Ingress/Egress tag	
• ETHA VLAN tag:	<input style="border: 1px solid #ccc; width: 20px; height: 20px; font-size: 0.8em;" type="text" value="0"/>
• ETHB VLAN tag:	<input style="border: 1px solid #ccc; width: 20px; height: 20px; font-size: 0.8em;" type="text" value="0"/>
• FW VLAN tag:	<input style="border: 1px solid #ccc; width: 20px; height: 20px; font-size: 0.8em;" type="text" value="0"/>
• PLC VLAN tag:	<input style="border: 1px solid #ccc; width: 20px; height: 20px; font-size: 0.8em;" type="text" value="0"/>
• SDIO VLAN tag:	<input style="border: 1px solid #ccc; width: 20px; height: 20px; font-size: 0.8em;" type="text" value="0"/>

9.1 VLAN Configuration

In the **VLAN Configuration** tab of one G.hn node, a VLAN tag can be added or removed per interface. Also, removing a tag at egress per interface can be also enabled or disabled:

- **Enable VLAN Configuration:** Select **No** from the drop down menu to disable completely the VLAN functionality, removing all tags.
- **Remove VLAN tag at egress:** Select **Yes** from the drop down menu for the port that you want to remove the VLAN tag from.
- **Ingress/Egress tag:** A tag value (from 1 to 4095) per interface can be added in this section. Set value to 0 for no tagging.



Chapter 10 G.hn spectrum Interface

PG-9171n Web Configuration [Log Out](#)

Notches Configuration

Notch index	Start freq (KHz)	Stop freq (KHz)	Depth (dB)	Type
0	1800	2000	100	Regulation
1	3500	4000	100	Regulation
2	7000	7300	100	Regulation
3	10100	10150	100	Regulation
4	14000	14350	100	Regulation
5	18068	18168	100	Regulation
6	21000	21450	100	Regulation
7	24890	24990	100	Regulation
8	28000	29700	100	Regulation
9	50000	54000	100	Regulation
10	0	1807	100	Regulation
11	80000	100000	100	Regulation
12	28000	30000	26	Regulation

Add new user notch

- Index (0..9)
- Start frequency (KHz)
- Stop frequency (KHz)
- Depth (0..40dB, 100 removes notch)

Ok Cancel

Remove user notch

- Index (0..9)

Ok Cancel

10.1 Notches

In this tab a table with all configured **Notches** of selected node will be shown. The table is composed of next columns for every notch: Notch Number, Type of notch, Start Frequency (KHz), Stop Frequency (KHz), Depth (in dB).



The first 22 notches (Regulation) are Read Only, **RO**, in the system and they can be neither removed nor modified. The next 40 notches (Vendor) are defined by the vendor using SDK and they are also RO. The last 10 notches (User) are R/W and they can be added/removed by user using this tool.

To add new notches the user should fill the "**Add a new User Notch**" fields, setting Start and Stop frequencies in KHz and depth in dB of notch and then press the "**OK**" button. They will be added in first User free position from number 0 to 9. (If successful, you can see a record in the Type column)

To remove a User Notch, the "**Remove a User Notch**" section should be used, setting notch number to be removed from 0 to 9 and pressing the "**OK**" button.

Chapter 11 Log file Interface

The screenshot shows the PG-9171n Web Configuration interface. The left sidebar has a navigation menu with links: G.hn, IP, Ethernet, Device, Multicast, QoS, VLAN, G.hn spectrum, Log file, and Advanced. The main content area is titled "Log File Configuration". It contains the following settings:

• Enable Log File	<input type="button" value="NO"/>
• Data capture interval (s)	1
• FTP server URL	<input type="text"/>
• FTP server login	<input type="text"/>
• FTP server password	<input type="text"/>
• Upload to server interval (min)	5

At the bottom are "Ok" and "Cancel" buttons.

11.1 Log File

In the **Log File** configuration the following settings can be read, and changed by clicking on the corresponding "**OK**" button for the selected node:

- **Enable Log File** set to YES for enabling Log File functionality in the node and set to NO for disabling it.
- **Data Capture Interval** sets the interval of time in seconds to capture data.
- **FTP Server URL** configures the url for the remote FTP server where the files will be uploaded.
- **FTP Server Login** configures the user for the FTP server.
- **FTP Server Password** configures the password for the FTP server.
- **Upload to Server Interval** sets the interval of time in minutes to send the captured file to the remote server.



Chapter 12 Advanced Interface

The screenshot shows the PG-9171n Web Configuration interface. On the left, a sidebar lists navigation options: G.hn, IP, Ethernet, Device, Multicast, QoS, VLAN, G.hn spectrum, Log file, and Advanced. The main content area has three tabs: Broadcast suppression, Hardware Reset, and Factory Reset*. The Broadcast suppression tab contains a field for 'Broadcast xput limit (Mbps)' with a value of '1', and buttons for 'Ok' and 'Cancel'. The Hardware Reset tab has a 'Hardware Reset' button. The Factory Reset* tab contains a 'Password' field and a warning message: '*Warning! Current configuration will be lost', with 'Ok' and 'Cancel' buttons.

Broadcast suppression : In this tab the broadcast suppression feature can be managed. Broadcast traffic higher than the selected value will be dropped.

Hardware Reset: Click on this button to perform a reboot in the node.

Factory Reset: Input the password: **betera** and click the **OK** button to perform a factory reset. The current configuration will be lost.



Chapter 13 Connecting to PG-9171nWireless-N Powerline Adapter by web browser

After the network connection is complete, the next step you should perform is to setup the Wireless-N Powerline Adapter with proper network parameters, so it can work properly in your network environment.

Before you can connect to the Wireless-N Powerline Adapter and start configuration procedures, your computer must be able to get an IP address automatically (use dynamic IP address). If it's set to use static IP address, or you're unsure, please follow the instructions below to configure your computer to use dynamic IP address. Windows 7 is used for reference; other operating systems might have slightly different configuration options or interfaces.


13.1 Windows 7 IP address setup

1. Click the Start button and select Control Panel. Double click Network and Internet and click Network and Sharing Center, the Network and Sharing Center window will appear.
2. Click Change adapter settings and right click on the Local Area Connection icon and select Properties. The Local Area Connection window will appear.
3. Check your list of Network Components. You should see Internet Protocol Version 4 (TCP/IPv4) on your list. Select it and click the Properties button.
4. In the Internet Protocol Version 4 (TCP/IPv4) Properties window, select 'Use the following IP address', then input the following settings in their respective fields:

IP address: 192.168.0.2 已註解 [Trevor1]: Is this ok?

Subnet Mask: 255.255.255.0

5. Click OK to confirm the setting.





13.2 Connecting to Web Management Interface

All functions and settings of this Wireless-N Powerline Adapter must be configured via web management interface. Please start your web browser, and input '**192.168.0.10**' in the address bar, then press 'Enter' key. The following should be displayed:



Input the user name and password in the respective fields, default user name is '**root**', and default password is '**12345**', then press the 'OK' button, and you can see the Quick Setup interface of this Wireless-N Powerline Adapter.



13.3 Quick Setup

After login, the **Quick Setup** screen will appear. It is the default screen when no connections exist. This screen allows for the configuration of DSL settings and the IP configuration. It includes LAN, Wireless and Security setup screens.

NOTE: If you can't see the web management interface, and you're being prompted to input user name and password again, it means you didn't input the username and password correctly. Please retype the user name and password again. If you're certain about the user name and password you type are correct, please see section 1.2 to perform a factory reset, to set the password back to default value.

13.3.1 LAN Settings

Enable your Wireless-N Powerline Adapter to dynamically receive an IP Address from your home gateway. Your Wireless-N Powerline Adapter must have an IP Address in the Local Area Network's existing IP range.

Quick Setup | Status | General Setup | Wireless | Tools

Quick Setup

LAN Settings
 Wireless Settings
 Security Settings

Enable your Wireless-N Powerline Adapter to dynamically receive an IP Address from your home gateway. Your Wireless-N Powerline Adapter must have an IP Address in the Local Area Network's existing IP range.

IP Address: 192.168.0.10
Subnet Mask: 255.255.255.0
Default Gateway: 0.0.0.0
DNS :
DHCP: Disabled

Next>>

IP Address	The IP address for the Wireless-N Powerline Adapter.
Subnet Mask	The Subnet Mask for the Wireless-N Powerline Adapter.
Default Gateway	Specify the IP address of the default gateway of your network here.
DNS	Input the IP address of the domain name server.
DHCP	Disable or Enable DHCP client. If Enabled, IP Address, Subnet Mask, Default Gateway and DNS will be obtained by DHCP client automatically.

Click the **Next** button to continue.



13.3.2 Wireless Settings

This page is used to configure the parameters for the wireless connection of tablets, smart phones, and laptops.

This page is used to configure the parameters for the wireless connection of tablets, smart phones, and laptops.

Band: 2.4 GHz (B+G+N)

Mode: AP

Network Type: Infrastructure

SSID: Comtrend093B

Channel Width: 40MHz

Control Sideband: Upper

Channel Number: Auto

Click the **Next** button to continue.

Band	Select the wireless band you wish to use. By selecting a different band setting, you'll be able to allow or deny the wireless client of a certain band. If you select 2.4GHz (B), 2.4GHz (N), or 2.4GHz (G), only wireless clients using the wireless band you select (802.11b, 802.11 n, or 802.11g) will be able to connect to this Wireless-N Powerline Adapter. If you select 2.4GHz (B+G), then only wireless clients using 802.11b and 802.11g band will be able to connect to this Wireless-N Powerline Adapter. If you want to allow 802.11b, 802.11g, and 802.11 Draft-N clients to connect to this Wireless-N Powerline Adapter, select 2.4GHz (B+G+N).
Mode	PG-9171n only supports AP mode.
Network Type	In Infrastructure Mode, wireless clients can access the other networks (perhaps Internet) via this AP. For AP. Only Infrastructure Mode is allowed here.
SSID	Input the ESSID (the name used to identify this Wireless-N Powerline Adapter) here. You can input up to 32 alphanumeric characters. PLEASE NOTE THAT THE ESSID IS CASE SENSITIVE.
Channel Width	Select wireless channel width (bandwidth taken by wireless signals of this Wireless-N Powerline Adapter). It's suggested to select 'Auto 20/40MHz'. Do not change to '20 MHz' unless you know what it is.



Control Sideband	Specify if the extension channel should be in the Upper or Lower sideband.
Channel Number	Select a channel number ("Auto" is recommended). Please select a channel number you wish to use. If you know a certain channel number is being used by other wireless access points nearby, please refrain from using the same channel number.

13.3.3 Security Settings

Turn on WEP or WPA encryption to prevent unauthorized access to your wireless network.

The screenshot shows the 'Quick Setup' interface for a COMTREND Wireless-N G.hn Powerline Adapter. The left sidebar has 'Quick Setup' selected, with radio buttons for 'LAN Settings', 'Wireless Settings', and 'Security Settings'. The main content area is titled 'Turn on WEP or WPA encryption to prevent unauthorized access to your wireless network.' It includes a dropdown menu for 'Encryption' (set to 'WPA2 Mixed'), a dropdown for 'Pre-Shared Key Format' (set to 'Passphrase'), and a text input field for 'Pre-Shared Key' (containing '123456789b'). At the bottom are 'Cancel', '<<Back', and 'Apply' buttons.

Select the **Encryption** method from the drop down menu. Then select and fill in the required parameters.

Click the **Apply** button to display the following.


The screenshot shows the 'Quick Setup' interface after applying the security settings. The left sidebar still shows 'Quick Setup' selected. The main content area displays a success message: 'Change setting successfully!', followed by 'Do not turn off or reboot the Device during this time.', and 'Please wait 13 seconds ...'.

Do not turn off or reboot the device during this time.

13.4 Status

13.4.1 Device Status

This page shows the current status and some basic settings of the device.



The screenshot shows the 'Status' page of the COMTREND Wireless-N G.hn Powerline Adapter. The top navigation bar includes 'Quick Setup', 'Status', 'General Setup', 'Wireless', and 'Tools'. The left sidebar under 'Status' has links for 'Device Status', 'System Log', and 'Statistics'. The main content area displays the following information:

System	
Uptime	0day:0h:0m:32s
Firmware Version	PG-9171n-WLAN-3465CTU-C01_R01
Wireless Configuration	
Mode	AP
Band	2.4 GHz (B+G+N)
SSID	Comtrend093B
Channel Number	1
Encryption	WPA2 Mixed
BSSID	f8:8e:85:f5:09:3b
Associated Clients	0
TCP/IP Configuration	
Attain IP Protocol	Fixed IP
IP Address	192.168.0.10
Subnet Mask	255.255.255.0
Default Gateway	0.0.0.0
DNS	
MAC Address	f8:8e:85:f5:09:3b

Up time	Displays the total time passed since the Wireless-N Powerline Adapter was powered on.
Firmware Version	Displays Firmware version of wireless Wireless-N Powerline Adapter.
Mode	Displays current wireless operating mode.
Band	Displays the transmission mode (802.11b, 802.11n or 802.11g).
SSID	Displays current SSID (the name used to identify this Wireless-N Powerline Adapter).
Channel Number	Displays current wireless channel number.
Encryption	Displays current wireless security setting.
BSSID	Displays current BSSID (a set of unique identification name of this Wireless-N Powerline Adapter, it cannot be modified by user).
Associated Clients	Displays the number of connected wireless clients.
Attain IP Protocol	Displays the method of obtaining the IP address.



IP Address	Displays the IP address of this Wireless-N Powerline Adapter.
Subnet Mask	Displays the net mask of IP address.
Default Gateway	Displays the IP address of default gateway.
DNS	Displays the IP address of the DNS server.
MAC address	Displays the MAC address of WLAN interface.

13.4.2 System Log

This page shows the system's operational information; start up time, system events, and also lets you enable or disable certain logging features.

The screenshot shows the 'System Log' configuration page. The top navigation bar includes 'Quick Setup', 'Status', 'General Setup', 'Wireless', and 'Tools'. On the left, a sidebar titled 'Status' lists 'Device Status', 'System Log', and 'Statistics'. The main content area contains a descriptive text block and several configuration options. The 'Enable Log' checkbox is checked, with sub-options for 'system all', 'wireless', and 'DoS'. The 'Enable Remote Log' checkbox is also checked, and a 'Log Server IP Address' input field is present. Below these are 'Apply Changes', 'Refresh', and 'Clear' buttons.


To enable the System Log tick the check box and make your selections.
Click the **Apply Changes** button to display the following.

A message box displays the text: 'Change setting successfully! Your changes have been saved. The router must be rebooted for the changes to take effect. You can reboot now, or you can continue to make other changes and reboot later.' It contains two buttons: 'Reboot Now' and 'Reboot Later'.

Click the **Reboot Now** button for the changes to take effect. Click the **Reboot Later** button to continue to make changes and reboot the device at a different time.

13.4.3 Statistics

This page shows the packet count for the Wireless and Ethernet LAN.



Wireless-N G.hn Powerline Adapter

Quick Setup | Status | General Setup | Wireless | Tools

Status

- Device Status
- System Log
- Statistics

This page shows data traffic statistics for the Wireless and Ethernet networks.

	Sent Packets	Received Packets
Wireless LAN	144	11352
Ethernet LAN	454	253

Refresh

Wireless LAN Sent Packets	It shows the statistic count of sent packets on the wireless LAN interface
Wireless LAN Received Packets	It shows the statistic count of received packets on the wireless LAN interface
Ethernet LAN Sent Packets	It shows the statistic count of sent packets on the Ethernet LAN interface
Ethernet LAN Received Packets	It shows the statistic count of received packets on the Ethernet LAN interface

Click the **Refresh** button to update the Wireless/Ethernet LAN statistics.


13.5 General Setup

13.5.1 Time Zone Setting

Automatically synchronize your Wireless-N Powerline Adapter time with Internet time servers. Select your local time zone from the drop-down menu.

This page is used to configure NTP client to get current time.

After clicking 'Time Zone' on the left of web management interface and the following will be displayed:



Wireless-N G.hn Powerline Adapter

Quick Setup | Status | General Setup | Wireless | Tools

General Setup

- ▶ [Time Zone](#)
- ▶ [Password Settings](#)
- ▶ [TR-069 Client](#)
- ▶ [LAN Settings](#)

Automatically synchronize your Wireless-N Powerline Adapter time with Internet time servers. Select your local time zone from the drop-down menu.

Time Zone Select : (GMT-08:00)Pacific Time (US & Canada); Tijuana

Automatically Adjust Daylight Saving

Enable NTP client update

NTP server : 208.184.49.9 - North America (Manual IP Setting)

Buttons: Apply Change, Reset, Refresh

Time Zone Select	Select the time zone in your country
Automatically Adjust Daylight Saving	Click this box to enable or disable Automatically Adjust Daylight Saving function
Enable NTP client update	Click the checkbox to enable NTP client update
NTP server	Click select default or input NTP server IP address



13.5.2 Password

This page is used to set the account to access the web server of your Wireless-N Powerline Adapter. Emptying the user name and password fields will disable the protection.

The screenshot shows the COMTREND Wireless-N G.hn Powerline Adapter web interface. The top navigation bar includes links for Quick Setup, Status, General Setup, Wireless, and Tools. The main content area is titled "General Setup" and contains a list of sub-links: Time Zone, Password Settings (which is currently selected), TR-069 Client, and LAN Settings. To the right of this list is a descriptive text block: "This page allows you to create an account to access the web server of your Wireless-N Powerline Adapter. Emptying the user name and password fields will disable the protection." Below this text are three input fields for "User Name", "New Password", and "Confirmed Password". At the bottom of the form are two buttons: "Apply Changes" and "Reset".

Click the **Apply Changes** button to create the new password setting.

Click the **Reset** button to reset/clear the data just input on screen.



13.5.3 TR-069 Client

WAN Management Protocol (TR-069) allows an Auto-Configuration Server (ACS) to perform auto-configuration, provision, collection, and diagnostics of this device.

The screenshot shows the 'General Setup' section of the COMTREND configuration interface. It includes fields for ACS URL, User Name, Password, and Periodic Inform Interval. There are also sections for Connection Request and Certificate Management. At the bottom, there are 'Apply Changes' and 'Undo' buttons, and a note about a system reboot after configuration.

General Setup

WAN Management Protocol (TR-069) allows an Auto-Configuration Server (ACS) to perform auto-configuration, provision, collection, and diagnostics of this device.

TR-069: Disabled Enabled

ACS:

URL:

User Name:

Password:

Periodic Inform Enable: Disabled Enabled

Periodic Inform Interval: 86400

Connection Request:

User Name: test

Password: test

Path: 0

Port: 7547

Apply Changes Undo

Please note that this system will be reboot after new TR-069 configuration is set.

Certificate Management:

CA Certificat: No file selected.

Select desired values and click **Apply Changes** to configure TR-069 client options.

ACS URL	URL for the CPE to connect to the ACS using the CPE WAN Management Protocol. This parameter MUST be in the form of a valid HTTP or HTTPS URL. An HTTPS URL indicates that the ACS supports SSL. The "host" portion of this URL is used by the CPE for validating the certificate from the ACS when using certificate-based authentication.
ACS User Name	Username used to authenticate the CPE when making a connection to the ACS using the CPE WAN Management Protocol. This username is used only for HTTP-based authentication of the CPE.



ACS Password	Password used to authenticate the CPE when making a connection to the ACS using the CPE WAN Management Protocol. This password is used only for HTTP-based authentication of the CPE.
Periodic Inform Enable	Whether or not the CPE periodically sends CPE information to the ACS.
Periodic Inform Interval	The duration in seconds of the interval for which the CPE attempts to connect with the ACE if periodic inform is enabled.
Connection Request	
User Name	Username used to authenticate an ACS making a Connection Request to the CPE.
Password	Password used to authenticate an ACS making a Connection Request to the CPE.
Path	This is an element in the makeup of the Connection Request URL.
Port	This is an element in the makeup of the Connection Request URL.



13.5.4 LAN Settings

Enable your Wireless-N Powerline Adapter to dynamically receive an IP Address from your home gateway. Your Wireless-N Powerline Adapter must have an IP Address in the Local Area Network's existing IP range.

Wireless-N G.hn Powerline Adapter

General Setup

Time Zone
Password Settings
TR-069 Client
LAN Settings

Quick Setup | Status | General Setup | Wireless | Tools

Enable your Wireless-N Powerline Adapter to dynamically receive an IP Address from your home gateway. Your Wireless-N Powerline Adapter must have an IP Address in the Local Area Network's existing IP range.

IP Address: 192.168.0.10
Subnet Mask: 255.255.255.0
Default Gateway: 0.0.0.0
DNS :
DHCP: Disabled

Apply Changes Reset

IP Address	The IP address for the Wireless-N Powerline Adapter.
Subnet Mask	The Subnet Mask for the Wireless-N Powerline Adapter.
Default Gateway	The LAN default gateway.
DNS	Specify the IP address of the default gateway of your network here.
DHCP	Disable or Enable DHCP client. If Enabled, IP Address, Subnet Mask, Default Gateway and DNS will be obtained by DHCP client automatically.

Click the **Apply Changes** button to apply the amendments you made.

Click the **Reset** button to clear the data just inputted on the screen.



13.6 Wireless

13.6.1 Basic settings

This page is used to configure the parameters for the wireless connection of tablets, smart phones, and laptops.

This page is used to configure the parameters for the wireless connection of tablets, smart phones, and laptops.

Disable Wireless LAN Interface

Band: 2.4 GHz (B+G+N) ▾

Mode: AP ▾

Network Type: Infrastructure ▾

SSID: Comtrend0938

Channel Width: 40MHz ▾

Control Sideband: Upper ▾

Channel Number: Auto ▾

Broadcast SSID: Enabled ▾

WMM: Enabled ▾

Data Rate: Auto ▾

Associated Clients: Show Active Clients

Apply Changes Reset

Disable Wireless LAN interface	Clicking it will disable your Wireless LAN Interface. The Wireless Interface default is Enable.
Band	<p>Please select the wireless band you wish to use. By selecting a different band setting, you'll be able to allow or deny the wireless client of a certain band.</p> <p>If you select 2.4GHz (B), 2.4GHz (N), or 2.4GHz (G), only wireless clients using the wireless band you select (802.11b, 802.11 n, or 802.11g) will be able to connect to this Wireless-N Powerline Adapter.</p> <p>If you select 2.4GHz (B+G), then only wireless clients using 802.11b and 802.11g band will be able to connect to this Wireless-N Powerline Adapter.</p> <p>If you want to allow 802.11b, 802.11g, and 802.11 Draft-N clients to connect to this Wireless-N Powerline Adapter, select 2.4GHz (B+G+N).</p>



Mode	PG-9171n supports not only AP mode, but also provides WDS, AP+WDS. Please refer to below for detailed wireless Basic Settings. In Default, PG-9171n will work with AP mode.
Network Type	In Infrastructure Mode, wireless clients can access the other networks (perhaps Internet) via this AP. For AP. Only Infrastructure Mode is allowed here.
SSID	Please input the ESSID (the name used to identify this Wireless-N Powerline Adapter) here. You can input up to 32 alphanumerical characters. PLEASE NOTE THAT THE ESSID IS CASE SENSITIVE.
Channel Width	Select wireless channel width (bandwidth taken by wireless signals of this Wireless-N Powerline Adapter). It's suggested to select 'Auto 20/40MHz'. Do not change to '20 MHz' unless you know what it is.
Control Sideband	Specify if the extension channel should be in the Upper or Lower sideband.
Channel Number	Please select a channel number you wish to use. If you know a certain channel number is being used by other wireless access points nearby, please refrain from using the same channel number
Broadcast SSID	Decide if the Wireless-N Powerline Adapter will broadcast its own SSID or not. You can hide the SSID of your Wireless-N Powerline Adapter (set the option to 'Disable'), so only people those who know the SSID of your Wireless-N Powerline Adapter can get connected.
WMM	<p>WMM (Wi-Fi Multimedia) technology, which can improve the performance of certain network applications, like audio/video streaming, network telephony (VoIP), and others.</p> <p>When you enable the WMM function, the Wireless-N Powerline Adapter will define the priority of different kinds of data, to give higher priority to applications which require instant responding. Therefore you can improve the performance of such network applications.</p>
Data rate	Set the wireless data transfer rate to a certain value. Since most of wireless devices will negotiate with each other and pick a proper data transfer rate automatically, it's not necessary to change this value unless you know what will happen after modification.
Associated Clients	Click the 'Show Active Clients' button and a new popup window will appear which contains the information about all wireless clients connected to this Wireless-N Powerline Adapter. You can click the 'Refresh' button in the popup window to keep information up-to-date.

Click the **Show Active Clients** button to display the following.



Active Wireless Client Table - Windows Internet Explorer
http://192.168.0.10/wlistab.htm

Active Wireless Client Table

This table shows the MAC address, transmission, reception packet counters and encrypted status for each associated wireless client.

MAC Address	Mode	Tx Packet	Rx Packet	Tx Rate (Mbps)	Power Saving	Expired Time (s)
None

Refresh Close

After you finish with the settings, please click 'Apply Changes', and the following message will be displayed:

Change setting successfully!

Your changes have been saved. The router must be rebooted for the changes to take effect.
You can reboot now, or you can continue to make other changes and reboot later.

When you see this message, the settings you made are successfully saved. You can click the 'Reboot Later' button to back to previous page and continue on other setting items, or click the 'Reboot Now' button to restart the Wireless-N Powerline Adapter and the changes will take effect after about 30 seconds.



13.6.2 Advanced settings

This Wireless-N Powerline Adapter has many advanced wireless features. Please note that all settings listed here are for experienced users only, if you're not sure about the meaning and function of these settings, please don't modify them, or the wireless performance will be reduced.

You can click 'Advanced Settings' on the left to enter the advanced settings menu, and the following message will be displayed:

The Advanced screen allows you to configure advanced features of the wireless LAN interface. These settings should not be changed unless you know what effect they will have in your wireless network.

Fragment Threshold:	2346	(256-2346)
RTS Threshold:	2347	(0-2347)
Beacon Interval:	100	(20-1024 ms)
Preamble Type:	<input type="radio"/> Long Preamble <input checked="" type="radio"/> Short Preamble	
IAPP:	<input checked="" type="radio"/> Enabled <input type="radio"/> Disabled	
Protection:	<input type="radio"/> Enabled <input checked="" type="radio"/> Disabled	
Aggregation:	<input checked="" type="radio"/> Enabled <input type="radio"/> Disabled	
Short GI:	<input checked="" type="radio"/> Enabled <input type="radio"/> Disabled	
STBC:	<input checked="" type="radio"/> Enabled <input type="radio"/> Disabled	
LDPC:	<input checked="" type="radio"/> Enabled <input type="radio"/> Disabled	
20/40MHz Coexist:	<input checked="" type="radio"/> Enabled <input type="radio"/> Disabled	
TX Beamforming:	<input type="radio"/> Enabled <input checked="" type="radio"/> Disabled	
Multicast to Unicast:	<input checked="" type="radio"/> Enabled <input type="radio"/> Disabled	
RF Output Power:	<input checked="" type="radio"/> 100% <input type="radio"/> 70% <input type="radio"/> 50% <input type="radio"/> 35% <input type="radio"/> 15%	

Apply Changes **Reset**

Fragment Threshold	Set the Fragment threshold of wireless radio. Do not modify default value if you don't know what it is, default value is 2346
RTS Threshold	Set the RTS threshold of wireless radio. Do not modify default value if you don't know what it is, default value is 2347
Beacon Interval	Set the beacon interval of wireless radio. Do not modify default value if you don't know what it is, default value is 100
Preamble Type	Set the type of preamble of wireless radio, Do not modify default value if you don't know what it is, default setting is 'Short Preamble'
IAPP	Click to enable or disable the IAPP function.
Protection	Click to enable or disable the Protection function.
Aggregation	Click to enable or disable the Aggregation function.



Short GI	Click to enable or disable the Short GI function.
STBC	Click to enable or disable the STBC function.
LDPC	Click to enable or disable the LDPC function.
20/40MHz Coexist	Click to enable or disable the 20/40MHz Coexist function.
TX Beamforming	Click to enable or disable the TX Beamforming function.
Multicast to Unicast	Click to enable or disable the multicast to unicast conversion function.
RF Output Power	You can set the output power of wireless radio. Unless you're using this Wireless-N Powerline Adapter in a really big space, you may not have to set output power to 100%. This will enhance security (malicious / unknown users in distance will not be able to reach your Wireless-N Powerline Adapter).

After you finish with the settings, please click 'Apply Changes', and the following message will be displayed:

Change setting successfully!

Your changes have been saved. The router must be rebooted for the changes to take effect.
You can reboot now, or you can continue to make other changes and reboot later.

When you see this message, the settings you made are successfully saved. You can click the 'Reboot Later' button to go back to previous page and continue on other setting items, or click the 'Reboot Now' button to restart the Wireless-N Powerline Adapter and the changes will take effect after about 30 seconds.



13.6.3 Security settings

This Wireless-N Powerline Adapter provides many types of wireless security (wireless data encryption). When you use data encryption, data transferred by radio signals in the air will become unreadable for those people who don't know correct encryption key (encryption password). You can click 'Security Settings' on the left to enter the security settings menu, and the following will be displayed:

The screenshot shows the 'Wireless' configuration page for a COMTREND Wireless-N G.hn Powerline Adapter. The left sidebar lists 'Basic Settings', 'Advanced Settings', 'Security Settings' (which is selected and highlighted in blue), 'Access Control', and 'WPS'. The main content area has a sub-header: 'This page allows you to setup wireless security. Turn on WEP or WPA encryption to prevent unauthorized access to your wireless network.' Below this are 'Apply Changes' and 'Reset' buttons. The configuration fields include:

- Encryption:** WPA-Mixed (selected from a dropdown menu)
- Authentication Mode:** Personal (Pre-Shared Key) (selected radio button)
- WPA Cipher Suite:** TKIP, AES (checkboxes checked)
- WPA2 Cipher Suite:** TKIP, AES (checkboxes checked)
- Pre-Shared Key Format:** Passphrase (selected from a dropdown menu)
- Pre-Shared Key:** A masked password field showing '*****'.

Encryption	Select the encryption supported over wireless access. The encryption method can be None, WEP, WPA(TKIP), WPA2 or WPA2 Mixed.
------------	------------------------------------------------------------------------------------------------------------------------------

Different selections will produce different parameters.

13.6.3.1 Disable Security

When you select 'Disable', wireless encryption for the network is disabled.

This page allows you to setup wireless security. Turn on WEP or WPA encryption to prevent unauthorized access to your wireless network.

Encryption:

802.1x Authentication:

13.6.3.2 WEP

WEP (Wired Equivalent Privacy) is a common encryption mode, it's safe enough for home and personal use. But if you need higher level of security, please consider using WPA encryption (see next Section).

However, some wireless clients don't support WPA, but only support WEP, so WEP is still a good choice for you if you have such kind of client in your network environment.

When you select 'WEP' as the encryption type, the following will be displayed:

This page allows you to setup wireless security. Turn on WEP or WPA encryption to prevent unauthorized access to your wireless network.

Encryption:

802.1x Authentication:

Authentication: Open System Shared Key Auto

Key Length:

Key Format:

Encryption Key:

802.1x Authentication	While WEP Encryption is selected. Click the check box to enable the IEEE 802.1x authentication function.
Key Length	There are two types of WEP key length: 64-bit and 128-bit. Using '128-bit' is safer than '64-bit', but will reduce some data transfer performance.

已註解 [Trevor2]: Please provide a description

Key Format	There are two types of key format: ASCII and Hex. When you select a key format, the number of characters of the key will be displayed. For example, if you select '64-bit' as key length, and 'Hex' as key format, you'll see the message at the right of 'Key Format' is 'Hex (10 characters)', which means the length of WEP key is 10 characters.
------------	------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

13.6.3.3 WPA/WPA2/WPA-Mix

WPA/WPA2/WPA-Mix are the safest encryption methods currently, and it's recommended to use one of these encryption methods to ensure the safety of your data.

In our example below we select 'WPA-Mix' as the encryption type. The following will be displayed:

Apply Changes
Reset

Encryption:

WPA-Mixed
 ▼

Authentication Mode:

Enterprise (RADIUS) Personal (Pre-Shared Key)

WPA Cipher Suite:

TKIP AES

WPA2 Cipher Suite:

TKIP AES

Pre-Shared Key Format:

Passphrase
 ▼

Pre-Shared Key:

••••••••••

WPA Authentication Mode	Click to select the WPA-Mixed Authentication Mode with Enterprise (RADIUS) or Personal (Pre-Shared Key).
WPA/WPA2 Cipher Suite	There are two type of Cipher :TKIP and AES
Pre-shared Key Format	Please select the format of pre-shared key here, available options are 'Passphrase' (8 to 63 alphanumerical characters) and 'Hex' (64 hexadecimal characters – 0 to 9 and a to f).
Pre-shared Key	Please input pre-shared key according to the key format you selected here. For security reasons, don't use simple words).

已註解 [Trevor3]: Please add to the description

13.6.4 Access Control

Another security measure you can use to keep hackers and intruders away is 'Access Control'. You can pre-define a so-called 'white-list', which contains MAC addresses of the wireless clients you trust. All other wireless client with the MAC address which is not in your list will be denied by this Wireless-N Powerline Adapter.

To setup MAC filtering, please click 'Access Control' on the left of web management interface and the following will be displayed:



Wireless-N G.hn Powerline Adapter

Quick Setup | Status | General Setup | Wireless | Tools

Wireless

- ▶ [Basic Settings](#)
- ▶ [Advanced Settings](#)
- ▶ [Security Settings](#)
- ▶ [Access Control](#) **Current**
- ▶ [WPS](#)

For security reasons, the Wireless-N Powerline Adapter features MAC Address Filtering that will only allow authorized MAC Addresses to access the Wireless-N Powerline Adapter. Follow the on-screen instructions to set up this feature.

Wireless Access Control Mode:

MAC Address: Comment:

Current Access Control List:

MAC Address	Comment	Select
<input type="button" value="Delete Selected"/>	<input type="button" value="Delete All"/>	<input type="button" value="Reset"/>

Wireless Access Control Mode	Click Disabled, Allow Listed or Deny Listed from the drop down menu. This is a security control function; only those clients registered in the access control list can link to this WLAN Broadband Router.
MAC Address	Fill in the MAC address of the client to register this WLAN Broadband Router access capability.
Comment	Fill in the comment tag for the registered client.
Current Access Control List	It shows the registered clients that are allowed to link to this WLAN Broadband Router.

After you finish with the settings, please click 'Apply Changes'.



13.6.5 WPS

Wi-Fi Protected Setup (WPS) is the simplest way to build a connection between wireless network clients and this Wireless-N Powerline Adapter. You don't have to select encryption mode and input a long encryption passphrase every time when you need to setup a wireless client, you only have to press a button on wireless client and this Wireless-N Powerline Adapter, and the WPS will do the setup for you.

This Wireless-N Powerline Adapter supports two types of WPS: Push-Button Configuration (PBC), and PIN code. If you want to use PBC, you have to switch this Wireless-N Powerline Adapter to WPS mode and push a specific button on the wireless client to start WPS mode. You can push the Reset/WPS button of this Wireless-N Powerline Adapter, or click the 'Start PBC' button in the web configuration interface to do this; if you want to use PIN code, you have to provide the PIN code of the wireless client you wish to connect to this Wireless-N Powerline Adapter and then switch the wireless client to WPS mode. The detailed instructions are listed follow:

Note: WPS function of this Ethernet adapter will not work for those wireless clients that do not support WPS.

To use the WPS function to set an encrypted connection between this Wireless-N Powerline Adapter and WPS-enabled wireless client by WPS, click 'WPS' on the left, and the following information will be displayed:

The screenshot shows the 'WPS' configuration page of the COMTREND Wireless-N G.hn Powerline Adapter. The page includes a note about WPS compatibility, a 'Disable WPS' button, and several configuration options for WPS status, auto-lock-down, and push button configuration. A table displays current key information, including authentication, encryption, and the key itself.

This page allows you to setup or configure settings for WPS (Wi-Fi Protected Setup). WPS can help wireless clients automatically connect to the Wireless-N Powerline Adapter upon initial setup.

Disable WPS

WPS Status: Configured UnConfigured

Auto-lock-down state: unlocked

Self-PIN Number: 30743625

Push Button Configuration:

STOP WSC

Client PIN Number:

Current Key Info:

Authentication	Encryption	Key
WPA2-Mixed PSK	TKIP+AES	123456783b




Disable WPS	Check this box to enable or disable the WPS function.
WPS Status	Displays WPS status. If data encryption settings of this Wireless-N Powerline Adapter have never been set, the 'unConfigured' message will be displayed here; if data encryption settings have been set before, the 'Configured' message will be displayed here.
Auto-lock-down state	When WSC daemon is attacked by the wrong pin code 10 times, then WSC will enter lock-down state.
Self-PIN Number	This is the WPS PIN code of this Wireless-N Powerline Adapter. This code is useful when you need to build wireless connection by WPS with other WPS-enabled wireless devices.
Push Button Configuration	Click 'Start PBC' to start the Push-Button style WPS setup procedure. This Wireless-N Powerline Adapter will wait for WPS requests from wireless clients for 2 minutes. The 'WLAN' LED on the Wireless-N Powerline Adapter will be steady on for 2 minutes when this Wireless-N Powerline Adapter is waiting for an incoming WPS request.
STOP WSC	Click 'Stop WSC' to stop WPS setup procedure.
Client PIN Number	Please input the PIN code of the wireless client you via client wish to connect, and click the 'Start PIN' button. The 'WLAN' LED on the Wireless-N Powerline Adapter will be steady on when this Wireless-N Powerline Adapter is waiting for incoming WPS request.

NOTE: When you're using PBC type WPS setup, you must press the 'PBC' button (hardware or software) of the wireless client within 120 seconds; if you didn't press PBC button of the wireless client within this time period, please press 'PBC' button (hardware or software) of this access point again.


13.7 Tools

13.7.1 Configuration Tools

Use the "Backup" tool to save the current configuration of your Wireless-N Powerline Adapter to a file named "config.dat". You can then use the "Restore" tool to recover the saved configuration to your Wireless-N Powerline Adapter.



Click the **Backup** button to display the following.



Click the **Save** button to backup your current configuration.



13.7.2 Firmware Upgrade

This page allows you upgrade the Wireless-N Powerline Adapter firmware to the new version. Please note, do not power off the device during the upload as it may crash the system.

After clicking 'Upgrade Firmware' on the left of web management interface and the following will be displayed:

The screenshot shows the 'Firmware Upgrade' page of the COMTREND web interface. The top navigation bar includes links for 'Quick Setup', 'Status', 'General Setup', 'Wireless', and 'Tools'. On the left, a sidebar titled 'Tools Setup' lists 'Configuration Tools', 'Firmware Upgrade' (which is currently selected), and 'Factory Defaults'. The main content area contains instructions for upgrading the firmware, a 'Firmware Version' field showing 'PG-9171n-WLAN-3465CTU-C01_R01', a 'Select File:' input field with 'Browse...' and 'No file selected.' buttons, and 'Apply' and 'Reset' buttons at the bottom.

Click the **Browse** button to locate the file.

Click the **Apply** button to apply the upgrade.



13.7.3 Factory Defaults

This page allows you to reset the current configuration to factory defaults.

A screenshot of a web-based configuration interface for a COMTREND Wireless-N G.hn Powerline Adapter. The top navigation bar includes the COMTREND logo, the product name 'Wireless-N G.hn Powerline Adapter', and links for 'Quick Setup', 'Status', 'General Setup', 'Wireless', and 'Tools'. The left sidebar is titled 'Tools Setup' and lists 'Configuration Tools', 'Firmware Upgrade', and 'Factory Defaults'. The main content area contains a message: 'This page allows you to reset the current configuration to factory defaults.' Below this is a form with the label 'Reset Settings to Default:' and an 'Apply' button.

Click the **Apply** button to reset the configuration.