

[vlan-priority <integer(0-7>)]	Denotes the VLAN priority to be assigned to the packets if the packet meets the requirements of the marking rules specified in Section 3.4.12.7.1 .	Optional	0	0-7, where 7 is the highest
[qos enable]	Indicates whether this QoS marking rule should be enabled. The absence of this flag indicates that this QoS flag is disabled. By default, a bearer plane QoS marking rule is disabled. If you enable this QoS marking rule, packets on bearer plane that were created using the parameters in Section 3.4.12.7.1 , the Outer DSCP and VLAN Priority fields in the IP header and Ethernet header, respectively are populated with the values you specify for the outer-dscp and vlan-priority parameters.	Optional	By default, the QoS marking rule is disabled.	The presence/absence of this flag indicates that this QoS flag is enabled/disabled.

Command Bearer plane QoS marking rules configuration mode
Modes

3.4.12.7.3 Restoring the Default Configuration Parameters for the Bearer Plane QoS Output Marking Rules

Run the following command to restore the default configuration for this bearer plane QoS marking rule:

```
npu(config-bqos)# no {outer-dscp | vlan-priority | qos enable}
```

When you execute this command, it automatically disables this QoS marking rule.



NOTE

Refer to [Section 3.4.12.7.2](#) for a description and default values of these parameters.

Command Syntax	<code>npu(config-bqos)# no {outer-dscp vlan-priority qos enable}</code>
----------------	---

Privilege Level	10
-----------------	----

Command Modes	Bearer plane QoS marking rules configuration mode
---------------	---

3.4.12.7.4 Terminating the QoS Marking Rules Configuration Mode

Run the following command to terminate the marking rules configuration mode:

`npu(config-bqos)# exit`

Command Syntax	<code>npu(config-bqos)# exit</code>
----------------	-------------------------------------

Privilege Level	10
-----------------	----

Command Modes	Bearer plane QoS marking rules configuration mode
---------------	---

3.4.12.7.5 Deleting Bearer Plane QoS Marking Rules

Run the following command to delete the a QoS marking rule:

`npu(config)# no bearerqos [<qos-alias>]`



CAUTION

Specify the QoS alias if you want to delete a specific bearer plane qos marking rule. Otherwise all the configured bearer plane QoS marking rules are deleted except "int_default" and "ext_default" which cannot be deleted.

Command Syntax	<code>npu(config)# no bearerqos [<qos-alias>]</code>
----------------	--

Privilege Level	10
-----------------	----

Syntax**Description**

Parameter	Description	Presence	Default Value	Possible Values
[<qos-alias>]	Denotes the QoS alias of the bearer QoS marking rule that you want to delete. Specify a value for this parameter if you want to delete a specific bearer QoS marking rule. Do not specify a value for this parameter if you want to delete all bearer QoS marking rules except "int_default" and "ext_default".	Optional	N/A	String

Command

Global configuration mode

Modes

3.4.12.7.6 Displaying Configuration Information for the Bearer Plane QoS Marking Rules

To display configuration information for specific or all bearer plane QoS marking rules, run the following command:

```
npu# show bearerqos [<qos-alias>]
```

Specify the QoS alias if you want to display configuration information for a particular bearer plane QoS marking rule. Do not specify a value for this parameter if you want to view configuration information for all bearer plane QoS marking rules.

Command**npu# show bearerqos** [<qos-alias>]**Syntax****Privilege**

1

Level

Syntax
Description

Parameter	Description	Presence	Default Value	Possible Values
[<qos-alias>]	Denotes the QoS alias of the bearer QoS marking rule that you want to display. Specify a value for this parameter if you want to display a specific bearer QoS marking rule. Do not specify a value for this parameter if you want to display all bearer QoS marking rules.	Optional	N/A	String

Display
Format

Bearer QoS Configuration :

```
qos-alias intf-type svc-type trfc-priority media-type inner-dscp outer-dscp vlan-priority status
voip <value> <value> <value> <value> <value> <value> enabled
```

Command
Modes

Global command mode

3.4.12.8 Managing Service Interfaces

A Service Interface defines the parameters of the interface used by the ASN-GW on the network side for services specified in the applicable Service Group.

The following types of Service Interface are available:

- IP-IP: The Service Interface defines the parameters on the ASN-GW side of a point-to-point tunnel to be used for the applicable traffic.
- VLAN: The Service Interface defines the VLAN ID to be added/removed by the ASN-GW to/from the applicable traffic.
- QinQ: Applicable only for special applications requiring local support of unauthenticated mode. The QinQ Service Interface is applicable only for supporting VLAN CS Service Flows associated with a QinQ Service Group.

Up to 10 Service Interfaces may be defined.

**To configure a Service Interface:**

- 1 Enable the Service Interface configuration mode for the selected Service Interface (refer to [Section 3.4.12.8.1](#))
- 2 You can now execute any of the following tasks:
 - » Configure one or more of the parameters of the Service Interface (refer to [Section 3.4.12.8.2](#))
 - » Restore the default values of the Service Interface parameters (refer to [Section 3.4.12.8.3](#))
 - » Terminate the Service Interface configuration mode (refer to [Section 3.4.12.8.4](#))

In addition, you can, at any time, display configuration information for one or all existing Service Interfaces (refer to [Section 3.4.12.8.6](#)) or delete an existing Service Interface (refer to [Section 3.4.12.8.5](#)).

3.4.12.8.1 Enabling the Service Interface Configuration Mode Creating a Service Interface

To configure the parameters of a Service Interface, first enable the Service Interface configuration mode for the specific Service Interface. Run the following command to enable the Service Interface configuration mode. You can also use this command to create a new Service Interface.

```
npu(config)# svc-intf [<string>] [{IP-IP|VLAN|QinQ}]
```

For example, to define a new IP-IP Service Interface named SI1, run the following command:

```
npu(config)# svc-intf SI1 IP-IP
```

To enable the configuration mode for an existing Service Interface named SI1, run the following command:

```
npu(config)# svc-intf SI1
```

If you use this command to create a new Service Interface, the configuration mode for this Service Interface is automatically enabled.

**NOTE**

The Bearer IP Interface (refer to [“Configuring IP interfaces” on page 143](#)) must be configured prior to creating IP-IP or VLAN service interfaces.

After enabling the configuration mode for a Service Interface you can execute any of the following tasks:

- Configure one or more of the Service Interface parameters (refer to [Section 3.4.12.8.2](#))
- Restore the default values of non-mandatory parameters of the Service Interface (refer to [Section 3.4.12.8.3](#))

After executing the above tasks, you can terminate the Service Interface configuration mode (refer to [Section 3.4.12.8.4](#)) and return to the global configuration mode.

Command Syntax `npu(config)# srvc-intf [<string>] [{IP-IP|VLAN|QinQ}]`

Privilege Level 10

Syntax Description

Parameter	Description	Presence	Default Value	Possible Values
[<string>]	The Service Interface alias of the Service Interface for which you want to enable the configuration mode. If you want to create a new Service Interface, specify a new alias and define the type of service interface (see below).	Mandatory	N/A	String (1 to 30 characters)
[{IP-IP VLAN QinQ}]	The Service Interface's type.	Optional	IP-IP	■ IP-IP ■ VLAN ■ QinQ

Command Global configuration mode
Modes

3.4.12.8.2 Configuring Service Interface Parameters

This section describes the commands for:

■ “Configuring Parameters for IP-IP Service Interface” on page 256

■ “Configuring Parameters for VLAN Service Interface” on page 257

3.4.12.8.2.1 Configuring Parameters for IP-IP Service Interface

After enabling the IP-IP Service Interface configuration mode, run the following command to configure the IP-IP service interface parameters:

This command shall configure one or more parameters of the IP-IP Service Interface.

npu(config-srvcif-ipip)# config tunnel ([**descr** <string>] [**srcaddr** <ip4addr>] [**dstaddr** <ipv4addr>] [**chksm**])



IMPORTANT

An error may occur if you provide an invalid value for any of these parameters. Refer to the syntax description for more information about the appropriate values and format for configuring these parameters.

At least one parameter must be specified (the value is optional): The command npu(config-srvcif-ip-ip)# config tunnel will return an Incomplete Command error.

Command **npu(config-srvcif-ip-ip)# config tunnel** ([**descr** <string>] [**srcaddr** <ip4addr>]
Syntax {**dstaddr** <ipv4addr>} [**chksm**])

Privilege 10
Level

Syntax
Description

Parameter	Description	Presence	Default Value	Possible Values
[descr <string>]	A description of the Service Interface.	Optional	null	String (up to 70 characters)

[srcaddr <ip4addr>]	The source IP address that indicates the point of origination of the tunnel for the service interface. Must be set to the same address as the NPU Bearer IP Address.	Optional	0.0.0.0	IP Address of Bearer Interface.
{dstaddr <ip4addr>}	The destination IP address that indicates the point of termination of the tunnel for the service interface. Must be set to a valid IP address. The destination IP address of an existing Service Interface (if already configured to a valid value) cannot be changed.	Optional	0.0.0.0	Valid IP Address.
[chksm]	Indicates that end-to-end checksumming mechanism on ServiceTunnel Interface is enabled.	Optional	By default, this feature is disabled.	The presence/absence of this flag indicates that this feature is enabled/disabled.

Command IP-IP Service Interface configuration mode
Modes

3.4.12.8.2.2 Configuring Parameters for VLAN Service Interface

After enabling the VLAN Service Interface configuration mode, run the following command to configure the VLAN service interface parameters:

This command shall configure one or more parameters of the VLAN Service Interface.

```
npu(config-srvcif-vlan)# config ([descr <string>] [vlan-id <size(1-9 | 11-4094)>] [dflt-gw-ip <ipaddress> <mask>])
```

**IMPORTANT**

An error may occur if you provide an invalid value for any of these parameters. Refer to the syntax description for more information about the appropriate values and format for configuring these parameters.

At least one parameter must be specified (the value is optional): The command `npu(config-srvcif-vlan)# config` will return an Incomplete Command error.

Command
Syntax

`npu(config-srvcif-vlan)# config` ([**`descr`** <string>] [**`vlan-id`** <size(1-9|11-4094>]
[**`dflt-gw-ip`** <ip address> <mask>])

Privilege
Level

10

Syntax
Description

Parameter	Description	Presence	Default Value	Possible Values
<code>descr</code> <string>	Aa description of the service interface.	Optional	null	String (up to 70 characters)
<code>vlan-id</code> <size(1-9 11-4094>] >]	A Service Interface VLAN ID shall not conflict with other instances of Service Interface VLAN ID and VLAN IDs of Bearer, Local-Management, External-Management and AU Maintenance interfaces. Shall also not conflict with CVID of any transparent MS with L2 service. Must be set to a valid value other than the default (0). The VLAN ID of an existing Service Interface cannot be changed.	Optional	0	1-9, 11-4094

	[dflt-gw-ip <ip address> <mask>]	The IP Address and subnet mask of the Default Gateway. The IP address shall be unique among all the Host Interfaces IP's (Bearer, Local-Management, Internal-Management, External-Management) and existing instances of Service Interface's Tunnel Destination IP Address and Default Gateway IP Address. Interface mask should be configured in such a way that the resulting subnet should not overlap with an existing Interface subnet (host interfaces, other service interfaces). Should be in the same subnet with the IP Address of the DHCP server/proxy/relay to be assigned to a service group using this service interface. Must be changed from the default value. The Default Gateway IP Address of an existing service interface cannot be changed. The Subnet Mask of a service interface associated to a service group cannot be changed.	Optional	0.0.0.0 255.255.255.0	valid IP address and mask
--	----------------------------------	---	----------	--------------------------	---------------------------

Command VLAN Service Interface configuration mode
Modes

3.4.12.8.2.3 Configuring Parameter for QinQ Service Interface

After enabling the QinQ Service Interface configuration mode, run the following command to configure the QinQ service interface parameters:

This command shall configure one or more parameters of the QinQ Service Interface.

npu(config-srvcif-QinQ)# config ([**descr** <string>] [**vlan-id** <size(1-4094)>])



IMPORTANT

An error may occur if you provide an invalid value for any of these parameters. Refer to the syntax description for more information about the appropriate values and format for configuring these parameters.

At least one parameter must be specified (the value is optional): The command npu(config-srvcif-QinQ)# config will return an Incomplete Command error.

Command
Syntax

npu(config-srvcif-QinQ)# config ([**descr** <string>] [**vlan-id** <size(1-4094)>])

Privilege
Level

10

Syntax
Description

Parameter	Description	Presence	Default Value	Possible Values
descr <string>	A description of the service interface.	Optional	null	String (up to 70 characters)
vlan-id <size(1-4094)>]	A Service Interface VLAN ID shall not conflict with other instances of Service Interface VLAN ID and VLAN IDs of Bearer, Local-Management and External-Management interfaces. Shall also not conflict with CVID of any transparent MS. Note that the default (0) is not a valid value.	Optional	0	1-9, 11-4094

Command
Modes

QinQ Service Interface configuration mode

3.4.12.8.3 Restoring the Default Configuration Parameters for an IP-IP Service Interface

Run the following command to restore the default configuration for IP-IP service interface chksm parameter:

npu(config-srvcif-ipip)# no tunnel [chksm]

**NOTE**

Refer to [Section 3.4.12.8.2.1](#) for a description and default value of this parameter.

Command Syntax	npu(config-srvcif-ipip)# no tunnel [chksm]
----------------	--

Privilege Level	10
-----------------	----

Command Modes	IP-IP Service Interface configuration mode
---------------	--

3.4.12.8.4 Terminating a Service Interface Configuration Mode

This section describes the commands for:

- [“Terminating the IP-IP Service Interface Configuration Mode” on page 261](#)
- [“Terminating the VLAN Service Interface Configuration Mode” on page 262](#)
- [“Terminating the QinQ Service Interface Configuration Mode” on page 262](#)

3.4.12.8.4.1 Terminating the IP-IP Service Interface Configuration Mode

Run the following command to terminate the IP-IP service interface configuration mode:

npu(config-srvcif-ipip)# exit

Command Syntax	npu(config-srvcif-ipip)# exit
----------------	-------------------------------

Privilege Level	10
-----------------	----

Command Modes	IP-IP Service interface configuration mode
---------------	--

3.4.12.8.4.2 Terminating the VLAN Service Interface Configuration Mode

Run the following command to terminate the vlan service interface configuration mode:

npu(config-srvcif-vlan)# exit

Command Syntax	npu(config-srvcif-vlan)# exit
----------------	-------------------------------

Privilege Level	10
-----------------	----

Command Modes	VLAN Service interface configuration mode
---------------	---

3.4.12.8.4.3 Terminating the QinQ Service Interface Configuration Mode

Run the following command to terminate the QinQ service interface configuration mode:

npu(config-srvcif-QinQ)# exit

Command Syntax	npu(config-srvcif-QinQ)# exit
----------------	-------------------------------

Privilege Level	10
-----------------	----

Command Modes	QinQ Service interface configuration mode
---------------	---

3.4.12.8.5 Deleting a Service Interface

You can, at any time, run the following command to delete service interface:

npu(config)# no srvc-intf [<intf-alias>]



NOTE

A Service Interface cannot be deleted if it is assigned to any Service Group.

A QinQ Service Interface cannot be deleted if it is assigned to a Service Flow (with a VPWS-QinQ Service Group). For details refer to [“Configuring Service Flows” on page 314](#).

Command **npu(config)# no srvc-intf [<intf-alias>]**
 Syntax

Privilege 10
 Level

Syntax
 Description

Parameter	Description	Presence	Default Value	Possible Values
[<intf-alias>]	The alias of the Service interface which needs to be deleted	Mandatory	N/A	String

Command Global configuration mode
 Modes

3.4.12.8.6 Displaying Configuration Information for the Service Interface

To display configuration information for one or all service interfaces, run the following command:

npu# show srvc-intf <intf-alias>

Specify a value for the `intf-alias` parameter if you want to display configuration information for a particular service interface. Do not specify a value for this parameter if you want to view configuration information for all service interfaces.

Command **npu# show srvc-intf <intf-alias>**
 Syntax

Privilege 1
 Level

Syntax**Description**

Parameter	Description	Presence	Default Value	Possible Values
<intf-alias>	The alias of the service interface that you want to display. If you do not specify a value for this parameter, all the services interfaces that are configured, are displayed.	Optional	N/A	String

Display**Format****IP-IP****Service****Interface**

if-alias <string>

if-descr <string>

intf-type IP-IP

tun-src-ip <IP address>

tun-dst-ip <IP address>

tun-chksum <Enable/Disable>tun-mtu <value>

Display**Format****VLAN****Service****Interface**

% Asn-gateway Srvc Intf config

if-alias <string>

if-descr <string>

intf-type VLAN

if-vlan-id <value>

if-dflt-gw-ip <value>

if-dflt-gw-netmask <value>

vlan-mtu <value>

Display**Format****QinQ****Service****Interface**

% Asn-gateway Srvc Intf config

if-alias <value>

if-descr <value>

intf-type QinQ

if-vlan-id <value>

Command**Modes**

Global command mode

3.4.12.9 Configuring the AAA Client Functionality

The AAA client functionality enables configuration of one RADIUS client. The RADIUS client encapsulates the messages destined for the AAA server in RADIUS messages or decapsulates messages sent by the AAA server for the MS.

In addition, you can also configure certain RADIUS parameters such as the NAS ID and the time zone offset that are applicable for all AAA clients. In the current release a single AAA client is supported.

This section describes the commands for:

- “Managing AAA Client Configuration” on page 265
- “Managing Global RADIUS Configuration Parameters” on page 271

3.4.12.9.1 Managing AAA Client Configuration



To configure the AAA client:

- 1 Enable the AAA client configuration mode (refer to [Section 3.4.12.9.1.1](#))
- 2 You can now execute any of the following tasks:
 - » Configure the AAA client parameters (refer to [Section 3.4.12.9.1.2](#))
 - » Restore the default configuration of the Alternate Server (refer to [Section 3.4.12.9.1.3](#))
 - » Switch between the Primary and Alternate Servers (refer to [Section 3.4.12.9.1.4](#))
 - » Terminate the AAA client configuration mode (refer to [Section 3.4.12.9.1.5](#))

In addition, you can, at any time, display the AAA client configuration information (refer to [Section 3.4.12.9.1.6](#)). The AAA client cannot be deleted.

3.4.12.9.1.1 Enabling the AAA Client Configuration Mode

To configure the AAA client parameters, first enable the AAA client configuration mode. Run the following command to enable the AAA client configuration mode.

```
npu(config)# aaa-client <client-alias>
```

The system is supplied with a pre-configured AAA client with the following properties that cannot be modified:

client-alias: default

src-intf: Bearer

After enabling the AAA client configuration mode you can execute any of the following tasks:

- Configure the AAA client parameters (refer to [Section 3.4.12.9.1.2](#))
- Restore the default configuration of the Alternate Server (refer to [Section 3.4.12.9.1.3](#))
- Switch between the Primary and Alternate Servers (refer to [Section 3.4.12.9.1.4](#))
- Terminate the AAA client configuration mode and return to the global configuration mode (refer to [Section 3.4.12.9.1.5](#)).

Command Syntax **npu(config)# aaa-client** <client-alias>

Privilege Level 10

Syntax Description

Parameter	Description	Presence	Default Value	Possible Values
<client-alias>	Denotes the client-alias of the AAA client for which the configuration mode is to be enabled. In the current release a single AAA client is supported, with client-alias "default".	Mandatory	N/A	default

Command Modes Global configuration mode

3.4.12.9.1.2 Configuring Parameters for the AAA Client

After enabling the AAA client configuration mode, run the following command to configure the parameters for the AAA client:

```
npu(config-aaa)# config ([src-intf <ip-intf>] [primary-serveraddr
<ipv4addr>] [alternate-serveraddr <ipv4addr>] [rad-sharedsecret
<string>] [aaaRedundancy {Enable|Disable}] [rad-CallingStationId
{Binary | UTF-8}])
```

**IMPORTANT**

An error may occur if you provide an invalid value for any of these parameters. Refer the syntax description for more information about the appropriate values and format for configuring these parameters.

**IMPORTANT**

If the bearer interface IP address is being modified after aaa-client configuration, you must re-configure the src-intf parameter to "bearer" so that the aaa-client will attach itself to the new bearer interface IP address.

Command
Syntax

```
npu(config-aaa)# config ([src-intf <ip-intf>] [primary-serveraddr <ipv4addr>]
[alternate-serveraddr <ipv4addr>] [rad-sharedsecret <string>] [aaaRedundancy
{Enable|Disable}] [rad-CallingStationId {Binary | UTF-8}])
```

Privilege
Level

10

Syntax
Description

Parameter	Description	Presence	Default Value	Possible Values
[src-intf <ip-intf>]	Indicates the interface providing RADIUS client functionality. Must be either the bearer interface or the external-management interface.	Optional	bearer	■ bearer ■ external-man agement
[primary-serveraddr <ipv4addr>]	Denotes IPv4 address of the primary AAA server. primary-serveraddr and alternate-serveraddr cannot be the same. primary-serveraddr and alternate-serveraddr cannot have IP address assigned to NPU IP interfaces.	Mandatory	172.16.0.10	Valid IP Address

[alternate-serveraddr <ipv4addr>]	Denotes IPv4 address of the alternate (secondary) AAA server. 0.0.0.0 means no alternate server. Must be set to a valid IP address if aaaRedundancy is enabled.	Optional	0.0.0.0	Valid IP Address
[rad-sharedsecret <string>]	Denotes the shared secret between the AAA client and the AAA server(s).	Optional	default	String (1 to 49 characters)
[aaaRedundancy {Enable Disable}]	Indicates whether AAA server redundancy is supported. If enabled, the ASN-GW will try switching to the alternate server if the primary server does not respond, and vice versa. If enabled - the ip-address of the active server (primary or alternate) cannot be modified.	Optional	Disable	☒ Enable ☒ Disable
[rad-CallingStationId {Binary UTF-8}]	The format of the MAC address used to define the Calling Station ID	Optional	UTF-8	☒ Binary ☒ UTF-8

Command AAA client configuration mode
Modes

3.4.12.9.1.3 Restoring the Default Value of the Alternate Server

Run the following command to restore the default value (0.0.0.0) Of the alternate server:

```
npu(config-aaa)# no alternate-serveraddr
```



IMPORTANT

The alternate server cannot be cleared (restored to the default value) if aaaRedundancy is enabled.

Command Syntax	npu(config-aaa)# no alternate-serveraddr
----------------	--

Privilege Level	10
-----------------	----

Command Modes	AAA client configuration mode
---------------	-------------------------------

3.4.12.9.1.4 Switching between the Primary and Alternate Servers

Run the following command to switch between servers:

npu(config-aaa)# aaaSwitchOver

This command is applicable only when aaa redundancy is enabled.

If you execute this command when the active server is the primary server, the unit will attempt connecting to the alternate server, and vice versa.

Command Syntax	npu(config-aaa)# aaaSwitchOver
----------------	--------------------------------

Privilege Level	10
-----------------	----

Command Modes	AAA client configuration mode
---------------	-------------------------------

3.4.12.9.1.5 Terminating the AAA Client Configuration Mode

Run the following command to terminate the AAA client configuration mode:

npu(config-aaa)# exit

Command Syntax	npu(config-aaa)# exit
----------------	-----------------------

Privilege Level	10
-----------------	----

Command AAA client configuration mode
Modes

3.4.12.9.1.6 Displaying Configuration and Status Information for the AAA Client

To display one or all AAA clients, run the following command:

npu# show aaa-client <client-alias>

In the current release a single AAA client is supported. The client-alias is default.

Command **npu# show aaa-client <client-alias>**
Syntax

Privilege 1
Level

Syntax
Description

Parameter	Description	Presence	Default Value	Possible Values
[<client-alias>]	Denotes the client-alias for which the associated AAA client information is to be displayed. In the current release the client-alias of the supported client is default.	Optional	N/A	default or null

Display AAA-client :
Format Src-intf(IP) :
 Primary-ServerAddr :
 Alternate ServerAddr :
 Radius Shared Secret : <not available for display>
 Active AAA server :
 AAA Redundancy :
 Station ID Format :

Command Global command mode
Modes

In addition to configurable parameters, the currently Active AAA server (Primary/Alternate) is also displayed.

3.4.12.9.2 Managing Global RADIUS Configuration Parameters

Global RADIUS configuration parameters for AAA clients determine how AAA clients should send access requests. This section describes the commands to be used for:

- “Configuring Global RADIUS Parameters” on page 271
- “Restoring the Default Global RADIUS Configuration Parameters” on page 273
- “Displaying Global RADIUS Configuration Parameters” on page 274

3.4.12.9.2.1 Configuring Global RADIUS Parameters

To configure the global RADIUS configuration parameters to be used for all AAA clients, run the following command:

```
npu(config)# radius <[accessreq-retries <retransmissions>]
[accessreq-interval <timeout>] [nasid <nas-identifier>]
[timezone-offset <time-offset(0-86400)>] [mtu <framed mtu
size(1020-2000)>] [RadiusAtrbtTypeServiceProfileName
<AtrbtTypeId(1-255)>] [vlan-classf-bit-align
{msbShift|lsb}] [alrmAaaSwitchoverRetryFailThrshld(1-250)>]>
```



NOTE

You can display configuration information for global RADIUS parameters. For details, refer to [Section 3.4.12.9.2.3](#)



IMPORTANT

An error may occur if you provide an invalid value for any of these parameters. Refer the syntax description for more information about the appropriate values and format for configuring these parameters.

Command **npu(config)# radius <[accessreq-retries <retransmissions>] [accessreq-interval <timeout>]**
Syntax **[nasid <nas-identifier>] [timezone-offset <time-offset(0-86400)>] [mtu <framed mtu**
 size(1020-2000)>] [RadiusAtrbtTypeServiceProfileName <AtrbtTypeId(1-255)>]
 [alrmAaaSwitchoverRetryFailThrshld(1-250)>] [vlan-classf-bit-align {msbShift|lsb}]]>

Privilege
Level

10

Syntax
Description

Parameter	Description	Presence	Default Value	Possible Values
[accessreq-retries <retransmissions>]	Denotes the maximum number of times the AAA client can resend the access request.	Optional	3	0-5
[accessreq-interval <timeout>]	Denotes the interval, in seconds, after which the AAA client can resend the access request.	Optional	500	10-100000
[nasid <nas-identifier>]	Denotes the unique identifier of the ASNGW NAS. Sent in Access Request message only if configured. Should be in FQDN format.	Optional	null	String (up to 64 characters)
[timezone-offset <time-offset(0-86400)>]	Denotes the time zone offset, in seconds, from GMT at the NAS.	Optional	0	0-86400
[mtu <framed mtu size(1020-2000)>]	Denotes the MTU to be used for the AAA client functionality.	Optional	2000	1020-2000
[RadiusAtrbtTypeServiceProfileName <AtrbtTypeId(1-255)>]	Denotes the RADIUS attribute in which the ASN-GW shall expect to get the service profile name. For example, configure 11 if AAA uses Filter ID as the container of service profile name, Use only unassigned freetext-type RADIUS attributes.	Optional	11	1-255

[almAaaSwitchoverRetryFailThreshld (1-250)>]	Threshold to set alarm when the number of AAA switchover "unsuccessful access to primary + secondary" failed events for a measured period (PM interval of 15 minutes) exceeds the provisioned number.	Optional	250	1 - 250
[vlan-classf-bit-align {msbShift lsb}]	Defines how to transfer VLAN ID between R3 and R6: If msbShift is selected: a. When transferring classifier VID value from R3 side to R6 side, the binary value of the 12 least significant bits in R3 TLV will be copied and pasted as most significant bits in R6 TLV. b. When transferring classifier VID value from R6 to R3, the binary value of the 12 the most significant bits in R6 TLV will be copied and pasted as the 12 least significant bits in R3 TLV. if lsb is selected: The whole 16 bit value of the relevant TLV will be transferred without any change when transferring classifier VID value from R3 side to R6 side and from R6 to R3.	Optional	msbShift	■ msbShift ■ lsb

Command Global configuration mode
Modes

3.4.12.9.2.2 Restoring the Default Global RADIUS Configuration Parameters

To restore the default global RADIUS configuration used for AAA clients, run the following command:

```
npu(config)# no radius [accessreq-retries] [accessreq-interval]
[nasid] [timezone-offset] [mtu]
```

**NOTE**

Refer [Section 3.4.12.9.2.1](#) for a description and default values of these parameters.

Command Syntax	npu(config)# no radius [accessreq-retries] [accessreq-interval] [nasid] [timezone-offset] [mtu]
----------------	---

Privilege Level	10
-----------------	----

Command Modes	Global configuration mode
---------------	---------------------------

3.4.12.9.2.3 Displaying Global RADIUS Configuration Parameters

To display global RADIUS configuration parameters used for all AAA clients, run the following command:

npu# show radius

Command Syntax	npu# show radius
----------------	------------------

Privilege Level	1
-----------------	---

Display Format	TimeOut <value> accessReq-retries <value> NAS-ID <value> TimeZone Offset <value> framed MtuSize <value> Profile AtrbtType <value> alrmAaaSwitchoverRetryFailThreshld <value> VLAN Bit Alignment <value>
----------------	--

Command Modes	Global command mode
---------------	---------------------

3.4.12.10 Managing Service Groups

A service group is a group of MSs that are served by the same service provider or service flows that belong to the same service class.

The following service group types are supported:

- **IP:** This type of service group is used only for IP CS flows. Once service group is configured as type IP, additional IP allocation configuration is also required (such as DHCP mode, IP pool, IP Subnet, etc). This type of service group must be associated with either IP-IP (encapsulated IP packets) or VLAN type of R3 service interface. An IP service group can be configured to support time based or volume and time based accounting. In addition, an IP service group can be configured to support direct communication between MSs belonging to the service group.
- **VPWS-Transparent:** This type of service group is used only for VLAN CS flows. Once service group is configured as VPWS-Transparent type, IP allocation configuration is not required. This type of service group is not associated with any R3 service interface as vlan-tagged MS traffic is transferred transparently on the on the R3 interface. A VPWS-Transparent service group can be configured to support time based accounting.
- **VPWS-QinQ:** This type of service group is used only for VLAN CS flows. Once service group is configured as type VPWS-QinQ type, IP allocation configuration is not required. This type of service group is not associated with any R3 service interface as double-tagged MS traffic is transferred transparently on the on the R3 interface. The QinQ VLAN used by the MS should be received from the AAA server in Access-Accept messages. A VPWS-QinQ service group can be configured to support time based accounting.
- **VPWS-Mapped:** This type of service interface is intended for special needs were VLAN CS service flows from multiple MSs use the same VLAN ID. Once service group is configured as VPWS- Mapped type, IP allocation configuration is not required. This type of service group makes the mapping between a unique MS flow VLAN ID used on R3 interface and a CVID. The CVID can be missing. For this service group type a VLAN pool need to configured. The ASNGW will uniquely allocate a VLAN from the configured pool to each MS flow to be used on R3 interface. A VPWS-Mapped service group can be configured to support time based accounting.

You can configure up to 10 service groups, where each of the IP Service Groups is:

- Associated with a separate service IP or VLAN service interface.
- Configured as any one of the following:
 - » DHCP server that allocates an IP address to the MS from the local pool (in the non-HA mode).
 - » DHCP relay that obtains the IP address using an external DHCP server (in the non-HA mode).
 - » DHCP proxy for either of the following boot modes:
 - ◇ Non-HA mode: The DHCP proxy assigns the MS the IP address that was received from AAA in the MS profile (in FRAMED-IP attribute or R3 Descriptors) or
 - ◇ HA mode: The DHCP proxy assigns the MS, the IP address received in the MS profile or obtains the IP address from HA using the mobile IP.

**To configure a service group:**

- 1 Enable the service group configuration mode (refer to [Section 3.4.12.10.1](#))
- 2 You can now execute any of the following tasks:
 - » Configure the common parameters of an IP service group (refer to [Section 3.4.12.10.2](#))
 - » Enable/Disable the VLAN Interface of an IP Service Group (refer to [Section 3.4.12.10.3](#))
 - » Enable the service group DHCP operation mode and configure the DHCP server/proxy/relay-specific parameters (refer to [Section 3.4.12.10.4](#))
 - » Configure the parameters of a VPWS-Transparent Service Group (refer to [Section 3.4.12.10.5](#))
 - » Configure the parameters of a VPWS-QinQ Service Group (refer to [Section 3.4.12.10.6](#))
 - » Configure the parameters of a VPWS-Mapped Service Group (refer to [Section 3.4.12.10.7](#))

- » Terminate the service group configuration mode (refer to [Section 3.4.12.10.8](#))

In addition, you can, at any time, display configuration information (refer to [Section 3.4.12.10.10](#)) or delete an existing service group (refer to [Section 3.4.12.10.9](#)).

3.4.12.10.1 Enabling the Service Group Configuration Mode\ Creating a New Service Group

To configure the parameters for the service group, first enable the service group configuration mode. Run the following command to enable the service group configuration mode or create the service group.

```
npu(config)# srvc-grp <grp-alias> [ServiceGrpType {IP | VPWS-QinQ |  
VPWS-Transparent | VPWS-Mapped}]
```

If you use this command to create a new service group, the configuration mode for this group is automatically enabled after which you can configure or restore the default parameters for this service group.

After enabling the service group configuration mode, you can execute any of the following tasks:

- Configure the common parameters for an IP service group (refer to [Section 3.4.12.10.2](#))
- Enable/Disable the VLAN Interface of an IP Service Group (refer to [Section 3.4.12.10.3](#))
- Enable the service group operation mode and configure the DHCP server/proxy/relay-specific parameters (refer to [Section 3.4.12.10.4](#))
- Configure the parameters of a VPWS-Transparent Service Group (refer to [Section 3.4.12.10.5](#))
- Configure the parameters of a VPWS-Transparent Service Group (refer to [Section 3.4.12.10.6](#))
- Configure the parameters of a VPWS-Transparent Service Group (refer to [Section 3.4.12.10.7](#))

After executing these tasks, you can terminate the service group configuration mode (refer to [Section 3.4.12.10.8](#)).

**NOTE**

You can display configuration information for specific or all service groups. For details, refer to [Section 3.4.12.11.2](#).

Command Syntax **npu(config)# svc-grp** <grp-alias> [ServiceGrpType {IP | VPWS-QinQ | VPWS-Transparent | VPWS-Mapped}]

Privilege Level 10

Syntax Description

Parameter	Description	Presence	Default Value	Possible Values
svc-grp <grp-alias>	Denotes the group-alias of the service group for which the service group configuration mode is to be enabled. If you want to create a new service group, specify the group alias to be assigned to the service group.	Mandatory	N/A	String (1 to 30 characters)
[ServiceGrpType {IP VPWS-QinQ VPWS-Transparent VPWS-Mapped}]	The Service group's type.	Optional	IP	■ IP ■ VPWS-QinQ ■ VPWS-Transparent ■ VPWS-Mapped

Command Modes Global configuration mode

3.4.12.10.2 Configuring Common Parameters of an IP Service Group

After enabling the service group configuration mode for an IP service group, run the following command to configure common parameters for the service group:

npu(config-svcgrp)# config {[<svcif-alias> <service interface>] [<waitdhcp-holdtime> <timeout>] [<dhcp-ownaddr> <ipv4addr>]} |

```
{server|proxy|relay} | {[<acct (none|time|volumeTime)>]} | {[<ms-loop
(enable|disable)>]} | [acctInterimTmr <integer(0|5-1600)>]}
```

This commands comprises 5 sub-commands:

- 1 npu(config-srvgrp)# config {[srvcif-alias <service interface>]
[waitdhcp-holdtime <timeout>] [dhcp-ownaddr <ipv4addr>]}
- 2 npu(config-srvgrp)# config {server | proxy | relay}
- 3 npu(config-srvgrp)# config {[<acct (none | time | volumeTime)>]}
- 4 npu(config-srvgrp)# config {[<ms-loop (enable | disable)>]}
- 5 npu(config-srvgrp)# config {[acctInterimTmr <integer(0 | 5-1600)>]}



NOTE

You can display configuration information for the service group. For details, refer to [Section 3.4.12.11.2](#).



IMPORTANT

An error may occur if you provide an invalid value for any of these parameters. Refer the syntax description for more information about the appropriate values and format for configuring these parameters.

Command	npu(config-srvgrp)# config {[srvcif-alias <service interface>] [waitdhcp-holdtime <timeout>]
Syntax	[dhcp-ownaddr <ipv4addr>]} {server proxy relay} {[<acct (none time volumeTime)>]} {[<ms-loop (enable disable)>]} [acctInterimTmr <integer(0 5-1600)>]}

Privilege Level	10
--------------------	----

Syntax Description	
-----------------------	--

Parameter	Description	Presence	Default Value	Possible Values
[srvcif-alias <service interface>]	Denotes the pre-defined IP or VLAN service interface alias to be used as the data path for traffic towards the core network. Note that a Service Interface alias can be associated only to a single Service Group.	Mandatory	N/A	String

[waitdhcp-holdtime <timeout>]	Denotes the period, in seconds, for which the NPU waits for an IP address allocation trigger (MIP registration request / DHCP discover) from the MS. If you specify the value of this parameter as 0, no timer is started and the NPU will wait infinitely for the IP address allocation trigger.	Optional	0	0-86400
[dhcp-ownaddr <ipv4addr>]	Denotes the IPv4 address of the DHCP server/ relay/ proxy. Must be unique in the network. For a service group using a VLAN service interface, should be in same subnet with the Default Gateway configured for the service interface associated with the service group. Subnet mask is taken as the default subnet mask i.e 255.255.255.0. Note: In DHCP Server mode, the DHCP server IP address must be in the same subnet but outside the range allocated for users address pool as provisioned in the DHCP Server.	Mandatory	N/A	Valid IP Address
{server proxy relay }	Mode of IP address allocation used for subscribers: DHCP Server/ Proxy/ Relay.	Mandatory	N/A	☒ dhcp-server ☒ dhcp-proxy ☒ dhcp-relay

{acct {none time volume Time}}	The Accounting mode for the service interface: none: No accounting support. time: The ASN-GW send RADIUS Accounting Start/Stop Requests. The ASN-GW shall also send Interim Accounting requests to AAA server using RADIUS Accounting Interim messages on a preconfigured or negotiated interval. AAA server can send negotiated time interval in Access-Accept message. If ASN GW defined value (see acctInterimTmr below) is zero and there is no Acct-Interim-Interval in Access Accept, interim updates should be deactivated. volumeTime: Same as for time option above. In addition, this mode supports postpaid accounting by supporting IP Session Volume Based Accounting. The ASN-GW will report the cumulative volume counters for each MS IP Session. The counters will be collected per MS Service Flow and will be cumulated in order to get the MS IP Session counters.	Optional	time	☐ none ☐ time ☐ volumeTime
{ms-loop {enable disable}}	Denotes whether MS loopback (direct communication between two MSs belonging to the same service group) is enabled or disabled for the service interface	Optional	Disable	☐ Enable ☐ Disable

	[acctInterimTmr <integer(0 5-1600) >]	Applicable only if acct (see above) mode is set to either time or volumeTime. The default interval in minutes for Accounting Interim reports to be used if Acct-Interim-Interval is not received from the AAA server. Value "0" means interim reports are deactivated unless Acct-Interim-Interval is sent by the AAA server in Access Accept messages.	Optional	5	■ 0 ■ 5-1600
--	---	--	----------	---	------------------------------------

Command IP Service group configuration mode
Modes

3.4.12.10.3 Enabling/Disabling VLAN Service Interface for an IP Service Group

This command is applicable only for an IP service group associated with a VLAN service interface.

Run the following commands to enable/disable the creation of a data-path for a VLAN Service:

To enable: **npu(config-srvgrp)# set vlan-enable**

To disable: **npu(config-srvgrp)# no vlan-enable**



IMPORTANT

The default is **disabled**

Command npu(config-srvgrp)# set vlan-enable
Syntax npu(config-srvgrp)# no vlan-enable

Privilege Level 10

Command IP Service group configuration mode
Modes

3.4.12.10.4 Configuring the DHCP Server/Proxy/Relay



To configure the DHCP server/proxy/relay:

- 1 Enable the service group operation mode for DHCP server/relay/proxy (refer to [Section 3.4.12.10.4.1](#))
- 2 You can now execute one of the following tasks according to the selected DHCP mode:
 - » Configure the DHCP server (refer to [Section 3.4.12.10.4.2](#))
 - » Configure the DHCP proxy (refer to [Section 3.4.12.10.4.3](#))
 - » Configure the DHCP relay (refer to [Section 3.4.12.10.4.4](#))

3.4.12.10.4.1 Enabling the Service Group Operation Mode for DHCP Server//Proxy/Relay

Run the following command enable the DHCP (server/relay/proxy) configuration mode.

```
npu(config-srvgrp)# config {server|proxy|relay}
```

When you run this command, the DHCP server/proxy/relay configuration mode is enabled, after which you can execute the following tasks:

- Configure the DHCP server (refer to [Section 3.4.12.10.4.2](#))
- Configure the DHCP proxy (refer to [Section 3.4.12.10.4.3](#))
- Configure the DHCP relay (refer to [Section 3.4.12.10.4.4](#))



NOTE

You cannot modify the configured DHCP mode. To change the DHCP mode you should first delete the Service Group and configure it again.

Command Syntax	npu(config-srvgrp)# config {server proxy relay}
----------------	---

Privilege Level	10
-----------------	----

Syntax

Description

Parameter	Description	Presence	Default Value	Possible Values
{server proxy relay}	Indicates whether the service group operation mode is to be enabled for the DHCP server, proxy or relay.	Mandatory	N/A	■ server ■ proxy ■ relay

Command

Service group configuration mode

Modes

3.4.12.10.4.2 Configuring the DHCP Server

After enabling the service group operation mode for the DHCP server, you can execute any of the following tasks:

- [“Configuring DHCP Server Parameters” on page 284](#)
- [“Restoring Configuration Parameters for the DHCP Server” on page 288](#)
- [“Configuring Exclude IP Addresses for the DHCP Server” on page 288](#)
- [“Deleting Exclude IP Addresses for the DHCP Server” on page 289](#)



NOTE

Before executing these tasks, ensure that you have enabled the DHCP server configuration mode. For details, refer to [“Enabling the Service Group Operation Mode for DHCP Server / Proxy / Relay” on page 283](#).

3.4.12.10.4.2.1 Configuring DHCP Server Parameters

Run the following command to configure the DHCP server:

```
npu(config-srvgrp-dhcpserver)# config ([pool-minaddr <string>]
[pool-maxaddr <string>] [pool-subnet <string>] [dflt-gwaddr
<string>] [lease-interval <integer(24-4294967295)>]
[renew-interval <integer>] [rebind-interval <integer>]
[dnssrvr-addr <string>] [offerreuse-holdtime <integer>] [opt60
<string(30)>] [opt43 {[Name <string(64)>] [Value <string(64)>]}]
[Sname <string(64)>] [File <string(128)>] [dnssrvr-addr2 <string>])
```

**IMPORTANT**

An error may occur if you provide an invalid value for any of these parameters. Refer the syntax description for more information about the appropriate values and format for configuring these parameters.

Command npu(config-srvgrp-dhcpserver)# config ([pool-minaddr <string>] [pool-maxaddr <string>]
Syntax [pool-subnet <string>] [dflt-gwaddr <string>] [lease-interval <integer(24-4294967295)>]
 [renew-interval <integer>] [rebind-interval <integer>] [dnssrvr-addr <string>] [offerreuse-holdtime
 <integer>] [opt60 <string(30)>] [opt43 {[Name <string(64)>] [Value <string(64)>]}] [Sname
 <string(64)>] [File <string(128)>] [dnssrvr-addr2 <string>])

Privilege Level 10

Syntax Description

Parameter	Description	Presence	Default Value	Possible Values
[pool-minaddr <string>]	Denotes the minimum (lowest) IP address of the address pool to be used for address allocation for MSs from this Service Group. DHCP address in the pool shall not overlap with the DHCP address pool defined in an existing service group and with ip addresses of host interfaces (Bearer, External mgmt, Internal mgmt and Local mgmt).	Optional	0.0.0.0	Valid IP Address

[pool-maxaddr <string>]	Denotes the maximum (highest) IP address of the address pool configuration. DHCP address in the pool shall not overlap with the DHCP address pool defined in an existing service group and with ip addresses of host interfaces (Bearer, External mgmt, Internal mgmt and Local mgmt).	Optional	255.255.255.255	Valid IP Address
[pool-subnet <string>]	The IP subnet mask to be provided by local DHCP Service with IP address for MSs from this Service Group.	Optional	255.255.255.255	IP subnet
[dflt-gwaddr <string>]	IP address of Default Gateway to be provided by local DHCP Service with IP address for MS from this Service Group.	Optional	0.0.0.0 (none)	Valid IP Address
[lease-interval <integer(24-4294967 295)>]	Lease time in seconds of IP address allocated for MS from this Service Group.	Optional	86400	24-4294967295
[renew-interval <integer>]	Denotes the period, after which, the MS can request for renewal of the lease which has expired. Specify the value of this parameter as a percentage of the lease-interval parameter. The renew-interval must be lower than rebind-interval.	Optional	50	1-100
[rebind-interval <integer>]	Denotes the rebind interval maintained as a percentage of the lease interval. This is passed to the MS (DHCP client).	Optional	75	1-99

[dnssrvr-addr <string>]	IP Address of the first DNS Server to be provisioned to MS from this Group.	Optional	0.0.0.0 (none)	Valid IP Address
[offerreuse-holdtime <integer>]	Denotes the Offer Reuse time in seconds of IP address offered to MS from this Service Group.	Optional	5	1-120
[opt60 <string(30)>]	Configures option 60. An empty string (null) means that DHCP Option 60 is disabled.	Optional	null	String (up to 30 characters). Null (empty string) disables Option 60.
[opt43 {[Name <string(64)>]	Configures option 43 Name	Optional	Internet GatewayDevice. ManagementServer.URL	String (up to 64 characters)
[Value <string(64)>]	Configures option 43 Value	Optional	empty string	String (up to 64 characters)
[Sname <string(64)>]	Configures the server host name. This parameter is sent in dhcp-offer / dhcp-ack messages and may be used by certain CPEs.	Optional	empty string	String (up to 64 characters)
[File <string(128)>]	Configures the boot file name. This parameter is sent in dhcp-offer / dhcp-ack messages and may be used by certain CPEs.	Optional	empty string	String (up to 128 characters)
[dnssrvr-addr2 <string>]	IP Address of the second DNS Server to be provisioned to MS from this Group.	Optional	0.0.0.0 (none)	Valid IP address

Command Service Group-DCHP server configuration mode
Modes

3.4.12.10.4.2.2 Restoring Configuration Parameters for the DHCP Server

Run the following command to restore the default values of one or several DHCP server parameters. This command can be used to delete the DNS server address configuration (if specified).

```
npu(config-srvgrp-dhcpserver)# no [lease-interval]
[renew-interval] [rebind-interval] [dnssrvr-addr]
[offerreuse-holdtime] [dnssrvr-addr2]
```

Specify one or several parameters to restore the specified parameters to their default values. Do not specify any parameter to restore all of these parameters to their default values.



NOTE

Refer to [Section 3.4.12.10.4.2.1](#) for a description and default values of these parameters.

Command Syntax	<code>npu(config-srvgrp-dhcpserver)# no [lease-interval] [renew-interval] [rebind-interval] [dnssrvr-addr] [offerreuse-holdtime] [dnssrvr-addr2]</code>
Privilege Level	10
Command Modes	Service group-DHCP server configuration mode

3.4.12.10.4.2.3 Configuring Exclude IP Addresses for the DHCP Server

Run the following command to configure exclude IP addresses for the DHCP server:

```
npu(config-srvgrp-dhcpserver)# exclude-addr <no. of Addrs (1-9)>
<ipv4addr> [<ipv4addr>] ...
```

In each command you may add up to 9 IP addresses to be excluded. The total number of excluded IP addresses is up to a maximum of 16384.



IMPORTANT

An error may occur if you provide an invalid IP address. Refer the syntax description for more information about the appropriate values and format for configuring this parameters.

Command **npu(config-srvgrp-dhcpserver)# exclude-addr** <no. of Addrs (1-9)> <ipv4addr> [<ipv4addr>]
 Syntax

Privilege 10
 Level

Syntax
 Description

Parameter	Description	Presence	Default Value	Possible Values
<no. of Addrs (1-9)>	The number of IP addresses to be excluded	Mandatory	N/A	1-9
<ipv4addr>	Denotes the exclude IP address that will not be assigned to an MS by the DHCP server. The number of IP address entries must match the value defined by the no. of Addrs parameter.	Mandatory	N/A	Valid IP address

Command Service group-DCHP server configuration mode
 Modes

3.4.12.10.4.2.4 Deleting Exclude IP Addresses for the DHCP Server

Run the following command to delete one or several excluded IP addresses for the DHCP server:

npu(config-srvgrp-dhcpserver)# no exclude-addr <no. of Addrs (1-9)> <ipv4addr> [<ipv4addr>] ...

Run the following command (without specifying the parameters) to delete all excluded IP addresses for the DHCP server:

npu(config-srvgrp-dhcpserver)# no exclude-addr

The deleted exclude IP addresses are no longer excluded when the DHCP server allocates the IP addresses. That is, the server may allocate these IP addresses to the MS.

Command **npu(config-srvgrp-dhcpserver)# no exclude-addr** no. of Addrs (1-9)> <ipv4addr>
 Syntax [<ipv4addr>] ...

Privilege Level 10

Syntax Description

Parameter	Description	Presence	Default Value	Possible Values
<no. of Addrs (1-9)>	The number of excluded IP addresses to be deleted. Do not specify any value if you want to remove all the exclude IP addresses specified for that DHCP server.	Optional	N/A	1-9
<ipv4addr>	Denotes an IP address that you want to remove from the list of exclude IP addresses. The number of IP address entries must match the value defined by the no. of Addrs parameter. Do not specify any value if you want to remove all the exclude IP addresses specified for that DHCP server.	Optional	N/A	Valid IP address

Command Modes Service group-DHCP server configuration mode

3.4.12.10.4.2.5 Terminating the DHCP Server Configuration Mode

Run the following command to terminate the DHCP server configuration mode:

npu(config-srvgrp-dhcpserver)# exit

Command Syntax npu(config-srvgrp-dhcpserver)# exit

Privilege Level 10

Command	Service group-DHCP server configuration mode
Modes	

3.4.12.10.4.3 Configuring the DHCP Proxy

After enabling the service group operation mode for the DHCP proxy, you can execute the following tasks:

- “Specifying DHCP Proxy Configuration Parameters” on page 291
- “Restoring the Default Configuration Parameters for the DHCP Proxy” on page 294
- “Terminating the DHCP Proxy Configuration Mode” on page 295

3.4.12.10.4.3.1 Specifying DHCP Proxy Configuration Parameters

Run the following command to configure the DHCP proxy:

```
npu(config-srvgrp-dhcp-proxy)# config ([offer-reuse-holdtime
<integer>] [lease-interval <integer>] [dnssrvr-addr <string>]
[pool-subnet <string>] [dflt-gwaddr <string>] [renew-interval
<integer>] [rebind-interval <integer>] [opt60 <string(30)>] [opt43
{[Name <string(64)>] [Value <string(64)>]}] [Sname <string(64)>]
[File <string(128)>]) [dnssrvr-addr2 <string>]
```



IMPORTANT

An error may occur if you provide an invalid value for any of these parameters. Refer the syntax description for more information about the appropriate values and format for configuring these parameters.

Command	npu(config-srvgrp-dhcp-proxy)# config ([offer-reuse-holdtime <integer>] [lease-interval <integer>]
Syntax	[dnssrvr-addr <string>] [pool-subnet <string>] [dflt-gwaddr <string>] [renew-interval <integer>] [rebind-interval <integer>] [opt60 <string(30)>] [opt43 {[Name <string(64)>] [Value <string(64)>]}] [Sname <string(64)>] [File <string(128)>] [dnssrvr-addr2 <string>])

Privilege Level	10
-----------------	----

Syntax
Description

Parameter	Description	Presence	Default Value	Possible Values
[offerreuse-holdtime <integer>]	Denotes the duration in seconds within which the MS should send a DHCP request to accept the address sent by the NPU. If the MS does not accept the address within this period, the MS is deregistered.	Optional	5	0-120
[lease-interval <integer>]	Lease time in seconds of IP address allocated for MS from this Service Group. In the Proxy mode, this value is used if appropriate parameter is not received in RADIUS Access-Accept.	Optional	86400	24 - 4294967295
[dnssvr-addr <string>]	IP Address of the first DNS Server to be provisioned to MS from this Group. In the Proxy mode, this value is used if appropriate parameter is not received in RADIUS Access-Accept.	Optional	0.0.0.0 (none)	Valid IP Address
[pool-subnet <string>]	The IP subnet mask to be provided by local DHCP Service with IP address for MSs from this Service Group. In the Proxy mode, this value is used if appropriate parameter is not received in RADIUS Access-Accept.	Optional	255.255.255.255	IP subnet

[dflt-gwaddr <string>]	IP address of Default Gateway to be provided by local DHCP Service with IP address for MS from this Service Group. In the Proxy mode, this value is used if appropriate parameter is not received in RADIUS Access-Accept.	Optional	0.0.0.0 (none)	Valid IP Address
[renew-interval <integer>]	Denotes the period, after which, the MS can request for renewal of the lease which has expired. Specify the value of this parameter as a percentage of the lease-interval parameter. This value is used if appropriate parameter is not received in RADIUS Access-Accept.	Optional	50	1-100
[rebind-interval <integer>]	Denotes the rebind interval maintained as a percentage of the lease interval. This is passed to the MS (DHCP client). This value is used if appropriate parameter is not received in RADIUS Access-Accept.	Optional	75	1-99
[opt60 <string(30)>]	Configures option 60.	Optional	null	String (up to 30 characters)
[opt43 {[Name <string(64)>]	Configures option 43 Name	Optional	Internet Gateway Device. ManagementServer.URL	String (up to 64 characters)
[Value <string(64)>]	Configures option 43 Value	Optional	empty string	String (up to 64 characters)

[Sname <string(64)>]	Configures the proxy host name. This parameter is sent in dhcp-offer / dhcp-ack messages and may be used by certain CPEs.	Optional	empty string	String (up to 64 characters)
[File <string(128)>]	Configures the boot file name. This parameter is sent in dhcp-offer / dhcp-ack messages and may be used by certain CPEs.	Optional	empty string	String (up to 128 characters)
[dnssrvr-addr2 <string>]	IP Address of the second DNS Server to be provisioned to MS from this Group. In the Proxy mode, this value is used if appropriate parameter is not received in RADIUS Access-Accept.	Optional	0.0.0.0 (none)	Valid IP address

Command Service group-DHCP proxy configuration mode
Modes

3.4.12.10.4.3.2 Restoring the Default Configuration Parameters for the DHCP Proxy

Run the following command to restore the default values of one or several DHCP proxy parameters. This command can also be used to delete the configured DNS server address (if specified).

```
npu(config-srvgrp-dhcp-proxy)# no [offer-reuse-holdtime]
[lease-interval] [dnssrvr-addr] [renew-interval] [rebind-interval]
[dnssrvr-addr2]
```

Specify one or several parameters to restore the specified parameters to their default values. Do not specify any parameter to restore all of these parameters to their default values.



NOTE

Refer [Section 3.4.12.10.4.3.1](#) for a description and default values of these parameters.

Command Syntax	npu(config-srvgrp-dhcproxy)# no [offerreuse-holdtime] [lease-interval] [dnssrvr-addr][renew-interval] [rebind-interval] [dnssrvr-addr2]
----------------	---

Privilege Level	10
-----------------	----

Command Modes	Service group-DHCP proxy configuration mode
---------------	---

3.4.12.10.4.3 Terminating the DHCP Proxy Configuration Mode

Run the following command to terminate the DHCP proxy configuration mode:

npu(config-srvgrp-dhcproxy)# exit

Command Syntax	npu(config-srvgrp-dhcproxy)# exit
----------------	-----------------------------------

Privilege Level	10
-----------------	----

Command Modes	Service group-DHCP proxy configuration mode
---------------	---

3.4.12.10.4.4 Configuring the DHCP Relay

After enabling the service group operation mode for the DHCP relay, you can execute any of the following tasks:

- [“Configuring the DHCP Relay Parameters” on page 295](#)
- [“Terminating the DHCP Relay Configuration Mode” on page 301](#)

3.4.12.10.4.4.1 Configuring the DHCP Relay Parameters

Run the following command to configure the DHCP server address for the DHCP relay:

npu(config-srvgrp-dhcprelay)# config ([server-addr <ipV4Addr>] [{EnableOpt82**|**DisableOpt82**}])**

**IMPORTANT**

An error may occur if you provide an invalid value for the DHCP server address. Refer to the syntax description for more information about the appropriate values and format for configuring this parameters.

Command **npu(config-srvgrp-dhcprelay)# config ([server-addr <ipV4Addr>]**
 Syntax **[{EnableOpt82 | DisableOpt82}]**

Privilege Level 10

Syntax Description

Parameter	Description	Presence	Default Value	Possible Values
[server-addr <ipV4Addr>]	Denotes the IP address of the external DHCP server. Must be configured to a valid IP address.	Optional	0.0.0.0	Valid IP Address
[{EnableOpt82 DisableOpt82}]	Denotes whether DHCP option 82 is enabled or disabled.	Optional	Disable Opt82	■ EnableOpt82 ■ DisableOpt82

Command Modes Service group-DHCP relay configuration mode

3.4.12.10.4.2 Configuring the DHCP Relay Option 82 Parameters

If Option 82 for the DHCP Relay is enabled, run the following command to configure suboptions of option 82 of DHCP messages:

```
npu(config-srvgrp-dhcprelay-Opt82)# config ([Subopt1value
{Default | MSID | BSID | NASID | NASIP | Full-NAI | Domain | asciiMsID | asciiBsID | asciiBsMac | AsciiFrStrng <string(32)> | BinFrStrng <string(32)>}] [Subopt2value
{Default | MSID | BSID | NASID | NASIP | Full-NAI | Domain | asciiMsID | asciiBsID | asciiBsMac | AsciiFrStrng <string(32)> | BinFrStrng <string(32)>}] [Subopt6value
{Default | MSID | BSID | NASID | NASIP | Full-NAI | Domain | AsciiFrStrng <string(32)> | BinFrStrng <string(32)>}] [{Subopt7value [service-type]
[vendor-specific] [session-timeout]}] [{EnableUnicast | DisableUnicast}])
```



IMPORTANT

- For DhcpRlOpt82SubOpt1BinFrstrng value, enter hex string without spaces.
- If Opt82Unicast is enabled then DHCP relay agent appends option 82 to all DHCP messages (unicast and broadcast).
- If Opt82Unicast is disabled (default) then DHCP relay agent appends option 82 only to broadcast DHCP request messages.

Command Syntax	<pre>npu(config-srvgrp-dhcprelay-Opt82)# config ([Subopt1value {Default MSID BSID NASID NASIP Full-NAI Domain asciiMsID asciiBsID asciiBsMac AsciiFrStrng <string(32)> BinFrStrng <string(32)>}] [Subopt2value {Default MSID BSID NASID NASIP Full-NAI Domain asciiMsID asciiBsID asciiBsMac AsciiFrStrng <string(32)> BinFrStrng <string(32)>}] [Subopt6value {Default MSID BSID NASID NASIP Full-NAI Domain AsciiFrStrng <string(32)> BinFrStrng <string(32)>}] [{Subopt7value [service-type] [vendor-specific] [session-timeout]}] [{EnableUnicast DisableUnicast}])</pre>
Privilege Level	10

Syntax
Description

Parameter	Description	Presence	Default Value	Possible Values
[Subopt1value {Default MSID BSID NASID NASIP Full-NAI Domain asciiMsID asciiBsID asciiBsMac AsciiFrStrng <string(32)> BinFrStrng <string(32)>}]	Configures the suboption 1 (Agent Circuit ID) of DHCP option 82. For AsciiFrStrng (string enter up to 32 characters, For BinFrStrng (string enter a string of up to 32 hexadecimal digits (no spaces).	Optional	Not Set	■ Default ■ MSID ■ BSID ■ NASID ■ NASIP ■ Full-NAI ■ Domain ■ asciiMsID ■ asciiBsID ■ asciiBsMac ■ AsciiFrStrng (string32) ■ BinFrStrng (string32)

	[Subopt2value {Default MSID BSID NASID NASIP Full-NAI Domain asciiMsID asciiBsID asciiBsMac AsciiFrStrng <string(32)> BinFrStrng <string(32)>}]	Configures the suboption 2 (Agent Remote ID) of DHCP option 82. For AsciiFrStrng (string enter up to 32 characters, For BinFrStrng (string enter a string of up to 32 hexadecimal digits (no spaces).	Optional	Not Set	■ Default ■ MSID ■ BSID ■ NASID ■ NASIP ■ Full-NAI ■ Domain ■ asciiMsID ■ asciiBsID ■ asciiBsMac ■ AsciiFrStrng (string32) ■ BinFrStrng (string32)
	[Subopt6value {Default MSID BSID NASID NASIP Full-NAI Domain AsciiFrStrng <string(32)> BinFrStrng <string(32)>}]	Configures the suboption 6 (Agent Subscriber ID) of DHCP option 82. For AsciiFrStrng (string enter up to 32 characters, For BinFrStrng (string enter a string of up to 32 hexadecimal digits (no spaces).	Optional	Not Set	■ Default ■ MSID ■ BSID ■ NASID ■ NASIP ■ Full-NAI ■ Domain ■ AsciiFrStrng (string32) ■ BinFrStrng (string32)

	[Subopt7value [service-type] [vendor-specific] [session-timeout]]	Configures the suboption 7 of DHCP option 82. Allows enabling/disabling the use of suboption 7 by specifying it. In addition, allows enabling/disabling the following attributes (by specifying attributes to be enabled) if suboption 7 is enabled: ■ service-type (attribute 6) ■ vendor-specific (attribute 26) ■ session-timeout (attribute 27)	Optional		
	[EnableUnicast DisableUnicast]]	Indicates whether the Unicast parameter is enabled or disabled.	Optional	Disable	■ Enable ■ Disable

Command Mode Service group-DHCP relay-option 82 configuration mode

3.4.12.10.4.4 Removing the DHCP Relay suboption values

Run the following command to remove one, several or all of the Suboption values configured by the user for DHCP Option 82.

```
npu(config-srvgrp-dhcprelay-opt82)# no [Subopt1value] [Subopt2value]
[Subopt6value] [Subopt7value]
```

Command Syntax npu(config-srvgrp-dhcprelay-opt82)# no [Subopt1value] [Subopt2value] [Subopt6value] [Subopt7value]

Privilege Level 10

Syntax
Description

Parameter	Description	Presence	Default Value	Possible Values
no [Subopt1value] [Subopt2value] [Subopt6value] [Subopt7value]	Indicates the removal status of DHCP Option 82 suboptions. If no suboption is specified, the values of all suboptions will be removed.	Optional	N/A	N/A

Command Mode Service group-DHCP relay-Option 82 configuration mode

3.4.12.10.4.4 Terminating the DHCP Relay Configuration Mode

Run the following command to terminate the DHCP relay configuration mode for this service group:

npu(config-srvgrp-dhcprelay)# exit

Command Syntax npu(config-srvgrp-dhcprelay)# exit

Privilege Level 10

Command Modes Service group-DHCP relay configuration mode

3.4.12.10.5 Configuring the Parameters of a VPWS-Transparent Service Group

After enabling the service group configuration mode for a VPWS-Transparent service group, run the following command to configure the accounting parameters for the service group:

npu(config-srvgrp-VPWS)# config {acct {none|time} | acctInterimTmr <integer(0|5-1600)>}



NOTE

You can display configuration information for the service group. For details, refer to [Section 3.4.12.11.2](#).

Command npu(config-srvgrp)# config {acct {none|time} | acctInterimTmr <integer(0|5-1600)>}

Syntax

Privilege 10

Level

Syntax

Description

Parameter	Description	Presence	Default Value	Possible Values
{acct {none time}}	The Accounting mode for the service interface: none: No accounting support. time: The ASN-GW send RADIUS Accounting Start/Stop Requests. The ASN-GW shall also send Interim Accounting requests to AAA server using RADIUS Accounting Interim messages on a preconfigured or negotiated interval. AAA server can send negotiated time interval in Access-Accept message. If ASN GW defined value (see acctInterimTmr below) is zero and there is no Acct-Interim-Interval in Access Accept, interim updates should be deactivated.	Optional	time	■ none ■ time

	[acctInterimTmr <integer(0 5-1600) >]	Applicable only if acct (see above) mode is set to time. The default interval in minutes for Accounting Interim reports to be used if Acct-Interim-Interval is not received from the AAA server. Value "0" means interim reports are deactivated unless Acct-Interim-Interval is sent by the AAA server in Access Accept messages.	Optional	5	☐ 0 ☐ 5-1600
--	---------------------------------------	---	----------	---	---

Command Modes
VPWS-Transparent Service group configuration mode

3.4.12.10.6 Configuring the Parameters of a VPWS-QinQ Service Group

After enabling the service group configuration mode for a VPWS-QinQ service group, run the following command to configure the accounting parameters for the service group:

```
npu(config-srvgrp-VPWS)# config {acct {none|time} | acctInterimTmr <integer(0|5-1600)>}
```



NOTE

You can display configuration information for the service group. For details, refer to [Section 3.4.12.11.2](#).

Command Syntax
npu(config-srvgrp)# config {acct {none|time} | acctInterimTmr <integer(0|5-1600)>}

Privilege Level
10

Syntax
Description

Parameter	Description	Presence	Default Value	Possible Values
{acct {none time}}	The Accounting mode for the service interface: none: No accounting support. time: The ASN-GW send RADIUS Accounting Start/Stop Requests. The ASN-GW shall also send Interim Accounting requests to AAA server using RADIUS Accounting Interim messages on a preconfigured or negotiated interval. AAA server can send negotiated time interval in Access-Accept message. If ASN GW defined value (see acctInterimTmr below) is zero and there is no Acct-Interim-Interval in Access Accept, interim updates should be deactivated.	Optional	time	■ none ■ time
[acctInterimTmr <integer(0 5-1600) >]	Applicable only if acct (see above) mode is set to time. The default interval in minutes for Accounting Interim reports to be used if Acct-Interim-Interval is not received from the AAA server. Value "0" means interim reports are deactivated unless Acct-Interim-Interval is sent by the AAA server in Access Accept messages.	Optional	5	■ 0 ■ 5-1600

Command Modes
VPWS-QinQ Service group configuration mode

3.4.12.10.7 Configuring the Parameters of a VPWS-Mapped Service Group

After enabling the service group configuration mode for a VPWS-Mapped service group, you can configure the following parameters for the service group:

Accounting parameters (see [Section 3.4.12.10.7.1](#))

VID Map Range parameters (see [Section 3.4.12.10.7.2](#))

3.4.12.10.7.1 Configuring the Accounting Parameters of a VPWS-Mapped Service Group

run the following command to configure the accounting parameters for the service group:

```
npu(config-srvgrp-VPWS-Mapped)# config {acct {none|time} |  
acctInterimTmr <integer(0|5-1600)>}
```



NOTE
You can display configuration information for the service group. For details, refer to [Section 3.4.12.11.2](#).

Command Syntax	npu(config-srvgrp-VPWS-Mapped)# config {acct {none time} acctInterimTmr <integer(0 5-1600)>}														
Privilege Level	10														
Syntax Description	<table><tr><th>Parameter</th><th>Description</th><th>Presence</th><th>Default Value</th><th>Possible Values</th></tr><tr><td></td><td></td><td></td><td></td><td></td></tr></table>					Parameter	Description	Presence	Default Value	Possible Values					
Parameter	Description	Presence	Default Value	Possible Values											

{acct {none time}}	The Accounting mode for the service interface: none: No accounting support. time: The ASN-GW sends RADIUS Accounting Start/Stop Requests. The ASN-GW also sends Interim Accounting requests to AAA server using RADIUS Accounting Interim messages on a preconfigured or negotiated interval. AAA server can send negotiated time interval in Access-Accept message. If ASN GW defined value (see acctInterimTmr below) is zero and there is no Acct-Interim-Interval in Access Accept, interim updates should be deactivated.	Optional	time	■ none ■ time
[acctInterimTmr <integer(0 5-1600) >]	Applicable only if acct (see above) mode is set to time. The default interval in minutes for Accounting Interim reports to be used if Acct-Interim-Interval is not received from the AAA server. Value "0" means interim reports are deactivated unless Acct-Interim-Interval is sent by the AAA server in Access Accept messages.	Optional	5	■ 0 ■ 5-1600

Command Modes
VPWS-Mapped Service group configuration mode

3.4.12.10.7.2 Configuring the VID Map Range Parameters of a VPWS-Mapped Service Group

run the following commands to configure the vid-map-range parameters for the service group:

To configure the start vlan id run the command:

```
npu(config-srvgrp-VPWS-Mapped)# config vid-map-range-start vlan-id
<size(1-4094)>.
```

To configure the end vlan id run the command:

```
npu(config-srvgrp-VPWS-Mapped)# config vid-map-range-end vlan-id
<size(1-4094)>.
```



IMPORTANT

When creating a new VPWS-Mapped service group, both start vlan-id and end vlan-id must be defined.



NOTE

You can display configuration information for the service group. For details, refer to [Section 3.4.12.11.2](#).

Command
Syntax

```
npu(config-srvgrp-VPWS-Mapped)# config vid-map-range-start vlan-id <size(1-4094)>
npu(config-srvgrp-VPWS-Mapped)# config vid-map-range-end vlan-id <size(1-4094)>
```

Privilege
Level

10

Syntax
Description

Parameter	Description	Presence	Default Value	Possible Values
vid-map-range-start vlan-id <size(1-4094)>	The start value of the range of VLAN IDs for mapping. None of the value within the range shall overlap with any existing infrastructure (host interfaces) VLAN IDs. None of the value within the range shall overlap with VID mapping ranges of other existing Service Groups	Mandatory	N/A	1-4094

vid-map-range-end vlan-id <size(1-4094)>	The start value of the range of VLAN IDs for mapping. Cannot be lower than vid-map-range-start vlan-id None of the value within the range shall overlap with any existing infrastructure (host interfaces) VLAN IDs. None of the value within the range shall overlap with VID mapping ranges of other existing Service Groups	Mandatory	N/A	1-4094
--	---	-----------	-----	--------

Command VPWS-Mapped Service group configuration mode
Modes

3.4.12.10.8 Terminating the Service Group Configuration Mode

Run the following command to terminate the service group configuration mode:

npu(config-srvgrp)# exit

npu(config-srvgrp-VPWS)# exit

npu(config-srvgrp-VPWS-Mapped)# exit

Command npu(config-srvgrp)# exit
Syntax npu(config-srvgrp-VPWS)# exit
 npu(config-srvgrp-VPWS-Mapped)# exit

Privilege 10
Level

Command IP/VPWS-Transparent/VPWS-QinQ/VPWS-Mapped Service group configuration mode
Modes

3.4.12.10.9 Deleting a Service Group

You can, at any time, run the following command to delete a service group:

npu(config)# no srvgrp <grp-alias>

**NOTE**

A Service Group cannot be deleted if it is assigned to a Service Flow. For details refer to [“Configuring Service Flows” on page 314](#).

To delete a VLAN service group (associated with a VLAN service interface), first execute the "no vlan-enable" command (refer to [Section 3.4.12.10.3](#)).

Command **npu(config)# no srvc-grp <grp-alias>**
Syntax

Privilege Level 10

Syntax Description

Parameter	Description	Presence	Default Value	Possible Values
<grp-alias>	Denotes the group-alias for which the service group to be deleted.	Mandatory	N/A	String

Command Modes Global configuration mode

3.4.12.10.10 Displaying Configuration Information for the Service Group

To display configuration information for one service group or for all service groups, run the following command:

npu# show srvc-grp [<grp-alias>]

Command **npu# show srvc-grp [<grp-alias>]**
Syntax

Privilege Level 1

Syntax
Description

Parameter	Description	Presence	Default Value	Possible Values
[<grp-alias>]	Denotes the group-alias for which the service group to be displayed. If no grp-alias is specified, the parameters of all service groups will be displayed.	Optional	N/A	String

Display
Format

According to Service Group type and (for IP Service Group) the configured DHCP mode.

3.4.12.11 Configuring the Service Flow Authorization Functionality

The Service Flow Authorization (SFA) functionality handles creation/maintenance of pre-provisioned service flows for MS. It maps the AAA parameters (service profile name) received from the AAA server to pre-configured WiMAX-specific QoS parameters in the NPU. The SFA functionality enables you to configure multiple service profiles with multiple service flows and classification rules.

This section describes the commands to be used for:

- [“Configuring the SFA PHS Functionality” on page 310](#)
- [“Displaying Configuration Information for the SFA PHS Functionality” on page 311](#)
- [“Configuring Service Profiles” on page 311](#)
- [“Configuring Classification Rules” on page 330](#)

3.4.12.11.1 Configuring the SFA PHS Functionality

To configure the SFA functionality with respect to PHS Rules, run the following command:

To enable PHS: `npu(config)# sfa phs-enable`

To disable PHS: `npu(config)# no sfa phs-enable`

The default configuration is PHS Disable.

**NOTE**

You can display configuration information for the SFA functionality. For details, refer [Section 3.4.12.11.2](#).

For details on PHS Rules, refer to [“Configuring PHS Rules” on page 362](#).

Command	npu(config)# sfa phs-enable
Syntax	npu(config)# no sfa phs-enable

Privilege Level	10
-----------------	----

Command Modes	Global configuration mode
---------------	---------------------------

3.4.12.11.2 Displaying Configuration Information for the SFA PHS Functionality

To display the current configuration information for the SFA PHS functionality, run the following command:

npu# show sfa

Command Syntax	npu# show sfa
----------------	---------------

Privilege Level	1
-----------------	---

Display Format	SFA Configuration : PHS <Enable/Disable>
----------------	---

Command Modes	Global command mode
---------------	---------------------

3.4.12.11.3 Configuring Service Profiles

The NPU allows for guaranteed end-to-end QoS for user traffic across the ASN. The QoS approach is connection-oriented, whereby user traffic is classified into "service flows." A service flow is a unidirectional stream of packets, either in the

downlink or uplink direction, associated with a certain set of QoS requirements such as maximum latency. The QoS requirements for service flows are derived from "service profiles" defined by the operator. A service profile is a set of attributes shared by a set of service flows. For instance, an operator might define a service profile called "Internet Gold" that will include QoS and other definitions to be applied to service flows associated with users subscribed to the operator's "Internet Gold" service package.

The factory default configuration includes an 'empty' (no defined Service Flows) Service Profile with the name Default. If enabled, it will be used if profile descriptor is missing in service provisioning or if received profile descriptor is disabled (unauthenticated mode). Up to 63 additional Service Profiles may be created.



To configure one or more service profiles:

- 1 Enable the service profile configuration mode (refer to [Section 3.4.12.11.3.1](#))
- 2 You can now execute any of the following tasks:
 - » Configure the parameters for this service profile (refer to [Section 3.4.12.11.3.2](#))
 - » Manage service flow configuration for this service profile (refer to [Section 3.4.12.11.3.3](#))
 - » Delete service flows (refer to [Section 3.4.12.11.3.3.7](#))
- 3 Terminate the service profile configuration mode (refer to [Section 3.4.12.11.3.4](#))

You can, at any time, display configuration information (refer to [Section 3.4.12.11.3.5](#)) or delete an existing service profile (refer to [Section 3.4.12.11.3.6](#)).

3.4.12.11.3.1 Enabling the Service Profile Configuration Model Creating a New Service Profile

To configure the parameters for a service profile, first enable the service profile configuration mode. Run the following command to enable the service profile configuration mode. You can also use this command to create a new service profile.

```
npu(config)# srvc-profile <profile-name> [dgwPrfl]
```

**NOTE**

The dgwPrfl option is for future use. Do not use this option. In the rest of this section this option will be ignored.

If you use this command to create a new service profile, the configuration mode for this rule is automatically enabled, after which you can execute any of the following tasks:

- Configure the parameters for this service profile (refer to [Section 3.4.12.11.3.2](#))
- Manage service flow configuration for this service profile (refer to [Section 3.4.12.11.3.3](#))
- Delete service flows (refer to [Section 3.4.12.11.3.3.7](#))

After you have executed these tasks, terminate the service profile configuration mode (refer to [Section 3.4.12.11.3.4](#)) to return to the service group configuration mode.

Command **npu(config)# svc-profile** <profile-name>
Syntax

Privilege Level 10

Syntax Description

Parameter	Description	Presence	Default Value	Possible Values
<profile-name>	Denotes the name of the service profile for which the configuration mode is to be enabled. If you are creating a new service profile, specify the name of the new service profile. The configuration mode is automatically enabled for the new service profile.	Mandatory	N/A	String (1 to 30 characters)

Command	Global configuration mode
Modes	

3.4.12.11.3.2 Enabling/Disabling the Service Profile

After enabling the service profile configuration mode, run the following command to enable this service profile:

```
npu(config-srvcpfrfl)# config profile-enable
```

A service profile can be enabled only if at least one service flow is configured.

To disable this service profile, run the following command:

```
npu(config-srvcpfrfl)# no profile-enable
```

The default mode is Disabled.



NOTE

You can display configuration information for specific or all service profiles. For details, refer to [Section 3.4.12.11.3.5](#).

Command	<code>npu(config-srvcpfrfl)# config profile enable</code>
Syntax	<code>npu(config-srvcpfrfl)# no profile enable</code>

Privilege Level	10
-----------------	----

Command Modes	Service profile configuration mode
---------------	------------------------------------

3.4.12.11.3.3 Configuring Service Flows

Service flows are unidirectional stream of packets, either in the downlink or uplink direction, associated with a certain set of QoS requirements such as maximum latency and minimum rate. Based on certain classification rules, service flows are transported over the R1 air interface in 802.16e connections, identified by connection IDs, and identified by GRE keys over the R6 interface in GRE tunnels. In addition, the ASN-GW can mark outgoing traffic in the R3 interface for further QoS processing within the CSN.

The system supports two types of service flows according to the convergence sublayer (CS) type: IP CS and VLAN CS. An IP CS service flow can be associated only with an IP service group. A VLAN CS service flow can be associated only with a VPWS (Transparent/QinQ/Mapped) service group. Typically VLAN CS service flows should be managed (created/modified/deleted) only by the AAA server. However, to support special needs, it is possible to define VLAN CS service flows for the Default Service Profile.

Up to 12 Service Flows can be defined for each Service Profile.



After enabling the service profile configuration mode, execute the following tasks to configure service flows within this service profile:

- 1 Enable the service flow configuration mode (refer to [Section 3.4.12.11.3.3.1](#))
- 2 You can now execute any of the following tasks:
 - » Configure the parameters for this service flow (refer to [Section 3.4.12.11.3.3.2](#))
 - » Restore the default parameters for this service flow (refer to [Section 3.4.12.11.3.3.3](#))
 - » Configure uplink/downlink classification rule names (refer to [Section 3.4.12.11.3.3.4](#))
- 3 Terminate the service flow configuration mode (refer to [Section 3.4.12.11.3.3.6](#))

You can, at any time delete an existing service flow (refer to [Section 3.4.12.11.3.3.7](#)).

[3.4.12.11.3.3.1 Enabling the Service Flow Configuration Model Creating a New Service Flow](#)

To configure the parameters for a service flow, first enable the service flow configuration mode. Run the following command to enable the service flow configuration mode. You can also use this command to create a new service flow.

```
npu(config-srvcprfl)# flow [<flow-id (1-255)>] [grp-alias
<srvc-grp-alias>] [if-alias <string>] [mcast-sfid <integer(0-65535)>
{[mcastipv4add <string(15)>]}] [<string>]
```

**NOTE**

The `mcast-sfid` and `mcastipv4add` parameter are for future use with a DGW profile (not supported in the current release). Do not use these parameters. In the following sections these parameters will be ignored.

If you use this command to create a new service flow, the configuration mode for this service flow is automatically enabled, after which you can execute any of the following tasks:

- Configure the parameters for this service flow (refer to [Section 3.4.12.11.3.3.2](#))
- Restore the default parameters for this service flow (refer to [Section 3.4.12.11.3.3.3](#))
- Configure uplink/downlink classification rule names (refer to [Section 3.4.12.11.3.3.4](#))

After you have executed these tasks, you can terminate the service flow configuration mode, and return to the service profile configuration mode (refer to [Section 3.4.12.11.3.3.6](#)).

Command Syntax **npu(config-srvcpfl)#flow** [<flow-id (1-255)] [**grp-alias** <svc-grp-alias>] [**if-alias** <string>]

Privilege Level 10

Syntax Description

Parameter	Description	Presence	Default Value	Possible Values
flow [<flow-id (1-255)]	Denotes the flow ID of the service flow for which the service flow configuration mode is to be enabled. If you are creating a new service flow, specify the service flow ID of the new service flow. The configuration mode is automatically enabled for the new service flow.	Mandatory	N/A	1-255

[grp-alias <svc-grp-alias>]	Indicates the Reference Name for an existing service group to be used by the service flow. VPWS Service Groups are applicable only for VLAN CS Service Flows of the Default Service Profile.	Mandatory when creating a new flow	N/A	An existing Service Group Alias.
[if-alias <string>]	Indicates the Reference Name for an existing QinQ service interface. Applicable only if the assigned Service Group is of type VPWS-QinQ (in a VLANCS Service Flow of the Default Service Profile).	Mandatory when creating a new flow, only if the type of the specified grp-alias is VPWS-QinQ.	N/A	An existing QinQ Service Interface.

3.4.12.11.3.3.2 Specifying Service Flow Configuration Parameters

Command Service profile configuration mode
Modes

After enabling the service flow configuration mode, run the following command to configure the parameters for this service flow:

```
npu(config-srvcpfl-flow)# config ([flow-type <type (1)>] [cs-type
<type (1 | 4)>] [media-type <string>] [uldatadlrvy-type
<type(0<UGS> | 1<RTVR> | 2<NRTVR> | 3<BE> | 4<ERTVR> | 255<ANY>)>]
[ulqos-maxsustainedrate <value(10000-400000000)>]
[ulqos-trafficpriority <value(0-7)>] [dldatadlrvy-type
<type(0<UGS> | 1<RTVR> | 2<NRTVR> | 3<BE> | 4<ERTVR> | 255<ANY>)>]
[dlqos-maxsustainedrate <value(10000-400000000)>]
[dlqos-trafficpriority <value(0-7)>] [ul-rsrv-rate-min
<integer(0-400000000)>] [ul-latency-max <integer>]
[ul-tolerated-jitter <integer>] [ul-unsol-intrvl
<integer(0-65535)>] [dl-rsrv-rate-min <integer(0-400000000)>]
[dl-latency-max <integer>] [dl-tolerated-jitter <integer>])
```



IMPORTANT

An error may occur if you provide an invalid value for any of these parameters. Refer the syntax description for more information about the appropriate values and format for configuring these parameters.

Command **npu(config-srvcpfl-flow)# config** ([flow-type <type (1)>] [cs-type <type (1 | 4)>] [media-type <string>] [uldatadvry-type <type(0<UGS> | 1<RTVR> | 2<NRTVR> | 3<BE> | 4<ERTVR> | 255<ANY>)>] [ulqos-maxsustainedrate <value(10000-40000000)>] [ulqos-trafficpriority <value(0-7)>] [dlldatadvry-type <type(0<UGS> | 1<RTVR> | 2<NRTVR> | 3<BE> | 4<ERTVR> | 255<ANY>)>] [dlqos-maxsustainedrate <value(10000-40000000)>] [dlqos-trafficpriority <value(0-7)>] [ul-rsrv-rate-min <integer(0-40000000)>] [ul-latency-max <integer>] [ul-tolerated-jitter <integer>] [ul-unsol-intrvl <integer(0-65535)>] [dl-rsrv-rate-min <integer(0-40000000)>] [dl-latency-max <integer>] [dl-tolerated-jitter <integer>])

Privilege Level 10

Syntax Description

Parameter	Description	Presence	Default Value	Possible Values
[flow-type <type (1)>]	Denotes the type of flow, that is, bi-directional (1) or multicast (2). multicast (2) is not supported in current release.	Optional	1	■ 1: Indicates bi-directional
[cs-type <type (1 4)>]	Convergence Sublayer Type. This parameter is applied to both UL and DL Service Flows. Must match the type of service group referenced by ServiceGrpAlias during creation of the flow: IPv4CS should be selected if the assigned Service Group is of type IP. VLANCS should be selected if the assigned Service Group is of type VPWS.	Optional	1 (IPv4CS)	■ 1: IPv4CS ■ 4: VLANCS
[media-type <string>]	Describes the type of media carried by the service flow.	Optional	Null	String, up to 32 characters

[uldatadlvry-type <type(0<UGS> 1<RTVR> 2<NRTVR> 3<BE> 4<ERTVR> 255<ANY>)>]	Denotes the data delivery type for uplink traffic carried by the service flow.	Optional	3 (BE)	0-4 or 255 for ANY.
[ulqos-maxsustainedrate <value(10000-400000)>]	Denotes the maximum sustained traffic rate, in bps, for uplink traffic carried by the service flow. Although available for all service flows, applicable only for service flows with the appropriate uplink data delivery type (NRTVR, RTVR, BE, ERTVR, ANY)	Optional	250000	10000-400000 bps
[ulqos-trafficpriority <value(0-7)>]	Denotes the traffic priority to be applied to the uplink traffic carried by the service flow. Although available for all service flows, not applicable for service flows with UGS uplink data delivery type.	Optional	0	0-7, where 0 is lowest and 7 is highest
[dlldatadlvry-type <type(0<UGS> 1<RTVR> 2<NRTVR> 3<BE> 4<ERTVR> 255<ANY>)>]	Denotes the data delivery type for the downlink traffic carried by the service flow.	Optional	3 (BE)	■ 0 (UGS) ■ 1 (RTVR) ■ 2 (NRTVR) ■ 3 (BE) ■ 4 (ERTVR) ■ 255 (ANY)
[dlqos-maxsustainedrate <value(10000-400000)>]	Denotes the maximum sustained traffic rate, in bps, for the downlink traffic carried by the service flow. Although available for all service flows, applicable only for service flows with the appropriate downlink data delivery type (NRTVR, RTVR, BE, ERTVR, ANY)	Optional	250000	10000-400000 bps

[dlqos-trafficpriority <value(0-7)>]	Denotes the traffic priority to be applied to the downlink traffic carried by the service flow. Although available for all service flows, not applicable for service flows with UGS uplink data delivery type.	Optional	0	0-7, where 7 is highest
[ul-rsrv-rate-min <integer(0-4000000)>]	the minimum rate in bps reserved for this uplink service flow. Although available for all service flows, applicable only for service flows with the appropriate uplink data delivery type (UGS, NRTVR, RTVR, ERTVR). For NRTVR, RTVR and ERTVR-cannot be higher than ulqos-maxsustainedrate.	Optional	250000	0- 40000000
[ul-latency-max <integer>]	The maximum latency in ms allowed in the uplink. Although available for all service flows, applicable only for service flows with the appropriate uplink data delivery type (UGS, RTVR, ERTVR). If uplink data delivery type is ERTVR or UGS, the default value should be 90ms.	Optional	500	0- 4294967295
[ul-tolerated-jitter <integer>]	the maximum delay variation (jitter) in milliseconds for this uplink service flow. Although available for all service flows, applicable only for service flows with the appropriate uplink data delivery type (UGS, ERTVR)	Optional	0	0- 4294967295

[ul-unsol-intrvl <integer(0-65535) >]	The nominal interval in ms between successive data grant opportunities for this uplink service flow. Although available for all service flows, applicable only for service flows with the appropriate uplink data delivery type (UGS, ERTVR). Must be lower than ul-latency-max.	Optional	20	0-65535
[dl-rsrv-rate-min <integer(0-40000000)>]	the minimum rate in bps reserved for this downlink service flow. Although available for all service flows, applicable only for service flows with the appropriate downlink data delivery type (UGS, NRTVR, RTVR, ERTVR) For NRTVR, RTVR and ERTVR-cannot be higher than dlqos-maxsustainedrate.	Optional	250000	0- 40000000
[dl-latency-max <integer>]	The maximum latency in ms allowed in the downlink. Although available for all service flows, applicable only for service flows with the appropriate downlink data delivery type (UGS, RTVR, ERTVR). If uplink data delivery type is ERTVR or UGS, the default value should be 90ms.	Optional	500	0- 4294967295
[dl-tolerated-jitter <integer>]	the maximum delay variation (jitter) in milliseconds for this downlink service flow. Although available for all service flows, applicable only for service flows with the appropriate downlink data delivery type (UGS, ERTVR)	Optional	0	0- 4294967295

Command	Service profile-service flow configuration mode
Modes	

3.4.12.11.3.3 Restoring the Default Service Flow Configuration Parameters

Run the following command to restore the default values of one or several parameters for this service flow:

```
npu(config-srvcpfl-flow)# no [cs-type] [media-type]
[uldatadvry-type] [ulqos-maxsustainedrate]
[ulqos-trafficpriority] [dladvry-type]
[dlqos-maxsustainedrate] [dlqos-trafficpriority][ul-rsrv-rate-min]
[ul-latency-max] [ul-tolerated-jitter] [ul-unsol-intrvl]
[dl-rsrv-rate-min] [dl-latency-max] [dl-tolerated-jitter]
```

Do not specify any parameter to restore all parameters to their default values.



NOTE

Refer to [Section 3.4.12.11.3.2](#) for a description and default values of these parameters.

Command	npu(config-srvcpfl-flow)# no [cs-type] [media-type] [uldatadvry-type]
Syntax	[ulqos-maxsustainedrate] [ulqos-trafficpriority] [dladvry-type] [dlqos-maxsustainedrate] [dlqos-trafficpriority][ul-rsrv-rate-min] [ul-latency-max] [ul-tolerated-jitter] [ul-unsol-intrvl] [dl-rsrv-rate-min] [dl-latency-max] [dl-tolerated-jitter]

Privilege Level	10
-----------------	----

Command	Service profile-service flow configuration mode
Modes	

3.4.12.11.3.4 Configuring Uplink/Downlink Classification Rule Names

After enabling the service flow configuration mode, run the following commands to configure up to a maximum of 6 uplink and 6 downlink classification rules:

```
npu(config-srvcpfl-flow)# ulclsf-rulename <num_of_rule_names>
(1-6)> <rulename> [<rulename>] [...]
```

```
npu(config-srvcpfl-flow)# dlclsf-rulename <num_of_rule_names>
(1-6)> <rulename> [<rulename>] [...]
```

**IMPORTANT**

.If no classifier is associated with the service flow for one or both directions, it means any traffic.

After you have executed these tasks, you can terminate the service flow configuration mode, and return to the service profile configuration mode (Section 3.4.12.11.3.3.6). For more information about configuring classification rules, refer “[Configuring Classification Rules](#)” on page 330.

Command `npu(config-srvcpfl-flow)# ulclsf-rulename <num_of_rule_names (1-6)> <rulename>`
Syntax `[<rulename>] [...]`

Command `npu(config-srvcpfl-flow)# dlclsf-rulename <num_of_rule_names (1-6)> <rulename>`
Syntax `[<rulename>] [...]`

Privilege Level 10

Syntax Description

Parameter	Description	Presence	Default Value	Possible Values
<num_of_rule_names (1-6)>	Indicates the number of uplink/downlink classification rules to be created	Mandatory	N/A	1-6

	<rulename>	Indicates the name of the uplink/downlink classification rule to be linked to this service flow. Use the classification rule name to reference the appropriate classification rule. For VLANCS service flows the linked uplink and downlink classification rules should be the same. This is because the VLANCS classification rules define the CVID (Customer VLAN ID), that should be the same for uplink and downlink flows. The number of rule name entries must match the number defined in num_of_rule_names. For more information about creating classification rules, refer to Section 3.4.12.11.4.1.	Mandatory	N/A	Valid classification rule name
--	------------	---	-----------	-----	--------------------------------

Command Service profile-service flow configuration mode
Modes

3.4.12.11.3.3.5 Deleting Uplink/Downlink Classification Rule Names

After enabling the service flow configuration mode, run the following commands to delete uplink/downlink classification rules:

```
npu(config-srvcpfl-flow)# no ulclsf-rulename [<num_of_rulenames
(1-6)> <rulename> [<rulename>] ...]
```

```
npu(config-srvcpfl-flow)# no dlclsf-rulename [<num_of_rulenames
(1-6)> <rulename> [<rulename>] ...]
```

After you have executed these commands, you can terminate the service flow configuration mode, and return to the service profile configuration mode (refer to [Section 3.4.12.11.3.3.6](#))

Command **npu(config-srvcpfl-flow)# no ulclsf-rulename** [<num_of_rulenames (1-6)> <rulename>
 Syntax **[<rulename>] ...]**

npu(config-srvcpfl-flow)# no dlclsf-rulename [<num_of_rulenames (1-6)> <rulename>
 [<rulename>] ...]

Privilege 10
 Level

Syntax
 Description

Parameter	Description	Presence	Default Value	Possible Values
[<num_of_rulenames (1-6)>]	Indicates the number of uplink/downlink classification rules to be deleted.	Mandatory	N/A	1-6
<rulename>	Indicates the name of the uplink/downlink classification rule to be deleted from this service flow. Use the classification rule name to reference the appropriate classification rule. The number of rule name entries must match the number defined in num_of_rule_names.	Mandatory	N/A	Valid classification rule name

Command Service profile-service flow configuration mode
 Modes

3.4.12.11.3.3.6 Terminating the Service Flow Configuration Mode

Run the following command to terminate the service flow configuration mode:

npu(config-srvcpfl-flow)# exit

Command npu(config-srvcpfl-flow)# exit
 Syntax

Privilege Level 10

Command Modes Service profile-service flow configuration mode

3.4.12.11.3.3.7 Deleting Service Flows

You can, at any time, run the following command to delete one or all service flows:

npu(config-srvcpfl)# no flow [<flow-id>]



CAUTION

Specify the flow ID if you want to delete a specific service flow. Otherwise all the configured service flows are deleted.

Command Syntax **npu(config-srvcpfl)# no flow [<flow-id>]**

Privilege Level 10

Command Syntax **npu(config-srvcpfl)# no flow [<flow-id>]**

Syntax Description

Parameter	Description	Presence	Default Value	Possible Values
[<flow-id>]	Denotes the flow ID of the service flow to be deleted. If you do not specify a value for this parameter, all the service flows are deleted.	Optional	N/A	0-255

Command Modes Service profile configuration mode

3.4.12.11.3.4 Terminating the Service Profile Configuration Mode

Run the following command to terminate the service profile configuration mode:

npu(config-srvcpfl)# exit

Command	npu(config-srvcpfl)# exit
Syntax	

Privilege Level	10
-----------------	----

Command Modes	Service profile configuration mode
---------------	------------------------------------

3.4.12.11.3.5 Displaying Configuration Information for Service Profiles

To display all or specific service profiles, run the following command:

npu# show srvc-profile [<profile-name>]

Specify the profile name if you want to display configuration information for a particular service profile. Do not specify a value for this parameter if you want to view configuration information for all service profile.

**IMPORTANT**

An error may occur if you provide an invalid service profile name. Refer the syntax description for more information about the appropriate values and format for configuring this parameter.

Command Syntax	npu# show srvc-profile [<profile-name>]
----------------	---

Privilege Level	1
-----------------	---

Syntax**Description**

Parameter	Description	Presence	Default Value	Possible Values
[<profile-name>]	Indicates the name of the service profile for which configuration information is to be displayed. If you do not specify a value for this parameter, configuration information is displayed for all service profiles.	Optional	N/A	String

Display Format	Srv Profile <value>
	status <value>
	flow-id <value>
	flow-type <value>
	srvc-grp <value>
	Service-If <value or null>
	CS-type <value>
	Media-Type <value>
	UL-flowDataDeliveryType <value>
	UL-flowQosMaxSustainedRate <value>
	UL-flowQosTrafficPriority <value>
	DL-flowDataDeliveryType <value>
	DL-flowQosMaxSustainedRate <value>
	DL-flowQosTrafficPriority <value>
	UL-MinReservedTrafficRate <value>
	UL-MaxLatency <value>
	UL-ToleratedJitter <value>
	UL-UnsolicitedGrantInterval <value>
	DL-MinReservedTrafficRate <value>
	DL-MaxLatency <value>
	DL-ToleratedJitter <value>
	UL-Rulenames :<value>, <value>.....
	DL-Rulenames :<value>, <value>....
	flow-id <value>.....

Command Modes	Global configuration mode
------------------	---------------------------

3.4.12.11.3.6 Deleting Service Profiles

Run the following command to delete one or all service profiles:

```
npu(config)# no srvc-profile [<profile-name>]
```

**NOTE**

The Default Service Profile cannot be deleted.

**CAUTION**

Specify the profile name if you want to delete a specific service profile. Otherwise all the configured service profiles (excluding the Default Service Profile) are deleted.

Command **npu(config)# no srvc-profile** [<profile-name>]

Syntax

Privilege Level 10

Syntax Description

Parameter	Description	Presence	Default Value	Possible Values
[<profile-name>]	Denotes the name of the service profile you want to delete. Specify this parameter only if you want to delete a specific service profile.	Optional	N/A	String

Command Modes Global configuration mode

3.4.12.11.4 Configuring Classification Rules

Classification rules are user-configurable rules that are used to classify packets transmitted on the bearer plane. You can associate one or more classification rules with a particular service profile (For details, refer to [Section 3.4.12.11.3.3.4](#)).

You can define an L3 classification rule with respect to the following criteria:

- IP ToS/DSCP
- IP protocol (such as UDP or TCP)
- IP source address (an address mask can be used to define a range of addresses or subnet)

- IP destination address (an address mask can be used to define a range of addresses or subnet)
- Source port range
- Destination port range

You can define an L2 classification rule based on the Customer VLAN ID (CVID).

Classification rules can be specified for:

- Downlink data is classified by the ASN-GW into GRE tunnels, which, in turn, are mapped into 802.16e connections in the air interface
- Uplink data is classified by the MS into 802.16e connections, and with respect to classification rules defined in the service profile provisioned in the ASN-GW and downloaded to the MS when establishing a connection.

For instance, you can define an L3 downlink classification rule that will classify traffic to a certain MS with a DSCP value of 46 into a UGS connection, and all other traffic to the MS into a best effort connection. In addition, an uplink L3 classification rule can be defined that will classify traffic from this MS with a UDP destination port higher than 5000 into a UGS connection, and all other traffic from the MS into a best effort connection.

Up to a maximum of 100 classification rules can be created.



To configure one or more L3 classification rules:

- 1 Enable the L3 classification rules configuration mode (refer to [Section 3.4.12.11.4.1](#))

- 2 You can now execute any of the following tasks:
 - » Configure the parameters for this classification rule (refer to [Section 3.4.12.11.4.2](#))
 - » Restore the default parameters for this classification rule (refer to [Section 3.4.12.11.4.3](#))
 - » Manage protocol configuration (refer to [Section 3.4.12.11.4.4](#))
 - » Manage source address configuration (see [Section 3.4.12.11.4.5](#))
 - » Manage destination address configuration (refer to [Section 3.4.12.11.4.6](#))
 - » Manage source port configuration (refer to [Section 3.4.12.11.4.7](#))
 - » Manage destination port configuration (refer to [Section 3.4.12.11.4.8](#))
- 3 Terminate the L3 classification rules configuration mode (refer to [Section 3.4.12.11.4.9](#))

You can, at any time, display configuration information (refer to [Section 3.4.12.11.4.13](#)) or delete an existing classification rule (refer to [Section 3.4.12.11.4.14](#)), protocol lists (refer to [Section 3.4.12.11.4.4.5](#)), source addresses (refer to [Section 3.4.12.11.4.5.5](#)), destination addresses (refer to [Section 3.4.12.11.4.6.5](#)), source ports (refer to [Section 3.4.12.11.4.7.5](#)), or destination ports (refer to [Section 3.4.12.11.4.8.5](#)) configured for this classification rule.



To configure one or more L2 classification rules:

- 1 Enable the L2 classification rules configuration mode (refer to [Section 3.4.12.11.4.1](#))
- 2 You can now execute any of the following tasks:
 - » Configure the parameters for this classification rule (refer to [Section 3.4.12.11.4.10](#))
 - » Clear the configuration of this classification rule (refer to [Section 3.4.12.11.4.11](#))
 - » Terminate the L2 classification rules configuration mode (refer to [Section 3.4.12.11.4.12](#))

You can, at any time, display configuration information (refer to [Section 3.4.12.11.4.13](#)) or delete an existing classification rule (refer to [Section 3.4.12.11.4.14](#)).

3.4.12.11.4.1 Enabling the Classification Rule Configuration Mode\ Creating a New Classification Rule

To configure the parameters for a classification rule, first enable the classification rule configuration mode. Run the following command to enable the classification rule configuration mode. You can also use this command to create a new classification rule.

```
npu(config)# clsf-rule <rulename> [clsfRuleType {L2 | L3}]
```

If you use this command to create a new classification rule, the configuration mode for this rule is automatically enabled.

After enabling the classification rule configuration mode for an L3 rule you can execute any of the following tasks:

- Configure the parameters for this classification rule (refer to [Section 3.4.12.11.4.2](#)).
- Restore the default parameters for this classification rule (refer to [Section 3.4.12.11.4.3](#))
- Manage protocol configuration (refer to [Section 3.4.12.11.4.4](#))
- Manage source address configuration (refer to [Section 3.4.12.11.4.5](#))
- Manage destination address configuration (refer to [Section 3.4.12.11.4.6](#))
- Manage source port configuration (refer to [Section 3.4.12.11.4.7](#))
- Manage destination port configuration (refer to [Section 3.4.12.11.4.8](#))

After you have executed these tasks, you can terminate the classification rules configuration mode (refer to [Section 3.4.12.11.4.9](#)).

After enabling the classification rule configuration mode for an L2 rule you can execute any of the following tasks:

- Configure the parameters for this classification rule (refer to [Section 3.4.12.11.4.10](#)).

- Clear the current configuration of this classification rule (refer to [Section 3.4.12.11.4.11](#))

After you have executed these tasks, you can terminate the classification rules configuration mode (refer to [Section 3.4.12.11.4.12](#)).

Command **npu(config)# clsf-rule <rulename> [clsfRuleType {L2 | L3}]**
 Syntax

Privilege 10
 Level

Syntax
 Description

Parameter	Description	Presence	Default Value	Possible Values
<rulename>	Denotes the name of the classification rule.	Mandatory	N/A	String (1 to 30 characters)
[clsfRuleType {L2 L3}]	The type of classifier: L2 or L3.	Optional when creating a new rule.	L3	■ L2 ■ L3

Command Global configuration mode
 Modes

3.4.12.11.4.2 Specifying Configuration Parameters for the L3 Classification Rule

After enabling the classification rules configuration mode for an L3 classification rule, run the following command to configure the parameters for this classification rule:

```
npu(config-clsfrule)# config [priority <priority(0-255)>]
[phs-rulename <rulename>] [iptos-low <value(0-63)>] [iptos-high
<value(0-63)>] [iptos-mask <value(0-63)>] [iptos-enable]
```



NOTE

You can display configuration information for specific or all classification rules. For details, refer to [Section 3.4.12.11.4.13](#).

Command npu(config-clsrule)# config [**priority** <priority(0-255)>] [**phs-rulename** <rulename>] [**iptos-low**
 Syntax <value(0-63)>] [**iptos-high** <value(0-63)>] [**iptos-mask** <value(0-63)>] [**iptos-enable**]

Privilege 10
 Level

Syntax
 Description

Parameter	Description	Presence	Default Value	Possible Values
[priority <priority(0-255)>]	Denotes the priority level to be assigned to the classification rule.	Optional	0	0-255
[phs-rulename <rulename>]	Indicates the Packet Header Suppression (PHS) rule name to be associated with the classification rule. Specify the PHS rulename if you want to perform PHS for this flow. For more information about configuring PHS rules, refer Section 3.4.12.12 .	Optional	None	String An existing PHS rule name.
[iptos-low <value(0-63)>]	Denotes the value of the lowest IP TOS field to define the lowest value where the range can begin. Cannot be higher than iptos-high. Can be modified only when IP TOS classification is disabled (see iptos-enable below). If set to a value higher than iptos-high, IP TOS classification cannot be enabled.	Optional	0	0-63

[iptos-high <value(0-63)>]	Denotes the value of highest IP TOS field to define the highest value where the range can end. Cannot be lower than iptos-low. Can be modified only when IP TOS classification is disabled (see iptos-enable below). If set to a value lower than iptos-low, IP TOS classification cannot be enabled.	Optional	0	0-63
[iptos-mask <value(0-63)>]	Denotes the mask for IP TOS value. This mask is applied to the TOS field received in the IP header to be matched within the TOS range configured.	Optional	0	0-63
[iptos-enable]	Indicates whether the use of TOS-based classification is to be enabled.	Optional	By default, the use of TOS-based classification is disabled.	The presence/absence of this flag indicates that the use of TOS-based classification should be enabled/disabled.

Command L3 Classification rules configuration mode
Modes

3.4.12.11.4.3 Restoring the Default Parameters for the L3 Classification Rule

Run the following command to restore the default configuration for this classification rule.

```
npu(config-clsfrole)# no [priority] [iptos-low] [iptos-high]
[iptos-mask] [iptos-enable] [phs-rulename]
```



NOTE

Refer to [Section 3.4.12.11.4.3](#) for a description and default values of these parameters.

Command Syntax	<code>npu(config-clsfrule)# no [priority] [iptos-low] [iptos-high] [iptos-mask] [iptos-enable] [phs-rulename]</code>
Privilege Level	10
Command Modes	L3 Classification rules configuration mode

3.4.12.11.4.4 Managing IP Protocol Configuration for the L3 Classification Rule

L3 classification rules can classify the packet, based on the value of IP protocol field. You can configure the value of IP protocol for a given classification rule.



To configure IP protocol classifier:

- 1 Enable the IP protocol configuration mode (refer to [Section 3.4.12.11.4.4.1](#))
- 2 Enable/disable IP protocol classification (refer to [Section 3.4.12.11.4.4.2](#) and [Section 3.4.12.11.4.4.3](#))
- 3 Terminate the protocol configuration mode (refer to [Section 3.4.12.11.4.4.4](#))

In addition, you can, at any time, delete an existing IP protocol classifier (refer to [Section 3.4.12.11.4.4.5](#)).

The following example illustrates the sequence of commands for enabling the IP protocol configuration mode, enabling IP protocol 100, and then terminating the protocol lists configuration mode:

```
npu(config-clsfrule)# ip-protocol
npu(config-clsfrule-protocol)# protocol-enable 1 100
npu(config-clsfrule-protocol)# exit
```

3.4.12.11.4.4.1 Enabling the IP Protocol Configuration Mode

Run the following command to enable the IP protocol configuration mode.

```
npu(config-clsfrule)# ip-protocol
```

You can now enable or disable the IP protocol (refer to [Section 3.4.12.11.4.4.2](#) and [Section 3.4.12.11.4.4.3](#)).

Command npu(config-clsrule)# ip-protocol
Syntax

Privilege 10
Level

Command L3 Classification rules configuration mode
Modes

3.4.12.11.4.4.2 Enabling IP Protocol Classifier

After enabling the IP protocol configuration mode, run the following command to enable the IP protocol classifier and define the Protocol number:

npu(config-clsrule-protocol)# protocol-enable <number of protocols(1)> <protocol>



IMPORTANT

If source port range (see [Section 3.4.12.11.4.7.2](#)) or destination port range (see [Section 3.4.12.11.4.8.2](#)) is enabled, then:

IP protocol (protocol-enable) must be set to enabled.

Protocol can be either 6 (TCP) or 17 (UDP).

Command npu(config-clsrule-protocol)# protocol-enable <number of protocols(1)> <protocol>
Syntax

Privilege 10
Level

Syntax
Description

Parameter	Description	Presence	Default Value	Possible Values
<number of protocols(1)>	Indicates the number of protocol lists to be enabled. In the current release, only one protocol can be enabled per classification rule.	Mandatory	N/A	1

	<protocol>	Indicates the IP protocol to be enabled. In the current release, only one protocol can be enabled per classification rule.	Mandatory	N/A	0-255 (Using standard IANA protocol values)
--	------------	--	-----------	-----	---

Command L3 Classification rules-IP protocol configuration mode
Modes

3.4.12.11.4.4.3 Disabling Protocol Lists

After enabling the protocol configuration mode, run the following command to disable IP protocol classification:

npu(config-clsrule-protocol)# no protocol-enable <number of protocols(1)> <protocol>

Command **npu(config-clsrule-protocol)# no protocol-enable <number of protocols(1)> <protocol>**
Syntax

Privilege Level 10

Syntax Description

Parameter	Description	Presence	Default Value	Possible Values
<number of protocols(1)>	Indicates the number of protocol lists to be disabled. In the current release, only one protocol can be enabled per classification rule.	Mandatory	N/A	1
<protocol>	Indicates the protocol to be disabled.	Mandatory	N/A	0-255

Command L3 Classification rules-IP protocol configuration mode
Modes

3.4.12.11.4.4.4 Terminating the Protocol Configuration Mode

Run the following command to terminate the IP protocol configuration mode:

npu(config-clsrule-protocol)# exit

Command Syntax	npu(config-clsrule-protocol)# exit
----------------	------------------------------------

Privilege Level	10
-----------------	----

Command Modes	L3 Classification rule-IP protocol configuration mode
---------------	---

3.4.12.11.4.5 Deleting the IP Protocol Classifier

You can, at any time, run the following command to delete the protocol classifier:

npu(config-clsrule)# no ip-protocol

Command Syntax	npu(config-clsrule)# no ip-protocol
----------------	-------------------------------------

Privilege Level	10
-----------------	----

Command Modes	L3 Classification rule-IP protocol configuration mode
---------------	---

3.4.12.11.4.5 Managing Source Address Configuration for the L3 Classification Rule

Classification rules can classify the packet, based on the source address of the packet. You can configure the value of source address for a given classification rule.



To configure a source address classifier:

- 1 Enable the source address configuration mode (refer to [Section 3.4.12.11.4.5.1](#))

- 2 You can now execute any of the following tasks:
 - » Configure the address mask (refer to [Section 3.4.12.11.4.5.2](#))
 - » Disable the source address (refer to [Section 3.4.12.11.4.5.3](#))
- 3 Terminate the source address configuration mode (refer to [Section 3.4.12.11.4.5.4](#))

You can, at any time, delete an existing source address (refer to [Section 3.4.12.11.4.5.5](#)).

The following example illustrates the (sequence of) commands for enabling the source address configuration mode, enabling the source address classifier, configuring the address mask, and then terminating the source address configuration mode:

```
npu(config-clsfrule)# srcaddr 10.203.155.20  
  
npu(config-clsfrule-srcaddr)# config addr-enable addr-mask  
255.255.0.0  
  
npu(config-clsfrule-srcaddr)# exit
```

[3.4.12.11.4.5.1](#) *Enabling the Source Address Configuration Mode\ Creating a New Source Address*

To configure the parameters for a source address, first enable the source address configuration mode. Run the following command to enable the source address configuration mode. This command also creates the source address classifier.

```
npu(config-clsfrule)# srcaddr <ipv4addr>
```

The configuration mode for the newly created source address is automatically enabled, after which you can execute any of the following tasks:

- Configure the address mask (refer to [Section 3.4.12.11.4.5.2](#))
- Disable the source address (refer to [Section 3.4.12.11.4.5.3](#))

After you have executed these tasks, terminate the source address configuration mode to return to the service classification rule configuration mode (refer to [Section 3.4.12.11.4.5.4](#)).

**IMPORTANT**

An error may occur if you provide an invalid source IP address. Refer the syntax description for more information about the appropriate value and format for configuring this parameter.

Command **npu(config-clsfrole)# srcaddr <ipv4addr>**
 Syntax

Syntax
 Description

Parameter	Description	Presence	Default Value	Possible Values
<ipv4addr>	Denotes the IPv4 address of the source address for which the configuration mode is to be enabled. The source address configuration mode is automatically enabled.	Mandatory	N/A	Valid IP Address

Privilege
 Level 10

Command Modes
 L3 Classification rules configuration mode

3.4.12.11.4.5.2 Enabling the Source Address and Configuring the Address Mask

After enabling the source address configuration mode, run the following command to enable the source address and configure the address mask for the source address.

npu(config-clsfrole-srcaddr)# config [addr-enable] [addr-mask <value>]

You can also run this command to enable a source address that is currently disabled. For details, refer to [“Disabling the Source Address” on page 343](#).

**IMPORTANT**

An error may occur if you provide an invalid address mask for the source address. Refer the syntax description for more information about the appropriate value and format for this parameter.

Command **npu(config-clsrcaddr)# config [addr-enable] [addr-mask <value>]**
 Syntax

Privilege Level 10

Syntax Description

Parameter	Description	Presence	Default Value	Possible Values
[addr-enable]	Indicates that the use of the associated source address is enabled for the classification rule that you are configuring. If the use of this address is disabled, the associated source address is ignored while classifying the packet.	Optional	By default, the use of the associated source address is disabled.	The presence/absence of this flag indicates that the use of the associated source address is enabled/disabled.
[addr-mask <value>]	Denotes the mask field that is used to specify a range of source addresses.	Optional	255.255.255.255	Valid address mask

Command Modes L3 Classification rules-source address configuration mode

3.4.12.11.4.5.3 Disabling the Source Address

You can run the following command to disable the source address that is currently enabled:

npu(config-clsrcaddr)# no addr-enable



IMPORTANT

To enable this source address, run the following command:

npu(config-clsrcaddr)# config [addr-enable] [addr-mask <value>]

For details, refer to [“Enabling the Source Address and Configuring the Address Mask”](#) on page 342.

Command	npu(config-clsrule-srcaddr)# no addr-enable
Syntax	

Privilege Level	10
-----------------	----

Command Modes	L3 Classification rules-source address configuration mode
---------------	---

3.4.12.11.4.5.4 Terminating the Source Address Configuration Mode

Run the following command to terminate the source address configuration mode:

npu(config-clsrule-srcaddr)# exit

Command	npu(config-clsrule-srcaddr)# exit
Syntax	

Privilege Level	10
-----------------	----

Command Modes	L3 Classification rule-source address configuration mode
---------------	--

3.4.12.11.4.5.5 Deleting Source Address

You can, at any time, run the following command to delete the source address classifier:

npu(config-clsrule)# no srcaddr [<ip-Addr>]

Command	npu(config-clsrule)# no srcaddr [<ip-Addr>]
Syntax	

Privilege Level	10
-----------------	----

Syntax**Description**

Parameter	Description	Presence	Default Value	Possible Values
[<ip-Addr>]	Denotes the IPv4 address of the source address that you want to delete from a classification rule.	Optional	N/A	Valid IP Address

Command

L3 Classification rules configuration mode

Modes**3.4.12.11.4.6 Managing Destination Address Configuration for the L3 Classification Rule**

Classification rules can classify the packet, based on the destination address of the packet. You can configure the value of destination address for a given classification rule.

**To configure a destination address classifier:**

- 1** Enable the destination address configuration mode (refer to [Section 3.4.12.11.4.6.1](#))
- 2** You can now execute any of the following tasks:
 - » Configure the address mask (refer to [Section 3.4.12.11.4.6.2](#))
 - » Disable the destination address (refer to [Section 3.4.12.11.4.6.3](#))
- 3** Terminate the destination address configuration mode (refer to [Section 3.4.12.11.4.6.4](#))

In addition, you can, at any time, delete an existing destination address (refer to [Section 3.4.12.11.4.6.5](#)).

The following example illustrates the (sequence of) commands for enabling the destination address configuration mode, enabling the destination address classifier, configuring the address mask, and then terminating the destination address configuration mode:

```
npu(config-clsfrole)# dstaddr 10.203.155.22
```

```
npu(config-clsrule-dstaddr)# config addr-enable addr-mask
0.0.255.255
```

```
npu(config-clsrule-srcaddr)# exit
```

3.4.12.11.4.6.1 Enabling the Destination Address Configuration Mode\ Creating a New Destination Address

To configure the parameters for a destination address, first enable the destination address configuration mode. Run the following command to enable the destination address configuration mode. This command also creates the new destination address classifier.

```
npu(config-clsrule)# dstaddr <ipv4addr>
```

The configuration mode for the newly created destination address is automatically enabled, after which you can execute any of the following tasks:

- Configure the address mask (refer to [Section 3.4.12.11.4.6.2](#))k
- Disable the destination address (refer to [Section 3.4.12.11.4.6.3](#))

After you execute these tasks, you can terminate the destination address configuration mode (refer to [Section 3.4.12.11.4.6.4](#)) and return to the classification rules configuration mode.



IMPORTANT

An error may occur if you provide an invalid destination IP address. Refer the syntax description for more information about the appropriate values and format for configuring this parameter.

Command	npu(config-clsrule)# dstaddr <ipv4addr>
Syntax	

Privilege	10
Level	

Syntax**Description**

Parameter	Description	Presence	Default Value	Possible Values
<ipv4addr>	Denotes the IPv4 address of the destination address for which the configuration mode is to be enabled. The destination address configuration mode is automatically enabled.	Mandatory	N/A	Valid IP Address

Command

L3 Classification rules configuration mode

Modes**3.4.12.11.4.6.2 Enabling the Destination Address and Configuring the Address Mask**

Run the following command to enable the destination address classifier and configure the address mask for the destination address.

```
npu(config-clsfrole-dstaddr)# config [addr-enable] [addr-mask <value>]
```

You can also run this command to enable a destination address that is currently disabled. For details, refer to [“Disabling the Destination Address” on page 348](#).

**IMPORTANT**

An error may occur if you provide an invalid address mask. Refer the syntax description for more information about the appropriate values and format for configuring this parameter.

Command

```
npu(config-clsfrole-dstaddr)# config [addr-enable] [addr-mask <value>]
```

Syntax**Privilege**

10

Level

Syntax
Description

Parameter	Description	Presence	Default Value	Possible Values
[addr-enable]	Indicates that the use of the associated destination address is enabled for the classification rule that you are configuring. If the use of this address is disabled, the associated destination address is ignored while classifying the packet.	Optional	By default, the use of the associated destination address is disabled.	The presence/absence of this flag indicates that the use of the associated destination address is enabled/disabled.
[addr-mask <value>]	Denotes the mask field that is used to specify a range of destination addresses.	Optional	255.255.255.255	Valid address mask

Command Modes
L3 Classification rules-destination address configuration mode

3.4.12.11.4.6.3 Disabling the Destination Address

Run the following command to disable the destination address that is currently enabled:

npu(config-clsrule-dstaddr)# no addr-enable

Command Syntax
npu(config-clsrule-dstaddr)# no addr-enable

Privilege Level
10

Command Modes
L3 Classification rules-destination address configuration mode

3.4.12.11.4.6.4 Terminating the Destination Address Configuration Mode

Run the following command to terminate the destination address configuration mode:

npu(config-clsfrole-dstaddr)# exit

Command	npu(config-clsfrole-dstaddr)# exit
Syntax	

Privilege Level	10
-----------------	----

Command Modes	L3 Classification rule-destination address configuration mode
---------------	---

3.4.12.11.4.6.5 Deleting Destination Address

You can, at any time, run the following command to delete the destination address classifier:

npu(config-clsfrole)# no dstaddr [<ip-Addr>]



IMPORTANT

An error may occur if you provide an invalid IP address. Refer the syntax description for more information about the appropriate values and format for configuring this parameter.

Command	npu(config-clsfrole)# no dstaddr [<ip-Addr>]
Syntax	

Privilege Level	10
-----------------	----

Syntax Description	
--------------------	--

Parameter	Description	Presence	Default Value	Possible Values
[<ip-Addr>]	Denotes the IPv4 address of the destination address that you want to delete from a classification rule.	Optional	N/A	Valid IP Address

Command	L3 Classification rules configuration mode
Modes	

3.4.12.11.4.7 Managing Source Ports Range Configuration for the L3 Classification Rule

Classification can be based on the source port of the packet. You can configure the range of source ports for a given classification rule.



To configure a source ports range classifier:

- 1 Enable the source port configuration mode (refer to [Section 3.4.12.11.4.7.1](#))
- 2 Enable/disable the source port range (refer to [Section 3.4.12.11.4.7.2](#)/[Section 3.4.12.11.4.7.3](#))
- 3 Terminate the source port configuration mode (refer to [Section 3.4.12.11.4.7.4](#))

In addition, you can, at any time, delete an existing source port configuration (refer to [Section 3.4.12.11.4.7.5](#)).

The following example illustrates the (sequence of) commands for enabling the source port configuration mode, enabling the source port range, and then terminating the source port configuration mode:

```
npu(config-clsfrule)# srcport 20 50
npu(config-clsfrule-srcport)# port-enable
npu(config-clsfrule-srcport)# exit
```

3.4.12.11.4.7.1 Enabling the Source Port Configuration Model Creating a New Source Port

To configure the parameters for a source port, first enable the source port configuration mode. Run the following command to enable the source port configuration mode. This command also creates the new source ports range classifier.

```
npu(config-clsfrule)# srcport <start-port> <end-port>
```



IMPORTANT

An error may occur if you provide an invalid value for any of these parameters. Refer the syntax description for more information about the appropriate values and format for configuring these parameters.

The configuration mode for the newly created source port is automatically enabled, after which you can enable/disable the source port range (refer to [Section 3.4.12.11.4.7.2](#)/[Section 3.4.12.11.4.7.3](#)).

You can then terminate the source port configuration mode (refer to [Section 3.4.12.11.4.7.4](#)) and return to the classification rules configuration mode.

Command **npu(config-clsrule)# srcport <start-port> <end-port>**
 Syntax

Privilege 10
 Level

Syntax
 Description

Parameter	Description	Presence	Default Value	Possible Values
<start-port>	Denotes the starting value of port range to be configured. Cannot be higher than end-port.	Mandatory	N/A	1-65535
<end-port>	Denotes the end value of port range to be configured. Cannot be lower than start-port.	Mandatory	N/A	1-65535

Command L3 Classification rules configuration mode
 Modes

[3.4.12.11.4.7.2](#) *Enabling the Source Port Range*

Run the following command to enable the source port range:

npu(config-clsrule-srcport)# port-enable

You can also run this command to enable a source port range that is currently disabled. For details, refer to [“Disabling the Source Port Range” on page 352](#).

**IMPORTANT**

If source port range is enabled, then:
 IP protocol (protocol-enable) must be set to enabled.
 Protocol can be either 6 (TCP) or 17 (UDP).
 For details on these parameters refer to [Section 3.4.12.11.4.4.2](#).

Command Syntax	npu(config-clsrule-srcport)# port-enable
Privilege Level	10
Command Modes	L3 Classification rules-source port configuration mode

3.4.12.11.4.7.3 *Disabling the Source Port Range*

Run the following command to disable the source port range that is currently enabled:

npu(config-clsrule-srcport)# no port-enable

**IMPORTANT**

To enable this source port range, run the following command:
 npu(config-clsrule-srcport)# port-enable
 For details, refer to [“Enabling the Source Port Range” on page 351](#).

Command Syntax	npu(config-clsrule-srcport)# no port-enable
Privilege Level	10
Command Modes	L3 Classification rules-source port configuration mode

3.4.12.11.4.7.4 *Terminating the Source Port Configuration Mode*

Run the following command to terminate the source port configuration mode:

npu(config-clsrule-srcport)# exit

Command npu(config-clsrule-srcport)# exit
Syntax

Privilege 10
Level

Command L3 Classification rule-source port configuration mode
Modes

3.4.12.11.4.7.5Deleting Source Ports Range

Run the following command to delete a source ports range classifier:

npu(config-clsrule)# no srcport [<start-port> <end-port>]

**IMPORTANT**

An error may occur if you provide an invalid value for the start -port and end -port parameters. Refer the syntax description for more information about the appropriate values and format for configuring these parameters.

Command npu(config-clsrule)# no srcport [<start-port> <end-port>]
Syntax

Privilege 10
Level

Syntax
Description

Parameter	Description	Presence	Default Value	Possible Values
<start-port>	Denotes the starting value of port range to be deleted.	Optional	N/A	1-65535
<end-port>	Denotes the end value of port range to be deleted.	Optional	N/A	1-65535

Command L3 Classification rules configuration mode
Modes

3.4.12.11.4.8 Managing Destination Ports Range Configuration for the L3 Classification Rule

Classification can be based on the destination port of the packet. You can configure the range of destination ports for a given classification rule.



To configure a destination ports range classifier:

- 1 Enable the destination port configuration mode (refer to [Section 3.4.12.11.4.8.1](#))
- 2 Enable/disable the destination port range (refer to [Section 3.4.12.11.4.8.2](#)/[Section 3.4.12.11.4.8.3](#))
- 3 Terminate the destination port configuration mode (refer to [Section 3.4.12.11.4.8.4](#))

In addition, you can, at any time, delete an existing destination port configuration (refer to [Section 3.4.12.11.4.8.5](#)).

The following example illustrates the (sequence of) commands for enabling the destination port configuration mode, enabling the destination port range, and then terminating the destination port configuration mode:

```
npu(config-clsfrole)# dstport 50 400
npu(config-clsfrole-dstport)# port-enable
npu(config-clsfrole-dstport)# exit
```

3.4.12.11.4.8.1 Enabling the Destination Port Configuration Mode\ Creating a New Destination Port

To configure the parameters for a destination port, first enable the destination port configuration mode. Run the following command to enable the destination ports range configuration mode. This command also creates the new destination ports range.

```
npu(config-clsfrole)# dstport <start-port> <end-port>
```

The configuration mode for the newly created destination ports range is automatically enabled, after which you can enable/disable the destination port range (refer to [Section 3.4.12.11.4.8.2](#)/[Section 3.4.12.11.4.8.3](#)). After executing these tasks, you can terminate the destination port configuration mode (refer to [Section 3.4.12.11.4.8.4](#)).

**IMPORTANT**

An error may occur if you provide an invalid value for the `start-port` and `end-port` parameters. Refer the syntax description for more information about the appropriate values and format for configuring these parameters.

Command **`npu(config-clsrule)# dstport <start-port> <end-port>`**
 Syntax

Privilege Level 10

Syntax Description

Parameter	Description	Presence	Default Value	Possible Values
<code><start-port></code>	Denotes the starting value of port range to be configured. Cannot be higher than <code>end-port</code> .	Mandatory	N/A	1-65535
<code><end-port></code>	Denotes the end value of port range to be configured. Cannot be lower than <code>start-port</code> .	Mandatory	N/A	1-65535

Command Modes L3 Classification rules configuration mode

3.4.12.11.4.8.2 Enabling the Destination Port Range

You can run the following command to enable the destination port range:

`npu(config-clsrule-dstport)# port-enable`

You can also run this command to enable a destination port range that is currently disabled. For details, refer to [“Disabling the Destination Port Range” on page 356](#).

**IMPORTANT**

If destination port range is enabled, then:
 IP protocol (protocol-enable) must be set to enabled.
 Protocol can be either 6 (TCP) or 17 (UDP).
 For details on these parameters refer to [Section 3.4.12.11.4.4.2](#).

Command Syntax	<code>npu(config-clsrule-dstport)# port-enable</code>
Privilege Level	10
Command Modes	L3 Classification rules-destination port configuration mode

[3.4.12.11.4.8.3](#) *Disabling the Destination Port Range*

You can run the following command to disable the destination port range that is currently enabled:

`npu(config-clsrule-dstport)# no port-enable`

**IMPORTANT**

To enable this destination port range, run the following command:
`npu(config-clsrule-dstport)# port-enable`
 For details, refer to [“Enabling the Destination Port Range” on page 355](#).

Command Syntax	<code>npu(config-clsrule-srcport)# no port-enable</code>
Privilege Level	10
Command Modes	L3 Classification rules-destination port configuration mode

[3.4.12.11.4.8.4](#) *Terminating the Destination Port Configuration Mode*

Run the following command to terminate the destination port configuration mode:

npu(config-clsrule-dstport)# exit

Command npu(config-clsrule-dstport)# exit
Syntax

Privilege 10
Level

Command L3 Classification rule-destination port configuration mode
Modes

3.4.12.11.4.8.5 Deleting Destination Ports Range

Run the following command to delete the destination ports range:

npu(config-clsrule)# no dstport [<start-port> <end-port>]

**IMPORTANT**

An error may occur if you provide an invalid value for the start-port and end-port parameters. Refer the syntax description for more information about the appropriate values and format for configuring these parameters.

Command npu(config-clsrule)# no dstport [<start-port> <end-port>]
Syntax

Privilege 10
Level

Syntax
Description

Parameter	Description	Presence	Default Value	Possible Values
<start-port>	Denotes the starting value of port range to be deleted.	Optional	N/A	1-65535
<end-port>	Denotes the end value of port range to be deleted.	Optional	N/A	1-65535

Command L3 Classification rules configuration mode
Modes

3.4.12.11.4.9 Terminating the L3 Classification Rule Configuration Mode

Run the following command to terminate the L3 classification rules configuration mode:

npu(config-clsrule)# exit

Command npu(config-clsrule)# exit
Syntax

Command L3 Classification rules configuration mode
Modes

3.4.12.11.4.10 Specifying Configuration Parameters for the L2 Classification Rule

After enabling the classification rules configuration mode for an L2 classification rule, run the following command to configure the parameters for this classification rule:

npu(config-clsrule-L2)# cvid <value(1-4094)>



NOTE

You can display configuration information for specific or all classification rules. For details, refer to [Section 3.4.12.11.4.13](#).

Command **npu(config-clsrule-L2)# cvid <value(1-4094)>**
Syntax

Privilege 10
Level

Syntax
Description

Parameter	Description	Presence	Default Value	Possible Values
cvid <value(1-4094)>	Denotes the Customer VLAN ID value to be assigned to the classification rule.	Mandatory	N/A	1-4094

Command L2 Classification rules configuration mode
Modes

3.4.12.11.4.11 Clearing the configuration of the L2 Classification Rule

Run the following command to clear the configuration of this classification rule (removing the configured cvid):

npu(config-clsf-rule-L2)# no cvid

After clearing the configuration you can define a new cvid for this classification rule.

Command Syntax	npu(config-clsf-rule- L2)# no cvid
----------------	--

Privilege Level	10
-----------------	----

Command Modes	L2 Classification rules configuration mode
---------------	--

3.4.12.11.4.12 Terminating the L2 Classification Rule Configuration Mode

Run the following command to terminate the L2 classification rules configuration mode:

npu(config-clsf-rule-L2)# exit

Command Syntax	npu(config-clsf-rule- L2)# exit
----------------	---

Command Modes	L2 Classification rules configuration mode
---------------	--

3.4.12.11.4.13 Displaying Configuration Information for Classification Rules

To display all or specific classification rules, run the following command:

npu# show clsf-rule [<rulename>]

Specify the classification rule name if you want to display configuration information for a particular rule. Do not specify a value for this parameter if you want to view configuration information for all classification rules.

**IMPORTANT**

An error may occur if you provide an invalid value for the `rulename` parameter. Refer the syntax description for more information about the appropriate values and format for configuring this parameters.

Command **npu# show clsf-rule** [`<rulename>`]
Syntax

Privilege 1
Level

Syntax
Description

Parameter	Description	Presence	Default Value	Possible Values
[<code><rulename></code>]	Denotes the name of the classification rule that you want to display. Specify this parameter only if you want to display a specific classification rule. If you do not specify a rule name, it displays all configured classification rules.	Optional	N/A	String

Display
Format for
each L3 rule

Classification Rule Configuration :

`ClsfRuleName <value>`

`clsfRuleType: L3`

`Priority <value>`

`Phs rulename <value>`

`IpTosLow <value> IpTosHigh <value> IpTosMask <value> IpTosEnable <0/1>`

`clsfRuleSrcAddr <value> clsfRuleMask <value> SrcAddrEnable <0/1>`

`clsfRuleDstAddr <value> clsfRuleAddrMask <value> DstAddrEnable <0/1>`

`clsfRuleSrcPort Start <value> clsfRuleSrcPort End <value> clsfRulePortEnable <0/1>`

`clsfRuleDstPort Start <value> clsfRuleDstPort End <value> clsfRulePortEnable <0/1>`

Display ClsfRuleName <value>
 Format for
 each L2 rule clsfRuleType: L2
 Cvid <value>

Command Global command mode
 Modes

3.4.12.11.4.14 Deleting Classification Rules

Run the following command to delete one or all classification rules:

npu(config)# no clsf-rule [<ruleName>]



CAUTION

Specify the rule name if you want to delete a specific classification. Otherwise all the configured classification rules are deleted.

Command **npu(config)# no clsf-rule** [<ruleName>]
 Syntax

Privilege 10
 Level

Syntax
 Description

Parameter	Description	Presence	Default Value	Possible Values
[<ruleName>]	Denotes the name of the classification rule that you want to delete. Specify this parameter only if you want to delete a specific classification rule, otherwise all configured classification rules are deleted.	Optional	N/A	String

Command Global configuration mode
 Modes

3.4.12.12 Configuring PHS Rules

Packet Header Suppression (PHS) is a mechanism that conserves air-interface bandwidth by removing parts of the packet header that remain constant along the traffic session. PHS operates by allowing the MS and ASN-GW to associate PHS rules to each service flow.

When PHS is enabled, a repetitive portion of the payload headers of higher layers is suppressed in the MAC SDU by the sending entity and restored by the receiving entity. At the uplink, the sending entity is the MS and the receiving entity is the NPU. At the downlink, the sending entity is the NPU, and the receiving entity is the MS. If PHS is enabled at the MAC connection, each MAC SDU is prefixed with a PHSI, which references the Payload Header Suppression Field (PHSF).

For instance, the ASN-GW will associate a PHS rule to each provisioned service flow intended for VoIP traffic that will suppress the IP address field from the IP header and other unvarying fields (e.g. protocol version) from the IP and RTP headers. The PHS rules are provisioned on a per-service profile name basis. (For details, refer [Section 3.4.12.11.4.](#))

PHS rules define:

- Header fields that need to be suppressed
- Static values that can be configured for the suppressed header fields



To configure one or more PHS rules:

- 1 Enable the PHS rules configuration mode (refer to [Section 3.4.12.12.1](#))
- 2 Configure the parameters for the PHS rule (refer to [Section 3.4.12.12.2](#))
- 3 Terminate the PHS rules configuration mode (refer to [Section 3.4.12.12.3](#))

You can, at any time, display configuration information (refer to [Section 3.4.12.12.5](#)) or delete an existing PHS rules (refer to [Section 3.4.12.12.4](#)).

The following example illustrates the (sequence of) commands for enabling the PHS rules configuration mode, configuring the parameters of a PHS rule, and then terminating the PHS configuration mode, should be executed as shown in the example below:

```
npu(config)# phs-rule phs-rule1
```

```
npu(config-phsrule)# config field
00000000000000000000000000000000FFFFFFFF00000000 mask 000F00 verify 0 size
20
```

```
npu(config-phsrule)# exit
```

3.4.12.12.1 Enabling the PHS Rules Configuration Mode /Creating a New PHS Rule

To configure the parameters for a PHS rule, first enable the PHS rules configuration mode. Run the following command to enable the PHS rules configuration mode. You can also use this command to create a new PHS rule.

```
npu(config)# phs-rule <rulename>
```

If you use this command to create a new PHS rule, the configuration mode for this PHS rule is automatically enabled, after which you can configure the parameters for the PHS rule (refer to [Section 3.4.12.12.2](#)). You can then terminate the PHS rules configuration mode (refer to [Section 3.4.12.12.3](#)) and return to the global configuration mode.

Command Syntax	npu(config)# phs-rule <rulename>
----------------	---

Privilege Level	10
-----------------	----

Syntax Description	
--------------------	--

Parameter	Description	Presence	Default Value	Possible Values
<rulename>	Denotes the PHS rule for which the PHS configuration mode is to be enabled.	Mandatory	N/A	String (1 to 30 characters)

Command Modes	Global configuration mode
---------------	---------------------------

3.4.12.12.2 Configuring Parameters for the PHS Rule

Run the following command to configure the parameters of the PHS rule:

```
npu(config-phsrule)# config [<field <value>] [<mask <value>>] [<verify <value>>] [<size <value>]>
```

**NOTE**

You can display configuration information for specific or all PHS rules. For details, refer [Section 3.4.12.12.5](#).

**IMPORTANT**

An error may occur if you provide an invalid value for any of these parameters. Refer the syntax description for more information about the appropriate values and format for configuring these parameters.

Command
Syntax

npu(config-phsrule)# config <[field <value>] [mask <value>] [verify <value>] [size <value>]>

Privilege
Level

10

Syntax
Description

Parameter	Description	Presence	Default Value	Possible Values
[field <value>]	Denotes the PHSF value, that is, the header string to be suppressed.	Mandatory	N/A	String. This parameter is of format "0x00000000000000000000000000000000". Here Octet(x), x=20 bytes, each Byte will represent two characters when used as string like in xml file.

	[mask <value>]	Indicates the PHSM, which contains the bit-mask of the PHSF with the bits set that is to be suppressed.	Mandatory	N/A	String This parameter is of format "0x000000". Here Octet(x), x=3 bytes, each Byte will represent two characters when used as string like in xml file.
	[verify <value>]	Indicates whether the PHS header is to be verified.	Optional	0 (No)	■ 0: Indicates that the PHS header should not be verified. ■ 1: Indicates that the PHS header should be verified.
	[size <value>]	Indicates the size in bytes of the header to be suppressed.	Mandatory	N/A	0-20

Command PHS rules configuration mode
Modes

3.4.12.12.3 Terminating the PHS Rules Configuration Mode

Run the following command to terminate the PHS rules configuration mode:

npu(config-phsrule)# exit

Command npu(config-phsrule)# exit
Syntax

Privilege 10
Level

Command PHS rules configuration mode
Modes

3.4.12.12.4 Deleting PHS Rules

Run the following command to delete one or all PHS rules:

```
npu(config)# no phs-rule [<rulename>]
```



CAUTION

Specify the rule name if you want to delete a specific PHS rule. Otherwise all the configured PHS rules are deleted.

Command **npu(config)# no phs-rule** [<rulename>]
 Syntax

Privilege 10
 Level

Syntax
 Description

Parameter	Description	Presence	Default Value	Possible Values
[<rulename>]	Denotes the rule name of the PHS rule that you want to delete. Specify a value for this parameter if you want to delete a specific PHS rule. Do not specify a value for this parameter, if you want to delete all PHS rules.	Optional	N/A	String

Command Global configuration mode
 Modes

3.4.12.12.5 Displaying Configuration Information for PHS Rules

To display all or specific PHS rules, run the following command:

```
npu# show phs-rule [<rulename>]
```

Specify the rule name if you want to display configuration information for a particular PHS rule. Do not specify a value for this parameter if you want to view configuration information for all PHS rule.

**IMPORTANT**

An error may occur if you provide an invalid value for the `rulename` parameter. Refer the syntax description for more information about the appropriate values and format for configuring this parameter.

Command **`npu# show phs-rule [<rulename>]`**
 Syntax

Privilege 1
 Level

Syntax
 Description

Parameter	Description	Presence	Default Value	Possible Values
[<rulename>]	Denotes the rule name of the PHS rule that you want to display. Specify a value for this parameter if you want to display the parameters of a specific PHS rule. Do not specify a value for this parameter, if you want to display all PHS rules.	Optional	N/A	String

Display PHS Configuration :
 Format `rulename field mask verify size`
`<value> <value> <value> <value> <value>`

Command Global command mode
 Modes

3.4.12.13 Managing the Hot-Lining Feature

Hot-Lining provides a WiMAX operator with the capability to efficiently address issues with users that would otherwise be unauthorized to access packet data services.

When Hot-Lining is enabled, the ASN-GW implements UL/DL traffic filters. These traffic filters are dynamically applied and removed per MSID. Triggers for filter

application/removal are relevant RADIUS messages from the AAA server. Filter's action on traffic shall be one of the following: pass, drop, or HTTP-redirect the traffic. The ASN-GW shall apply the pre-configured profile according to the Hotline-Profile-ID as delivered from the AAA server.

If filtering is applied, uplink subscriber's packet that does not match any UL-filter-rule shall be dropped. Downlink subscriber's packet that does not match any DL-filter-rule shall be dropped.

DHCP traffic in UL and DL direction is always passed.

Anti-spoofing function filtering of UL traffic is performed before the hot-lining filtering.

Hot-Lining is not applied on an MS with VLAN or Ethernet Services. If the ASN-GW receives Access-Accept message, which includes any Hot-Lining attributes, and the subject MS is granted at least one flow with CS-type of VLAN or Ethernet, the ASN-GW shall initiate De-registration of the MS.

Hot-Lining is supported only for IP-CS services using IP-in-IP tunnel or VLAN interface connectivity towards the CSN.

When Hot-Lining is disabled in ASN-GW, it shall not include Hot-Lining Capabilities attributes in any Access-Request messages. If AAA replies with Access-Accept message which includes any Hot-Lining attributes, ASN-GW shall initiate De-registration of the MS.

The following sections describe the following tasks:

- [“Enabling/Disabling the Hot-Lining Feature” on page 368](#)
- [“Managing Hot-Lining Profiles” on page 369](#)
- [“Deleting Hot-Lining Profiles” on page 379](#)
- [“Displaying Configuration Information for Hot-Lining Profiles” on page 380](#)
- [“Displaying the Status of the Hot-Lining Feature” on page 381](#)

3.4.12.13.1 Enabling/Disabling the Hot-Lining Feature

To enable the hot-lining feature, run the following command:

```
npu(config)# config hotlining-enable
```

To disable hot-lining, run the following command:

npu(config)# no hotlining-enable**IMPORTANT**

The unit must be reset after enabling/disabling hot-lining.

Command	npu(config)# config hotlining-enable
Syntax	npu(config)# no hotlining-enable

Privilege Level	10
-----------------	----

Command Modes	Global configuration mode
---------------	---------------------------

3.4.12.13.2 Managing Hot-Lining Profiles

Up to 10 hot-lining profiles can be defined. Each profile can include up to 16 filter rules and (if applicable) an HTTP-redirect URL. To manage hot-lining profiles, first enable the configuration mode for the profile (refer to [“Enabling the Profile Configuration Mode\ Creating a New Profile” on page 369](#)). You can then execute the following:

- [“Enabling/Disabling the Profile” on page 370](#)
- [“Configuring the HTTP Redirect URL for the Profile” on page 371](#)
- [“Configuring Hot-Lining Filter Rules” on page 372](#)
- [“Deleting Filter Rules” on page 378](#)
- [“Terminating the Profile Configuration Mode” on page 379](#)

3.4.12.13.2.1 Enabling the Profile Configuration Mode\ Creating a New Profile

To configure the parameters for a hot-lining profile, first enable the hot-lining profile configuration mode. Run the following command to enable the hot-lining profile configuration mode. You can also use this command to create a new profile.

npu(config)# hotlining-profile <profilename>

If you use this command to specify a new profile, the configuration mode for the newly created profile is automatically enabled, after which you can configure the profile's filtering rules (refer to [“Configuring Hot-Lining Filter Rules” on page 372](#)) or delete filter rules (refer to [“Deleting Filter Rules” on page 378](#)).

You can then terminate the hot-lining profile configuration mode (refer to [“Terminating the Profile Configuration Mode” on page 379](#)) and return to the global configuration mode.

Command npu(config)# hotlining-profile <profilename>
Syntax

Privilege 10
Level

Syntax
Description

Parameter	Description	Presence	Default Value	Possible Values
profilename	Denotes the name of the hot-lining profile for which the configuration mode is to be enabled. Must be unique per BTS. If you are creating a new hot-lining profile, specify the name of the new profile. The configuration mode is automatically enabled for the new profile.	Mandatory	N/A	String (1 to 30 characters)

Command Global configuration mode
Modes

3.4.12.13.2.2 Enabling/Disabling the Profile

After enabling the hot-lining profile configuration mode, run the following command to enable/disable the profile:

npu(config-hotlining-profile)# set profile { enabled | disabled }

Command npu(config-hotlining-profile)# set profile { enabled | disabled }
Syntax

Privilege Level 10

Syntax Description

Parameter	Description	Presence	Default Value	Possible Values
set profile { enabled disabled }	Defines whether the profile is enabled or disabled.	Optional	disabled	■ enabled ■ disabled

Command Modes hot-lining profile configuration mode

3.4.12.13.2.3 Configuring the HTTP Redirect URL for the Profile

After enabling the hot-lining profile configuration mode, run the following command to configure the HTTP redirect address (if required):

npu(config-hotlining-profile)# redirect-address <http-redirect-address>

Command Syntax npu(config-hotlining-profile)# redirect-address <http-redirect-address>

Privilege Level 10

Syntax Description

Parameter	Description	Presence	Default Value	Possible Values
redirect-address <http-redirect-address>	The HTTP redirect URL to be used by uplink filter rules with redirect action (see Section 3.4.12.13.2.4) Redirection location to be used in Http-Redirection message.	Optional	N/A	URL in ASCII string format.

Command Modes hot-lining profile configuration mode

3.4.12.13.2.4 Configuring Hot-Lining Filter Rules

Up to 16 filter rules can be defined for each hot-lining profile. To manage a filter rule, first enable the hot-lining configuration mode for the filter rule (refer to [“Enabling the Filtering Rule Configuration Mode\ Creating a New Filtering Rule” on page 372](#)). You can then execute the following:

- [“Configuring IP Address Parameters for the Filter Rule” on page 373](#)
- [“Configuring Source Port Range Parameters for the Filter Rule” on page 374](#)
- [“Configuring Destination Port Range Parameters for the Filter Rule” on page 375](#)
- [“Configuring DSCP Range Parameters for the Filter Rule” on page 376](#)
- [“Configuring IP Protocol Parameter for the Filter Rule” on page 377](#)
- [“Restoring the Default Values of Filter Rule Components” on page 377](#)



NOTE

Filtering Rules can be added/updated only when the Profile is disabled.

You can then terminate the filter configuration mode (refer to [“Terminating the Filter Rule Configuration Mode” on page 378](#)) and return to the hotlining profile configuration mode.

3.4.12.13.2.4.1 Enabling the Filtering Rule Configuration Mode\ Creating a New Filtering Rule

To configure the parameters for a filter rule, first enable the filter rule configuration mode. Run the following command to enable the filter rule configuration mode. You can also use this command to create a new filter rule.

```
npu(config-hotlining-profile)# filter-rule <string> [ direction { uplink | downlink } ] [ action { drop | pass | redirect } ]
```

If you use this command to specify a new filter rule, the configuration mode for the newly created filter rule is automatically enabled, after which you can configure the filter rule's parameters.

You can then terminate the filter rule configuration mode and return to the profile configuration mode.

The priority of checking for a match in filter rules is applied with respect to the sequence in which these filter rules were defined. The first found match is applied.

Command Syntax `npu(config-hotlining-profile)# filter-rule <string> [ direction { uplink | downlink } ] [ action { drop | pass | redirect } ]`

Privilege Level 10

Syntax Description

Parameter	Description	Presence	Default Value	Possible Values
filter-rule <string>	Denotes the unique (per BTS) name of the filter rule for which the configuration mode is to be enabled. If you are creating a new filter rule, specify the name of the new rule. The configuration mode is automatically enabled for the new filter rule.	Mandatory	N/A	String (1 to 30 characters)
direction { uplink downlink }	The direction for which the rule should be applied.	Optional	uplink	☒ uplink ☒ downlink
action { drop pass redirect }	Action to be performed on packets that match the rule, redirect is applicable only if direction is uplink. If set to redirect then redirect-address (see Section 3.4.12.13.2.3) must be defined.	Optional	pass	☒ drop ☒ pass ☒ redirect

Command Modes hot-lining profile configuration mode

3.4.12.13.2.4.2 Configuring IP Address Parameters for the Filter Rule

After enabling the filter rule configuration mode, run the following command to configure the IP address parameters of the filter rule:

`npu(config-hotlining-filter-rule)# ip-address <ipV4Addr> [<netMask>]`

If you do not configure IP address parameters for the filter rule, the default IP address (0.0.0.0) and subnet mask (0.0.0.0) will be used, meaning that IP address is ignored.

Command **npu(config-hotlining-filter-rule)# ip-address** <ipV4Addr> [<netMask>]
Syntax

Privilege Level 10

Syntax Description

Parameter	Description	Presence	Default Value	Possible Values
<ipV4Addr>	If direction is downlink then this is the downlink Source IP Address. If direction is uplink then this is the uplink Destination IP Address 255.255.255.255 means not applicable (ignore this condition).	Optional	255.255.255.255	ip address
[<netMask>]	Defines Subnet Mask associated with the configured IP address.	Optional	255.255.255.255	subnet mask

Command Modes hotlining filter rule configuration mode

3.4.12.13.2.4.3Configuring Source Port Range Parameters for the Filter Rule

After enabling the filter rule configuration mode, run the following command to configure the source port parameters of the filter rule:

npu(config-hotlining-filter-rule)# source-port start <port-number(0-65535)>
stop <port-number(0-65535)>

If you do not configure source port parameters for the filter rule, the default values will be used, meaning that source port is ignored.

Command **npu(config-hotlining-filter-rule)# source-port start** <port-number(0-65535)>
 Syntax **stop** <port-number(0-65535)>

Privilege Level 10

Syntax Description

Parameter	Description	Presence	Default Value	Possible Values
start <port-number(0-65535)>	The minimum value of source TCP/UDP port range	Optional	0	0-65535
stop <port-number(0-65535)>	The maximum value of source TCP/UDP port range	Optional	65535	0-65535

Command hotlining filter rule configuration mode
 Modes

3.4.12.13.2.4 Configuring Destination Port Range Parameters for the Filter Rule

After enabling the filter rule configuration mode, run the following command to configure the destination port parameters of the filter rule:

npu(config-hotlining-filter-rule)# destination-port start
 <port-number(0-65535)> **stop** <port-number(0-65535)>

If you do not configure destination port parameters for the filter rule, the default values will be used, meaning that destination port is ignored.

Command **npu(config-hotlining-filter-rule)# destination-port start**
 Syntax <port-number(0-65535)> **stop** <port-number(0-65535)>

Privilege Level 10

Syntax**Description**

Parameter	Description	Presence	Default Value	Possible Values
start <port-number(0-65535)>	The minimum value of destination TCP/UDP port range	Optional	0	0-65535
stop <port-number(0-65535)>	The maximum value of destination TCP/UDP port range	Optional	65535	0-65535

Command

hotlining filter rule configuration mode

Modes**3.4.12.13.2.4.5Configuring DSCP Range Parameters for the Filter Rule**

After enabling the filter rule configuration mode, run the following command to configure the DSCP parameters of the filter rule:

```
npu(config-hotlining-filter-rule)# dscp start <dscp-value(0-63)> stop  
<dscp-value(0-63)>
```

If you do not configure DSCP parameters for the filter rule, the default values will be used, meaning that DSCP is ignored.

Command**npu(config-hotlining-filter-rule)# dscp start <dscp-value(0-63)> stop****Syntax****<dscp-value(0-63)>****Privilege Level**

10

Syntax**Description**

Parameter	Description	Presence	Default Value	Possible Values
start <dscp-value(0-63)> >	The minimum value of DSCP	Optional	0	0-63
stop <dscp-value(0-63)> >	The minimum value of DSCP	Optional	63	0-63

Command hotlining filter rule configuration mode
Modes

3.4.12.13.2.4.6 Configuring IP Protocol Parameter for the Filter Rule

After enabling the filter rule configuration mode, run the following command to configure the IP protocol parameter of the filter rule:

npu(config-hotlining-filter-rule)# ip-protocol <protocol-number (0-255)>

If you do not configure the IP protocol parameter for the filter rule, the default value (255) will be used, meaning that IP protocol is ignored.

Command **npu(config-hotlining-filter-rule)# ip-protocol** <protocol-number (0-255)>
Syntax

Privilege Level 10

Syntax Description

Parameter	Description	Presence	Default Value	Possible Values
<protocol-number (0-255)>	The IP protocol number. 255 means “any” (ignore this condition).	Optional	255	0-255

Command hotlining filter rule configuration mode
Modes

3.4.12.13.2.4.7 Restoring the Default Values of Filter Rule Components

Run the following command to restore the default values of the IP address parameters: **npu(config-hotlining-filter-rule)# no ip-address**.

Run the following command to restore the default values of the source port parameters: **npu(config-hotlining-filter-rule)# no source-port**.

Run the following command to restore the default values of the destination port parameters: **npu(config-hotlining-filter-rule)# no destination-port**.

Run the following command to restore the default values of the DSCP range parameters: **npu(config-hotlining-filter-rule)# no dscp-range**.

Run the following command to restore the default value of the IP protocol parameters: **npu(config-hotlining-filter-rule)# no ip-protocol.**

Command	npu(config-hotlining-filter-rule)# no ip-address
Syntax	npu(config-hotlining-filter-rule)# no source-port
	npu(config-hotlining-filter-rule)# no destination-port
	npu(config-hotlining-filter-rule)# no dscp-range
	npu(config-hotlining-filter-rule)# no ip-protocol

Privilege	10
Level	

Command	hotlining filter rule configuration mode
Modes	

3.4.12.13.2.4.8 Terminating the Filter Rule Configuration Mode

Run the following command to terminate the filter rule configuration mode:

npu(config-hotlining-filter-rule)# exit

Command	npu(config-hotlining-filter-rule)# exit
Syntax	

Privilege	10
Level	

Command	hotlining filter rule configuration mode
Modes	

3.4.12.13.2.5 Deleting Filter Rules

Run the following command to delete a filter rule of the profile:

npu(config-hotlining-profile)# no filter-rule <filter-rule-name>

Command	npu(config-hotlining-profile)# no no filter-rule <filter-rule-name>
Syntax	

Privilege Level 10

Syntax Description

Parameter	Description	Presence	Default Value	Possible Values
<filter-rule-name>	Denotes the rule name of the filter rule that you want to delete.	Mandatory	N/A	String

Command Modes hotlining profile configuration mode

3.4.12.13.2.6 Terminating the Profile Configuration Mode

Run the following command to terminate the profile configuration mode:

npu(config-hotlining-profile)# exit

Command Syntax **npu(config-hotlining-profile)# exit**

Privilege Level 10

Command Modes hotlining profile configuration mode

3.4.12.13.3 Deleting Hot-Lining Profiles

Run the following command to delete a profile:

npu(config)# no hotlining-profile <profilename>

Command Syntax **npu(config)# no hotlining-profile <profilename>**

Privilege Level 10

Syntax**Description**

Parameter	Description	Presence	Default Value	Possible Values
<profilename>	Denotes the profile name of the profile that you want to delete.	Mandatory	N/A	String

Command

hotlining profile configuration mode

Modes**3.4.12.13.4 Displaying Configuration Information for Hot-Lining Profiles**

To display all or specific profiles, run the following command:

npu# show hotlining-profile [<profilename>]

Specify the rule name if you want to display configuration information for a particular profile. Do not specify a value for this parameter if you want to view configuration information for all profiles.

Command

npu# show hotlining-profile [<profilename>]

Syntax**Privilege**

1

Level**Syntax****Description**

Parameter	Description	Presence	Default Value	Possible Values
[<profilename>]	Denotes the profile name of the profile that you want to display. Specify a value for this parameter if you want to display the parameters of a specific profile. Do not specify a value for this parameter, if you want to display all profiles.	Optional	null	String

Display	% Asn-gw hotlining profile configuration:
Format	For each displayed profile (specific or all) the following will be displayed:
	Hotlining profile: <name>
	Redirection address: <address.>
	Status: <Disabled/Enabled>
	for each displayed profile, all defined filter rules will be displayed. For each rule, the following details will be displayed:
	Filter rule: <name>1
	Protocol: <value> (only if defined)
	Src Port: <start value-stop value> (only if defined)
	Dst Port: <start value-stop value> (only if defined)
	Action: <drop/pass/redirect>
	Direction: <uplink/downlink>
	Priority of looking for a match is according to the order of the displayed rules.

Command	Global command mode
Modes	

3.4.12.13.5 Displaying the Status of the Hot-Lining Feature

To display the status of the Hot-Lining feature, run the following command:

npu# show hotlining-status

Command	npu# show hotlining-status
Syntax	

Privilege	1
Level	

Display	Hotlining status: <Enabled/Disabled>
Format	

Command	Global command mode
Modes	

3.4.12.14 Managing the ASN-GW Keep-Alive Functionality

Once an MS enters the network, its context is stored in ASN entities (BS, ASN-GW). Dynamically, MS context could be transferred/updated (during HO and re-authentication) to other entities or duplicated to other entities (separation between anchor functions such as Authenticator, Data Path and Relay Data Path).

In certain cases, such as entity reset, other entities are not aware of service termination of an MS in that entity, and keep maintaining the MS context. This may result in service failure, excessive consumption of memory resources and accounting mistakes.

The keep-alive mechanism should be used to clear MS context from all network entities when it is de-attached from the BS, and de-register MS from the network when its context becomes unavailable in one of its serving function locations.

When the keep-alive mechanism is enabled the ASN-GW periodically polls other ASN entities-of-interest (BSs) and waits for their responses. In case of no keep-alive response, the ASN-GW shall make further actions, such as clearing the applicable MS(s) context.

The ASN-GW builds a list of BS-of-interest which it must poll. The list shall be dynamically updated; the ASN-GW tracks all BSID(s) in all MS(s) contexts it holds, and dynamically updates the list of BSs-of-interest. When a new MS is attached to a BS that does not exist in the list, it will be added to the list. When the last MS(s) with specific BSID makes network exit, the ASN-GW shall remove the BS from the list if there is no other MS attached.

The ASN-GW periodically polls the BS(s) for keep-alive. The polling mechanism is independent and unrelated for every BS-of-interest the ASN-GW polls.

The keep-alive mechanism uses configurable retry timer and retries counter. Upon expiration of the retry timer, the ASN-GW resends the ASN Keep-Alive request message. Upon expiration of the retries counter, the ASN-GW assumes failure of the polled BS and clears the contexts of all MS(s) served by that BS.

In addition, the ASN-GW verifies that for each polled entity that the “Last-Reset-Time” UTC value of poll N+1 is equal to the value of poll N. If the “Last-Reset-Time” UTC value of poll N+1 is higher than the value of poll N, this means that the BS went through reset state during the interval between two consecutive polls. In this case, the ASN-GW shall clear all MS(s) contexts, served by that specific BS that are “older” than BS life after reset (through calculation of difference between polled entity “Last-Reset-Time” received on poll N+1 and MS network entry time stamp on ASNGW).

If the ASN-GW is the authenticator for the MS(s) the failing BS served, then in addition to context clearance it also sends R3 Accounting-Request (Stop) message including a release indication to AAA.

When keep-alive fails, ASN-GW generates an event.

Regardless of the enable/disable status of the keep-alive mechanism in the ASN-GW, it replies to ASN_Keep_Alive_Req received from other BSs with ASN_Keep_Alive_Rsp. that includes also its “Last-Reset-Time”. It responds only if all its functions operate properly. In case one of the functions fails, the ASN-GW shall not respond to the keep-alive poll.

3.4.12.14.1 Configuring ASN-GW Keep-Alive Parameters

To configure one or several keep-alive parameters, run the following command:

```
npu(config)# keep-alive ([asn-ka <enable | disable>] [period <integer (10-1000)>] [rtx-cnt <integer (0-10)>] [rtx-time <integer (5000-10000)>] )
```



IMPORTANT

An error may occur if you provide an invalid value for any of these parameters. Refer to the syntax description for more information about the appropriate values and format for configuring these parameters.

An error may occur if you provide configuration values that do not satisfy following condition:
'period*1000 >= rtx-time * (rtx-cnt + 1)'

At least one parameter must be specified (the value is optional): The command npu(config)# keep-alive will return an Incomplete Command error.

Command Syntax	npu(config)# keep-alive ([asn-ka <enable disable>] [period <integer (10-1000)>] [rtx-cnt <integer (0-10)>] [rtx-time <integer (5000-10000)>])
----------------	---

Privilege Level	10
-----------------	----

Syntax
Description

Parameter	Description	Presence	Default Value	Possible Values
[asn-ka <enable disable>]	Enable/Disable the ASN-GW keep-alive mechanism.	Optional	disable	■ enable ■ disable
[period <integer (10-1000)>]	The period in seconds between polling sessions. period x 1000 (value in milliseconds) cannot be lower than rtx-time x (rtx-cnt +1).	Optional	60	10-1000
[rtx-cnt <integer (0-10)>]	Maximum number of retries if rtx-time has expired without getting a response.	Optional	5	1-10
[rtx-time <integer (5000-10000)>]	Time in milliseconds to wait for a response before initiating another polling attempt or reaching a decision that the polled entity has failed (if the maximum number of retries set by rtx-cnt has been reached).	Optional	5000	5000-10000

Command Global configuration mode
Modes

3.4.12.14.2 Displaying Configuration Information for ASN-GW Keep-Alive Parameters

To display the ASN-GW keep-alive parameters, run the following command:

npu# show keep-alive

Command npu# show keep-alive
Syntax

Privilege 1
Level

Display	% Asn-gateway Keep Alive Configuration
Format	asn-ka : <enable/disable>
	period : <value>
	rtx-cnt : <value>
	rtx-time : <value>

Command	Global command mode
Modes	

3.4.13 Configuring Logging

Logs can be generated to record events that occur with respect to the following system modules:

- System startup procedures: Refers to all procedures/events that occur during system startup.
- NPU/AU upgrade procedures: Refers to all the procedures executed while upgrading the NPU/AU.
- Fault management procedures: Refers to internal processes that are executed for monitoring erroneous conditions or fault conditions.
- System performance procedures: Refers to internal processes that are executed for monitoring system performance.
- Shelf management procedures: Refers to internal processes that are executed for monitoring the health and temperature of all hardware components (other than the NPU) such as the AU, PIU and PSU.
- WiMAX signaling protocols: Refers to all the protocols that implement the ASN-GW functionality.
- User interface: Refers to the command line or remote management interface used for executing all user-initiated events such as system shut down or reset.
- AU Manager: Refers to all internal processes used for fault, configuration, and performance management for AU.

**IMPORTANT**

The Syslog utility is used to implement the logging feature for 4Motion.

You can specify the severity level for which log messages are to be generated for each module. Logs are generated for events for which the severity level is equal to or higher than the configured level. The following are the severity levels that you can configure for each module:

- Alert
- Error
- Information

By default, system-level logging is enabled. The system stores a maximum of 1000 log and trace messages. The system stores log and trace messages using the cyclic buffer method. That is, when there are more than 1000 messages, the system overwrites the oldest log and trace messages.

**IMPORTANT**

It is recommended that you periodically make backups of log messages before these are overwritten. For details, refer to [“Making a Backup of Log Files on the NPU Flash” on page 393](#).

To configure logging, first specify system-level logging that is applicable across the entire system. You can then configure logging, individually for each system module. This section describes the commands to be used for:

- [“Managing System-level Logging” on page 386](#)
- [“Configuring Module-level Logging” on page 397](#)

3.4.13.1 Managing System-level Logging

System-level logging refers to all the procedures to be executed for managing logging for the entire system. To manage system-level logging:

- Enable/disable logging across the entire system, and specify the destination (a file on the local system or on an external server) where logs are to be maintained.
- Make periodic backups of log files.

You can, at any time, view the current log destination or delete log files from the NPU flash. After you have enabled/disabled system-level logging and specified the destination for storing log messages, you can configure logging separately for each module. You can also transfer log files from the NPU file system to an external TFTP server. To support debugging, you can create a “collect logs” file that contains the also all status and configuration files. This section describes the commands to be used for:

- [“Enabling System-level Logging” on page 387](#)
- [“Disabling Logging to File or Server” on page 389](#)
- [“Displaying System-level Logs” on page 391](#)
- [“Displaying the Current Log Destination” on page 392](#)
- [“Making a Backup of Log Files on the NPU Flash” on page 393](#)
- [“Deleting Backup Log Files from the NPU Flash” on page 395](#)
- [“Creating a Collected System Logs File” on page 396](#)
- [“Transferring Files from the NPU Flash to a TFTP Server” on page 396](#)
- [“Displaying Log Files Residing on the NPU Flash” on page 397](#)

3.4.13.1.1 Enabling System-level Logging

You can enable logging for the entire system and specify the destination where logs should be written. The destination can be either written to:

- File
- External server (Log files are sent to the external server in the Syslog log format. The Syslog daemon on the external server can save these log messages in the appropriate format depending upon the server configuration.)

By default, system-level logging is enabled. To view whether the system-level logging is enabled/disabled for logging to file or server. For details, refer [Section 3.4.13.1.4](#).

The system maintains a maximum of 1000 log and trace messages. The system stores log and trace messages using the cyclic buffer method. That is, when there

are more than 1000 messages, the system overwrites the oldest log and trace messages.



IMPORTANT

If you have enabled writing of log messages to file, it is recommended that you periodically make a backup of this log file. This is because log messages that are written to file are deleted after system reset. For more information about making backups of log files on the NPU flash, refer to [Section 3.4.13.1.5](#).

To enable system-level logging, run the following command:

```
npu(config)# log destination {file | server <IP address>}
```



NOTE

After you execute this command, logging is enabled for the entire system. You may also configure logging separately for each system module. For details, refer to [Section 3.4.13.2](#).



IMPORTANT

An error may occur if:

- Logging is already enabled for the requested destination (file or server).
- Logging is enabled to a server with a different IP address. Because logging can be enabled to only one external server, you can specify another server IP address after you disable logging to the existing server IP address. For more information about disabling logging to server, refer to [“Disabling Logging to File or Server” on page 389](#).
- An internal error has occurred.
- You have specified the IP address in an invalid format. Specify the IP address in the format, XXX.XXX.XXX.XXX.

Command	npu(config)# log destination {file server <IP address>}
Syntax	

Privilege	10
Level	

Syntax
Description

Parameter	Description	Presence	Default Value	Possible Values
{file server <IP address>}	Indicates whether logs are to be written to a file or server.	Mandatory	N/A	■ file: Indicates that logs are to be written to a file. (Logs written to file are not maintained after system reset; periodically save the log file to flash.) For details, refer to Section 3.4.13.1.5. ■ server: Indicates that logs are to be written to an external server. Specify the server IP address of the server in the format, XXX.XXX.XX.XXX.

Command Global configuration mode
Modes

3.4.13.1.2 Disabling Logging to File or Server

To disable logging to file or server, run the following command:

```
npu(config)# no log destination {file | server <IP address>}
```

**IMPORTANT**

An error may occur if:

- Logging is already disabled for the requested destination (file or server).
- An internal error has occurred.
- The server IP address that you have specified does not exist.

Command	npu(config)# no log destination {file server <IP address>}
Syntax	

Privilege	10
Level	

Syntax
Description

Parameter	Description	Presence	Default Value	Possible Values
{file server <IP address>}	Indicates whether the system-level logs are to be disabled for a file or server.	Mandatory	N/A	■ file: Indicates that system-level logging to a file is to be disabled. ■ server<ip address>: Indicates that system-level logging to a server is to be disabled. Specify the IP address if you want to disable logging to a specific server. Otherwise logging is disabled for the server that was last enabled for logging. Provide the IP address in the format, XXX.XXX.XX.XXX.

Command
Modes

Global configuration mode

3.4.13.1.3 Displaying System-level Logs

To display system-level logs, run the following command:

npu# show logs

When you run this command, all the log messages are displayed. (4Motion maintains a maximum of 1000 log and trace messages.) If you want to filter log messages to be displayed, run the following command to specify the filter criteria:

```
npu# show logs [| grep <search string>]
```

For example, if you want to view log messages pertaining to only Error logs, run the following command:

```
npu# show logs |grep ERROR
```



IMPORTANT

An error may occur if:

- There are no logs to be displayed.
- The log files are inaccessible or an internal error occurred while processing the result.

Command Syntax	npu# show logs [grep <search string>]
----------------	---

Privilege Level	1
-----------------	---

Syntax Description	
--------------------	--

Parameter	Description	Presence	Default Value	Possible Values
[grep <search string>]	Indicates the criteria for filtering the log messages to be displayed.	Optional	N/A	String

Command Modes	Global command mode
---------------	---------------------

3.4.13.1.4 Displaying the Current Log Destination

To view the current log destination, that is, whether logs are written to file or an external server, run the following command:

```
npu# show log destination
```

**IMPORTANT**

An error may occur if an internal error occurs when you execute this command.

Command npu# show log destination
Syntax

Privilege 1
Level

Display
Format

Log File : <Enabled/Disabled>

Log Server : <Enabled/Disabled>

(ServerIP - <IP address>)

Command Global command mode
Modes

3.4.13.1.5 Making a Backup of Log Files on the NPU Flash

The system stores a maximum of 1000 log and trace messages in the log file, after which the oldest messages are overwritten. This log file resides in the TFTP boot directory (/tftpboot/management/system_logs/) of the NPU. You can TFTP this file from the NPU flash. You can display the list of log files residing on the NPU flash. For details, refer [Section 3.4.13.1.9](#).

In addition, logs written to file are not maintained after system reset. If you have enabled writing of logs to file, it is recommended that you periodically make a backup of log messages on the NPU flash.

**IMPORTANT**

You can display a list of log files that are currently residing on the NPU flash. For details, refer [Section 3.4.13.1.9](#).

When you make a backup of log files on the NPU flash, the last 1000 log and trace messages are stored in a compressed file, which is saved on the NPU flash. There is no limit on the number of log files that can be saved unless there is inadequate space on the NPU flash.

**IMPORTANT**

Trace messages are also written to the same file as log messages (provided you have enabled writing of trace messages to file.) When you make a backup of log files written to file, the backup file also contains trace messages (provided you have enabled writing of trace messages to file). For more information about configuring traces, refer to [Section 3.12.1.1](#).

Run the following command to make a backup of the log and trace messages (written to file), on the NPU flash:

```
npu(config)# save log file <file name.gz>
```

When you run this command, the last 1000 log and trace messages are stored in the compressed file, which is saved on the NPU flash.

**IMPORTANT**

An error may occur if:

- You have specified the file name in an invalid format. Because the backup log file is a compressed file, always suffix the file name with **.gz**.
- The length of the file name has exceeded 255 characters.
- The system was unable to compress the file or save the compressed file to flash.
- A processing error has occurred.

Command	npu(config)# save log file <file name>
Syntax	

Privilege	10
Level	

Syntax	
Description	

Parameter	Description	Presence	Default Value	Possible Values
<file name>	Indicates the name of the compressed file that contains the last 1000 log and trace messages. Always suffix the file name with .gz .	Mandatory	N/A	<file name>.gz file name string can contain 1 to 50 printable characters.

Command Global configuration mode
Modes

3.4.13.1.6 Deleting Backup Log Files from the NPU Flash

You can delete the backup log files from the NPU flash. It is recommended that you periodically make a backup of these log files, and delete these from the NPU flash.



IMPORTANT

Trace and log messages are stored in the same backup file on the NPU flash. When you execute this procedure, trace messages are also deleted from the NPU flash. For details, refer to [“Managing System-level Tracing” on page 671](#).

To delete log and trace backup files from the NPU flash, run the following command:

```
npu(config)# erase log file [<file name>]
```



CAUTION

Specify the file name if you want to delete a specific backup file. Otherwise all the backup files residing in the NPU flash are deleted.



IMPORTANT

An error may occur if:

- The file name that you have specified does not exist.
- A processing error has occurred.

Command npu(config)# erase log file [<file name>]
Syntax

Privilege 10
Level

Syntax
Description

Parameter	Description	Presence	Default Value	Possible Values
[<file name>]	Indicates the name of the compressed log file to be deleted. If you do not specify the file name, all the log files residing in the NPU flash are deleted. Always suffix the file name with .gz .	Optional	N/A	<file name>.gz

Command
Modes

Global configuration mode

3.4.13.1.7 Creating a Collected System Logs File

To create a collected system log file that contains all current logs, status and configuration files of the system run the following command:

npu# collect logs

The name of the file is: system_logs_<Date & Time>.tar

Command
Syntax

npu# collect logs

Privilege
Level

10

Command
Modes

Global command mode

3.4.13.1.8 Transferring Files from the NPU Flash to a TFTP Server

To transfer files from the NPU flash to a TFTP server, run the following command:

npu# **transfer logs** [**server-ip** <ip-addr>] **file** {<file name (*.tar)> | All | Latest}

Command
Syntax

npu# transfer logs [server-ip <ip-addr>] file {<file name (*.tar)> | All | Latest}

Privilege
Level 10

Syntax
Description

Parameter	Description	Presence	Default Value	Possible Values
[<ip-addr>]	Indicates the IP address of the destination TFTP server.	Mandatory	N/A	IP address
{<file name (*.tar)> All Latest}	The file(s) to be transferred: <file name>.tar: A selected file that exists in the flash. All: All files in the flash. Latest: The latest created file.	Mandatory	N/A	■ <file name (*.tar)> ■ All ■ Latest

Command
Modes Global command mode

3.4.13.1.9 Displaying Log Files Residing on the NPU Flash

You can display a list of log files that are residing on the NPU flash. For details, refer [Section 3.11.2](#).

3.4.13.2 Configuring Module-level Logging

You can configure logging (enable/disable) separately for the following modules, and define the severity level for which logging is required:

- System startup procedures
- NPU/AU upgrade procedures
- Fault management procedures
- System performance procedures
- Shelf management procedures
- WiMAX signaling protocols
- User interface

- AU management procedures

This section describes the commands to be used for:

- “Configuring the Log Severity Level” on page 398
- “Displaying Configuration Information for Module-level Logging” on page 400
- “Disabling Module-level Logging” on page 401

3.4.13.2.1 Configuring the Log Severity Level

You can configure the severity level for logs to be generated for each module. This means that if an event occurs for a module for which the severity level is equal to or higher than the configured level, a log is generated. The following are the severity levels (highest to lowest) that can be configured for each module:

- Alert
- Error
- Information



IMPORTANT

By default, logging is enabled for all modules, and the severity level is Error. The severity levels recorded in 4Motion log messages are defined in RFC 3164.

To specify the severity level for each module for which logs are to be created, run the following command:

```
npu(config)# log level
[ {StartupMgr | SWDownload | FaultMgr | PerfMgr | ShelfMgr | SIGASN | UserIF | AU
Mgr} ] {ALERT | ERROR | INFO}
```

The parameters in this command correspond to the system modules/procedures listed in the following table:

Table 3-24: Modules for which Logging can be Enabled

Parameter	Refers to...
StartupMgr	System startup procedures
SWDownload	Software upgrade procedures