

Eazi-TC
Thin Client Card
Hardware Installation Guide



FCC ID: LLA-NF3000

Federal Communications Commission (FCC) Statement

This Equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning:

You are cautioned that changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference &
(2) This device must accept any interference received, including interference that may cause undesired operation.

TC-Card Hardware Installation Guide

Copyright Notice © 1998 VXL Instruments Limited ALL RIGHTS RESERVED.

Document Number : 600010105086 Z02

2nd Edition, January 1999

Printed in INDIA

Information in this document is subject to change without notice and does not represent a commitment on the part of VXL Instruments Limited. The software, which includes information contained in databases, described in this document is furnished under a license and nondisclosure agreement and may be used or copied only in accordance with the terms of the agreement. It is against the law to copy the software except as specifically allowed in the license or nondisclosure agreement. No part of this manual may be reproduced or transmitted in any form or means, electronic or mechanical, including photocopying and recording, for any purpose, without the express written permission of VXL Instruments Limited.

Eazi-TC is the registered trademark of VXL Instruments Limited.

ICA 3, WinFrame are registered trademarks of Citrix Systems, Inc.
Microsoft, MS DOS, Windows and Windows NT are trademarks of Microsoft Corporation.

DR DOS is the trademark of Caldera , Inc.

FTP is the trademark of FTP Software , Inc.

IBM PC, IBM PC / XT, IBM PC / AT are registered trademarks of International Business Machines Corporation USA.

Ethernet is the trademark of XEROX.

Novell, NetWare and IPX are registered trademarks of Novell NetWare Inc.

UNIX is the trademark of UNIX System Laboratories.

CENTRONICS is the registered trademark of Data Computer Corporation

All other Trademarks are acknowledged.



Contents

INTRODUCTION

OVERVIEW	5
FEATURES	6

INSTALLATION


INSTALLATION PROCEDURE.....	7
TYPICAL NETWORK INSTALLATIONS	8
PC BIOS SETUP	9
CUSTOMIZING THE CONFIGURATION.....	10
TC-CARD SETUP.....	12

SPECIFICATIONS

MECHANICAL.....	14
ENVIRONMENTAL.....	14
ELECTRICAL	14
NETWORK CONNECTION.....	14
VIDEO CONNECTION	14

CONNECTORS & CABLING INFORMATION

CONNECTORS	16
10BASE-T	16
10BASE-2	16
Video Port	17
CABLING REQUIREMENTS	17
10BASE-T Connection.....	17



Chapter-1

INTRODUCTION

OVERVIEW

Congratulations!

You have made the right decision to protect your investment in your existing PC.

Easy to install, TC-Card instantly converts an IBM compatible PC into a Thin Client. After installation you can use your system either in PC mode or as a Thin Client. Following installation into the PC, we will refer to the PC system as a Thin Client while it is connected onto a ICA network.

The Thin Client provides a cost effective route of bringing Windows applications to the desktop, providing network users with the user friendly Windows NT™ operating system.

The Thin Clients are essentially terminal devices that connect onto multi-user application servers operating under the Citrix MetaFrame™, Citrix WinFrame™ and Windows NT operating system. They communicate with the application server via the ICA protocol developed by Citrix Systems Inc.

The client has built within it simple setup procedures which allow the definition of server connection configuration, user names, resolution, passwords and a variety of other customizable features.

The Thin Client is equipped with a 10Base-T Ethernet port which gives an instant connection to a multi-user Windows NT™ application server.



FEATURES

The Thin Client terminal:

- is fully compatible with all Windows 3.1, Windows 95, Windows NT and DOS (text) applications through WinFrame and ICA based application servers.
- provides secure access to network resources.
- provides extremely low administration costs.
- is 100% ICA 3 protocol compliant.
- can be directly connected to any server equipped with Microsoft NT Server – TSE, Citrix™ MetaFrame™ Enterprise, Citrix™ MetaFrame™ Terminals, Citrix™ WinFrame™ Enterprise, Citrix™ WinFrame™ Terminals, Insignia™ Solutions NTrigue™, NCD WinCenter Pro, Tektronix™ WinDD™ or any other server supporting the ICA 3™ protocol.

Note: In an endeavor to provide a better product to you, the customer, our Company pursues continuous development of software and hardware features. As a result the product you received may have features additional to those contained and described within this guide.

OPTIONAL FEATURES ^{*}:

- VGA port supporting SVGA display monitors.
- 10Base-2 Ethernet port.

* Some of the options are mutually exclusive. Only certain combinations of the optional features are possible.

Chapter-2

INSTALLATION

The TC-Card carton would contain:

- TC-Card
- Hardware Installation Guide (which you are currently reading)
- Software User's Guide

Note: Trans-shipment should be done in the original packing to avoid damage. Retain the carton and package material for re-packing.

INSTALLATION PROCEDURE

- Switch off the PC. Remove the PC's cabinet cover.
- **Precaution :** Always switch off the PC before removing or inserting the card.
- Insert the TC-Card in one of the empty ISA slots. Fix the TC-Card's clamp to PC's cabinet.
- Re-fix the PC's cabinet cover.
- Connect the monitor cable to the VGA connector of the card.

If you are already using a display card, change the VGA option in the TC-Card using P11 jumper setting as shown in the table below.

Option	Jumper P11
Disable VGA	Pin 1 & 2 short
Enable VGA	Pin 2 & 3 short

After the TC-Card is fixed into your PC, the PC system is called as a Thin Client with reference to your ICA network. Connect the Thin Client to the server by any of the means described in the topic "Typical Network Installations".


7
CENTRE
COPY
CONTROL COPY
IN RED COLOUR
66
CENTRE COPY

TYPICAL NETWORK INSTALLATIONS

The Thin Client communicates with the server using the ICA 3 protocol. This section illustrates how to install Thin Client in different network topologies. The Thin Client can be linked to the server by:

- LAN connection through TCP/IP through 10base-T (10base-2 optional)
- Direct connection through RS232 (through a serial port)
- Dial-In remote connection through modem (through a serial port)

If LAN connection through TCP/IP is desired, then connect 10BASE-T cable from Thin Client 10BASE-T outlet to a hub as shown in figure.



LAN Connection (Through 10BASE-T)

ALL RIGHTS RESERVED
CONTROL COPY
IN RED COLOUR
\$6
COPYRIGHT CONTROL

TC-Card Hardware Installation Guide

If Direct Connection through RS232 is desired, connect


- RS232 cross cable from a PC serial port (COM1 or COM2) to a Server serial port as shown in figure below.



Direct Connection through RS232

If Dial-In Remote Connection through modem is desired, connect

- RS232 straight cable from a PC serial port to a modem connected to telephone line as shown in figure below.



Dial-In Remote Connection through Modem

Refer to chapter "Connectors & Cabling Information" for more information about connectors and cables.

PC BIOS SETUP

- Switch on the PC
- Enter the BIOS setup, instructions will appear on the display directing you to press a special key such as "del" key at the required time. Set below listed parameters to the specified values.

BIOS Parameter	Change to
Boot Sequence	C,A
D000-D3FF Shadow	Disabled**

* BIOS setup procedure and default values of all PC BIOS are not same. Please use your PC's installation/user's manual to locate how to access setup utility and how to change above parameter values. In case of problem in locating or changing above parameters, please contact your PC's supplier.

** If Jumper P9 is equipped, the Shadow RAM area D8000-DBFF should be disabled.

CONTROL COPY
IN RED COLOUR

9 6

DOCUMENT CO

If your BIOS supports Plug and Play (PnP), enter the PnP PCI CONFIGURATION.

The TC-Card is not configured for PnP and if your PC supports this feature, it should be disabled for the ISA slot and IRQ selected for this card. Default IRQ is 5.

PnP PCI CONFIGURATION	
Resources controlled by	Manual
IRQ 5	Legacy ISA

For other BIOS that support PnP with different setup fields, follow the BIOS instructions to select the TC-Card IRQ as non-PNP.

- Save and exit from the setup.
- Reset the PC, using Reset button.

After few moments the following message would appear.

```
#TC-Card Configuration#
TC-Card is using IRQ 5 and IO_Base 300h
Press Ctrl+Alt+z to change settings . . .
```

NOTE : If you want to change the setup configuration, press Ctrl+Alt+z. Refer to section TC-Card Setup for details.

If there is no response from keyboard for few seconds, the system boots through TC-Card and Thin Client model screen appears which is followed by client prompt Enter the Client Name.

Conduct Thin Client setup. Refer to your Thin Client Software User's Guide.

If the system does not boot through TC-Card for the default values, refer the topics "Customizing the Configuration" and "TC-Card Setup".

RECEIVED
CONTROL COPY
* IN RED COLOUR
DOCUMENT COPY
#6

CUSTOMIZING THE CONFIGURATION

In most cases the default settings should allow for a simple installation of the TC-Card. With some PCs, particularly those that had been used with many card devices, special setup may be required.

The TC-Card is factory set to operate at IRQ 5 and IO_Base 300h by default and uses memory space D000-D3FF. This setting may be currently used by another card within your PC. There may be two cases to customize your TC-Card.


Case 1 IRQ 5 & IO_Base 300h already in use by another card

- In order to rectify this first reset your PC. Using a system diagnostic utility like MSD of DOS 6.0, note down the unused (unoccupied) IRQ's (between 0-7), IO_Base (between 200 - 3E0).

These parameters are required to configure your card through TC-Card Setup application. Refer to following section Setup application for changing the existing settings.

Case 2 During startup #TC-Card Configuration# message does not appear

- Check whether memory segment D000-D3FF is occupied. If occupied,
 - switch off the PC and remove the screws
 - equip the jumper P9 on the TC-Card
 - refix the PC screws and switch on the PC
 - enter PC-Bios and disable the Shadow RAM D8000-DBFF area




TC-CARD SETUP

TC-Card setup application is used to configure your TC-Card. To enter into the TC-Card setup application:

- Reset the PC
- After few moments the following message would appear :

```
#TC-Card Configuration#  
  
TC-Card is using IRQ 5 and IO_Base 300h  
Press Ctrl+Alt+z to change settings . . .
```


- Now press Ctrl+Alt+z simultaneously.
- You would enter the TC-Card Setup as shown below.



TC-Card Setup Dialog Box

VXL REPRO-ENVIRONMENT
* CONTROL COPY *
* IN RED COLOUR *
* DOCUMENT CONTROL *


This page is intentionally left blank



CONNECTORS

Pin	Signal	6	RXD-
3	RXD+	3	RXD+
2	TXD-	2	TXD-
1	TXD+	1	TXD+

10BASE-T



Pin	Signal	2	GND
1	SIGNAL	1	SIGNAL




10BASE-2


CONNECTORS & CABLING INFORMATION

Appendix-B

Staright Connection - (With Hub)




Cross Connection - (Without Hub)



10BASE-T Connection

CABLING REQUIREMENTS

Pin	Signal	Pin	Signal
1	Red	6	Red return GND
2	Green	7	Green return GND
3	Blue	8	Blue return GND
4	No Connection	9	No Connection
5	GND	10	GND
11	No Connection	14	Vertical Sync
12	No Connection	13	Horizontal Sync
15	No Connection		



TC-CARD CONTROL
V2.1
PRINTED COLOR
46
DOCCUENT
CONTROL COPY
PRINTED COLOR

NOTES

SPECIFICATIONS

Appendix-A

Mechanical

Height	25 mm	Width	121 mm
Depth	180 mm		
Weight (approximately)	150 gm		

Environmental

Operating Temperature	+ 5° C to + 50° C	Storage Temperature	- 20° C to + 65° C
Humidity	10% to 90% RH non condensing		

Electrical

Power Consumption (Max.) 1.5W

Network Connection

10Base-T Interface	RJ-45 Modular 8 pin jack (for twisted pair cable)	BNC Connector (for thin coaxial cable)	10Base-2 (Optional)
IRG Options	2/9, 3, 4, 5, 10, 11, 12, 15	I/O Base Address	200, 220, 240, 260, 280, 2A0, 2C0, 2E0, 300,
I/O Options	320, 340, 360, 380, 3A0, 3C0, 3E0	Options	
Status Indicator	Green LED		

Video Connection

SVGA compatible

SAVE & EXIT

- Save the setup changes and then to exit from the setup. Press **ESC** to exit from the setup without saving setup changes. Press **ESC** to exit from the setup with saving setup changes. Press **ESC** to exit from the setup and then to exit from the setup. Press **ESC** to exit from the setup. Save and Exit from the setup.
- If you want to use TC-Card as a VGA Card press **Enter** key on the field **Disable Network Controller**. This disables the TC-Card booting as Thin Client.

TC-CARD OPTIONS

- You can select one of the free IO-BASE VALUES listed. * Notation indicates that the IO-BASE is occupied by other devices & cannot be selected.
- You can select one of the free IO-BASE VALUES listed. * Notation indicates the IO-BASE is occupied by other devices & cannot be selected.
- Set the IO-BASE to the value noted as an unoccupied IO-BASE address in the PC's BIOS setup.
- Set the IO-BASE to the value noted as an unoccupied IO-BASE address in the PC's BIOS setup.

SELECT IO-BASE

- You can select one of the free IRQs listed. * Notation indicates that the IRQ is occupied by other devices & cannot be selected.
- You can select one of the free IRQs listed. * Notation indicates the IRQ is occupied by legacy ISA in PC's BIOS setup.
- Set the IRQ to the value, which you set to legacy ISA in PC's BIOS setup.

SET NETWORK IRQ

- Select this option, if you want to see the current configuration of the TC-Card. You can see the IRQ and IO-Base address that is currently used.
- Ethernet address is purely voluntary. This is also referred to as the MAC address and cannot be altered.

VIEW CURRENT CONFIGURATION

The TC-Card setup is pre-loaded with default values. Use the cursor keys to move among the fields and menu items. The setup basically consists of following options: