

PSR-78-9537-XB MANUAL

VERSION 0.24



**3116 West Vanowen St.
Burbank, CA 91505
Tel: 818-840-8131
Fax: 818-840-8138**

www.adrftech.com



*Information in this document is subject to change without notice.
Advanced RF Technologies, Inc. 1996-2019.
All rights reserved.*

Please send comments to:

E-Mail: info@adrfttech.com

Phone: (818) 840-8131

(800) 313-9345

Fax: (818) 840-8138

Address:

Advanced RF Technologies, Inc.
Attention: Technical Publications Department
3116 Vanowen St.
Burbank, CA 91505
USA
www.adrfttech.com

REVISION HISTORY

Version	Author	Descriptions	Date
0.1	ADRF	Initial Release	08/07/2019
0.12	ADRF	update	09/11/2019
0.22	ADRF	B9B Update	08/04/2020
0.23	ADRF	update	09/04/2020
0.24	ADRF	update	22/04/2020

CHANGE LIST

Version	Change list	Contents

TABLE OF CONTENTS

1.	Introduction	9
1.1	Highlights	9
1.2	Parts List.....	10
1.3	Quick View	11
1.4	Warnings and Hazards	13
2.	Overview	17
2.1	LED	17
2.2	Host / Remote Switch	17
2.3	Cable Connection	18
2.3.1	AC Power	18
2.3.2	External Alarm	19
2.3.3	RF.....	20
2.3.4	Annunciator	20
2.3.5	Back Up Battery Port	21
2.3.6	Grounding.....	22
3.	Alarms	23
3.1	Message Board Alarms and Notifications.....	23
3.2	Alarms	23
3.3	External Alarms.....	24
3.3.1	External Alarm Output interface	24
3.3.2	External Alarm Input interface	25
4.	Installation	25
4.1	Installation Procedures	25
4.1.1	Wall Mount Procedure	25
4.1.2	PSR-ANN Annunciator Installation	26
4.2	Antenna Separation/Isolation.....	28
5.	PSR-78-9533-X/9537-X Web-GUI Setup.....	30
5.1	Repeater/PC Connection Using Web-GUI.....	30
5.2	Status Tab	31
5.2.1	Band Info	32
5.2.2	Power & Gain.....	32
5.2.3	Alarms.....	33
5.2.4	AAI	33
5.2.5	Repeater Info / Repeater Location / Technical Support / Installer Contact Info.....	34
5.3	Control Tab	35
5.3.1	General Settings	36
5.3.1.1	Emergency Power Off Switch Support	36
5.3.2	System	36
5.3.3	Manual Gain Control	37

5.3.4	Alarm Settings & Battery Alarm Settings.....	37
5.4	Install Tab.....	38
5.4.1	Technology	39
5.4.2	Band Selection	39
5.4.3	SNMP	40
5.4.4	Location	40
5.4.5	Modem Box Setting	40
5.4.6	AAI Input.....	41
5.4.7	Location Info / Installer Info	41
5.4.8	Date & Time.....	41
5.5	System	42
5.5.1	System: Account	42
5.5.1.1	System: Account – Account Management.....	42
5.5.1.2	System: Account – New Account.....	42
5.5.1.3	System: Account – Change Password	42
5.5.2	System – SNMP.....	43
5.5.3	System – Logs	43
5.5.4	System – Update	44
5.5.5	System – Backup / Restore	44
5.6	Help.....	45
5.7	Logout	45
6.	Maintenance Guide for PSR-78-9533-X/9537-X Repeater.....	45
6.1	Periodic Inspection Checklist	45
6.2	Preventive Measures for Optimal Operation	45
6.2.1	Recommendations.....	45
6.2.2	Precautions.....	45
7.	Warranty and Repair Policy	46
7.1	General Warranty	46
7.2	Limitations of Warranty.....	46
7.3	Limitation of Damages.....	46
7.4	No Consequential Damages.....	46
7.5	Additional Limitation on Warranty	46
7.6	Return Material Authorization (RMA)	46
8.	Specifications	47
8.1	Electrical Specifications	47
8.2	Mechanical Specifications.....	48
8.3	Power Specifications.....	48
8.4	Warranty & Certificates	48
9.	Mechanical Drawing	52
10.	Appendix	56

10.1	Shutdown Retry Logic.....	56
------	---------------------------	----

FIGURES

Figure 1-1	PSR-78-9533-X/9537-X Repeater Parts List	10
Figure 1-2	PSR-78-9533-X/9537-X Quick View (Bottom).....	11
Figure 1-2	PSR-ANN Annunciator	12
Figure 2-1	LED Panel.....	17
Figure 2-2	Host/Remote Switch.....	18
Figure 2-3	AC Input Port	18
Figure 2-4	AC On/Off Switch.....	18
Figure 2-5	External Alarm Port	19
Figure 2-6	RF Ports.....	20
Figure 2-10	Annunciator Port	20
Figure 2-7	Battery Backup Port (4-pin Female)	21
Figure 2-8	Battery Switch	21
Figure 2-9	Ground Cable Terminal.....	22
Figure 4-1	Wall Mount.....	25
Figure 4-2	PSR-ANN Repeater Mount.....	26
Figure 4-3	PSR-ANN Wall Mount	27
Figure 4-4	RF Repeater Oscillation	28
Figure 5-1	Login Page	30
Figure 5-2	Status Tab	31
Figure 5-3	Status Tab – Band Info Display	32
Figure 5-4	Status Tab – Power & Gain Display	32
Figure 5-5	Status Tab – Alarm Display	33
Figure 5-6	Status Tab – AAI Alarm Display (Remote Power Switch Disabled)	33
Figure 5-7	Status Tab – AAI Alarm Display (Remote Power Switch Enabled).....	33
Figure 5-8	Status Tab – Repeater Info / Repeater Location / Technical Support / Installer Contact Info	34
Figure 5-9	Control Tab	35
Figure 5-10	Control Tab – General Setting	36
Figure 5-11	AAI Alarm Cable – Alarm Input	36
Figure 5-12	Control Tab – System.....	36
Figure 5-13	Control Tab – Manual Gain Control.....	37
Figure 5-14	Control Tab – Alarm & Battery Alarm Settings.....	37
Figure 5-15	Install Tab	38
Figure 5-16	Install Tab – Technology	39
Figure 5-17	Install Tab – Band Selection.....	39
Figure 5-18	Install Tab – SNMP.....	40
Figure 5-19	Install Tab – Location	40
Figure 5-20	Install Tab – Modem Box Setting.....	40
Figure 5-21	Install Tab – AAI Input	41
Figure 5-22	Install Tab – Location Info / Installer Info	41
Figure 5-23	Install Tab – Date & Time	41
Figure 5-24	System: Account – Account Management	42
Figure 5-25	System: Account – New Account.....	42
Figure 5-26	System: Account – Change Password	42
Figure 5-27	SNMP	43
Figure 5-28	System: Logs	43
Figure 5-29	System: Update	44
Figure 5-30	System: Update is Complete Popup Message	44

Figure 5-31	System: Backup / Restore.....	44
Figure 5-32	Help	45
Figure 9-1	PSR-78-9533-X Mechanical Drawing	53
Figure 9-2	PSR-78-9537-XB Mechanical Drawing	54
Figure 9-3	PSR-ANN Annunciator Mechanical Drawing.....	55

TABLES

Table 1-1	Parts List	10
Table 2-1	LED Specifications.....	17
Table 2-2	External Alarm Port Pin Description	19
Table 3-1	Message Board Alarms and Notifications.....	23
Table 3-2	Alarms.....	23
Table 8-1	Electrical Specifications	47
Table 8-2	Mechanical Specifications	48
Table 8-3	Power Specifications	48
Table 8-4	Warranty & Certificates.....	48

Terms and Abbreviations

The following is a list of abbreviations and terms used throughout this document.

Abbreviation/Term	Definition
AGC	Automatic Gain Control
ALC	Automatic Level Control
AROMS	ADRF Repeater Operation and Management System
BDA	Bi-Directional Amplifier
BTS	Base Transceiver Station
CDMA	Code Division Multiple Access
CFR	Crest Factor Reduction
CP	Cyclic Prefix
CW	Continuous Wave (un-modulated signal)
DAS	Distributed Antenna System
DL	Downlink
HPA	High Power Amplifier
HW	Hardware
IF	Intermediate Frequency
LNA	Low Noise Amplifier
LTE	Long Term Evolution
MS	Mobile Station
OFDM	Orthogonal Frequency-Division Multiplexing
OFDMA	Orthogonal Frequency-Division Multiple Access
PAR (PAPR)	Peak to Average Power Ratio (Crest Factor)
PLL	Phase Locked Loop
PSU	Power Supply Unit
QAM	Quadrature Amplitude Modulation
QPSK	Quadrature Phase Shift Keying
RB	Resource Block
RF	Radio Frequency
SC-FDMA	Single Carrier-Frequency Division Multiple Access
SQE	Signal Quality Estimate
SW	Software
UE	User Equipment
UL	Uplink
VSWR	Voltage Standing Wave Ratio

1. INTRODUCTION

PSR-78-9537-XB bi-directional amplifiers (BDAs) extend the coverage area of radio communications in buildings and RF shadow environments. These units feature low noise figure and wide dynamic range and are certified to UL 2524.

The PSR-78-9537-XB is a revolutionary digital public safety repeater designed to protect the lives of first responders and building occupants.

Through the use of digital signal processing (DSP) filtering technology, the PSR-78-9537-XB helps eliminate adjacent channel interference to allow band selectivity and support for 700 MHz (FirstNet) frequencies including FirstNet. Up to two non-contiguous wideband filters can be simultaneously supported in the 700 MHz frequencies via ADRF's celebrated web-based GUI, which provides versatility and total control to the user.

The PSR-78-9537-XB is the best-in-class public safety repeater with FirstNet support and it is fully compliant with International Fire Code (IFC) and National Fire Protection Association (NFPA).

Product Features

- NFPA 1221 2016 code compliant and FirstNet compliant
- Alarming output to supervised circuits for: antenna, amplifier, power supply, battery, and charger failure
- IP66 compliant enclosure for both indoor and outdoor environments
- Class B wideband repeater designations
- Up to 95dB of gain and up to 37 dBm downlink output power per band and up to 30 dBm uplink output power shared

1.1 Highlights

- UL 2524 Certified
- Supports 700MHz (FirstNet) Public Safety Frequency in a single repeater
- Supports 2 wideband (LTE 5 & 10 MHz)
- Air convection cooling without fans
- Sharp Filter Roll-off performance (Wide: 60dBc @ Filter Bandwidth Edge + 1MHz | Narrow: 55dBc @ Filter Bandwidth Edge + 3 * Filter BW)
- Supports SNMP v1, v2c, v3 (get and set)
- Web-based GUI Interface; No 3rd party GUI software required
- Web-GUI connectivity via DHCP in host mode
- External Alarm Function supporting dry contacts (11 outputs, 1 input)
- Support Emergency Power Off Switch

1.2 Parts List

Table 1-1 Parts List

Label	Quantity	Description
A	1	PSR-78-9537-XB
B	1	Wall Mount Bracket
C	1	Mounting Bracket Template
D	1	AAI Alarm Cable
E	1	AC Power Cable
F	1	Ethernet Cable (Crossover)
G	4	Anchor Bolt
H	1	PSR-ANN (Annunciator Panel)




Figure 1-1 PSR-78-9537-XB Repeater Parts List

1.3 Quick View




Figure 1-2 PSR-78-9537-XB Quick View (Bottom)




Figure 1-3 PSR-ANN Announcer

1.4 Warnings and Hazards



WARNING! ELECTRIC SHOCK

Opening the PSR-78-9533-XB could result in electric shock and may cause severe injury.



WARNING! DAMAGE TO REPEATER

Operating the PSR-78-9533-XB with antennas in very close proximity facing each other could lead to severe damage to the repeater.

RF EXPOSURE & ANTENNA PLACEMENT Guidelines

Actual separation distance is determined upon gain of antenna used.

Please maintain a minimum safe distance of at least 400cm while operating near the donor and the server antennas. Also, the donor antenna needs to be mounted outdoors on a permanent structure.

WARRANTY

Opening or tampering the PSR-78-9537-XB will void all warranties.

Lithium Battery: CAUTION. RISK OF EXPLOSION IF BATTERY IS REPLACED BY INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO INSTRUCTIONS.

In accordance with the FCC regulations, this device must meet 5W ERP requirements.

To satisfy this, the antenna cable name we propose is LMR200. If available, the antenna length must be at least of 30m (antenna cable loss at 30m is about 8 dBi). If you use another antenna cable, the cable loss must be considered to more than DL: 2dBi and UL: 7 dBi. So, the maximum antenna gain after accounting for any cable losses should be UP To DL: 0.6 dBi, Omni antenna / UL: 8 dBi, Pannel antenna.

Preclude indications that Home/ personal use are prohibited.

Use of unauthorized antennas, cables, and/or coupling devices not conforming with ERP/EIRP is prohibited.

FCC Part 15.21

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

FCC Part 15 Class A

NOTE: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at their own expense.

Regulatory Warning Statement

FCC RF Radiation Exposure Statement:

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 400 cm between the radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

RSS-GEN, Sec. 7.1.2– (transmitters)

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.

Conformément à la réglementation d'Industrie Canada, le présent émetteur radio peut fonctionner avec une antenne d'un type et d'un gain maximal (ou inférieur) approuvé pour l'émetteur par Industrie Canada.

Dans le but de réduire les risques de brouillage radioélectrique à l'intention des autres utilisateurs, il faut choisir le type d'antenne et son gain de sorte que la puissance isotroperayonnée équivalente (p.i.r.e.) ne dépasse pas l'intensité nécessaire à l'établissement d'une communication satisfaisante.

RSS-GEN, Sec. 7.1.2– (detachable antennas)

This radio transmitter (identify the device by certification number, or model number if Category II) has been approved by Industry Canada to operate with the antenna types listed below with the maximum permissible gain and required antenna impedance for each antenna type indicated. Antenna types not included in this list, having a gain greater than the maximum gain indicated for that type, are strictly prohibited for use with this device.

Maximum antenna gain after accounting for any cable losses should be up to DL: 0.6 dBi, Omni antenna /UL: 8 dBi, Panel antenna (minimum Antenna cable length : 30 m).

Le présent émetteur radio (identifier le dispositif par son numéro de certification ou son numéro de modèle s'il fait partie du matériel de catégorie I) a été approuvé par Industrie Canada pour fonctionner avec les types d'antenne énumérés ci-dessous et ayant un gain admissible maximal et l'impédance requise pour chaque type d'antenne. Les types d'antenne non inclus dans cette liste, ou dont le gain est supérieur au gain maximal indiqué, sont strictement interdits pour l'exploitation de l'émetteur.

RF Radiation Exposure

This equipment complies with RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 400 cm between the radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. RF exposure will be addressed at time of installation and the use of higher gain antennas require larger separation distances.

L'antenne (ou les antennes) doit être installée de façon à maintenir à tout instant une distance minimum de au moins 400 cm entre la source de radiation (l'antenne) et toute personne physique. Cet appareil ne doit pas être installé ou utilisé en conjonction avec une autre antenne ou émetteur.

◆LABEL WARNING◆**Part 90 Signal Boosters****This is A 90.219 CLASS B DEVICE**

WARNING. THIS is NOT a CONSUMER device. It is designed for installation by FCC LICENSEES and QUALIFIED INSTALLERS. You MUST have an FCC LICENSE or express consent of an FCC Licensee to operate this device. You MUST register Class B signal boosters (as defined in 47 CFR 90.219) online at www.fcc.gov/signal-boosters/registration. Unauthorized use may result in significant forfeiture penalties, including penalties in excess of \$100,000 for each continuing violation.

2. OVERVIEW

2.1 LED

PSR-78-9537-XB LED indicator lights are located on the inside of the repeater towards the bottom. Below the LED indicators is a button that is used to trigger the door open alarm.



Figure 2-1 LED Panel

Table 2-1 LED Specifications

POWER	DL	UL	ALARM
AC Fail	DL Signal Not Detected	UL Out-Band Overload	Power-Related Alarms
DC Fail	DL Signal Low Detected	UL Input Overload	RF DL Path Related Alarms
Battery Fail	DL RF Power	UL DSP Over Input	RF UL Path Related Alarms
Low Battery	DL Out-Band Overload	UL Over Input	Over Temperature
Battery Not Charge	DL Input Overload	UL Over Power	DSP Communication
Battery Not Connected	DL DSP Over Input	UL Return Power	Door Open
Over Current	DL Over Input	UL PLL Fail	System Halt
	DL Over Power		
	DL Return Power		
	DL PLL Fail		

LED Indicator	Specifications
Solid Green	Normal operation
Solid Yellow	Soft Fail alarm exists in the system
Solid Red	Hard Fail alarm exists in the system

2.2 Host / Remote Switch

The Host/Remote Switch allows the user to switch the default Repeater IP, Subnet Mask, and Gateway of the Ethernet port of the repeater to an alternative setup. These settings can only be adjusted by logging into the repeater under HOST mode and configuring the settings under the Modem Box Setting section on the Install Page (section 5.4.5).

Once the settings are set, flipping the switch to the REMOTE position will reboot the repeater with the new alternate settings. *Please note that when the repeater is set to the REMOTE position, DHCP is disabled and the repeater will not automatically assign an IP address to any device that connects directly to the repeater.*

- Host IP: 192.168.63.1 (Fixed IP, unable to modify this IP address)
- Remote IP: 192.168.63.5 (Default IP, but can be modified in Host mode)
-



Figure 2-2 Host/Remote Switch

2.3 Cable Connection

2.3.1 AC Power

AC power is accepted through a standard 3-wire male plug (MS3106A-22-2S) with phase, neutral, and ground leads. The AC power is wired to a high-efficiency DC switching power supply which is UL approved.

The AC port is located at the bottom of the repeater and has a free-voltage range input of 100-240V AC.



Figure 2-3 AC Input Port




Figure 2-4 AC On/Off Switch

The AC Power on/off switch is on the left-hand side of the PSU which is located inside of the repeater.

2.3.2 External Alarm



Figure 2-5 External Alarm Port

This port should be connected only to the fire alarm control panel.

Table 2-2 External Alarm Port Pin Description

Pin	Bundle	Color	Pin Description (24 pins)	ADRF External Alarm Box Pin Description	Alarm Type
A	Fire	Black	Donor antenna malfunction_P	1-POS	Output
B		Black	Donor antenna malfunction_N	1-NEG	Output
C		Brown	Active RF device malfunction_P	2-POS	Output
D		Brown	Active RF device malfunction_N	2-NEG	Output
E		Red	Low battery capacity (70%)_P	3-POS	Output
F		Red	Low battery capacity (70%)_N	3-NEG	Output
G		Orange	System component malfunction_P	4-POS	Output
H		Orange	System component malfunction_N	4-NEG	Output
J	System Monitoring	Yellow	Normal AC Power_P	5-POS	Output
K		Yellow	Normal AC Power_N	5-NEG	Output
L		Green	Loss of normal AC Power_P	6-POS	Output
M		Green	Loss of normal AC Power_N	6-NEG	Output
N		Blue	Battery charger failure_P	7-POS	Output
P		Blue	Battery charger failure_N	7-NEG	Output
Q		Purple	Low battery capacity (70%)_P	8-POS	Output
R		Purple	Low battery capacity (70%)_N	8-NEG	Output
S		Grey	Donor antenna malfunction_P	9-POS	Output
T		Grey	Donor antenna malfunction_N	9-NEG	Output
U		White	Active RF emitting device malfunction_P	10-POS	Output
V		White	Active RF emitting device malfunction_N	10-NEG	Output
W	Alarm Input	Pink	System component malfunction_P	11-POS	Output
X		Pink	System component malfunction_N	11-NEG	Output
Y	Alarm Input	Light Blue	Alarm Input-1	-	Input
Z		Light Blue	GND	-	GND

2.3.3 RF




Figure 2-6 RF Ports

The RF connections are made via two 4.3-10 female connectors. The RF connector labeled “DONOR” must be connected to the antenna pointing towards the base station. The DONOR port can receive both 700 and 800MHz public safety signals. The RF connection labeled “SERVER” must be connected to the antenna facing the area to be covered by the BDA. The repeater has a single SERVER port that supports both 700 and 800MHz public safety signals.

The RF connections must be made using cables with an impedance of 50 ohms.

The separation between the antennas is necessary to prevent oscillation. Oscillation occurs when the signal entering the system continually re-enters, due to the lack of separation between the donor and server antennas. In other words, the signal is being fed back into the system. This creates a constant amplification of the same signal. As a result, the noise level rises above the signal level.

To prevent feedback, the donor and server antennas must be separated by an appropriate distance to provide sufficient isolation. Isolation is attained by separating antennas a sufficient distance so that the output of one antenna does not reach the input of the other. This distance is dependent on the gain of the repeater.

- **DONOR** – 4.3-10 female which is used to connect the donor antenna (700MHz + 800MHz PS)
- **DONOR_CPL (30dB)** – SMA female 30 dB coupling port which is used to monitor the amplified UL signal
- **SERVER_CPL (30dB)** – SMA female 30 dB coupling port which is used to monitor the amplified DL signal
- **SERVER** – 4.3-10 female which is used to connect the server antenna (700MHz + 800MHz PS)

2.3.4 Annunciator

The Annunciator port provided power and communication to the PSR-ANN annunciator box. The PSR-ANN annunciator box provides a summary status of the repeater via LED indicator lights and an audible alarm.



Figure 2-7 Annunciator Port

2.3.5 Battery Backup Port

This port connects to the ADRF-BBS/BBL-24 (24V battery backup unit) via a dedicated cable provided by the ADRF.



Figure 2-8 Battery Backup Port (4-pin Female)

If an ADRF-BBS/BBL-24 is connected to the repeater, the battery switch on the PSU must be switched to the ON position. This will enable the repeater to charge the ADRF-BBS/BBL-24 battery backup unit when AC power is present.



Figure 2-9 Battery Switch

The PSR-78-9537-XB can be connected to an ADRF-BBS/BBL-24 to provide power during a power failure. If an ADRF-BBS/BBL-24 is utilized, connect it to the PSR-78-9537-XB via the external battery port.

(WARNING: The circuit breaker switch on the ADRF-BBS/BBL-24 must be set to OFF before connecting it to the PSR-78-9537-XB to prevent damage to the repeater or the ADRF-BBS/BBL-24 and personal injury.)

Note: Please contact ADRF Technical Support for assistance if you are unfamiliar with the installation procedure of the battery box.

2.3.6 Grounding

The grounding terminal is located at the lower right-hand side of the BDA. A grounding cable should be properly connected before powering on the equipment.



Figure 2-10 Ground Cable Terminal

Ground terminals located on the side of the repeater and can support a ground cable up to 1.25mm² (16AWG) in diameter and should be permanently connected to a grounding bar.

3. ALARMS

3.1 Message Board Alarms and Notifications

Table 3-1 Message Board Alarms and Notifications

Parameters	Remark
AC Fail	AC Input is outside of operating range
DC Fail	DC Output is outside of operating range
Temperature	The module is above/below the normal operating temperature
Current	PSU is providing more than the max current
System Halt	The system is in a shutdown state due to a hard fail alarm
DSP Fault	The system has detected an issue with the internal DSP
OSC	Oscillation detected
DL Signal not detected	DL signal is below the specified level
DL Signal Low	DL signal is below the specified level
Input Overload	Incoming in-band DL or UL signal is too strong
Out of band Overload	Incoming out-band DL or UL signal is too strong
Synthesizer Lock Fail	There is an issue with the internal PLL
DL RF Power	Input + gain does not match the output level (above delta of 6 dB)
Overpower	The output level is above the max output levels
VSWR	Power is being reflected back to the repeater
Heartbeat	Heartbeat is sent out to the NOC
Reboot	Soft reboot performed
Factory setting	Factory default settings restored
Door	Door alarm set/clear

3.2 Alarms

Table 3-2 Alarms


Parameters	Remark
AC Fail	The power supply is not operating within specs. (4 seconds)
DC Fail	The power supply is not operating within specs. (4 seconds)
Temperature	The module is above the normal operating temperature. (4 seconds)
Current	The power supply is not operating within specs. (4 seconds) Over Current [Hard: Above 20A]
System Halt	The system is in a shutdown state due to a hard fail alarm. (10 cycles)
DSP Fault	The system has detected an issue with the internal DSP chip. (Cannot communicate with DSP)
OSC	Oscillation detected.
DL Signal not Detected	DL signal is below the specified level. (default: -90dBm, 4 seconds)
DL Signal Low	DL signal is below the specified level. (default: -85dBm, 4 seconds)
Input Overload	Input signal is above the threshold. (4 seconds) (Soft: DL -5dBm/UL -5dBm, Hard: DL +5dBm/UL +5dBm)
Out of Band Overload	Out of band signal is above the threshold. (4 seconds) (Soft: DL -5dBm/UL -5dBm, Hard: DL +5dBm/UL +5dBm)
Synthesizer Lock Fail	There is an issue with internal PLL. (4 seconds)

DL RF Power	Input + gain does not match the output level. (default delta of 6 dB)
Overpower	The output level is above the max output levels. AGC On case (Soft: AGC Level + 1~2dB, Hard: AGC Level + >2dB) AGC Off case (Soft: max output level + 1~2dB, Hard: max output level + >2dB)
VSWR	Power is being reflected back to the repeater. Threshold = output power - 8dB. For example, if the repeater is outputting 24dBm and detects 16dBm of return power, then the VSWR will be triggered. (Alarm will only trigger when the output power is 15dBm or greater)
Door	Door alarm set: Door open Door alarm clear: Door close

3.3 External Alarms

The PSR-78-9537-XB supports dry contact alarms and can be connected to a fire alarm control panel. The user can program the repeater to either create an open or closed circuit when an alarm is present in the system.

3.3.1 External Alarm Output interface



External Alarm Name		Set Condition
Fire Alarm	Donor Antenna Malfunction	<ul style="list-style-type: none"> - UL Return Power Hard Fail or No DL Signal Detected
	Active RF Device Malfunction	<ul style="list-style-type: none"> - RF Power Soft Fail - DL Return Power Hard Fail - DL/UL Over Power Hard Fail - DL/UL Input Overload Hard Fail
	Low Battery Capacity (70% depleted)	<ul style="list-style-type: none"> - Low Battery Soft Fail
	System Component Malfunction	<ul style="list-style-type: none"> - Over Current Hard Fail - Over Temperature Hard Fail - DSP Hard Fail - Out-band Overload Hard Fail
System Monitoring	Normal AC Power	<ul style="list-style-type: none"> - AC Normal Set - AC Fail Soft Clear
	Loss of Normal AC Power	<ul style="list-style-type: none"> - AC Fail Soft Set - AC Normal Clear
	Battery Charger Failure	<ul style="list-style-type: none"> - Battery Fail Soft Fail - Battery Not Connected Soft fail - Battery Not Charge Soft Fail
	Low Battery Capacity (70% depleted)	<ul style="list-style-type: none"> - Low Battery Soft Fail

External Alarm Name		Set Condition
	Donor Antenna Malfunction	<ul style="list-style-type: none"> - UL Return Power Hard Fail or No DL Signal Detected
	Active RF Emitting Device Malfunction	<ul style="list-style-type: none"> - RF Power Soft Fail - DL Return Power Hard Fail - DL/UL Over Power Hard Fail - DL/UL Input Overload Hard Fail
	System Component Malfunction	<ul style="list-style-type: none"> - Over Current Hard Fail - Over Temperature Hard Fail - DSP Hard Fail - Out-band Overload Hard Fail

3.3.2 External Alarm Input interface

User Alarm Input Port

No	External Alarm In	User Alarm	Remark
1	ALARM IN 1	TBD	

4. INSTALLATION

4.1 Installation Procedures

4.1.1 Wall Mount Procedure

- Verify that the PSR-78-9537-XB and mounting holes are in good condition
- Place the PSR-78-9537-XB mounting bracket template up against the wall and mark off mounting holes
- Drill the appropriate size holes and install the included wall anchors
- Remove the wall mount bracket from the repeater and bolt the wall mount bracket to the wall
- Place the repeater onto the wall mount bracket and secure the bracket to the repeater
- Connect the GND cable
- Connect the Antenna cables
- Connect the Power cable




Figure 4-1 Wall Mount

4.1.2 PSR-ANN Annunciator Installation

The PSR-ANN annunciator box has been designed to either mount on top of the PSR-78-9537-XB repeater or can also be wall mounted separately. By default, the mounting bracket is configured to mount to the top of the repeater with the mounting bracket at the bottom of the PSR-ANN annunciator box. If individually wall mounting the PSR-ANN, then the bracket will need to moved from the bottom of the box to the back of the box.

Once the PSR-ANN annunciator box has securely mounted, connect the included power/data cable from the side of the PSR-ANN box to the port labeled Annunciator on the PSR-78-9537-XB.




Figure 4-2 PSR-ANN Repeater Mount




Figure 4-3 PSR-ANN Wall Mount

4.2 Antenna Separation/Isolation

The separation between the donor and server antennas is necessary to prevent oscillation. Oscillation occurs when the signal entering the system continually re-enters, due to the lack of separation between the donor and server antennas. In other words, the signal is being fed back into the system. This creates a constant amplification of the same signal. As a result, the noise level rises above the signal level.




Figure 4-4 RF Repeater Oscillation

To prevent feedback, the donor and server antennas must be separated by an appropriate distance to provide sufficient isolation. Isolation can be attained by separating antennas at a sufficient distance so that the output of one antenna does not reach the input of the other. This distance is dependent on the gain of the repeater.

Recommended isolation value is 15dB greater than the user-set gain of the repeater. For example, if the user-set gain of the repeater is 50dB, then isolation of 65dB or greater is required. In the same manner, to utilize the maximum gain of 95dB of the PSR-78-9537-XB, isolation of at least 110dB is required.



WARNING. This is **NOT** a **CONSUMER** device. It is designed for installation by **FCC LICENSEES** and **QUALIFIED INSTALLERS**. You **MUST** have an **FCC LICENSE** or express consent of an FCC Licensee to operate this device. Unauthorized use may result in significant forfeiture penalties, including penalties in excess of \$100,000 for each continuing violation.

DO NOT APPLY AC POWER TO THE BDA UNTIL CABLES ARE CONNECTED TO BOTH PORTS OF THE BDA AND THE ANTENNAS.

1. To mount on a wall. Using appropriate screws and anchors attach the BDA to the wall at the four mounting holes.
2. Ensure that the isolation between the donor antenna and the serving antennas is at least 15 dB greater than the BDA gain.
3. Connect the cable from the donor antenna to the BDA connector labeled “DONOR” and the cable from the serving antennas to the BDA connector labeled “SERVER”.
4. Connect the AC power cord to the BDA and turn on the switch at the left of PSU.
5. Installation of the BDA is now complete. Adjust the gain controls to suit the specific signal environment through the GUI on your PC.

5. PSR-78-9537-XB WEB-GUI SETUP

The Web-GUI allows the user to communicate with the repeater either locally or remotely. To connect to the repeater locally, you will need a laptop with an Ethernet port and an RJ-45 crossover cable. To connect to the repeater remotely, you will need to have an active internet connection via an external modem or LAN.

5.1 Repeater/PC Connection Using Web-GUI

- Verify that your Local Area Network Connection is set to **obtain an IP address automatically** under the Internet Protocol (TCP/IP) properties.
- If you are connecting to the unit remotely (use of a modem), then skip the step above.
 - Connect the RJ-45 crossover cable between the laptop's Ethernet port and the repeater's Ethernet port.
 - Launch either Internet Explorer or Google Chrome.
 - Type the following IP address into the address bar of the Internet Browser: <http://192.168.63.1>
- If you are connecting to the unit remotely, then type the IP address of the modem to connect to the unit
 - The following login screen will appear:
 -




Figure 5-1 Login Page

If you are not the Administrator, please type in your assigned username & password which you should have received from the Administrator.

The default username and password for the General User is **adrft** & **adrft**, respectively.
The default Administrator login is **admin** & **admin**, respectively.

5.2 Status Tab



PSR-78-9533
Site ID : ADRF Tech
Mode :
N – PS700 (16ch) + PS800 (16ch) (758-861MHz)

The Signal For Success

Advanced RF Technologies, Inc. ("ADRF") is an established, leading provider of in-building equipment and services that improve wireless coverage and capacity for the largest service providers and enterprise customers around the world.

PS700		PS800				
Power & Gain						
Downlink						
Input [dBm]	---	User Set	---			
OutBand [dBm]	-30.8	50.0	50.0			
Gain [dB]	Actual	50.0	50.0			
Output [dBm]	---	---	---			
Band Info						
Downlink		Uplink				
	Input (dBm)	Center Frequency (MHz)	BW (kHz)	Input (dBm)	Center Frequency (MHz)	BW (kHz)
Broad Channel 1 Channel 2 Channel 1 Channel 2 Channel 3 Channel 4 Channel 5 Channel 6 Channel 7 Channel 8 Narrow Channel 9 Channel 10 Channel 11 Channel 12 Channel 13 Channel 14 Channel 15 Channel 16	---	--	--	---	--	--
	---	--	--	---	--	--
	---	--	--	---	--	--
	---	--	--	---	--	--
	---	--	--	---	--	--
	---	--	--	---	--	--
	---	--	--	---	--	--
	---	--	--	---	--	--
	---	--	--	---	--	--
	---	--	--	---	--	--
	---	--	--	---	--	--
	---	--	--	---	--	--
	---	--	--	---	--	--
	---	--	--	---	--	--
	---	--	--	---	--	--
	---	--	--	---	--	--
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--	---	--	--	
---	--	--				

5.2.1 Band Info

The Band Info section displays frequency information along with the corresponding bandwidths that have been set from the Install tab. Input levels for each channel are also displayed in this section.

Band Info		Downlink			Uplink		
		Input (dBm)	Center Frequency (MHz)	BW (kHz)	Input (dBm)	Center Frequency (MHz)	BW (kHz)
Broad	Channel 1	--,-	--,-	--,-	--,-	--,-	--,-
	Channel 2	--,-	--,-	--,-	--,-	--,-	--,-
Narrow	Channel 1	--,-	--,-	--,-	--,-	--,-	--,-
	Channel 2	--,-	--,-	--,-	--,-	--,-	--,-
	Channel 3	--,-	--,-	--,-	--,-	--,-	--,-
	Channel 4	--,-	--,-	--,-	--,-	--,-	--,-
	Channel 5	--,-	--,-	--,-	--,-	--,-	--,-
	Channel 6	--,-	--,-	--,-	--,-	--,-	--,-
	Channel 7	--,-	--,-	--,-	--,-	--,-	--,-
	Channel 8	--,-	--,-	--,-	--,-	--,-	--,-
	Channel 9	--,-	--,-	--,-	--,-	--,-	--,-
	Channel 10	--,-	--,-	--,-	--,-	--,-	--,-
	Channel 11	--,-	--,-	--,-	--,-	--,-	--,-
	Channel 12	--,-	--,-	--,-	--,-	--,-	--,-
	Channel 13	--,-	--,-	--,-	--,-	--,-	--,-
	Channel 14	--,-	--,-	--,-	--,-	--,-	--,-
	Channel 15	--,-	--,-	--,-	--,-	--,-	--,-
	Channel 16	--,-	--,-	--,-	--,-	--,-	--,-

Figure 5-3 Status Tab – Band Info Display

5.2.2 Power & Gain

This section displays the Input, Gain, and Output for both downlink and uplink.

Power & Gain		Downlink		Uplink	
		Input [dBm]	--,-	Output [dBm]	--,-
Gain [dB]	User Set	50.0		50.0	
	Actual	50.0		50.0	
Output [dBm]		--,-	--,-	--,-	--,-

Figure 5-4 Status Tab – Power & Gain Display

- Input [dBm]** – Displays the in-band Downlink/Uplink signal level. The system will display “--,-” when the input level is < -90 dBm.
- Outband [dBm]** – Displays the out-band composite power.
- Gain [dB]**
 - User Set: Displays the amount of gain that the user set.
 - Actual: Displays the actual amount of gain that is currently in use.
- Output [dB]** – Displays the Downlink/Uplink composite output power levels. The system will display “--,-”, when the output level is < +5 dBm.

5.2.3 Alarms

This section displays the alarm status for System alarms, RF Alarms, and Power alarms. If an alarm is present in the system, then the color of the alarm tab will change according to the type of failure.




Figure 5-5 Status Tab – Alarm Display

5.2.4 AAI

This section displays the AAI alarm status for each dry contact alarm. Red indicates that the dry contact alarm is active and light blue indicates the alarm is inactive. If the Remote Power Switch function is enabled, then the AAI Alarm In status will not be present from the AAI alarm status since this function is disabled when the Remote Power Switch is enabled.




Figure 5-6 Status Tab – AAI Alarm Display (Remote Power Switch Disabled)




Figure 5-7 Status Tab – AAI Alarm Display (Remote Power Switch Enabled)

5.2.5 Repeater Info / Repeater Location / Technical Support / Installer Contact Info

Information	
Serial Number	
Latitude	
Longitude	
Firmware	F2.0.F
Web GUI	F2.0.0

Location	
Description	

Technical Support
 Phone: 1-800-313-9345
 E-mail: techsupport@adrftech.com

Installer Contact Info
 Company:
 Installer:
 Phone:
 E-mail:

Figure 5-8 Status Tab – Repeater Info / Repeater Location / Technical Support / Installer Contact Info

- **Repeater Info:** Displays the serial number, latitude, longitude, firmware version, and Web-GUI version
- **Repeater Location:** Displays the address where the repeater is installed
- **Technical Support:** Displays ADRF's Technical Support contact information
- **Installer Contact Info:** Displays the installer's name, phone, and e-mail address

5.3 Control Tab

General Settings

ALC On
 PS 700 DL HPA On
 PS 800 DL HPA On
 PS 700+800 UL HPA On
 Remote Power Switch

System

PS700

Manual Gain Control

DL Gain [dB] 50.0

UL Gain [dB] 50.0

DL ALC Level [dBm] 37.0

UL ALC Level [dBm] 30.0

DL ALC Offset Level [dB] 7.0

UL ALC Offset Level [dB] 7.0

DL /UL Gain Balance ON Off

Battery Alarm Settings

Battery Check Check All

Battery Not Charge Check On

PS800

Alarm Settings

DL Signal Low Level [dBm] -85.0

DL Signal Not Detect Level [dBm] -90.0

DL RF Power Level [dB] 6.0

DL Over Power Level [dBm] 37.0

UL Over Power Level [dBm] 30.0

AAI Test

Alarm setting Status
 Closed
 Open

Donor Antenna Malfunction Check Time 3min

AAI Test On

Fire Alarm

System Monitoring

Donor Antenna Malfunction Normal

Active RF Emitting Device Malfunction Normal

Low Battery Capacity Set

System Component Malfunction Set

Normal AC Power Normal

Loss of Normal AC Power Set

Battery Charger Failure Set

Low Battery Capacity Set

Donor Antenna Malfunction Normal

Active RF Emitting Device Malfunction Normal

System Component Malfunction Set

Figure 5-9 Control Tab

Advanced RF Technologies, Inc.

35

5.3.1 General Settings

The General Settings section allows the user to enable/disable amplifiers and the ALC routine.




Figure 5-10 Control Tab – General Setting

- **ALC ON:** Enables or disables Automatic Level Control (ALC)
- **PSR 700 DL HPA On:** Enables or disables the Downlink High Power Amplifier (HPA) for 700MHz PS
- **PSR 800 DL HPA On:** Enables or disables the Downlink High Power Amplifier (HPA) for 800MHz PS
- **PSR 700+800 UL HPA On:** Enables or disables the Uplink High Power Amplifier (HPA) for 700+800MHz PS
- **Remote Power Switch:** Enables or disables the Remote Power Switch function

To enable/disable any of the settings, click on the checkbox and click the Apply button.

5.3.1.1 Emergency Power Off Switch Support

The PSR-78-9537-XB now support the ability to connect an extern power switch to turn on/off the high power amplifier via our Alarm Input dry contact pins. This Emergency Power Off (EPO) function is an optional feature that is only active when the function is enabled. If the EPO function is enabled, the AAI dry contact input alarm pair will no longer function. This feature is available on firmware version 2.0.33 or higher and older repeaters can be updated using a field upgradeable firmware.

On the dry contact alarming cable, if the Alarm Input-1 & GND (light blue pair) is an open circuit, the DL and UL HPA will be turned on. If this pair is shorted together (closed circuit) then the DL and UL HPA will turn off. If needed, the cable length can be extended up to approximately 300 ft. using CAT6 Shielded Twisted Pair cable.



Figure 5-11 AAI Alarm Cable – Alarm Input

5.3.2 System

Under the System section, the user is able to perform a soft reboot on the repeater and also can restore factory default settings.



Figure 5-12 Control Tab – System

- **Reboot:** Performs a soft reboot of the repeater
- **Factory Set:** Restores all settings to factory defaults

5.3.3 Manual Gain Control



Manual Gain Control


DL Gain [dB]	50.0
UL Gain [dB]	50.0
DL ALC Level [dBm]	33.0
UL ALC Level [dBm]	30.0
DL ALC Offset Level [dBm]	7.0
UL ALC Offset Level [dBm]	7.0
DL / UL Gain Balance ON	On

Apply

Figure 5-13 Control Tab – Manual Gain Control

- DL/UL Gain:** Gain levels of the repeater can be specified here
- DL/UL ALC Level:** Prevents the output power from exceeding the specified value
- DL/UL Output ALC Offset:** If any ALC attenuation has been applied, the system will release this attenuation when the signal level drops by the specified level
- DL / UL Gain Balance ON:** Allows the user to enable or disable the gain balance. When gain balance is enabled, the delta value between the downlink and uplink gains remain constant

5.3.4 Alarm Settings & Battery Alarm Settings



Alarm Settings

DL Signal Low Level [dBm]	-85.0
DL Signal Not Detect Level [dBm]	-90.0
DL RF Power Level [dBm]	6.0
DL Over Power Level [dBm]	33.0
UL Over Power Level [dBm]	30.0

Apply

Battery Alarm Settings

Battery Check	Check All
Battery Not Charge Check	On

Apply

Figure 5-14 Control Tab – Alarm & Battery Alarm Settings

- DL Signal Low Level:** Allows the user to specify how low the signal can be before triggering a “Downlink Signal Low” soft-fail alarm
- DL Signal Not Detected Level:** Allows the user to specify how low the signal can be before triggering a “Downlink Signal Not Detected” soft-fail alarm
- DL RF Power Level:** Allows the user to set a maximum deviation value for the downlink RF power before triggering a “DL RF Power Level” soft-fail alarm
 - For example, if the input signal is -50 dBm and the gain is set to 60 dB, the expected output power should be 10 dBm. If the Downlink RF Power alarm value is set to 6dB, then a soft-fail alarm will trigger if the output power falls below 4 dBm
- DL Over Power Level:** DL Over Power Alarm will trigger when the DL output level exceeds this level
- UL Over Power Level:** UL Over Power Alarm will trigger when the UL output level exceeds this level
- Battery Check:**
 - Check All – All battery related alarms are checked which include Battery Fail, Battery Not Installed, Low Battery, and Battery Not Charge
 - Except Install – Only Battery Fail, Low Battery, and Battery Not Charge alarms are checked
 - Check Off – Does not perform any battery check
- Battery Not Charge Check:**
 - On – Checks for the Battery Not Charge alarm
 - Off – Disables the check for the Battery Not Charge alarm

5.4 Install Tab

Technology									
<input style="width: 100%; height: 25px; border: 1px solid #ccc;" type="button" value="N - PS700 (16ch) + PS800 (16ch) (758-861MHz)"/>									
<input style="width: 100px; height: 25px; border: 1px solid #ccc; border-radius: 10px;" type="button" value="Apply"/>									
Band Selection									
PS700				PS800					
		Channel Center Frequency (MHz)	Bandwidth (KHz)	Downlink Gain (dB)	DSP Output Level (dBm)	Set	Downlink Freq (MHz) Start	End	
N a r r o w	Broad	PS700	--	OFF	0.0	--	<input style="width: 100px; height: 25px; border: 1px solid #ccc; border-radius: 10px;" type="button" value="Apply"/>	--	--
	Ch. 1	PS700	--	OFF	0.0	--	<input style="width: 100px; height: 25px; border: 1px solid #ccc; border-radius: 10px;" type="button" value="Apply"/>	--	--
	Ch. 2	PS700	--	OFF	0.0	--	<input style="width: 100px; height: 25px; border: 1px solid #ccc; border-radius: 10px;" type="button" value="Apply"/>	--	--
	Ch. 3	PS700	--	OFF	0.0	--	<input style="width: 100px; height: 25px; border: 1px solid #ccc; border-radius: 10px;" type="button" value="Apply"/>	--	--
	Ch. 4	PS700	--	OFF	0.0	--	<input style="width: 100px; height: 25px; border: 1px solid #ccc; border-radius: 10px;" type="button" value="Apply"/>	--	--
	Ch. 5	PS700	--	OFF	0.0	--	<input style="width: 100px; height: 25px; border: 1px solid #ccc; border-radius: 10px;" type="button" value="Apply"/>	--	--
	Ch. 6	PS700	--	OFF	0.0	--	<input style="width: 100px; height: 25px; border: 1px solid #ccc; border-radius: 10px;" type="button" value="Apply"/>	--	--
	Ch. 7	PS700	--	OFF	0.0	--	<input style="width: 100px; height: 25px; border: 1px solid #ccc; border-radius: 10px;" type="button" value="Apply"/>	--	--
	Ch. 8	PS700	--	OFF	0.0	--	<input style="width: 100px; height: 25px; border: 1px solid #ccc; border-radius: 10px;" type="button" value="Apply"/>	--	--
	Ch. 9	PS700	--	OFF	0.0	--	<input style="width: 100px; height: 25px; border: 1px solid #ccc; border-radius: 10px;" type="button" value="Apply"/>	--	--
	Ch. 10	PS700	--	OFF	0.0	--	<input style="width: 100px; height: 25px; border: 1px solid #ccc; border-radius: 10px;" type="button" value="Apply"/>	--	--
	Ch. 11	PS700	--	OFF	0.0	--	<input style="width: 100px; height: 25px; border: 1px solid #ccc; border-radius: 10px;" type="button" value="Apply"/>	--	--
	Ch. 12	PS700	--	OFF	0.0	--	<input style="width: 100px; height: 25px; border: 1px solid #ccc; border-radius: 10px;" type="button" value="Apply"/>	--	--
	Ch. 13	PS700	--	OFF	0.0	--	<input style="width: 100px; height: 25px; border: 1px solid #ccc; border-radius: 10px;" type="button" value="Apply"/>	--	--
	Ch. 14	PS700	--	OFF	0.0	--	<input style="width: 100px; height: 25px; border: 1px solid #ccc; border-radius: 10px;" type="button" value="Apply"/>	--	--
	Ch. 15	PS700	--	OFF	0.0	--	<input style="width: 100px; height: 25px; border: 1px solid #ccc; border-radius: 10px;" type="button" value="Apply"/>	--	--
Ch. 16	PS700	--	OFF	0.0	--	<input style="width: 100px; height: 25px; border: 1px solid #ccc; border-radius: 10px;" type="button" value="Apply"/>	--	--	

SNMP <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 50%; padding: 5px;">Site ID</td> <td style="width: 50%; padding: 5px;">ADRF Tech</td> </tr> <tr> <td style="width: 50%; padding: 5px;">Description</td> <td style="width: 50%; padding: 5px;">ADRF Tech PSR-78 Serise</td> </tr> </table>	Site ID	ADRF Tech	Description	ADRF Tech PSR-78 Serise	Modem Box Setting <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 50%; padding: 5px;">Repeater IP</td> <td style="width: 50%; padding: 5px;">192.168.63.11</td> </tr> <tr> <td style="width: 50%; padding: 5px;">Subnet Mask</td> <td style="width: 50%; padding: 5px;">255.255.255.0</td> </tr> <tr> <td style="width: 50%; padding: 5px;">Gateway</td> <td style="width: 50%; padding: 5px;">192.168.63.254</td> </tr> </table>	Repeater IP	192.168.63.11	Subnet Mask	255.255.255.0	Gateway	192.168.63.254
Site ID	ADRF Tech										
Description	ADRF Tech PSR-78 Serise										
Repeater IP	192.168.63.11										
Subnet Mask	255.255.255.0										
Gateway	192.168.63.254										
<input style="width: 100px; height: 25px; border: 1px solid #ccc; border-radius: 10px;" type="button" value="Apply"/>	<input style="width: 100px; height: 25px; border: 1px solid #ccc; border-radius: 10px;" type="button" value="Apply"/>										
Location <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 50%; padding: 5px;">Latitude</td> <td style="width: 50%; padding: 5px; text-align: center;">N +00</td> </tr> <tr> <td style="width: 50%; padding: 5px;">Longitude</td> <td style="width: 50%; padding: 5px; text-align: center;">W +1</td> </tr> </table>	Latitude	N +00	Longitude	W +1	AAI Input <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 50%; padding: 5px;">AAI Input 1</td> <td style="width: 50%; padding: 5px;"></td> </tr> </table>	AAI Input 1					
Latitude	N +00										
Longitude	W +1										
AAI Input 1											
<input style="width: 100px; height: 25px; border: 1px solid #ccc; border-radius: 10px;" type="button" value="Apply"/>	<input style="width: 100px; height: 25px; border: 1px solid #ccc; border-radius: 10px;" type="button" value="Apply"/>										

Figure 5-15 Install Tab

5.4.1 Technology

This section allows the user to set the repeater mode to either use PS700, PS800, or PS700+PS800.




Figure 5-16 Install Tab – Technology

5.4.2 Band Selection

	PS700				PS800			
	Channel Center Frequency (MHz)	Bandwidth (kHz)	Downlink Gain (dB)	DSP Output Level (dBm)	Set	Downlink Freq (MHz)		
	--	OFF ▼	0.0 ▼	--	Apply	Start	End	
Broad	PS700 ▼	--	OFF ▼	0.0 ▼	--	Apply	--	--
	PS700 ▼	--	OFF ▼	0.0 ▼	--	Apply	--	--
	Ch. 1	--	OFF ▼	0.0 ▼	--	Apply	--	--
	Ch. 2	--	OFF ▼	0.0 ▼	--	Apply	--	--
	Ch. 3	--	OFF ▼	0.0 ▼	--	Apply	--	--
	Ch. 4	--	OFF ▼	0.0 ▼	--	Apply	--	--
	Ch. 5	--	OFF ▼	0.0 ▼	--	Apply	--	--
	Ch. 6	--	OFF ▼	0.0 ▼	--	Apply	--	--
	Ch. 7	--	OFF ▼	0.0 ▼	--	Apply	--	--
	Ch. 8	--	OFF ▼	0.0 ▼	--	Apply	--	--
	Ch. 9	--	OFF ▼	0.0 ▼	--	Apply	--	--
	Ch. 10	--	OFF ▼	0.0 ▼	--	Apply	--	--
	Ch. 11	--	OFF ▼	0.0 ▼	--	Apply	--	--
	Ch. 12	--	OFF ▼	0.0 ▼	--	Apply	--	--
	Ch. 13	--	OFF ▼	0.0 ▼	--	Apply	--	--
	Ch. 14	--	OFF ▼	0.0 ▼	--	Apply	--	--
	Ch. 15	--	OFF ▼	0.0 ▼	--	Apply	--	--
	Ch. 16	--	OFF ▼	0.0 ▼	--	Apply	--	--

Figure 5-17 Install Tab – Band Selection

Band selection allows the user to specify the desired frequencies by inputting the center frequencies and selecting the bandwidths.

- **Channel Center Frequency:** The user can input the center frequency of the pass-band.
- **Bandwidth:** Allows the user to select the desired bandwidth for the passband. Choices for wideband frequencies include 3, 5, or 10 MHz. Narrowband choices include 6.25, 12.5, 25.0, 75.0 and 200 kHz. The required frequency spacing between channels is 4x the bandwidth from center to center. For example, if there are 2 channels each at 12.5KHz, then the required frequency spacing between these 2 channels will be 50KHz (measuring from center to center). If channel bandwidths are different between the 2 channels, then the required frequency spacing will be 4x the larger bandwidth.
- **Downlink Gain:** Minor gain adjustments can be performed on a per channel basis to equalize signal levels
- **Downlink Freq - Start:** Displays the start frequency of the pass-band once the band selection has been set
- **Downlink Freq - End:** Displays the end frequency of the pass-band once the band selection has been set

5.4.3 SNMP




The SNMP section allows you to specify the Site ID and Description. The Site-ID is the code that is used to identify the repeater.

Figure 5-18 Install Tab – SNMP

The SNMP section allows you to specify the Site ID and Description. The Site-ID is the code that is used to identify the repeater.

5.4.4 Location

This section allows the user to input the latitude and the longitude of the repeater.




The Location section allows you to specify the latitude and longitude of the repeater.

Figure 5-19 Install Tab – Location

5.4.5 Modem Box Setting

This section allows the user to specify alternative Repeater IP, Subnet Mask, and Gateway settings. These settings are enabled when the Host/Remote switch is set to the Remote position.



The Modem Box Setting section allows you to specify alternative Repeater IP, Subnet Mask, and Gateway settings. These settings are enabled when the Host/Remote switch is set to the Remote position.

Figure 5-20 Install Tab – Modem Box Setting

5.4.6 AAI Input

The PSR-78-9537-XB can accept a dry contact input alarms. The alarm can be labeled in this section. Once the alarm is labeled, it will show up in the system with the new custom names on the Status tab. This feature is only available if the Emergency Power Off switch function is not being utilized.



Figure 5-21 Install Tab – AAI Input

5.4.7 Location Info / Installer Info

This section allows the user to specify the address of the repeater and also the information of the installer.




Figure 5-22 Install Tab – Location Info / Installer Info

5.4.8 Date & Time

This section allows the user to specify the current date and time.




Figure 5-23 Install Tab – Date & Time

5.5 System

The System tab allows the user to perform firmware updates, upload closeout packages, view any changes to the system, backup existing configuration, add/remove user accounts, and change the login credentials of the Administrator.

5.5.1 System: Account

5.5.1.1 System: Account – Account Management

The Account Management section allows the Administrator to delete any user accounts. Please note that the Account Management section is only available if you are logged into the system as the Administrator. To delete a user account, click on the Account Management link and under the Edit column, click on the delete button.

Account Management / New account / Change Password					
No	User Name	Password	Status	Last Login	Edit
1	admin	admin	administrator	2007-01-01 00:03:42	-
2	adrf	adrf	user	1970-01-01 00:00:00	delete
3	guest	guest	guest	1970-01-01 00:00:00	delete

Figure 5-24 System: Account – Account Management

5.5.1.2 System: Account – New Account

The New account section allows the Administrator to create a new user account. Please note that the New account section is only available if you are logged into the system as the Administrator. To create a new user account, click on the new account link, fill in the fields, and click Create.

Account Management / New account / Change Password	
④ User Name	<input type="text"/>
④ User Group	<input type="text" value="user"/>
④ Password	<input type="text"/>
④ Confirm password	<input type="text"/>
	Create Cancel

Figure 5-25 System: Account – New Account

5.5.1.3 System: Account – Change Password


The Change Password section allows the current user who is logged into the system to change their login credentials.

Account Management / New account / Change Password	
④ User Name	admin
④ New User Name	<input type="text" value="admin"/>
④ Confirm New User Name	<input type="text" value="admin"/>
④ Password	<input type="text"/>
④ Confirm password	<input type="text"/>
Please enter new password.	
	Apply Cancel

Figure 5-26 System: Account – Change Password

5.5.2 System – SNMP

This section displays The SNMP section allows the user to define the parameters for SNMP v1, v2c, and v3. Community strings for v1/v2c can be specified from here and SNMP user account can be created/deleted from this section.



The figure displays three separate configuration panels for SNMP:

- SNMP V1 / V2 ADD SNMP:** A table with columns: Version (dropdown: v2c), Permission (dropdown: read/write), Community (text input), and Command (button: add). Below it is a table for Active SNMP with rows for v1 and v2c, each with read/write permission and public community, and delete buttons.
- SNMP V3 ADD SNMP:** A table with columns: User ID (text input), Permission (dropdown: read/write), Auth Algorithm / Password (dropdown: MD5), Privacy Algorithm (dropdown: None), and Command (button: add). Below it is a table for Active SNMP with columns: User ID, Permission, Auth Algorithm / Password, Privacy Algorithm, and Command.
- SNMP Monitoring:** A table for SNMP V1 / V2 with columns: Enabled (checkbox), Version (dropdown: v1), Permission (dropdown: read only), Community (text input), and Command (button: set). Below it is a table for SNMP V3 with columns: Enabled, User ID, Permission, Auth Algorithm / Password (dropdown: MD5), Privacy Algorithm (dropdown: None), and Command (button: set).

Figure 5-27 SNMP

5.5.3 System – Logs

This section displays system events that have taken place. The Log displays the time and date of when the event took place, and what changes were made to the system.

Seq	Date	Event	Description
80	2016-11-15 07:14:15	Broad Band Freq set	Broad Band Freq changed 0.0, Bandwidth Set to 0.0
79	2016-11-15 07:14:15	700 Narrow Band Freq Set	700 Narrow Band Freq changed 0.0, Bandwidth Set to 0.0
78	2016-11-15 07:14:15	700 Narrow Band Freq Set	700 Narrow Band Freq changed 0.0, Bandwidth Set to 0.0
77	2016-11-15 07:14:15	700 Narrow Band Freq Set	700 Narrow Band Freq changed 0.0, Bandwidth Set to 0.0
76	2016-11-15 07:14:15	700 Narrow Band Freq Set	700 Narrow Band Freq changed 0.0, Bandwidth Set to 0.0
75	2016-11-15 07:14:15	700 Narrow Band Freq Set	700 Narrow Band Freq changed 0.0, Bandwidth Set to 0.0
74	2016-11-15 07:14:15	700 Narrow Band Freq Set	700 Narrow Band Freq changed 0.0, Bandwidth Set to 0.0
73	2016-11-15 07:14:15	700 Narrow Band Freq Set	700 Narrow Band Freq changed 0.0, Bandwidth Set to 0.0
72	2016-11-15 07:14:15	700 Narrow Band Freq Set	700 Narrow Band Freq changed 0.0, Bandwidth Set to 0.0
71	2016-11-15 07:14:15	700 Narrow Band Freq Set	700 Narrow Band Freq changed 0.0, Bandwidth Set to 0.0
70	2016-11-15 07:14:15	700 Narrow Band Freq Set	700 Narrow Band Freq changed 0.0, Bandwidth Set to 0.0
69	2016-11-15 07:14:15	700 Narrow Band Freq Set	700 Narrow Band Freq changed 0.0, Bandwidth Set to 0.0
68	2016-11-15 07:14:15	700 Narrow Band Freq Set	700 Narrow Band Freq changed 0.0, Bandwidth Set to 0.0
67	2016-11-15 07:14:15	700 Narrow Band Freq Set	700 Narrow Band Freq changed 0.0, Bandwidth Set to 0.0
66	2016-11-15 07:14:15	700 Narrow Band Freq Set	700 Narrow Band Freq changed 0.0, Bandwidth Set to 0.0
65	2016-11-15 07:14:15	700 Narrow Band Freq Set	700 Narrow Band Freq changed 0.0, Bandwidth Set to 0.0
64	2016-11-15 07:14:15	700 Narrow Band Freq Set	700 Narrow Band Freq changed 0.0, Bandwidth Set to 0.0
63	2016-11-15 07:14:15	700 Narrow Band Freq Set	700 Narrow Band Freq changed 0.0, Bandwidth Set to 0.0
62	2016-11-15 07:14:15	700 Narrow Band Freq Set	700 Narrow Band Freq changed 0.0, Bandwidth Set to 0.0
61	2016-11-15 07:14:15	700 Narrow Band Freq Set	700 Narrow Band Freq changed 0.0, Bandwidth Set to 0.0

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20
 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40
 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56 57 58 59 60
 61 62 63 64 65 66 67 68 69 70 71 72 73 74 75 76 77 78 79 80
 81 82 83 84 85 86 87 88 89 90 91 92 93 94 95 96 97 98 99 100

Figure 5-28 System: Logs

5.5.4 System – Update

- To perform a firmware update, click on the Update tab and the following screen will appear.




Figure 5-29 System: Update

- Click on the Choose File button and locate the firmware file.
- Click on the Upgrade button to perform the firmware update.
- Once the firmware update is complete, the following popup message will appear:




Figure 5-30 System: Update is Complete Popup Message

5.5.5 System – Backup / Restore

The Backup / Restore section allows the user to save the settings of the repeater. To perform the backup, click on the Backup button and you will be prompted to save the backup file. To restore the settings to the system, click on Choose File button, select the backup file, and click the Restore button.




Figure 5-31 System: Backup / Restore

5.6 Help

If an internet connection is available, clicking on the Help Tab will redirect the user to our Technical Support page.




Figure 5-32 Help

5.7 Logout

Clicking the Logout button will log the current user off the system.

6. MAINTENANCE GUIDE FOR PSR-78-9537-XB REPEATER

6.1 Periodic Inspection Checklist

- Check for loose connections between the repeater and antennas. If connections are loose, make sure that all connections are tightly fastened properly.
- Cables and connectors are in good condition.
- Ensure that the repeater brackets are in good condition and that the repeater is securely fastened.

6.2 Preventive Measures for Optimal Operation

6.2.1 Recommendations

- Perform the *Periodic Inspection Checklist* quarterly or semi-annually.

6.2.2 Precautions

- Do not operate the repeater with the antennas in extremely close proximity to one another as this may cause damage to the repeater.
- Do not change the parameters unless instructed to do so by an authorized supervisor.
- Do not move the repeater unless instructed to do so by an authorized supervisor.
- Do not detach any cables to the repeater unless repair of respective components is necessary.

7. WARRANTY AND REPAIR POLICY

7.1 General Warranty

The PSR-78-9537-XB/9537-X carries a Standard Warranty period of two (2) years unless indicated otherwise on the package or in the acknowledgment of the purchase order.

7.2 Limitations of Warranty

Your exclusive remedy for any defective product is limited to the repair or replacement of the defective product. Advanced RF Technologies, Inc. may elect which remedy or combination of remedies to provide in its sole discretion. Advanced RF Technologies, Inc. shall have a reasonable time after determining that a defective product exists to repair or replace the problem unit. Advanced RF Technologies, Inc. warranty applies to repaired or replaced products for the balance of the applicable period of the original warranty or ninety days from the date of shipment of a repaired or replaced product, whichever is longer.

7.3 Limitation of Damages

The liability for any defective product shall in no event exceed the purchase price for the defective product.

7.4 No Consequential Damages

Advanced RF Technologies, Inc. has no liability for general, consequential, incidental or special damages.

7.5 Additional Limitation on Warranty

Advanced RF Technologies, Inc. standard warranty does not cover products which have been received improperly packaged, altered, or physically damaged. For example, broken warranty seal, labels exhibiting tampering, physically abused enclosure, broken pins on connectors, any modifications made without Advanced RF Technologies, Inc. authorization, will void all warranty.

7.6 Return Material Authorization (RMA)

No product may be returned directly to Advanced RF Technologies, Inc. without first getting approval from Advanced RF Technologies, Inc. If it is determined that the product may be defective, you will be given an RMA number and instructions on how to return the product. An unauthorized return, i.e., one for which an RMA number has not been issued will be returned to you at your expense. Authorized returns are to be shipped to the address on the RMA in an approved shipping container. You will be given our courier information. It is suggested that the original box and packaging materials should be kept if an occasion arises where a defective product needs to be shipped back to Advanced RF Technologies, Inc. To request an RMA, please call (800) 313-9345 or send an email to techsupport@adrftech.com.

8. SPECIFICATIONS

8.1 Electrical Specifications

Table 8-1 Electrical Specifications (PSR Series)

Parameters		Specifications		Remark
		DL	UL	
Frequency Range (MHz)	FirstNet + PS 700	758 - 768	788 - 798	Support
	PS 800			N/A
Composite Output Power (PSR-78-9537-XB)	FirstNet / PS 700 / FirstNet + PS 700	37 dBm	30 dBm	Support
	PS 800	37 dBm	30 dBm	N/A
	FirstNet + PS 700 + PS 800	40 dBm (37dBm + 37dBm)	30 dBm	N/A
System Gain (dB)		95	95	
Filter selection		Broad / Narrow / Broad + Narrow band		Only Broad band
Simultaneous Filter Support numbers	Broad Band	2 (non-contiguous) @ FirstNet / PS 700 / PS 800 / FirstNet + PS 700 / FirstNet + PS 700 + PS 800		2 (non-contiguous) @ FirstNet
	Narrow Band	Up to 32 (Non-contiguous) @ PS 700 / PS 800 Up to 32 (Non-contiguous) @ PS 700 + PS 800		
Filter Bandwidth	Broad (MHz)	3, 5, 10		LTE 5 & 10 MHz
	Narrow (KHz)	6.25, 12.5, 25, 75, 200		N/A
Filter Roll-off	Broad (MHz)	60dBc@Filter Bandwidth Edge + 1MHz		
	Narrow (KHz)	55dBc @Filter Bandwidth Edge + 3 * Filter BW		
Spurious		3GPP Rule Compliant		
Passband Ripple		±2 dB		
ALC Dynamic Range		≥ 60dB		
Gain Dynamic Range		45dB		
Channel Setting Resolution		0.025 KHz		
Noise Figure @ Max. gain		≤5dB		
System Group Delay	Broad Band	<6us		
	Narrow Band	<126us@6.25KHz BW, <67us@12.5KHz BW, <36us@25KHz BW, <18us@75KHz BW, <10us@200KHz BW		
Power Supply		100 -240 VAC, 60 Hz (Free Voltage)		Optional battery backup
Power Consumption (PSR-78-9537-XB / 9537)		< 150 W / < 222 W		
Max RF Input Power without overdrive		-20dBm		
No damage Max Input Power		+10 dBm		
Impedance		50 Ω		
VSWR		< 1.5 : 1		
Dry Contacts		NFPA 1221 2016 Code Compliant		
Remote Alarming / Network Management		Dry Contacts, Web-GUI, SNMP, (External Wireless Modem Required)		
Humidity		5% - 95% RH Condensed		
Operating at Ambient Temperature		-40°F to +140°F (-40°C to +60°C)		

8.2 Mechanical Specifications

Table 8-2 Mechanical Specifications

PSR-78-9537-XB	Specifications	Comments
Dimensions W x D x H	11.0 x 9.0 x 21.3 in (w/o mounting bracket)	
Weight	55 lbs (w/o mounting bracket)	
RF Connector	4.3-10 (Female)	
Weather Resistances	IP66	

PSR-78-9537-XB	Specifications	Comments
Dimensions W x D x H	12.0 x 11.9 x 21.3 in (w/o mounting bracket)	
Weight	64 lbs (w/o mounting bracket)	
RF Connector	4.3-10 (Female)	
Weather Resistances	IP66	

8.3 Power Specifications

Table 8-3 Power Specifications

Parameters	Specifications	Comments
AC Power	100 -240 VAC, 60 Hz (Free Voltage)	
AC Supply Protection	Fuse & Circuit Protector	T6.3L250V
Battery Backup		
Power Consumption	AC 150W (120V/1.25A), DC 24V/6.25A	
Ground	External Threaded Stud	

8.4 Warranty & Certificates

Table 8-4 Warranty & Certificates

Parameters	Specifications	Comments
MTBF	> 100,000 Hours	Ambient
Compliance	UL60950	
Warranty	2 Years	

8.5 Description of PSR-78-9537-XB

- PSR-78-9537-XB/ PSR-78-9537-XB are for Digital Repeater (or BDA)
- Main devices that PSR-78-9537-XB/ PSR-78-9537-XB includes are Triplexer, DSP, UDC (RF Module), HPA and PSU.
- For the function of Repeater, see O Signal Flow
- Frequency Information

Frequency	Specifications	
	DL	UL
FirstNet + PS 700	758 - 768MHz	788 - 798 MHz

Signal Flow

Downlink



Figure 8-1 Downlink Signal Flow

1. Donor Triplexer band Passes DL signal
2. DL UDC (before DSP) amplifies, adjusts this signal received via antenna from Base Station signal to appropriate level and then transmits the signal to DL DSP.
3. DL DSP has a digital filter, which converts analog signal to digital signal, does digital filtering and then converts digital signal to analog signal.
4. DL UDC (after DSP) adjusts to appropriate level and then transmits to DL HPA.
5. DL HPA amplifies the signal from DL UDC high power level and then transmit to Triplexer
6. Server Triplexer band passes DL band signal and then transmits to Mobile Station antenna

Uplink




Figure 8-2 Uplink signal flow

1. Server Triplexer band Passes DL signal
2. UL UDC (before DSP) amplifies, adjusts this signal received via antenna from Base Station signal to appropriate level and then transmits the signal to DL DSP.
3. UL DSP has a digital filter, which converts analog signal to digital signal, does digital filtering and then converts digital signal to analog signal.
4. UL UDC (after DSP) adjusts to appropriate level and then transmits to UL HPA.
5. UL HPA amplifies the signal from DL UDC high power level and then transmit to Triplexer
6. Donor Triplexer band passes DL band signal and then transmits to Base Station antenna

- **BLOCK DIAGRAM**




Figure 0-1 Block Diagram

- **FUNCTION AND SPECIFICATION PER DEVICE/COMPONENT**

UDC

Parameter	Specifications	
	DL	UL
RF Frequency	758 - 768MHz	788 - 798 MHz
Rating Gain	before DSP	57 ± 2 dB
Rating Gain Gain control range	after DSP	12 ± 2 dB
	45dB	45dB
Gain flatness	p-p 3dB	p-p 3dB
VSWR	Max. 1.5:1	Max. 1.5:1

Table 0-1 UDC specifications

DSP

Parameter	Specifications	
	DL_700	UL_700
IF Center Frequency	125MHz	125MHz
Insertion Loss	-15dB	-15dB
Gain flatness	p-p 1dB	p-p 1dB
VSWR	Max. 1.5:1	Max. 1.5:1

Table 0-2 DSP specifications

Donor/Server Triplexer

Parameter	Specifications	
	DL_700	UL_700
Insertion Loss	Max 1.5dB	Max 1.5dB
Gain flatness	p-p 1dB	p-p 1dB
Isolation	90dB	90dB
VSWR	Max. 1.5:1	Max. 1.5:1

Table 0-3 Donor/Server Triplexer specifications

DL HPA

Parameter	Specifications
Frequency	758 - 768MHz
Rating Gain	35dB±1dB
Gain flatness	p-p 3dB
VSWR	Max. 1.5:1

Table 0-4 DL HPA specifications

UL HPA

Parameter	Specifications
Frequency	788 - 798 MHz
Rating Gain	35dB±1dB
Gain flatness	p-p 3dB
VSWR	Max. 1.5:1

Table 0-5 UL HPA specifications

▪ FREQUENCY BAND AND BLOCK

- This Repeater supports FirstNet, it is a selective filter system
- You can set filter center frequency and filter bandwidth within FirstNet
- Simultaneous Filter Supporting 2 Wide Band (LTE BW 5/10 MHz)

Filter selection	Wide	
Support Filter numbers	Wide	2 (Non-contiguous)
Filter Bandwidth	Wide(MHz)	LTE 5 & 10 MHz

Table 0-1 Selective filter specifications

- **ALC FUNCTION**

- This Repeater has ALC(Automatic Level Control) function as automatic power down mechanism for protecting system from output overload
- The picture below is regarding output ALC function
- Adjustable range of ALC function is minimum 40dB
- ALC level do not exceed the setting power level




Figure 0-1 ALC Function operation

8. MECHANICAL DRAWING




Figure 8-1 PSR-78-9537-XB Mechanical Drawing




Figure 8-2 PSR-78-9537-XB Mechanical Drawing




Figure 8-3 PSR-ANN Annunciator Mechanical Drawing

9. APPENDIX

9.8 Shutdown Retry Logic

The function of the built-in shutdown routine is to protect the repeater from any further damage from a hard-fail that the system may be experiencing.

Within 5 seconds of a hard-fail alarm being detected, the repeater will start the shutdown routine. The repeater will shut down by powering off the HPAs (high-powered amplifiers) for 30 seconds.

After 30 seconds have elapsed, the repeater will power on the HPAs and check to see if the hard-fail alarm still exists. If the hard-fail alarm still exists, then the repeater will shut down for 1 minute (double the time of the previous shutdown time).

After 1 minute has elapsed, the repeater will power on the HPAs and check to see if the hard-fail alarm still exists. If the hard-fail alarm still exists, then the repeater will shut down for 2 minutes (double the time of the previous shutdown time).

The shutdown routine will repeat itself a total of 10 times. If the hard-fail alarm still exists after the 10th retry, then the repeater will turn off its HPAs permanently until a reset is performed or factory set is executed.