



## USB-2 + INSTALLATION GUIDE

### Overview of the USB PortServer

The **USB-2 +** is the smart way to connect serial or parallel devices to a PC or workstation. Each **USB-2 +** provides two high speed ports (up to 230 Kbps) and one bi-directional parallel port through the USB port on your machine. The **USB-2 +** is fully compliant with USB Specification Version 1.0.

### Unpacking the Product

Inspect the shipping carton for any damage. If the contents are damaged, report this immediately to the carrier, who will instruct you on how to file a damage claim. Contact us if the product has been damaged. Be sure to save the shipping carton and all of the packing materials, in case you ever need to reship the product in the future.

### How to Contact Central Data

Phone: 1.217.359.8010  
Toll Free (U.S.): 1.800.482.0315  
FAX: 1.217.359.6904  
email: support@cd.com  
WWW: <http://www.cd.com>  
[ftp://ftp.cd.com](http://ftp.cd.com)

### INSTALLING THE USB PORTSERVER

1. Turn on the Host PC and boot up the operating system.
2. Insert the Central Data driver diskette or CDROM.
3. Plug the free end of the USB cable into the USB port of your Host PC, or into the downstream port of a USB Hub.
4. The LED will light as soon as the **USB-2 +** is connected to the Host, indicating that the connection with the Host is sound and that the **USB-2 +** self-tests have been successful.
5. If the LED does not light or if it blinks continually, disconnect and reconnect the cable. If this does not solve the problem, notify Central Data technical support.

6. The first time you attach the **USB-2 +** to your machine, the machine will immediately start installation of the driver.
7. Now you may attach devices to any of the ports on the **USB-2 +**. Use the cabling information provided below. Each serial port will be mapped as COMx; the parallel port will be mapped as LPTy.
8. The LED will normally remain lit unless the **USB-2 +** is placed in "suspend mode."
9. To update your **USB-2 +** driver in the future, click the Start button on your screen, choose Settings, then Control Panel, and then System. Open the Device Manager tab and expand "USB serial bus controller." Select Central Data USB-2 and click "Property" button. Open Driver tab and click "Update Driver." You will then need to reboot your machine.

### PARALLEL PORT CABLING

You can use a standard Centronics printer cable to attach to your printer. Use shielded cables with at least 85% coverage to ensure that the unit satisfies all radio frequency emission requirements.

### RS-232 CABLING

RS-232 serial devices are designed as either Data Terminal Equipment (DTE) or Data Communications Equipment (DCE). Terminals, serial printers, PC ports, and the **USB-2 +** ports are DTE devices. Modems are DCE devices. The signal names and pin numbers for each type of device are the same; the only difference is whether each signal is input or output. The RS-232 ports on your **USB-2 +** are DTE type, just like normal PC serial ports.

Signal	DB-9 Pin	DB-25 Pin	DTE Use	DCE Use
DCD	1	8	input	output
RxD	2	3	input	output
TxD	3	2	output	input
DTR	4	20	output	input
GND	5	7	ground	ground
DSR	6	6	input	output
RTS	7	4	output	input
CTS	8	5	input	output
RI	9	22	input	output

