

HOW TO OPERATE:

- 1) Open battery compartment (fig.2) and snap in a 9-volt battery, replace door firmly.
- 2) Turn switch (fig.1) to "Walkie" for Walkie-Talkie mode or to "Radio" for Radio mode.
- 3) Plug the handsfree, earphone/speaker into the handsfree jack on the Walkie Talkie to receive and transmit.
- 4) "Walkie" mode:
 - Press the "Push-to-talk" button (fig.1) for transmitting, and speak in a normal voice level into the speaker of the handsfree.
 - Release the "Push-to-talk" button (fig.1) for receiving through the earphone of the handsfree.
 - Best transmission and reception are obtained when the antenna (fig.1) is held in vertical position.
- 5) "Radio" mode:
 - Adjust the volume to the desired level.
 - Press Reset button and the receiving frequency will be set to 87.5Mhz.
 - Press Scan button and the radio will search the radio stations from 87.5Mhz to 108Mhz until a certain station is obtained. If reception is not satisfactory, the user can press Reset button again for better reception.
 - When the highest frequency of 114Mhz is reached, press Reset button when Scan button is pressed many times and no programs can be obtained, it indicates the highest frequency of 114Mhz has been reached.

- 6) Volume: Adjust the volume by rolling the volume switch up or down.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

