

2. USERS MANUAL

1. OVERVIEW OF EXPOSE

① External appearance and button operation

② Explanation of LCD display

2. USE OF EXPOSE AND EXPLANATION OF FUNCTIONS

① Getting Started

② Receipt and confirmation of messages

- 1) To read a message
- 2) Reading an incoming message
- 3) Protection of messages
- 4) Removing a protected message
- 5) Individual deletion of messages
- 6) Auto scroll

③ Operation of the function menu

④ Setting Functions

- 1) Selection of alert type
- 2) Power on/ off
- 3) Setting date and time
- 4) Setting alarm clock
- 5) Turning alarm clock off
- 6) Setting automatic power on/ off
- 7) Cancelling automatic power on/ off
- 8) Entire message deletion
- 9) Stop Watch

⑤ Other functions

- 1) Low battery warning
- 2) Receipt of duplicated message
- 3) Duplication of locked message
- 4) Tone only
- 5) Unread Messages
- 6) Memory full indication

3. REPLACEMENT OF BATTERY

1. Overview of Expose

① External appearance and button operation

1) Mode Button


Repeated pressing of this button will scroll through the various functions of the pager

2) Select Button

When the required function is set by the mode button as above, this button is then used to set the parameters of that function

② Explanation of LCD display


- a) Bleep alert selected
- b) Melody alert selected
- c) Vibrate alert selected
- d) Alarm clock function set
- e) Power on/ off times set
- f) Protected message indicator
- g) In service area indicator
- h) Message overflow indicator




2. Use of Expose and explanation of functions

① Getting started

Remove the battery door by sliding the lock upwards and gently sliding the door sideways. Insert a new AAA battery, taking care to note the polarity marked on the case. The power automatically switches on and the LCD will appear. The pager will self test by vibrating, bleeping and then switching into standby mode. The pager is now ready for use.



Auto Conversion




Standard Mode

② Receipt and confirmation of messages



1) To read a message

On receipt of a message, the pager will bleep, melody or vibrate, depending on your choice of setting, and the message will be displayed on the LCD.




The bleep may be silenced by pressing the  button during the receipt of call.

When receiving a message containing more than 13 characters, the  symbol will appear on the LCD. Press the  button to continue reading the message




2) Reading an incoming message


The time that the message was received is displayed by pushing the ▸ button once in standby mode



The received message is displayed by pushing the ▸ button again. Subsequent messages are displayed by repeated pressing of the ▸ button.




If 'NO PAGES' is displayed, this indicates that no messages have been received.



3) Protection of messages


If you want to retain the message for future reference, pushing the ⊙ button whilst the received message is displayed will lock the message, and the 0↪ symbol will be displayed on the LCD. The time of receipt is not protected.

- EXPOSE can store 20 messages of up to 20 characters



4) Removing a protected message


Use the ▸ button to display the message that you want to unlock, and then press the ⊙ button. Once all messages are unlocked the 0↪ symbol will disappear, and the display show '00:00A'



5) Individual deletion of messages


Use the  button to display the message that you want to delete. Press and hold the  button for more than 2 seconds, and the message will be deleted. The display will show 'ERASED' and return to standby.

When more than 20 messages have been received, the oldest message is automatically deleted.
To completely delete the message memories, refer to section ④ function 8








6) Auto scroll


From standby mode, press and hold the  button until a short bleep is heard. Release the button and the display will automatically scroll through the stored messages with time of receipt, from the newest to the oldest.



Stand-By Mode

Push  Button More Than Two Second






To return to standby during the automatic scroll, press the ⊖ button.

③ OPERATION OF THE FUNCTION MENU

To enter the function menu from standby mode, press and hold the ⊖ button for more than 2 seconds.


Each subsequent press of the ⊖ button will step through the available functions.



Stand-By Mode


Push ▸ Button More Than Two Second

“Function 1”




Push ⊖ button More Than Two Second

“Function 2”




Push ⊖ button

“Function 3”




Push ⊖ button

“Function 4”




Push ⊖ button

“Function 5”




Push ⊖ button

“Function 6”




Push ⊖ button

“Function 7”




Push ⊖ button

"Function 8"




Push  button

"Function 9"



Push  button




Stand-By Mode

④ SETTING FUNCTIONS

1) Selection of alert type


There are 7 types of alert mode available, bleep, melodies 1-5 and silent/ vibrate. To select these, press and hold the  button until 'SET BEEP' is displayed, and then select the alert mode using the  button. The selected mode will sound, following which you should press the  button to return to standby.




Stand-By Mode

Push  Button More Than Two Second


"Function 1"




Push  button




Push  button



Push  button



Push  button




Stand-By Mode

2) Power On/ Off

Function 2 is selected by pressing and holding the $\odot$ button until a short beep is heard, and then press the $\odot$ button once more. The display will show:


"Function 2"




Push $\blacktriangleright$ Button

Pressing the $\blacktriangleright$ button will now turn off the pager. The current time will be shown, but messages cannot be received.

To switch the pager back on, press the $\blacktriangleright$ button. The pager will self test and return to standby mode.



Push $\blacktriangleright$ Button




Stand-By Mode

3) Setting Date and Time

Function 3 is selected by pressing and holding the $\odot$ button until a short beep is heard, and then press the $\odot$ button twice more. The display will show:


"Function 3"










Push $\blacktriangleright$ Button

Press the $\blacktriangleright$ button and adjust the Year, Month, Date, Hour, Minutes (tens), Minutes (units), AM/PM by selecting each item with the $\odot$ button and adjusting each item with the $\blacktriangleright$ button.

Once the correct Date and Time has been selected, return to standby mode by pressing the $\odot$ button or waiting 8 seconds.




Select the Year
Using $\blacktriangleright$ Button

Push  button	
	Select the Month Using  Button
Push  button	
	Select the Date Using  Button
Push  button	
	Select the Time Using  Button
Push  button	
	Select the Minute(1 st) Using  Button
Push  button	
	Select the Minute(2 nd) Using  Button
Push  button	
	Select the AM/PM Using  Button
Push  button	
	
Stand-By Mode	

4) Setting Alarm Clock

Function 4 is selected by pressing and holding the  button until a short beep is heard, and then press the  button Three times more. The display will show:


"Function 4"



Push  Button


Press the  button and adjust the Hour, Minutes (tens), Minutes (units), AM/PM by selecting each item with the  button and adjusting each item with the  button.

Once the required alarm time has been selected, return to standby mode by pressing the $\odot$ button or waiting 8 seconds. The LCD will display the $\odot$ symbol




Select the Time
Using $\blacktriangleright$ Button

Push $\odot$ button




Select the Minute(1st)
Using $\blacktriangleright$ Button

Push $\odot$ button




Select the Minute(2nd)
Using $\blacktriangleright$ Button

Push $\odot$ button



Select the AM/PM
Using $\blacktriangleright$ Button

Push $\odot$ button




Stand-By Mode

5) Turning Alarm Clock Off


Function 5 is selected by pressing and holding the $\odot$ button until a short beep is heard, and then press the $\odot$ button four times more.

Press the $\blacktriangleright$ button to switch off the alarm clock and return to standby mode.

“Function 5”



Push $\blacktriangleright$ Button




Stand-By Mode

6) Setting Automatic Power On/Off

Function 6 is selected by pressing and holding the $\odot$ button until a short beep is heard, and then press the $\odot$ button five times more. The display will show:


“Function 6”



Push ▸ Button


Press the ▸ button and adjust the Hour and AM/PM by selecting each item with the ⊙ button and adjusting each item with the ▸ button.

Once the required automatic on and off times have been selected, return to standby mode by pressing the ⊙ button or waiting 8 seconds. The LCD will display the ○ symbol.




Push ⊙ button

Select the Time
of Automatic Power On
Using ▸ Button




Push ⊙ button

Select the AM/PM
of Automatic Power On
Using ▸ Button




Push ⊙ button

Select the Time
of Automatic Power Off
Using ▸ Button



Push ⊙ button

Select the AM/PM
of Automatic Power Off
Using ▸ Button




Stand-By Mode

7) Cancelling Automatic Power On/ Off


Function 7 is selected by pressing and holding the ⊙ button until a short beep is heard, and then press the ⊙ button six times more.

Press the ▸ button to switch off the automatic on/ off and return to standby mode.

“Function 7”



Push ▸ Button



Stand-By Mode


8) Entire Message Deletion

WARNING: Use of this feature will delete all of the stored messages



Function 8 is selected by pressing and holding the button until a short beep is heard, and then press the button seven times more.

Press and hold the button until the word 'Erased' appears on the LCD. The pager will then delete all stored messages and return to standby mode.

"Function 8"



Push Button More Than Two Second




Stand-By Mode

9) Stop Watch

Function 9 is selected by pressing and holding the button until a short beep is heard, and then press the button eight times more. The display will show:

"Function 9"



Push Button

Press the button to enter stop watch mode.


Successive presses of the button will start and stop the timer.

Pressing the button momentarily will reset the stop watch to zero.


Press and hold the button to return to standby



Push Button



Start



Push ▶ Button



Stop

Push ▶ Button More Than Two Second




Reset

Stand-By Mode

⑤ OTHER FUNCTIONS


1) Low Battery Warning

The words 'LOW BATTERY' will appear in the LCD when the battery requires replacement. Insert a new AAA battery, taking care to note the polarity marked on the case.




2) Receipt Of Duplicated Message

The time, duplicated sign and number of duplications is displayed when an identical message to one already stored in memory is received.




3) Duplication Of Locked Message

The word 'DUPLICATED' is displayed on the LCD when an attempt is made to lock a message which is identical to one already locked.




4) Tone Only

The words 'TONE ONLY' are displayed on the LCD when a call is received without a message.




5) Unread Messages

The number of messages that have been received and not read will be displayed on the LCD



6) Memory Full Indication

The words 'MEM FULL' are displayed on the LCD when 20 messages have been locked. No further messages can be locked until some or all have been deleted.



3 REPLACEMENT OF BATTERY

Change the battery when 'LOW BATTERY' appears on the LCD.

Remove the battery door by sliding the lock upwards and gently sliding the door sideways.

Insert a new AAA battery, taking care to note the polarity marked on the case.

Replace the battery cover and slide the lock down into place.

1-1. Receiver

1-1-1	Frequency Range	135.000MHz~174.000MHz
1-1-2	Channel Spacing	25KHz
1-1-3	Sensitivity(Optimal Position)	1200bps:7 μ V, 2400bps:9 μ V
1-1-4	Receiving Method	Double Super Heterodyne
1-1-5	Image Rejection	More Than 55db
1-1-6	Spurious Rejection	More Than 60db
1-1-7	Selectivity	More Than 65db
1-1-8	Frequency Stabilization	Less Than 10ppm Min(-10 $^{\circ}$ C ~ +50 $^{\circ}$ C)
1-1-9	Radio Forms	F2A/B
1-1-10	Dimension	58.0(W) $\times$ 18(H) $\times$ 48(D)

1-2. Decode

1-2-1	Signal Method	Pocsag
1-2-2	Modulation Scheme	FSK $\pm$ 4.5KHz
1-2-3	Bit Rate	512, 1200, 2400bps

1-3. Display

1-3-1	Display Device	L. C. D
1-3-2	L. C. D	Lamp

1-4. Alert And Memory Capacity

1-4-1	Alert Type	4ea(A, B, C, D)
1-4-2	Address Capacity	2,000,000
1-4-3	Memory Capacity	280Character

1-5. Error Detect And Correction Method

B.C.H

1-6. Receiver

1-6-1	Alert Frequency	3200Hz
1-6-2	Alert Level	More Than 75db SPL (@ 30cm)

1-7. Vibration Alert

Vibration Motor