


TB688




User's Manual

Precaution

Thank you for purchasing this digital TB688. For perfect operation and security, please read the manual carefully and keep it for future reference.

Safety Precautions



The lightning icon inside a triangle is intended to alert the user to the presence of exposed dangerous voltages within the product's enclosure, that could cause electric shock.



The lightning icon inside a triangle is intended to alert the user to read important operating and maintenance(servicing) instructions within the literature accompanying this product.

Important Safety Instructions

- 1) Read these instructions.
- 2) Keep these instructions.
- 3) Heed all warnings.
- 4) Follow all instructions.
- 5) Do not use this apparatus near water.
- 6) Clean only with dry cloth.
- 7) Do not block any ventilation openings, install in accordance with the manufacturer's instructions.
- 8) Do not place near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- 9) Do not bypass the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety, if the provided plug does not fit into your outlet. consult an electrician for replacement of the obsolete outlet.
- 10) Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- 11) Only use attachments/accessories specified by the manufacturer.
- 12) Use only with the trolley, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tipping over (Figure 1).
- 13) Unplug this equipment during lightning storms or when unused for a long periods of time.
- 14) Refer all servicing to qualified service personnel. Servicing is required when the equipment has been damaged in any way, such as power-supply cord, or plug is damaged, liquid has been spilled or objects have fallen into the equipment, the equipment has been exposed to rain or moisture, does not operate normally, or has been dropped.



(Figure 1)

WARNING: To reduce the risk of fire or electric shock, do not expose this equipment to rain or moisture.

CAUTION: Equipment must not be exposed to liquid dripping or splashing and also no objects filled with liquids, such as vases, or beverages may be placed.

Always make sure all batteries are inserted the correct way around to match the +/- polarity markings.

Always replace all of the batteries at the same time. Do not combine old and new batteries, also do not mix battery types, as this can cause overheating, or fire, or battery fluid leakage.

Remove the batteries from the instrument if it is not to be used for a long time.

Thanks For Using Our Electronic Keyboard

Your instrument is a high-quality electronic keyboard with 61 standard touch sensitive keys, and which employs the most advanced PCM tone generation technology, as well as a high quality DSP (Digital Signal Processor). It has 203 accompaniment styles which can be used to provide fully-orchestrated auto accompaniment. The multi-functional LCD (Multi Display) provides easy to understand information regarding your keyboard's various settings.

We recommend that you read through the manual carefully, so you can get the best performance and maximum enjoyment from your new electronic keyboard.

Contents

Panel Control	1
Basic Operation	3
Turn On the Power	3
Phones/Line Out Jack	3
Line In Jack	3
Pedal Jack	4
Mic Jack	4
USB To Host Jack	4
Adjust the Main Volume	5
Demo Songs	5
Play the Electronic Keyboard	6
Select a Voice	6
Overall Control	7
Auto Accompaniment	14
Selecting a Style	14
Turn Chord On/Off	14
Full keyboard	15
Accompaniment Control	16
Metronome	16
Overall Control	17
Registration Memory	18
Record and Play	19
Chord Dictionary	20
Teaching Function	21
Appendix	23
Percussion Voice List	23
Voice List	24
Style List	27
Troubleshooting Hints	29
Specifications	30


Top Panel Controls

1. POWER[POWER ON/OFF]
2. MASTER VOLUME
3. [REVERB] Button
4. [CHORUS] Button
5. [APREG.] Button
6. [TRANS./TUNE] Button
7. [TEMPO/TAP] Button
8. [MIXER] Button
9. ACCOMPANIMENT CONTROL
[SYNCHRO] Button
[START/STOP] Button
[INTRO/ENDING] Button
[FILL IN] Button
10. [KBD.MODE] Button
11. [PEDAL] Button
12. [TOUCH] Button
13. [O.T.S] Button
14. [GRAND PIANO] Button
15. REGESTRATION MEMORY
[STORE/BANK] Button
[M1]-[M4]Button
16. [METRONOME] Button
17. MULTI LCD DISPLAY
18. [+] [-] Buttons
[0] - [9] Number Buttons
19. [VOICE/STYLE] Button
20. [DUAL] Button
21. [DEMO/LEARN] Button
22. [RECORD] Button
23. [PLAY] Button

Rear Panel Controls


24. Pitch Bend
25. DC 12V In Jack
26. Phones/Line Out Jack
27. Line In Jack
28. Pedal Jack
29. Mic Jack
30. USB To Host

Panel Controls



Turn On the Power

1. Ensure the keyboard is turned off when connecting and disconnecting the power, and turn the volume switch to reach the minimum level.



2. Connect the adaptor into the AC wall outlet and the cord into the unit, then turn the power on.

NOTE:

When the keyboard is not in use or in the time of thunderstorm, please disconnect the power for safety purpose.

Phones/Line Out jack

Plug a set of stereo headphone into the [PHONES/LINE OUT] jack, and the internal speaker system is automatically shut off when the headphone is plugged.


The [PHONES/LINE OUT] jack can be used to deliver the output of the piano to a keyboard amplifier, stereo sound system, mixing console or tape recorder.



Line In jack


The audio output from other sound system connected to the LINE IN jack on the rear panel can be mixed with the sound of the unit. This function is convenient when you want to play along with a favourite song.

Basic Operation




Pedal Jack

A foot switch can be plugged into the rear-panel [PEDAL] jack. The Pedal is a damper pedal controlling sustain function. Press the pedal you can sustain the notes after the keys are released.



Mic Jack

A Micphone can be plugged into the rear-pannel [MIC] jack .



USB To Host Jack


Connect PC or other USB to host devices that support USB audio with a standard USB cable. For devices with USB cable, after the driver is installed and initialization is finished, you can choose USB audio device in the device menu of the software to transfer midi data.



Basic Operation

Adjust the Main Volume



Use [MAIN VOLUME] control to adjust the volume to your desired level.



Demo Songs

There are 5 preset demo songs and 100 learning songs that you can play individually. Here's how you can select and play the demo songs .

1. Press [DEMO/LEARN] button and the LCD display : “d0” .Then your instrument will play the demo songs in sequence.



2. Use the [+] [-] button or number button to select a demo song. Press the [TEMPO/TAP] button and then press [+] [-] button to change the tempo.

3. Press [DEMO/LEARN] button again to stop playing.


Play the Electronic Keyboard

Your instrument has 479 voices that you can select and play.

Select a Voice

- Press the [VOICE/STYLE] button to let the cursor point to "VOICE". The voice number will appear on the LCD display.

Select a Main Voice Number



Use the [+] / [-] buttons or the number buttons to select the required voice number (01-479). Press the [+] button briefly to increment the value, or the [-] button to decrement. If you hold the [+] or [-] button down, the value will increment or decrement continuously - simply release the button when the desired value has been reached.

1~9 voice: press 01~09.

10~99 voice: press 10~99.

100~479 voice: hold the [1] button till the LCD displays: 1_ _, then enter the tens digit and single digits.

In Voice Mode, the main voice number will appear on the LCD.


Select a Split Voice Number

Your keyboard can be split into two sections which means different voices can be played with the left and right hands at the same time.

Press [KBD.MODE] button so that the cursor points to "SPLIT" to turn Split mode ON. The split voice number will appear on the MULTI DISPLAY. Use the [+] and [-] buttons or the number buttons to select the desired split voice number (01 through 479). There is a horizontal line behind the "33" when the LCD display the voice of left hand area.

If you want to change the voice of right hand area, press the [VOICE/STYLE] button, then the horizontal line will disappear, you can use the [+] and [-] buttons or the number buttons to select desired voice and the LCD will display the number of the right hand area.


Play the Electronic Keyboard



Overall Control

Pedal


Press [PEDAL] button to turn on/off the function. Press the [PEDAL] button and then press the pedal ,the cursor will point to [PEDAL].



1. Multi-function pedal

This function allows you to set the function of the pedal plugged into the pedal jack on the back board.

Your instrument has 7 different pedal functions. Press the [PEDAL] button. Then use [+] and [-] buttons to select your desired pedal function among “PE1-PE7” .



Play the Electronic Keyboard

PE1----- It performs the same function as the damper pedal on an actual acoustic piano, letting you sustain the sound of the voices even after releasing your fingers from the keys.

PE2-----It performs the same function as the soft pedal on an actual acoustic piano, the volume of the whole keyboard will decrease when you play the TB688 keys and depress the soft pedal.

PE3-----If you play a note or chord on the keyboard and press the sostenuto pedal whilst the notes are held, those notes will be sustained as long as the pedal is held, but all subsequently played notes will not be sustained.

PE4-----You can change the volume of the keyboard by the pedal.

PE5-----This function is the same as the [START/STOP] button on the front panel. Switches the rhythm on/off whenever you press the Left Foot-switch.


PE6-----This function is the same as the [FILL 1] button on the front panel. Let you add dynamic variations and breaks in the rhythm of the accompaniment.

PE7-----Anytime you store to a REGISTRATION MEMORY button, all settings previously stored in that button will be erased and replaced by the new settings.

2.Detail Instructions

Sustain Pedal (Switch-type Pedal)

If your pedal is a switch-type pedal, connect the pedal to your piano, then the pedal is ready to use. The default pedal function is “PE1”, sustainer pedal function.



Note: If “PE4” is selected while you are using the sustain pedal, the pedal can only be used to turn on or off the keyboard volume.

Volume Pedal(AD-type Pedal)


If your pedal is a volume pedal, you have to preset it.

Press the [REVERB], [TRANSPOSE] and [POWER] button at the same time to enter the Pedal Setting Mode. Press the [+] (or [-]) button before stepping the pedal. Then step the pedal and press the [-] (or [+]) button.

Then the LCD will show two values between 0 and 255. Press the [STORE/BANK] button to save your redefined parameters.

Note: If your instrument is restored, it will restore the current setting.


Play the Electronic Keyboard



PITCH BEND


The PITCH BEND wheel is located on the left side of your keyboard that can be used to tune the pitch of the keyboard. Push the wheel upward, the keyboard pitch will be increased and pull wheel downward will decreased the keyboard pitch.

Push the wheel to the top position for about 2 seconds, LCD will display the pitch range (pitch sensitivity). You can use the [+] and [-] or the number [0]-[9] buttons or the digital dial to set the pitch sensitivity: 1~ 12 semitones. When the power is turned ON, the preset sensitivity is +/- 2 semitones.



Touch

Press [TOUCH] button, you can turn ON/OFF the touch function. When the Touch function is ON, the volume will be varied according to how hard you play on the keyboard.




Play the Electronic Keyboard

Reverb

Press the [REVERB] button and then use the [+]/- buttons to select the Reverb types (10).


Hold down the [REVERB] button, LCD will display the value of Reverb depth, then you can use [+]/- buttons or number button to set the value:00-63(default:18).



Trans/Tune

Press the [Trans/Tune] button until the LCD display “ 7_U ” , it possible to shift the pitch of this instrument up or down in semitone intervals up to a maximum of 12 semitones (total one octave).

Press the [Trans/Tune] button until the LCD display “ 7_U ” , this function makes it possible to tune the pitch of your instrument to match other instruments. Tune can be accomplished over ± 50 cents range (that's 100 cents total, or one semitone) in 128 (-64~63) steps (approximately 0.8 cents per step).




Chorus

Press the [CHORUS] button and then use the [+]/- buttons to select the Chorus types (8).

Hold down the [CHORUS] button, LCD will display the value of Chorus depth, then you can use [+]/- buttons or number button to set the value:00-63(default:18).

Play the Electronic Keyboard




Arpeggio

An Arpeggio, also called “broken chord” , is a group of notes played in sequence from the lowest to the highest note or from the highest to the lowest note. It is a musical technique usually used in practicing songs. An arpeggio may be a melody part of songs and may be written with a squiggly vertical line in front of the chord. Arpeggio is divided into the Tonic Triad, Diminished Seventh Chords and Dominant Seventh Chord.

Press the [ARPEGGIO] button and the LCD will show “P1” , indicating the Arpeggio function is enabled. When “P1” is selected, hold one key or several keys and you will hear the note played from the lowest to the highest. When “P2” is selected, hold one key or several keys and you will hear the note played from the highest to the lowest.

Repeatedly press the [ARPEGGIO] button to turn off the Arpeggio function.




Mixer

This function can set Accompaniment Volume, Main Volume, Split Volume, Dual Volume and Metronome Volume.

Accompaniment Volume


Press the [MIXER] button repeatedly to select “**AC**” , then use [+]/[-] buttons or number buttons to set the Accompaniment Volume. Range: 00~15. Default: 12

Play the Electronic Keyboard




M. Volume

Press the [MIXER] button repeatedly to select “*rG*” , then use [+]/[-] buttons or number buttons to set the Main Volume. Range: 00~127. Default: 127.



S. Volume


Press the [MIXER] button repeatedly to select “*LF*” , then use [+]/[-] buttons or number buttons to set the Split Volume. Range: 00~127. Default: 127.



Dual Volume


Press the [MIXER] button repeatedly to select “*du*” , then use [+]/[-] buttons or number buttons to set the Dual Volume. Range: 00~127. Default: 75.

Play the Electronic Keyboard



Metronome Volume

Press the [MIXER] button repeatedly to select “7r”, then use [+]/[-] buttons or number buttons to set the Metronome Volume. Range: 00~127. Default: 127.



Grand Piano

Press the [GRAND PIANO] button. This convenient function allows you to instantly call up the Grand Piano voice.




Dual

This function is capable of enhancing the delicacy of your music by playing two voices of musical instruments simultaneously; new combinations of voices and music could be created then.

Press [+]/[-] buttons or number button to select your desired voice.

Press [DUAL] button again to turn off the dual voice

When the cursor is stop flashing, you can select the main voices. .



Auto Accompaniment

The keyboard has a total of 203 accompaniment styles which can be used to provide Fully-orchestrated Auto Accompaniment. When the Auto Accompaniment function is turned on, this instrument creates fully-orchestrated rhythm, bass and chord accompaniment based on chords that you play with the left hand, in the Auto Accompaniment section of the keyboard (i.e. all keys to the left of the Auto Accompaniment split point). The right-hand section of the keyboard is available for normal playing.

The default Auto Accompaniment split point is the F 2 key. The Auto Accompaniment section of the keyboard consists of all keys to its left.

Selecting a Style


Press the [VOICE/STYLE] button to let the Active Input Arrow point to string “STYLE”. The style number will appear on the MULTI DISPLAY. You can use the [+] and [-] buttons or the number buttons to select the required style number(00 through 203).

You can use [+]/[-] buttons or number buttons to select the desired style.

1~9 style: press 01~09.

10~99 style: press 10~99.


100~203 style: hold the [1] button till the LCD displays: 1_ , then enter the tens digit and single digits.



Turn Chord On/Off

Press the [KBD.MODE] button repeatedly to select “CHORD” and its Active Input Arrow lights. The specified left-hand section of the keyboard becomes the “Auto Accompaniment” section, and chords played in this section are automatically detected and used as a basis for fully automatic accompaniment with the selected style.

Auto Accompaniment




Full Keyboard

This function detects chord in entire key range. Chords are detected in a way similar to fingered, even if you split the notes between your left and right hands.

For example: playing a bass note with your left hand and a chord with you right, or by playing a chord with your left hand and a melody note with your right.

Press [FULL KEYBOARD] button to enter the Full Keyboard mode. “FULL KEYBOARD” signal appears in the display.



Press [SYNCHRO] button to enter the sync start waiting mode, play the keyboard to start the accompaniment.

Press [KBD.MODE] repeatedly to turn off the full keyboard function and the cursor will disappear.

Auto Accompaniment



Accompaniment Control

The [START/STOP] button starts the selected accompaniment style immediately.

Selecting the Chord mode(Reference:Turn chord on/off P.14) . The left hand section of the keyboard becomes the Auto Accompaniment section, and chords played in this section are automatically detected and used as a basis for fully automatic accompaniment with the selected style.

Any of your instrument accompaniment patterns can be started with an appropriate introduction by pressing the [INTRO/ENDING] button directly.



If you press the [SYNCHRO] button and then the [INTRO/ENDING] button, the accompaniment will start from the introduction as soon as a chord is detected in the AUTO ACCOMPANIMENT section of the keyboard.



Press the [FILL IN] button at any time while the accompaniment is playing to add a one-measure fill-in.

If you hold the [FILL IN] button , the fill-in pattern will repeat until the button is released , then the MAIN section will play from the beginning of the next measure.

Press the [SYNCHRO] button, then the accompaniment will start when you play the first chord on the AUTO ACCOMPANIMENT section of the keyboard.




Metronome

The metronome sound may be alternately turned on and turned off by pressing the [METRONOME] button.

Hold the [METRONOME] button to enter the page for selecting the time signature. Then use the [+]/[-] buttons to select your desired time signature.

Time signature: 2/2,1/4, 2/4, 3/4, 4/4, 5/4,6/4, 3/8, 6/8, 7/8,9/8,12/8.(Default: 4/4)


Auto Accompaniment



Overall Control

Tempo

This function allows you to set the rhythm tempo by tapping in tempo on [TEMPO/TAP] button. Tap on the button 2 times while rhythm is playing, The rhythm tempo are set as your desired speed.




If you want to set the tempo before starting rhythm, you have to tap the button 4 times.

O.T.S

This function is actually a convenient feature to automatically select a suitable voice to match your selected style. In addition, various panel settings (such as voice, effect, Tempo, etc.) that match the selected style can be recalled with just a single button [O.T.S].

Press the [O.T.S] button to enter this mode and the arrow point strings to O.T.S.

Press the [O.T.S] button repeatedly to turn on or turn off One Touch Setting function.




Registration Memory

Your instrument REGISTRATION MEMORY can be used to store 4 sets of VOICE and AUTO ACCOMPANIMENT settings that can be recalled during you playing at the touch of one single button. The main voice number (right hand), split voice number (left hand), sustain and touch status, tempo value, transpose value, Auto Accompaniment volume (ACC VOL) , Chord and split status can be restored to REGISTRATION MEMORY.

Memorizing the settings


The panel settings listed above can be stored to any one of the 4 registration memory buttons by pressing the button [M1] , [M2] , [M3] or [M4] while holding the [STORE/BANK] button . The [S-1]-[S-4] will appear on the LCD display.

Press the [STORE/BANK] button repeatedly to change the banks:1-8. The defalut bank is :1.



Recalling the settings

The settings stored to a REGISTRATION MEMORY button can be recalled simply by pressing the [M1]-[M4] button. The [E-1]-[E-4] will appear on the LCD display.




Record and Play

Your instrument allows you to record and playback what you have played on the keyboard include part panel operation.

Record

Press the [RECORD] button to start recording and the arrow point to RECORD.


Press this [RECORD] button again to stop recording.



Play

Press [PLAY] button, you can enjoy the song you have recorded. Now you can follow the song by playing the keyboard and change the tempo of the song by press [TEMPO/TAP] button.

Press [PLAY] button again, the playing will be ended.




Chord Dictionary

The Chord Dictionary function allows you to look up chords. When you want to quickly learn how to play a certain chord, the Dictionary function will help you to look up the individual notes of the chord.


Chord Dictionary

Press the [KBD.MODE] Button repeatedly to select Chord Dictionary, the arrow point to Chord Dictionary.




Select the Chord Root

Press the root note of the Chord you want to look up. This needs to be in the Chord Root section of the keyboard. For example:



Select the Chord Type

After pressing the Chord Root, select the Chord Type you want to look up in the Chord Type section of the keyboard. The Chord Type includes Major Triad, Minor Triad and Seventh Chord. Then the LCD will display the Chord Type and key position you currently want to look up. If you press the correct key as the notes shown on the LCD, the beep will sound.



Exit the Chord Dictionary

Press the [KBD.MODE] button again to exit the function.


Teaching Function

Your instrument has a teaching function which can teach a beginner how to play a song. There are three teaching steps for you to learn by playing the songs step by step.

Learn 1

Hold down the [DEMO/LEARN] button to enter the Learn mode and the LCD will display "L1". You can use[+] [-] button or number button to select lean songs and then press [PLAY] button to start learning function. When you play a key on the keyboard, the teaching song will be layed note by note. Making it easy and fun for you to learn.


After playing the learning song two seconds ,it will stop learning state, you can press [DEMO/LEARN] button repeatedly until the screen does not display the "L" to exit this function.



Learn 2

Hold down the [DEMO/LEARN] button to enter the Learn mode and press [DEMO/LEARN] button repeat to select "L2". You can use[+] [-] button or number button to select lean songs and then press [PLAY] button to start learning function. The learning song will continue until you play the correct key on the keyboard. You can quickly master these songs in a very short time.

After playing the learning song two seconds ,it will stop learning state, you can press [DEMO/LEARN] button repeatedly until the screen does not display the "L" to exit this function.



Teaching Function

Learn 3

Hold down the [DEMO/LEARN] button to enter the Learn mode and press [DEMO/LEARN] button repeat to select “L3”. You can use[+] [-] button or number button to select lean songs and then press [PLAY] button to start learning function. You can play the song with the instrumentation playing. Now you can play this song by yourself.

After playing the learning song two seconds ,it will stop learning state, you can press [DEMO/LEARN] button repeatedly until the screen does not display the "L" to exit this function.



Appendix

Percussion Voice List

Note#	Note	Standard(0)	Room(8)	Power(16)	Electronic(24)	Synth(25)	Jazz(32)	Brush(40)	Classic(48)	Effects(56)
24	C	Seq Click H	←→	←→	←→	←→	←→	←→	←→	
25	#C	Brush Tap	←→	←→	←→	←→	←→	←→	←→	
26	D	Brush Swirl L	←→	←→	←→	←→	←→	←→	←→	
27	#D	Brush Slap	←→	←→	←→	←→	←→	←→	←→	
28	E	Brush Swirl H	←→	←→	Rever se Cymbal	Rever se Cymbal	←→	←→	←→	
29	F	Snare Roll	←→	←→	←→	←→	←→	←→	←→	
30	#F	Castanet	←→	←→	Hi-Q	Hi-Q	←→	←→	←→	
31	G	Snare L	←→	SD Elec M	Snare L	SD Elec H2	Snare Jazz	Brush Slap L	←→	
32	#G	Sticks	←→	←→	←→	←→	←→	←→	←→	
33	A	Bass Drum L	←→	←→	←→	←→	←→	←→	Bass Drun L3	
34	#A	Open Rim Shot	←→	←→	←→	←→	←→	←→	←→	
35	B	Bass Drum M	←→	←→	BD Rock	BD Analog 1L	←→	←→	Gran Casa	
36	C	Bass Drum H	←→	BD Rock	BD Rock 2	BD Analog 1H	BD Jazz	BD Jazz	Gran Casa Mute	
37	#C	Side Stick	←→	←→	←→	Analog Side Stick	←→	←→	←→	
38	D	Snare M	SD Room L	SD Rock	SD Elec M	SD Analog 1H	SD Jazz L	Brush Slap H	Marching SD M	
39	#D	Hand Clap	←→	←→	←→	←→	←→	←→	←→	High-Q
40	E	Snare H	SD Room H	SD Rock Rim	SD Elec H	SD Analog 1L	SD Jazz H	Brush Tap	Marching SD H	Slap
41	F	Floor Tom L	Room Tom 1	Rock Tom 1	E Tom 1	Analog Tom 1	←→	Brush Tom 1	←→	Scratch Push
42	#F	Hi-Hat Closed	←→	←→	←→	Analog HH Closed1	←→	←→	←→	Scratch Pull
43	G	Floor Tom H	Room Tom 2	Rock Tom 2	E Tom 2	Analog Tom 2	←→	Brush Tom 2	←→	Sticks
44	#G	Hi-Hat Pedal	←→	←→	←→	Analog HH Closed2	←→	←→	←→	Square Click
45	A	Low Tom	Room Tom 3	Rock Tom 3	E Tom 3	Analog Tom 3	←→	Brush Tom 3	←→	Mtrnm .Click
46	#A	Hi-Hat Open	←→	←→	←→	Analog HH 1Open	←→	←→	←→	Mtrnm. Bell
47	B	Mid Tom L	Room Tom 4	Rock Tom 4	E Tom 4	Analog Tom 4	←→	Brush Tom 4	←→	Gt.FretNoiz
48	C	Mid Tom H	Room Tom 5	Rock Tom 5	E Tom 5	Analog Tom 5	←→	Brush Tom 5	←→	Gt.CutNoise
49	#C	Crash Cymbal 1	←→	←→	←→	Analog Cymbal	←→	←→	Hand Cym.L Open	Gt.CutNoise
50	D	High Tom	Room Tom 6	Rock Tom 6	E Tom 6	Analog Tom 6	←→	Brush Tom 6	←→	String Slap
51	#D	Ride Cymbal 1	←→	←→	←→	←→	←→	←→	Hand Cym.L Closed	Fl.KeyClick
52	E	Chinese Cymbal	←→	←→	←→	←→	←→	←→	←→	Laughing
53	F	Ride Cymbal Cup	←→	←→	←→	←→	←→	←→	←→	Screaming
54	#F	Tambourine	←→	←→	←→	←→	←→	←→	←→	Punch
55	G	Splash Cymbal	←→	←→	←→	←→	←→	←→	←→	Heart Beat
56	#G	Cowbell	←→	←→	←→	Analog Cowbell	←→	←→	←→	Footsteps 1
57	A	Crash Cymbal 2	←→	←→	←→	←→	←→	←→	Hand Cym.H Open	Footsteps 2
58	#A	Vibraslap	←→	←→	←→	←→	←→	←→	←→	Applause
59	B	Ride Cymbal 2	←→	←→	←→	←→	←→	←→	Hand Cym.H Closed	Door Creaking
60	C	Bongo H	←→	←→	←→	←→	←→	←→	←→	Door
61	#C	Bongo L	←→	←→	←→	←→	←→	←→	←→	Scratch
62	D	Conga H Mute	←→	←→	←→	Analog Conga H	←→	←→	←→	Wind Chimes
63	#D	Conga H Open	←→	←→	←→	Analog Conga M	←→	←→	←→	Car-Engine
64	E	Conga L	←→	←→	←→	Analog Conga L	←→	←→	←→	Car-Stop
65	F	Timbale H	←→	←→	←→	←→	←→	←→	←→	Car-Pass
66	#F	Timbale L	←→	←→	←→	←→	←→	←→	←→	Car-Crash
67	G	Agogo H	←→	←→	←→	←→	←→	←→	←→	Siren
68	#G	Agogo L	←→	←→	←→	←→	←→	←→	←→	Train
69	A	Cabasa	←→	←→	←→	←→	←→	←→	←→	Jetplane
70	#A	Maracas	←→	←→	←→	Analog Maracas	←→	←→	←→	Helicopter
71	B	Samba Whistle H	←→	←→	←→	←→	←→	←→	←→	Starship
72	C	Samba Whistle L	←→	←→	←→	←→	←→	←→	←→	Gun Shot
73	#C	Cuiro Short	←→	←→	←→	←→	←→	←→	←→	Machine Gun
74	D	Cuiro Long	←→	←→	←→	←→	←→	←→	←→	Lasergun
75	#D	Claves	←→	←→	←→	Analog Claves	←→	←→	←→	Explosion
76	E	Wood Block H	←→	←→	←→	←→	←→	←→	←→	Dog
77	F	Wood Block L	←→	←→	←→	←→	←→	←→	←→	HorseGallop
78	#F	Guica Mute	←→	←→	Scratch Push	Scratch Push	←→	←→	←→	Bird
79	G	Guica Open	←→	←→	Scratch Pull	Scratch Pull	←→	←→	←→	Rain
80	#G	Triangle Mute	←→	←→	←→	←→	←→	←→	←→	Thunder
81	A	Triangle Open	←→	←→	←→	←→	←→	←→	←→	Wind
82	#A	Shaker	←→	←→	←→	←→	←→	←→	←→	Seashore
83	B	Jingle Bell	←→	←→	←→	←→	←→	←→	←→	Stream
84	C	Bell Tree	←→	←→	←→	←→	←→	←→	←→	Bubble

Appendix

Voice List

NO.	PROGRAM CHANGE	BANK	VOICE NAME
Piano			
01	0	0	AcousticGrandPiano
02	1	0	BrighAcoustictPiano
03	2	0	ElectricGrandPiano
04	3	0	Honky-TonkPiano
05	4	0	Electricpiano1
06	5	0	ElectricPiano2
07	6	0	Harpsichord
08	7	0	Clavi
Chromatic Percussion			
09	8	0	Celesta
10	9	0	Glockenspiel
11	10	0	MusicBox
12	11	0	Vibraphone
13	12	0	Marimba
14	13	0	Xylophone
15	14	0	TubularBells
16	15	0	Dulcimer
Organ 风琴			
17	16	0	DrawbarOrgan
18	17	0	PercussiveOrgan
19	18	0	RockOrgan
20	19	0	ChurchOrgan
21	20	0	ReedOrgan
22	21	0	Accordion
23	22	0	Harmonica
24	23	0	TangoAccordion
Guitar			
25	24	0	AcousticGuitar(Nylon)
26	25	0	AcousticGuitar(Steel)
27	26	0	ElectricGuitar(Jazz)
28	27	0	ElectricGuitar(Clean)
29	28	0	ElectricGuitar(Muted)
30	29	0	OverdrivenGuitar
31	30	0	DistortionGuitar
32	31	0	GuitarHarmonics
Bass			
33	32	0	AcousticBass
34	33	0	FingerBass
35	34	0	PickBass
36	35	0	FretlessBass
37	36	0	SlapBass1
38	37	0	SlapBass2
39	38	0	SynthBass1
40	39	0	SynthBass2
Strings			
41	40	0	Violin
42	41	0	Viola
43	42	0	Cello
44	43	0	Contrabass
45	44	0	TremoloStrings
46	45	0	PizzicatoStrings
47	46	0	OrchestralHarp
48	47	0	Timpani
Ensemble			
49	48	0	StringsEnsemble1
50	49	0	StringsEnsemble2

NO.	PROGRAM CHANGE	BANK	VOICE NAME
51	50	0	Synth Strings 1
52	51	0	Synth Strings 2
53	52	0	Choir Aahs
54	53	0	Voice Oohs
55	54	0	Synth Voice
56	55	0	Orchestra Hit
Brass			
57	56	0	Trumpet
58	57	0	Trombone
59	58	0	Tuba 长号
60	59	0	Muted Trumpet
61	60	0	French Horn
62	61	0	Brass Section
63	62	0	Synth Brass 1
64	63	0	Synth Brass 2
Reed			
65	64	0	Soprano Sax
66	65	0	Alto Sax
67	66	0	Tenor Sax
68	67	0	Baritone Sax
69	68	0	Oboe
70	69	0	English Horn
71	70	0	Bassoon
72	71	0	Clarinet
Pipe			
73	72	0	Piccolo
74	73	0	Flute
75	74	0	Recorder
76	75	0	Pan Flute
77	76	0	Blown Bottle
78	77	0	Shakuhachi
79	78	0	Whistle
80	79	0	Ocarina
Synth Lead			
81	80	0	Lead 1 (Square)
82	81	0	Lead 2 (Sawtooth)
83	82	0	Lead 3 (Calliope)
84	83	0	Lead 4 (Chiff)
85	84	0	Lead 5 (Charang)
86	85	0	Lead 6 (Voice)
87	86	0	Lead 7 (Fifth)
88	87	0	Lead 8 (Bass+Lead)
Systh Pad			
89	88	0	Pad 1 (New Age)
90	89	0	Pad 2 (Warm)
91	90	0	Pad 3 (Polysynth)
92	91	0	Pad 4 (Choir)
93	92	0	Pad 5 (Bowed)
94	93	0	Pad 6 (Metallic)
95	94	0	Pad 7 (Halo)
96	95	0	Pad 8 (Sweep)
Synth Effects			
97	96	0	Fx 1 (Rain)
98	97	0	Fx 2 (Soundtrack)
99	98	0	Fx 3 (Crystal)
100	99	0	Fx 4 (Atmosphere)
101	100	0	Fx 5 (Brightness)
Ethnic			
102	101	0	Fx 6 (Goblins)
103	102	0	Fx 7 (Echoes)
104	103	0	Fx 8 (Sci-Fi)
Percussive			
105	104	0	Sitar
106	105	0	Banjo
107	106	0	Shamisen
108	107	0	Koto
109	108	0	Kalimba
110	109	0	Bagpipe
111	110	0	Fiddle
112	111	0	Shanai
Sound Effects			
113	112	0	Tinkle Bell
114	113	0	Agogo
115	114	0	Steel Drums
116	115	0	Woodblock
117	116	0	Taiko Drum
118	117	0	Melodic Tom
119	118	0	Synth Drum
120	119	0	Reverse Cymbal
Piano			
121	120	0	Guitar Fret Noise
122	121	0	Breath Noise
123	122	0	Seashore
124	123	0	Bird Tweet
125	124	0	Telephone Ring
126	125	0	Helicopter
127	126	0	Applause
128	127	0	Gunshot

Appendix

NO.	PROGRAM CHANGE	BANK	VOICE NAME
Chromatic Percussion			
155	8	0	Celesta
156	8	92	Celesta 2
157	8	99	Celesta 3
158	9	0	Glocken1
159	9	99	Glocken2
160	10	0	Music Box
161	11	0	Vibraphone
162	11	92	Vibes 1
163	11	99	Vibes 2
164	12	0	Marimba 1
165	12	99	Marimba 2
166	13	0	Xylophone 1
167	13	99	Xylophone 2
168	14	0	Tubular Bells
169	14	98	ChurchBell
170	14	99	TubeBell
171	15	0	Dulcimer
Organ			
172	16	0	Drawbar Organ
173	16	98	DetunedOrgan 1
174	17	98	DetunedOrgan 2
175	17	0	Percussive Organ
176	18	0	Rock Organ
177	18	91	ElecOrgan1
178	18	92	ElecOrgan2
179	18	93	ElecOrgan3
180	18	99	ElecOrgan4
181	19	0	Church Organ 1
182	19	98	ChurchOrgan 2
183	19	91	PipeOrgan1
184	19	92	PipeOrgan2
185	19	99	PipeOrgan3
186	20	0	Reed Organ
187	21	0	Accordion
188	21	98	ItalianAccordion
189	21	99	Accordion_MT
190	22	0	Harmonica1
191	22	91	Harmonica2
192	22	99	HarmoPan
193	23	0	Tango Accordion
Guitar			
194	24	0	Nylon Guitar
195	24	98	Ukulele
196	24	99	Guitar1
197	25	0	Steel Guitar 1
198	25	90	Mandolin
199	25	98	StringGuitar
200	25	99	Guitar2
201	26	0	Jazz Guitar
202	26	98	HawaiianGuitar
203	26	99	ElecGuitar1
204	27	99	ElecGuitar2
205	27	0	Clean Guitar
206	27	98	ChorusedGuitar
207	28	0	Muted Guitar
208	28	98	FunkGuitar

NO.	PROGRAM CHANGE	BANK	VOICE NAME
209	29	0	Overdriven Guitar
210	30	0	Distortion Guitar
211	30	98	FeedbackGuitar1
212	31	0	Guitar Harmonics
213	31	98	GuitarFeedback2
Bass			
214	32	0	Acoustic Bass 1
215	32	91	Acou Bass 2
216	32	99	Acou Bass 3
217	33	0	Finger Bass
218	33	99	ElecBass 1
219	34	99	ElecBass 2
220	34	0	Pick Bass
221	35	0	Fretless Bass 1
222	35	91	Fretless 2
223	35	99	Fretless 3
224	36	0	Slap Bass 1
225	37	0	Slap Bass 2
226	36	99	Slap Bass 3
227	37	99	Slap Bass 4
228	38	0	Synth Bass 1
229	39	0	Synth Bass 2
230	38	91	SynthBass 3
231	38	92	SynthBass 4
232	38	98	SynthBass 5
233	39	91	SynthBass 6
234	39	92	SynthBass 7
235	39	98	SynthBass 8
Strings			
236	40	0	Violin1
237	40	91	Violin2
238	40	99	Violin3
239	40	98	SlowViolin
240	41	0	Viola
241	42	0	Cello 1
242	42	91	Cello 2
243	42	99	Cello 3
244	43	0	Contrabass 1
245	43	99	ContraBass_MT
246	44	0	Tremolo Strings
247	44	99	DoctorSolo
248	45	0	Pizzicato Strings1
249	45	99	Pizzicato 2
250	46	0	Orchestral Harp 1
251	46	91	Harp 1
252	46	99	Harp 2
253	47	0	Timpani 1
254	47	93	Timpani 2
Ensemble			
255	48	0	Strings Ensemble 1
256	49	0	Strings Ensemble 2
257	48	98	OrchestralPad
258	48	99	StringSection1
259	49	99	StringSection2
260	50	99	StringSection3
261	50	0	Synth Strings 1
262	51	0	Synth Strings 2

NO.	PROGRAM CHANGE	BANK	VOICE NAME
263	50	98	SynthStrings3
264	52	0	Choir Ahhs
265	52	99	Chorale
266	53	0	Voice Ooohs
267	53	99	SoundTrack
268	54	0	Synth Voice
269	54	99	FunnyVox
270	55	0	Orchestra Hit1
271	55	99	OrchestraHit 2
Brass			
272	56	0	Trumpet 1
273	56	91	Trumpet 2
274	56	99	Trumpet 3
275	57	0	Trombone 1
276	57	91	Trombone 2
277	57	99	Trombone 3
278	58	0	Tuba
279	58	90	Tuba 2
280	58	91	BrassSection1
281	58	99	BrassSection2
282	59	0	Muted Trumpet
283	60	0	French Horn 1
284	60	91	FrenchHorns 2
285	60	99	FrenchHorns 3
286	61	0	Brass Section
287	61	98	Brass2
288	62	0	Synth Brass 1
289	63	0	Synth Brass 2
290	62	91	SynthBrass 3
291	62	98	SynthBrass 4
292	62	99	SynthBrass 5
293	63	91	SynthBrass 6
294	63	98	SynthBrass 7
295	63	99	SynthBrass 8
Reed			
296	64	0	Soprano Sax
297	65	0	Alto Sax
298	66	0	Tenor Sax
299	67	0	Baritone Sax
300	64	99	Sax1
301	65	99	Sax2
302	66	99	Sax3
303	67	99	Sax4
304	68	0	Oboe1
305	68	91	Oboe2
306	68	99	Oboe2001
307	69	0	English Horn 1
308	69	99	English Horn 2
309	70	0	Bassoon 1
310	70	99	Bassoon 2
311	71	0	Clarinet 1
312	71	91	Clarinet 2
313	71	99	Clarinet 3
Pipe			
314	72	0	Piccolo 1
315	72	91	Piccolo 2
316	72	99	Piccolo 3

Appendix

NO.	PROGRAM CHANGE	BANK	VOICE NAME
317	73	0	Flute 2
318	73	91	Flute 3
319	73	99	BreathPipe
320	73	92	Recorder1
321	74	0	Recorder 2
322	74	99	Pan Flute
323	75	0	Sho
324	75	97	PanPipes
325	75	99	Blown Bottle1
326	76	0	Bottle Bottle2
327	76	99	Shakuhachi
328	77	0	Shakuhachi 2
329	77	99	Whistle 1
330	78	0	Whistle 2
331	78	91	Whistle 3
332	78	99	Ocarina
333	79	0	
Synth Lead		Lead 1 (Square)	
334	80	0	Sine Wave
335	80	98	Square Wave
336	80	99	Lead 3 (Sawtooth)
337	81	0	DeepSnare
338	81	99	Lead 5 (Calliope)
339	82	0	Lead 7 (Chiff)
340	83	0	Lead 8 (Charang)
341	84	0	Lead 10(Voice)
342	85	0	Lead 12 (Fifth)
343	86	0	Lead 13 (Bass+Lead)
344	87	0	
Synth Pad		Pad 1 (New Age)	
345	88	0	Pad 3 (Warm)
346	89	0	Pad 4 (Polysynth)
347	90	0	Pad 5 (Choir)
348	91	0	Pad 6 (Bowed)
349	92	0	Pad7(Metallic)
350	93	0	Pad 9 (Halo)
351	94	0	Pad 10 (Sweep)
352	95	0	
Synth Effects		Fx 1 (Rain)	
353	96	0	IceRain_MT
354	96	99	Fx 2 (Soundtrack)
355	97	0	Fx 3 (Crystal)
356	98	0	Fx 4 (Atmosphere)
357	99	0	Fx6(Brightness)
358	100	0	Fx 7 (Goblins)
359	101	0	Fx 8 (Echoes)
360	102	0	EchoPan
361	102	99	Fantasy1
362	103	0	Fantasy2
363	103	99	
Ethnic		Sitar	
364	104	0	Sitar_MT
365	104	99	Banjo
366	105	0	Shamisen
367	106	0	Koto1
368	107	0	Koto2
369	107	98	

NO.	PROGRAM CHANGE	BANK	VOICE NAME
370	107	99	Koto_MT
371	108	0	Kalimba
372	109	0	Bagpipe
373	110	0	Fiddle
374	111	0	Shanai
375	111	97	BreathPipe
Percussive			
376	112	0	Tinkle Bell
377	112	91	EchoBell
378	112	92	WindBell
379	112	93	WaterBell
380	112	94	JungleTune
381	112	97	BellSinger
382	112	99	WarmBell
383	113	0	Agogo
384	113	93	SynMallet
385	113	99	MelodicTom
386	114	0	Steel Drums
387	115	0	Woodblock
388	115	97	ElecPerc 1
389	115	99	ElecPerc 2
390	116	0	Taiko Drum
391	116	91	TaikoRim
392	116	98	ConcertBassDrum
393	116	99	Taiko_MT
394	117	0	Melodic Tom1
395	117	98	MeloTom2
396	118	0	Synth Drum
397	118	98	808Tom 808
398	119	0	Reverse Cymbal
399	119	99	Cymbal
Sound Effects			
400	120	0	GuitarNoise
401	120	92	StringSlap
402	120	99	GtrCutNoise
403	121	0	Breath Noise
404	121	91	FluteKeyClick
405	121	93	Glasses
406	121	99	Triangle
407	122	0	Seashore
408	122	91	Rain
409	122	92	Thunder
410	122	93	Wind
411	122	94	Stream
412	122	95	Bubble
413	122	96	Atmosphere
414	123	0	Bird Tweet
415	123	91	Dog
416	123	92	HorseGallop
417	123	93	Bird 2
418	123	99	BirdTweet
419	124	0	Telephone 1
420	124	91	Telephone 2
421	124	99	Telephone 3
422	124	92	DoorCreaking
423	124	93	DoorSlam
424	124	94	Scratch

NO.	PROGRAM CHANGE	BANK	VOICE NAME
425	124	95	WindChimes
426	125	0	Helicopter
427	125	90	BurstNoise
428	125	91	CarEngine
429	125	92	CarStop
430	125	93	CarPass
431	125	94	CarCrash
432	125	95	Siren
433	125	96	Train
434	125	97	JetPlane
435	125	98	Starship
436	125	99	OneNoteJam
437	126	0	Applause
438	126	91	Laughing
439	126	92	Screaming
440	126	93	Punch
441	126	94	HeartBeat
442	126	95	FootSteps
443	126	99	SchoolDaze
444	127	0	Gunshot1
445	127	91	MachineGun
446	127	92	LazerGun
447	127	93	Explosion
448	127	97	JungleTune
Ethnic			
449	73	81	Bangdi
450	40	81	Erhu 1
451	40	82	Erhu 2
452	24	81	Pipa 1
453	24	82	Pipa 2
454	25	81	Liuqin
455	27	81	Zhongruan
456	33	81	Guzheng 1
457	33	82	Guzheng 2
458	34	81	Yangqin
459	41	81	Banhu
460	56	82	Suona
461	56	81	SuonaHigh
462	58	81	LuShen
463	72	81	Hulusi
464	76	81	Xiao
465	32	82	Guqin
466	43	82	Matouqin
467	58	82	Reed
Percussive			
468	0	127	Standard
469	1	127	Standrd2
470	8	127	Room
471	16	127	Power
472	24	127	Eletroni
473	25	127	Synth
474	26	127	Dance
475	32	127	Jazz
476	40	127	Brush
477	48	127	Classic
478	127	127	Sino
479	56	127	Effect

Appendix

Style List

NO.	Style Name
8	Beat
1	8Bt_Mdrn
2	MrsyBeat
3	SurfPop
4	8Beat1
5	8Beat2
6	8Beat3
7	Ballrock
8	60sRock
9	HardRock
10	ShufRock
11	80sRock
12	Slrock1
13	Slrock2
16	Beat
14	16Beat1
15	16Beat2
16	16Beat3
17	16Beat4
18	16Beat5
19	PopShuf
20	GuitPop
21	JazzRock
22	SwngFunk
23	PopRock
24	60Rock2
25	70Ties
26	Surfrock
27	Ballad
28	PnoBalad
29	LoveSong
30	68Modern
31	68SlowRk
32	ShowBld
33	PopBalad
34	16BtBld
35	Ballad1
36	Ballad2
37	Ballad3
38	Dance
39	Rap
40	DancePop
41	House
42	SwingHse
43	TechnoPop
44	ClubDnce
45	ClubLatn
46	Garage
47	HipHop
48	Techno8Bt
49	ChillOut
50	Cumbia
51	Dance
52	Techno1
53	Techno2
54	Disco
55	80sDisco

NO.	Style Name
56	DscParty
57	DscFever
58	NYDisco
59	Disco1
60	Disco2
61	Disco3
62	Disco4
63	Swing&Jazz
64	BBFast
65	BBMid
66	BBBallad
67	JazzClub
68	Swing
69	JzBallad
70	Dixie
71	Ratime
72	Stride
73	BBRetime
74	BBRetimeP
75	BBRetime2
76	BBRetime3
77	BBRetime4
78	BBRetime5
79	BBRetime6
80	BBRetime7
81	BBRetime8
82	BBRetime9
83	BBRetime10
84	BBRetime11
85	BBRetime12
86	BBRetime13
87	BBRetime14
88	BBRetime15
89	BBRetime16
90	BBRetime17
91	BBRetime18
92	BBRetime19
93	BBRetime20
94	BBRetime21
95	BBRetime22
96	BBRetime23
97	BBRetime24
98	BBRetime25
99	BBRetime26
100	BBRetime27
101	BBRetime28
102	BBRetime29
103	BBRetime30
104	BBRetime31
105	BBRetime32
106	R&B
107	Soul
108	DrtPop
109	Rhtmblus
110	68soul
111	Twist
112	RockRollP
113	Rocknrol
114	68Blues
115	34Gospel
116	GsplShuf
117	Germwalz
118	88Gospel
119	Gospel
120	Gypsi
121	Rocknrol
122	68Blues2
123	Rockrol2
124	R&B2
125	R&B3
126	R&B4
127	R&B5
128	R&B6
129	R&B7
130	R&B8
131	R&B9
132	R&B10
133	R&B11
134	R&B12
135	R&B13
136	R&B14
137	R&B15
138	R&B16
139	R&B17
140	R&B18
141	R&B19
142	R&B20
143	R&B21
144	R&B22
145	R&B23
146	R&B24
147	R&B25
148	R&B26
149	R&B27
150	R&B28
151	R&B29
152	R&B30
153	R&B31
154	R&B32
155	R&B33
156	R&B34
157	Country
158	Country1
159	Country2
160	Country3
161	Country4
162	Country5
163	Country6
164	Country7
165	Country8
166	Country9
167	Country10
168	Country11
169	Country12
170	Country13
171	Country14
172	Country15
173	Country16
174	Country17
175	Country18
176	Country19
177	Country20
178	Country21
179	Country22
180	Country23
181	Country24
182	Country25
183	Country26
184	Country27
185	Country28
186	Country29
187	Country30
188	Country31
189	Country32
190	Country33
191	Country34
192	Country35
193	Country36
194	Country37
195	Country38
196	Country39
197	Country40
198	Country41
199	Country42
200	Country43
201	Country44
202	Country45
203	Country46
204	Country47
205	Country48
206	Country49
207	Country50
208	Country51
209	Country52
210	Country53
211	Country54
212	Country55
213	Country56
214	Country57
215	Country58
216	Country59
217	Country60
218	Country61
219	Country62
220	Country63
221	Country64
222	Country65
223	Country66
224	Country67
225	Country68
226	Country69
227	Country70
228	Country71
229	Country72
230	Country73
231	Country74
232	Country75
233	Country76
234	Country77
235	Country78
236	Country79
237	Country80
238	Country81
239	Country82
240	Country83
241	Country84
242	Country85
243	Country86
244	Country87
245	Country88
246	Country89
247	Country90
248	Country91
249	Country92
250	Country93
251	Country94
252	Country95
253	Country96
254	Country97
255	Country98
256	Country99
257	Country100
258	Country101
259	Country102
260	Country103
261	Country104
262	Country105
263	Country106
264	Country107
265	Country108
266	Country109
267	Country110
268	Country111
269	Country112
270	Country113
271	Country114
272	Country115
273	Country116
274	Country117
275	Country118
276	Country119
277	Country120
278	Country121
279	Country122
280	Country123
281	Country124
282	Country125
283	Country126
284	Country127
285	Country128
286	Country129
287	Country130
288	Country131
289	Country132
290	Country133
291	Country134
292	Country135
293	Country136
294	Country137
295	Country138
296	Country139
297	Country140
298	Country141
299	Country142
300	Country143
301	Country144
302	Country145
303	Country146
304	Country147
305	Country148
306	Country149
307	Country150
308	Country151
309	Country152
310	Country153
311	Country154
312	Country155
313	Country156
314	Country157
315	Country158
316	Country159
317	Country160
318	Country161
319	Country162
320	Country163
321	Country164
322	Country165
323	Country166
324	Country167
325	Country168
326	Country169
327	Country170
328	Country171
329	Country172
330	Country173
331	Country174
332	Country175
333	Country176
334	Country177
335	Country178
336	Country179
337	Country180
338	Country181
339	Country182
340	Country183
341	Country184
342	Country185
343	Country186
344	Country187
345	Country188
346	Country189
347	Country190
348	Country191
349	Country192
350	Country193
351	Country194
352	Country195
353	Country196
354	Country197
355	Country198
356	Country199
357	Country200
358	Country201
359	Country202
360	Country203
361	Country204
362	Country205
363	Country206
364	Country207
365	Country208
366	Country209
367	Country210
368	Country211
369	Country212
370	Country213
371	Country214
372	Country215
373	Country216
374	Country217
375	Country218
376	Country219
377	Country220
378	Country221
379	Country222
380	Country223
381	Country224
382	Country225
383	Country226
384	Country227
385	Country228
386	Country229
387	Country230
388	Country231
389	Country232
390	Country233
391	Country234
392	Country235
393	Country236
394	Country237
395	Country238
396	Country239
397	Country240
398	Country241
399	Country242
400	Country243
401	Country244
402	Country245
403	Country246
404	Country247
405	Country248
406	Country249
407	Country250
408	Country251
409	Country252
410	Country253
411	Country254
412	Country255
413	Country256
414	Country257
415	Country258
416	Country259
417	Country260
418	Country261
419	Country262
420	Country263
421	Country264
422	Country265
423	Country266
424	Country267
425	Country268
426	Country269
427	Country270
428	Country271
429	Country272
430	Country273
431	Country274
432	Country275
433	Country276
434	Country277
435	Country278
436	Country279
437	Country280
438	Country281
439	Country282
440	Country283
441	Country284
442	Country285
443	Country286
444	Country287
445	Country288
446	Country289
447	Country290
448	Country291
449	Country292
450	Country293
451	Country294
452	Country295
453	Country296
454	Country297
455	Country298
456	Country299
457	Country300
458	Country301
459	Country302
460	Country303
461	Country304
462	Country305
463	Country306
464	Country307
465	Country308
466	Country309
467	Country310
468	Country311
469	Country312
470	Country313
471	Country314
472	Country315
473	Country316
474	Country317
475	Country318
476	Country319
477	Country320
478	Country321
479	Country322
480	Country323
481	Country324
482	Country325
483	Country326
484	Country327
485	Country328
486	Country329
487	Country330
488	Country331
489	Country332
490	Country333
491	Country334
492	Country335
493	Country336
494	Country337
495	Country338
496	Country339
497	Country340
498	Country341
499	Country342
500	Country343
501	Country344
502	Country345
503	Country346
504	Country347
505	Country348
506	Country349
507	Country350
508	Country351
509	Country352
510	Country353
511	Country354
512	Country355
513	Country356
514	Country357
515	Country358
516	Country359
517	Country360
518	Country361
519	Country362
520	Country363
521	Country364
522	Country365
523	Country366
524	Country367
525	Country368
526	Country369
527	Country370
528	Country371
529	Country372
530	Country373
531	Country374
532	Country375
533	Country376
534	Country377
535	Country378
536	Country379
537	Country380
538	Country381
539	Country382
540	Country383
541	Country384
542	Country385
543	Country386
544	Country387
545	Country388
546	Country389
547	Country390
548	Country391
549	Country392
550	Country393
551	Country394
552	Country395
553	Country396
554	Country397
555	Country398
556	Country399
557	Country400
558	Country401
559	Country402
560	Country403
561	Country404
562	Country405
563	

Appendix

Troubleshooting Hints

<ul style="list-style-type: none"> When the instrument is turned on or off, a Popping sound is temporarily produced. 	This is normal and indicates that the instrument is receiving electrical power.
<ul style="list-style-type: none"> When using a mobile phone, noise is produced. Using a mobile phone in close proximity to the instrument may produce interference. 	To prevent this, turn off the mobile phone or use it further away from the instrument.
<ul style="list-style-type: none"> Not all of the voices seem to sound, or the sound seems to cut off. 	The instrument is polyphonic up to a maximum of 32 notes — including Dual voice, Split Voice, auto accompaniment, song, and Metronome. Notes exceeding this limit will not sound.
<ul style="list-style-type: none"> The Auto Accompaniment does not sound properly. 	Make sure that the Auto Accomp Volume Function is set to an appropriate level. Is the Split Point set to an appropriate key for the chords you are playing? Set the Split Point to an appropriate position on the keyboard. Is the chord indicator showing in the LCD display? If it is not showing, press the CHORD button so that it does show.
<ul style="list-style-type: none"> No sound produced by the keyboard, but the lights and screen work. 	Check that the master volume control is not set to minimum. Check that nothing is plugged into the headphone socket.
<ul style="list-style-type: none"> The sound of the voice changes from note to note. 	This is normal. The digital tone generation uses multiple recordings (samples) of an instrument across the range of the keyboard; The actual sound of the voice may be slightly different from note to note.
<ul style="list-style-type: none"> The volume is too soft. The sound quality is poor. The rhythm stops unexpectedly or will not play. The recorded data of the song, etc. does not play correctly. The LCD display suddenly goes dark, and all panel settings are reset. 	The batteries are low or dead. Replace all six batteries with completely new ones, or use the supplied AC adaptor. If you have lost or damaged your AC adaptor, please contact your nearest store for a correct replacement adaptor. An incorrect AC mains adaptor which is not rated sufficiently can cause malfunction or damage.
<ul style="list-style-type: none"> To completely restore all settings as per factory settings 	Perform a factory reset, Please refer to content in this owner's manual. All of the user setting will be erased and the default factory settings will be applied to the instrument.
<ul style="list-style-type: none"> Power suddenly and unexpectedly turns off, after a period of not touching the keys. 	This is normal and the Auto Power Off function may have been activated. If you need to disable the Auto Power Off function, please see how to do this in the owner's manual.
<ul style="list-style-type: none"> The sustain pedal or footswitch seems to produce the opposite effect. Example pressing the footswitch deactivates the sustain, and releasing the footswitch triggers the sustain. 	The polarity of the footswitch needs to be correctly detected. Make sure the jack plug for the footswitch is connected. Switch the instrument on whilst not touching the pedal.

Appendix

Specifications

Keyboard:	61 standard-size touch sensitivity keys(C1 through C6)
Display:	Multi-Function LCD
Number Buttons:	[0]-[9],[+],[-]
Voices:	479
Polyphony:	32
Voice Control:	Sustain, Transpose, Pitch Bend, Touch, Mixer
Auto accompaniment:	203 Styles
Accompaniment Control:	Synchro, Start/Stop, Intro/Ending, Fill In, Tempo/Tap, Accompaniment Volume, Metronome
Keyboard Modes:	Fullkeyboard, Split, Chord
Setup:	Power(ON/OFF), Master Volume(MIN-MAX)
Registration Memory:	Store, M1-M4
DEMO:	Demo Songs: 5, Learning Songs: 100
Recording:	Record, Play
Interface:	DC12V, Phones/Line Out, Line In, Pedal, Mic, USB To Host
Dimensions(W x D x H):	950mm x 350mm x 130mm
Weight:	6kgs

FCC STATEMENT

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
 - (1) This device may not cause harmful interference.
 - (2) This device must accept any interference received, including interference that may cause undesired operation.
2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

