

FRONT

LA CROSSE TECHNOLOGY

Breeze sensor




SET UP GUIDE

MODEL NUMBER: TX145WSDTH3

PRESSURE

Pressure Settings

Your Relative Pressure reading will come from your station's internal barometer. Please allow up to 10 days for automatic calibration, or program your local pressure value with the MODE/PRESSURE button. The arrows located to the left of the values represents Pressure Tendency (rising/falling). Hold the MODE/PRESSURE button to enter the Pressure Settings Menu to set your Units of Measure (INHG or HPA) and Pressure Value.



Use the +/- buttons on the top of the station to adjust the values.

Press the MODE/PRESSURE button to confirm selection and move to next step or exit.

PRESSURE & RAIN

View Pressure & Rain Readings

Pressure is displayed. Rain is displayed.

Change what is displayed: MODE/PRESSURE

Press the MODE/PRESSURE button to toggle between Pressure and Rain readings. The Pressure or Rain icon will show to indicate which reading you are viewing. When the Autoscroll is displayed, the station will toggle between current Pressure and Rain readings.

Pressure is displayed. Rain is displayed.

Autoscroll between Pressure and Rain readings.

Sensor Reception

RAIN

View Rain Records

1. Press the RAIN button to view Rainfall Records.

2. When viewing month, press the + (PLUS) button to toggle through the past 11 months' rainfall.

1 HOUR: Last one-hour rainfall (12 consecutive 5 minutes rainfall accumulated total). Example: current time is 6:49. 1-HR rain is accumulated total between 5:50 and 6:49.

24 HOURS: A running total for the past 24 hours of accumulated rain. This will update at the top of each hour.

7 DAYS: Rainfall from the last 7 consecutive 24-HR readings. Updates each day at midnight.

MONTH: Current Month Total (January 1-January 31). This will reset to zero and the start of each new calendar month.

YEAR: Current Year (January 1-December 31). This will reset to zero at the start of each new calendar year.

TOTAL: Total rainfall since powered on or reset.

RAIN

Reset Rain Records

1. Press the RAIN button to view individual Rainfall Records.

2. Hold the - (MINUS) button to reset the rainfall record you are viewing to zero.

1 YEAR RECORD

1 Year Record

POSITIONING THE RAIN SENSOR

For Accurate Measurements

1. Mount the Rain Sensor in an open area at least 3 feet above the ground and away from rainfall readings.

2. Ensure the sensor is level and mounted horizontally.

3. Make sure the base of your Rain Sensor is not in a depression. The Rain Sensor has drainage holes in the bottom to allow it to self-empty.

View sensor mounting video at: bitly/Rain_SensorMounting

SEARCH FOR RAIN SENSOR

Hold the RAIN button to search for the Rain Sensor. This Reception Indicator will animate while searching and be solid once connected.

RAIN

Cleaning and Storage

Cleaning Your Rain Sensor

Leaves, grass and other debris may need to be removed periodically from the funnel of your Rain Sensor.

Insects or dirt may also get inside your Rain Sensor and restrict the movement of the rocker.

Open the locking tabs on the side of the Rain Sensor to remove the funnel. This allows you to clean the funnel and the inside of the Rain Sensor.

Winter Storage Options

Remove batteries and store in a safe place.

Leave outside, uncovered. While the Rain Sensor cannot accurately record snowfall, when the snow melts the water will be counted as rain.

The Rain Sensor is self-emptying, so water will not freeze inside.

This Rain Sensor is designed for outdoor use and will withstand temperatures below freezing.

WIND

Viewing Wind Readings

Wind is displayed. Rain is displayed.

Change what is displayed: MODE/PRESSURE

Press the MODE/PRESSURE button to toggle between Pressure and Rain readings. The Pressure or Rain icon will show to indicate which reading you are viewing. When the Autoscroll is displayed, the station will toggle between current Pressure and Rain readings.

Wind is displayed. Rain is displayed.

Autoscroll between Pressure and Rain readings.

Sensor Reception

WIND

Wind Speed Records

Viewing Wind Speed Records

1. Press the WIND button to toggle through wind speed records with time and date stamps.

2. Hold the MINUS (-) button to reset individual records to current readings.

WIND

Wind Speed Units

Wind Speed Units (MPH or KM/H)

Wind Direction

Wind Direction (Letters or Degrees)

Rainfall Inches or Millimeters

STATION SETTINGS

1. When the station is first powered on, it will begin searching for your outdoor sensor, which should connect shortly.

2. Hold the SET button to enter the Settings Menu.

SETTINGS MENU ORDER

Greeting
Language
Beep ON/OFF
Atomic ON/OFF
DST
Automatic/Always ON/Always OFF
Time Zone
12/24 Hour Time
+/- Minutes
Year
Month
Date
Mount Date or Date/Month
Maintenance/Celsius
Wind Speed Units (MPH or KM/H)
Wind Direction (Letters or Degrees)
Rainfall Inches or Millimeters

ALERTS

Use the +/- buttons on the top of the station to adjust the values.

Press the SET button to confirm selection and move to next step.

You may exit the Settings Menu at any time by pressing the ALERTS button.

DAYLIGHT SAVING TIME OPTIONS

DST Automatic: Changes Spring and Fall
DST Always ON: Does not change to standard time in Fall
DST Always OFF: Does not change to DST in the Spring.

TIME ZONE SELECTION

Selectable Time Zones:
ATLANTIC, EASTERN, CENTRAL, MOUNTAIN, PACIFIC, ALASKA, & HAWAII

ATOMIC TIME SIGNAL

The station will begin searching for the Atomic Time Signal when first powered on.

If the reception is not picked up right away, it will search every 2 hours until the WWVB signal is received.

Press the SET button to start or stop a manual WWVB signal search.

The WWVB tower icon will flash when searching, and be solid when the signal is received.

For information about WWVB Atomic Time visit: bitly/AtomicTime

QR CODE

BACK

WIND

Positioning the Breeze Sensor

For Accurate Measurements

The Breeze Sensor is mounted level with the Solar Panel facing directly to the South. This will help optimize battery life and transmit correct wind direction.

The Breeze Sensor should be mounted on the tallest object in your area. Avoid mounting the sensor parallel to trees, eaves, rooftops, or other objects that may obstruct wind readings.

Make sure all the screws on the Mounting Bracket, Wind Cups, Wind Vane, and Battery and Component are securely fastened.

The Breeze Sensor should be mounted with the Wind Cups on the top.

INCLUDED MOUNTING ACCESSORIES

Mount

The horizontal condensate pipe where the sensor should be mounted can be secured by either the Adjustable Base or Pole Adapter.

Adjustable Arms

These Arms provide exact 90° to 180° degree angles when mounted with the arm on the Mast.

Pole Adapter

Use the top of the Adjustable Base for mounting on top of cylindrical condensate pipes.

Adjustable Mast

The Mast is used for mounting onto flat surfaces or when added U-bolts hold separately. The top of the Mast is used to attach the Breeze Sensor to angled surfaces while still ensuring the Mast and sensor are level.

ADD-ON SENSOR

Add-on Temperature & Humidity Sensor

If you feel the temperature & humidity is not reading correctly from your Breeze Sensor, you can add a separate sensor to your system. Visit www.lacrossetechnology.com/sensor-finder/ and enter 328-1414BW to find a list of compatible add-on sensors.

Adding a Separate Temperature & Humidity Sensor

1. Press the - (MINUS) button and the Outdoor Temperature will flash.

2. Hold the MINUS (-) button to delete the Temperature & Humidity readings. Your station will search for a signal.

3. Install new batteries into the add-on sensor and press the TX button inside its battery compartment. The LED light on the sensor will flash.

4. The sensor should connect almost instantly with its data appearing on screen. The icon will appear when an add-on TH sensor is being used.

Temperature & Humidity from the Breeze Sensor

Temperature & Humidity from an add-on TH Sensor

SUPPORT

Low Battery Indicator

We're Here to Help

If you require additional support, get in touch with our friendly customer support team based in La Crosse, WI. Phone 1608.782.1610. Online bitly/contact_techsupport

Our knowledgeable customer support team is available Mon-Fri: 8am-6pm CST

Sensor Search

1. Hold the RAIN button to search for the Rain sensor.

2. Hold the WIND button to search for the Breeze sensor.

3. Hold the TEMP button to search for the Add-on TH sensor.

4. The sensor should connect almost instantly with its data appearing on screen. The icon will appear when an add-on TH sensor is being used.

Temperature & Humidity from the Breeze Sensor

Temperature & Humidity from an add-on TH Sensor

APPENDIX

Specifications

BREEZE SENSOR (TX145WSDTH3)

- Wind Speed Range: 0 to 111 mph (0 to 178 km/h)
- Degrees of Wind Direction: 360 with 16 Cardinal Directions
- Outdoor Temp. Range: -40°F to 104°F (-40°C to 40°C)
- Outdoor Humidity Range: 10 to 99%RH
- Transmission Range: 330 feet (100 meters)
- Power Requirements: 3 "AA" batteries (sold separately)
- Update Interval: Every 31 Seconds
- Station Dimensions: 8.98" L x 1.00" W x 5.43" H (22.8 cm L x 1.3 cm W x 12.8 cm H)
- Language Options: English, Spanish, and French (Translated Available for Menus and Calender)

BREEZE SENSOR (TX145WSDTH3)

- Wind Speed Range: 0 to 111 mph (0 to 178 km/h)
- Degrees of Wind Direction: 360 with 16 Cardinal Directions
- Outdoor Temp. Range: -40°F to 104°F (-40°C to 40°C)
- Outdoor Humidity Range: 10 to 99%RH
- Transmission Range: 330 feet (100 meters)
- Power Requirements: 3 "AA" batteries (sold separately)
- Update Interval: Every 31 Seconds
- Station Dimensions: 8.98" L x 1.00" W x 5.43" H (22.8 cm L x 1.3 cm W x 12.8 cm H)
- Language Options: English, Spanish, and French (Translated Available for Menus and Calender)

CARE & MAINTENANCE

Please consider the environment when deciding to dispose of this product. Although household electronics are generally safe to use on a daily basis, incorrect disposal can cause negative and potentially irreversible impacts on our environment.

All rights reserved. This manual may not be reproduced in any form, even in part, or duplicated or processed using electronic, mechanical, or chemical or physical process without the written permission of the publisher.

This device contains license-exempt transmitters/receivers that comply with Innovation, Science and Economic Development Canada's license-exempt RSS. Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

CAUTION

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

CANADA STATEMENT

This device contains license-exempt transmitters/receivers that comply with Innovation, Science and Economic Development Canada's license-exempt RSS. Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation of the device.

LA CROSSE TECHNOLOGY

La Crosse Technology, Ltd. provides a 1-year limited time warranty (from date of purchase) on this product, relating to manufacturing defects in materials and workmanship. For full warranty details, you can visit www.lacrossetechnology.com/support

RECYCLING & DISPOSAL

Recycling & Disposal

WARRANTY

FCC STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. There is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

STATION SETTINGS

To Set Alerts

1. Hold the ALERTS button to enter Alert Settings.

2. Use the +/- buttons to Aler/DisAler Alerts, and to adjust Alert Values when flashing.

3. Press the ALERTS button to move to next alert.

ALERT SETTING ORDER

High Wind Speed
24 Hour Rainfall
Outdoor High Temperature
Outdoor Low Temperature
Outdoor High Humidity
Outdoor Low Humidity
Indoor High Temperature
Indoor Low Temperature
Indoor High Humidity
Indoor Low Humidity

ALERT INDICATORS

Wind Alert
High Alert
Low Alert

FORECAST

Viewing Your Forecast Data

Seasonal Trees

The foliage scene in the forecast section changes twice per year. The dates are pre-programmed.

Forecast Icons

Your station will use changes in barometric pressure to predict your weather to come in the next 12 hours. This is represented by the 6 forecast scenes below.

FORECAST

Day/Night Forecast

From 7am to 7pm the forecast will show a Sun icon when the forecast is Sunny or Partly Sunny.

FORECAST

Summer: April 1 - October 31

Winter: November 1 - March 31

7am to 7pm

FORECAST

7pm to 7am

Please Note: The Forecast Icons may not represent your current weather. They are a future prediction of the weather to come over the next 12 hours.

TREND ARROWS

The Trend Arrows represent the change in pressure over the past 3 hours.

Pressure is rising

Pressure is steady

Pressure is falling

Please Note: The Moon Icon does not change to provide Moon Phase. The Moon Icon indicates nighttime only.