



- 1) There are 2 PCBs in the scale, one is main board, the other is power board.
- 2) POWER & USB: Supply DC5V power to the whole scale.
- 3) A/D Converter: Convert the load cell analog voltage to digital signal.
- 4) LCD DIsplay: Display the weight and other message.
- 5) MCU: The MCU get the AD value from the A/D converter and calculate the weight, then send this value to LCD to display and also send to PC via USB.