

Statement

Please read this guide carefully before using the device to ensure your safety and correct use of the device. For information about the device configuration, please refer to the contract information related to the device and the seller of the device to you.

The pictures in this guide are for reference only. If some pictures do not match the actual products, please refer to the actual products. Many network functions described in this document are special services provided by network service providers (ISPs). The availability of these network functions depends on the ISPs that provide the services to you.

No part of this Manual shall be reproduced, excepted, backed up, modified, transmitted, translated into other languages, or used in whole or in part for commercial purposes in any form or by any means without the permission of the Company.

Package Content

Components	Name	Quantity
V77 Counter POS Terminal		1
Power adapter		1
Quick operation guide (Certificate of qualification and Warranty card)		1

Product Description

Quick installation

2 Install the SIM/ SAM(PSAM) card:

- Open the battery cover.
- Follow the silkscreen indication and place each of the needed SIM/SAM card separately into the right slot following the direction as the picture showed.

1 Install the printing paper:

Cautions

- When installing or removing the SIM/ SAM card, please confirm that the device is power-off, otherwise the cards may be damaged.
- When installing the SIM/ SAM card, the chip faces toward the internal side of the device.
- SIM/ SAM card cannot paste stickers, tags, or other materials that may change the thickness of the card in order to prevent non-smooth installation or disassembly.

Cautions

Please be careful with the direction when installing the thermal printing paper, and please do so by following the figures below, otherwise it will cause a failure of printing.

Statement

Please read this guide carefully before using the device to ensure your safety and correct use of the device. For information about the device configuration, please refer to the contract information related to the device and the seller of the device to you.

The pictures in this guide are for reference only. If some pictures do not match the actual products, please refer to the actual products. Many network functions described in this document are special services provided by network service providers (ISPs). The availability of these network functions depends on the ISPs that provide the services to you.

No part of this Manual shall be reproduced, excepted, backed up, modified, transmitted, translated into other languages, or used in whole or in part for commercial purposes in any form or by any means without the permission of the Company.

Product Description

Name	Function introduction
Contactless sensing area	Induction area for contactless IC card reading and writing.
Camera	Used for bar and QR code scanning etc.
Display screen	Optional Touch screen, display transaction and operation prompt information, etc.
Magnetic card reader	Magnetic stripe card reader, support bi-directional swiping.
IC card reader	Contact IC card inserting position.
Keypad	Power on and off, input amount and code, confirm and cancel transaction etc.
Power indicator light	Indicate whether the device is connected to power.
Printing paper export	Printed receipts and bills export.
Type-C USB port	Used for connecting external PC or other terminals, allows for data transmission.
*NANO SIM slots	NANO SIM card slot.
SAM card slot	SAM card slot.
Line port	Provides data communication over telephone lines.
LAN Ethernet port	Provides data communication via Ethernet.
RS232 Serial port	Used to connect external devices such as PC/Scanner and other devices.
Power port	Provide port for adapter power plugging in.
Cable clip slot	Used to secure extended cables.

Quick installation

2 Install the SIM/ SAM(PSAM) card:

- Open the battery cover.
- Follow the silkscreen indication and place each of the needed SIM/SAM card separately into the right slot following the direction as the picture showed.

1 Install the printing paper:

Cautions

- When installing or removing the SIM/ SAM card, please confirm that the device is power-off, otherwise the cards may be damaged.
- When installing the SIM/ SAM card, the chip faces toward the internal side of the device.
- SIM/ SAM card cannot paste stickers, tags, or other materials that may change the thickness of the card in order to prevent non-smooth installation or disassembly.

Cautions

Please be careful with the direction when installing the thermal printing paper, and please do so by following the figures below, otherwise it will cause a failure of printing.

Statement

Please read this guide carefully before using the device to ensure your safety and correct use of the device. For information about the device configuration, please refer to the contract information related to the device and the seller of the device to you.

The pictures in this guide are for reference only. If some pictures do not match the actual products, please refer to the actual products. Many network functions described in this document are special services provided by network service providers (ISPs). The availability of these network functions depends on the ISPs that provide the services to you.

No part of this Manual shall be reproduced, excepted, backed up, modified, transmitted, translated into other languages, or used in whole or in part for commercial purposes in any form or by any means without the permission of the Company.

Product Description

Name	Function introduction
Contactless sensing area	Induction area for contactless IC card reading and writing.
Camera	Used for bar and QR code scanning etc.
Display screen	Optional Touch screen, display transaction and operation prompt information, etc.
Magnetic card reader	Magnetic stripe card reader, support bi-directional swiping.
IC card reader	Contact IC card inserting position.
Keypad	Power on and off, input amount and code, confirm and cancel transaction etc.
Power indicator light	Indicate whether the device is connected to power.
Printing paper export	Printed receipts and bills export.
Type-C USB port	Used for connecting external PC or other terminals, allows for data transmission.
*NANO SIM slots	NANO SIM card slot.
SAM card slot	SAM card slot.
Line port	Provides data communication over telephone lines.
LAN Ethernet port	Provides data communication via Ethernet.
RS232 Serial port	Used to connect external devices such as PC/Scanner and other devices.
Power port	Provide port for adapter power plugging in.
Cable clip slot	Used to secure extended cables.

Quick installation

2 Install the SIM/ SAM(PSAM) card:

- Open the battery cover.
- Follow the silkscreen indication and place each of the needed SIM/SAM card separately into the right slot following the direction as the picture showed.

1 Install the printing paper:

Cautions

- When installing or removing the SIM/ SAM card, please confirm that the device is power-off, otherwise the cards may be damaged.
- When installing the SIM/ SAM card, the chip faces toward the internal side of the device.
- SIM/ SAM card cannot paste stickers, tags, or other materials that may change the thickness of the card in order to prevent non-smooth installation or disassembly.

Cautions

Please be careful with the direction when installing the thermal printing paper, and please do so by following the figures below, otherwise it will cause a failure of printing.

Troubles and Troubleshooting

Troubles	Troubleshooting
Failing to turn on the device	1. Ensure the adapter is correctly plugged into the device and the power socket. 2. Try using a different adapter and restart the POS machine.
Device freezes	1. Disconnect the power adapter, wait a few seconds, then reconnect it and try powering on the device. 2. If the issue persists, please contact the after-sales service.
Printer not working or unclear printing	1. Check the paper roll, install it correctly, or replace it if empty. 2. Inspect the roller for any debris or foreign objects.
Touchscreen unresponsive or keys not working	1. Wipe the screen with a soft, clean cloth to ensure it is dry. 2. Restart the device to restore normal operation.
Transaction failed or unable to connect to the network	1. Check the network connection and ensure the power adapter and network cable are securely connected. 2. Ensure the WiFi or mobile network settings are configured correctly. 3. Restart the device or contact your service provider.

Matters need attention

Cautions for use

- Unauthorized disassembly of this device will cause the built-in security key to be destroyed resulting in unusable.
- If the power adapter plug or power cord is damaged, please do not use them in case of electric shock or fire.
- Please do not touch the power cord with wet hands or pull the power adapter like pulling power cable.
- Do not touch the screen with pens, pencils or other sharp objects.
- Do not strike, throw, step on, or subject batteries to severe physical shock.

FCC compliance statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes and modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Accessories requirements

- Please use manufacturer-authorized power adapters and other accessories. Use of unauthorized or incompatible accessories may result in fire, explosion or other hazard.
- The usage of unauthorized accessories will result in the violation of the warranty provisions or local relevant provisions, and may cause safety accidents. To obtain authorized accessories, contact the sales agent or distributor who sold the devices to you.

Operating environment

- Do not use the device during thunderstorms. Otherwise, the device may fail or you could get an electric shock.
- Keep the device away from rain, moisture and acid liquids that corrode circuit boards.
- Do not store or use the device in dusty or dirty places.

Troubles and Troubleshooting

Troubles	Troubleshooting
Failing to turn on the device	1. Ensure the adapter is correctly plugged into the device and the power socket. 2. Try using a different adapter and restart the POS machine.
Device freezes	1. Disconnect the power adapter, wait a few seconds, then reconnect it and try powering on the device. 2. If the issue persists, please contact the after-sales service.
Printer not working or unclear printing	1. Check the paper roll, install it correctly, or replace it if empty. 2. Inspect the roller for any debris or foreign objects.
Touchscreen unresponsive or keys not working	1. Wipe the screen with a soft, clean cloth to ensure it is dry. 2. Restart the device to restore normal operation.
Transaction failed or unable to connect to the network	1. Check the network connection and ensure the power adapter and network cable are securely connected. 2. Ensure the WiFi or mobile network settings are configured correctly. 3. Restart the device or contact your service provider.

Matters need attention

Cautions for use

- Unauthorized disassembly of this device will cause the built-in security key to be destroyed resulting in unusable.
- If the power adapter plug or power cord is damaged, please do not use them in case of electric shock or fire.
- Please do not touch the power cord with wet hands or pull the power adapter like pulling power cable.
- Do not touch the screen with pens, pencils or other sharp objects.
- Do not strike, throw, step on, or subject batteries to severe physical shock.

FCC compliance statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes and modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Accessories requirements

- Please use manufacturer-authorized power adapters and other accessories. Use of unauthorized or incompatible accessories may result in fire, explosion or other hazard.
- The usage of unauthorized accessories will result in the violation of the warranty provisions or local relevant provisions, and may cause safety accidents. To obtain authorized accessories, contact the sales agent or distributor who sold the devices to you.

Operating environment

- Do not use the device during thunderstorms. Otherwise, the device may fail or you could get an electric shock.
- Keep the device away from rain, moisture and acid liquids that corrode circuit boards.
- Do not store or use the device in dusty or dirty places.