


# Proximity Card Reader SmartID

Ref. V2-112005

INTEGRATED  
ENGINEERING

*Smart Technology!*



This manual is applicable for the following SmartID products:

- 800-8000 SmartID/EM4102
- 800-8001 SmartID/EM4102/pin
- 800-8015 SmartID/Hitag1&2
- 800-8016 SmartID/Hitag1&2/RW
- 800-8025 Mifare Serial number Reader/Rs232
- 800-8030 ISO14443-3 Mifare Sector reader
- 800-8045 ISO14443-3 Mifare Sector reader and pinpad
- 800-8062 SmartID/ISO14443-3/MifareDual/RO
- 800-8077 SmartID/ISO14443-3/PIN/MifareDual
- 800-8060 ISO14443-4 DESFire reader (PIV II)
- 800-8061 ISO14443-4 DESFire reader
- 800-8076 ISO14443-4DESFire PINpad reader
- 800-8075 ISO14443-4DESFire PINpad reader (PIV II)
- 800-8063 ISO14443-4 DESFire and Mifare reader
- 800-8078 ISO14443-4 DESFire and Mifare PINpad reader
- 800-8080 ISO14443-4 reader (ISO7816-4, PIV II)
- 800-8085 ISO14443-4 PINpad reader (ISO7816-4, PIV II)
- 800-8081 ISO14443-4 PINpad reader (ISO7816-4 and Mifare, PIV II)
- 800-8086 ISO14443-4 PINpad reader (ISO7816-4 and Mifare, PIV II)

Extra options for these readers, which are included in this manual, are:

- 500-0300 Reader Tamper switch
- 500-9287 SmartID/Mountingplate/Grey (Spacer)
- 500-8090 SmartID/SPMD (Switch Box Mounting Device)

## **Table of content:**

<b>Features.....</b>	<b>4</b>
<b>Mullion Mounting .....</b>	<b>5</b>
<b>Indications.....</b>	<b>5</b>
<b>Connections .....</b>	<b>5</b>
<b>Output protocols .....</b>	<b>5</b>
<b>Security .....</b>	<b>6</b>
<b>Specifications.....</b>	<b>7</b>
Typical read range with an ISO Card .....	7
Power Supply .....	7
Current requirements .....	7
Interface.....	7
Dimensions .....	7
Material .....	7
Operating temperature .....	7
Certifications.....	8
Cable Distance .....	8
SIA recommended cable type for Wiegand signals....	9
Cable .....	9
Wiegand Signal Levels .....	9
SmartID output interface and pull-up resistors .....	9
<b>Timing.....</b>	<b>10</b>
<b>Installation instruction .....</b>	<b>11</b>
<b>Mullion Mounting .....</b>	<b>13</b>
<b>Connector Assignments .....</b>	<b>14</b>
<b>Tamper Switch .....</b>	<b>15</b>
<b>Mounting tool.....</b>	<b>16</b>
<b>Mounting Plate (Spacer) .....</b>	<b>18</b>
<b>Notes .....</b>	<b>19</b>

## **Features**

The Smart ID Reader has a slim door style mountable design to match any decor. The sunk LED's and buzzer allow the Smart ID Readers to be mounted indoors and outdoors.

The Smart ID Reader accepts 4 to 16 Volts DC. The reader output formats like clock-and-data magstripe (ABA / ISO7811), Wiegand and a number of other formats are determined by the personalization of the card or configuration of the reader. The 5 Volt DC capability allows the replacement of older reader systems without rewiring or pulling new cables. The Smart ID Reader offers high reliability, consistent read characteristics and low power consumption.

Within the Smart ID Proximity Reader Family also models with a RS232/RS422/RS485 interface are available for read-only and read/write operations.

The Smart ID Reader Family supports both the 125KHz and 13.56MHz technologies. Different models are available for EM4002, HiTAG1 and 2, Mifare, DESFire and I-Code technology. Standard capabilities include Host system controlled red and green LED's and a buzzer.

The Smart ID Reader can be mounted on any surface without relevant performance degradation. For mounting on a metal surface a spacer is advised.

Our commitment is to bring non-proprietary, open Radio Frequent Identification (RFID) systems to the market demonstrated with the Smart ID Reader Family.

## **Mullion Mounting**

The Smart ID Readers can be mounted on a door mullion.

Optional there is a mounting kit available in case the small Smart ID reader will be mounted over a wall box (mounting US back box, vertical 84 milimeter (3.31 inch), mounting European back box, horizontal 60 millimeter (2.36 inch)).

## **Indications**

When a proximity card is decoded successfully the with the card associated code is send to the Host system and the buzzer sounds a short 3KHz beep. Both LED's and the buzzer are also controllable by the Host system.

## **Connections**

The Smart ID Reader Family has a flexible and reliable connector interface. The space for the cable and the connector within the Smart ID housing can be sealed with silicone to withstand harsh environmental conditions.

## **Output protocols**

The Smart ID Reader Family can operate with any facility, system or card coding scheme. The output format, contents and length are determined by the personalization of the card or configuration of the reader. Output formats like magstripe, Wiegand and several others are available.

## **Security**

Depending on the model and the RF technology used the Smart ID Reader Family offers high security challenge response schemes to protect the RFID air interface against various attacks schemes like record & playback attacks.

# **Specifications**

## **Typical read range with an ISO Card**

EM4102	up to 7.5 cm (2.95 inch)
Hitag1&2	up to 8 cm (3.15 inch)
ISO14443	up to 3 cm (1.8 inch)
ISO15693	up to 15 cm (5.91 inch)
DESFire	up to 2 cm (0.79 inch)

## **Power Supply**

4.5 – 16 Volt DC

## **Current requirements**

Average Power Consumption 1.25 Watt  
Peak Power Consumption 1.68 Watt

## **Interface**

Inputs EMC Prot. 10K ohm pull-ups  
Outputs EMC Prot. open drain 0.5 A/max

## **Dimensions**

142 x 46.2 x 25 mm (5.59 x 1.81 x 0.98 inch)

## **Material**

SB housing with polyurethane potting

## **Operating temperature**

-20° to 60° C (-4 to 140 Fahrenheit)

## **Certifications**

CE, FCC

### **FCC ID's are:**

- Hitag1&2: Smart ID/Hitag1&2  
P4E-SMARTPIN-2
- ISO14443: Smart ID/ ISO14443/SNR/RS232  
P4E-SMARTPIN-1
- ISO 14443-3: Smart ID/ISO14443-3/Sect  
P4E-SMARTPIN-1
- DESFire: Smart ID/DESFire  
P4E-SMARTPIN-1

Consult your National Authority if any authorization is needed for this product.

This device complies with Part 15 of the FCC Rules.  
Operation is subject to the following two conditions:

- 1) that this device does not cause harmful interference, and
- 2) that this device must accept any interference received, including interference that may cause undesired operation.

### **Cable Distance**

Up to 150 meter (492 foot), depending on output protocol and cable type. Recommended cable type: stranded conductor with overall stranded shield or equivalent

SIA recommended cable type for Wiegand signals

<b>Cable Length</b>	<b>Cable</b>	<b>Diameter inch</b>	<b>Diameter mm</b>
Up to 61m (200.1 ft)	AWG22	0.025	0.64
Up to 91m (301.8 ft)	AWG20	0.03	0.82
Up to 153m (502 ft)	AWG18	0.04	1.02

Recommended cable for clock and data ABA track 2 emulation: Up to 25 meter (82 foot), AWG22.

### **Wiegand Signal Levels**

Voh = Output Voltage idle high

Vol = Output Voltage active low

### **SmartID output interface and pull-up resistors**

The SmartID readers provided true open collector outputs for Wiegand/Clock&Data ABA track 2 emulation. This means the data output is not voltage driven.


External pull-up resistors are required when the controller does not provide internal pull-up resistors. The typical value for the pull-up resistors is 1 kOhm. The recommend position to place the pull-up resistors is at the controller side.

The pull-up resistor #1 connects form Data/D1 (reader connector pin 3) to a 5 Volt reference.


The pull-up resistor #2 connects form Clock/D0 (reader connector pin 4) to a 5 Volt reference.

## Timing

### Typical timing for Wiegand



### Typical timing for ABA track 2 emulation



## **Installation instruction**


- 1)** Determine an appropriate position for the Reader and drill two holes for mounting the reader to the surface (see mullion mounting drawing on 13). Do not mount the readers less than 20 cm (7.87 inch) from each other. Make sure that enough room to connect the cable is allowed. Protect the cable against sharp edges and any damage from chaffing.
- 2)** Remove the Terminal Connector 8 pins from the back of the Reader. Use a small flat head screwdriver to loosen off all of the terminals. The end of the cable should be prepared by cutting it back to expose the wires and each end should be twisted to eliminate any loose or frayed wires.
- 3)** The wires should then be connected to the Reader inline with the Connector Assignments. Wire ends outside the shielding and optional permanent LED links should be kept as short as possible. Twist the connector a few times to twine the wire ends to avoid differential mode interference on the data lines.

Note: wires at the connector must be kept as short as possible: long, unshielded connections will reduce the sensitivity of the reader.

- 4)** After wiring the reader and the Host system the Reader is ready to be tested. Apply power and present a Card to the Reader. The green LED should flash and the buzzer should beep indicating a read. If the Host system is connected to the red and green LED inputs these should follow the functionality of the Host system.
- 5)** The Reader can now be secured to the surface using the appropriate screws. Mount the black cover (sticker) and mount the cap over the mounting hole.

## Mullion Mounting

The size in the drawing is in mm. 1 mm is 0.039 inch.





## Connector Assignments

	<b>Clock/Data (ABA)</b>	<b>Wiegand</b>	<b>RS232</b>	<b>RS422</b>
1	Green LED input	Green LED input	Green LED input)**	Green LED input)**
2	Led LED input	Led LED input	Led LED input)**	Led LED input)**
3	Data	D1	Do not connect	TXA
4	Clock	D0	TXD	TXA
5	Buzzer input	Buzzer input	Do not connect	RXA
6	Do not Connect	Do not Connect	RXD	RXB
7	Ground	Ground	Ground	Ground
8	Power 4.5 to 16.00 VDC	Power 4.5 to 16.00 VDC	Power 4.5 to 16.00 VDC	Power 4.5 to 16.00 VDC

**Attention:** 4.5 Volt DC is MINIMUM VOLTAGE AT READER CONNECTOR PINS


\*\*) LED input only valid in read-only applications

*Optional*  
**Tamper Switch**



*Optional*  
**Mounting tool**


The sizes in the drawing is in mm. 1 mm is 0.039 inch.




Smart ID MOUNTING KIT

3

Mount Side Caps  
Left and right





(After mounting: Side Caps  
can't be removed!)



4


Mount Cover  
(take off sticker paper)  
and mount Cap



(If needed, reader can be removed  
without removing the Side Caps)


## *Optional* **Mounting Plate (Spacer)**

The sizes in the drawing is in mm. 1 mm is 0.039 inch.



Cable conduit (Attema K25)

## **Notes**



The crossed-out wheeled bin means that within the European Union the product must be taken to separate collection at the product end-of life. This applies to your device but also to any enhancements marked with this symbol. Do not dispose of these products as unsorted.



### **Approval**

If used according to the instructions, this radio system meets the basic requirements of article 3 and the remaining applicable conditions of the R&TTE directive (1999/5/E6) of March 1999.

© Copyright 2005

Issue: December 2005 – This manual supercedes and renders invalid all earlier versions. The information in this manual can be changed without prior notice.

The information in this manual has been put together to the best of the authors' knowledge and conscience. The manufacturers accepts no liability for the accuracy or completeness of the information in this manual. In particular, the manufacturer cannot be held liable for consequential damages caused as a result of incorrect or incomplete information. As it is impossible to avoid mistakes despite all our efforts, we are always grateful if these are pointed out.

The installation recommendations contained in this manual assume the most favorable framework conditions. The manufacturer cannot guarantee that the system will function perfectly under other conditions.

The manufacturer cannot guarantee that the information contained in this document is not protected by external property rights. The manufacturer is not granting licenses to its own or external patents or other property right.