

Mantis™ II 433.92MHz Reader

User Manual

Revision 00





USER MANUAL – Mantis™ II 433.92MHz Reader

User Manual

Document Created:	26 July 2005
Document ID:	UM-C2020-R02-20030422

Issue Date	Comment	Revision
26 Jul 2005	Initial Draft	00

Important - This document is not intended for public distribution. No copying of this material is allowed without prior written permission.

Contents

User Manual

1. Introduction	4
2. Hardware	5
Front View – LED Indicators.....	5
Rear View – Data Connections.....	6
Antennas – Positioning	7
Environmental Limits	10
Tag Positioning	10
3. Firmware	11
File System	11
Upgradeable Firmware	11
Reader Setup.....	12
Configuration Files & Default Settings.....	17
4. Troubleshooting	20

Appendix

A. List of Acronyms	23
B. Index	25
C. FCC Compliance	26
C. Copyright Statement	27



USER MANUAL – Mantis™ II 433.92MHz Reader

User Manual

- 1 – Introduction
- 2 – Hardware
- 3 – Firmware
- 4 – Troubleshooting

1 - Introduction

2 - Hardware

3 - Firmware

4 - Troubleshooting



USER MANUAL – Mantis™ II 433.92MHz Reader

1 – Introduction

The **Mantis™ II 433.92MHz System** by **RF Code™** is an RFID monitoring system designed to report Tags within defined Reader operating ranges. The system utilizes “beacon” Tags that periodically report their presence with an encoded radio transmission. The **Mantis™ II 433.92MHz Reader** is a dual-channel radio receiver tuned to the **Mantis™ Tag** transmission frequency of 433.92MHz.

This manual provides the instructions for the **Mantis™ II 433.92MHz Reader** setup and operation. This Reader has different modes of operation and optional functions that are user-selected depending on the system's operational requirements.

The instructions in this manual show how to install, configure, and upgrade the **Mantis™ II 433.92MHz Reader** as well as tips on **Mantis™ Tag** placement and antenna optimization. Operational instructions for the **Mantis™ II 433.92MHz System** using the **TAVIS™ Concentrator** software by **RF Code™** are found in the **TAVIS™ Concentrator User Manual**.

2 – Hardware

The **Mantis™ II 433.92MHz Reader** is housed in a 5 x 5 x 1.5 inch (12.7 x 12.7 x 3.81 cm) metal chassis and contains the internal components of a RFID Reader combined with connections to allow for both Ethernet and serial port connectivity.

Front View – LED Indicators



Figure 2.1 – Mantis™ II 433.92MHz Reader (front view)
shown with standard 1/4-wave helical antennae.

Three LEDs are mounted on the front of the **Mantis™ II 433.92MHz Reader**.

- **Unlabeled LED** – This LED is used for a feature that is not implemented in this version of the Reader.
- **On-Ready LED** – This LED indicates the Reader has power applied through an external power adapter.
- **Tag Activity LED** – This LED is used for two purposes: (1) to show the status of the Reader while in standby mode and (2) to show Tag detections while in operation.

Tag Activity LED

- **While Operating** – The Tag Activity LED flashes intermittently, indicating the Reader has read one or more Tags each time it flashes. Because the Reader can decode Tags faster than the light can be turned on and off, a single flash may indicate more than one Tag being decoded.
- **While in Standby Mode** – The Tag Activity LED turns on and off at a distinctive rate that indicates the Reader is in standby mode.

Rear View – Data Connections




Figure 2.2 – Mantis™ II 433.92MHz Reader (rear view) showing connections for Network/Ethernet (RJ-45), Power, and Serial/COM (RS-232).

Several connections are housed on the back of the **Mantis™ II 433.92MHz Reader**.

- **Ethernet** – RJ-45 Ethernet jack. The Ethernet connection has a link-state “LINK” LED and collision “COL” LED such as those found on common Ethernet network connections. The LINK light stays solid when there is no network activity and flashes when activity is present.
- **Power** – A plug allows for connection to both AC and DC power sources. Power requirements are 12 to 28 VDC and 9 to 20 VAC.
- **Serial** – DB-9 RS-232 Serial port.

Antennas – Positioning



Each antenna post supplies an RF signal to the two parallel radio receivers in the **Mantis™ II 433.92MHz Reader**. Antenna input impedance is 50 ohms nominal.

Both the type of antennas used and the Reader range setting determine the effective read range. The normal Reader-range features are defined using **1/4-wave helical** antennas.

These antennas are appropriate for most Reader applications. Optional antennas that offer diverse receiving properties or extend the range of the Reader are available for the **Mantis™ II 433.92MHz Reader**. Contact your **Mantis™ II 433.92MHz Reader** distributor for more information.

The **Mantis™ II 433.92MHz Reader** has two receiver channels that can operate independently or jointly to provide Tag signal diversity reception. The Reader can operate with one antenna on either antenna post, but the



USER MANUAL – Mantis™ II 433.92MHz Reader

benefit of receiver diversity reception is obtained with both antennas attached.

Depending on the location and orientation of the tags, the signal path to the Reader may vary for each Tag. This may allow only one antenna to receive the signal.

To achieve the best receiver diversity:

- **Antenna Angle from Reader** – It is desirable to have the antennas positioned at different angles from the Reader.
- **Antenna Angle from Each Other** – Antennas should be at 90-degree angles relative to each other. It may be necessary to experiment with antenna positions to achieve optimum coverage.
- **Height** – As a rule, the higher a Reader is positioned above the ground or floor, the better the Reader's detection range.



WARNING – Do not allow antennas to overlap. Keep the antennas separated. Allowing the antennas to overlap reduces the effectiveness of each antenna.

To minimize RF interference:

- **Separation** – Maintain a 4-to-6-foot separation between the Reader antennas and potential RF radiators such as computers, monitors, printers and electronic office equipment. The local radio environment can limit the Reader's effective range.
- **Height** – Do not operate the Reader on or close to the floor or ground. Grounded and reflective metallic structures around the Reader and/or Tags affect the system performance. For best results, the Reader should be mounted as high as reasonably possible.



WARNING – Readers should not be positioned close to ceilings as they act as ground planes.



TOOLS – Low loss SMA coaxial extension cables may be used to separate the antennas from the Reader.




NOTE – Optional antennas that offer diverse receiving properties or extend the range of the Reader are available for the Mantis™ II Reader. Contact your Mantis™ II Reader distributor.

Environmental Limits

The **Mantis™ II 433.92MHz Reader** is approved for use within the temperature ranges set forth below.

- **Operation:** -20 to +70 degrees Celsius.
- **Storage:** -40 to +80 degrees Celsius.

Tag Positioning



Wherever possible, Mantis™ 433.92MHz Tags should be placed in the same orientation (plane) in order to optimize the Reader's ability to receive transmissions from the Tag. The Tags should not be placed closer than ½ inch in proximity to one another.

3 – Firmware



NOTE – The Mantis™ II Reader can only be configured through an Ethernet connection via the RJ-45 jack on the rear of the Reader.



WARNING – When an Ethernet connection is made directly between the Reader and a PC, a cross-over network cable is necessary.

File System

All embedded operating systems, signal processing software, and configuration options of the **Mantis™ II 433.92MHz Reader** are stored in a flash-based file system internal to the Reader. If any changes or updates are required, the files are collected in a directory on the PC, packaged into a new file system, and then transferred to the Reader by **TFTP** (Trivial File Transfer Protocol).

Upgradeable Firmware

The **Mantis™ II 433.92MHz Reader** has the ability to be updated as new firmware is released. It is vital these updates be obtained directly from **RF Code™** or its authorized source, since these files define the operation of the Reader and if defective, the files will render the Reader inoperable.



WARNING – Firmware updates should be obtained directly from RF Code™ or its authorized source. If defective, these files will render the Mantis™ II Reader inoperable.

Reader Setup




Figure 3.1 – Network-enabled Reader Programmer Utility.

To perform a **Reader** setup or update:

Step 1 – Launch the **Configure Mantis II Reader** utility, found in the RF Code Mantis II Reader program group on the Start Menu. (The location will be different if the defaults were not used during the install process.)

Step 2 – The **Network-enabled Reader Programmer** utility appears in a DOS screen (see **Figure 3.1** above). Refer to the commands below:

- **Reader Settings** – Refer to page 13.
- **Network Settings** – Refer to page 14.
- **Advanced Network Settings** – Refer to page 15.
- **Programming Options** – Refer to page 16.
- **Network Installation** – Refer to the example on page 17.



WARNING – Computer administrative privileges are recommended when using the network-enabled Reader programmer utility. In the event of IP resolution conflicts, the utility will attempt to modify the Address Resolution Protocol (ARP) table. On some systems this can only be achieved with sufficient privileges.

Reader Settings

(R)eaders

R

R - Select a new Reader to program.

- Reads and displays a Reader's saved calibration and settings from its configuration file (**SSI_info\AXnnnnnn.txt** where **AXnnnnnn** is the serial number). Any undefined settings will remain blank.
- Errors are displayed if the info file is missing or contains bad calibration data.
- The **Reader #** is the **s/n** (serial number) on the silver label on the underside of the Reader. When entering this number ignore the space between the two sets of 4 numbers and input it as a single 8-digit alpha-numeric serial number.

(U)B processor FW

U

U – Choose firmware revision for the network processor.

- Prints list of available files.
- Type the desired filename (case-sensitive).
- An error message is displayed if the firmware file cannot be found.

(D)A processor SW

D

D – Choose firmware revision for the DSP processor.

- Prints list of available files.
- Type the desired filename (case-sensitive).
- An error message is displayed if the firmware file cannot be found.

Calibration (loaded from reader in upload process)

Reader calibration data.

- This field only displays the calibration data for the Reader at the time of the upload process, when this information is retrieved from the Reader. This field is informational only and cannot be modified.

Network Settings

MAC Addr

Reader MAC address.

- Displays the MAC address of the Reader. This field is informational only and cannot be modified.

(I)P Addr

I – Change network IP address.

- Enter in normal dotted decimal format, e.g.: **192.168.1.129**
- An error message is displayed if the format is unintelligible or the numbers are out of range.
- This entry represents the new IP address that will be assigned to the Reader during an upload.

WARNING – Microsoft Windows-based PCs have restrictions on certain IP address ranges (e.g. 127.x.x.x and 224.x.x.x through 254.x.x.x). Since addresses fitting these parameters cannot be configured on a Windows-based PC, it will not be possible to use the configuration utility to reconfigure a Reader that has been assigned an address within this scope.

(S)ubnet

S

S – Change subnet mask.

- Enter in normal dotted decimal format, e.g.: **255.255.255.0**
- An error message is displayed if the format is unintelligible or the numbers are out of range.

(G)ateway Addr

G

G – Change gateway address.

- Enter in normal dotted decimal format, e.g.: **192.168.1.1**
- An error message is displayed if the format is unintelligible or the numbers are out of range.

(P)ing TFTP IP Addr

P

P – Pings the TFTP IP address.

- An error message is displayed if the TFTP IP address is blank.
- A status message is displayed which reflects the results of the ping operation.
- If a ping is unsuccessful, the utility will attempt to remove the TFTP IP address from the ARP table and perform another ping.

(A) RP Table display**A****A – Displays the ARP Table.**

- When two or more Readers initially share the same IP address, it is likely that the ARP will need to be either modified or flushed before sequential accesses to the same IP address can be performed (due to physical addressing). This feature provides a method of querying the ARP table to assess IP resolution issues.

Advanced Network Settings**(1) Keep Alive Probes (default is 10)****1****1 – Change the number of keep-alive probes.**

- Defines the maximum number of keep-alive probes to send.
- An error message will be displayed if an invalid number is entered (and the field will be cleared).

(2) Keep Alive Signal Interval (default is 1000 ms)**2****2 – Change the keep-alive signal interval.**

- Defines how often keep-alive probes are sent on a connection (in milliseconds).
- An error message will be displayed if an invalid number is entered (and the field will be cleared).

(3) Packet Size (default is 1400 bytes)**3****3 – Change the packet size.**

- Defines the maximum packet size in bytes.
- An error message will be displayed if an invalid number is entered (and the field will be cleared).

(4) Packet Timeout (default is 500 ms)**4****4 – Change packet timeout setting.**

- Defines the packet timeout (in milliseconds).
- An error message will be displayed if an invalid number is entered (and the field will be cleared).

Programming Options

(L)oad Defaults

L – Load default firmware and network settings.

- These are settings as defined in the **SSI_info\defaults.txt** file.
- This command is useful after a **(R)ead #** command to update to a standard network configuration before programming.
- Errors are displayed if any settings are invalid.

(F)ilesystem Upload to Reader

F – Create file system and upload to the Reader.

- Prior to the upload, the Reader parameters are verified and the TFTP IP address is pinged. The process will only continue if these are successful.
- Creates file system (**A.bin**, **Bcom.bin**, **caltable.txt**, **network.txt**) using currently displayed settings, uploads to the Reader, then initiates self-programming.
- If applicable, after re-initialization of the Reader the file system is retrieved from the Reader and verified against the original.
- Errors are displayed if any vital components are missing, if the settings are not properly defined, or if there are problems communicating with the Reader over the network.
- Saves the Reader configuration data upon a successful upload.



WARNING – If the IP address to be assigned to the Reader is out of scope with regard to the subnet mask, the utility will upload the file system to the Reader but will NOT attempt to retrieve this file system back from the Reader for verification.

(T)FTP Addr

T – Set TFTP address for the file system upload.

- This address must reflect the current IP address of the Reader, which likely differs from the new IP address to which it is being set with the **(I)P Addr** command.
- Under normal circumstances, this should not have to be changed. The **TFTP** (Trivial File Transfer Protocol) address is automatically updated when the **IP** address of the Reader is changed and a successful upload is performed.

(Q)uit

Q – Quit the Network-enabled Reader Programmer Utility.

Configuration Files & Default Settings

Each Reader has a configuration file under **SSI_info\AXnnnnnn.txt** (where **AXnnnnnn** is the serial number) reflecting its last programmed state. After a successful program upload to a Reader, the configuration file for that Reader is updated with the current settings.

The next time the Reader is selected for configuration, these saved settings are imported and displayed as a baseline configuration. The Reader configuration file is therefore purposely similar to the interactive commands.



WARNING – Do not use [CTRL]+[C] to exit, or the last settings of the Mantis™ II 433.92MHz Reader will be lost!

Example – Network Installation

Step 1 – Select the **(R)** command, then enter the Reader's serial number when prompted.

Step 2 – Select the **(I)** command, then enter the new IP address for the Reader (e.g. 192.168.4.34).

Step 3 – Select the **(S)** command, then enter the new subnet mask for the Reader (e.g. 255.255.0.0).

Step 4 – Select the **(F)** command to upload the new file system and update the Reader settings.



USER MANUAL – Mantis™ II 433.92MHz Reader

Serial Settings

The **Mantis™ II 433.92MHz Reader** supports operation via a standard RS-232 serial port, which may be used instead of, or in conjunction with the Ethernet jack. The Reader will accept commands from either source, or output results to both. In addition, the serial port doubles as a diagnostic port, providing valuable feedback about Reader functionality and configuration during power-up and programming.

Having selected the appropriate serial port (COM port) on your system, use the following settings in your communications package:

Bits Per Second: **115200**

Data Bits: **8**

Parity: **None**

Stop bits: **1**

Flow Control: **None**

ASCII Setup

ASCII Sending

Send line ends with line feeds: **NO**

Echo typed characters locally: **NO**

Line delay: **10 ms**

Character delay: **0**

ASCII Receiving

Append line feeds to incoming line ends: **YES**

Force incoming data to 7-bit ASCII: **NO**

Wrap lines: **NO**

Ethernet Settings

As shipped, the default network settings for the **Mantis™ II 433.92MHz Reader** are:

IP address:	192.168.1.129
Subnet mask:	255.255.255.0
Gateway:	192.168.1.5



WARNING – These settings must be changed to match the subnet of the network on which the Mantis™ II 433.92MHz Reader is to be used.

These Ethernet settings are stored in the **network.txt** file, which is read by the Reader at boot time. Each setting is represented as a string of hexadecimal characters. For IP addresses, a pair of hexadecimal characters (00 to FF) represent each decimal component (0 to 255) of the address. For example:

IP address:	192.168.1.239 =>	COA801EF
Subnet mask:	255.255.0.0 =>	FFFF0000
Gateway:	192.168.1.1 =>	COA80101

The **network.txt** file consists of these default hexadecimal strings that are concatenated on a single line. For example:

COA80181	FFFFFOO	COA80105	0A	3E8	578	1F4
IP Addr	Sub. Mask	Gateway	Keep-alive probes	Keep-alive interval (ms)	Packet size (bytes)	Packet timeout (ms)



WARNING – This network.txt file should not be altered. Instead, the Network-enabled Reader Programmer allows the user to change these settings using dotted decimal notation for IP addresses, the subnet mask, and other advanced settings.

4 – Troubleshooting

This is a brief list of potential problems, with possible solutions, that may be encountered while using the **Mantis™ II 433.92MHz Reader** or the network-enabled Reader programming utility. If the problem cannot be resolved using this list, please call the distributor from which you obtained the **Mantis™ II 433.92MHz System** for help in resolving the problem.

SYMPTOM – There are no Tags being read at the Reader.

- **CONDITION** – The Reader power light is off.
- **REMEDIY** – Plug in the Reader power supply.
- **REMEDIY** – Turn on the Reader power switch.

SYMPTOM – There are no Tags being read at the Reader.

- **CONDITION** – The Reader power light is on.
- **CONDITION** – The Reader detect light is turning on and off at a regular interval.
- **REMEDIY** – The Reader is in standby mode and needs to be configured and enabled for operation.

SYMPTOM – There are no Tags being read at the Reader.

- **CONDITION** – The Reader has power but is unresponsive to system communications or remote restart commands.
- **REMEDIY** – Verify the LAN is connected and the Client Bridge can be “Pinged”.
- **REMEDIY** – Verify that the Reader is connected to the LAN by a wired cable or by wireless but not by both. If connected by a wired LAN, remove the wireless card from the Reader.

SYMPTOM – There are no Tags being read at the Reader. The Reader has been configured, enabled and is communicating.

- **CONDITION** – The Reader power light is on.
- **CONDITION** – The Reader detect light is not flashing.
- **CONDITION** – The system is receiving the “status” message from the Reader.
- **REMEDIY** – Verify the antennas are attached to the Reader and/or move the Tags closer to the Reader.
- **REMEDIY** – Change the range setting on the Reader to a longer range to see the available Tags.
- **REMEDIY** – Verify the communication medium between the Reader and the computer is operational.
- **REMEDIY** – Verify that the configured group code is the same as the Tags being read.
- **REMEDIY** – Verify the computer program is set up correctly to receive TagIDs.



USER MANUAL – Mantis™ II 433.92MHz Reader

SYMPTOM – TagIDs do not drop off the computer display when the Tags are moved away from the Reader.

- **CONDITION** – The antenna(s) are installed on the Reader.
- **REMEDY** – Verify that the data communication path from the Reader to the computer is functional.
- **REMEDY** – Change the Reader's range setting to a shorter range.

SYMPTOM – All the indicator lights on the Reader turn off and back on again.

- **REMEDY** – If the Reader is not in operation or off-line, the watchdog timer inside the Reader periodically power-cycles the whole Reader. This is normal operation.



USER MANUAL – Mantis™ II 433.92MHz Reader

1 - Introduction

2 - Hardware

3 - Firmware

4 - Troubleshooting

Appendix

Appendix

A – List of Acronyms

B – Index

C – FCC Compliance

D – Copyright Statement



USER MANUAL – Mantis™ II 433.92MHz Reader

A – List of Acronyms

RFCP – **RF Code** Common Protocol

RFQS – **RF Code** Quick Search

TAVIS™ – Total Asset VISibility

ADO - ActiveX Data Objects

API - Application Program Interface

ARIN – American Registry for Internet Numbers

ARP – Address Resolution Protocol

ASP – Active Server Page

B2B - Business-to-Business

BGP4 - Border Gateway Protocol

BSA - Business Systems Analyst

CDFS - Compact Disc File System

CGI – Common Gateway Interface

COM - Component Object Model

CPU - Central Processing Unit

CSS - Cascading Style Sheet

DDL – Description Definition Language

DHTML - Dynamic Hyper-Text Markup Language

DLL – Dynamic Link Library

DLT - Digital Linear Tape

DMZ - Demilitarized Zone

DNS - Domain Name Server

DoS - Denial of Service

EDI - Electronic Data Interchange

EJB - Enterprise Java Beans

ERP - Enterprise Resource Planning

FTP - File Transfer Protocol

GIF - Graphics Interchange Format

GPS – Global Positioning System

GRE - Generic Routing Encapsulation

HTML - HyperText Markup Language

HTTP - HyperText Transfer Protocol

I/O - Input/Output

IDE - Integrated Drive Electronics

IE - Internet Explorer

IIS - Internet Information Services

IP - Internet Protocol

IPSec - Internet Protocol Security

ISO – International Organization for Standardization

ISP - Internet Service Provider

IT - Information Technology



USER MANUAL – Mantis™ II 433.92MHz Reader

J2EE - Java 2 Platform, Enterprise Edition

JPEG - Joint Photographic Experts Group

JSP - Java Server Pages

L2TP - Layer 2 Tunneling Protocol

LAN – Local Area Network

NNTP – Network News Transport Protocol

NTP – Network Time Protocol

OBI - Open Buying on the Internet Consortium

OC - Optical Carrier

ODBC - Open Database Connectivity

OLTP – Online Transaction Processing

OS - Operating System

PAT - Port Address Translate

PDF - Portable Document Format

POP - Point of Presence

RAID - Redundant Array of Independent Disks

RAM - Random Access Memory

RFID – Radio Frequency Identification

ROM - Read Only Memory

RTLS – Real Time Location System

SAN - Storage Area Network

SAP™ - Systems, Applications, Products, and Data Processing™

SDK - Software Developer's Kit

SGML - Standard Generalized Markup Language

SNMP – Simple Network Management Protocol

SOAP – Simple Object Access Protocol

SQA - Software Quality Assurance

SSL - Secure Sockets Layer

SSI – Signal Strength Indication

TCP/IP - Transmission Control Protocol/Internet Protocol

TOAD - Tool for Oracle Applications Development

UBC - Unified Buffer Cache

UN/SPSC – United Nations Products & Services Classification

UNSPSC – Universal Standard Products & Services Classification

UPS - Uninterruptible Power Supply

URL - Universal Resource Locator

VPN - Virtual Private Network

VSS - Visual SourceSafe

WAN – Wide Area Network

WSC – Windows Script Components

XML - eXtensible Markup Language

XSL - eXtensible Style Language

XSTL - eXtensible Style Language Transformation

XHTML - eXtensible Table Markup Language

B – Index

- 1 command, 14
- 2 command, 14
- 3 command, 14
- 4 command, 14
- A command, 14
- acronyms, 22
- Advanced network
 - commands, 14
- antennas, 7
- ARP, 12, 14
- calibration, 12
- commands, 12, 15
- configuration files, 16
- copyright statement, 26
- D command, 12
- data connections, 6
- default settings, 16
- environmental limits, 9
- ethernet connection, 6
- ethernet settings, 18
- example, 16
- F command, 15
- FCC compliance, 25
- file system, 10
- files, 16
- firmware, 10
- front view, 5
- G command, 13
- hardware, 5
- I command, 13
- index, 24
- introduction, 4
- Keep Alive Probes, 14
- Keep Alive Signal Interval, 14
- L command, 15
- LED indicators, 5
- limits, 9
- MAC Address, 13
- Network commands, 13
- network installation, 16
- note, 8, 10
- on-ready LED, 5
- P command, 13
- Packet Size, 14
- Packet Timeout, 14
- positioning, 7, 9
- power connection, 6
- Programming commands, 15
- Q command, 15
- R command, 12
- Reader commands, 12
- Reader setup, 11
- Reader update, 10, 11
- rear view, 6
- S command, 13
- serial connection, 6
- serial settings, 17
- settings, 16
- setup, 11
- T command, 15
- Tag activity LED, 5, 6
- Tag positioning, 9
- Tags, 9
- tools, 8
- troubleshooting, 19
- U command, 12
- upgradeable firmware, 10
- warning, 8, 10



USER MANUAL – Mantis™ II 433.92MHz Reader

C – FCC Compliance

Changes or modifications to this equipment, not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee against interference to radio or television reception, which may be determined by turning the equipment off and on; the user must try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
- Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his/her own expense.

The **Mantis™ II 433.92MHz System** has two major components which are independently certified and comply with Federal Communications Commission (FCC) rules, part 15.

This **Mantis™ II 433.92MHz Reader** complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The system operates by using **Mantis™ 433.92MHz Tags** which have been certified or are in the certification process. These devices comply with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) these devices may not cause harmful interference, and (2) these devices must accept any interference received, including interference that may cause undesired operation.

- a. FCC IDs: P6F2005433 for:
 - i. 10-second static/ 1-second motion Mantis II Tag P/N: 05102050-49A



USER MANUAL – Mantis™ II 433.92MHz Reader

D – Copyright Statement

Copyright © 2005 RF Code, Inc. All rights reserved.

Mantis™ II 433.92MHz Reader

User Manual

Revision 00

Technical Writer: John Moxon

This document, as well as the hardware and firmware described therein, is furnished under license and may only be used or copied in accordance with the terms of such license. The information in these pages are furnished for informational use only, are subject to change without notice, and should not be construed as a commitment by RF Code, Inc. RF Code assumes no responsibility or liability for any errors or inaccuracies that may appear in these pages.

Except as permitted by such license, no part of these pages may be reproduced, stored in a retrieval system, or transmitted, in any form or by any means -- electronic, mechanical, recording or otherwise -- without the prior written permission of RF Code.

Every effort has been made to supply complete and accurate information. However, RF Code assumes no responsibility for its use, or for any infringements of patents or other rights of third parties, which would result. Information in these pages is subject to change without notice.

Some of the names of individuals and companies that may appear in these pages are fictitious. Any similarity to real persons or companies is coincidental.

Written and designed by RF Code.

Microsoft is a trademark of Microsoft Corporation. All other product names are copyright and registered trademarks or trade names of their respective owners.



RF Code, Inc.
1250 South Clearview Avenue
Mesa, AZ 85208 USA

www.rfcode.com