

1. Caution

Please follow the instructions below to avoid physical injury:
You should not install the unit during a storm. Likewise you should not connect or disconnect any line to avoid the risk of electric shock.

Caution & Warning

- This unit is indoor use and all the communication wirings are limited to inside of the building.
- DO NOT plug in, turn on or attempt to operate an obviously damaged unit.
- DO NOT use near water.
- DO NOT place near high temperature source.
- DO NOT disassemble the unit.
- DO NOT operate the unit in a location where the maximum ambient temperature exceeds 40°C.
- Open optical connections must use a protective cap under all circumstances to protect against physical damage and dirt.
- Before making connections, use isopropyl alcohol and non-fibrous cellulose to clean the faces of the connectors.
- Avoid impact stresses when handling connectors. Physical damage to the faces of optical connections impairs transmission quality (higher attenuation).
- Avoid a bend radius in excess of 30 mm for fiber optic links.
- Check the available voltage supply.
- Only use the unit in dry rooms.
- Set up the unit away from direct sunlight or other electrical equipment.
- Only connect approved accessories.
- It may only be repaired by authorized service personnel.
- This equipment is not suitable for use in locations where children are likely to be present.

Limited Warranty

- Not covered under this warranty is defect and damage resulting from product disassembly by yourself. And also, such behavior may amount to intellectual property infringement.

2. Introduction

2.1 Package Contents


- 2428TE
- QIG (Quick Installation Guide)

2.2 Specification

Item	Specification
Service Interface	4 10/100/1000Base-T ports (RJ45) 1 2.5GBase-T port (RJ45)
Wi-Fi	Wi-Fi Internal antenna
VoIP Interface	2 FXS ports (RJ11)
Power Adapter	Output: 12VDC/2.5A
Operating Temp.	0 to 40°C (32 to 104°F)
Operating Humidity	5 to 95% (non-condensing)
Dimensions	182 x 263 x 75 mm (W x H x D)

Information furnished by DZS is believed to be accurate and reliable. However, no responsibility is assumed by DZS for its use, nor for any infringements of patents or other rights of third parties which may result from its use. No license is granted by implication or otherwise under any patent or patent rights of DZS. DZS reserves the rights to change specifications at any time without notice.

2.3 Interface




Item	Description
① LEDs	Operating status LEDs.
② USB	Connect an external 3.0 USB drive.
③ TEL 1-2	Connect to VoIP phone.
④ GE 1-4	Connect to PC or LAN. (10/100/1000Base-T interfaces)
⑤ 2.5GE	Connect to PC or LAN.
⑥ WPS button	Press to initiate WPS connection process
⑦ Reset button	Reboot the unit or reset to factory defaults Press and hold for 10 seconds to reset factory defaults.
⑧ UPS	Power connector and UPS backup power
⑨ Power port	Connect an external power supply.
⑩ On/Off button	Turn on/off the unit

2.4 LED


Label	Light	Status	Definition
5.8G	Green	ON	5GHz Wi-Fi service is enabled on ONT.
		Slow Blink (1/sec)	5GHz Wi-Fi data passing between ONT and connected devices.
2.4G	Green	ON	2.4GHz Wi-Fi service is enabled on ONT.
		Slow Blink (1/sec)	2.4GHz Wi-Fi data passing between ONT and connected devices.
VOICE	Green	ON	USB is connected.
		OFF	USB is not connected.
GE1	Green	ON	Registered successfully
		Slow Blink (1/sec)	Off hook
GE2	Green	ON	Registration failed or telephone service is not provisioned.
		OFF	Ethernet interface linked
GE3	Green	ON	Data transmitting
		OFF	Ethernet interface not linked
GE4	Green	ON	Internet service is available.
		OFF	Internet service is unavailable. (no response from DNS server)
INTERNET	Green	ON	Ranged successfully
		OFF	Ranging in progress
WAN	Green	ON	Not ready for ranging or not provisioned
		OFF	No major alarms
ALARM	Red	ON	Major Alarm (including operating in battery power)
		Slow Blink (2/sec)	SW or Config update in progress
BATT	Yellow	ON	Normal operation on AC source
		Slow Blink (2/sec)	Operating on Battery Power
STATUS	Blue	ON	Battery Alarm (Low Battery, Missing or Replace)
		Rapid Blink (10/sec)	Unit has been reset to factory defaults /is unconfigured.
		OFF	Normal Operation
		Slow Blink	Boot-up / Initialization / provisioning in progress
		OFF	Power off

3. Installation

- Attach the 2428TE to the desktop stand in the direction of the marked arrow.
- Connect the telco cable from POTS port to phone lines.
- Connect the Ethernet cable from GE port to PC.
- Connect the power cable from power port to an electrical outlet.
- (OPTIONAL) Connect the Battery Backup Unit power and telemetry to the UPS port.




Pin	Signal	Comments
1	+VDC	Power in from UPS
2	-VDC	Power return to UPS
3	On Battery	Open signal when on battery power
4	Signal Return	Connected to Signal GND on ONT
5	Missing Battery	Open signal when battery not detected
6	Replace Battery	Open signal when battery should be replaced
7	GND	Connected to Signal GND on ONT
8	Low Battery	Open signal when battery is low



Mounting on a Wall

If necessary, you may have your ONT mounted on a wall using mounting holes.



4. Web Access

You can access the unit through a web browser by using the following steps:

- Connect an Ethernet cable from your computer to GE1 on the 2428TE.
- Launch a browser or telnet session and point it to **192.168.1.1**.
- Enter the username and password.
The default username/password is **admin/dzsi**.
For security the password should be changed.