



Illustration 49 g03866585
Time Zone

7. Select the local time zone from the drop-down list.



Illustration 50 g03866589
Local Date and Time

8. Enter the local date and time. Use an accurate reference to set the time.

Note: Laptop clocks are not accurate and may have a different time than the local time.



Illustration 51 g03866592
ET Display

9. Then press the "OK" button. The Cat ET will display the following message.




Illustration 52 g03866593
Cat ET Time Confirmation

10. Click on the "Yes" button in order to change the date and time or click on the "No" button in order to cancel the change. The Cat ET will display the new time on a 24 hour clock.




Illustration 53 g03866595
Cat ET Display 24 Hour Clock

i06229333

Software - Uninstall ("Immobilizer" Feature)

SMCS Code: 7631-011

The "Uninstall" feature of the Machine Security System MSS allows the user to uninstall the Immobilizer feature from other electronic control modules.

The MSS3s ECM should be removed after the immobilizer software has been successfully uninstalled. If the MSS3s ECM is not removed, the LED for the status of the MSS will give a false indication.

The “Uninstall” screen for the Machine Security System consists of the areas that are listed below:

“Status Line” – The “status line” displays messages regarding the process of this function.

Display Area – The “Uninstall” display for the Machine Security System consists of two columns. The two columns are the “ECM” column and the “Security System Status” column. The “ECM” column lists every ECM that is installed on the machine with the immobilizer feature. The “Security System Status” column lists the status of the immobilizer feature of the Machine Security System. The status of the immobilizer feature is either “Installed” or “Not Installed” .

“Uninstall Button” – The “Uninstall” button starts the “Uninstall” process.

Perform the steps that are listed below in order to uninstall the Machine Security System:

Note: You will need to obtain a factory password in order to perform this procedure. A master electronic key will not allow the user to uninstall the Machine Security System. Refer to the Testing and Adjusting, “Factory Password - Obtain” section of this manual for information on obtaining a factory password.

1. Connect a laptop Computer with the Caterpillar® ET to the machine via the communication adapter.
2. Place a key in the key start switch.
3. Turn the key to the “ON” position.
4. Start the Electronic Technician and establish communications with the MSS3s ECM.
5. Obtain a factory password. Refer to the Testing and Adjusting, “Factory Password - Obtain” section of this manual for information on obtaining a factory password.
6. Select the “Machine Security System Uninstall” option from the “Service” menu. This selection will cause the Cat® ET to display the message that is shown in Illustration 54 .






Illustration 54

g01097964

Machine Security System Uninstall screen

7. Click on the "Uninstall" button that is located at the lower left-hand corner of the "Machine Security System Uninstall" screen. This button will cause the ET to display the "Factory Password Screen" that is shown in Illustration 55 .

Note: A factory password is required to perform the "Machine Security System Uninstall" . A master electronic key will not allow you to uninstall the Machine Security System. Refer to the Testing and Adjusting, "Factory Password - Obtain" section of this manual for information on obtaining a factory password.

Testing and Adjusting



Illustration 55

Factory Password screen

g03866606

8. The factory passwords are provided by the Factory Password System. Enter the factory passwords in the dialog boxes that are provided on the “Enter Factory Password” screen. Once the ET accepts the passwords, the screen shown in Illustration 56 will be displayed.

Note: Pressing the “No” button aborts the “uninstall” of the Machine Security System.




Illustration 56

Uninstall Confirmation screen

g01097989

9. Press the “Yes” button if you want to proceed with the “uninstall” of the Machine Security System. This button will cause the ET to display the message that is shown in Illustration 57 .




Illustration 57

g00831242

Process in Progress screen

Note: Once the Machine Security System has been successfully uninstalled, the ET will display the message that is shown in Illustration 58 .




Illustration 58 g00916867
Uninstall Successful screen

10. Press the “OK” button in order to return to the “Machine Security System Uninstall” screen.

Note: If the Machine Security System has not been successfully uninstalled, the ET will display the message that is shown in Illustration 59 .




Illustration 59 g00921613
Uninstall Failed screen

11. Press the “OK” button in order to return to the “Machine Security System Uninstall” screen. The “Uninstall” button that is located on the “Machine Security System Uninstall” screen will be labeled “Retry” . Press the “Retry” button in order to restart the uninstall.

12. Turn the key switch to the OFF position.

13. Remove the MSS3s ECM from the machine.

Note: If the MSS3s ECM is configured to control other devices, (start relay and/or main power relay), those devices must be reconnected in accordance with the machine Electrical Schematic.

i06229289

Glossary of Terms

SMCS Code: 7631

Armed – The state of the security system when the machine is disabled.

Disarmed – The state of the security system when the machine is able to operate normally.

Electronic Control Module – The portion of the MSS that contains the microprocessor and memory

EID – Event Identifier

Exciter Coil – The exciter coil is a small coil of fine wire. The wire is molded into the bezel of a keyswitch with harness wiring. The exciter coil provides a path of communication. The electronic key and the electronic control module communicate via radio frequency.

Immobilizer – The MSS Immobilizer is a feature within another ECM (engine and/or transmission) that restricts the operation of the machine until the Machine Security System disarms.

Master Access Level – Keys that are programmed for this level of access permit the operation of the machine and the key allows the user to add new keys. Also, keys that are already programmed can be modified.

MSS – Machine Security System

PID – A parameter identifier is used to identify specific parameters that are used by the MSS.

Product ID – The Product ID is an 8 digit alphanumeric number that identifies the machine.

Programming – Programming refers to the process of storing information in the memory of the control module.

Standard Access Level – Keys that are programmed for this level of access permit the operation of the machine.

Tattletale – The tattletale is a counter in the ECM that is used as part of the calculation for the factory password. The tattletale is incremented after a factory password is used. The affected parameter will have an increase in the specific parameter of the tattletale and the total tattletale will reflect the increase as well. Once you use the factory password, the factory password will no longer be valid. Another password will be required for changes on the same ECM at a later date.

i06227306

System Schematic

SMCS Code: 7566

Refer to the corresponding schematic of the machine
or Special Instruction.

PROOF

Index

C

Cat Data Link - Test	37
Diagnostic Trouble Code Procedure	37
Theft Deterrent Module ECM	37
Circuit Tests	37
Connector Contact Description	59
ECM Pull Down Voltage	59
ECM Pull Up Voltage	59
Input/Output	60
Inputs	59
Outputs	60
Connector Locations	17

D

Data Links	16
Determining Diagnostic Trouble Codes	24
Diagnostic Capabilities	18
The Cat® Electronic Technician (Cat ET) Service Tool	19
Diagnostic Operation	10
Active Diagnostics	11
Logged Diagnostics	11
Diagnostic Trouble Codes	24-25
Component Identifier (CID)	25
Detailed FMI Explanations	25
Diagnostic Codes	29
Failure Mode Identifier (FMI)	25
Module Identifier (MID)	25
Troubleshooting Procedures	27

E

ECM - Configure	52
Cat® Electronic Technician (Cat ET) Service Tool Configuration Procedure	52
ECM - Replace	52
ECM Output Driver - Test	39
Diagnostic Trouble Code Procedure	40
Theft Deterrent Module ECM	39
ECM Software - Install	52
Electrical Connector - Inspect	43
Guidelines	43
Important Safety Information	43
Tests	43
Electrical Power Supply - Test	46
Diagnostic Trouble Code Procedure	47
Theft Deterrent Module ECM	46
Electronic Control Module (ECM)	14
ECM Inputs	15
ECM Outputs	15
FCC NOTICE	14
Industry Canada Notice to Users	14
Emerging Symptom Information	30
Engine Does Not Crank and Status Indicator Is Green	31
Engine Does Not Start and Status Indicator Is Continuously Red	34
Events	11
Cat® Electronic Technician (Cat ET)	11
Logged Events	13

F

Factory Password - Obtain	79
Internet	80
Telephone Help Line	85

G

General Information	4, 17, 61
Cat® Electronic Key	61
Security Management using Cat® Electronic Technician (Cat ET)	61
Glossary of Terms	91

I

Important Safety Information	2
Introduction	17

K

Key - Program	63
“Fleet/Key Configuration”	70
Programming with a Service Tool	63
Key Information	8
Access Level	9
Expiration Date	9
Security ID	9
Security Type	9

L

Lost Key (MSS)	36
Lost Key (MSS3S)	36

M

Machine Preparation for Troubleshooting	22
General Procedure	22
Warnings	22

N

Normal Operation	7
Armed	7
Disarm	7
Reading the ID of a Key	7
Timeouts	7

O

Operation of Status Indicator	7
Status Indicator	8

P

Product Identification Number - Program	61
Protected Functions	13

S

Scheduled Access ("Security System Bypass Times")	10
Service	52
Service Operation Using Machine Security System	14
Service Operation Using Service Tool	14
Service Tools	17
Software - Uninstall ("Immobilizer" Feature)	87
Symptom Procedures	30
Symptom Troubleshooting	30
Determine Possible Causes	30
Know the Machine	30
Provide Feedback to Caterpillar	30
Test and Repair the System	30
Understand the Symptom	30
Use Available Service Literature	30
Verify the Symptom	30
System Components	15
Cat® Electronic Key	15
Exciter Coil	15
Status Indicator	16
System Disarm - Program (Security System Bypass)	78
System Overview	6
System Schematic	92
Systems Operation Section	4

T

Table of Contents	3
Testing and Adjusting	61
Testing and Adjusting Section	61
Time - Set	86
Troubleshooting Section	17

V

Visual Inspection	23
Check the Electrical System	23

W

Wiring Harness (Open Circuit) - Test	49
Test For An Open Circuit	50
Wiring Harness (Short Circuit) - Test	50
Test For A Short Circuit	51



UENR7061
©2016 Caterpillar
All Rights Reserved

CAT, CATERPILLAR, their respective logos, "Caterpillar Yellow", and the POWER EDGE trade dress as well as corporate and product identity used herein, are trademarks of Caterpillar and may not be used without permission.