

## Before using the system

Thank you for choosing AIRWOLF, a remote engine starter system manufactured by Semi Korea Inc. You are about to experience convenience through the various carefully designed functions for customer satisfaction. To fully benefit from the capabilities of your AIRWOLF system, we encourage you to read this user manual thoroughly before using the system.

### ※ Caution

1. Semi Korea warrants the operation of AIRWOLF system for a period of 2 years. Defects in parts or workmanship will be repaired by the manufacturer, but any installation problems will be resolved by your installation dealer.
2. Even though this product provides a theft deterrent function, Semi Korea gives no warranty against the theft or damage of any vehicle.
3. The manufacturer is not responsible for any accident caused by unauthorized installation or modification of the equipment.
4. The repair cost of this equipment due to the damage caused by natural calamity or customer fault will be charged. In addition to that, exchanging expendable supplies such as motor, remote control case, and battery will be charged regardless of the warranty period.
5. The battery for the remote control lasts about 100 days if it is used 10 times a day (It might be different depending on the type of the battery).  
User is responsible for purchasing and exchanging the battery (AAA Size V)

**This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.**  
**Caution:** Any changes or modifications in construction of this device which are not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

## AIRWOLF features

- Provides easy-to-use menu-driven user interface that allows easier function operation for user's convenience.
- Immediately displays the answer from the vehicle to the user commands through the LCD and the beeper of the remote control so that user would not be anxious about the current status of the vehicle.
- Displays the signal sensitivity between the vehicle and the remote control by using 4-step signal sensitivity antenna.
- Allows detailed time configuration in all menus to meet customer's various needs.
- Displays the current vehicle status on the LCD, when an alarm occurs so those users can easily recognize the status of the vehicle. Also different beeping sound is provided for each individual status of the vehicle by the remote control for easier distinction of the status.
- Saves all user configurations even if power is not supplied. Therefore, reconfiguration is not needed after replacing batteries.
- Notifies by sound if the vehicle is unreachable area from the remote control.
- Provides easy-to-use time data configuration function (INITIAL SETUP) designed to meet various requirements of vehicles including special-purpose, and imported vehicles in which other remote starter systems could not be installed.
- Adopted the most advanced code hopping technology.

※ Code hopping technology offers the most advanced protection available against "code-grabbing" devices that thieves may use to record the digital code transmitted by your remote control. When you leave the area, a thief can then play back the code to start or stop your system. The remote control of AIRWOLF randomly changes the code every time you use it by using the code hopping technology, and makes code-grabbing devices useless.


## Contents

<b>1. The contents of the package</b>	5
<b>2. Button descriptions</b>	6
<b>3. Functions of the buttons</b>	7
3-1. Remote engine start	
3-2. Door Lock/Unlock	
3-3. Emergency siren	
3-4. Status check including finding the vehicle, checking the communication status, and checking the vehicle status.	
3-5. Opening the trunk	
3-6. Turning the LCD lamp on	
3-7. Configuring auxiliary output 1/2/3	
<b>4. Functions of the icons on the LCD</b>	10
4-1. Signal sensitivity	
4-2. Configuring valet mode	
4-3. Configuring siren	
4-4. Configuring cold start	
4-5. Configuring engine start time	
4-6. Configuring run time	
4-7. Configuring turbo stop	
4-8. Configuring current remote control time	
4-9. Configuring remote control alarm	
4-10. Configuring automatic door lock	
4-11. Parking/driving time display	
4-12. Configuring auxiliary output 1, 2, and 3	
4-13. Command failure notification	
4-14. Low-battery warning	
4-15. Current time display	
<b>5. Alarms</b>	20
5-1. Weak shock detection	
5-2. Serious shock detection	
5-3. Door open detection	
5-4. Engine start detection	
5-5. Hood open detection	
5-6. Trunk open detection	
5-7. Error occur detection	
<b>6. In case of manual transmission vehicles</b>	22
<b>7. Valet mode button</b>	23
<b>8. Function Summary</b>	23
<b>9. Miscellaneous functions</b>	24
<b>10. FAQ</b>	25

## 1. The contents of the package



Remote



brain(main Control Box)



shock sensor



valet mode button



LED



antenna




battery (AAA)



user guide

## 2. Button descriptions




### ■ Functions of the buttons

Time	Button A ( )	Button B ( )	Button C (*)	Button D ( )
Press for a moment	To turn the LED lamp on	To lock or unlock door	Finding vehicle	To display menu
Press for few seconds	To configure auxiliary output 1/2/3 ( ) / ( ) / ( )	To operate emergency siren	To open trunk	To start engine

\* Press for a moment means press for about 0.5 second or more, and press for few seconds means press for more than 2 seconds.

## 3. Functions of the buttons

### 3-1. Remote engine start (Press button D for seconds)




Blink & Sound  
4 (4 x times)

If the engine is started, headlight and tire will blink. Even if the doors are unlocked, they are locked automatically. The engine runs for the configured time in the run time configuration

#### Tip

- The remote started engine will stop when you press the brake without placing the key to 'ON' position.
- In case of starting failure, the unit attempts to start engine 2 times continuously.(Total 3 times engin Start attempt.)

### 3-2. Door Lock/Unlock (Press button B for a moment)




Blink & Sound  
1 (x one time)

If the door is closed, a shield appears and the vehicle enters precaution mode in 20 seconds turning the red LED of the driver's seat on.  
※ To adjust the 20 seconds waiting time, ask your installation dealer

If the shield disappears, precaution mode is released and the LED is turned off



Blink & Sound  
2 (x 2 times)

### 3-3. Emergency siren (Press button B for seconds, default setting is 30 seconds)



In case of emergency, you can let people know the emergency status by flashing the parking lights and siren. To stop emergency siren, press button B or C.

### 3-4. Status check (Press button C for a moment)




Since this function does not affect the status of the vehicle, you can utilize this function easily in the following cases

#### Tip

- To find your vehicle in a complex and large parking area
- To check the communication status and signal strength
- To confirm the status of your vehicle

### 3-5. Opening the trunk (Press button C for seconds)




You can open the trunk of the vehicle by using this function

### 3-6. Turning the LCD lamp on (Press button A for a moment)



If LCD screen is dim, you can turn the lamp on using this button. Pressing button A for a moment turns the remote control LCD lamp on, and it is turned off in about 5 seconds. To turn off the lamp manually, press the button again while the lamp is turned on.

### 3-7. Configuring auxiliary output 1/2/3 (Press button A for seconds)




1. Press button A for seconds to display all ①②③ icons.
2. Press button A once again to enable auxiliary output 1 and make icon ① blink.
3. Press button B to enable auxiliary output 2 and make icon ② blink.
4. Press button C to enable auxiliary output 3 and make icon ③ blink.

#### Tip

- Auxiliary output is used to control heater, air conditioner, sunroof, or power windows. The auxiliary output port should be connected to the corresponding equipment of the vehicle.
- Press button A for seconds to configure auxiliary output, and press button A, C, and B to enable auxiliary output 1, 2, and 3 respectively as described above.
- When the icon is on, if you select AUX again, the icon becomes disappeared.
- AUX output is released at the moment you apply the brake as the car is already started.

## 4. Functions of the icons on LCD



If a command or configuration that needs the communication between the remote control and the brain is installed in the vehicle completely successfully, a simple tone will sound and the corresponding information will be displayed on the LCD panel, but if it is failed, an error tone will sound without any display.


### 4-1. Signal sensitivity

Signal sensitivity represents the signal strength between the vehicle and the remote control in 4 steps.



### 4-2. Configuring valet mode (Default setting is OFF)

Place your system in valet mode to stop all functions whenever your vehicle is being serviced by mechanics, car wash personnel or driven by valet parking attendants. Only door lock/unlock function will work in this mode but door status will not be displayed on LCD. If there is no remote, see page 24.



※ If the communication with the vehicle is failed, the function will not be set.

### Tip

- Press the button D three times in a row to select or release Disable.



#### 4-3. Configuring siren (Default setting is ON for 5 seconds)

Set operation of siren built into a vehicle. Set whether the siren operates or not and how long the siren operates (1 ~ 25 sec.) in case of a reply for remote, alarm occurrence or emergency siren operation.

1




④ Press button D to display all the menu icons.

2



Use button B and C to move to the siren icon.

3



The siren icon blinks.

4



④ Select the icon with button D.

5



The current setting, ON appears.

6




Press button B to set the siren to ON, or button C to set it to OFF.

7



Current configured operation duration is displayed in seconds.

8



Press button B to increase the duration by one second, or button C to decrease it by one second.

9



After completing the configuration, press button D.

10



Finish the configuration.

※ If the communication with the vehicle is failed, the function will not be set.

※ Set the siren OFF so that only remote can generate an alarm in emergency, enabling you to identify an unauthorized intruder while he or she doesn't know.



#### 4-4. Configuring cold start (Default setting is OFF)


This function enables the vehicle to start the engine periodically when it is very cold. To enable this function, select the icon, and input desired operation interval. Then the engine periodically at the specified interval will start and begin the warm-up procedure. Configurable period range is 1~12 hours. Engine run time is configured in run time configuration.

1



④ Press button D to display all the menu icons.

2



Use button B and C to move to the cold start setup icon blinks.

3



The cold start setup icon blinks.

4



④ Select the icon with button D.

5



The current setting, OFF appears.

6



Press button B to set the function to ON.

7




Press D button, to select 'ON'.

8



The current interval configured is displayed.

9



Press button B to increase the interval by 1 hour, and button C to decrease it by 1 hour.

10



After completing the configuration, press button D.

11




Finish the configuration.

※ If the communication with the vehicle is failed, the function will not be set.



#### 4-5. Configuring engine start time (Default setting is OFF)

This function allows you to start engine at a specified time everyday automatically. To enable this function, select the icon, and input desired time to start engine.




- ※ If the communication with the vehicle is failed, the function will not be set.
- ※ Brain starts operation according to the remotter time. Therefore, set the remotter time accurately.
- ※ You can cancel this function just do same as above.(But, you should choose 'OFF' at the No.6 step)



#### 4-6. Configuring run time (Default setting is 5 minutes)

The run time can be configured for cold start, engine start reservation, and remote engine start depending on the personal taste, weather, or the model of the vehicle. Configurable period range is 1~30 minutes.



※ If the communication with the vehicle is failed, the function will not be set.

**TB**

#### 4-7. Configuring turbo stop (Default setting is OFF)

Turbo Stop Mode allows you to leave your vehicle running when the ignition key is removed to cool the engine especially after high-speed or long-distance driving. To stop the engine by force, press and hold button D (D) for seconds, or press the brake pedal. Configurable period range is 1 ~ 20 minutes.

**1**


(D) Press button D to display all the menu icons.

**2**



Use button B and C to move to the turbo stop icon.

**3**


The turbo stop icon would blink.

**4**


(D) Select the icon with button D.

**5**


The current setting, OFF appears.

**6**


Press button B to set the function to ON, or button C to set it to OFF.

**7**


The current configured time period is displayed.

**8**


Press button B to increase the period by 1 minute, or button C to decrease it by 1 minute.

**9**


After completing the configuration, press button D.

**10**


※ If the communication with the vehicle is failed, no icon will be displayed and only an error tone will sound.

※ No icon appears during LPG gas switch operation.

Finish the configuration.



#### 4-8. Configuring current remote control time

The alarm function of the remote control can be configured. The clock of the remote control can be configured if necessary in the same manner as that of Configuring engine start time.

※ Brain operates based on the time set of the terminal. That's why accurately setting up the timing of the terminal is so important.



#### 4-9. Configuring remote control alarm (Default setting is OFF)

The alarm function of the remote control can be configured if necessary in the same manner as that of Configuring engine start time.



#### 4-10. Configuring automatic door lock (Default setting is OFF)

Automatic door lock feature provides the following functions:

- ① If door is not opened within 20 seconds after unlocking the doors with the remote control, the doors are automatically locked.
- ② The door lock is automatically applied to secure safety during the driving.
  - \* If the starter is connected to the generator, the door lock is applied when you step on the brake twice, and if the starter is connected to TACH, it is applied when RPM goes over 1500.
- ③ When the ignition key is removed after driving, doors are unlocked automatically.

**1**


(D) Press button D to display all the menu icons.

**2**


Use button B and C to move to the automatic door lock icon.

**3**


The automatic door lock icon blinks.

**4**


(D) Select the icon with button D.

**5**



The current setting, OFF appears.

**6**


Press button B to set the function to ON, or button C to set it to OFF.

**7**


After completing the configuration, press button D.

**8**


Finish the configuration.

※ If the communication with the vehicle is failed, the function will not be set.