

PiloTREK

W-100

two-wire non-contact microwave
compact level transmitter

User's and Programming manual
1st edition



Manufacturer:
NIVELCO Process Control Co.
H-1043 Budapest, Dugonics u. 11.
Tel.: (36-1) 889-0100 ■ Fax: (36-1) 889-0200
E-mail: sales@ nivelco.com ■ www.nivelco.com



BASIC CONCEPTS OF MICROWAVE LEVEL MEASUREMENT




TABLE OF CONTENTS

1. INTRODUCTION	5
2. ORDER CODES.....	6
3. TECHNICAL DATA.....	7
3.1. DIMENSIONS AND SPECIAL DATA OF THE ANTENNA VARIATIONS.....	8
3.2. ACCESSORIES	13
3.3. CONDITIONS OF SAFE OPERATION	13
3.4. REPAIR AND MAINTENANCE	13
4. INSTALLATION	14
4.1. MOUNTING	14
4.2. WIRING	17
4.2.1. <i>Wiring of Compact instruments</i>	18
4.3. LOOP CURRENT CHECKING WITH HAND INSTRUMENT.....	18
5. PROGRAMMING	19
5.1. THE SAP-300 DISPLAY UNIT	20
5.1.1. <i>Primary Measurement Screen</i>	20
5.1.2. <i>Information Screens</i>	22
5.1.3. <i>Echo Map</i>	23
5.2. PROGRAMMING WITH THE SAP-300 DISPLAY MODULE	24
5.2.1. <i>Components of the programming interface</i>	24
5.2.2. <i>Menu structure</i>	25
5.3. PROGRAMMABLE FEATURES DESCRIPTION	26
5.3.1. <i>Basic measurement settings</i>	26
5.3.2. <i>Analogue output</i>	28
5.3.3. <i>Digital output</i>	29
5.3.4. <i>Measurement optimization</i>	30
5.3.5. <i>Calculations</i>	32
5.3.6. <i>Service functions</i>	36
6. ERROR CODES.....	39
7. PilotREK W-100 PARAMETER TABLE.....	40
8. MENUMAP	42



*Thank you for choosing a NIVELCO instrument.
We are sure that you will be satisfied throughout its use!*

1. INTRODUCTION

Application

The **PiloTREK W-100** non-contact microwave level transmitters provide the most advanced, new generation measurement technique of the industrial process automation field. **PiloTREK** is an ideal solution of high precision level transmitting of liquids, slurries, dollops, emulsions and other chemicals in a wide range of application area, such as food industry, energy industry, pharmaceutical industry, chemical industry, and even in naval applications with mm accuracy range and high measuring stability.

PiloTREK is able to provide an excellent non-contact measurement solution for those substances which tend to steam, or for liquids with a gas layer. Since there is no need for a defined propagation medium in the case of microwaves, the **PiloTREK** is applicable in vacuum.

Operation principle

The reflection of the emitted microwave impulses is considerably depending on the relative dielectric constant of the measured medium. The essential condition of microwave level measurement is that the relative dielectric constant (ϵ_r) of the medium should be more than 1.9.

The operation of the non-contact microwave level transmitters is based on the measurement of the time of flight of the reflected signals, so-called Time Domain Reflectometry (TDR) method.

The propagation speed of microwave impulses is practically the same in air, gases and in vacuum, independently from the process temperature and pressure, so the measured distance is not affected by the physical parameters of medium to be measured.

PiloTREK level transmitter is a Pulse Burst Radar operating at 24 GHz (K-band) microwave frequency.

The 24 GHz models' most noticeable advantage over the lower frequency (5-12 GHz) radars are the smaller antenna size, the better focusing, lower dead-band and smaller transmission angle.

The level transmitter induces few nanosecond length microwave impulses in the antenna and a part of the energy of the emitted signals reflects back from the measurement surface depending on the measured media. The time of flight of the reflected signal is measured and processed by the electronics, and then this is converted to distance, level or volume proportional data.

2. ORDER CODES

Not all combinations possible!

PiloTREK		W	□	□	-	1	□	□	-	□				
FUNCTION	CODE		ANTENNA / HOUSING MATERIAL	CODE		ANTENNA / DIAMETER	CODE		PROCESS CONNECTION	CODE		OUTPUT / Ex	CODE	
Transmitter	E		1.4571 / Aluminium housing	S		DN40 Horn / 1½"	4		BSP	0		4 - 20 mA + HART / normal	4	
Transmitter + display	G		1.4571 / Plastic housing	M		DN50 Horn / 2"	5		NPT	N		4 - 20 mA + HART / Ex	8*	
High temperature transmitter	H		PP / Plastic housing	P		DN80 Horn / Flange	8		DN 80 PN25	2				
High temperature transmitter + display	J								DN 100 PN25	3				
									DN 125 PN25	4				
									DN 150 PN25	5				
									DN 80, PP	6				
									DN 100, PP	7				
									DN 125, PP	8				
									DN 150, PP	9				
									3" RF 150 psi	A				
									4" RF 150 psi	B				
									5" RF 150 psi	C				
									6" RF 150 psi	D				
									3" RF, PP	E				
									4" RF, PP	F				
									5" RF, PP	G				
									6" RF, PP	H				
ACCESSORIES:		ORDER CODES												
PP antenna enclosure with 1½" BSP threaded process connection		WAP-140-0												
PP antenna enclosure with 1½" NPT threaded process connection		WAP-14N-0												
PP antenna enclosure with 2" BSP threaded process connection		WAP-150-0												
PP antenna enclosure with 2" NPT threaded process connection		WAP-15N-0												
PTFE antenna enclosure with DN50 (2") TRICLAMP process connection		WAT-14T-0												
PTFE antenna enclosure with DN50 (2") Pipe coupling process connection		WAT-14R-0												

* Approval is pending





3. TECHNICAL DATA

TYPE	PLASTIC HOUSING WOM-1□□-□, WOP-1□□-□	ALUMINIUM HOUSING WOS-1□□-□	HIGH TEMPERATURE VERSION WH-1□□-□, WJ-1□□-□
Measured values		Level, distance	
Calculated values		Volume, mass	
Measured media		Liquids	
Frequency of the measuring signal		~24 GHz (K band)	
Minimal measuring range			
Maximal measuring range			
Material of wetted parts			See chapter 3.1
Process connection			
Beam angle			
Minimal ϵ_r of the medium			
Maximal medium pressure (depending on the antenna)	3 bar (at 25 °C)		25 bar (at 120 °C)
Medium temperature	-25 ... + 80 °C	-30 ... + 100 °C (up to max. 2 min.: 120 °C) with PP antenna enclosure: max.: 80 °C	-30 ... + 180 °C
Ambient temperature		20 ... +60 °C	
Linearity error (as per EN 61298-2)	Depending on the measured distance: < 0.5m: ± 15 mm, 0.6m - 1 m: ± 8 mm, 1-8 m: ± 3 mm, > 8 m: $\pm 0.04\%$ of the measured distance		
Resolution		1 mm	
Temperature error (as per EN 61298-3)		0.05% FSK / 10 °C (-20 ... +60 °C)	
Output	Analogue	4 - 20 mA (3.9 - 20.5 mA)	
	Digital communication	HART (minimal terminal resistor: 250 Ohm)	
	Display	SAP-300 graphical display unit	
Damping time		Selectable: 0 ... 99 sec	
Measuring frequency		10...60 sec as per the application settings	
Error indication		Output = 22 mA or 3.8 mA	
Output load		$R_i = (U_i - 20V) / 0.022 A$, U_i = power supply voltage	
Power supply voltage		20 V ... 36 V DC, Ex: 20 V ... 28 V DC	
Electrical protection		Class III.	
Ingress protection		IP 67	
Electrical connection	2x M 20 x 1.5 cable glands + internal thread for 2x $1\frac{1}{2}$ " NPT cable protective pipe, cable outer diameter: $\varnothing 7...13$ mm, cross section: max. 1.5 mm^2		
Housing material	Plastic (PBT)	Paint coated aluminium (EN AC 4200)	
Sealing	Viton, EPDM		
Mass	1-1.6 kg	2-2.6 kg	-

3.1. DIMENSIONS AND SPECIAL DATA OF THE ANTENNA VARIATIONS


ALUMINIUM HOUSING, 1½" HORN ANTENNA WES-140-□, WGS-140-□, WES-14N-□, WGS-14N-□	ALUMINIUM HOUSING, 2" HORN ANTENNA WES-150-□, WGS-150-□ WES-15N-□, WES-15N-□	PLASTIC HOUSING, 1½" HORN ANTENNA WEM-140-□, WGM-140-□, WEM-14N-□, WGM-14N-□	PLASTIC HOUSING, 2" HORN ANTENNA WEM-150-□, WGM-150-□ WEM-15N-□, WGM-15N-□

* L_{MIN} is according to the drawings


ALUMINIUM HOUSING, 1½" ANTENNA WITH PP ENCLOSURE WES-140-□, WGS-140-□ + WAP-140-0, WAP-14N-0	PLASTIC HOUSING, 1½" PP ENCAPSULATED ANTENNA WEP-140-□, WGP-140-□ WEP-14N-□, WGP-14N-□	ALUMINIUM HOUSING, 2" ANTENNA WITH PP ENCLOSURE WES-150-□, WGS-150-□ + WAP-150-0, WAP-15N-0	PLASTIC HOUSING, 2" ANTENNA WITH PP ENCLOSURE WEM-150-□, WGM-15N-□ + WAP-150-0, WAP-15N-0
			
Material of wetted parts	PP	PP	PP
Process connection	1½" BSP, 1½" NPT	1½" BSP, 1½" NPT	2" BSP, 2" NPT
Measuring range ($\epsilon_r = 4 \dots 10$) [*]	0.2 ... 10m	0.2 ... 10m	0.2 ... 16m
Measuring range ($\epsilon_r > 10$) [*]	0.2 ... 16m	0.2 ... 16m	0.2 ... 20m

* L_{MIN} is according to the drawings


**ALUMINIUM HOUSING, 2" TRICLAMP
ANTENNA WITH PTFE ENCLOSURE,
HYGIENIC VERSION
WES-140-□, WGS-140-□
+ WAT-14T-0**




**PLASTIC HOUSING, 2" TRICLAMP
ANTENNA WITH PTFE ENCLOSURE,
HYGIENIC VERSION
WEM-140-□, WGM-140-□
+ WAT-14T-0**



**ALUMINIUM HOUSING, DN50 PIPE COUPLING
ANTENNA WITH PTFE ENCLOSURE,
HYGIENIC VERSION
WES-140-□, WGS-140-□
+ WAT-14R-0**




**PLASTIC HOUSING, DN50 PIPE COUPLING
ANTENNA WITH PTFE ENCLOSURE,
HYGIENIC VERSION
WEM-140-□, WGM-140-□
+ WAT-14R-0**



Material of wetted parts	1.4571, PTFE	1.4571, PTFE	1.4571, PTFE	1.4571, PTFE
Process connection	2" TRICLAMP	2" TRICLAMP	DN50 Pipe coupling (MILCH)	DN50 Pipe coupling (MILCH)
Measuring range ($\epsilon = 4 \dots 10$)*	0.2 ... 10m	0.2 ... 10m	0.2 ... 10m	0.2 ... 10m
Measuring range ($\epsilon > 10$)*	0.2 ... 16m	0.2 ... 16m	0.2 ... 16m	0.2 ... 16m

* L_{MN} is according to the drawings


**ALUMINIUM HOUSING,
HORN ANTENNA WITH FLANGE
WES-18□-□, WGS-18□-□**




Material of wetted parts	1.4571, PTFE
Process connection	Flange
Beam angle (-3dB)	11°
Measuring range ($\epsilon = 1,9 \dots 4$) [*]	0.2 ... 15m
Measuring range ($\epsilon = 4 \dots 10$) [*]	0.2 ... 23m
Measuring range ($\epsilon > 10$) [*]	0.2 ... 23m

* L_{MIN} is according to the drawings


**HIGH TEMPERATURE VERSION,
ALUMINIUM HOUSING,
1½" HORN ANTENNA
WHS-140-□, WHS-140-□,
WJS-14N-□, WJS-14N-□**




**HIGH TEMPERATURE VERSION,
ALUMINIUM HOUSING,
2" HORN ANTENNA
WHS-150-□, WHS-150-□,
WJS-15N-□, WJS-15N-□**



**HIGH TEMPERATURE VERSION,
ALUMINIUM HOUSING,
HORN ANTENNA WITH FLANGE
WHS-18□-□, WJS-18□-□**



**HIGH TEMPERATURE VERSION,
ALUMINIUM HOUSING, 2" TRICLAMP
ANTENNA WITH PTFE ENCLOSURE,
HYGIENIC VERSION
WHS-140-□, WJS-140-□
+ WAT-14T-0**



Material of wetted parts	1.4571, PTFE	1.4571, PTFE	1.4571, PTFE	1.4571, PTFE
Process connection	1½" BSP, 1½"NPT	2" BSP, 2"NPT	Flange	2" TRICLAMP
Beam angle	19°	16°	11°	
Measuring range ($\epsilon_r = 1.9 \dots 4$)*	0.2 ... 4.5m	0.2 ... 7m	0.2 ... 15m	
Measuring range ($\epsilon_r = 4 \dots 10$)*	0.2 ... 12m	0.2 ... 18m	0.2 ... 23m	0.2 ... 10m
Measuring range ($\epsilon_r > 10$)*	0.2 ... 18m	0.2 ... 23m	0.2 ... 23m	0.2 ... 16m

* L_{MIN} is according to the drawings

3.2. ACCESSORIES

- User's and Programming Manual
- Warranty Card
- Declaration of Conformity
- 2 pcs M20x1.5 cable glands
- Sealing (Klinger® Oilit) only for BSP threaded process connections

3.3. CONDITIONS OF SAFE OPERATION

To avoid the danger of electrostatic charge accumulation, in case of the **W□P**, **W□M** types (with plastic electronic housing or plastic antenna enclosure) the following safety rule shall be observed:

- The measured medium should be an electrostatic conductor, and the electrical resistivity of the measured medium cannot exceed $10^4 \Omega\text{m}$.
- The speed and the method of the filling and emptying process should be chosen properly according to the measured medium.

Meeting the requirements of the technological process

Please carefully consider that all parts of the instrument which possible to come into contact with the measured medium – including the transducer, the sealing and any other mechanical parts – should meet all requirements of the applied technological process, such as the process pressure, temperature and chemical effects of the used technologies.

FCC Radio license

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment.

3.4. REPAIR AND MAINTENANCE

PiloTREK does not require maintenance on a regular basis.

Repairs during or after the warranty period are carried out exclusively at the Manufacturer.

The equipment sent back for repairs should be cleaned or neutralised (disinfected) by the User!

4. INSTALLATION

4.1. MOUNTING

When choosing the installation place please ensure proper space for later calibrations, verification or maintenance service.


PLACEMENT

The ideal position for the PiloTREK is on the $r = (0.3 \dots 0.5) R$ (in case of cylindrical tank).

It is highly recommended to consider the beam cone on the 1st page drawing.

The distance between the sensor and the tank wall should be at least 200 mm.


If the unit is installed into dome top or spherical tank, unwanted multiple reflections may appear.



POLARIZATION PLANE

The emitted radar impulses of PiloTREK are electromagnetic waves. The orientation of the polarization plane is the same as for the electric wave component of the electro-magnetic wave. The rotation of the polarization plane compared to the tank position could be useful (for example to avoid disturbing reflections) in certain applications.




To rotate the polarization plane loosen the M6 hex socket set screw above the process connection and rotate the instrument. Then tighten the unit by the screw.



MOVING LIQUID SURFACE


Waving, vortex or strong vibration effects can have negative influence on the measurement accuracy. To avoid these effects, the mounting placement should be as far as possible from the sources of these disturbing effects.

For example the device should be mounted as far as possible from the filling stream or the tank outlet.



FOAMING

Filling, stirring or any other processes in the tank can generate dense foams on the liquid surface, which may considerably damp the reflected signals. According to NIVELCO's experience, in these cases the maximal measurement range decreases by at least approximately by 50%.




FUMES, VAPOURS

If the measured medium or its foam reaches the antenna or a highly fuming measured medium can form deposits on the sensor, it may result unreliable level measurement.


SENSOR ALIGNMENT

The antenna face should be parallel to the medium surface within $\pm 2\text{--}3^\circ$.



TEMPERATURE


To avoid overheating the instrument should be protected against direct sunshine.



OBSTACLES


Make sure that no objects (cooling pipes, bracing elements, thermometers, etc.) cross the microwave signals and the instrument has clean view on the medium to be measured. Especially in case of extraordinary large silos bracing elements and other structural obstacles may cause false reflections which can be damped in most cases: a small bent metal deflector plate mounted above the obstacle can disperse the microwave signals and eliminates the false reflections which disturb the reliable measurement.

If there is no possible mechanical solution to avoid these kinds of false reflections, the programming of the instrument allows blocking out the obstacles. (see: 5.3.4.5)



SOCKET

The process connection should be dimensioned that the antenna end should protrude at least 10 mm out of the socket.



4.2. WIRING

The instrument operates from 20 ... 36 V galvanic isolated and not grounded DC power supply in two-wire system. (For Ex version: 20 ... 28 V DC!)

The voltage value measured on the terminal of the instrument should be minimum 20 V (in case of 4mA)! In case of using HART interface – to achieve proper communication between the transmitter's interface and the power-supply – a minimal 250 Ohm resistance should be maintained within the network. The instrument should be wired with shielded cable led through the cable gland. The wiring of cables can be done after removing the cover of the instrument and the SAP display unit.

IMPORTANT: The housing of the transmitter should be grounded to the equipotential network. Resistance of the EP network should be $R \leq 2 \text{ Ohm}$ measured from the neutral point. Shielding of the cable should be grounded at the control room side to the EP network. To avoid disturbing noises, keep away of closeness to high-voltage cables. Especially the inductive couplings of AC harmonics can be critical (which are present at frequency converter control) because even cable shielding does not supply effective protection against these cases.





The instrument may be damaged by electrostatic discharge (ESD) via its terminal, thus apply the precautions commonly used to avoid electrostatic discharge e.g. by touching a properly grounded point before removing the cover of the enclosure.
A possible electrostatic discharge can cause damage for the instrument. Do not touch the internal terminals!


WATER / VAPOUR

To achieve suitable ingress protection NIVELCO recommends using the suggested cable outer diameter (see technical data table in the 3rd chapter) and fasten properly the cable gland.


NIVELCO also recommends leading the connecting cables downwards to lead aside the rain water and the condensed water. This is needed in case of outside installations and some special applications where there is very high humidity or the possibility of water condensation is quite high (for example in cleaning, purification processes, in cooled and / or heated tanks).




4.2.1. Wiring of Compact instruments



Using HART communication
in non-Ex environment



Using Ex approved instrument
in hazardous environment



Using MultiCONT process controller
with Ex approved instrument
in hazardous environment

4.3. LOOP CURRENT CHECKING WITH HAND INSTRUMENT

After removing the cover and the Display Module, the actual loop current can be measured throughout an internal 1 Ohm shunt resistor by connecting a voltmeter (in the range of 200 mV) to the points 2 and 5 indicated on the wiring drawing above.

5. PROGRAMMING

The PiloTREK transmitters can be programmed (basically) with the following two ways:

- **Programming with the SAP-300 display unit (see 5.2)**

All features of the unit can be accessed and all parameters can be set, such as measurement configuration and optimisation, outputs, dimensions for 11 tanks with different shape, 99-point linearization.

- **Programming with MultiCONT process controller or EView2 PC configuration software**

The PiloTREK WG□ and WJ□ types include the SAP-300 display unit.

The PiloTREK transmitters are fully operational without the SAP-300 display as well, it is only needed for local programming and / or local measurement displaying.

FACTORY DEFAULT SETTING

The PiloTREK W-100 series level transmitters are factory programmed by the following way:

- ⇒ Measurement mode: Level (LEV). The displayed value is the measured level.
- ⇒ The current output and the bargraph on the right are proportional to the measured level.
- ⇒ 4 mA and 0% are assigned to zero level.
- ⇒ 20 mA and 100% are assigned to the maximal level.
- ⇒ Error indication by the current output: holding the last value.
- ⇒ Level tracking time constant: 0 sec.

The instrument regards the distance (DIST) measured from the antenna end as the basic measurement value. This distance is handled and display in one of the selected dimensions: m, cm, mm, feet, or inch. Since the maximal measurement distance is given (entered in P04) the instrument can calculate the actual level (LEV) value. If the proper mechanical dimensions of the mounting – distance between the sealing and the tank bottom – is known, the measured level values can be more accurate by adding this data. The level values calculated that way are the base for volume (VOL) calculation and the 99-point linearization table (VMT) also uses these values as input data.

5.1. THE SAP-300 DISPLAY UNIT

5.1.1. Primary Measurement Screen

The SAP-300 is a 64x128 dot-matrix LCD display which can be plugged into the transmitter. (It is universal – usable in other NIVELCO devices as well – provided that the system software supports SAP-300.)

Warning!

The SAP-300 module is based on LCD technology, so please make sure it is not exposed to permanent heat or direct sunlight, in order to avoid damage of the display unit. If the instrument cannot be protected against direct sunlight or high temperature that is beyond the standard operating temperature range of the SAP-300, please do not leave the SAP display in the instrument.




Measurement displaying with the SAP-300 display unit

Elements of the displaying:

- 1, Primary (Measured) Value (PV), in accordance to BASIC SETUP / PV. MODE.
- 2, Calculation mode of Primary Value (PV), in accordance to BASIC SETUP / PV. MODE.
- 3, Type and value of the initial quantity used for calculating the Primary Value (PV):
 - in case of Level measurement (LEV) it is Distance (DIST),
 - in case of Volume measurement (VOL) it is Level (LEV).
- 4, Trend direction arrows. The empty triangle shows when the change of the measured value is small, the filled triangle shows large-scale change. If none of the arrows are shown the measured value is constant.
- 5, Measured PV (Distance Value) in relation to measurement range (Sensor range) displayed in a bargraph.
- 6, Indication of Primary Value simulation. In this case the display and output show the values of the simulation and not the measured values.
- 7, Indication of active (Volume / Mass Table - VMT) calculation mode.

During active simulation the critical measurement errors will be displayed to give information to the user.



A, Calculated value of the output current.

After the dimension, the mode of current output is indicated by inverse inscription:

M

Manual mode (see 5.3.2.1)

H

HART address is not 0, so output current has become overwritten to 4mA (see 5.3.2.1)

E !

Analogue transmission reacts to a programmed failure condition
if an upper or lower fault current is programmed (see 5.3.2.4)

B, Output range (4-20mA) indicated in a bargraph.

The bottom of the bargraph is assigned to 4mA and the top is assigned to 20mA.

C, Indication of Menu Lock:

- If key symbol is visible, the unit is protected with a password. When entering the menu, the instrument asks for the correct password (see 5.3.6.1).
- If REM message is visible, the instrument is in remote programming mode and the main menu cannot be accessed.

Errors occurred during the measurement can be seen at the bottom line of the display.

5.1.2. Information Screens

Press  button to cycle between the information displays:

1. General information display (DEV. INFO)

Overall running time (OV. RUN TIME)

Run time after power on (RUN TIME)

Type of interface (INTERFACE) in the instrument.

Type of the instrument (TYPE)

2. Sensor information: (SENSOR INFO)

Number of echoes (ECHO TOT/SEL)

Blocking (BLOCKING)

Signal-to-noise ratio (SN)

Temperature (TEMP)


3. Echo table: (ECHO TABLE)

The informative screen returns back to main screen after 30 seconds.

By pressing the  button the user can return to the main screen any time.

Pressing the  button in any of the screens the user can enter the main menu.

After exiting the menu always the main screen will be shown.



5.1.3. Echo Map

Pressing the  button in the measurement screen the echo map screen will appear. This screen shows the following information:


1. Echo diagram
2. Actual measured distance
3. Maximal measuring range

The echo map screen returns back to main screen after 30 seconds.

By pressing the  button the user can return to the main screen any time.

Pressing the  button in any of the screens the user can enter main menu.

After exiting the menu always the main screen will be shown.



5.2. PROGRAMMING WITH THE SAP-300 DISPLAY MODULE

When entering the menu the instrument makes a copy of the actual parameters and all changes are done to this duplicated parameter set. During programming the instrument keeps measuring and transmitting with the current (and intact) parameter set. After exiting the menu the instrument replaces the original parameters with the new parameter set and will measure according to the new parameters. This means that the change of the parameters does not become immediately effective when pressing the \textcircled{E} button!

Entering the menu can be done by pressing the \textcircled{E} button, while exiting the menu can be done by pressing the $\textcircled{\leftarrow}$ button.

If the instrument is left in programming mode after 30 minutes it will automatically return to measuring mode. If the SAP-300 display is removed during programming the instrument immediately returns to measuring mode.

As programming with SAP-300 (manual programming) and HART (remote mode) programming is not possible at the same time, only one programming method could be chosen. Measured values can be read out through HART at any time.

5.2.1. Components of the programming interface

The parameters of the instrument are grouped according to their functions. The programming interface consists of lists, dialog windows, edit windows and report windows.

Lists

Navigation between the lines of a list can be done by pressing $\textcircled{\uparrow}$ / $\textcircled{\downarrow}$ buttons. Pressing the \textcircled{E} button activates a list item. Selected list item is marked with inverse colour. Exit from a list by pressing the $\textcircled{\leftarrow}$ button.


Menu list

Menu list is a specialized list. Its characteristic is that upon selecting a list item we directly get into another list, and these lists are opening from each other in different levels.

The menu header (1) helps to navigate.


Entering the main menu can be done by pressing the \textcircled{E} button. Navigation between the menu items can be done by pressing the $\textcircled{\uparrow}$ / $\textcircled{\downarrow}$ buttons. Enter to the selected menu by pressing the \textcircled{E} button. The selected list item is marked with inverse colour.

Exit from a submenu by pressing the $\textcircled{\leftarrow}$ button. Pressing the $\textcircled{\leftarrow}$ button in the main menu will quit from the programming mode and the instrument will return to measuring mode.



Dialog window

During the programming the system sends messages or warnings to the users by dialog windows. These usually can be acknowledged by pressing the \leftarrow button or the user can choose between two options (usually YES or NO) by pressing \leftarrow / \downarrow buttons. In some cases one of the parameters has to be changed to correct an error.



Edit window

An edit window is used for modifying a numeric parameter value. The selected character can be changed using the \leftarrow / \downarrow buttons. The cursor can be moved to left, using the \leftarrow button.

The direction of the cursor movement through the digits is right to left. Changed value can be validated by pressing the E button. The software checks if the entered value is appropriate, exiting the edit window is only possible after entering a correct value. If the entered value is uninterpretable the software sends an error message in the bottom line (1) of the display.

Edit window – button combinations



In the edit window the following button combinations are available:

1. - Recalling the parameters to the state before editing (\leftarrow + \uparrow , pressed for 3 secs);
2. - Recalling default parameters (\leftarrow + \downarrow , pressed for 3 secs);
3. - Inserting (currently) measured value to the edit window (\leftarrow + E , pressed for 3 secs)
Only for certain parameters!

5.2.2. Menu structure

Main menu

BASIC SETUP	Parameter group of the basic measurement parameters
OUTPUT SETUP	Parameter group of the output parameters
OPTIMIZATION	Parameter group for measurement optimization settings
CALCULATION	Calculations
SERVICE	Service functions, calibration, test and simulation



5.3. PROGRAMMABLE FEATURES DESCRIPTION

5.3.1. Basic measurement settings

5.3.1.1 Default unit system

Parameter:	P00: c, where c: 0, 1.	Default value:	EU
Path:	BASIC SETUP / UNITS / ENGINEERING SYSTEM		
Description:	This should be configured as the first step of the programming. Here you can choose the default unit system:		
<ul style="list-style-type: none">• EU European unit system• US Anglo-Saxon / American unit system			

5.3.1.2 Dimension of the default unit system

Parameter:	P00: b, and P02: b, or P02: c	Default value:	mm, m ³ , t
Path:	BASIC SETUP / UNITS / ENGINEERING UNITS		
Description:	The dimension of the selected default unit system can be specified in this menu. The selected measurement mode here will define the primary measured value and the displayed value, furthermore it will be the source for the current output.		
<ul style="list-style-type: none">• BASIC UNITS (m, cm, mm, ft, inch)• VOLUME / FLOW UNITS (m³, l, ft³, gallon)• MASS UNITS (t, t)• TOT UNITS (m³, l, ft³, gallon)• TOT UNITS (sec, min, hour, day)			

If the dimension is modified, the device resets all the parameters after a warning message.

5.3.1.3 Primary Value Mode

Parameter:	P01: b a	Default value:	DIST
Path:	BASIC SETUP / PV MODE		
Description:	This mode determines the primary value and the displayed value. It also determines the value which will be proportional to the output current.		
	<ul style="list-style-type: none">• DISTANCE• LEVEL• VOLUME• MASS		

5.3.1.4 Maximal Measuring Distance

Parameter:	P04	Default value:	
Path:	BASIC SETUP / MAX. MEAS.DIST		
Description:	This parameter should be entered all the cases, except distance measurement mode. But it is suggested to be programmed in case of distance measurements in order to avoid the disturbing effects of possible unwanted multiple reflections.		

5.3.1.5 Damping Time

Parameter:	P20	Default value:	0 sec
Path:	BASIC SETUP / DAMPING TIME		
Description:	Damping time is used to damp the unwanted fluctuations of the output and display. If the measured value changes rapidly the new value will settle with 1% accuracy after this set time. (Damping is according to the exponential function).		

5.3.1.6 Demo Mode

Parameter:	P00: d	Default value:	OFF
Path:	BASIC SETUP / DEMO MODE		

Description:

- OFF: The operation is performed with considering all the application parameters (such as filling, emptying speed, echo selection, etc..)
- ON: This fast operation mode ignores the application parameters. The demo mode uses a fast algorithm evaluation independently from P25, P26 and P27 parameters. The measurement accuracy and reliable operation between process environments are not guaranteed!

5.3.2. Analogue output

5.3.2.1 Output Current Mode

Parameter:	P12:b, where b: 0, 1.	Default value:	AUTO
Path:	OUTPUT SETUP / ANALOG OUTPUT / CURRENT MODE		
Description:	Transmission mode of the current output.		
	<ul style="list-style-type: none"> • AUTO The output current is calculated from the measured value, output is active. • MANUAL The output current is fixed at a constant (set) value (see 5.3.2.5). In this mode the setting of the error current is irrelevant. The set (current) value overwrites the 4mA output of HART multidrop mode! 		

5.3.2.2 Output Current Value assigned to 4mA

Parameter:	P10	Default value:	0 mm
Path:	OUTPUT SETUP / ANALOG OUTPUT / 4mA VALUE		
Description:	Measured value assigned to 4mA current value.		
	The transmitted value is in accordance to the primary value (PV) (P01:a). Assignment can be done that the change in measured value and the change in the output value are the same (normal), or opposite directional (inverse operation). For example: 1m level is 4 mA, 10m level is 20mA, or 1m level is 20mA and 10m level is 4mA.		

5.3.2.3 Output Current Value assigned to 20mA

Parameter:	P11	Default value:	
Path:	OUTPUT SETUP / ANALOG OUTPUT / 20mA VALUE		Maximal measurement range (mm)

Description: Measured value assigned to 20mA current value.
The transmitted value is in accordance to the primary value (PV) (P01: a). Assignment can be done that the change in measured value and the change in the output value are the same (normal), or opposite directional (inverse operation). For example: 1m level is 4mA, 10m level is 20mA, or 1m level is 20mA and 10m level is 4mA.

5.3.2.4 Output Current Error Mode

Parameter:	P12:a, where a: 0, 1, 2	Default value:	HOLD
Path:	OUTPUT SETUP / ANALOG OUTPUT / ERROR MODE		
Description:	Error indication by the current output: <ul style="list-style-type: none">• HOLD Error indication has no effect on the output current.• 3.8mA Error indication: the output current gets 3.8mA.• 22mA Error indication: the output current gets 22mA. Warning: This error indication is active unless the failure is fixed, or until the failure terminates.		

5.3.2.5 Fixed Output Current

Parameter:	P08	Default value:	4 mA
Path:	OUTPUT SETUP / ANALOG OUTPUT / MANUAL VALUE		
Description:	Parameter for setting the fixed output current: Values between 3.8 and 20.5 can be entered. The output current will be set to the entered value and analogue transmission will be suspended (see: 5.3.2.1). This error indication overrides all other error indication.		

5.3.3. Digital output

5.3.3.1 HART Polling Address

Parameter:	P19	Default value:	0
Path:	OUTPUT SETUP / SERIAL OUTPUT / ADDRESS		

Description:	HART Polling Address
	The polling address can be set between 0 and 15. For a single instrument the polling address is 0 and the output is 4-20mA (analogue output). If multiple units are used in HART Multidrop mode (max. 15 pcs.) the polling addresses should differ from 0 (1-15), in this case the output current will be fixed at 4mA.

5.3.4. Measurement optimization

5.3.4.1 Blocking, Dead Zone

Parameter:	P05	Default value:	200 mm
Path:	OPTIMIZATION / DEAD ZONE		
Description:	The instrument ignores all reflections within the dead zone and the close-end blocking distance. The disturbing objects and false reflections which are close to the sensor can be eliminated by entering the dead zone value manually.		

5.3.4.2 Echo Selection

Parameter:	P25:a, where a: 0, 1, 2, 3	Default value:	AUTO			
Path:	OPTIMIZATION / ECHO SELECTION					
Description:	Selection of Echo within the measuring window. In order to avoid disturbing reflections the instrument forms a so-called measuring window around the reflected signal. The distance measurement is performed with the echo signal within the measurement window. <ul style="list-style-type: none"> • AUTO • FIRST • HIGHEST AMPLITUDE • LAST 					

5.3.4.3 Emptying Speed

Parameter:	P27	Default value:	5000 m/h
Path:	OPTIMIZATION / EMPTYING SPEED		
Description:	This parameter provides additional protection against echo loss in applications involving very heavy fuming during emptying process. Correct setting increases the reliability of the measurement during the emptying. The parameter must not be smaller than the fastest possible emptying rate of the actual technology.		

5.3.4.4 Filling Speed

Parameter: P26

Default value: 5000 m/h


Path: OPTIMIZATION / FILLING SPEED

Description: This parameter provides additional protection against echo loss in applications involving very heavy fuming during filling process. Correct setting increases the reliability of the measurement during the filling. The parameter must not be smaller than the fastest possible filling rate of the actual technology.

5.3.4.5 Background Echo Image

Path: OPTIMIZATION / BACKG.ECHO IMAGE / SAVE BACKG. IMAGE

Description: Blocking out disturbing objects. The not-moving disturbing objects inside the tank which generates unwanted false reflections can be blocked out from the measurement range. For this purpose the instrument needs to map the totally empty tank to create a "background image". After this procedure the software will automatically recognise and ignore the reflections coming from the disturbing objects crossing the microwave beam (see 4.1 - Obstacles).



5.3.4.6 Using saved background image

Parameter:	P35: a, where a: 0, 1	Default value:	OFF
Path:	OPTIMIZATION / BACKG.ECHO IMAGE / SAVE BACKG: IMAGE		
Description:	Turning ON or OFF the usage of saved background image during the calculations as per the above 5.3.4.5 point described.		

- OFF: Ignoring the saved background image.
- ON: Saving background image, damping reflections coming from the disturbing objects.

5.3.4.7 Threshold value

Parameter:	P29	Default value:	3 dB
Path:	OPTIMIZATION / THRESHOLD VALUE		
Description:	Defining an upper limit value above the saved background image described in 5.3.4.5 point. The instrument will evaluate the measurement result as a real echo when the reflected signal exceeds the saved background level with the threshold value entered here. Setting the threshold value is useful when the level in the tank and the position of the (small surface) not-moving disturbing object are the same. This case the instrument will not regards the echo signal as false reflection.		

5.3.5. Calculations

5.3.5.1 Specific gravity

Parameter:	P32	Default value:	0
Path:	CALCULATION / SPECIFIC GRAVITY		
Description:	Entering a value (other than "0") of specific gravity in this parameter, the MASS value will be displayed instead of Volume (VOL) in the dimension of tonne or lb/tonne depending on P00 (c) and P02 (b).		

5.3.5.2 Volume / Mass Calculation Mode

Parameter:	P47: a	Default value:	0
Path:	CALCULATION / V/M CALC. MODE		
Description:	Calculation of the volume and mass can be performed with two ways:		

- TANK FUNCTION/SHAPE – volume and mass calculation with a tank shape formula. Entering this menu point the table is automatically OFF.
- V/M TABLE – volume and mass calculation with a table. Entering this menu point the table is automatically ON

5.3.5.3 Volume / Mass Table

Parameter:

Path: CALCULATION / V/M CALC. MODE / V/M TABLE

Description:

- VIEW/EDIT TABLE
- ADD ITEM
- DELETE ITEM

If none of the formulas match perfectly to the characteristics of the needed tank, there is a possibility to use table calculation mode. The device can handle a 99-point table on this purpose and counts values between the neighbouring point pairs with linear interpolation.

The input (left) side of the table contains the level data, the output (right) side contains the volume or mass data.

The first point pair of the table should be 0,0. If a long table wanted to be shortened, 0,0 point pair should be entered into the last item of the table and the device modifies the unused point pairs automatically in the background to 0,0.

The status (ON or OFF) of the table is shown on a warning message (1) on the bottom line of the display.

All modifications are done on a temporary table. This temporary table becomes valid after exiting.

Modifications during the programming procedure have no effect on the measurement and the transmitting.

Entering the point pairs can be done in arbitrary order, because the device sorts according to ascending order. Both sides of the table have to be strictly monotonic increasing. In case of any error, warning message (see: 6th chapter) will appear. When entering again the table an inscription indicates the first wrong line.

View table:





In VIEW/EDIT TABLE menu point items of the ordered table can be checked. For moving in the list use the \downarrow and \uparrow buttons, for editing the selected item use the \mathbb{E} button. Exiting from the list can be done by pressing the \mathbb{C} button.

Edit table:

Adding a point pair (ADD ITEM) to the list or pressing \mathbb{E} button on an existing item, an edit screen will appear. In this edit screen there are two editing fields. Both editing field works as same as editing a parameter. Getting from the first field to the second field press the \mathbb{E} button. Pressing \mathbb{E} button in the second field will return back to the previous menu point. When exiting from the last field, the device performs the ordering of the table.

Delete item

Moving in the list can be done with \downarrow and \uparrow buttons, for deleting an item press the \mathbb{E} button on the selected item. Exiting from the list can be done by pressing the \mathbb{C} button. The table should contain at least 2 items.



5.3.5.4 Tank Functions / Shape

Parameter:	P40: a, where a: 0,1, 2, 3, 4.	Default value:	0
Path:	CALCULATION / V/M CALC. MODE / TANK FUNCTION/SHAPE		
Description:	<ul style="list-style-type: none">• STANDING CYL.: Standing cylindrical tank• STD. CYL. CON. BOT.: Standing cylindrical tank with conical bottom• STD. RECT. W/CHUTE: Standing rectangular tank with or without chute• LYING CYLINDRICAL: Lying cylindrical tank• SPHERICAL: Spherical tank		

5.3.5.5 Tank Bottom Shape


Parameter:	P40: b, where b: 0,1, 2, 3	Default value:	0
Path:	CALCULATION / V/M CALC. MODE / TANK FUNCTION/SHAPE		
Description:	This menu only appears, if it has an importance on the selected tank shape type!		

- SHAPE0
- SHAPE1
- SHAPE2
- SHAPE3


5.3.5.6 Tank Dimensions

Parameter:	P41- P45	Default value:	0
Path:	CALCULATION / V/M CALC. MODE / TANK FUNCTION/SHAPE		
Description:	<ul style="list-style-type: none">• DIM1 (P41)• DIM2 (P42)• DIM3 (P43)• DIM4 (P44)• DIM5 (P45)		


Standing cylindrical tank with hemispherical bottom $a = 0$



Standing cylindrical tank with conical bottom $a = 1$; $b = 0$




Standing rectangular tank with or without chute $a = 2$; $b = 1$




If no chute: P43, P44 and P45 = 0

Lying cylindrical tank $a = 3$



Spherical tank $a = 4$; $b = 0$



5.3.6. Service functions

5.3.6.1 Security Codes

User codes

Path: SERVICE / SECURITY / USER LOCK
Description: Setting or unlocking the user security code.
The instrument can be protected against unauthorized programming with a 4 digit PIN (Personal Identification Number) code. If either of the digits differs from 0 the code is active. If zero is specified, then the secret code has been deleted!
In case of Active code, this code is requested at menu entry.

Service code

Path: SERVICE / SECURITY / SERVICE LOCK
Description: Setting of the service code.
Only for trained personnel!

5.3.6.2 Current Output Test


Parameter: P80
Path: SERVICE / OUTPUT TEST / ANALOG OUTPUT / CURRENT VALUE
Description: Loop current test (mA)
Entering this Parameter the current value which is proportional to the actual measurement value will appear on the display and the output. In loop current test mode, values between 3.9 and 20.5 can be entered. The output current will be set to the entered value. The measured current on the output should be equal to the set value.
In test mode a dialog window warns the user of the fixed output current until the user exits the warning message window.
Exiting can be done by pressing the  button.

5.3.6.3 Distance Simulation

This function facilitates the user to be able to check the calculations (tank formula, table), outputs, and the additional processing instruments connected to the output. PiloTREK transmitters can perform simulation on the value of a constant or a variable. To start simulation the instrument must return to Measurement mode. In Measurement mode if simulation is in progress, an inverse SIM caption appears on the display.

Simulation mode

Parameter:	P84:a, where a: 0,1, 2, 3, 4	Default value:	OFF
Path:	SERVICE / DIST SIMULATION / MODE		
Description:	Simulation mode:		
	OFF	No simulation	
	FIX VALUE	Value of the simulated distance is set according to the lowest value of the simulation.	
	MANUAL VALUE	
	TRIANGLE WAVE	Value of the simulated distance changes linearly between the lowest and highest values with an adjustable cycle time.	
	SQUARE WAVE	The simulated value jumps between the lowest and highest values with an adjustable cycle time.	



Simulation cycle

Parameter:	P85	Default value:	60 sec
Path:	SERVICE / DIST. SIMULATION / TIME		
Description:	Cycle time of the simulation		

Bottom value of the simulation

Parameter:	P86	Default value:	0 mm
Path:	SERVICE / DIST. SIMULATION / BOTTOM VALUE		
Description:	Lowest value of the simulation		

Upper value of the simulation

Parameter:	P87	Default value:	Programmed measurement range
Path:	SERVICE / SIMULATION / UPPER VALUE		
Description:	Highest value of the simulation		

5.3.6.4 Load Default Values

Path: SERVICE / DEFAULTS / LOAD DEFAULT

Description: This command loads all default values of the instrument.

After loading the default values the parameters can freely be changed, the effect of the changes does not affect on the measurement until the user exits from the Programming mode and returns to Measurement mode. Before loading the defaults the software asks for a confirmation from the user because all user parameters will be lost!

6. ERROR CODES

MESSAGE ON THE SCREEN	ERROR DESCRIPTION	PROCEDURE TO DO	CODE
MEMORY ERROR	Memory error in the electronics	Contact the service!	1
NO INPUT SIGNAL	Sensor error	Contact the service!	2
EE COM. ERROR	Hardware error (EEPROM communication error)	Contact the service!	3
MATH. OVERLOAD	Display overflow	Check the programming!	4
SIGNAL IN N.D.B.	Sensor or calibration error (Measured value is in the close-end dead-zone)	Contact the service!!	5
SIGNAL IN F.D.B.	Sensor or calibration error (Measured value is in the far-blocking zone)	Check the installation conditions!	7
VMT SIZE ERROR	Linearization error: Less than two items are in the table.	Check the content of the VMT! See: 5.3.5.3.	12
VMT INPUT ERROR	Linearization table error: monotonicity error in the input (level) side of the table.	Check the content of the VMT! See: 5.3.5.3.	13
VMT OUTPUT ERROR	Linearization table error: monotonicity error in the output (volume or mass) side of the table.	Check the content of the VMT! See: 5.3.5.3.	14
VMT INPUT OV.RNG.	Linearization table error: The measured level is greater than the highest level of the table's input side.	Check the content of the VMT! See: 5.3.5.3. Device performs extrapolation according to the last point pairs!	15
EE CHK ERROR	Parameter checksum error.	Check the programming! For recalculate the checksum modify a parameter and return to Measurement mode. If this error still remains, contact the service!	16
INTEGRITY ERROR	Incorrect parameter values. Stored parameters are damaged. (Automatically corrected internal error). Only WARNING message.	Check the programming!	17
AC COM. ERROR	Hardware error	Contact the service!	18
CALIBRATION ERROR	Sensor calibration error	Contact the service!	

7. PiloTREK W-100 PARAMETER TABLE

Pxx	Parameter name	d	c	b	a
00	Engineering system, dimensions	DEMO mode 0 = Normal mode 1 = Demo mode	Engineering system: 0 = EU 1 = US	Dimension: (EU) 0 = m, 1 = cm, 2 = mm (US) 0 = ft, 1 = inch	
01	Source of Primary Value (PV)				0 = DIST, 1 = LEVEL, 2 = VOLUME, 3 = MASS
02	Applicable dimensions	TOT units: (TOT-EU) 0 = m ³ , 1=litre (TOT-US) 0 = ft ³ , 1 =US gallon	Time units: 0 = sec 1 = min 2 = hour 3 =day	(VOL/F-EU) 0 = m ³ , 1=litre (VOL/F-US) 0 = ft ³ , 1 = US gallon (MASS-EU) 0 = tonne, 1= US tonne (MASS-US) 0 = tonne, 1 =lb(pound)	Temperature unit: 0 = °C
04	Max. measuring distance	FLOAT			
05	Blocking / DEAD ZONE	FLOAT			
08	Fix current output	FLOAT (3.8-22 mA)			
10	4mA	FLOAT			
11	20mA	FLOAT			
12	Output current mode			Operation mode: 0= AUTO 1= MANUAL	Error indication of the current output: 0 = HOLD 1 = 3.8mA 2 = 22mA
19	HART polling address	ULONG			
20	FILTER (damping time)	ULONG (0-999 sec)			
25	Echo selection in the measuring window				0 = AUTO 1 = FIRST 2 = HIGHEST AMPLITUDE 3 = LAST
26	Filling speed	FLOAT			
27	Emptying speed	FLOAT			
29	Threshold value	FLOAT (0 - 6 dB)			
32	Specific gravity of the medium	FLOAT			

35	Background mode				Background echo processing mode: 0 = OFF 1 = ON
40	Tank shape				0 = Standing cylindrical tank with dome bottom 1 = Standing cylindrical tank with conical bottom 2 = Standing rectangular tank with or without chute 3 = Lying cylindrical tank 4 = Spherical tank
41-45	Tank dimensions				
47	VMT mode				Operation of the linearization: 0 = OFF, 1 = ON
60	Overall runtime	ULONG			
61	Runtime after last reset	ULONG			
70	Number of echoes	ULONG			
71	Position of the measuring window	ULONG			
74	Singal-to-noise ratio	FLOAT			
75	Blocking distance value	FLOAT			
80	Current output test	FLOAT (3.8-22 mA)			
84	Simulation				Distance simulation mode: 0 = No simulation 1 = Fix value 2 = Simulation with a manual value: PV=a entered in P86 3= Simulation between P86 and P87 levels with P85 cycle time (triangle wave) 4= Simulation between P86 and P87 levels with P85 cycle time (square wave)
85	Cycle time of DIST simulation	ULONG [sec]			
86	Bottom value of the simulation	FLOAT			
87	Upper value of the simulation	FLOAT			

8. MENUMAP

