

Wireless Pushbutton

Model WP-3010 / WP-2024 / WP-2012 / WP-2014 / WP-2036

This package contains:

- Decorative Slimline wireless doorbell pushbutton
- CR2032 Lithium coin cell battery
- Adhesive pad, 2 screws and 2 wall plugs for installing the doorbell pushbutton

You will require:

- A small Phillips head and Flat head screwdriver

Installation Instructions

Please note: Installing the pushbutton on or near metal structures or reinforced PVC doors or doorframes may reduce the transmission range.

Open the doorbell pushbutton as shown in Figure 1.



Remove the front cover by inserting a flat blade screwdriver into the slot and twisting gently (A).

Install the battery (Refer to Figure 2)

Position the front cover as shown and slide the CR 2032 Lithium battery into the holder as shown, with the + side of the battery facing you.


Automatic Programming

Do not hold the doorbell pushbutton in your hand while programming or testing as this can reduce transmission range.




Basic Battery WD-1120 & Basic Plug-in WD-1140

1. Reset the chime by pressing and holding button A until the chime sounds.
2. Program the **Front Doorbell pushbutton** by pressing the Front Doorbell pushbutton, the chime will respond with a chime.
3. Program the **Back Doorbell pushbutton** by pressing the Back Doorbell pushbutton, the chime will respond with a chime. **This must be completed within 2 minutes of programming the Front Doorbell pushbutton or the chime will not accept it.** If this happens you will need to *Reset the chime programming. Please repeat step 1 to reset the chime programming.*




Musical Chime WD-6502

1. Reset the chime base by pressing and holding button A until the chime sounds.
2. Program the **Front Doorbell pushbutton** by pressing the Front Doorbell pushbutton, the chime will respond with a chime.
3. Program the **Back Doorbell pushbutton** by pressing the Back Doorbell pushbutton, the chime will respond with a chime. **This must be completed within 2 minutes of programming the Front Doorbell pushbutton or the chime will not accept it.** If this happens you will need to *Reset the chime programming. Please repeat step 1 to reset the chime programming.*




Wireless chime WD-2408, WD-2810, WD-2820, WD-2830, PC7520, PC7670, PC7690, PC7710, PC5870, PC5610, PC5527 and PC5810

1. Press and hold button B on chime until a triple bi-tone is heard. This indicates the chime is in the program mode for the Back Doorbell pushbutton.
2. Program the **Back Doorbell pushbutton** by pressing the Back Doorbell pushbutton, the chime will respond with a chime. **This must be completed within 2 minutes or the chime will not accept it.** If this happens you will need to *Reset the chime programming. Please repeat step 1 to reset the chime programming.*




Big Ben WD-4021

1. Press and hold button B on chime until a triple bi-tone is heard. This indicates the chime is in the program mode for the Back Doorbell pushbutton.
2. Program the **Back Doorbell pushbutton** by pressing the Back Doorbell pushbutton, the chime will respond with a chime. **This must be completed within 2 minutes or the chime will not accept it.** If this happens you will need to *Reset the chime programming. Please repeat step 1 to reset the chime programming.*



Plug-in WD-2041, WD-2042 & WD-2044

1. Press and hold button B on chime until a triple bi-tone is heard. This indicates the chime is in the program mode for the Back Doorbell pushbutton.
2. Program the **Back Doorbell pushbutton** by pressing the Back Doorbell pushbutton, the chime will respond with a chime. **This must be completed within 2 minutes or the chime will not accept it.** If this happens you will need to *Reset the chime programming. Please repeat step 1 to reset the chime programming.*



Sound Selection

Please refer to the Door Chime instruction manual.

Install the Pushbutton (Figure 4)

Ensure the wall surface is clean and dry. Install the base using either the double-sided adhesive pad on a smooth surface, or the screws and wall plugs provided. Do not install on or near large metal objects, as this can block signals from the wireless pushbutton.




Figure 4

Hook the top of the pushbutton over the base as shown in Figure 5 and then press down at the base to snap in place.




Figure 5

Note:

This device complies with part 15 of FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. To comply with FCC RF exposure requirements, this device and its antenna must not be co-located or operated in conjunction with any other antenna or transmitter.

Troubleshooting

Chime doesn't sound when pushbutton is pressed
Check that the battery has been inserted correctly. The doorbell pushbutton LED light should come on when the pushbutton is pressed.
Doorbell pushbutton may be positioned out of range of the door chime. Move the door chime closer to the pushbutton. Note: During the programming cycle, the transmission range may be reduced and will resume optimum range after 2 minutes.
A metallic object may be blocking the signal to the door chime from the pushbutton position. Experiment with the location of the door chime to see if you can move it to a more suitable place.
Battery in the pushbutton may need replacing. See instruction for installation of battery. Note: In cold conditions, poor location or environment, operating at maximum range it is advisable to replace the battery more frequently (i.e. every 12-18 months) to maintain optimum performance.
For any other problem, call 1-800-296-1869 Mon-Fri between 9 a.m. and 5 p.m. EST.

IQ America Two Year Warranty

This is a "Limited Warranty" which gives you specific legal rights. You may also have other rights which vary from state to state and province to province. For a period of two years from the date of purchase, any malfunction caused by factory defective parts or workmanship will be corrected at no charge to you. To obtain a refund or replacement, return the product to the place of purchase. NOT COVERED: Repair service, adjustment and calibration due to misuse, abuse or negligence. Unauthorized service or modification of the product or of any furnished component will void this warranty. This warranty does not include reimbursement for inconvenience, installation, setup time, loss of use or unauthorized service. This warranty covers only IQ America products and is not extended to other equipment and components that a customer uses in conjunction with our products. This warranty is expressly in lieu of all other warranties, express or implied, including any warranty, representation or condition of merchant ability or that the products are fit for any particular purpose or use, and specifically in lieu of all special, indirect or incidental or consequential damages. Repair or replacement shall be the sole remedy of the customer and there shall be no liability on the part of IQ America for any special, indirect, incidental or consequential damages, including but not limited to any loss of business or profit, whether or not foreseeable. Some states or provinces do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. Retain receipt for warranty claims.