

K92

User Guide

Copyright © 2017 ZTE CORPORATION. All rights reserved. ZTE and the ZTE logos are trademarks of the ZTE Corporation. AT&T, the AT&T logo and all other AT&T marks contained herein are trademarks of AT&T Intellectual Property and/or AT&T.

No part of this publication may be excerpted, reproduced, translated or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm, without the prior written permission of ZTE Corporation.

The manual is published by ZTE Corporation. We reserve the right to make modifications on print errors or update specifications without prior notice.

microSDXC is a trademark of SD, 3C-LLC. The *Bluetooth*® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc.

Manufactured under license from Dolby Laboratories. Dolby, Dolby Audio, and the double-D symbol are trademarks of Dolby Laboratories.

Qualcomm and Snapdragon are trademarks of Qualcomm Incorporated, registered in the United States and other countries. Used with permission.

Version No. : V1.0

Edition Time: April 2017

Getting Started

Installing the nano-SIM Card and the microSDXC Card

You do not need to power off your tablet before installing or replacing the nano-SIM card or before installing or removing the microSDXC card (not included). You need to unmount the microSDXC card before removing it (see *Connecting to Networks and Devices – Using the microSDXC Card as Portable or Internal Storage*).

Warning! To avoid damage to the tablet, please only use a standard nano-SIM card. You can obtain a standard nano-SIM card from your service provider.

1. Open the nano-SIM/microSDXC card cover on the back of the tablet.
2. Insert the nano-SIM card into the nano-SIM card slot or the microSDXC card (not included) into the microSDXC card slot with the contacts facing down.
3. Close the cover.

Charging the Battery

Your tablet's battery should have enough power for the tablet to turn on and find a signal. You should fully charge the battery as soon as possible.

If the battery is low, there will be a pop-up message on the screen. As you charge your tablet, the screen will tell you the exact battery

level each time you wake up your tablet.

Warning! Use only ZTE-approved chargers and cables. The use of unapproved accessories could damage your tablet or cause the battery to explode.

Important: Do not change the built-in rechargeable battery in your device by yourself. The battery can only be changed by ZTE or ZTE authorized service provider.

1. Connect the adapter to the charging jack. Ensure the adapter has the correct orientation before insertion. Do not force the connector into the charging jack.
2. Connect the charger to a standard AC wall outlet. If the tablet is on, you'll see a charging icon, such as  or , appear in the Status Bar.
3. Disconnect the charger when the battery is fully charged.

Note: If the battery is extremely low, you may be unable to power on the tablet even when it is being charged. In this case, try again after charging the tablet for at least 20 minutes. Contact customer service if you still cannot power on the tablet after prolonged charging.

Extending the Battery Life

Active applications, screen brightness levels, *Bluetooth* and Wi-Fi usage, and GPS functionality can drain your battery. You can follow the helpful tips below to conserve your battery power:

- Reduce the screen backlight time.
- Lower the screen brightness.
- Turn auto-sync, Wi-Fi, and *Bluetooth* off when not in use.
- Disable the GPS function when not in use. Most applications

using this function will periodically query the GPS satellites for your current location; each query drains your battery.

Powering Your Tablet On/Off

- Press and hold the Power key to power on your tablet.
- To turn it off, press and hold the Power key to open the options menu. Tap Power off.

Note: If the tablet freezes or takes too long to respond, press and hold the **Power** key for about 10 seconds to power the tablet off. Press and hold the Power key to turn the tablet on again.

Setting Up Your Tablet for the First Time

To set up the tablet, follow the on-screen prompts when you first power on your tablet after you purchase it or after performing a factory reset (see *Settings – Device – Backup & reset*).

1. Tap the language field to select the language you want, and tap **LTE'S GO**.
2. Follow the prompts to set up your Wi-Fi connection, Google account, Google services, and other options.

Locking/Unlocking the Screen and Keys

Your tablet allows you to quickly lock the screen and keys (put the tablet into Sleep mode) when not in use and also to turn the screen back on and unlock it when you need it.

Locking the Screen and Keys

To quickly turn the screen off and lock the keys, press the **Power** key.

Note: To save battery power, the tablet automatically turns off the

screen after a certain period of time when you leave it idle. You will still be able to receive notifications while the tablet screen is off.

Unlocking the Screen and Keys

1. Press the **Power** key to turn the screen on.
2. Press and hold a blank area of the screen.

Note: If you have set an unlock pattern, PIN, or password for your tablet (see *Personalizing – Protecting Your Tablet With Screen Locks*), you'll need to draw the pattern or enter the PIN/Password to unlock your screen.

Using the Touch Screen

Your tablet's touch screen lets you control actions through a variety of touch gestures.


- **Tap** – When you want to type using the on-screen keyboard, select on-screen items (such as application and settings icons), or press on-screen buttons, simply tap them with your finger.
- **Press and Hold** – To open the available options for an item (for example, a message or link in a web page), press and hold the item.
- **Swipe or Slide** – To swipe or slide means to quickly drag your finger vertically or horizontally across the screen.
- **Drag** – To drag, press and hold your finger with some pressure before you start to move your finger. While dragging, do not release your finger until you have reached the target position.
- **Pinch** – In some apps (such as Maps and Gallery), you can

zoom in and out by placing two fingers on the screen at once and pinching them together (to zoom out) or spreading them apart (to zoom in).

- Rotate the Screen – For most screens, you can automatically change the screen orientation from portrait to landscape by turning the tablet sideways.

Note: You can access the screen rotation control by sliding down the Status Bar twice and tapping **Auto-rotate**.

Getting to Know Your Tablet



Key Functions

Key	Function
Power key	Press and hold to turn Airplane mode on or off, to Restart, or to Power off. Press to change your tablet to Sleep mode. Press to wake up your tablet.
Home key	Press to return to the home screen from any application or screen. Press and hold to access Google Search™ or Google Now™.
Recent apps key	Press to see recently used applications.
Back key	Press to go to the previous screen.
Volume key	Press or hold to turn the volume up or down.
DTV key	Press to open a bound app.

Health and Safety Information

General Safety

	Don't use while driving. Never text while driving.
	Small parts may cause choking.
	Your device can produce a loud sound.
	To prevent possible hearing damage, do not listen at high volume levels for long periods.
	Avoid contact with anything magnetic.
	Keep away from pacemakers and other electronic medical devices.
	Turn off when asked to in hospitals and medical facilities.
	Turn off when told to in aircrafts and airports.
	Turn off when near explosive materials or liquids.
	Don't use at gas stations.
	Your device may produce a bright or flashing light.

	Don't dispose of your device in fire.
	Avoid extreme temperatures.
	Avoid contact with liquids. Keep your device dry.
	Do not attempt to disassemble your device.
	Only use approved accessories.
	Don't rely on your tablet as a primary device for emergency communications.

FCC RF Exposure Information (SAR)

This device is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the United States.

The exposure standard for wireless employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6W/kg.

The FCC has granted an Equipment Authorization for this model device with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. SAR information on this model device is on file with the FCC and can be found under the Display Grant section of www.fcc.gov/oet/ea/fccid after searching on FCC ID: SRQ-K92.

For this device, the highest reported SAR value for usage near the body is 1.20 W/kg.

FCC Regulations

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This device has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION:

Changes or modifications not expressly approved by the party

responsible for compliance could void the user's authority to operate the equipment.

CTIA

- Do not disassemble or open, crush, bend or deform, puncture or shred.
- Do not modify or remanufacture, attempt to insert foreign objects into the battery, immerse or expose to water or other liquids, expose to fire, explosion or other hazard.
- Only use the battery for the system for which it is specified.
- Only use the battery with a charging system that has been qualified with the system per CTIA Certification Requirements for Battery System Compliance to IEEE 1725. Use of an unqualified battery or charger may present a risk of fire, explosion, leakage, or other hazard.
- Do not short circuit a battery or allow metallic conductive objects to contact battery terminals.
- Replace the battery only with another battery that has been qualified with the system per this standard, IEEE-Std-1725. Use of an unqualified battery may present a risk of fire, explosion, leakage or other hazard.
- Promptly dispose of used batteries in accordance with local regulations.
- Battery usage by children should be supervised.
- Avoid dropping the device or battery. If the device or battery is dropped, especially on a hard surface, and the user suspects damage, take it to a service center for inspection.

- Improper battery use may result in a fire, explosion or other hazard.
- The device shall only be connected to CTIA certified adapters, products that bear the USB-IF logo or products that have completed the USB-IF compliance program.

Distraction

Driving

Full attention must be given to driving at all times in order to reduce the risk of an accident. Using a wireless device while driving (even with a hands-free kit) can cause distraction and lead to an accident. You must comply with local laws and regulations restricting the use of wireless devices while driving.

Operating Machinery

Full attention must be given to operating the machinery in order to reduce the risk of an accident.

Product Handling

General Statement on Handling and Use

You alone are responsible for how you use your device and any consequences of its use.

You must always power off your device wherever the use of a wireless device is prohibited. Use of your device is subject to

safety measures designed to protect users and their environment.

- Always treat your device and its accessories with care and keep it in a clean and dust-free place.
 - Do not expose your device or its accessories to open flames or lit tobacco products.
 - Do not expose your device or its accessories to liquid, moisture, or high humidity.
 - Do not drop, throw, or try to bend your device or its accessories.
 - Do not use harsh chemicals, cleaning solvents, or aerosols to clean the device or its accessories.
 - Do not paint your device or its accessories.
 - Do not attempt to disassemble your device or its accessories. Only authorized personnel can do so.
 - Do not expose your device or its accessories to extreme temperatures, minimum 23 °F and maximum 122 °F (minimum -5 °C and maximum +50 °C).
 - Please check local regulations for disposal of electronic products.
-
- Do not carry your device in your back pocket as it could break when you sit down.

Small Children

Do not leave your device and its accessories within the reach of small children or allow them to play with it. They could hurt themselves or others, or could accidentally damage the device.

Your device contains small parts with sharp edges that may cause an injury or may become detached and create a choking hazard.

Demagnetization

To avoid the risk of demagnetization, do not allow electronic devices or magnetic media close to your device for a long time.

Electrostatic Discharge (ESD)

Do not touch the SIM card's metal connectors.

Antenna

Do not touch the antenna unnecessarily.

Air Bags

Do not place the device in the area over an air bag or in the air bag deployment area as an airbag inflates with great force and serious injury could result.

Store the device safely before driving your vehicle.

Seizures/Blackouts

The device can produce a bright or flashing light. A small percentage of people may be susceptible to blackouts or seizures (even if they have never had one before) when exposed to flashing lights or light patterns such as when playing games or watching video. If you have experienced seizures or blackouts or have a family history of such occurrences, please consult a physician.

Repetitive Strain Injuries

To minimize the risk of Repetitive Strain Injury (RSI) when texting or playing games with your device:

- Do not grip the device too tightly.

- Press the keys lightly.
- Use the special features that are designed to minimize the times of pressing buttons, such as Message Templates and Predictive Text.
- Take lots of breaks to stretch and relax.

Loud Noise

This device is capable of producing loud noises, which may damage your hearing. Turn down the volume before using headphones, *Bluetooth* stereo headsets or other audio devices.

Device Heating

Your device may become warm during charging and during normal use.

Electrical Safety

Accessories

Use only approved accessories.

Do not connect with incompatible products or accessories.

Take care not to touch or allow metal objects, such as coins or key rings, to contact or short-circuit in the battery terminals.

Connection to a Car

Seek professional advice when connecting a device interface to the vehicle electrical system.

Faulty and Damaged Products

Do not attempt to disassemble the device or its accessories.

Only qualified personnel can service or repair the device or its

accessories.

If your device (or its accessories) has been submerged in water, punctured, or subjected to a severe fall, do not use it until you have taken it to be checked at an authorized service center.

Radio Frequency Interference

General Statement on Interference

Care must be taken when using the device in close proximity to personal medical devices, such as pacemakers and hearing aids.

Pacemakers

Pacemaker manufacturers recommend that a minimum separation of 6 inches (15 cm) be maintained between a mobile device and a pacemaker to avoid potential interference with the pacemaker. To achieve this, use the device on the opposite ear to your pacemaker and do not carry it in a breast pocket.

Hearing Aids

People with hearing aids or other cochlear implants may experience interfering noises when using wireless devices or when one is nearby.

The level of interference will depend on the type of hearing device and the distance from the interference source, increasing the separation between them may reduce the interference. You may also consult your hearing aid manufacturer to discuss alternatives.

Medical Devices

Please consult your doctor and the device manufacturer to determine if operation of your device may interfere with the

operation of your medical device.

Hospitals

Power off your wireless device when requested to do so in hospitals, clinics, or health care facilities. These requests are designed to prevent possible interference with sensitive medical equipment.

Aircraft

Power off your wireless device whenever you are instructed to do so by airport or airline staff.

Consult the airline staff about the use of wireless devices on board the aircraft. If your device offers a 'flight mode', this must be enabled prior to boarding an aircraft.

Interference in Cars

Please note that because of possible interference to electronic equipment, some vehicle manufacturers forbid the use of mobile devices in their vehicles unless a hands-free kit with an external antenna is included in the installation.

Explosive Environments

Gas Stations and Explosive Atmospheres

In locations with potentially explosive atmospheres, obey all posted signs to turn off wireless devices such as your tablet or other radio equipment.

Areas with potentially explosive atmospheres include fueling areas, below decks on boats, fuel or chemical transfer or storage facilities, and areas where the air contains chemicals or particles,

such as grain, dust, or metal powders.

Blasting Caps and Areas

Power off your mobile device or wireless device when in a blasting area or in areas posted with power off “two-way radios” or “electronic devices” notices to avoid interfering with blasting operations.