

# **Korenix JetPort 5804 / 5804i Wireless Serial Device Server**

---

## **User's Manual**

Mar. 2013 (V1.0)



**[www.korenix.com](http://www.korenix.com)**

# **Korenix JetPort 5804 / 5804i Wireless Serial Device Server User's Manual**

## **Copyright Notice**

Copyright © 2013 Korenix Technology Co., Ltd.

All rights reserved.

Reproduction in any form or by any means without permission is prohibited.

# Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

For product available in the USA/Canada market, only channel 1~11 can be operated. Selection of other channels is not possible.

## **IMPORTANT NOTE:**

### **FCC Radiation Exposure Statement:**

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

# Contents

---

<b>1</b>	<b>Introduction 4</b>	
1.1	Serial to Ethernet Technology Overview .....	5
1.2	Product Features .....	5
1.3	Product Specification .....	5
1.4	Package Checklist .....	8
<b>2</b>	<b>Hardware Installation .....</b>	<b>9</b>
2.1	Panel and LEDs .....	10
	5804 Panel and Interfaces .....	10
	5804i Panel and Interfaces .....	10
	5804/5804i LED Indicators .....	11
2.2	Reset Button .....	11
2.3	Connecting the Power .....	12
2.4	Connecting the Network .....	12
2.5	Wireless LAN Architecture .....	13
2.6	Wireless Security .....	14
2.7	Connecting the Serial Device .....	15
2.8	Digital Input/Output .....	16
2.9	DIN-Rail Mounting Installation .....	18
2.10	Wall-Mounting Installation .....	19
<b>3</b>	<b>Windows Management Tool .....</b>	<b>21</b>
3.1	Software Quick Setup .....	22
	<b>Install JetPort Commander</b> .....	22
<b>4</b>	<b>Web and Telnet Console .....</b>	<b>26</b>
4.1	Web Console .....	27
	<b>Server Configuration</b> .....	27
	<b>Port Configuration</b> .....	29
	Serial Setting .....	29
	Service Mode- Real/Virtual COM .....	31
	Service Mode- TCP Server .....	32
	Service Mode- TCP Client .....	32
	Service Mode- UDP .....	33
	<b>Management</b> .....	34
	DI/DO Status .....	34
	IP Filtering .....	35
	Event Notification .....	35
	Email and SNMP Trap Notification .....	37
	Maintenance .....	38
4.2	SSH Console .....	39
	SSH Client .....	39
	Configuration .....	41
<b>Appendix A</b>	<b>SNMP MIB II and RS-232 Like Support .....</b>	<b>42</b>
<b>Appendix B</b>	<b>RS-232 Pin Assignment .....</b>	<b>44</b>
<b>Appendix C</b>	<b>Revision History .....</b>	<b>46</b>

# 1 Introduction

JetPort 5804 series is a 4-ports Serial to Wireless Device Server. JetPort 5804 provides 4 3-in-1 RS-232/422/485 serial interfaces. JetPort 5804i provides 4 RS-422/485 serial interfaces with 2KV isolation protection. You can use one IP address, dual redundant paths to control maximum 4 serial devices over the Ethernet. The Wireless LAN solution is 802.11b/g with up to 54Mbps bandwidth. Give you an easy solution to the hard-to-wire or moving environment. Ease your network cabling problem in the field. Protect your serial data transmission with 128 bit WEP over the Wireless LAN and avoid the illegal access or hack.

The JetPort 5804 series supports RTTD technology so that the dual Ethernet ports can auto-recovery within 200ms. JetPort 5804 series are also equipped with abundant value-added hardware features include the 2 types of power inputs, 4 Digital Input and 2 Digital Output. JetPort 5804 series can be configured by JetPort Commander, the easy-to-use utility for Windows and the HTTPS and SSH for secured management. The Notification includes the Email alert, System log, SNMP traps and Digital Output for pre-defined events.

This chapter describes:

- **Serial to Ethernet Technology Overview**
- **Product features**
- **Product specification**
- **Package checklist**

## 1.1 Serial to Ethernet Technology Overview

Korenix JetPort serial device servers provide perfect solution to manage serial devices via Ethernet in flexible ways, such as TCP server, TCP client, UDP, or Windows virtual COM. JetPort creates a transparent gateway for the serial communication to Ethernet. If the control program uses network standard API, you can choose TCP or UDP as the communication protocol. If the control program uses COM port, you can install the Windows driver to add virtual COM ports.

## 1.2 Product Features

JetPort 5804/5804i has the following features:

- Four-port RS-232/422/485 to 802.11b/g (up to 54Mbps) Wireless network (5804)
- Four-port RS-422/485 with Isolation to 802.11b/g (up to 54Mbps) Wireless network (5804i)
- Serial ports supports 2KV isolation protection (5804i)
- Encrypted data transmission with 128-bit WEP and WPA
- External antenna expands the range of WLAN
- Fiberglass antenna for water, dust and UV resistance
- RTTD, Redundant to the Device function Dual Ethernet Ports, network auto-recovery in 200ms
- Four Digital Inputs and Two Digital Outputs
- Redundant Power Inputs by 12-48VDC Terminal Block and DC Jack.
- Independent serial services, Real/Virtual COM, TCP Server/Client/Tunnel and UDP Connections
- JetPort Commander, Easy-to-use Windows Utility with smart setup Wizards.
- Secured Management by HTTPS and SSH
- Event Notification by Syslog, Email, SNMP trap, and Digital Output
- Vertical mounting by Din-Rail, Wall mount and Desk-top

## 1.3 Product Specification

### Network Interface

<b>WLAN Standard</b>	802.11b/g WLAN
<b>Spread Spectrum Technology</b>	DSSS(802.11b), OFDM(802.11g)
<b>Tx Power</b>	13-17dBm at maximum radiation direction
<b>Rx Sensitivity</b>	-71 dBm @ 54 Mbps, -84 dBm @ 11Mbps
<b>Transmission Rate</b>	54 Mbps (max.) with auto fallback

<b>Transmission Distance</b>	Up to 100 meters (open area)
<b>Antenna</b>	Supports the antenna diversity function
<b>Ethernet</b>	2* 10/100BaseTX, Redundant Dual Ethernet
<b>Connector</b>	RJ-45
<b>Feature</b>	Auto Recovery in less than 200ms, Auto MDI/MDI-X
<b>Protection</b>	Built-in 1.5 KV magnetic isolation protection
<b>Protocols</b>	IP, TCP, UDP, ICMP, DHCP, BootP, ARP/RARP, SNMP, HTTPS, SSH, SNTP, SMTP

#### Serial Communication

<b>Number of Ports</b>	4
<b>Interface</b>	RS-232, RS-422, RS-485 2/4-wire (5804) RS-422, RS-485 2/4-wire with 2KV Isolation Protection (5804i)
<b>Connectors</b>	male DB9
<b>Baud Rates</b>	110 bps to 460.8 Kbps
<b>Data Bits</b>	5, 6, 7, 8
<b>Parity</b>	odd, even, none
<b>Stop Bits</b>	1, 1.5, 2
<b>RS-232</b>	TxD, RxD, RTS, CTS, DTR, DSR, GND, DCD
<b>RS-422</b>	Tx+,Tx-, Rx+, Rx-,GND
<b>RS-485 (4-wire)</b>	Tx+,Tx-, Rx+, Rx-,GND
<b>RS-485 (2-wire)</b>	Data+, Data-,GND
<b>Flow Control</b>	XON/XOFF, RTS/CTS, DTR/DSR
<b>Serial Line Protection</b>	15KV ESD
<b>Long Distance</b>	2*pin 120ohm DIP switches
<b>Termination</b>	

#### Digital Input/Output

<b>Number of DI</b>	4
<b>Power Input voltage</b>	5V/TTL Logic 0: 0.8V max (0-0.8V) Logic 1: 2.0V min (2-5V)
<b>Number of DO</b>	2
<b>Power Output voltage</b>	5V/TTL Logic 0: 0.8V max (0-0.8V) Logic 1: 2.0V min (2-5V)

#### Features

<b>LED</b>	Power 1: Startup(Red); Ready(Green); WLAN Link (Orange) Power 2: Startup(Red); Ready(Green) Ethernet port: Left:100M Link (Green On) / Activity(Green Blinking)
------------	--

	Right:10M Link (Orange On) /Activity(Orange Blinking)
	Serial 1/2/3/4:TX only(Green), RX only(Red), Both RX/TX(Orange)
<b>Configuration</b>	Windows Utility-JetPort Commander, HTTP, Telnet
<b>Serial Service</b>	Real COM, Virtual COM, TCP Server, TCP Client, TCP Tunnel and UDP
<b>Reset</b>	Software reload default, Hardware reset button
<b>Beeper</b>	Embedded beeper for positioning
<b>RTTD</b>	Redundant to the Device, Auto-recover in less than 200ms
<b>SNTP</b>	For time management
<b>Access IP Table</b>	16 IP addresses to prevent illegal users
<b>Monitor</b>	Devices' status, RCOM/VCOM status
<b>SNMP</b>	RFC1213 MIB II, RFC1317 RS232_like and SNMP Trap
<b>E-Mail Alert</b>	Automatic e-mail warning by pre-defined events
<b>System Log</b>	Trap to Syslog server or local display
<b>System Events</b>	Cold/Warm Start, Login Failed, IP and Password Changed, Access IP Blocked, DI/DO changed, Serial Port DCD/RI/DSR/CTS changed, Serial Port connected/disconnected.
<b>Windows Utility</b>	
<b>JetPort Commander</b>	Device Discovery, Auto IP, Network Setting, Device and Serial Port Setting and monitoring, Notification setting, Firmware Upgrade, Configuration Backup and Restore, Group Configuration Wizards.
<b>Serial Service Mode</b>	Real COM, Virtual COM, TCP Server, TCP Client, TCP Tunnel and UDP
<b>Advanced Serial Setting</b>	TCP Alive Check Timeout, Inactivity Idle Timeout, Performance mode, Delimiter, Force TX Timeout for Data Packing and Force TX interval time
<b>Group Configuration Wizard</b>	JetPort Commander: Group IP Wizard, Group firmware upgrade, Group Backup/Restore, RCOM, VCOM and TCP Tunnel Setup Wizard
<b>Power Requirements</b>	
<b>System Power</b>	PWR1: 12~48VDC Terminal Block PWR2: 12~48VDC Power Jack with Power Adapter
<b>Power Line protection</b>	1 KV Burst (EFT), EN61000-4-4 0.5 KV Surge, EN61000-4-5
<b>Power Consumption</b>	Maximum 4.7 Watts
<b>Mechanical</b>	
<b>Dimensions</b>	145mm(W)x120mm(D)x46.5mm(H)
<b>Regulatory Approvals</b>	FCC Class A, CE Class A , RoHS
<b>Environmental</b>	



**Operating Temperature** -10°C ~55°C  
**Operating Humidity** 5% ~ 95%, non-condensing  
**Storage Temperature** -40°C ~ 85 °C

## 1.4 Package Checklist

**JetPort is shipped with the following items:**

- Wireless Device Server
- Antenna
- 100-240VAC Power adapter
- Din-Rail/Wall Mount kit
- Foot pads
- Documentation and Software CD
- Quick Installation Guide



If any of the above items is missing or damaged, please contact your local sales representative.

## 2 Hardware Installation


JetPort serial device server can be configured by Windows utility, web browser, or Telnet console. Advanced management features include SNMP support and Email alert. JetPort Commander is a powerful Windows utility that supports device discovery, group setup, group firmware update, and monitoring functions.

This chapter introduces how to quick start JetPort


- **Panel and LEDs**
- **Reset Button**
- **Connecting the Power**
- **Connecting the Network**
- **Connection the Serial Device**
- **Wireless LAN Architecture**
- **Wireless Security**
- **Digital Input/Output**
- **DIN Rail Mounting Installation**
- **Wall Mounting Installation**

## 2.1 Panel and LEDs

### 5804 Panel and Interfaces



### 5804i Panel and Interfaces



## 5804/5804i LED Indicators

There are 6 LEDs in 5804/5804i front panel and 2 LED in RJ-45 ports, indicating real-time system status.

LED	Color	Indication
PWR 1	Red	On: Power 1 is on and booting up. Blinking: Indicates an IP conflict, or DHCP or BOOTP server did not respond properly.
	Green	On: Power is on and functioning normally. Blinking: Located by Administrator's Location function.
	Orange	On: WLAN is linking.
	Off	Power is off, or power error condition exists.
PWR 2	Red	On: Power 2 is on and booting up. Blinking: Indicates an IP conflict, or DHCP or BOOTP server did not respond properly.
	Green	On: Power 2 is on and functioning normally. Blinking: Located by Administrator's Location function.
	Off	Power is off, or power error condition exists.
Eth 1	Left	Green: 100M Ethernet cable is connected. Green Blinking: Traffic is transmitting or receiving.
	Right	Orange: 10M Ethernet cable is connected. Orange Blinking: Traffic is transmitting or receiving.
	Off	Ethernet cable is disconnected, or has a short.
Eth 2	Left	Green: 100M Ethernet cable is connected. Green Blinking: Traffic is transmitting or receiving.
	Right	Orange: 10M Ethernet cable is connected. Orange Blinking: Traffic is transmitting or receiving.
	Off	Ethernet cable is disconnected, or has a short.
S1	Red	Serial port is receiving data.
	Green	Serial port is transmitting data.
	Orange	Serial port is receiving and transmitting data.
	Off	No data is being transmitted or received through the serial port.
S2	Red	Serial port is receiving data.
	Green	Serial port is transmitting data.
	Orange	Serial port is receiving and transmitting data.
	Off	No data is being transmitted or received through the serial port.
S3	Red	Serial port is receiving data.
	Green	Serial port is transmitting data.
	Orange	Serial port is receiving and transmitting data.
	Off	No data is being transmitted or received through the serial port.
S4	Red	Serial port is receiving data.
	Green	Serial port is transmitting data.
	Orange	Serial port is receiving and transmitting data.
	Off	No data is being transmitted or received through the serial port.

## 2.2 Reset Button

The Reset button provides users with a quick and easy way to restore the default settings of JetPort. Press reset button for 10 seconds. Release after Power LED blinking red. JetPort will restore to default value including default IP address (192.168.10.2), and no password. When the Power LED turns green, the device is ready to function.

## 2.3 Connecting the Power

### Terminal Block (PWR1):

1. Insert the positive and negative wires of your DC supply into the V+ and V- contacts of the terminal block connector.



(GND / V- / V+)

2. Tighten the terminal screws to prevent the DC wires from coming loose.



### Power Jack(PWR2):

Connect the power jack input with the enclosed 12VDC power adapter, or 24VDC power input. The power LED will show red color until the system is ready. If the IP setting is running correctly, the power LED will turn green.

**Note:** If the 2 power inputs are connected (PWR 1, PWR 2), the JetPort 5804 will be powered from the highest connected voltage. The unit will not alarm for loss of DC IN power, the alarm function only applies to loss of power at PWR1 or PWR2.

## 2.4 Connecting the Network

### LAN Interface

Connect the Ethernet cable to the JetPort 5804/5804i 10/100M Ethernet port 1, 2 or both. The interfaces support auto MDI/MDIX. If both of the Ethernet port 1 and 2 are connected when startup device, the Ethernet port 1 will be the master port, Ethernet port 2 will be the backup. But, if Ethernet port 2 is attached first before attach port 1, the Ethernet port 2 will remain the master port. The major purpose of the LAN interface is for you to configure the SSID for WLAN interface. Run JetPort Commander to manually configure the SSID or Auto Search the available remote Access Point (AP). Refer to the manual of the JetPort Commander to see how to configure SSID.

### WLAN Interface


Screw the attached Wireless Antenna when you get the unit. Always rotate the antenna clockwise to change the direction.



**Note:** Only one of the LAN or WLAN interface can work. When connecting LAN and WLAN at the same time, the LAN interface has higher priority than WLAN interface.


## 2.5 Wireless LAN Architecture

There are 2 typical WLAN architectures, one is infrastructure, and the other is Ad-Hoc mode.



**Infrastructure mode:** The 2 ends communicate via Access Point (AP). Access Point is the base station which allows WLAN clients connect to. Each AP can accept several clients depend on the network performance you plan to give. Usually up to 10-20 clients. The AP works like a hub, the connected clients share the bandwidth it supports. For example: The AP supports 802.11g which means the available

**Ad-Hoc mode:** The 2 ends communicate with each other directly. In this architecture, there is no need any access point. The JetPort and the host PC or 2 JetPorts can communicate with each other directly.



### SSID:

SSID is short of the Service Set Identifier, it is referred to as a network name that identifies a wireless network. The SSID is attached to the header of packets sent over the WLAN. The 2 ends of the communication pairs should have the same SSID. This also can be viewed as one kind of password for the WLAN end devices.

To configure the WLAN settings, no matter Infrastructure or Ad-Hoc mode. You should know the SSID of the 2 ends first. In infrastructure mode, you should know the SSID of the access point and configure this in the JetPort. In Ad-hoc mode, you should configure the same SSID for the JetPort and host PC or 2 JetPorts.

Configure the SSID of the Access Point (AP) by JetPort Commander when you first use the WLAN interface or when you move to JetPort 5804 to the range of the other AP. Unplug the LAN port or power reboot the device, then the WLAN interface can connect to the Access Point (AP) you assigned. It may

take few seconds to connect to the WLAN AP when you unplugging the LAN interface. Refer to the WLAN LED can help you to see the WLAN connection status.

**Channel:**

In each region, it defines the channels of the wireless band. When choosing Infrastructure mode, the channel of the JetPort is automatically decided by the Access Point. This is to avoid the conflict and easy maintaining the WLAN performance. In Ad-hoc mode, you should assign the same channel to the 2 ends.

**Transmission Rate:**

The JetPort 5804 supports 802.11b and 802.11g standard. The typical transmission rate of the 802.11b is 11Mbps, the 802.11g is 54Mbps. The transmission rate of JetPort is "Auto". It'd use the best transmission rate it can meet in that environment. The transmission rate may also decide by the Access Point. The network installation may also affect this, weak signal or poor connection will reduce the rate.

## 2.6 Wireless Security

JetPort 5804 supports several types of Wireless security protection.

**No Encryption:** Disable the Wireless encryption.

**WEP:** WEP is abbreviation of the **Wired Equivalent Privacy**. WEP is a security protocol for WLAN. It is designed to provide the same level of security as that of a wired LAN. WEP aims to provide security by encrypting data over radio waves so that the serial data is protected from JetPort 5804 to the Access Point (AP) or another end station.

There are 4 types WEP encryption you can choose:

Character Input: 5 Characters [WEP64]

Character Input: 13 Characters [WEP128]

Hexadecimal Input: 10 digits [WEP64]

Hexadecimal Input: 26 digits [WEP128]

After choosing the encryption type, you can type the Key in the below field. There are 4 keys you can configure and save; one of the key can work at one time.

General | Security | Networking | **Wireless** | Notification | Management | Upgrade Firmware | S

Network Type: Infra  
 SSID: default [SSID Scan]

**Wireless Encryption**

No Encryption  
 WEP

WEP Encryption Key: Character Input: 5 characters(WEP64)

1 [ ]  3 [ ]  
 2 [ ]  4 [ ]

TKIP  
 AES

WPA-PSK (Previously Shared Key) [ ]  
 Key Renewal Period: 0 minutes

The 5804 also supports **WPA** (Wi-Fi Protected Access). WPA was created by the Wi-Fi Alliance; it was designed to enhance the security of wireless networks. WPA has better protection than WEP.

JetPort 5804 supports **WPA Personal** mode. This mode is designed for the networks which don't require the complex 802.1x authentication server. The WPA personal mode requires manual configuration of a PSK (Previously Share Key) on the AP and Client. The PSK is a passphrase (password), each client must enter a passphrase to access the network, the security depends on the strength of the passphrase. The passphrase may be from 8 to 63 printable ASCII characters or 64 hex decimal digits (256 bits). The passphrase you typed will be stored in JetPort thus you can use this passphrase to communicate with the AP.

JetPort 5804 WPA supports 2 encryption modes, **TKIP** and **AES**.

**TKIP** is short of **Temporal Key Integrity Protocol**. It's an enhancement to WEP security. TKIP uses the RC4 stream cipher with 128-bit keys for encryption and 64-bit keys for authentication. TKIP helps to ensure that only the intended audience understands the transmitted data.

**AES** is short of **Advanced Encryption Standard**. 5804 provides encryption support AES.

Choose the encryption type, TKIP or AES, then type the key in the WPA-PSK and time in the Key Renewal Period (minutes) field.


*Note: The above security settings should be the same in your access point (AP) and JetPort. Incorrect password/key may lead you lost the connection.*

## 2.7 Connecting the Serial Device

JetPort 5804 serial port is a standard DB9 male port. Connect the serial device to the unit DB9 male port by the pin assignment table. The Long-Range Termination switch can configure 120ohm termination for RS-422/4-wire RS-485/2-wire RS-485.



## Pin Assignment



Pin #	RS-232	RS-422	RS-485 (4 wire)	RS-485(2 wire)
1	DCD	RXD-	RXD-	
2	RXD	RXD+	RXD+	
3	TXD	TXD+	TXD+	DATA+
4	DTR	TXD-	TXD-	DATA-
5	GND	GND	GND	GND
6	DSR			
7	RTS			
8	CTS			
9	RI			

\*RS-232 mode act as **DTE**

## 120ohm DIP




DIP 1	DIP 2	120ohm Termination Configuration
ON	ON	120ohm Terminator for Long Distance 4-wire RS-485/RS-422
ON	OFF	---
OFF	ON	120ohm Termination for Long Distance 2-wire RS-485
OFF	OFF	No Termination for RS-232/485 (short distance)

## 2.8 Digital Input/Output

JetPort 5804 series provides 4 digital inputs and 2 digital outputs. It allows users to connect the termination units' 5V TTL digital input/output. JetPort Commander allows you to monitor the status of the DI and DO, and set the value 0 or 1 to DO. JetPort also provides one data port for user to program DI/O get and set commands. The logic Low (Value=0) power voltage is 0-0.8V, 0.8V is the max value. The logic High (Value =1) power voltage is 2-5V, 2V is the min value.

The Digital I/O pin can be pulled high or low, thus the connected equipments can actively drive these pins high or low. When the digital output of the connected device pulls high to the digital input pin of 5804, or program the digital output value of the connected device to high, the 5804 can trigger the value and display 1 (logic high) in the JetPort Commander. When the connected device pulls low or program to low,



the 5804 can display 0 (logic low).

The Digital Output pin should be connected to 5V TTL digital input of the connected device. When user set the value to 1(high), the connected device can receive circuit from 5804 and will be pulled to 1 as well. Or you can connect the digital output pin to the 5V relay output board. Then connect the alarm beeper, lights to the relay output board. You can see the same function as the Relay Output of JetNet switches.


Note: The Digital Output feature is not Relay Output board design, it should be connected to digital I/O by pair. Connect digital input of connected device to digital output of 5804 or digital output of the connected device to digital input of 5804.

### 2.6.1 How to setup DI/O by JetPort Commander

**DI:** You can read the status of the DI. 0 means logic Low. 1 means logic High. When connect DI with DO of other terminal device, the DI can display the DO status of the terminal device.

**DO:** You can read and set the status of the DO. 0 means logic Low, 1 means logic High. Click the 0/1 button, you can change its value to 1 or 0.

means logic High for DO\_1.       means logic Low for DO\_1.



### 2.6.2 How to Program DI/O by the opened data port

The JetPort opens a data port for user to program. The programming socket port is 0x901 (2305). You can telnet to the device with TCP port number 2305. Below are the related commands:

#### Programming Commands

**getdo** get DO status

**getdi** get DI status

**setdo** set DO

#### Programming command parameters:

**getdo/getdi** No parameters.

**setdo** DO status string.

Ex: "1:0" (status delimiter is ":", order is "DO\_1: DO\_2")

Note: command should with "\r\n" at end.

### Programming returns:

**getdo** Return DO status string. (2 DO)

Ex: "1:0\n\r". (delimiter is ":", order is "DO\_1:DO\_2", "\n\r" is end flag.)

**getdi** Return DI status string. (4 DI)

Ex: "1:0:1:0\n\r". (delimiter is ":", order is "DI\_1:DI\_2:DI\_3:DI\_4", "\n\r" is end flag.)

**setdo** Return "OK" when success. Return error message when failure (like: "Unknown command, No DO status given").


And end flag is "\n\r".

## 2.9 DIN-Rail Mounting Installation

The DIN-Rail clip is already attached to the JetPort 5804 Series products when packaged. If the DIN-Rail clip is not screwed on the JetPort, follow the instructions and the figure below to attach the DIN-Rail clip to the JetPort.

1. Use the screws to attach the DIN-Rail clip to the rear panel of the JetPort 5804/5804i.


To remove the DIN-Rail clip, reverse step 1.



Follow the steps below to mount the JetPort to the DIN-Rail track.

1. First, insert the upper end of the DIN-Rail clip into the back of the DIN-Rail track from its upper side.

(Note: Here we use JetNet Industrial Ethernet Switch as an example.)



2. Lightly push the bottom of the DIN-Rail clip into the track.



3. Check if the DIN-Rail clip is tightly attached on the track.





The figure shows the 5804 and 5804i are attached on the track well.

4. To remove the JetPort from the track, reverse the steps above.

## 2.10 Wall-Mounting Installation


Follow these steps to mount the unit to a wall or other flat surface.

1. Use a screwdriver to attach the wall-mounting plate to the back of the JetPort using the six screws provided.



Wall-Mounting plate and screws.

2. Use a screwdriver to secure the Wall Mount kit to the wall-mounting plate.



Wall-Mounting Kits.

3. Lightly push the Wall-mounting kit into the track like the method described in Din Rail mounting installation.



The figure shows the 5804 is attached on the track well.

4. To remove the unit from the wall and from the wall-mounting plate, reverse steps 1-3.

# 3 Windows Management Tool

JetPort serial device server provides powerful Windows management tool for multiple device management.

Below are the major functions in JetPort Windows Commander. This chapter introduces you the **Software Quick Setup**. You can know how to install the JetPort Commander and setup the virtual COM mode.

The “**JetPort Commander Manual**” introduces the full configuration of JetPort commander. You can find the document in product CD or download from Korenix web site.


- **Server Configuration**
  - **Broadcast**
  - **Configuration**
  - **General**
  - **Locate**
  - **Security**
  - **Networking**
  - **Notification**
  - **Management**
  - **Firmware Update**
  - **Save / Reload**
- **Port Configuration**
  - **Port Serial Settings**
  - **Port Service Mode**
  - **Port Notification**
- **Setup Wizard**
  - **Real/Virtual COM Wizard**
  - **Serial Tunnel Wizard**
  - **Group IP Wizard**
  - **Group Setup Wizard**
  - **Group Firmware Wizard**
- **IP Collection**
- **Monitor**

## 3.1 Software Quick Setup

JetPort Commander is an easy-to-use utility with auto device discovery in a LAN or adding devices on the public network. All of the configurations on the serial server can be done in the JetPort Commander. You can also apply configurations of one serial server to the other serial servers. This document shows you how to quick setup the software. The full functions and configurations' description, please refer to the JetPort Commander Manual which you can find in the CD or download from Korenix web site.

### Install JetPort Commander

1. Insert the CD and auto-run the program. If the setup does not auto-run, select "JetPort 5804", and "Operation System", run JetPort Setup.exe to install Windows utility, JetPort Commander.




It automatically detects OS of your PC.

It will also turn on the Windows7's test mode.

Then you should reboot your PC for the settings to take effect.


After you reboot your PC, you should see a test mode watermark on the screen.



2. **Broadcast the JetPort unit:** Connect the Admin PC to the LAN interface of the JetPort 5804. JetPort Commander will broadcast the network and search all available JetPort units in the network. The default IP address of JetPort is “192.168.10.2”.




*Product Tip: If you have multiple Network Adapters (i.e. wireless and wired), please activate ONLY ONE Network Adapter that can locate the JetPort devices, and CLOSE the rest Network Adapters. Otherwise, JetPort Commander may broadcast INCORRECTLY.*



### 3. Configuring the JetPort unit:

- 3.1 Click on the JetPort unit and select “Add” for further configuring the unit.



- 3.2 Select “Static IP” if you want to specify the network parameters, or select “DHCP” or “BootP” if you want dynamic configuration for the JetPort unit.

### 4. Configure the JetPort WLAN setting:

- 4.1 Select the target unit’s IP address. Go to “Wireless” and assign Network Type to “Infra” (Infrastructure mode).
- 4.2 Press “SSID Scan” and select the available SSID.
- 4.3 If you can’t find the SSID, manually configure the SSID in the SSID field.
- 4.4 Press “Apply and Save” to apply this setting.

### 5. Configure the WLAN IP Address:




- 5.1 Go to “Networking” -> “Wireless”
- 5.2 Select “Static IP” if you want to specify the network parameters, or select “DHCP/BootP” if you want dynamic IP configuration for the JetPort unit.

6. Unplug the LAN interface or power reboot the JetPort 5804 to activate the WLAN connection. Run step 3 to find the JetPort 5804 through the WLAN connection.


**7. Configuring the serial port as COM port:**

- 7.1 Go to “Configuration”, and choose the “device” and the “port”. Select “Serial Settings” to configure the serial parameters

**Note:** In 5804 series, you can see 4 serial ports, port 1, 2, 3 and 4. Port 1 is Serial 1, Port 2 is Serial 2, Port 3 is Serial 3, and Port 4 is Serial 4.



- 7.2 Select “Service mode”, “Real/Virtual COM Mode” and press “Map COM” to map the port to the COM port.



Congratulations! You have finished JetPort configurations with Real/Virtual COM mode. You can also use web or telnet console by the JetPort IP address.

**Note:** *This document shows you how to quick setup the software. The full functions and configurations' description, please refer to the JetPort Commander Manual which you can find in the CD or download from Korenix web site.*

# 4 Web and Telnet Console

In addition to Windows utility, JetPort 5804 can also be managed by Web-HTTPS and the SSH Console.

The HTTPS is a security protocol that provides communication privacy over the internet. The HTTPS packets transmitted between the JetPort and PC would be encrypted.

The SSH allows users to securely login to remote host computers, to execute commands safely in a remote computer, to securely copy remote files and to provide secure encrypted and authenticated communications between two non-trusted hosts.

This chapter describes:

## ■ 4.1 HTTPS Console

- Server Configuration
- Port Configuration
- Management
- Maintenance


## ■ 4.2 SSH Console

- SSH Client
- Configuration

## 4.1 Web Console

When the JetPort has been configured with proper IP address and the web management is enabled, you can use web browser to make further configurations.

Type **JetPort's IP address** in the Address input box, for example <https://192.168.10.2>  
(Note: you can just type http://, this is not allowed in HTTPS. You should type https://.)



**Trust the JetPort.** The popup window will ask you to trust the JetPort product. Press **Yes** to trust the product and then you can use the web UI of JetPort.

If the JetPort is password protected, use the pre-assigned password to login first.



The overview page lists the basic information of this JetPort device.



Overview	
Model	JetPort5804
IP Address	192.168.10.2
MAC Address	00:12:77:FF:46:54
Firmware Version	2.0.5

### Server Configuration

Basic Setting configures Server name, Time Server, and Telnet console enable/disable.

## Welcome to JetPort Web Commander

## Server Configuration

[System Information](#)  
[SNTP Configuration](#)  
[IP Configuration](#)  
[Wireless Configuration](#)  
[User Authentication](#)

## Port Configuration

## Management

## Maintenance

## Basic Setting

Name	JETPORT5804-DEFAULT	
<b>Time</b>		
SNTP	<input type="radio"/> Enable <input checked="" type="radio"/> Disable	
Time Zone	(GMT+08:00)Taipei	
Local Time	Wed Mar 13 15:14:52 2013	
Time Server	pool.ntp.org	Port 123
<b>Console</b>		
Telnet Console	<input checked="" type="radio"/> Enable <input type="radio"/> Disable	

Submit

Network Setting configures the IP address, Netmask, Gateway, and DNS server for the JetPort. Auto IP Report is for dynamic IP address reporting in defined intervals.

## Network Setting

IP Configuration	Static
IP Address	192.168.10.2
Netmask	255.255.255.0
Gateway	192.168.10.3
DNS Server 1	168.95.1.1
DNS Server 2	
<b>Auto IP Report</b>	
Auto Report to IP	
Auto Report to TCP Port	0
Auto Report Interval	0 seconds

Wireless Setting configures the Network Type, SSID and Wireless Encryption for the Wireless LAN settings. "SSID Scan" can scan the available APs in the network. Or manually configure the SSI in the SSID field.

Wireless Encryption settings include WEP, TKIP and AES (WPA). Type the same settings as your AP's setting otherwise you can use the Wireless LAN network.

## Wireless Settings

Network Type	Infra	▼
SSID	korenix4	▼
<input type="button" value="SSID Scan"/>		
<b>Wireless Encryption</b>		
<input checked="" type="radio"/> No Encryption		
<input type="radio"/> WEP		
WEP Encryption Key	Character Input : 13 characters(WEP128) ▼	
<input checked="" type="radio"/> 1:	<input type="text"/>	
<input type="radio"/> 2:	<input type="text"/>	
<input type="radio"/> 3:	<input type="text"/>	
<input type="radio"/> 4:	<input type="text"/>	
<input type="radio"/> TKIP		
<input type="radio"/> AES		
WPA-PSK (Previously Shared Key):		
<input type="text"/>		
Key Renewal Period :	<input type="text"/>	minutes
<input type="button" value="Apply"/>		

You can also define Administration password to protect the JetPort from unauthorized modification. Avoid using space in password.

### Change Password

Old Password	<input type="text"/>
New Password	<input type="text"/>
Confirm New Password	<input type="text"/>
<input type="button" value="Submit"/>	

## Port Configuration

### Serial Setting

Port Configuration covers Serial Parameter settings for each serial port, such as Interface type, Baud Rate, Data Bits, Stop Bits, Parity, Flow Control, Force TX Interval Time and Performance mode.

**Serial Port:** Port 1 / Port 2 / Port 3 / Port 4

**Port Alias:** Remark the port to hint the connected device.

**Interface:** RS-232 / RS-422 / RS-485(2-wires) / RS-485(4-wires)

**Baud rate:** from 110bps to 460.8kbps

**Data Bits:** 5, 6, 7, 8

**Stop Bits:** 1, 2 (1.5)

**Parity:** No, Even, Odd, Mark, Space

**Flow Control:** None, XON/XOFF, RTS/CTS, DTR/DSR

**Force TX Interval Time** is to specify the timeout when no data has been transmitted. When the timeout is reached or TX buffer is full (4K Bytes), the queued data will be sent. Zero means disable (factory default).

**Performance:** Throughput, Latency

Throughput mode guarantees highest transmission speed

Latency mode guarantees shortest response time

## Serial Setting

	Port1	Port1
Port Alias	Port1	Port1
Interface	RS232	RS232
Baud Rate	38400	RS232
Data Bits	8	RS422
Stop Bits	1	RS485(2-wires)
Parity	None	RS485(4-wires)
Flow Control	None	
Force TX Interval Time	0 ms	
Performance	<input checked="" type="radio"/> Throughput <input type="radio"/> Latency	

Submit

For advanced data packing options, you can specify delimiters for Serial to Ethernet and / or Ethernet to Serial communications.

You can define max. 4 delimiters (00~FF, HEX) for each way. The data will be hold until the delimiters are received or the optional "Flush Data Buffer After" times out. Zero means disable (factory default).

## Port Profile

	Port1	Port1
Local TCP Port	4000	Port2
Command Port	4001	Port3
<b>Mode</b>	<b>Serial to Ethernet</b>	
Flush Data Buffer After	0	ms
Delimiter(Hex 0~ff)	1: 00	2: 00 3: 00 4: 00
<b>Mode</b>	<b>Ethernet to Serial</b>	
Flush Data Buffer After	0	ms
Delimiter(Hex 0~ff)	1: 00	2: 00 3: 00 4: 00

**Flush Data Buffer After** is to specify the timeout time if the device doesn't receive the Delimiters user setup.

## Service Mode- Real/Virtual COM

Select the Serial Port you want to configure first. In Real/Virtual COM mode, you can define the Idle Timeout, Alive Check, and Max. Connections allowed from 1 to 5.

**Note:** Since JetPort's Real/Virtual COM driver is implemented in JetPort Commander. You should run the JetPort Commander to assign the RCOM/VCOM number. You can only change the related parameters in web UI.

### Service Mode

	Port1	Port1
Service Mode	Virtual/Real COM Mode	Virtual/Real COM Mode
Idle Timeout	0 (0~65535)seconds	Virtual/Real COM Mode
Alive Check	420 (0~65535)seconds	TCP Server Mode
Max Connection	5 max. connection (1~5)	TCP Client Mode
		UDP Mode

**Idle Timeout:** When serial port stops data transmission for a defined period of time (Idle Timeout), the connection will be closed and the port will be freed and re-try for connection with other hosts. Zero is disable this setting (default). If Multilink is configured, only the first host connection is effective for this setting.

**Alive Check:** The JetPort device will send TCP Alive Check packet in each defined time interval (Alive Check) to remote host to test the TCP connection. If the TCP connection is not alive, the connection will be closed and the port will be freed for other hosts. Zero is to disable this setting Default time is 420.

**Note:** If you want to auto-connect your Real/Virtual COM when power on the device, you should



enable Alive Check. The Alive Check will re-connect virtual COM after booted up.

## Service Mode- TCP Server

In TCP Server mode, you need to select the Serial Port, define the available TCP port number, Idle timeout, Alive check, and Max. connections allowed from 1 to 5.

**Service Mode**

	Port1 ▾	Port1 ▾ Port1 Port2 Port3 Port4
<b>Service Mode</b>	TCP Server Mode ▾	
<b>TCP Server Port</b>	4000	
<b>Idle Timeout</b>	0	(0~65535)seconds
<b>Alive Check</b>	420	(0~65535)seconds
<b>Max Connection</b>	1 ▾	max. connection(1~5)

**TCP Server Port:** This is to assign the available TCP port number. The port number of TCP Server and TCP Client should be the same.

**Idle Timeout:** When serial port stops data transmission for a defined period of time (Idle Timeout), the connection will be closed and the port will be freed and re-try for connection with other hosts. Zero is disable this setting (default). If Multilink is configured, only the first host connection is effective for this setting.

**Alive Check:** The JetPort device will send TCP alive check package in each defined time interval (Alive Check) to remote host to test the TCP connection. If the TCP connection is not alive, the connection will be closed and the port will be freed for other hosts. Zero is disable this setting. Default time is 420.

## Service Mode- TCP Client

In TCP Client mode, you need select the Serial Port, define the destination host IP and port number, Idle timeout, Alive check. To deploy multilink, specify up to 4 more hosts IP and Port number.

## Service Mode

	<b>Port1</b>	
<b>Service Mode</b>	TCP Client Mode ▾	
<b>Destination Host</b>	0.0.0.0	: 4000
<b>Idle Timeout</b>	0	(0~65535)seconds
<b>Alive Check</b>	420	(0~65535)seconds
<b>Connect on</b>	<input checked="" type="radio"/> Startup <input type="radio"/> Any Character	
<b>Destination Host</b>	<b>Port</b>	
1.	0.0.0.0	65535
2.	0.0.0.0	65535
3.	0.0.0.0	65535
4.	0.0.0.0	65535

**TCP Server Port:** This is to assign the available TCP port number. The port number of TCP Server and TCP Client should be the same.

**Idle Timeout:** When serial port stops data transmission for a defined period of time (Idle Timeout), the connection will be closed and the port will be freed and re-try for connection with other hosts. Zero is disable this setting (default). If Multilink is configured, only the first host connection is effective for this setting.

**Alive Check:** The JetPort device will send TCP alive check package in each defined time interval (Alive Check) to remote host to test the TCP connection. If the TCP connection is not alive, the connection will be closed and the port will be freed for other hosts. Zero is disable this setting (default).

**Connect on Startup:** The TCP Client will build TCP connection once the connected serial device is startup.

**Connect on Any Character:** The TCP Client will build TCP connection once the connected serial device starts to send data.

## Service Mode- UDP

In UDP mode, you need to select the Serial Port, define the destination host IP and Local listen port number.

To create more destination hosts, specify the IP range of destination IP and send port number.

## Service Mode

<b>Port1</b>		
<b>Service Mode</b>	UDP Mode	
<b>Listen Port</b>	4000	
<b>Host start IP</b>	<b>Host end IP</b>	<b>Send Port</b>
1. 0.0.0.0	0.0.0.0	65535
2. 0.0.0.0	0.0.0.0	65535
3. 0.0.0.0	0.0.0.0	65535
4. 0.0.0.0	0.0.0.0	65535

## Management

### DI/DO Status

#### DI (Digital Input)

Can Get the status of the DI\_1, DI\_2, DI\_3 and DI\_4.

#### DO (Digital Output)

Can Get and Set the status of the DO\_1 and DO\_2.

Select the value and click **Submit** to apply the setting.

[Go to Korenix](#) • [Help](#)




### Welcome to JetPort Web Commander

**Server Configuration**

**Port Configuration**

**Management**

[DIDO Status](#)

[IP Filtering](#)

[E-mail and SNMP Trap](#)

[Event Notification](#)

**Maintenance**

#### DIDO Status

DI		
DI 1	<input checked="" type="radio"/> On	<input type="radio"/> Off
DI 2	<input checked="" type="radio"/> On	<input type="radio"/> Off
DI 3	<input checked="" type="radio"/> On	<input type="radio"/> Off
DI 4	<input checked="" type="radio"/> On	<input type="radio"/> Off
DO		
DO 1	<input type="radio"/> On	<input checked="" type="radio"/> Off
DO 2	<input checked="" type="radio"/> On	<input type="radio"/> Off

## IP Filtering

The IP Filtering is also known as Access IP Table (JetPort Commander). Access IP table specifies the IP address and subnet that can access to the device. The access is based on IP and Netmask combination.

**Note: Type the IP address and the Netmask before you click Submit. Otherwise, no user can access the device.** If the access is open to all hosts, do NOT enable this function.

**Netmask:** The Netmask of the host is 255.255.255.255.

### Access IP Setting

<input type="checkbox"/> Enable IP Filtering (Not check this option will allow any IP to have assessibility)			
No.	Activate the IP	IP Address	Netmask
1	<input type="checkbox"/>	<input type="text"/>	<input type="text"/>
2	<input type="checkbox"/>	<input type="text"/>	<input type="text"/>
3	<input type="checkbox"/>	<input type="text"/>	<input type="text"/>
4	<input type="checkbox"/>	<input type="text"/>	<input type="text"/>
5	<input type="checkbox"/>	<input type="text"/>	<input type="text"/>
6	<input type="checkbox"/>	<input type="text"/>	<input type="text"/>
7	<input type="checkbox"/>	<input type="text"/>	<input type="text"/>
8	<input type="checkbox"/>	<input type="text"/>	<input type="text"/>
9	<input type="checkbox"/>	<input type="text"/>	<input type="text"/>
10	<input type="checkbox"/>	<input type="text"/>	<input type="text"/>
11	<input type="checkbox"/>	<input type="text"/>	<input type="text"/>
12	<input type="checkbox"/>	<input type="text"/>	<input type="text"/>
13	<input type="checkbox"/>	<input type="text"/>	<input type="text"/>
14	<input type="checkbox"/>	<input type="text"/>	<input type="text"/>
15	<input type="checkbox"/>	<input type="text"/>	<input type="text"/>
16	<input type="checkbox"/>	<input type="text"/>	<input type="text"/>

Submit

## Event Notification

Specify the events that should be notified to the administrator. The events can be alarmed by means of email, SNMP trap, or system log.

Device Notification:

- Hardware Reset (Cold Start): Rebooting the JetPort will trigger the event
- Software Reset (Warm Start): Restarting the computer will trigger the event
- Login Failed: Using wrong password in console will trigger the event
- IP Address Changed: Changing network setting will trigger the event
- Password Changed: Changing the password will trigger the event
- Access IP Blocked: Report blocked IP addresses
- Redundant Power Change: Power change will trigger the event
- Redundant Ethernet Change: Ethernet master port change will trigger the event

- DI 1 Changed: DI 1 status changed will trigger the event.
- DI 2 Changed: DI 2 status changed will trigger the event.
- DI 3 Changed: DI 3 status changed will trigger the event.
- DI 4 Changed: DI 4 status changed will trigger the event.
- DO 1 Changed: DO 1 status changed will trigger the event.
- DO 2 Changed: DO 2 status changed will trigger the event.

### Event Notification

Device Notification			
Hardware Reset (Cold Start)	<input type="checkbox"/> Mail	<input checked="" type="checkbox"/> Trap	<input type="checkbox"/> Syslog
Software Reset (Warm Start)	<input type="checkbox"/> Mail	<input checked="" type="checkbox"/> Trap	<input type="checkbox"/> Syslog
Login Failed	<input type="checkbox"/> Mail	<input type="checkbox"/> Trap	<input type="checkbox"/> Syslog
IP Address Changed	<input type="checkbox"/> Mail	<input checked="" type="checkbox"/> Trap	<input type="checkbox"/> Syslog
Password changed	<input type="checkbox"/> Mail	<input type="checkbox"/> Trap	<input type="checkbox"/> Syslog
Access IP Blocked	<input type="checkbox"/> Mail	<input type="checkbox"/> Trap	<input type="checkbox"/> Syslog
Redundant Power Changed	<input type="checkbox"/> Mail	<input type="checkbox"/> Trap	<input type="checkbox"/> Syslog
Redundant Ethernet Changed	<input type="checkbox"/> Mail	<input type="checkbox"/> Trap	<input type="checkbox"/> Syslog
DI 1 Changed	<input type="checkbox"/> Mail	<input type="checkbox"/> Trap	<input type="checkbox"/> Syslog
DI 2 Changed	<input type="checkbox"/> Mail	<input type="checkbox"/> Trap	<input type="checkbox"/> Syslog
DI 3 Changed	<input type="checkbox"/> Mail	<input type="checkbox"/> Trap	<input type="checkbox"/> Syslog
DI 4 Changed	<input type="checkbox"/> Mail	<input type="checkbox"/> Trap	<input type="checkbox"/> Syslog
DO 1 Changed	<input type="checkbox"/> Mail	<input type="checkbox"/> Trap	<input type="checkbox"/> Syslog
DO 2 Changed	<input type="checkbox"/> Mail	<input type="checkbox"/> Trap	<input type="checkbox"/> Syslog

Select the events and the types of Email, SNMP Trap or Syslog, click **Submit** to enable it.

#### Port Notification:

- DCD changed: When DCD (Data Carrier Detect) signal changes, indicating the modem connection status has changed, the event will be triggered.
- DSR changed: When DSR (Data Set Ready) signal changes, indicating that the data communication equipment is powered off, the event will be triggered.
- RI changed: When RI (Ring Indicator) signal changes, indicating the incoming of a call, the event will be triggered.
- CTS changed: When CTS (Clear To Send) signal changes, indicating that the transmission between computer and DCE can proceed.
- Port connected: In TCP Server Mode, when the device accepts an incoming TCP connection, this event will be trigger. In TCP Client Mode, when the device has connected to the remote host, this event will be trigger. In Real/Virtual COM Mode, when Real/Virtual COM is ready to use, this event will be trigger.
- Port disconnected: In TCP Server/Client Mode, when the device lost the TCP link, this event will be trigger. In Real/Virtual COM Mode, When Real/Virtual COM is not available, this event will be trigger.

Port Notification			
	Port1		
DCD Changed	<input type="checkbox"/> Mail	<input type="checkbox"/> Trap	<input type="checkbox"/> Syslog
DSR Changed	<input type="checkbox"/> Mail	<input type="checkbox"/> Trap	<input type="checkbox"/> Syslog
RI Changed	<input type="checkbox"/> Mail	<input type="checkbox"/> Trap	<input type="checkbox"/> Syslog
CTS Changed	<input type="checkbox"/> Mail	<input type="checkbox"/> Trap	<input type="checkbox"/> Syslog
Port Connected	<input type="checkbox"/> Mail	<input type="checkbox"/> Trap	<input type="checkbox"/> Syslog
Port Disconnected	<input type="checkbox"/> Mail	<input type="checkbox"/> Trap	<input type="checkbox"/> Syslog

Select the target **port**, events and the types of Email, SNMP Trap or Syslog, click **Submit** to enable it.

## Email and SNMP Trap Notification

Email Server configuration includes the mail server's IP address or domain. If the authentication is required, specify the username and password. There are 4 email addresses you can specify to receive the notification.

E-mail Settings	
SMTP Server	<input type="text"/> Port <input type="text"/>
<input type="checkbox"/> My server requires authentication	
User Name	<input type="text"/>
Password	<input type="text"/>
E-mail Address 1	<input type="text"/>
E-mail Address 2	<input type="text"/>
E-mail Address 3	<input type="text"/>
E-mail Address 4	<input type="text"/>

SNMP Trap configuration includes up to 4 Trap Servers. You need to at least fill in one Trap Server's IP or domain. The Community is also required information. Do not use the “;” in this column. Location and Contact is optional information.

SNMP Trap Server	
SNMP Server 1	<input type="text"/>
SNMP Server 2	<input type="text"/>
SNMP Server 3	<input type="text"/>
SNMP Server 4	<input type="text"/>
Community	<input type="text"/>
Location	<input type="text"/>
Contact	<input type="text"/>
Syslog Server	
Syslog Server IP	<input type="text"/>
Syslog Server Port	<input type="text" value="0"/>

## Maintenance

This page allows you to Load Factory Default, Import and Export configuration file and Upgrade Firmware.

### Load Factory Default

The function will restore all JetPort setting to the factory default, except for the IP address and netmask setting.

### Import Configuration

The function will import previously saved configuration file into the JetPort

File to import:

### Export Configuration

The function will Export current configuration into a file.

### Upgrade Firmware

Specify the firmware image to upgrade.

Firmware:

**Load Factory Default:** Load default configuration except Network Settings.

**Import Configuration:** Retrieve saved configuration file to apply in the device. Click Browse to choose the configuration file then click the Import command.

**Export Configuration:** Save the current configuration into a file and save the file in current host.

**Upgrade Firmware:** Upgrade to new firmware. Click Browse to select the firmware then click Upgrade command.

## 4.2 SSH Console

For using SSH, you should open the SSH Client, assign the IP of the JetPort you'd like to access and enter the correct Username/Password, then you can enter the SSH console menu.

### SSH Client

There are many free, shareware, trial or charged SSH clients you can find in the internet. For example, PuTTY is a free and popular Telnet/SSH client, we'll use this tool to tell you how to login the JetPort by SSH. Note: *PuTTY is copyright 1997-2006 Simon Tatham.*


**Download PuTTY:** <http://www.chiark.greenend.org.uk/~sgtatham/putty/download.html>

**JetPort Settings:** Enable the "Telnet Management Enable" to enable the SSH feature of JetPort 5804/5804i. Click "Goto Telnet Management" will ask you to open the SSH client.



After modifying configuration, be sure to validate the changes by using "Apply Only" or "Apply and Save".


The copyright of **PuTTY**



### Open the PuTTY

In the Session sub-tree, enter the Host Name (IP Address of your JetPort) and Port number (default = 22). Choose the "SSH" protocol. Then click "**Open**" to start the SSH session console.





**SSH Console is opened.** The default username of the SSH public key is admin, password is admin. You can see the console as below:

Login as: admin  
[admin@192.168.10.3's](#) password: (admin)

```
*****
***      Korenix JetPort Commander      ***
*****
```

**Input System Password: \*\*\*\*\*** (The password you setup in the JetPort commander.)  
 Password confirmed. Starting Main Menu.  
 You can start to configure your JetPort by SSH console.

```
192.168.10.3 - PuTTY
login as: admin
admin@192.168.10.3's password:

*****
***      Korenix Jetport Commander      ***
*****

Input System Password: ****
Password confirmed. Starting Main Menu.
-----
[Korenix Jetport Commander]
1. Overview
2. General Settings
3. Network Settings
4. Ports settings
5. Security(Accessible IP) Settings
6. Notification(Auto Warning) Settings
C. Change Password
L. Load Factory Default
S. Save configuration
R. Reboot
Q. Exit & Logout

Select one function (1-6,C,L,S,R,Q): █
```

Type the Password you setup in the JetPort Commander.

## Configuration

Configure the device and port by pressing function number or the hinted initial.

Press “q” to exit the function.

Always press “a” to apply and save change after making a configuration.

# Appendix A

## SNMP MIB II and RS-232 Like Support

---

JetPort 5804 has built-in SNMP agent that supports SNMP trap, RFC 1317 RS-232 MIB and RFC1213 MIB-II. The following tables list SNMP variables implemented in JetPort 5804.

RFC1213 MIB-II supported SNMP variables

System MIB				
sysDescr	sysObjectID	sysUpTime	sysContact	sysName
sysLocation	sysORLastChange	sysORID	sysORDescr	sysORUpTime

Interface MIB				
ifNumber	ifIndex	ifDescr	ifType	ifMtu
ifSpeed	ifPhysAddress	ifAdminStatus	ifOperStatus	ifInOctets
ifInUcastPkts	ifInDiscards	ifInErrors	ifOutOctets	ifOutUcastPkts
ifOutDiscards	ifOutErrors	ifOutQLen	ifSpecific	

Address MIB				
atIfIndex	atPhysAddress	atNetAddress		

IP MIB				
ipForwarding	ipDefaultTTL	ipInReceives	ipInHdrErrors	ipInAddrErrors
ipForwDatagrams	ipInUnknownProtos	ipInDiscards	ipInDelivers	ipOutRequests
ipOutDiscards	ipOutNoRoutes	ipReasmTimeout	ipReasmReqds	ipReasmOKs
ipReasmFails	ipFragOKs	ipFragFails	ipFragCreates	ipAdEntAddr
ipAdEntIfIndex	ipAdEntNetMask	ipAdEntBcastAddr	ipRouteDest	ipRouteIfIndex
ipRouteMetric1	ipRouteNextHop	ipRouteType	ipRouteProto	ipRouteMask
ipRouteInfo	ipNetToMediaIfIndex	ipNetToMediaPhysAddress	ipNetToMediaNetAddress	ipNetToMediaType
ipRoutingDiscards				

ICMP MIB				
icmpInMsgs	icmpInErrors	icmpInDestUnreachs	icmpInTimeExcds	icmpInParmProbs
icmpInSrcQuenchs	icmpInRedirects	icmpInEchos	icmpInEchoReps	icmpInTimestamps
icmpInTimestampReps	icmpInAddrMasks	icmpInAddrMaskReps	icmpOutMsgs	icmpOutErrors
icmpOutDestUnreachs	icmpOutTimeExcds	icmpOutParmProbs	icmpOutSrcQuenchs	icmpOutRedirects
icmpOutEchos	icmpOutEchoReps	icmpOutTimestamps	icmpOutTimestampReps	icmpOutAddrMasks
icmpOutAddrMaskReps				

TCP MIB				
tcpRtoAlgorithm	tcpRtoMin	tcpRtoMax	tcpMaxConn	tcpActiveOpens
tcpPassiveOpens	tcpAttemptFails	tcpEstabResets	tcpCurrEstab	tcpInSegs
tcpOutSegs	tcpRetransSegs	tcpConnState	tcpConnLocalAddress	tcpConnLocalPort
tcpConnRemAddress	tcpConnRemPort	tcpInErrs	tcpOutRsts	

UDP MIB				
udpInDatagrams	udpNoPorts	udpInErrors	udpOutDatagrams	udpLocalAddress
udpLocalPort				


SNMP MIB				
snmpInPkts	snmpOutPkts	snmpInBadVersions	snmpInBadCommunityNames	snmpInBadCommunityUses
snmpInASNParseErrs	snmpInTooBig	snmpInNoSuchNames	snmpInBadValues	snmpInReadOnly
snmpInGenErrs	snmpInTotalReqVars	snmpInTotalSetVars	snmpInGetRequests	snmpInGetNexts
snmpInSetRequests	snmpInGetResponses	snmpInTraps	snmpOutTooBig	snmpOutNoSuchNames
snmpOutBadValues	snmpOutGenErrs	snmpOutGetRequests	snmpOutGetNexts	snmpOutSetRequests
snmpOutGetResponses	snmpOutTraps	snmpEnableAuthenTraps	snmpSilentDrops	snmpProxyDrops

RFC1317 R-S232 supported SNMP variables

RS-232 MIB				
rs232Number	rs232PortIndex	rs232PortType	rs232PortInSigNumber	rs232PortOutSigNumber
rs232PortInSpeed	rs232PortOutSpeed	rs232PortInFlowType	rs232PortOutFlowType	
rs232AsyncPortIndex	rs232AsyncPortBits	rs232AsyncPortStopBits	rs232AsyncPortParity	rs232AsyncPortAutobaud
rs232AsyncPortParityErrs	rs232AsyncPortFramingErrs	rs232AsyncPortOverrunErrs		
rs232InSigPortIndex	rs232InSigName	rs232InSigState	rs232InSigChanges	
rs232OutSigPortIndex	rs232OutSigName	rs232OutSigState	rs232OutSigChanges	

# Appendix B

## RS-232 Pin Assignment



Pin #	RS232	RS422	RS485 (4 wire)	RS485(2 wire)
1	DCD	RXD-	RXD-	
2	RXD	RXD+	RXD+	
3	TXD	TXD+	TXD+	DATA+
4	DTR	TXD-	TXD-	DATA-
5	GND	GND	GND	GND
6	DSR			
7	RTS			
8	CTS			
9	RI			
RS232 mode act as DTE				

Name	Notes/Description
DCD	Data Carrier Detect
RXD	Receive Data (RxD, Rx)
TXD	Transmit Data (TxD, Tx)
DTR	Data Terminal Ready
GND	Ground
DSR	Data Set Ready
RTS	Request To Send
CTS	Clear To Send
RI	Ring Indicator

## Appendix C: About Korenix

### Less Time At Work! Fewer Budgets on applications!

The Korenix business idea is to let you spend less time at work and fewer budgets on your applications. Do you really want to go through all that trouble but still end up with low quality products and lousy services? No! This is why you need Korenix. Korenix offers a complete products selection that fulfills all your needs for your applications. We bring you easier, faster, tailor-made services, and more reliable solutions. In Korenix, there is no need to compromise. Korenix takes care everything for you!

### Fusion of Outstandings

Your searching stops here. Korenix Technology is your one-stop supply center for industrial communications and networking products. Established by a group of professionals with more than 10 years of experience in the arenas of industrial control, data communications and industrial networking applications. Korenix Technology is well-positioned to fulfill your needs and demands by providing a great variety of tailor-made products and services. Korenix's industrial-grade products also come with quality services. No more searching, and no more worries. Korenix Technology stands by you all the way through.

### Core Strength---Competitive Price and Quality

With our work experience and in-depth know-how of industrial communications and networking, Korenix Technology is able to combine Asia's research / development ability with competitive production cost and with quality service and support.

### Global Sales Strategy

Korenix's global sales strategy focuses on establishing and developing trustworthy relationships with value added distributors and channel partners, and assisting OEM distributors to promote their own brands. Korenix supplies products to match local market requirements of design, quality, sales, marketing and customer services, allowing Korenix and distributors to create and enjoy profits together.

### Quality Services

**KoreCARE---** KoreCARE is Korenix Technology's global service center, where our professional staffs are ready to solve your problems at any time and in real-time. All of Korenix's products have passed ISO-9000/EMI/CE/FCC/UL certifications, fully satisfying your demands for product quality under critical industrial environments. Korenix global service center's e-mail is [koreCARE@korenix.com](mailto:koreCARE@korenix.com)

### 5 Years Warranty

Each of Korenix's product line is designed, produced, and tested with high industrial standard. Korenix warrants that the Product(s) shall be free from defects in materials and workmanship for a period of five (5) years from the date of delivery provided that the Product was properly installed and used. This warranty is voided if defects, malfunctions or failures of the warranted Product are caused by damage resulting from force majeure (such as floods, fire, etc.), environmental and atmospheric disturbances, other external forces such as power line disturbances, host computer malfunction, plugging the board in under power, or incorrect cabling; or the warranted Product is misused, abused, or operated, altered and repaired in an unauthorized or improper way

Korenix Technologies Co., Ltd.  
5F, No. 98-1, Ming-Chuan Rd., Shing Tien City, Taipei,  
TaiwanTel:+886-2-82193000 Fax:+886-2-82193300

**Business service :** [sales@korenix.com](mailto:sales@korenix.com)

**Customer service:** [koreCARE@korenix.com](mailto:koreCARE@korenix.com)

# C

## Revision History

---

Version	Description	Date
V1.0	The first released version.	Mar. 2013