

Data Links

User Guide – EDL Nano Product

AE301628-001

REV B

3 October 2019

For:

Part No. AE102474 & AE102882

Prepared by:



1775 West Hibiscus Blvd, Suite 200
Melbourne, FL 32901
(321) 984-1671

Aeronix Proprietary

Document Authorization

Review/Approval Title	Name
Originator:	S. Baduini
Approved By: Program Manager	L. Clarkson
Approved By: Quality Assurance	C. Hertzberg
Approved By: Configuration Management	D. Franks

Document Revision History

Ver/Rev	Description of Change	Chg'd By	Chg/Rel #	Date
-001/-	Initial L1 Release to CM	LC & SB	SP-2493	7/10/2019
-001/A	Release with updates for FCC testing	LC	SP-2519	9/11/2019
-001/B	Updated with FCC Statements	LC		10/3/2019

Table of Contents

1. INTRODUCTION.....	1
1.1.1. Purpose.....	1
1.2. REFERENCES	1
1.2.1. Government Documents.....	1
1.2.2. Non-Government Documents.....	1
1.3. OVERVIEW	1
1.4. NOTES FOR FCC ID	1
2. EDL NANO - ENHANCED DATA LINK (AE102429) AND RUGGED ENHANCED DATA LINK (AE102882).....	3
2.1. EDL NANO FEATURES	3
2.2. EDL NANO INSTALLATION AND STARTUP PROCEDURES.....	4
2.2.1. Input Power Supply.....	4
2.3. EDL NANO PHYSICAL I/O	6
2.3.1. USB OTG	9
2.3.2. USB Host	9
2.3.3. Ethernet 1 & 2	9
2.3.4. Console RS-232	9
2.3.5. Platform RS-232	10
2.3.6. P1 Antenna Interface TxRx 1	10
2.3.7. P2 Antenna Interface Rx 2	10
2.3.8. Tx Rx Enable.....	10
2.3.1. Tx Rx Enable 4 State (OFDM only).....	11
2.3.2. External GPIO 1 & 3	11
2.3.3. Red and Green LED.....	11
2.3.4. Tamper.....	11
2.3.5. RF Output Power	11
3. SYSTEM CONFIGURATION.....	11
3.1. AERONIX GUI INTERFACE	11
3.2. SNMP INTERFACE	12
3.3. STARTUP	12
3.4. RADIO MAINTENANCE LOGIN	12
3.4.1. Using Serial Port A.....	12
3.5. ETHERNET ALIAS IP ADDRESS	12
3.6. WEB BASED GUI SYSTEM CONFIGURATION	12
3.6.1. Base Station Status Page	13
3.6.2. Base Station Admin Page.....	17
3.6.3. Base Station Network Configuration Page.....	26
3.6.4. Base Station Profile Config Page	45
3.6.5. Base Station Radio Control.....	50
3.6.6. Base Station Maintenance Page	54
3.6.7. Base Station Video Page.....	59
3.6.8. Subscriber Station Status	61
3.6.9. Subscriber Station Admin Page	63
3.6.10. Subscriber Network Config Page.....	67
3.6.11. Subscriber Profile Config Page	69
3.6.12. Subscriber Station Radio Control Page.....	70
3.6.13. Subscriber Station Maintenance Page	74
3.6.14. Subscriber Station Video Page.....	77
3.6.15. BS and SS Common Pages	80
3.7. SNMP INTERFACE CONFIGURATION.....	90

Title: Aeronix Data Links – EDL Nano Products User Guide

3.7.1.	SNMP User Authentication.....	91
3.7.2.	SNMP examples	91
3.7.3.	SNMP Unsupported configurations.....	106
4.	DETERMINING NANO RADIO CONFIGURATION.....	106
4.1.	TWO WAYS TO DETERMINE RADIO IP ADDRESS	106
4.1.1.	Use Console.....	106
4.1.2.	Use radio's default IP address	107
5.	CHANGE RADIO IP ADDRESS VIA WEBGUI.....	107
6.	ADDING SUBSCRIBER EXAMPLE USING WEBGUI.....	108
6.1.	CONFIGURING MULTIPLE SERVICE FLOWS.....	112
7.	AERONIX SOFTWARE FEATURES.....	117
7.1.	NANO OUTPUT POWER	117
7.1.1.	View NANO output power calibration	117
7.2.	ARP TABLE FEATURE.....	122
7.2.1.	Enable Aeronix ARP feature.....	122
7.3.	AERONIX SERIAL FLOW CONTROL FEATURE.....	123
8.	RADIO PERFORMANCE	125
8.1.	GMSK NANO RF INTERFERENCE PERFORMANCE	125
8.2.	NANO GMSK RECEIVER SENSITIVITY.....	125
8.3.	OFDM NANO RF INTERFERENCE PERFORMANCE	125
8.4.	NANO OFDM RECEIVER SENSITIVITY.....	125
8.5.	DATA RATES	126
8.5.1.	OFDM Max Data Rates.....	126
8.5.2.	GMSK Data Rates.....	127
9.	MECHANICALS	129
9.1.	PART NUMBER AE102429	130
APPENDIX A: SNMP MIB.....		131
APPENDIX C: DEFINITIONS, ACRONYMS, AND ABBREVIATIONS.....		182

Table of Figures

Figure 2-1 NANO	3
Figure 2-2 NANO RF Input/Output.....	6
Figure 2-3 Nano Physical I/O	7
Figure 2-4 TR SW Timing.....	10
Figure 3-1 BS GMSK Status.....	14
Figure 3-2 BS Status GMSK RX Dual mode	16
Figure 3-3 BS Admin Page	17
Figure 3-4 BS Admin Station Names	18
Figure 3-5 BS Admin Transec Key Mgmt.....	19
Figure 3-6 BS Bridging Script and S/W Update.....	20
Figure 3-7 Example Adding a SS entry	22
Figure 3-8 Example Modify Transec Key	22
Figure 3-9 Example Modify Transec Key Result	22
Figure 3-10 Example Generate Start Script	23
Figure 3-11 Example Software Update.....	24
Figure 3-12 Example Software Update Progress	25
Figure 3-13 Software Update Result.....	25
Figure 3-14 BS Network Config.....	26
Figure 3-15 BS Network Config Network Options	26
Figure 3-16 BS Network Config Service Classes.....	27
Figure 3-17 BS Example Add Service Class	29
Figure 3-18 BS Example Modify Service Class	30
Figure 3-19 BS Provisioned SFs	30
Figure 3-20 BS Example Add Provisioned SFs.....	32
Figure 3-21 BS Example Modify Service Flow.....	32
Figure 3-22 BS Network Config Class Rules	33
Figure 3-23 BS Network Config Auto Populate.....	35
Figure 3-24 Example Auto Populate Network Layout	36
Figure 3-25 BS Example Auto Populate.....	37
Figure 3-26 BS Example Auto Populate Result.....	37
Figure 3-27 BS Example Auto Populate Additional Class Rules	38
Figure 3-28 BS Example Additional Class Rules Result.....	39
Figure 3-29 BS Example Auto Populate IP with Forwarders.....	40
Figure 3-30 BS Example Auto Populate IP with Forwarders Result.....	40
Figure 3-31 BS Example Auto Populate with MAC Address	41
Figure 3-32 BS Example Auto Populate with MAC Address Result	42
Figure 3-33 BS Example Class Rules ADD ENTRY	43
Figure 3-34 BS Example MODIFY ENTRY selection	44
Figure 3-35 BS Example MODIFY ENTRY.....	44
Figure 3-36 OFDM BS Profile Config Page.....	45
Figure 3-37 GMSK BS Profile Config Page.....	46
Figure 3-38 BS 802.16 Example Add Burst Profile	48
Figure 3-39 BS 802.16 Example Modify Burst Profile	49
Figure 3-40 OFDM BS Radio Control Page.....	50
Figure 3-41 GMSK BS Radio Control.....	51

Figure 3-42 BS GMSK Maintenance Page	55
Figure 3-43 BS Maintenance Registered SS Page	58
Figure 3-44 BS Video Page	59
Figure 3-45 SS OFDM Status Page	61
Figure 3-46 SS OFDM Status Rx Dual.....	63
Figure 3-47 SS Admin Page.....	64
Figure 3-48 SS Admin Station Name and Transec Key	64
Figure 3-49 SS Admin Start Script and SW Update	66
Figure 3-50 SS Network Config Page.....	68
Figure 3-51 SS OFDM Profile Config Page	69
Figure 3-52 SS OFDM Radio Control Page	71
Figure 3-53 SS GMSK Radio Control	72
Figure 3-54 SS OFDM Maintenance Page	74
Figure 3-55 SS Video Page.....	78
Figure 3-56 Save Settings Selection	81
Figure 3-57 Version Page	82
Figure 3-58 Maintenance Reboot Selection.....	83
Figure 3-59 Maintenance Use Default DB Selection.....	84
Figure 3-60 OFDM Maintenance System Tests Page.....	85
Figure 3-61 Maintenance Debug Page.....	88
Figure 6-1 Example Adding Subscriber Layout	108
Figure 6-2 Example Adding a Subscriber station name	109
Figure 6-3 Example Adding a Subscriber Provisioned SF	109
Figure 6-4 Example Adding a Subscriber Class Rules	111
Figure 6-5 Example Adding a Subscriber Result.....	112
Figure 6-6 Example Multiple SF Layout	113
Figure 6-7 Example Multiple SF Add SF	113
Figure 6-8 Example Multiple SF Add Class Rules.....	114
Figure 6-9 Example Multiple SF Result	116
Figure 6-10 Example Multiple SF BS Status Page	117
Figure 6-11 SS Example Multiple SF SS Status Page	117
Figure 7-1 802.16 phyEeprom interface	120
Figure 7-2 OFDM phyEeprom interace	120
Figure 7-3 GMSK powerSettings interface	121
Figure 7-4 Serial B to Serial B Exp	124
Figure 7-5 BS serial config exp	124
Figure 7-6 SS serial config exp.....	125

Table of Tables

Table 2-1. GMSK Typical Peak Current and Power 1800 MHz	4
Table 2-2. GMSK Typical Peak Current and Power 2300 MHz	4
Table 2-3. OFDM Typical Current and Power 1800 MHz	4
Table 2-4. OFDM Typical Current and Power 2300 MHz	5
Table 2-5. OFDM Typical Current and Power 2427 MHz	5
Table 2-6. Nano Hardware Interface.....	6
Table 2-7. Nano Hardware Interface.....	7
Table 2-8. J1: Main IF Pin Definitions	7
Table 2-9. J2: Camera IF Pin Definitions	9
Table 2-10 GMSK 14 MHz T/R SW Timing	10
Table 2-11 OFDM T/R SW Timing.....	11
Table 3-1. Base Station Status Page	14
Table 3-2. Base Station Status Page RX Dual Mode.....	16
Table 3-3. BS Admin Page Station Names.....	18
Table 3-4. BS Admin Transec Key Mgmt	19
Table 3-5. BS Admin Start Script and S/W Update.....	20
Table 3-6. Base Station Network Config Network Options	27
Table 3-7. Base Station Network Config Service Class	28
Table 3-8. Base Station Network Config Service Class	30
Table 3-9. Base Station Network Config Service Class	33
Table 3-10. Base Station Network Config Auto Populate	35
Table 3-11. Base Station Profile Config Page	46
Table 3-12. Base Station Radio Control	51
Table 3-13. Base Station Maintenance Page.....	55
Table 3-14. Base Station Video Page.....	59
Table 3-15. Subscriber Station Status Page	62
Table 3-16. Subscriber Station Admin Page Transec Key.....	65
Table 3-17. Subscriber Station Admin Page Transec Key.....	66
Table 3-18. Subscriber Station Network Config.....	68
Table 3-19. Subscriber Profile Config Page	69
Table 3-20. Subscriber Station Radio Control	72
Table 3-21. Subscriber Station Maintenance Page	75
Table 3-22. Subscriber Station Video Page	78
Table 3-23. Version Page.....	82
Table 3-24. Maintenance System Tests Page.....	85
Table 3-25. Maintenance Debug Page	88
Table 6-1. Adding Multiple Service Flow Class Rule	114
Table 7-1. Transmit Calibration interface.....	122
Table 8-1. GMSK Receiver SNR Assumptions.....	125
Table 8-2 OFDM. 14MHz Receiver SNR Assumptions.....	126
Table 8-3 OFDM. 7MHz Receiver SNR Assumptions.....	126
Table 8-4 OFDM. 3.5 MHz Receiver SNR Assumptions.....	126
Table 8-5. 3.5 MHz BW Max Data Rates.....	127
Table 8-6. 7 MHz BW Max Data Rates.....	127
Table 8-7. 14 MHz BW Max Data Rates.....	127

Table 8-8. 14 MHz BW GMSK Max Data Rates 128

1. Introduction

1.1.1. Purpose

User guide for Aeronix EDL Nano based family of data links. This user guide has information based on the NANO GMSK and OFDM software release.

1.2. References

The following documents are referenced in or were used in the preparation of this document:

1.2.1. Government Documents

None.

1.2.2. Non-Government Documents

- [1] “IEEE STD 802 2004 Part 16d: Air Interface for Fixed Broadband Wireless Access Systems”
Revision 2004. June 24,2004
- [2] “IEEE STD 802 2005 Part16e: Air Interface for Fixed and Mobile Broadband Wireless Access
System Amendment for Physical and Medium Access Control Layers for Combined Fixed and
Mobile Operation in Licensed Bands” Revision 2005.
- [3] AE301432-001 : Report RF Statistics Via Ethernet Interface Description

1.3. Overview

This user guide provides information deemed necessary to bring up the following radio products from point of delivery:

- Part No. AE102429 – EDL Nano Digital Data Link
- Part No. AE102882 – EDL Nano Digital Data Link Rugged

(WARNING: DO NOT POWER UP WITHOUT A LOAD ON THE ANTENNA PORT)

1.4. Notes for FCC ID

FCC testing was completed using GMSK low power mode (30 dBm) and frequencies within the ISM Band (2400 – 2483.4 MHz).

Exposure Statement:

RF Exposure WARNING: This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20 cm between the radiator and your body.

Title: Aeronix Data Links – EDL Nano Products User Guide

At 1000 mW Power (1W) and Antenna Gain of 4 (6 dB), and a minimum distance of 20cm (min separation distance for “Mobile Devices”).

$S = 0.8 \text{ mW/cm}^2$, which is less than the Uncontrolled Exposure Maximum Permissible Exposure (MPE) limit.

For radios labeled with FCC ID T2KAE102882 the following applies:

	FCC Part 15.19 Warning Statement- (Required for all Part 15 devices)
	THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRE OPERATION.
	FCC Part 15.21 Warning Statement-
	NOTE: THE GRANTEE IS NOT RESPONSIBLE FOR ANY CHANGES OR MODIFICATIONS NOT EXPRESSLY APPROVED BY THE PARTY RESPONSIBLE FOR COMPLIANCE. SUCH MODIFICATIONS COULD VOID THE USER’S AUTHORITY TO OPERATE THE EQUIPMENT.

2. EDL Nano - Enhanced Data Link (AE102429) and Rugged Enhanced Data Link (AE102882)

This unit is a software reprogrammable data link. This unit supports both Aeronix LAW functionality, GMSK waveform and video compression capabilities. The EDL Nano operates over the frequency band of 1.8 to 2.5 GHz with the appropriate antenna systems. **(WARNING: DO NOT POWER UP WITHOUT A LOAD ON THE ANTENNA PORT).**

Note: The pictures in this section are from AE102429. But, AE102882 operates the same and is just in a different housing.



Figure 2-1 NANO

2.1. EDL Nano Features

- Software Reprogrammable Radio
- Simple yet powerful GUI for radio configuration.
- Option to use SNMP for radio configuration
- Frequency Range 1.8-2.4 GHz in 1 MHz steps
- Linux OS on Quad Core Processor
- Xilinx Artix 200 FPGA
- Diversity Receive
- Less than 4 cubic inches
- Aeronix provided OFDM and GMSK Waveforms available

2.2. EDL Nano Installation and Startup Procedures

2.2.1. Input Power Supply

The EDL unit requires a voltage be provided between 8 – 18V. Application of power to the data link turns on the system.

2.2.1.1. NANO GMSK current and power measurements

Below is a measurement of the maximum current draw from a NANO GMSK radio over a period of time.

Table 2-1. GMSK Typical Peak Current and Power 1800 Mhz				
Description	Voltage (VDC)	Current (mA)	Power (W)	Tx power dBm
BS Tx 50% ,50% Rx, data, Hi Power	12	1496	18.900	35
BS Tx 50% ,50% Rx, data, Low Power	12	1425	17.100	33
BS Tx 70% , 30% Rx, data, Hi Power	12	1794	21.528	35
BS Tx 70% , 30% Rx, data, Low Power	12	1600	19.200	33
BS Tx/Rx Off	12	411	4.932	N/A

Table 2-2. GMSK Typical Peak Current and Power 2300 MHz				
Description	Voltage (VDC)	Current (mA)	Power (W)	Tx power dBm
BS Tx 50% ,50% Rx, data, Hi Power	12	1275	15.300	35
BS Tx 50% ,50% Rx, data, Low Power	12	996	11.952	33
BS Tx 70% , 30% Rx, data, Hi Power	12	1419	17.028	35
BS Tx 70% , 30% Rx, data, Low Power	12	1235	14.820	33
BS Tx/Rx Off	12	408	4.896	N/A

2.2.1.2. NANO OFDM current and power measurements

Measurements were taken at room temperature (25 C).

Table 2-3. OFDM Typical Current and Power 1800 MHz				
Description	Voltage (VDC)	Current (mA)	Power (W)	TX power (dBm)
BS Tx 50% data, no video, Hi data rate	12	920	11.0	31
BS Tx 50% data, no video, Hi power	12	965	11.6	33
BS Tx 70% data, no video, Hi data rate	12	945	11.3	31
BS Tx 70% data, no video, Hi power	12	995	11.9	33

Table 2-3. OFDM Typical Current and Power 1800 MHz				
Description	Voltage (VDC)	Current (mA)	Power (W)	TX power (dBm)
BS Tx/Rx Off	12	600	7.2	N/A

Table 2-4. OFDM Typical Current and Power 2300 MHz				
Description	Voltage (VDC)	Current (mA)	Power (W)	TX power (dBm)
BS Tx 50% data, no video, Hi data rate	12	845	10.1	29
BS Tx 50% data, no video, Hi power	12	870	10.4	32
BS Tx 70% data, no video, Hi data rate	12	850	10.2	29
BS Tx 70% data, no video, Hi power	12	880	10.6	32
BS Tx/Rx Off	12	600	7.2	N/A

Table 2-5. OFDM Typical Current and Power 2427 MHz				
Description	Voltage (VDC)	Current (mA)	Power (W)	TX power (dBm)
BS Tx 50% data, no video, Hi data rate	12	910	10.9	30
BS Tx 50% data, no video, Hi power	12	930	11.2	33
BS Tx 70% data, no video, Hi data rate	12	915	11.0	30
BS Tx 70% data, no video, Hi power	12	940	11.3	33
BS Tx/Rx Off	12	600	7.2	N/A

2.3. EDL Nano Physical I/O

The front panel of an EDL Nano is shown in the following figure. Indicated ports are described below.




Figure 2-2 NANO RF Input/Output

The back panel of an EDL Nano is shown in the following figure. Indicated connectors are described below.

Table 2-6. Nano Hardware Interface			
Connector	Description	EDL Connector	Mating Connector
P1	Tx/Rx1: Female SMA connector connects to the desired antenna	Male SMA	Female SMA
P2	Rx2: Female SMA connector connects to the desired antenna	Male SMA	Female SMA



Figure 2-3 Nano Physical I/O

Table 2-7. Nano Hardware Interface			
Connector	Description	EDL Connector	Mating Connector
J1	Main IF: Header 2x20	Molex 501571-4007	Molex 501189-4010
J2	Camera IF: Header 2x10	Molex 501571-2007	Molex 501189-2010

Table 2-8. J1: Main IF Pin Definitions	
Pin	Description
1	8-18 VDC
2	Ground

Title: Aeronix Data Links – EDL Nano Products User Guide

3	8-18 VDC
4	Ground
5	8-18 VDC
6	Ground
7	Platform RS-232 Rx
8	USB OTG VBUS
9	Platform RS-232 Tx
10	USB OTG DP
11	Ext GPIO 0 – External Tx Enable (1.8V)
12	USB OTG DN
13	Ext GPIO 2 – External Rx Enable (1.8V)
14	Ground
15	Ext GPIO 1
16	Console RS-232 Tx
17	Ext GPIO 3
18	Console RS-232 Rx
19	Green LED
20	Ground
21	Red LED
22	Ground
23	RX TX Enable
24	Ground
25	TAMPER
26	Ground
27	VBUS 5V
28	USB Host DN
29	Ground
30	USB Host DP
31	Ether2 Tx+
32	Ether1 Tx+
33	Ether2 Tx-
34	Ether1 Tx-
35	Ground
36	Ground
37	Ether2 Rx+
38	Ether1 Rx+
39	Ether2 Rx-
40	Ether1 Rx-

Table 2-9. J2: Camera IF Pin Definitions	
Pin	Description
1	3 VDC
2	Ground
3	CAM SDA
4	CAM CLK
5	CAM SCL
6	CSI D3P
7	CAM EN
8	CSI D3M
9	CAM RST#
10	Ground
11	CSI D0P
12	CSI D2P
13	CSI D0M
14	CSI D2M
15	Ground
16	Ground
17	CSI D1P
18	CSI CLKDP
19	CSI D1M
20	CSI CLKDM

2.3.1. USB OTG

USB OTG port is currently only used to download initial firmware. Software to use the USG OTG to recognize other applications has not been implemented.

2.3.2. USB Host

Software has not been formally tested.

2.3.3. Ethernet 1 & 2

Ethernet ports are both IEEE802.3 compliant 10/100 Mbps connection. Ethernet 1 is the primary Ethernet for the radio. Ethernet 2 currently is not configurable and usable on the radio.

2.3.4. Console RS-232

The Serial interface allows direct communication with the radio's control processor. This interface is a RS-232 standard interface. Port is configured as 8-N-1, 115200 BAUD. This port provides the radio's login console. You can login with administrative privileges by entering "root" at the login prompt and password "1234".

2.3.5. Platform RS-232

Serial interface is for serial to serial communication. This interface is a RS-232 standard interface. The debug port is configured as 8-N-1, the BAUD rate is configurable via the webgui or SNMP. This interface is used to pass serial data from a BS serial port to one of its SS serial port.

2.3.6. P1 Antenna Interface TxRx 1

The antenna interface is an SMA connector that provides both input and output RF signalling.

2.3.7. P2 Antenna Interface Rx 2

The antenna interface is an SMA connector that provides input RF signalling.

2.3.8. Tx Rx Enable

The Tx/Rx Enable is a three state condition. It requires an external pull-up resistor of 4.7 kilo ohms to supply voltage V (customer determined with a max of 5V), see diagram below.




Figure 2-4 TR SW Timing

Table 2-10 GMSK 14 MHz T/R SW Timing		
Marker	Time (us)	Description
t1	TBD	Minimum time from Tx Enable Active to start of Transmit Out
t2	TBD	Minimum time from Transmit Out Complete to Tx Enable Inactive
t3	TBD	Minimum Time from Rx Enable Active to Receive energy
t4	TBD	Minimum time from Receive Energy Complete to Rx Enable Inactive
t5	TBD	Minimum switching time, ie minimum amount of Idle time before a radio will switch between Rx and Tx state or Rx and Rx state

Table 2-11 OFDM T/R SW Timing		
Marker	Time (us)	Description
t1	12 us	Minimum time from Tx Enable Active to start of Transmit Out
t2	0	Minimum time from Transmit Out Complete to Tx Enable Inactive
t3	80 us	Minimum Time from Rx Enable Active to Receive energy
t4	11 us	Minimum time from Receive Energy Complete to Rx Enable Inactive
t5	10.5 us	Minimum switching time, ie minimum amount of Idle time before a radio will switch between Rx and Tx state or Rx and Rx state

2.3.1. Tx Rx Enable 4 State (OFDM only)

External Tx and Rx control lines with 1.8V logic.

2.3.2. External GPIO 1 & 3

Not Used

2.3.3. Red and Green LED

The external Red and Green LEDs will give the user some basic status of the radios current state.

- Green only LED on -> The NANO is in sync with another radio
- Red only LED on -> The Nano's RF is turned off via the software Tx/Rx enable/disable setting.
- Green and Red LED on (Yellow) -> The NANO RF is on, but NOT in sync with another radio.

2.3.4. Tamper

Not Used

2.3.5. RF Output Power

The NANO output power will remain unchanged regardless of the RF environment. The NANO output power is based on frequency and is calibrated per Radio Card. Each radio will have its own calibration programmed and available for the user to view. Each NANO may vary from 1-2 dB of output power. See section 7.1 NANO output power for more information on determining the output power measured on a particular frequency.

3. System Configuration

3.1. Aeronix GUI interface

This simple yet powerful GUI uses uncomplicated intuitive screens to allow the average user the ability to:

- Configure the system for their network
- Make the system operational
- Perform maintenance

The GUI screens and all their respective elements are described in the following subsections.

To get to the main page, type the following URL: `http://<ip address of the radio>/`

The recommended browsers to use are Internet Explorer Version 7 or newer and Mozilla Firefox.

3.2. SNMP interface

The NANO can be configured to run the Aeronix SNMP agent, and process SNMP (Simple Network Management Protocol) requests using the radio's IP. This allows the user to configure and monitor the radio over an IP network.

3.3. Startup

Each unit is configured with an IP address. Using the IP address, one can access the GUI which can be used for configuring the radio to the user's specifications. The typical factory default IP address that is set from the factory is 192.168.1.1 and the units default configuration is that of subscriber 1, unless specified otherwise. To browse the GUI type in the IP address of the unit in an internet browser. More information about the GUI screens and how to configure the unit can be found in this section.

3.4. Radio Maintenance Login

3.4.1. Using Serial Port A

- 1) Make sure antenna port has a load on it.
- 2) Apply appropriate power to unit.
- 3) Connect to Serial A port with terminal emulator. (Baud = 115200, 8-N-1 no flow control)
- 4) Login by typing "root"
- 5) Enter password "1234".
- 6) `$ cd /mnt/jffs2`

3.5. Ethernet alias IP address

The user can always access the radio over its Ethernet alias IP address of 169.254.1.1. This IP is consistent so if the user needs to access the GUI or SNMP and has forgotten the configured IP address for the radio's Ethernet, then the user can access 169.254.1.1.

3.6. WEB Based GUI System Configuration

This simple yet powerful GUI uses uncomplicated intuitive screens to allow the average EDL user:

- Configure the system for their network
- Take the system operational
- Perform maintenance

The GUI screens and all their respective elements are described in the following subsections.

To get to the main page, types the following URL: <http://<ip address of the radio>/>

The recommended browsers to use are Internet Explorer Version 8 or newer and Mozilla Firefox.

The sections below show screen shots using either OFDM or GMSK mode. If there is a difference in the GMSK versus OFDM screen captures then both captures will be displayed.

3.6.1. Base Station Status Page

The base station status page is the default page displayed when the radio's IP address is entered. The status page lists the current active subscribers received by the BS. It also lists the current configuration of the base station.

There are attributes each web page share, these are highlighted by items A and B in the image below.

A	This section displays the current mode radio is in and the HTML links to the all of the pages available.
B	The radio's configured name and IP address, located on the web page tab.

Base Station Status Page

Status

MAC Address: 00-61-65-6E-64-00
Current Channelization: 14 MHz
Current Channel: Custom (2.500 GHz)
BS Estimated EIRP: 30 dBm
Tx: ON
Rx: ON
Transec: OFF

Board Details

CPU	RF
Temperature	Temperature
41 C 105.8 F	50 C 122.0 F

Tx/Rx Over the Air Status

Front Panel: Base Sync Rcv Xmt Alarm

Subscriber Name	Current Rx Modulation Type	Rx Signal Strength	RSSI (dBm)	Service Flow	State	Est. Tx User B/W (Mbits/s)	Est. Tx Allocated B/W (Mbits/s)	Service Flow Oversubscribed
NA	NA	NA	--	DL_MULTICAST	Active	0.00	0.00	0
SS-1	8 PPS 3/4	Good	-78	BE_MAX	Active	0.00	2.82	0

Figure 3-1 BS GMSK Status

Table 3-1. Base Station Status Page		
	Field/Control	Description
1	Status	Status displays a subset of current settings. • MAC Address – The IEEE 802.16 MAC address of the base station • Current Channelization – Displays the channelization of the base station. The channelization may be changed on the Radio Control Screen. • Current Channel – The current 802.16 specified channel that the base station uses for transmit and receive. The channel may be changed on the Radio Control screen. • BS Estimated EIRP – Displays the estimated EIRP of the base station based upon user configured gain a loss values. (Est Tx Pwr + Antenna Gain – External Tx Cable Loss – Antennal Cable Loss – Internal Tx Loss) • Tx - Provides the status of the transmit portion of the unit. (On/Off) The status may be changed on the Radio Control screen. • Rx - Provides the status of the receive portion of the unit. (On/Off) The status may be changed on the Radio Control screen. • Transec Status – Displays the status of Transec (on or off). The Transec status can be changed on the Admin Screen.
2	Board Details	Display Temperature • CPU Temperature – Displays the temperature reported by the processor in Celsius and Fahrenheit • RF Temperature – Displays the temperature reported by the AD9361 chip on the RF card in Celsius and Fahrenheit
3	Front Panel	Displays PHY status on an interval basis. Base is a constant green light if the radio is configured as a Base Station • Sync is off on the base station when no subscribers are registered and is illuminated continuously when subscribers are registered. • Recv is green when the radio is receiving messages • Xmit is green when the radio is transmitting data • Alarm

Table 3-1. Base Station Status Page		
	Field/Control	Description
4	Tx/Rx Over the Air Status	The first part of the Tx/Rx Status Table Displays the receive status of each subscriber connection. The second part of the table is the amount of data the BS is transmitting to each active SS. - Subscriber Name - Configured Subscriber's name. - Current Modulation Type – Contains the current modulation/FEC type for the subscriber connection. The display show the modulation of the receive frame at the time sampled. - Rx Signal Strength: Contains an assessment of the receive signal strength. - RSSI (dBm) – Display the RSSI value measured at the P1 antenna port. See Figure 3-2 BS Status GMSK RX Dual mode for RX Dual mode display - Service Flow – Identifies the service class of the service flow for the connection. - State – Displays the state of the connection. The valid values are provisioned and active. - Est User B/W (Mbits/sec) – Displays the estimated bandwidth in megabits per second being used by the connection in the transmit direction. - Est Allocated B/W (Mbits/sec) – Displays the estimated bandwidth in megabits per second being allocated to the connection in the transmit direction. - Service Flow Oversubscribed – Displays the number of Ethernet packets dropped because the number of packets for that specific service flow has reached its limit and is full.

3.6.1.1. Base Station Status Page in Receive Dual

When the user enables RX Dual on the Radio control page the second receive RSSI will be reported on the RSSI1 column on the Tx/Rx Over the Air Status section.

Title: Aeronix Data Links – EDL Nano Products User Guide

Tx/Rx Over the Air Status									
Front Panel:		Base 		Sync 		Rcv 		Xmt 	
								Alarm 	
Subscriber Name	Current Rx Modulation Type	Rx Signal Strength	RSSI0 (dBm)	RSSI1 (dBm)	Service Flow	State	Est. Tx User B/W (Mbits/s)	Est. Tx Allocated B/W (Mbits/s)	Service Flow Oversubscribed
NA	NA	NA	--	--	DL_MULTICAST	Active	0.00	0.00	0
SS-1	8 PPS 3/4	Excellent	-22	-21	BE_MAX	Active	0.00	2.65	0

Figure 3-2 BS Status GMSK RX Dual mode

Table 3-2. Base Station Status Page RX Dual Mode		
	Field/Control	Description
	Tx/Rx Over the Air Status	The first part of the Tx/Rx Status Table Displays the receive status of each subscriber connection. The second part of the table is the amount of data the BS is transmitting to each active SS. - Subscriber Name - Configured Subscriber's name. - Current Modulation Type – Contains the current modulation/FEC type for the subscriber connection. The display show the modulation of the receive frame at the time sampled. - Rx Signal Strength: Contains an assessment of the receive signal strength. - RSSI0 (dBm) – Display the RSSI value measured at the P1 antenna - RSSI1 (dBm) – Display the RSSI value measured at the P2 antenna - Service Flow – Identifies the service class of the service flow for the connection. - State – Displays the state of the connection. The valid values are provisioned and active. - Est User B/W (Mbits/sec) – Displays the estimated bandwidth in megabits per second being used by the connection in the transmit direction. - Est Allocated B/W (Mbits/sec) – Displays the estimated bandwidth in megabits per second being allocated to the connection in the transmit direction. - Service Flow Oversubscribed – Displays the number of Ethernet packets dropped because the number of packets for that specific service flow has reached its limit and is full.

If the OFDM base station is no longer receiving valid receive information for a connection, the row for that connection will be displayed in red, which could mean the data is stale. If the base

The admin page allows administration of station names for the base station and subscribers. It also provides the capability to enable and disable TRANSEC and the selection of the TRANSEC key. Start script generation and software download are also supported on the admin page.

Station Names

My Name: BS

My Name:

Set

Subscribers		
Num	Subscriber Name	MAC Address
1	SS-1	00-61-65-6E-64-01
2	SS-2	00-61-65-6E-64-02

ADD ENTRY
MODIFY ENTRY ...
REMOVE ENTRY ...
CANCEL

Figure 3-4 BS Admin Station Names

Table 3-3. BS Admin Page Station Names		
	Field/Control	Description
1	My Name	Displays the current name of the base station.
2	My Name	Provides the capability to change or set the name of the base station. Type in the desired name and click the set button. The new name will automatically be distributed throughout the system
3	Subscribers	Relates a Subscriber's MAC Address with a user friendly name. • Number : Auto incrementing number. • Subscriber-Name: A unique name for the Subscriber, this is an alphanumeric string that will identify the SS. • MAC Address: MAC – the IEEE 802.16 MAC address of the subscriber station. The MAC address should be of the format 00-61-65-6E-64-XX where XX is the subscriber number in the system. The subscriber number is configured in the start script as part of the start script generation which is described later in this section of the document. The user can configure up to 32 subscribers for the network. • Add Entry Button – Add Subscriber to network • Modify Entry – Modify Subscriber Station entry • Remove Entry – Remove Subscriber Station Note: A subscriber's information must be added here first before moving on to adding a Provisioned Service Flow for it. Note: The BS will only allow a max of 10 Subscribers to be configured.

3.6.2.1. BS Admin Transec Key Management

Transec Key Management
Transec: OFF
Current Key Length: 256 bits

Transec:
Key Length

Load Key:
Current Key: EFF

Figure 3-5 BS Admin Transec Key Mgmt

Table 3-4. BS Admin Transec Key Mgmt		
	Field/Control	Description
	Transec Key Management	Displays the settings for Transec capability. - Transec - Displays current Transec state (ON/OFF). - Transec Enable/Disable buttons - Ability to enable or disable. - Key Length drop down menu – Allows user to specify the number of bits for the Transec Key - Load Key – Allows the ability to change the Transec Key in hexadecimal based on Key length. - Current Key – Displays the current key.

3.6.2.2. BS Admin Bridging Start Script and Software Update

Bridging is the default mode for operating the units. The Generate Bridging Start Script section of the admin page allows for configuration of the start script. Once the configuration is set by selecting the Generate Script button the unit must be rebooted or power cycled for the configuration to take effect.

Title: Aeronix Data Links – EDL Nano Products User Guide

Generate Bridging Start Script

Current Type: bs

Current Id: 0

Current User Interface: webgui

Quagga: Disabled

Current IPv4 Address: 192.168.100.1

Current IPv4 Netmask: 255.255.0.0

Current Vlan ID: Unknown

Current IPv6 Address: Unknown

Current IPv6 Netmask: Unknown

Current IPv4 Gateway: Unknown

Current IPv6 Gateway: Unknown

Current IPv6 Dest Net: Unknown

Current IPv6 Dest Mask: Unknown

☒ Base Station (ID Opt)
 ☐ Subscriber (ID Req)

Id:

User Interface: ☒ Webgui ☐ SNMP

Quagga: ☐ Enable ☒ Disable

IPv4 Address:

IPv4 Netmask:

Vlan ID (Optional):

IPv6 Address (Optional):

IPv6 Netmask (Optional):

IPv4 Default Gate (Opt):

IPv6 Default Gate (Opt):

IPv6 Dest Network:

IPv6 Dest Net Mask:

Software Update

File Path:

Figure 3-6 BS Bridging Script and S/W Update

Table 3-5. BS Admin Start Script and S/W Update		
	Field/Control	Description
1	Current Start Script	The current start script parameters.
2	Generate Script	User can change the mode the radio boots in or the IP address,etc. The unit should not be powered cycled while script generation is in process. - Type radio buttons: Select BS or SS for type - Id: If setting up start script as SS enter its Subscriber Number. - User Interface radio buttons: NANO can be statistics and configuration can be monitored using either the webgui interface or the SNMP interface - Click on the radio button for the desired interface - Quagga radio buttons: Option to enable additional network routing software suite providing implementations of Open Shortest Path First (OSPF). Note there is user configuration necessary to implement Quagga, this information is not covered in this document.

Table 3-5. BS Admin Start Script and S/W Update		
	Field/Control	Description
		- IPv4 Address: Provides the capability to set a new IPv4 address for the unit. - IPv4 Netmask: Provides the capability to set a new IPv4 netmask address for the unit - IPv4 Default Gate (Opt) : Optional ability to configure an IPv4 default gateway. - Vlan ID (Optional) : Allows user to add a VLAN ID to IP packets coming from radio. The radio will pass VLAN tagged packets unmodified, so this does not need to be set to allow VLAN packets to flow through the radio. Only if communication to the radio needs to have a VLAN ID. - IPv6 Default Gate (Opt) : Optional ability to configure an IPv6 default gateway. - IPv6 Address (Optional) : Optional IPv6 address for the Ethernet (Note : current release of EDL does not support IPv6) - IPv6 Netmask (Optional) : Optional IPv6 netmask for IPv6 address (Note: current release of EDL does not support IPv6) - Generate Script Button : Generates a new start script for the unit with the values input in the “Generate Bridging Start Script” section of the Admin page. Once the script has been generated, the unit must be rebooted or power cycled for the new values to take effect. The unit should not be power cycled while script generation is in process.
3	Software Update	Allows user to select a signed package file provided by the manufacturer to update the software on the unit. - File Path – Allows users to browse to location where the package file resides. - Start Update - Selection of the start update button starts the software update using the factory signed package file specified in the File Path. Once the update process begins, any interruption can render the box unusable and require its return to the factory.

3.6.2.3. Example Adding a SS Entry

A subscriber must be added here in order to continue configuring that subscriber in network. Enter a name for the subscriber and then a IEEE 802.16 MAC address for the subscriber station. The MAC address should be of the format 00-61-65-6E-64-XX where XX is the subscriber number in the system. The subscriber number is configured in the start script as part of the subscriber start script generation which is described later in this section of the document.

The system will allow the user to configure 10 Subscribers.

Station Names

My Name: BS

My Name:

Subscribers			
Num	Subscriber Name	MAC Address	
1	SS-1	00-61-65-6E-64-01	
2	SS-2	00-61-65-6E-64-02	
3	SS-3	00-61-65-6E-64-03	ADD

Figure 3-7 Example Adding a SS entry

3.6.2.4. Example Modify Transec Key

The following screen shows an example for updating a Transec key in the base station. The key is a 256 bit hexadecimal value. User must enter a new value in the 'Load Key' entry box. Then the user must click on the 'Load Now' Button.

Transec Key Management

Transec: OFF

Transec:

Load Key:

Current Key: EFEFFF

Figure 3-8 Example Modify Transec Key

Once the user clicks on the 'Load Now' button the Transec key will be updated.

Transec Key Management

Transec: OFF

Transec:

Load Key:

Current Key: 123456789ABCDEF123456789ABCDEF123456789ABCDEF123456789ABCDEF1234

Figure 3-9 Example Modify Transec Key Result

In order for the Transec Key to be saved to the database for future use, the user must select the 'Save Settings' Button on the left menu (not shown in picture above, refer to 3.6.15.1 Save Settings Button).

3.6.2.5. Generate Bridging Start Script Example

Bridging is the default mode for operating the units. The Generate Bridging Start Script section of the admin page allows for configuration of the start script. Once the configuration is set by selecting the Generate Script button the unit must be rebooted or power cycled for the configuration to take effect. In this example below depicts new BS start script with an IPv4 address of 10.1.100.1.

Generate Bridging Start Script	
Current Type: bs	☒ Base Station (ID Opt) ☐ Subscriber (ID Req)
Current Id: 0	Id:
Current User Interface: webgui	User Interface: ☒ Webgui ☐ SNMP
Quagga: Disabled	Quagga: ☐ Enable ☒ Disable
Current IPv4 Address: 192.168.100.1	IPv4 Address: 192.168.1.1
Current IPv4 Netmask: 255.255.0.0	IPv4 Netmask: 255.255.0.0 x
Current Vlan ID: Unknown	Vlan ID (Optional):
Current IPv6 Address: Unknown	IPv6 Address (Optional):
Current IPv6 Netmask: Unknown	IPv6 Netmask (Optional):
Current IPv4 Gateway: Unknown	IPv4 Default Gate (Opt):
Current IPv6 Gateway: Unknown	IPv6 Default Gate (Opt):
Current IPv6 Dest Net: Unknown	IPv6 Dest Network:
Current IPv6 Dest Mask: Unknown	IPv6 Dest Net Mask:
Generate Script	

Figure 3-10 Example Generate Start Script

The left section of the Generate Bridging Start Script will display the current start script settings. The right section displays the changes the user desires to make to the start script. Once the ‘Generate Script’ button is selected, the old start script will be overwritten with the new start script changes. Once a reboot or power cycle occurs the new changes will take effect.

3.6.2.6. Software Update Example

The following screens show an example of the software update process. When the user selects the ‘Browse’ button a window will pop up allowing the user to locate the package file. A user browses to the location of the manufacturer signed package file and selects the Start Update button. After a few seconds the update process begins. **This process should not be interrupted.** When the process completes, the unit reboots and the new software executes. If problems occur during software update the error can be viewed via the webgui after reboot or via the serial console.

Title: Aeronix Data Links – EDL Nano Products User Guide

Transec Key Management

Transec: ON

Current Key Length: 256 bits

Transec:

Key Length: 256

Load Key: 0

Choose File to Upload

Computer > Windows7_OS (C:) > SoftwareUpdate

Search SoftwareUpdate

Name	Date modified	Type
NanoRelease.pkg	6/9/2017 10:19 AM	PKG File

File name: All Files (*.*)

☐ Subscriber (ID Req)

☒ Webgui ☐ SNMP

☐ Enable ☒ Disable

168.1.1

255.0.0

Software Update

File Path:

Figure 3-11 Example Software Update

The picture below displays the results when the ‘Start Update’ button is selected. The software update process begins and the GUI displays the software update page. **This process should not be interrupted.**




Figure 3-12 Example Software Update Progress

When the software update is complete the radio will reboot. When the radio completes startup, the Webgui will default back to the SW Update page and display the results of the software update.




Figure 3-13 Software Update Result

3.6.3. Base Station Network Configuration Page

The base station network configuration screen allows the administrator to configure the 802.16d quality of service parameters and the traffic flow through network.

AERONIX 802.16 Tactical Radio

Base Station Bridging Mode

Network Options

Forward Multicast Status: ENABLED Forward Multicast Status

Classifiers Status: ENABLED Classifiers Status

ARP Table Status: ENABLED ARP Table Status

ARP Forwarding Status: ENABLED ARP Forwarding Status

Service Classes

Index	Name	Schedule Type	Max Rate	Min Rate	Priority
1	DL_MULTICAST	Best Effort	6096 Kbps	3657 Kbps	1
2	initial	Best Effort	5885 Kbps	1 Kbps	1
3	little	Best Effort	100 Kbps	1 Kbps	1
4	middle	Best Effort	2500 Kbps	1 Kbps	1
5	BE_MAX	Best Effort	50000 Kbps	1000 Kbps	1

Provisioned SFs

Subscriber Name	Downstream SF Id	Upstream SF Id	Service Class	UL Multicast Select
SS-1	4	5	BE_MAX	
SS-2	6	7	BE_MAX	

Class Rules

Address Mode: MAC

Forwarders Enabled: NO

Non-Forwarder Count: 0

Forwarder Count: 0

Current Page: 1 of 1

Index	SF	Src MAC	Src Mask	Dest MAC	Dest Mask
No Class Rules Found					

Figure 3-14 BS Network Config

3.6.3.1. Base Station Network Options

Network Options

Forward Multicast Status: ENABLED Forward Multicast Status

Classifiers Status: ENABLED Classifiers Status

ARP Table Status: ENABLED ARP Table Status

ARP Forwarding Status: ENABLED ARP Forwarding Status

Figure 3-15 BS Network Config Network Options

Table 3-6. Base Station Network Config Network Options		
	Field/Control	Description
1	Network Options	- Forward Multicast Status : This allows the BS to re-direct Multicast messages from one Subscriber to remaining Subscribers through the BS RF interface. If this is disabled Multicast messages will not be forwarded from one SS to another. - Classifier Status : Disables or Enables using the Classifier Rules Table. See 3.6.3.7 Base Station Network Config Class Rules - ARP Table Status: Disables or Enables the ARP Table Feature. See 7.2 ARP Table feature - ARP Forwarding Status : Disables or Enables the ability for Subscribers to pass data between each other. This is only an option on the BS.

3.6.3.2. Base Station Network Config Service Classes

Service classes define the parameters for the 802.16d quality of services that are used to schedule the traffic throughout the network. A total of 12 service classes can be configured on the base station.

Service classes define the 802.16d scheduling type parameters used for scheduling the traffic throughout the network.

Service Classes					
Index	Name	Schedule Type	Max Rate	Min Rate	Priority
1	DL_MULTICAST	Best Effort	6096 Kbps	3657 Kbps	1
2	initial	Best Effort	5885 Kbps	1 Kbps	1
3	little	Best Effort	100 Kbps	1 Kbps	1
4	middle	Best Effort	2500 Kbps	1 Kbps	1
5	BE_MAX	Best Effort	50000 Kbps	1000 Kbps	1
ADD ENTRY MODIFY ENTRY ... REMOVE ENTRY ... CANCEL					

Figure 3-16 BS Network Config Service Classes

Table 3-7. Base Station Network Config Service Class		
	Field/Control	Description
1	Service Classes	• Index – the index into the service class table for the entry. This field is not entered by the user. • Name – the user defined name for the service class. The name can be up to 31 valid characters in length. • Schedule Type – Defines the 802.16d scheduling type for the service class. The entries are defined in a drop down by the system. • Max Rate – The maximum data rate for the service class in Kbps as defined by the 802.16d schedule type. • Min Rate – The minimum data rate for the service class in Kbps as defined by the 802.16d schedule type. • Priority - Defines the priority of the service class as defined by the 802.16d schedule type. The higher number defines a higher priority (7 is the highest priority). The priority field is valid for schedule types of non real-time and real-time.
2	Control Buttons	• Add Entry Button allows for adding a new service class entry. Click on the button and enter the fields. When the fields are complete click on the add button to the right of the entry fields. • Modify Entry Button allows for modifying a service class entry in the table. Click on the button and then select the entry to modify by clicking on the modify button to the right of the entry line. When modifications are complete click the save button to the right of the entry line. • Remove Entry Button allows for removing a service class entry from the table. Click on the button and then click on the remove button to the right of the entry line to remove. • Cancel Button allows for canceling the current add or modify request.

Multicast Note:

A service class for downlink multicast data is automatically configured that defines the possible bandwidth for multicast messages. The maximum and minimum rate can be modified according to the expected multicast traffic of your system. The multicast service class cannot be deleted as multicast support is always on in the bridging configuration. Multicast is not currently supported in the non-bridging configuration.

- **Adding an Entry for a Service Class:**

Service classes define the parameters for the 802.16d quality of services that are used to schedule the traffic through the network. A total of 12 service classes can be configured on the base station.

The following screen displays an example for adding a service class. Once the ADD ENTRY button is selected the administrator can type in a name for the new service class and can select the schedule type from a pull down menu. The max and min data rates should be entered and a priority selected if valid for the chosen scheduling type. Once all of the information is input the administrator selects the ADD button to enter the information input.

Service Classes

Index	Name	Schedule Type	Max Rate	Min Rate	Priority	
1	DL_MULTICAST	Best Effort	6096 Kbps	3657 Kbps	1	
2	initial	Best Effort	5885 Kbps	1 Kbps	1	
3	little	Best Effort	100 Kbps	1 Kbps	1	
4	middle	Best Effort	2500 Kbps	1 Kbps	1	
5	BE_MAX	Best Effort	50000 Kbps	1000 Kbps	1	
	ExpRealTime	Real-Time	1000 Kbps	500 Kbps	0	ADD

Figure 3-17 BS Example Add Service Class

The above example adds a Real-Time service class named “ExpRealTime” with a maximum rate of 1000Kbps and a minimum rate of 500 kbps, at a priory of 0.

3.6.3.3. Modifying a Service Class

The following screen displays an example for modifying an existing service class entry. Once the administrator selects the MODIFY ENTRY button the max and min data rate fields and the priority fields can be modified. Once the new values are entered the administrator selects the SAVE button to the right of the entry to save the changes. To change the schedule type and service class name, the administrator adds another service class entry with the new parameters or deletes a current entry and adds a service class entry with the new parameters.

Service Classes

Index	Name	Schedule Type	Max Rate	Min Rate	Priority	
1	BE_MULTICAST	Best Effort	6096 Kbps	3657 Kbps	1	
2	initial	Best Effort	5885 Kbps	1 Kbps	1	
3	little	Best Effort	100 Kbps	1 Kbps	1	
4	middle	Best Effort	2500 Kbps	1 Kbps	1	
5	BE_MAX	Best Effort	50000 Kbps	1000 Kbps	1	
6	ExpRealTime	Real-Time	5000 Kbps	600 Kbps	0 ▾	SAVE

Figure 3-18 BS Example Modify Service Class

3.6.3.4. Base Station Network Config Provisioned SFs

The service flows define the subscriber connections that are allowable within the network. They also define the service class of the subscriber connection which is used to determine the data traffic and rate of data flow for that connection. A total of 32 pairs of service flows can be defined in the network. It is allowable to define multiple pairs of service flows per subscriber when there are service flow entries available.

Provisioned SFs

Subscriber Name	Downstream SF Id	Upstream SF Id	Service Class	UL Multicast Select
SS-1	4	5	BE_MAX	
SS-2	6	7	BE_MAX	

Figure 3-19 BS Provisioned SFs

Table 3-8. Base Station Network Config Service Class		
	Field/Control	Description
1	Provisioned Service Flows	- Subscriber Name – A drop down selection box with the alphanumeric names for all of the configured Subscribers on the Admin page. - Downstream SF Id - Defines the identification number for the downstream service flow (base station to subscriber). The values of 1,2,3 are reserved. - Upstream SF Id – Defines the identification number for the upstream service flow (subscriber to base station).

Table 3-8. Base Station Network Config Service Class		
	Field/Control	Description
		Not a user entry, this value will be Downstream SF Id + 1 • Service Class – A drop down selection for the service class used for scheduling traffic for the service flow pair. • UL Multicast Select – Defines the service flow from which the uplink data will be sent on. This is only critical if the user has configured multiple Service Flows for a subscriber station. Otherwise the only service flow defined for the Subscriber will be used.
2	Control Buttons	• Add Entry Button allows for adding a new provisioned service flow entry. Click on the button and enter the fields. When the fields are complete click on the add button to the right of the entry fields. • Modify Entry Button allows for modifying a provisioned service flow entry in the table. Click on the button and then select the entry to modify by clicking on the modify button to the right of the entry line. When modifications are complete click the save button to the right of the entry line. • Remove Entry Button allows for removing a provisioned service flow entry from the table. Click on the button and then click on the remove button to the right of the entry line to remove. • Cancel Button allows for canceling the current add or modify request Note: The GUI adds both downlink and uplink SFs at the same time.

3.6.3.5. Generating Service Flows

Service flow pairs can be added for a subscriber in the Network Config page. Only subscribers configured to the network in the station name portion of the Admin Page appear in the drop down list for the subscriber name selection of the service flow. The subscriber that the service flow pair represents is selected. The administrator provides a service flow identification number for the downstream service flow which should be a number greater than 4 and not be used for any other service flow id. The upstream identification number is generated automatically. The service identification numbers are only used for reference.

The service class drop down list contains all service classes defined in the service class section of the Network Config page. The administrator selects the desired service class. The UL Multicast Select box, when checked, indicates to the system which service flow will have the uplink data sent on. Each subscriber can have a maximum of one UL Multicast selected to it. The UL Multicast is optional; however, if there are multiple service flows defined for a subscriber and there is no UL Multicast selected, the system will automatically pick one at random. Once all the fields are complete, the administrator selects the ADD button to the right of the new entry, adding the new service flow pair to the network.

Provisioned SFs

Subscriber Name	Downstream SF Id	Upstream SF Id	Service Class	UL Multicast Select	
SS-1	4	5	BE_MAX		
SS-2	6	7	BE_MAX		
SS-3	8		ExpRealTime	☐	ADD

ADD ENTRY MODIFY ENTRY ... REMOVE ENTRY ... CANCEL

Figure 3-20 BS Example Add Provisioned SFs

3.6.3.6. Modifying a Service Flow Pair

Existing service flow pair entries can be modified using the MODIFY ENTRY button. The administrator can only modify the service class for the service flow pair to a service class of the same schedule type. Changing any of the other service flow parameters requires adding a new service flow pair with the desired parameters. If a subscriber station already has a UL Multicast checked for one of its service flows, none of its other service flows will be allowed to have their Multicast also selected. To select the status of the UL Multicast for a specific subscriber's service flow, any service flow already set to use the UL Multicast must be unchecked first. Any undesired service flow pairs should be removed.

Provisioned SFs

Subscriber Name	Downstream SF Id	Upstream SF Id	Service Class	UL Multicast Select	
SS-1	4	5	BE_MAX		
SS-2	6	7	initial	☐	SAVE
SS-3	8	9	ExpRealTime		

ADD ENTRY MODIFY ENTRY ... REMOVE ENTRY ... CANCEL

Figure 3-21 BS Example Modify Service Flow

3.6.3.7. Base Station Network Config Class Rules

If user is not using the ARP Table feature, then they will need to configure classifiers for IP data to pass between the radios. The Classifier Status must be enabled in the Network Options section of the Network Config page.

The class rules define the paths that are valid for data transmission within the network. It is valid to define class rules by using IP addresses or MAC addresses. All class rules must be defined using the same address type. Class Rules are configured on the base station and transferred to the subscribers when they connect to the base station. A valid class rule must exist for each downstream service flow and for each upstream service flow for data to pass in the define direction.

Class Rules

Address Mode: IP

Forwarders Enabled: NO

Non-Forwarder Count: 4

Forwarder Count: 0

Prev Page

Current Page: 1 of 1

Next Page

Index	SF	Src IP	Src Mask	Dest IP	Dest Mask
0	4	192.168.100.1	255.255.255.0	192.168.1.1	255.255.255.0
1	5	192.168.1.1	255.255.255.0	192.168.100.1	255.255.255.0
2	6	192.168.100.1	255.255.255.0	192.168.2.1	255.255.255.0
3	7	192.168.2.1	255.255.255.0	192.168.100.1	255.255.255.0

ADD ENTRY

MODIFY ENTRY ...

REMOVE ENTRY ...

CANCEL

Figure 3-22 BS Network Config Class Rules

Table 3-9. Base Station Network Config Service Class		
	Field/Control	Description
3	Current Class Rules Mode	- Address Mode - Displays the current address mode for the class rules. The valid values are IP and MAC - Forwarders Enabled - If selected, the GUI will populate forwarders for each configured SS. Auto populate does not account for multiple service flows per subscriber. The additional class rules need to be entered manually. - Non-Forwarder Count - Indicates the number of class rules not using forwarders.

Table 3-9. Base Station Network Config Service Class		
	Field/Control	Description
		Forwarder count - Indicates the number of class rules using forwarders.
2	IP/MAC Buttons	Provides the capability to change the address mode of the class rules. Changing the mode will delete the current class rules. The administrator receives a warning prior to rule deletion.
3	Auto Populate	Provides the capability to automate the class rule entry process such that each address gets entered once. Auto populate creates a class rule for the downstream service flow and a class rule for the upstream service flow.
4	Prev/Next Page	Allows for paging through the class rules if the information on the Network Config is larger than one page.
5	Classifier Table	IP addresses in this section are just examples. - Index – Internal index used for class rules. The index is automatically generated. - SF – Identifies the service flow that pertains to the class rule. - Src IP/MAC – The source address for the class rule. The address presented to the unit when initiating traffic through it. - Src Mask – The address mask for the source address. Masking portions of the IP address is only valid when the addresses of the units are configured on different subnets. Currently only the last subnet byte is allowed to be masked - Dest IP/MAC - The destination address for the class rule. The destination address for the traffic through the unit. - Dest Mask - The address mask for the destination address. Masking portions of the IP address is only valid when the addresses of the units are configured on different subnets. Currently only the last subnet byte is allowed to be masked
6	Control Buttons	The control buttons allow the administrator to add, modify and remove class rules and to cancel the current add, modify or remove transaction.

3.6.3.8. Base Station Network Configuration Auto Populate GUI

Class rules can be auto populated. The Aeronix S/W will look at either the IP Layer or the Ethernet layer of the Ethernet packet, depending if the classifiers are configured in IP mode or MAC mode. The addresses inputted should be those presented to the unit in bridging mode. They are typically the address of the peripherals generating the data for the source address and the peripheral receiving the data for the destination address

Title: Aeronix Data Links – EDL Nano Products User Guide

The screen below appears when the user clicks on the Auto Populate Button on the Base Station Network Configuration Screen.

Class Rules
IP ☐ MAC ☐
Auto Populate

Address Mode: IP
 Forwarders Enabled: NO
 Non-Forwarder Count: 4
 Forwarder Count: 0

Prev Page
Current Page: 1 of 1
Next Page

Index	Station	SF Indices	Station IP	Station Mask
0	BS	---	000.000.000.000	255.255.255.255
1	SS-1	4,5	000.000.000.000	255.255.255.255
2	SS-2	6,7	000.000.000.000	255.255.255.255

☐ Enable Forwarders
BS0 SS0
Extra Count
Generate Classifiers

ADD ENTRY
MODIFY ENTRY ...
REMOVE ENTRY ...
CANCEL

Figure 3-23 BS Network Config Auto Populate

Table 3-10. Base Station Network Config Auto Populate		
	Field/Control	Description
1	Auto Populate User Interface	Automatically generates classifiers based on the list of Subscribers that are configured. User must enter the IP/MAC address of the data from each Station. - Station – A list of all the stations (including BS) that are configured, not a user entry. - SF Indices – The SF index that is associated with a configured SS, not a user entry (note: BS does not have SF Id so it is “---”). - Station IP - The source external network station’s Ethernet IP address. This is the source of data packets. - Station Mask - Mask to be applied to Source IP fields, allows you to open up a range of IP addresses. Currently only the last subnet byte is allowed to be masked off. - Enable Forwarders check box - If selected, the GUI will populate forwarders for each configured SS.

Table 3-10. Base Station Network Config Auto Populate		
	Field/Control	Description
		• BS – Number of extra classifiers that will be added to the base station. • SS – Total number of extra classifiers that will be added to the subscriber stations. • Extra Count Button – Allows a user to add additional classifiers to a radio. • Generate Classifiers – This button triggers the GUI to generate the classifiers. It will create BS ↔ SS classifiers, and forwarders if enabled.




Figure 3-24 Example Auto Populate Network Layout

3.6.3.9. Base Station Network Configuration Auto Populate Example

The following screens provide an example of auto populating the class rules when the address type is set to IP. The user must select the ‘Auto Populate’ button on the Network Config page to get to the auto populate screen. The IP addresses input should be those presented to the unit in bridging mode. They are typically the address of the peripherals generating the data for the source address and the peripheral receiving the data for the destination address. In the case of the example network configuration above, the BS Station IP would be 192.168.100.0 with a mask of 255.255.255.0, SS-1 Station IP would be 192.168.10.0 with a mask of 255.255.255.0 and SS-2 Station IP would be 192.168.20.0 with a mask of 255.255.255.0. Since the networks are on different subnets the user can mask the last byte. When possible, masking the addresses reduce the amount of class rules generated and allow for the use of numerous peripherals on the units subnet.

Class Rules

Address Mode: IP

IP MAC

Auto Populate

Forwarders Enabled: NO

Non-Forwarder Count: 4

Forwarder Count: 0

Prev Page

Current Page: 1 of 1

Next Page

Index	Station	SF Indices	Station IP	Station Mask
0	BS	---	192.168.100.0	255.255.255.0
1	SS-1	4,5	192.168.1.0	255.255.255.0
2	SS-2	6,7	192.168.2.0	255.255.255.0

☐ Enable Forwarders

BS0 SS0

Extra Count

Generate Classifiers

ADD ENTRY

MODIFY ENTRY ...

REMOVE ENTRY ...

CANCEL

Figure 3-25 BS Example Auto Populate

The administrator selects the Generate Classifiers button after the IP addresses and masks are entered. The class rule generation process begins and should not be interrupted until complete. Figure 3-26 BS Example Auto Populate Result shows the rules after generation is complete without forwarders.

Class Rules

Address Mode: IP

IP MAC

Auto Populate

Forwarders Enabled: NO

Non-Forwarder Count: 4

Forwarder Count: 0

Prev Page

Current Page: 1 of 1

Next Page

Index	SF	Src IP	Src Mask	Dest IP	Dest Mask
0	4	192.168.100.0	255.255.255.0	192.168.1.0	255.255.255.0
1	5	192.168.1.0	255.255.255.0	192.168.100.0	255.255.255.0
2	6	192.168.100.0	255.255.255.0	192.168.2.0	255.255.255.0
3	7	192.168.2.0	255.255.255.0	192.168.100.0	255.255.255.0

ADD ENTRY

MODIFY ENTRY ...

REMOVE ENTRY ...

CANCEL

Figure 3-26 BS Example Auto Populate Result

3.6.3.10. Adding Additional Class Rules to Stations using Auto Populate

Additional classifiers can be added for each station. It is best to determine how many entries will be required before populating the table. Once the Auto Populate button is selected, the number of additional base station and subscriber station classifiers should be entered in the BS and SS text fields respectively. The Extra Count button is then selected to confirm the additional classifiers and the table will expand. Once the desired number of classifiers is added to the table, the station, SF indices, station IP and station masks can be selected/entered. The station and the service flow index per entry must match one of the entries in the Provisioned SF's table. Once the table is filled out, the Generate Classifiers button is selected to create the class rules. This process should not be interrupted until complete.

Class Rules

Address Mode: IP

IP MAC

Auto Populate

Forwarders Enabled: NO

Non-Forwarder Count: 16

Forwarder Count: 0

Prev Page

Current Page: 1 of 1

Next Page

Index	Station	SF Indices	Station IP	Station Mask
0	BS	---	192.168.100.1	255.255.255.255
1	BS	---	192.168.100.10	255.255.255.255
2	SS-1	4,5	192.168.1.1	255.255.255.255
3	SS-1	4,5	192.168.1.10	255.255.255.255
4	SS-2	6,7	192.168.2.10	255.255.255.255
5	SS-2	6,7	192.168.2.15	255.255.255.255

☐ Enable Forwarders
 BS 1 SS 2
 Extra Count
 Generate Classifiers

ADD ENTRY

MODIFY ENTRY ...

REMOVE ENTRY ...

CANCEL

Figure 3-27 BS Example Auto Populate Additional Class Rules

Class Rules

Address Mode: IP

IP MAC

Auto Populate

Forwarders Enabled: NO

Non-Forwarder Count: 16

Forwarder Count: 0

Prev Page

Current Page: 1 of 1

Next Page

Index	SF	Src IP	Src Mask	Dest IP	Dest Mask
0	4	192.168.100.1	255.255.255.255	192.168.1.1	255.255.255.255
1	5	192.168.1.1	255.255.255.255	192.168.100.1	255.255.255.255
2	4	192.168.100.1	255.255.255.255	192.168.1.10	255.255.255.255
3	5	192.168.1.10	255.255.255.255	192.168.100.1	255.255.255.255
4	6	192.168.100.1	255.255.255.255	192.168.2.10	255.255.255.255
5	7	192.168.2.10	255.255.255.255	192.168.100.1	255.255.255.255
6	6	192.168.100.1	255.255.255.255	192.168.2.15	255.255.255.255
7	7	192.168.2.15	255.255.255.255	192.168.100.1	255.255.255.255
8	4	192.168.100.10	255.255.255.255	192.168.1.1	255.255.255.255
9	5	192.168.1.1	255.255.255.255	192.168.100.10	255.255.255.255
10	4	192.168.100.10	255.255.255.255	192.168.1.10	255.255.255.255
11	5	192.168.1.10	255.255.255.255	192.168.100.10	255.255.255.255
12	6	192.168.100.10	255.255.255.255	192.168.2.10	255.255.255.255
13	7	192.168.2.10	255.255.255.255	192.168.100.10	255.255.255.255
14	6	192.168.100.10	255.255.255.255	192.168.2.15	255.255.255.255
15	7	192.168.2.15	255.255.255.255	192.168.100.10	255.255.255.255

ADD ENTRY

MODIFY ENTRY ...

REMOVE ENTRY ...

CANCEL

Figure 3-28 BS Example Additional Class Rules Result

3.6.3.11. Auto Populating Class rules of Type IP while Enabling Forwarders

Forwarders provide the capability for subscribers to talk to each other via the base station. They define data traffic from a subscriber that should be forwarded to another subscriber and used in the downlink direction only. It requires additional configuration of class rules and if data transmission occurs from subscriber to subscriber it will consume bandwidth allocated for those subscribers. Forwarding classifiers must be consistent with non-forwarding classifiers. For example, if using IP masks with the non-forwarders, one must also use the same mask with the

forwarders. Forwarders can be enabled or disabled when selecting the auto populate. They are generated and applied to the entire Class Rules table.

Class Rules
IP MAC
Auto Populate

Address Mode: IP
 Forwarders Enabled: NO
 Non-Forwarder Count: 16
 Forwarder Count: 0

Prev Page
Current Page: 1 of 1
Next Page

Index	Station	SF Indices	Station IP	Station Mask
0	BS	---	192.168.100.0	255.255.255.0
1	SS-1	4,5	192.168.1.0	255.255.255.0
2	SS-2	6,7	192.168.2.0	255.255.255.0

☒ Enable Forwarders

BS0 SS0

Extra Count

Generate Classifiers

ADD ENTRY
MODIFY ENTRY ...
REMOVE ENTRY ...
CANCEL

Figure 3-29 BS Example Auto Populate IP with Forwarders

Below is what is displayed after user hits the “Generate Classifiers” button. The forwarder class rules are not displayed, but the “Forwarder Count” has incremented for each forwarder created.

Class Rules
IP MAC
Auto Populate

Address Mode: IP
 Forwarders Enabled: YES
 Non-Forwarder Count: 4
 Forwarder Count: 2

Prev Page
Current Page: 1 of 1
Next Page

Index	SF	Src IP	Src Mask	Dest IP	Dest Mask
0	4	192.168.100.0	255.255.255.0	192.168.1.0	255.255.255.0
1	5	192.168.1.0	255.255.255.0	192.168.100.0	255.255.255.0
2	6	192.168.100.0	255.255.255.0	192.168.2.0	255.255.255.0
3	7	192.168.2.0	255.255.255.0	192.168.100.0	255.255.255.0

ADD ENTRY
MODIFY ENTRY ...
REMOVE ENTRY ...
CANCEL

Figure 3-30 BS Example Auto Populate IP with Forwarders Result

3.6.3.12. Auto Populating Class Rules of Type MAC

Auto populating the class rules can also be done when the address type is set to MAC. The MAC addresses input should be those presented to the unit in bridging mode. They are typically the address of the peripherals generating the data for the source address and the peripheral receiving the data for the destination address. In the case of the example network configuration in **Error! Reference source not found.** the BS Station MAC would be F0-E0-D0-C0-B0-A0, S-1 Station MAC would be F1-E1-D1-C1-B1-A1. SS-2 Station has 2 laptops connected to it so the user needs to add an “Extra Count” of 1 for SS2. SS MACs would be F2-E2-D2-C2-B2-A2 and F3-E3-D3-C3-B3-A3.

The administrator selects the Generate Classifiers button after the MAC addresses and masks are entered. The class rule generation process begins and should not be interrupted until complete.

Class Rules

Address Mode: MAC

IP MAC

Auto Populate

Forwarders Enabled: NO

Non-Forwarder Count: 0

Forwarder Count: 0

Prev Page

Current Page: 1 of 1

Next Page

Index	Station	SF Indices	Station MAC	Station Mask
0	BS	---	F0-E0-D0-C0-B0-A0	FF-FF-FF-FF-FF-FF
1	SS-1	4,5	F1-E1-D1-C1-B1-A1	FF-FF-FF-FF-FF-FF
2	SS-2	6,7	F2-E2-D2-C2-B2-A2	FF-FF-FF-FF-FF-FF
3	SS-2	6,7	F3-E3-D3-C3-B3-A3	FF-FF-FF-FF-FF-FF

☐ Enable Forwarders

BS0 SS1

Extra Count

Generate Classifiers

ADD ENTRY

MODIFY ENTRY ...

REMOVE ENTRY ...

CANCEL

Figure 3-31 BS Example Auto Populate with MAC Address

Below is the result of the user selecting the “Generate Classifiers” button.

Class Rules

Address Mode: MAC

IP MAC

Auto Populate

Forwarders Enabled: NO

Non-Forwarder Count: 6

Forwarder Count: 0

Prev Page

Current Page: 1 of 1

Next Page

Index	SF	Src MAC	Src Mask	Dest MAC	Dest Mask
0	4	F0-E0-D0-C0-B0-A0	FF-FF-FF-FF-FF-FF	F1-E1-D1-C1-B1-A1	FF-FF-FF-FF-FF-FF
1	5	F1-E1-D1-C1-B1-A1	FF-FF-FF-FF-FF-FF	F0-E0-D0-C0-B0-A0	FF-FF-FF-FF-FF-FF
2	6	F0-E0-D0-C0-B0-A0	FF-FF-FF-FF-FF-FF	F2-E2-D2-C2-B2-A2	FF-FF-FF-FF-FF-FF
3	7	F2-E2-D2-C2-B2-A2	FF-FF-FF-FF-FF-FF	F0-E0-D0-C0-B0-A0	FF-FF-FF-FF-FF-FF
4	6	F0-E0-D0-C0-B0-A0	FF-FF-FF-FF-FF-FF	F3-E3-D3-C3-B3-A3	FF-FF-FF-FF-FF-FF
5	7	F3-E3-D3-C3-B3-A3	FF-FF-FF-FF-FF-FF	F0-E0-D0-C0-B0-A0	FF-FF-FF-FF-FF-FF

ADD ENTRY

MODIFY ENTRY ...

REMOVE ENTRY ...

CANCEL

Figure 3-32 BS Example Auto Populate with MAC Address Result

3.6.3.13. Adding Class Rule using ADD ENTRY

The following screen provides an example of the ADD ENTRY functionality for a class rule. The user can add a class rule entry by selecting the ADD ENTRY button within the Class Rule section of the Network Config page (Figure 3-22 BS Network Config Class Rules). Once that occurs a similar screen to Figure 3-33 BS Example Class Rules ADD ENTRY appears. The administrator selects the service flow for which the rule pertains from the pull down menu. The administrator then inputs the valid IP/MAC source address and mask and the valid destination address and mask. Select the ADD button to the right of the entry to input the new class rule. The rule distributes through the network as needed.

Class Rules

Address Mode: IP

IP

MAC

Auto Populate

Prev Page

Current Page: 1 of 1

Next Page

Index	SF	Fwd	Src IP	Src Mask	Dest IP	Dest Mask	
0	4	N	192.168.100.0	255.255.255.0	192.168.10.0	255.255.255.0	
1	5	N	192.168.10.0	255.255.255.0	192.168.100.0	255.255.255.0	
2	6	N	192.168.100.0	255.255.255.0	192.168.20.0	255.255.255.0	
3	7	N	192.168.20.0	255.255.255.0	192.168.100.0	255.255.255.0	
4	4	Y	192.168.10.0	255.255.255.0	192.168.20.0	255.255.255.0	
5	5	N	192.168.10.0	255.255.255.0	192.168.20.0	255.255.255.0	
6	6	Y	192.168.20.0	255.255.255.0	192.168.10.0	255.255.255.0	
7	7	N	192.168.20.0	255.255.255.0	192.168.10.0	255.255.255.0	
	4	☐	000.000.000.000	255.255.255.255	000.000.000.000	255.255.255.255	ADD

ADD ENTRY

MODIFY ENTRY ...

REMOVE ENTRY ...

CANCEL

Figure 3-33 BS Example Class Rules ADD ENTRY

3.6.3.14. Modifying a Class Rule Using MODIFY Entry

The user can modify a class rule entry by selecting the MODIFY ENTRY button within the Class Rule section of the Network Config page (Figure 3-22 BS Network Config Class Rules). The MODIFY button to the right of the entry is selected to modify that entry (Figure 3-34 BS Example MODIFY ENTRY selection). The user may change the source and destination address for that class rule (**Error! Reference source not found.**). The SAVE button to the right of the entry is selected to input the new class rule data. The Forwarder Enabled status of the table can be changed by selecting the Auto Populate button and then checking or unchecking the Enable Forwarders box. The rule distributes throughout the network as needed.

Class Rules

Address Mode: IP

IP MAC

Auto Populate

Forwarders Enabled: NO

Non-Forwarder Count: 5

Forwarder Count: 0

Prev Page

Current Page: 1 of 1

Next Page

Index	SF	Src IP	Src Mask	Dest IP	Dest Mask	
0	4	192.168.100.0	255.255.255.0	192.168.1.0	255.255.255.0	MODIFY
1	5	192.168.1.0	255.255.255.0	192.168.100.0	255.255.255.0	MODIFY
2	6	192.168.100.0	255.255.255.0	192.168.2.0	255.255.255.0	MODIFY
3	7	192.168.2.0	255.255.255.0	192.168.100.0	255.255.255.0	MODIFY
4	4	192.168.10.0	255.255.255.0	192.168.100.0	255.255.255.0	MODIFY

ADD ENTRY

MODIFY ENTRY ...

REMOVE ENTRY ...

CANCEL

Figure 3-34 BS Example MODIFY ENTRY selection

Class Rules

Address Mode: IP

IP MAC

Auto Populate

Forwarders Enabled: NO

Non-Forwarder Count: 5

Forwarder Count: 0

Prev Page

Current Page: 1 of 1

Next Page

Index	SF	Src IP	Src Mask	Dest IP	Dest Mask	
	4	192.168.100.0	255.255.255.0	192.168.1.0	255.255.255.0	SAVE
0	5	192.168.1.0	255.255.255.0	192.168.100.0	255.255.255.0	
1	6	192.168.100.0	255.255.255.0	192.168.2.0	255.255.255.0	
2	7	192.168.2.0	255.255.255.0	192.168.100.0	255.255.255.0	
3	4	192.168.10.0	255.255.255.0	192.168.100.0	255.255.255.0	

ADD ENTRY

MODIFY ENTRY ...

REMOVE ENTRY ...

CANCEL

Figure 3-35 BS Example MODIFY ENTRY

3.6.4. Base Station Profile Config Page

The Profile Config page allows the administrator to configure the parameters which control the automatic change modulation (ACM) capability within the network.

Base Station
Bridging Mode
(Debug GUI)

ACM Parameters

Cur Exit Steps: 1
Cur Frm Accum: 2

FEC Exit Steps: 1 Set
FEC Entry Frame Accumulation: 2 Set

Downstream Burst Profiles

Index	DIUC	DCD FEC Code	CINR (dBm) Mandatory Exit	CINR (dBm) Minimum Entry	FEC (cnts) Mandatory Exit	FEC (cnts) Minimum Entry	Available
1	1	BPSK 1/2	6	9	0	0	Enabled
2	2	QPSK 1/2	10	12	15	4	Enabled
3	3	QPSK 3/4	12	17	3	1	Enabled
4	4	QAM16 1/2	17	19	22	6	Enabled
5	5	QAM16 3/4	19	21	6	2	Enabled
6	6	QAM64 2/3	21	24	23	6	Enabled
7	7	QAM64 3/4	24	26	12	3	Enabled

ADD ENTRY MODIFY ENTRY ... REMOVE ENTRY ... CANCEL

Upstream Burst Profiles

Index	UIUC	FEC
1	5	BPSK 1/2
2	6	QPSK 1/2
3	7	QPSK 3/4
4	8	QAM16 1/2
5	9	QAM16 3/4
6	10	QAM64 2/3
7	11	QAM64 3/4

Figure 3-36 OFDM BS Profile Config Page

802.16 Tactical Radio

Base Station Bridging Mode

ACM Parameters

Cur Exit Steps: 1
Cur Frm Accum: 2

FEC Exit Steps: 1
FEC Entry Frame Accumulation: 2

Downstream Burst Profiles

Index	DIUC	DCD FEC Code	SNR Mandatory Exit	SNR Minimum Entry	FEC (cnts) Mandatory Exit	FEC (cnts) Minimum Entry	Available
1	1	1 PPS 1/2	-5	-5	20	2	Enabled
2	2	2 PPS 1/2	-5	-4	20	2	Enabled
3	3	2 PPS 3/4	-2	-1	4	2	Enabled
4	4	4 PPS 1/2	-1	0	33	5	Enabled
5	5	4 PPS 3/4	0	1	10	5	Enabled
6	6	8 PPS 1/2	1	3	4	1	Enabled
7	7	8 PPS 3/4	3	5	8	0	Enabled

ADD ENTRY MODIFY ENTRY ... REMOVE ENTRY ... CANCEL

Upstream Burst Profiles

Index	UIUC	FEC
1	5	1 PPS 1/2
2	6	2 PPS 1/2
3	7	2 PPS 3/4
4	8	4 PPS 1/2
5	9	4 PPS 3/4
6	10	8 PPS 1/2
7	11	8 PPS 3/4

Figure 3-37 GMSK BS Profile Config Page

Table 3-11. Base Station Profile Config Page		
	Field	Description
1	Current ACM Parameters	OFDM ACM decisions are based on the received CINR and FEC corrected bits. GMSK ACM decisions are based on the received SNR and FEC corrected bits. - Cur Exit Steps – Current number of steps to lower the FEC Code type if need be. - Cur Frame Accum – Current number of frames to Accumulate before making the decision to move between FEC Codes.
2	Change ACM Parameters	- FEC Exit Steps – Provides the capability for the administrator to configure the number of steps in the burst profile table to take when ACM determines it is time to exit the current FEC. Valid of values are 0-2. A value of 0 means to jump to most robust FEC configured and enabled. - FEC Entry Frame Accumulation – Provides the capability for the administrator to configure the number of frames that must be accumulated in

Table 3-11. Base Station Profile Config Page		
	Field	Description
		succession that meet the change FEC criteria before moving to another FEC. Valid values are provided in the pull down menu.
3	Downstream Burst Profiles	Displays the downstream burst profiles which define the FEC types that the base station uses for transmissions. • Index - Value used internally to index the burst profiles. The value gets automatically generated. • DIUC – Downlink interval usage code defined by 802.16d. The values get generated automatically and are for viewing and debug purposes. • DCD FEC Code – Defines the forward error correction and coding for the burst profile entry. • CINR/SNR Mandatory Exit – Defines the CINR/SNR value in dBm used by ACM. If current average CINR/SNR is less than this value then ACM will exit current FEC code type. • CINR/SNR Minimum Entry – Defines the CINR/SNR value in dBm at which ACM allows entry into the FEC code type. The CINR/SNR average must be greater than the current FEC code types CINR/SNR minimum entry and equal to or greater than the next FEC code types CINR/SNR minimum entry. • FEC Mandatory Exit – Defines the largest number of FEC bits of one symbol in a frame averaged over the number of frames specified in FEC Entry Frame Accumulation that can occur before the decision is made to move out of the current FEC code type and into a lower more robust FEC code type. The FECs averaged over FEC Entry Frame Accumulation must be greater than the FEC Mandatory Exit before the move will occur. • FEC Minimum Entry – Defines the largest number of FEC bits of one symbol in a frame averaged over the FEC Entry Frame Accumulation can have before ACM attempts to move to a higher FEC code type. The FECs averaged over FEC Entry Frame Accumulation must be equal to or less than the FEC Mandatory Entry of the current FEC code type before the move will occur. • Available – Enable/Disable drop down menu. This option allows user to disable a certain FEC Code without deleting it from the database. Enabled profiles are used in the ACM scheme and disabled profiles are not used.
4	Control Buttons	The control buttons allow the administrator to add, modify and remove burst profiles and to cancel the current add, modify or remove transaction.

Table 3-11. Base Station Profile Config Page		
	Field	Description
5	Upstream Burst Profiles	The upstream burst profiles are displayed for informational and debug purposes. The upstream burst profiles use the same FEC code types and entry and exit thresholds defined for the downstream burst profiles.

ACM Note:

The OFDM and GMSK ACM methodology uses two criteria for changing modulations. It uses the average CINR/SNR value for the connection and the number of FECs. The number of FECs represents the largest number of FECs in any symbol in the given burst. ACM requires that only one threshold is met to cause the modulation to switch to a more robust modulation and it requires that both CINR and FEC thresholds be met to move to a less robust modulation.

3.6.4.1. ADD ENTRY Downstream Burst Profile Example

The user can add a burst profile entry by selecting the ADD ENTRY button within the Downstream Burst Profile section of the Profile Config page. The user selects the FEC code from the pull down menu and selects the ADD button to the right of the entry. The new burst profile distributes through the network as needed. Each burst profile added gets populated with the default CINR and FEC thresholds. The user can change those values by modifying the burst profile.

Downstream Burst Profiles

Index	DIUC	DCD FEC Code	CINR (dBm) Mandatory Exit	CINR (dBm) Minimum Entry	FEC (cnts) Mandatory Exit	FEC (cnts) Minimum Entry	Available	
1	1	BPSK 1/2	6	9	0	0	Enabled	
2	2	QPSK 1/2	10	12	15	4	Enabled	
3	3	QPSK 3/4	12	17	3	1	Enabled	
4	4	QAM16 1/2	17	19	22	6	Enabled	
5	5	QAM16 3/4	19	21	6	2	Enabled	
		BPSK 1/2					Enabled	ADD

ADD ENTRY
ADD ENTRY ...
REMOVE ENTRY ...
CANCEL

Upstream Burst Profiles

Index	UIUC	FEC Code
1	5	8PSK 1/2
2	6	16PSK 1/2
3	7	16PSK 3/4
4	8	QPSK 3/4
5	9	QAM16 1/2
		QAM16 3/4

Figure 3-38 BS 802.16 Example Add Burst Profile

3.6.4.2. MODIFY ENTRY Downstream Burst Profile Example

The user can modify a burst profile entry by selecting the MODIFY ENTRY button within the Downstream Burst Profile section of the Profile Config page. The user can modify the CINR entry and exit thresholds as well as the FEC entry and exit thresholds. The user can change the available status of the profile by using the pull down menu in the Available field. Modifications are saved and distributed through the network by selecting the SAVE button to the right of the burst profile. If the user modifies the CINR entry and exit thresholds or the FEC entry and exit thresholds to values outside of the recommend range, the values appear as red on the screen to provide a warning even though they are used in the network.

Downstream Burst Profiles

Index	DIUC	DCD FEC Code	CINR (dBm) Mandatory Exit	CINR (dBm) Minimum Entry	FEC (cnts) Mandatory Exit	FEC (cnts) Minimum Entry	Available	
1	1	BPSK 1/2	6	9	0	0	Enabled	
2	2	QPSK 1/2	10	12	15	4	Enabled	
3	3	QPSK 3/4	12	17	3	1	Enabled	
4	4	QAM16 1/2	17	19	22	6	Enabled	
5	5	QAM16 3/4	19	21	6	2	Enabled	
6	6	QAM64 2/3	21	24	23	6	Enabled	
7	7	QAM64 3/4	24	26	12	3	Enabled v	SAVE

Figure 3-39 BS 802.16 Example Modify Burst Profile

3.6.5. Base Station Radio Control

AERONIX 802.16 Tactical Radio

Base Station Bridging Mode

Receive Control

Current Rx Mode: Receive Dual ☒ Receive Dual ☐ SISO **Set** ①

Rx Data Swap Status: Disabled Rx Data Swap **On** **Off** ②

Tx/Rx

Tx/Rx Status: OFF Tx/Rx **On** **Off** ③

Up %: 60 Down %: 40 **User Bandwidth Allocation** Set Allocation: **Set** ④

40 % 60 %

Channel

Current Channel: Custom (2.200 GHz) Channel (Freq) 31 (2.412 GHz) **Set** ⑤

or Custom Freq (1800 - 2500) MHz **Set**

Current Channelization: 14 MHz ☐ 3.5 MHz ☐ 7 MHz ☒ 14 MHz **Set**

Power Values

BS Estimated EIRP: -1 dBm ⑥

Power Output Mode: High Data ☐ High Power ☒ High Data **Set** ⑥A

Cable Length and Loss Selection

External Rx: 0 ft. (0 dB) External Rx Cable Loss: 0 ft. No Cable (0 dB loss) **Set** ⑦

External Tx: 0 ft. (0 dB) External Tx Cable Loss: 0 ft. No Cable (0 dB loss) **Set**

Antenna: 3 ft. (1 dB) Antenna Cable Loss: 3 ft. 2.4GHz cable (1 dB loss) **Set**

Network Layout

Current Layout: Point to Multi-Point ☐ PTP ☒ PTMP **Set** ⑧

Current Max Distance: 0 miles Max Distance for SS Acquisition: 0.0 miles or 0.0 kms **Set**

Report Statistics Control

Stats via Ethernet: DISABLE Report statistics via Ethernet **Enable** **Disable** ⑨

Figure 3-40 OFDM BS Radio Control Page

AERONIX 802.16 Tactical Radio

Base Station Bridging Mode

Status
Admin
Network Config
Profile Config
Radio Control
Save Settings
Version
Maintenance
Video
Contact

Receive Control
Current Rx Mode: SISO ☐ Receive Dual ☒ SISO **Set** 1

Rx Data Swap Status: Disabled Rx Data Swap **On** **Off** 2

Tx/Rx
Tx/Rx Status: ON Tx/Rx **On** **Off** 3

Up %: 60 Down %: 40 **User Bandwidth Allocation** Set Allocation: **Set** 4
40 % 60 %

Channel
Current Channel: Custom (2.500 GHz) Channel (Freq) 31 (2.412 GHz) **Set** 5
or Custom Freq (1800 - 2500) **Set**
Current Channelization: 14 MHz

Power Values
BS Estimated EIRP: 30 dBm Power Output Mode: Low Power ☐ High Power ☒ Low Power **Set** 6
6A

Network Layout
Current Layout: Point to Point ☒ PTP ☐ PTMP **Set** 7
Current Max Distance: N/A Max Distance for SS Acquisition: **Set**

Figure 3-41 GSMK BS Radio Control

Table 3-12. Base Station Radio Control		
	Field/Control	Description
1	Rx Mode	- Receive Dual – Both receivers are enabled - SISO – Only one Receive path is enabled
2	Rx Data Swap	If enabled, the receive paths will be switched in the firmware.
3	Tx/Rx	- Tx/Rx Status – Displays the current status of transmit and receive of the unit. - Tx/Rx On and Off Buttons - Provides the capability to turn on or turn off the transmit/receive capability of the unit. When the selection is off the unit does not transmit or receive.

Table 3-12. Base Station Radio Control		
	Field/Control	Description
4	User Bandwidth Allocation	The current link bandwidth allocation is shown in percentage of upstream and downstream allocation. This value only gets set on the base station and gets distributed to the subscribers. Currently the limits for the allocation are 80% and 20% in either direction • Up % and Down % - Displays the current allocation of the network. • Link Bandwidth Allocation Slide Bar – Provides a method to adjust the allocation. The Down and Up percentages on each side of the slide bar displays the adjusted value. The user can also type in the percentages in the Down and Up boxes instead of sliding the bar. • Set Allocation Button – Changes the current allocation to the new settings displayed in the Down and Up boxes adjacent to the slide bar. Once selected the Up % and Down % on the left updates and the new values distribute through the network.
5	Channel / Channelization	Displays channel information for the base station. • Current Channel – Displays the current channel and frequency of the base station. • Channel (Freq) – Drop down list to choose a different channel/frequency for the base station. The base station and subscriber stations need to be configured for the same channelization for proper operation. • Set Button – Changes the current channel/frequency of the base station to the channel selected by the channel (freq) pull down or the custom frequency. • Custom Freq (1800 – 2500) — Allows the administrator to type in a frequency instead of selecting one from the channel (freq) drop down list. The frequency must be a valid operating frequency for the unit. The base station and subscriber stations need to be configured for the same channelization for proper operation. • Set Button – Changes the current channel of the base station to the custom frequency • Current Channelization – Displays the current channelization of the radio. The base station and subscriber stations need

Table 3-12. Base Station Radio Control		
	Field/Control	Description
		to be configured for the same channelization. - Channelization Selection – Allows the selection of the channelization. Current choices are 3.5 MHz, 7 MHz, and 14 MHz for OFDM s/w and 14Mhz for GMSK s/w - Set Button – Changes the current channelization of the base station to the new value selected. Note: Selecting a frequency outside of the ISM band (2400 – 2483.5MHz) voids the FCC Part 15.247 Certification.
6	Power Values	Allows the user to adjust the transmit power of the radio. BS Estimated EIRP - Displays the estimated EIRP of the base station based upon user configured gains and loss values. PA Gain + Antenna Gain – External Tx Cable Loss – Antennal Cable Loss – Internal Tx Loss.
6A	Power output mode	OFDM - High Power – radios TX power is calibrated to a higher power that still has a good enough EVM to maintain the QAM16 modulations. The QAM64 modulations will be disabled, if user re-enables them there is no guarantee the signal quality level will sustain QAM64 - High Data – radios TX power will be set to a power level who's EVM will sustain the QAM64 modulations. This power may be lower to maintain the higher EVMs required by QAM64 modulations. GMSK - High Power – radios TX power is calibrated to an output power of 35 dBm while still remaining within our GMSK mask. - High Data – radios TX power will be set to a power level of 30 dBm while remaining within our GMSK mask. Note: Selecting the high power mode voids the FCC Part 15.247 Certification.

Table 3-12. Base Station Radio Control		
	Field/Control	Description
		See 7.1 NANO output power for details on how to view transmit power values.
7	Network Layout	Displays and allows configuration of the network layout as a point to point or point to multi-point network. These items appear only on the base station and are distributed through the network. • Current Layout – Displays the current setting of the network layout. • PTP/PTMP radio buttons – - o PTP button – Point to Point. Allows user to switch to a point-to-point solution (only one SS allowed in system). This option maximizes the distance one SS can be from the BS. - o PTMP radio button – Point to MultiPoint. Allows multiple Subscribers to enter the system. • Set button – Changes to the selected layout option • Current Max Distance – Display the current Max Distance value • Max Distance for SS Acquisition – Allows the administrator to set the maximum distance that any subscriber in the network can be and still acquire connectivity with the base station. The value can be entered in miles or kilometers as defined by the two entry boxes. One only needs to enter a valid value in one of the boxes. This entry is only valid for the PTMP network layout and can be set to a value of up to 250 miles for OFDM radios and 210 miles for GMSK radios. Distances set for 25 miles or less default to 25 miles internally in PTMP • Set button – Sets the max distance

3.6.6. Base Station Maintenance Page

The Maintenance page provides more detailed information about the operational status of the unit than the Status page. It provides debug information as well as test capabilities.




Figure 3-42 BS GMSK Maintenance Page

Table 3-13. Base Station Maintenance Page		
	Field/Control	Description
1	More Options	- Reboot - Provides the capability to reboot the unit remotely. Confirmation for reboot is required via a pop up window. - Use Default DB - Provides the capability to revert to the factory default database. All changes made to configuration are lost by confirming the default database option via the pop up window. - Registered SSs - Provides a table of subscribers that have successfully registered with the base station. - Station Tests - Provides some test mechanisms for debug purposes. - Debug - Provides some additional debug capabilities for trouble shooting purposes.
2	Tx/Rx Over the Air Status	Provides the transmit and receive frame counts as well as error counts for debugging. - Rx Frames – Provides the number of frames received by the unit. - Invalid Frames – Provides the number of frames received that were invalid.

Table 3-13. Base Station Maintenance Page		
	Field/Control	Description
		• CRCs Rx – Provides the number of CRCs received. The packet within the frame where the CRC error was received is dropped. • Reset Rx – Provides the number of times the receive path is reset. • Tx Frames – Provides the number of frames transmitted by the unit. • Tx Drop – Provides the number of transmit packets that were dropped because there is no valid class rule for that packet.
3	Board Details	Display Temperature • CPU Temperature – Displays the temperature reported by the processor in Celsius and Fahrenheit • RF Temperature – Displays the temperature reported by the AD9361 chip on the RF card in Celsius and Fahrenheit
4	Ethernet Network status	Displays the number of transmitted and received frames on the network side of the unit. This reflects the eth0 interface in a non-bridging configuration and the mybridge interface in a bridging configuration.
5	Network	Tx Oversubscribed – displays the number of network Ethernet packets that were dropped due to oversubscribing the unit.
6	Channel Status	Provides some additional values on a connection basis for debugging and antenna pointing purposes. • Station – Displays the name of the subscriber the entry represents. ----- OFDM only • Current CINR – Displays the instantaneous CINR for the connection. • Average CINR – Displays the average CINR of the connection over a period of received frames. GMSK Only • Current SNR – Displays the instantaneous estimated SNR for the connection. • Average SNR – Displays the average estimated SNR of the connection over a period of received frames. -----

Table 3-13. Base Station Maintenance Page		
	Field/Control	Description
		• Current RSSI – Displays the instantaneous RSSI at the preamble for the connection. • Average RSSI – Displays the average RSSI at the preamble of the connection over a period of received frames. • Current Mod Type – Displays the current modulation type received by the BS. This represents the modulation of the SS transmissions. • Curr Freq Offset (Hz) – Displays the frequency offset at the time of the display update. • Avg Frequency Offset (Hz) – Displays the average frequency offset of the connection over a period of received frames. • FEC Corrected Bits – Displays the instantaneous forward error correction corrected bits. • Average FEC Corrected Bits – Displays the average forward error correction corrected bits over a period of received frames. • Reed-Solomon Symbol Errors Cur – Displays the instantaneous number of Reed-Solomon errors. • Reed-Solomon Symbol Errors Avg – Displays the average Reed-Solomon errors over a period of received frames. • Time of Arrive Difference – Displays the offset in time of when the BS expected to receive a burst and when it actually received a burst. • CP Offset Cur – Displays the instantaneous cyclic prefix offset. This offset refers to where the FFT is positioned in the symbol. • CP Offset Avg – Displays the average CP offset over a period of received frames.
7	Alarm Interrupts	• Temperature Protect –Provides a count of how many times the RF Temperature reached 83° C. When the RF temperature reaches 83° C, the software will disable the RF Transmit and Receive. When RF temperature lowers to 65°C, the

Table 3-13. Base Station Maintenance Page		
	Field/Control	Description
		software will re-enable the RF Transmit and Receive.

3.6.6.1. Base Station Maintenance Registered Subscriber Page

The Registered SSs page shows all subscribers that have completed the 802.16d registration process with the base station.

Index	MAC Address	Basic Cid	Primary Cid	CRC On/Off
23	00-61-65-6E-64-01	23	55	ON

Figure 3-43 BS Maintenance Registered SS Page

3.6.7. Base Station Video Page

Figure 3-44 BS Video Page

Table 3-14. Base Station Video Page		
	Field/Control	Description
1	Video Control Current Settings	- Allow Bad Frames – Enabling Bad Frames will allow UDP packets received over the RF link that have bit errors in them to continue to be pushed up to the radio’s Ethernet stack. This check is only made on UDP packets with destination port addresses between 1232-1247 - Currently the camera interface on the NANO radio has not been implemented.
2	Serial Flow Control Type	The serial flow feature wraps the serial data in a UDP IP Packet. - Serial B to Serial B – This allows bidirectional serial data to flow from Serial B of one radio to Serial B of another radio. - Serial B To Ethernet – Transfer data between serial B and Ethernet port

Table 3-14. Base Station Video Page		
	Field/Control	Description
		○ Rx Only – Receive data from designated receive port and push the data out to serial B ○ Tx Only – Transmit data from serial B to designated destination IP address and IP port ○ Both (Rx and Tx) – Radio will push data from its Serial B to an external node with the destination IP address and IP Port configured at GUI. The radio will also receive data from receive port and send that data to its Serial B.
3	Serial Flow Control Configuration	• Serial Baud Rate – A drop down menu with a selection of baud rates available. • Serial Raw Mode – • Enable – Enables Raw mode and serial B will process serial input in non-canonical mode. • Disable – Serial B will be set in canonical mode. This will enable line processing mode and each line designated by a new line. The entire line will be wrapped into a UDP packet and then sent across the RF link. • Destination Port – Ability to set the port that the BS serial data is being transmitted on. • Receive Port – Ability to set the port that the BS is receiving serial data on. • Destination IP Addr – Ability to set the Radio's IP address that the serial data is being transmitted to and received from. • Raw Serial mode processing configurations • Raw Buffer – in bytes, the maximum is 255 bytes. • Raw Timeout (deci seconds) - in tenths of seconds, maximum is 255 deci seconds. When in Raw mode the user can configure the serial to buffer bytes and to be more efficient than sending just one character, below are the valid configurations. • Raw Buffer > 0 Raw and Timeout > 0 – The serial will buffer the bytes until the first condition is met and then the data will be packaged into a UDP packet and sent. The timer will be started when the first byte is received.

Table 3-14. Base Station Video Page		
	Field/Control	Description
		- Raw Buffer > 0, and Raw Timeout = 0 – The serial will buffer bytes until the number of bytes on the serial match the Raw Buffer bytes and then the data will be packaged into a UDP packet and sent. - Raw Buffer = 0 and Raw Timeout > 0 – The serial will buffer the amount of bytes in the amount of time specified by the Raw Timeout. The timer is started at each interval, ie not when the first byte is received. - Raw Buffer = 0, and Raw Timeout = 0 – This will package up a byte as it is received from the serial. - Disable/Enable Flow Radio Buttons – Allows user to disable or enable the serial flow control - Submit Button – Once submitted all of the above changes will take effect

3.6.8. Subscriber Station Status

When the GUI is accessed using an approved browser, the unauthenticated status page is displayed.

AERONIX 802.16 Tactical Radio

Subscriber Bridging Mode

Status

MAC Address: 00-61-65-6E-64-02
 Current Channelization: 14 MHz
 Current Channel: 31 (2.412 GHz)
 BS Estimated EIRP: N/A - Multipoint Large Contention
 Tx: ON
 Rx: ON
 Transec: OFF

Board Details

CPU	RF
Temperature	Temperature
59 C 138.2 F	70 C 158.0 F

Tx/Rx Over the Air Status

Front Panel: Base Sync Rcv Xmt Alarm

Connection Status: Sync'd

Base Station Name	Current Rx Modulation Type	Rx Signal Strength	RSSI (dBm)	Service Flow	State	Est. Tx User B/W (Mbits/s)	Est. Tx Allocated B/W (Mbits/s)	Service Flow Oversubscribed
BS	QAM16 1/2	Good	-70	BE_MAX	Active	0.00	4.35	0

Figure 3-45 SS OFDM Status Page

Table 3-15. Subscriber Station Status Page

	Field/Control	Description
1	Status	Status displays a subset of current settings. • MAC Address – The IEEE 802.16 MAC address of the base station • Current Channelization – Displays the channelization of the subscriber station. • Current Channel – The current 802.16 specified channel that the subscriber station uses for transmit and receive. • BS Estimated EIRP – Displays the estimated EIRP of the base station that the subscriber received from the base station. A value of N/A – No Sync displays when the subscriber is not connected to the base station. • Tx - Provides the status of the transmit portion of the unit. (On/Off) The status may be changed on the Radio Control screen. • Rx - Provides the status of the receive portion of the unit. (On/Off). • Transec Status – Displays the status of Transec (on or off).
2	Board Details	Display Temperature • CPU Temperature – Displays the temperature reported by the processor in Celsius and Fahrenheit
3	Front Panel	Displays PHY status on an interval basis. • Base is a constant green light if the radio is configured as a Base Station • Sync is off on the base station when no subscribers are registered and is illuminated continuously when subscribers are registered. • Recv is green when the radio is receiving messages • Xmit is green when the radio is transmitting data
4	Tx/Rx Over the Air Status	The first part of the Tx/Rx Status Table Displays the receive status of each subscriber connection. The second part of the table is the amount of data the BS is transmitting to each active SS. • Base Station Name - Contains the name of the base station for which the information pertains to. • Current Modulation Type – Contains the current modulation/FEC type for the subscriber connection. The display show the modulation of the receive frame at the time sampled. • Rx Signal Strength: Contains an assessment of the receive signal strength.

Table 3-15. Subscriber Station Status Page		
	Field/Control	Description
		- RSSI at LNA – Displays the average RSSI value for the subscriber connection at the LNA. The value is determined using the RSSI value seen at the PHY card at the preamble and the values entered in the GUI for the receive gain and loss from the PHY card to the LNA. Values included: Avg Rssi, Internal Rx Loss, Rx Cable Loss, LNA - Service Flow – Identifies the service class of the service flow for the connection. - State – Displays the state of the connection. The valid values are provisioned and active. - Est User B/W (Mbits/sec) – Displays the estimated bandwidth in megabits per second being used by the connection in the transmit direction. - Est Allocated B/W (Mbits/sec) – Displays the estimated bandwidth in megabits per second being allocated to the connection in the transmit direction. - Service Flow Oversubscribed – Displays the number of Ethernet packets dropped for that specific service flow.

3.6.8.1. Subscriber Station Status Page in Receive Dual

When the user enables RX Dual on the Radio control page the second receive RSSI will be reported on the RSSI1 column on the Tx/Rx Over the Air Status section.

Tx/Rx Over the Air Status									
Front Panel:									
			Base	Sync		Rcv	Xmt	Alarm	
Connection Status: Sync'd									
Base Station Name	Current Rx Modulation Type	Rx Signal Strength	RSSI0 (dBm)	RSSI1 (dBm)	Service Flow	State	Est. Tx User B/W (Mbits/s)	Est. Tx Allocated B/W (Mbits/s)	Service Flow Oversubscribed
BS	QPSK 3/4	Good	-69	-91	BE_MAX	Active	0.00	4.20	0

Figure 3-46 SS OFDM Status Rx Dual

3.6.9. Subscriber Station Admin Page

The admin page for the subscriber station provides the capability to enable and disable Transec and the selection of the Transec key. Account management, start script generation and software download are also supported on the admin page.

Table 3-16. Subscriber Station Admin Page Transec Key		
1	Station Names	• My Name - Displays the current name of the subscriber. The base station provides the subscriber name over the network. Configuration of subscriber names occurs on the base station Admin page.
2	Transec Key Management	Displays the settings for Transec capability. • Transec - Displays whether Transec is on or off on the base station. • Transec Enable/Disable buttons - Turn Transec on or off. • Key Length drop down menu – Allows user to specify the number of bits for the Transec Key • Load Key – Allows the ability to change the Transec Key in hexadecimal based on Key length. • Current Key – Displays the current key.

3.6.9.2. SS Admin Bridging Start Script and Software Update

Bridging is the default mode for operating the units. The Generate Bridging Start Script section of the admin page allows for configuration of the start script. Once the configuration is set by selecting the Generate Script button, the unit must be rebooted or power cycled for the configuration to take effect.

For account management and software update examples, refer to the 3.6.2.2 Base Station BS Admin Bridging Start Script and Software Update.

Generate Bridging Start Script

Current Type: ss
 Current Id: 1
 Current User Interface: webgui
 Quagga: Disabled
 Current IPv4 Address: 192.168.1.1
 Current IPv4 Netmask: 255.255.0.0
 Current Vlan ID: Unknown
 Current IPv6 Address: Unknown
 Current IPv6 Netmask: Unknown
 Current IPv4 Gateway: Unknown
 Current IPv6 Gateway: Unknown
 Current IPv6 Dest Net: Unknown
 Current IPv6 Dest Mask: Unknown

Base Station (ID Opt) / Subscriber (ID Req)
 Id:
 User Interface: ☒ Webgui ☐ SNMP
 Quagga: ☐ Enable ☒ Disable
 IPv4 Address:
 IPv4 Netmask:
 Vlan ID (Optional):
 IPv6 Address (Optional):
 IPv6 Netmask (Optional):
 IPv4 Default Gate (Opt):
 IPv6 Default Gate (Opt):
 IPv6 Dest Network:
 IPv6 Dest Net Mask:
 Generate Script

Software Update
 File Path: Browse...
 Start Update

Figure 3-49 SS Admin Start Script and SW Update

Table 3-17. Subscriber Station Admin Page Transec Key		
1	Current Start Script	The current start script parameters.
2	Generate Script	User can change the mode the radio boots in or the IP address,etc. The unit should not be powered cycled while script generation is in process. - Type radio buttons: Select BS or SS for type - Id: If setting up start script as SS enter its Subscriber Number. - User Interface: Only valid interface for EDL is the Webgui - Quagga: Option to enable additional network routing software suite providing implementations of Open Shortest Path First (OSPF). Note there is user configuration necessary to implement Quagga. - IPv4 Address: Provides the capability to set a new IPv4 address for the unit. - IPv4 Netmask: Provides the capability to set a new IPv4 netmask address for the unit

Table 3-17. Subscriber Station Admin Page Transec Key		
		- Vlan ID: Allows user to add a VLAN ID to IP packets coming from radio. The radio will pass VLAN tagged packets unmodified, so this does not need to be set to allow VLAN packets to flow through the radio. Only if communication to the radio needs to have a VLAN ID. - IPv6 Address (Optional) : Optional IPv6 address for the Ethernet (Note : current release of EDL does not support IPv6) - IPv4 Default Gate (Opt) : Optional ability to configure an IPv4 default gateway. - IPv6 Default Gate (Opt) : Optional ability to configure an IPv6 default gateway - IPv6 Netmask (Optional) : Optional IPv6 netmask for IPv6 address (Note: current release of EDL does not support IPv6) - Enable/Disable Video Support Radio Buttons: If the start script is being configured for a SS then user has the option of enabling the video software to run at start up. Currently not a valid selection if the start script is being configured as a BS - Generate Script Button : Generates a new start script for the unit with the values input in the “Generate Bridging Start Script” section of the Admin page. Once the script has been generated, the unit must be rebooted or power cycled for the new values to take effect. The unit should not be power cycled while script generation is in process.
3	Software Update	Allows user to select a signed package file provided by the manufacturer to update the software on the unit. - File Path – Allows users to browse to location where the package file resides. - Start Update - Selection of the start update button starts the software update using the factory signed package file specified in the File Path. Once the update process begins, any interruption can render the box unusable and require its return to the factory.

3.6.10. Subscriber Network Config Page

The Network Config page on the subscriber contains the class rule information received from the base station.

AERONIX 802.16 Tactical Radio

Subscriber Bridging Mode

Network Options

Classifiers Status: **ENABLED** Classifiers Status:

ARP Table Status: **ENABLED** ARP Table Status:

Class Rules

Forwarders Enabled: **NO**

Non-Forwarder Count: **1**

Forwarder Count: **0**

Index	SF	Src MAC	Src Mask	Dest MAC	Dest Mask
0	7	00-00-00-00-00-00	00-00-00-00-00-00	00-00-00-00-00-00	00-00-00-00-00-00

Figure 3-50 SS Network Config Page

Table 3-18. Subscriber Station Network Config		
	Field/Control	Description
1	Network Options	- Classifier Status : Disables or Enables using the Classifier Rules Table - ARP Table Status: Disables or Enables the ARP Table Feature. See 7.1
2	Class Rules	Contains the following: - Index - Internal index used for class rules. - SF - Identifies the service flow that pertains to the class rule. - SRC IP/MAC - The source address for the class rule. The address presented to the unit when initiating traffic through it. - Src Mask - The address mask for the source address. Masking portions of the IP address is only valid when the addresses of the units are configured on different subnets. Currently only the last subnet byte is allowed to be masked. - Dest IP/MAC – The destination address for the class rule. The destination address for the traffic through the unit. - Dest Mask - The address mask for the destination address. Masking portions of the IP address is only valid when the addresses of the units are configured on different subnets. Currently only the last subnet byte is allowed to be masked.

3.6.11. Subscriber Profile Config Page

The subscriber station Profile Config page contains the DCD and UCD information for the unit received from the base station. This page is not modifiable from the subscriber. The information can only be modified on the base station.

Downstream Burst Profiles

Index	DIUC	DCD FEC Code	CINR (dBm) Mandatory Exit	CINR (dBm) Minimum Entry	FEC (cnts) Mandatory Exit	FEC (cnts) Minimum Entry	Available
1	1	BPSK 1/2	6	9	0	0	Enabled
2	2	QPSK 1/2	10	12	15	4	Enabled
3	3	QPSK 3/4	12	17	3	1	Enabled
4	4	8PSK 1/2	17	19	22	6	Enabled
5	5	QAM16 1/2	19	21	6	2	Enabled
6	6	QAM16 3/4	21	24	23	6	Enabled
7	7	QAM64 2/3	24	26	12	3	Enabled

Upstream Burst Profiles

Index	UIUC	FEC
1	5	BPSK 1/2
2	6	QPSK 1/2
3	7	QPSK 3/4
4	8	8PSK 1/2
5	9	QAM16 1/2
6	10	QAM16 3/4
7	11	QAM64 2/3

Figure 3-51 SS OFDM Profile Config Page

Table 3-19. Subscriber Profile Config Page		
	Field	Description
1	Downstream Burst Profiles	- Index – Value used internally to index the bust profiles. The value gets automatically generated. - DIUC - Downlink interval usage code defined by 802.16d. The values get generated automatically and are for viewing and debug purposes. - DCD FEC Code - Defines the forward error correction and coding for the burst profile entry. - CINR/SNR Mandatory Exit - Defines the CINR/SNR value in dBm at which ACM exits the FEC code type.

Table 3-19. Subscriber Profile Config Page		
	Field	Description
		• CINR/SNR Minimum Entry - Defines the CINR/SNR value in dBm at which ACM allows entry into to the FEC code type. • FEC Mandatory Exit - Defines the largest number of FEC bits one symbol can have before the decision is made to move out of the current FEC code type. • FEC Minimum Entry - Defines the largest number of FEC bits one symbol can have before ACM attempts to move to a higher data per symbol FEC Code type. • Available - symbol FEC Code type. • Available – Displays the availability of the burst profile. Enabled profiles are used in the ACM scheme and disabled profiles are not used.
2	Upstream Burst Profiles	The upstream burst profiles are displayed for informational and debug purposes. The upstream burst profiles use the same FEC code types and entry and exit thresholds defined for the downstream burst profiles.

3.6.12. Subscriber Station Radio Control Page

The subscriber station radio control page allows for configuring the 802.16d radio settings.

802.16 Tactical Radio

Subscriber Bridging Mode

Receive Control

☐ Receive Dual
 ☒ SISO
 Set

Current Rx Mode: SISO

Rx Data Swap Status: Disabled

☐ Rx Data Swap
 On
Off

Tx/Rx

☐ Tx/Rx Status: OFF
 On
Off

Channel

☐ Scan Channels
 Scan Channels ☐

Scan Channels: OFF
 Current Channel: 31 (2.412 GHz)

Channel (Freq) 31 (2.412 GHz)
Set

or Custom Freq (1800 - 2500)
Set

Current Channelization: 14 MHz

☐ 3.5 MHz
 ☐ 7 MHz
 ☒ 14 MHz
 Set

Power Values

☐ High Power
 ☒ High Data
 Set

BS Estimated EIRP: N/A - No Sync

Power Output Mode: High Data

Cable Length and Loss Selection

External Rx: 0 ft. (0 dB)

External Rx Cable Loss: 0 ft. No Cable (0 dB loss)
Set

External Tx: 0 ft. (0 dB)

External Tx Cable Loss: 0 ft. No Cable (0 dB loss)
Set

Antenna: 3 ft. (1 dB)

Antenna Cable Loss: 3 ft. 2.4GHz cable (1 dB loss)
Set

Report Statistics Control

☐ Report statistics via Ethernet
 Enable
Disable

Stats via Ethernet: DISABLE

Figure 3-52 SS OFDM Radio Control Page

AERONIX 802.16 Tactical Radio

Subscriber Bridging Mode

Receive Control
 Current Rx Mode: SISO Receive Dual ☐ SISO ☒ Set

Rx Data Swap Status: Disabled Rx Data Swap On Off

Tx/Rx
 Tx/Rx Status: ON Tx/Rx On Off

Channel
 Scan Channels: OFF Scan Channels ☐
 Current Channel: Custom (2.500 GHz) Channel (Freq) 31 (2.412 GHz) Set
 or Custom Freq (1800 - 2500) MHz Set

Current Channelization: 14 MHz

Power Values
 BS Estimated EIRP: N/A - PTP Mode
 Power Output Mode: Low Power High Power ☐ Low Power ☒ Set

Figure 3-53 SS GMSK Radio Control

Table 3-20. Subscriber Station Radio Control		
	Field/Control	Description
1	Rx Mode	- Receive Dual – Both receivers are enabled - SISO – Only one Receive path is enabled
2	Rx Data Swap	If enabled, the receive paths will be switched in the firmware.
3	Tx/Rx	- Tx/Rx Status - Shows the current status of the transmit and receive of the unit. - Tx/Rx On and Off Buttons - Provides the capability to turn on or turn off the transmit/receive capability of the unit. When the selection is off the unit does not transmit or receive.
4	Channel / Channelization	Displays channel information for the base station. - Scan Channels – Displays the current setting for scan channels (OFF/ON). - Scan Channels button – Allows the user to turn scan channels on or off. If on, the subscriber scans through the available channels per the channelization selected and tries to connect to a base station at each frequency. The subscriber remains

Table 3-20. Subscriber Station Radio Control		
	Field/Control	Description
		connected to the first base station a successful connection is made • Current Channel – Displays the current channel and frequency of the base station. • Channel (Freq) – – Pull down menu to choose a different channel/frequency for the base station. The base station and subscriber stations need to be configured for the same channelization for proper operation. • Set Button – Changes the current channel of the base station to the channel selected by the channel (freq) drop down. • Custom Freq (2412 – 2462) – Allows user to create a frequency outside of the drop down frequency list. The frequency must be a valid operating frequency for the unit. • Set Button – Changes the current channel of the base station to the custom frequency • Current Channelization – Displays the current channelization of the radio. The base station and subscriber stations need to be configured for the same channelization. • Channelization Selection – Allows the selection of the channelization. Current choices are 3.5 MHz, 7 MHz, and 14 MHz • Set Button – Changes the current channelization selected by the user. Note: Selecting a frequency outside of the ISM band (2400 – 2483.5MHz) voids the FCC Part 15.247 Certification.
5	Power Values	• BS Estimated EIRP - Displays the estimated EIRP of the base station based upon user configured gain and loss values.
5A	Power output mode	OFDM only • High Power – radios TX power is calibrated to a higher power that still has a good enough EVM to maintain the QAM16 modulations. The QAM64 modulations will be disabled, if user re-enables them there is no guarantee the signal quality level will sustain QAM64 • High Data – radios will TX power will be set to a power level whose EVM will

Table 3-20. Subscriber Station Radio Control		
	Field/Control	Description
		sustain the QAM64 modulations. this power may be lower to maintain the higher EVMs required by QAM64 modulations. GMSK - High Power – radios TX power is calibrated to an output power of 35-36 dB while still remaining within our GMSK mask. - High Data – radios TX power will be set to a power level of 30 dBm while remaining within our GMSK mask. Note: Selecting the high power mode voids the FCC Part 15.247 Certification. See 7.1 NANO output power for details on how to view transmit power values.

3.6.13. Subscriber Station Maintenance Page

The Maintenance page provides more detailed information about the operational status of the unit than does the Status page. It provides debug information and capabilities as well as test capabilities.




Figure 3-54 SS OFDM Maintenance Page

Table 3-21. Subscriber Station Maintenance Page		
	Field/Control	Description
1	More Options	• Reboot - Provides the capability to reboot the unit remotely. Confirmation for reboot is required via a pop up window. • Use Default DB - Provides the capability to revert to the factory default database. All changes made to configuration are lost by confirming the default database option via the pop up window. • Registered SSs - Provides a table of subscribers that have successfully registered with the base station. • Rx/Tx Loss - Provides a method to configure receive and transmit loss values that are internal to the unit. • Station Tests - Provides some test mechanisms for debug purposes. • Debug - Provides some additional debug capabilities for trouble shooting purposes.
2	Tx/Rx Over the Air Status	Provides the transmit and receive frame counts as well as error counts for debugging. • Rx Frames – Provides the number of frames received by the unit. • Invalid Frames – Provides the number of frames received that were invalid. • CRCs Rx – Provides the number of CRCs received. The packet within the frame where the CRC error was received is dropped. • Reset Rx – Provides the number of times the receive path is reset. • Rx Timeouts – Number of bursts the Subscriber has missed. • Tx Frames – Provides the number of frames transmitted by the unit. • Tx Drop – Provides the number of transmit packets that were dropped because there is no valid class rule for that packet.
3	Board Details	Display Temperature • CPU Temperature – Displays the temperature reported by the processor in Celsius and Fahrenheit • RF Temperature – Displays the temperature reported by the AD9361 chip on the RF card in Celsius and Fahrenheit
4	Ethernet Network status	Displays the number of transmitted and received frames on the network side of the unit. This

Table 3-21. Subscriber Station Maintenance Page		
	Field/Control	Description
		reflects the eth0 interface in a non-bridging configuration and the mybridge interface in a bridging configuration.
5	Network	Tx Oversubscribed – displays the number of network Ethernet packets that were dropped due to oversubscribing the unit.
6	Channel Status	Provides some additional values on a connection basis for debugging and antenna pointing purposes. - Station – Displays the name of the subscriber the entry represents. ----- OFDM only - Current CINR – Displays the instantaneous CINR for the connection. - Average CINR – Displays the average CINR of the connection over a period of received frames. GMSK Only - Quality Cur – Displays a number that quantifies the link reliability, with 26 being the best link value - Quality Avg – Average quality value ----- - Current RSSI – Displays the instantaneous RSSI at the preamble for the connection. - Average RSSI – Displays the average RSSI at the preamble of the connection over a period of received frames. - Current Mod Type – Displays the current modulation type received by the BS. This represents the modulation of the SS transmissions. - Curr Freq Offset (Hz) – Displays the frequency offset at the time of the display update. - Avg Frequency Offset (Hz) – Displays the average frequency offset of the connection over a period of received frames. - FEC Corrected Bits – Displays the instantaneous forward error correction corrected bits. - Average FEC Corrected Bits – Displays the average forward error correction corrected bits over a period of received frames.

Table 3-21. Subscriber Station Maintenance Page		
	Field/Control	Description
		• Reed-Solomon Symbol Errors Cur – Displays the instantaneous number of Reed-Solomon errors. • Reed-Solomon Symbol Errors Avg – Displays the average Reed-Solomon errors over a period of received frames. • Time of Arrive Difference – Displays the offset in time of when the BS expected to receive a burst and when it actually received a burst. • CP Offset Cur – Displays the instantaneous cyclic prefix offset. This offset refers to where the FFT is positioned in the symbol. • CP Offset Avg – Displays the average CP offset over a period of received frames.
7	Alarm Interrupts	• Temperature Protect –Provides a count of how many times the RF Temperature reached 85°C. When the RF temperature reaches 85°C, the software will disable the RF Transmit and Receive. When RF temperature lowers to 65°C, the software will re-enable the RF Transmit and Receive.

3.6.14. Subscriber Station Video Page

AERONIX 802.16 Tactical Radio

Subscriber Bridging Mode

Video Control

Allow Bad Frames: OFF Allow Bad Frames ← 1

VIDEO: NOT SUPPORTED

Serial Flow Control

Serial B to Serial B: ☒ Serial B to Serial B

-Or-

Serial B to Ethernet: ☐ Rx Only ☐ Tx Only ☐ Both (Rx and Tx) ← 2

Current Direction: Serial B to Serial B

Serial Baud Rate: 4800 Serial Baud Rate 4800 ▾

Serial RawMode: Disabled ☐ Raw ☒ Normal

Current Dest Port: 31330 Destination Port:

Current Rx Port: 31331 Receive Port:

Current Dest IP: 192.168.100.1 Destination IP Addr: ← 3

Current Raw Buffer: 0 Raw Buffer:

Current Raw Timeout: 0 Raw Timeout (deciseconds):

Serial Flow: Disabled ☒ Disable Flow ☐ Enable Flow

Figure 3-55 SS Video Page

Table 3-22. Subscriber Station Video Page		
	Field/Control	Description
1	Video Control Current Settings	- Allow Bad Frames – Enabling Bad Frames will allow UDP packets received over the RF link that have bit errors in them to continue to be pushed up to the radio's Ethernet stack. This check is only made on UDP packets with destination port addresses between 1232-1247. - Currently the camera interface on the NANO radio has not been implemented.
2	Serial Flow Control Type	The serial flow feature wraps the serial data in a UDP IP Packet. - Serial B to Serial B – This allows bidirectional serial data to flow from Serial B of one node to Serial B of another node. - Serial B To Ethernet – Transfer data between serial B and Ethernet port ☐ Rx Only – Receive data from designated receive port and push the data out to serial B

Table 3-22. Subscriber Station Video Page		
	Field/Control	Description
		0 Tx Only – Transmit data from serial B to designated destination IP address and IP port 0 Both (Rx and Tx) – Radio will push data from its Serial B to an external node with the destination IP address and IP Port configured at GUI. The radio will also receive data from receive port and send that data to its Serial B.
3	Serial Flow Control Configuration	• Serial Baud Rate – A drop down menu with a selection of baud rates available. • Serial Raw Mode – • Enable – Enables Raw mode and serial B will process serial input in non-canonical mode. • Disable – Serial B will be set in canonical mode. This will enable line processing mode and each line designated by a new line. The entire line will be wrapped into a UDP packet and then sent across the RF link. • Destination Port – Ability to set the port that the BS serial data is being transmitted on. • Receive Port – Ability to set the port that the BS is receiving serial data on. • Destination IP Addr – Ability to set the Radio's IP address that the serial data is being transmitted to and received from. • Raw Serial mode processing configurations • Raw Buffer – in bytes, the maximum is 255 bytes. • Raw Timeout (deciseconds) - in tenths of seconds, maximum is 255 deciseconds. When in Raw mode the user can configure the serial to buffer bytes and to be more efficient than sending just one character, below are the valid configurations. • Raw Buffer > 0 Raw and Timeout > 0 – The serial will buffer the bytes until the first condition is met and then the data will be packaged into a UDP

Table 3-22. Subscriber Station Video Page		
	Field/Control	Description
		packet and sent. The timer will be started when the first byte is received. • Raw Buffer > 0, and Raw Timeout = 0 – The serial will buffer bytes until the number of bytes on the serial match the Raw Buffer bytes and then the data will be packaged into a UDP packet and sent. • Raw Buffer = 0 and Raw Timeout > 0 – The serial will buffer the amount of bytes in the amount of time specified by the Raw Timeout. The timer is started at each interval, ie not when the first byte is received. • Raw Buffer = 0, and Raw Timeout = 0 – This will package up a byte as it is received from the serial. • Disable/Enable Flow Radio Buttons – Allows user to disable or enable the serial flow control • Submit Button – Once submitted all of the above changes will take effect

3.6.15. BS and SS Common Pages

3.6.15.1. Save Settings Button

The Save Settings button works the same for both the base station and subscriber. The Save Settings button saves any changes that have been made on the GUI to the database with the exception of the items mentioned in default database section that do not go back to default. All modifications made and set take effect automatically at the time they are set with the exception of generating start scripts. But, the changes do not get saved to the database unless the Save Settings button is selected and confirmed. Changes made and not saved to the database will be lost on a reboot or a power cycle. The save settings occurs for all screens simultaneously and not just for the screen currently being browsed. A confirmation popup appears when the Save Settings button gets selected.

The screenshot displays the Aeronix 802.16 Tactical Radio web interface. On the left is a navigation menu with buttons for Status, Admin, Network Config, Profile Config, Radio Control, Save Settings, Version, Maintenance, Video (highlighted), and Contact. The main content area is divided into two sections: Video Control and Serial Flow Control. The Video Control section shows 'Allow Bad Frames: OFF' and 'VIDEO: NOT SUPPORTED'. The Serial Flow Control section shows 'Serial B to Serial B' selected, 'Serial B to Ethernet' with options for Rx Only, Tx Only, and Both (Rx and Tx), and 'Current Direction: Serial B to Serial B'. Below these are fields for Serial Baud Rate (4800), Serial Raw Mode (Disabled), Current Dest Port (31331), Current Rx Port (31330), Current Dest IP (192.168.1.1), Current Raw Buffer (0), Current Raw Timeout (0), and Serial Flow (Disabled). A 'Message from webpage' dialog box is overlaid, asking 'Are you sure you want to save the current settings to database?' with OK and Cancel buttons. The dialog box also shows a 'Raw Buffer' field and a 'Raw Timeout (deciseconds)' field, with 'Disable Flow' selected and a 'Submit' button.

Figure 3-56 Save Settings Selection

3.6.15.2. Version Page

The Version page may be viewed by an authenticated or unauthenticated viewer by selecting the Version button. The base station and subscriber station Version page contains the same content.




Figure 3-57 Version Page

Table 3-23. Version Page		
	Field/Control	Description
1	GUI Software Information	Version, date and time of the GUI build on the unit. OFDM software releases will have 80216 string in the version. The GMSK software releases will have the GMSK string in the version.
2	Network Addresses	- My IP Address - Ethernet IP Address of the unit. - Internal IP Address - MAC S/W network interface IP Address. There is no internal IP address in the bridging mode

Table 3-23. Version Page		
	Field/Control	Description
		- My MAC Address - MAC H/W Address of unit. - Internal MAC Address - Internal MAC address of the unit used by the MAC S/W.
3	MAC BS/SS Version Information	Version, date and time of the MAC S/W build on the unit. OFDM software releases will have 80216 string in the MAC CVS tag. The GMSK software releases will have the GMSK string in the MAC CVS tag.
4	Phy Versions	Firmware versions for PHY and Serial Number of PHY hardware

3.6.15.3. Maintenance Page Reboot Button

The reboot button in the More Options section allows the administrator to reboot the unit remotely. The administrator must confirm the reboot.

The screenshot displays the 'Base Station Bridging Mode' interface. On the left is a vertical navigation menu with buttons: Status, Admin, Network Config, Profile Config, Radio Control, Save Settings, Version, Maintenance (highlighted), Video, and Contact. The main content area is divided into several sections:

- More Options:** Contains buttons for Reboot, Use Default DB, Registered SSs..., Station Tests..., and Debug...
- Tx/Rx Over the Air Status:** A table showing statistics:

Rx Frames	Invalid Frames	CRCs Rx	Reset Rx	Tx Frames	Tx Drop
6937825	1526	28	308	6828624	870
- Board Details:** A table showing temperatures:

CPU Temperature	RF Temperature
42 C 107.6 F	51 C 123.8 F
- Ethernet Network Status:** A table showing network metrics:

	Packets	Errors	Dropped	Overruns	Frames	Carrier
Rx	221885	0	0	0	0	N
Tx	143185	0	0	0	N/A	
- Channel Status:** A large table showing channel parameters for station SS-1:

Station	SNR (dBm)		RSSI (dBm)		Current Mod Type	Freq Offset (Hz)		Tx Power		Tx Rate		Tx Error		CP Offset
	Cur	Avg	Cur	Avg		Cur	Avg	Cur	Avg	Cur	Avg	Cur	Avg	
SS-1	16	16	-78	-79	8 PPS 3/4	0	0	0	0	0	0	2	0	1
- Alarm Interrupts:** A table showing the status of Temperature Protect:

Temperature Protect
0

A 'Message from webpage' dialog box is overlaid on the Ethernet Network Status table, containing a question mark icon and the text: 'Are you sure you want to reboot this node?'. It has 'OK' and 'Cancel' buttons.

Figure 3-58 Maintenance Reboot Selection

3.6.15.4. Maintenance Page Use Default DB

The Use Default DB button allows the user to revert to the factory default settings. Most saved configuration settings are lost once the user confirms the selection. A warning message pops up after selecting the Use Default DB button (Figure 3-59 Maintenance Use Default DB Selection). The node will reboot once the user confirms their selection.

Note: Settings that do not go back to default:
 Start script information
 Transec keys

AERONIX 802.16 Tactical Radio

Base Station Bridging Mode

More Options

- Reboot
- Use Default DB**
- Registered SSs...
- Station Tests...
- Debug...

Tx/Rx Over the Air Status

Rx Frames	Invalid Frames	CRCs Rx	Reset Rx	Tx Frames	Tx Drop
6945314	1526	28	308	6835931	870

Board Details

CPU Temperature	RF Temperature
41 C 105.8 F	50 C 122.0 F

Ethernet Network Status

	Packets	Errors	Dropped	Overruns	Frames
Rx	221898	0	0	0	0
Tx	143194	0	0	0	N/A

Channel Status

Station	SNR (dBm)		RSSI (dBm)		Current Mod Type	Freq C (Hz)		CP Offset						
	Cur	Avg	Cur	Avg		Cur	Avg	Cur	Avg					
SS-1	17	16	-78	-79	8 PPS 3/4	0	0	0	0	0	0	-2	0	3

Alarm Interrupts

Temperature Protect
0

Message from webpage

Are you sure you want to revert to the default database and REBOOT this node?

OK Cancel

Figure 3-59 Maintenance Use Default DB Selection

3.6.15.5. Maintenance System Tests Page

Station tests can be configured by selecting the Station Tests button on the More Options section of the Maintenance page. The Station Tests page provides the capability to execute a continuous sine wave test or a bit error rate test. When either of the tests are executing, the normal operation of the unit is not functional. Upon test completion the unit should return to normal operation.

Title: Aeronix Data Links – EDL Nano Products User Guide

Subscriber Bridging Mode (Debug GUI)

System Information
Current Channel: 11 (2.462 GHz)

CW Test
CW Status: Not Running
Start Transmit Start Receive Stop All Tests

BER Test
Current Mod Type: QAM64 2/3
Current Bit Pattern: 2²³-1
Current Test Length: 30 seconds
Current Num of Symbols: 122
BER Status: Not Running
Time Left: [blank]

Mod Type: QAM64 2/3
Bit Pattern: 2²³-1
Test Length: 30 seconds
Symbols (1-122): 122
(Input Symbols is Tx for a Master or Rx for a Slave)

BER Test Results (Rx)
Reset

Rx Sync	Latched Loss of Sync	Total Bits	Correct Bits	Error Bits	Bit Error Rate	MBits/sec	RSSI	Freq Offset
[icon]	[icon]	0	0	0	0.000000e+00	0.00	0.00	0

Run as Master Run as Slave Stop All Tests

Figure 3-60 OFDM Maintenance System Tests Page

Table 3-24. Maintenance System Tests Page		
	Field/Control	Description
1	System Information	Current Channel – Displays the current channel and frequency of the unit. This defines the channel where test execution occurs.
2	CW Test	Continuous Sine Wave Test - CW Status – Displays the state of the test 0 Not Running 0 Transmitting... 0 Receiving...(RSSI x) if actually receiving a CW then the RSSI level is displayed - Start Transmit button – Starts the CW transmission - Start Receive button – Puts the unit in receive mode to capture the CW transmission from another unit. - Stop All Tests – Stop the test from running and returns the unit to normal operation.
3	BER Test Current settings	Current Mod Type - Displays the current modulation setting for test execution.

Table 3-24. Maintenance System Tests Page		
	Field/Control	Description
		• Current Bit Pattern – Bit pattern to use in BER test • Current Test Length – The current length of time the test executes. • Current Num Of Symbols – Displays the current number of symbols in a frame to use for test execution. • BER Status – Status of test ○ Not Running ○ Running as Master ○ Running as Slave • Time left – Displays a countdown for the length of the test, if the length is “Until Stopped” this field displays a “∞” symbol
4	BER Test	Bit Error Rate Test requires a unit configured as the master and a unit configured as the slave for proper execution and results. • Mod Type – Allows the administrator to change the modulation for test execution. The drop down list provides the selections. • Set button – Changes the modulation to the value chosen from the Mod Type drop down list. • Bit Pattern – Allows the administrator to select a new bit pattern for test execution. The drop down list provides the selections. • Set button – Changes the bit pattern to the value chosen from the Bit Pattern drop down list. • Test Length – Allows the administrator to select a new test length. The drop down list provides the selections. • Set button - Changes the test execution length to the value chosen from the Test Length drop down list. • Symbols (0 –122) – Allows the administrator to provide a new number of symbols for test execution. The configured numbers of symbols much match on the master and slave. • BER Status – Displays the current state of the test. ○ Not Running ○ Running as Master ○ Running as Slave

Table 3-24. Maintenance System Tests Page		
	Field/Control	Description
		Time left – Displays a countdown for the test execution time left. If the Test Length selected is Until Stopped this field displays a ∞ symbol.
4	BER Test Results (Rx)	If the number of symbols to receive by the unit is not 0, the BER Test Results table contains the results after test execution completes. Test execution comprises of the master unit transmitting for the number of symbols selected and the slave listening for those symbols and the slave transmitting for the same number of symbols and the master listening for those symbols. This occurs for the value selected in the Test Length field. • Reset Button – Resets the test result fields in the table. • Rx Sync light – Appears green if the unit receives sync from the transmitter. • Latched Loss of Sync – Appears green if unit loses sync. • Total Bits – Displays the total bits received by the unit during test execution. • Correct Bits – Displays the number of correct bits during test execution. • Error Bits – Displays the number of bits with errors during test execution. • Bit Error Rate – Displays ratio of non-correct bits versus correct bits • Mbits/sec – Displays the number of bits received divided by the number of seconds the test executed. • RSSI – Provides the received signal strength. • Freq Offset – Provides the frequency offset.
5	BER Mode Buttons	• Run as Master button – Starts the test in master mode. • Run as Slave button – start test in Slave mode • Stop All Tests button – Stops the BER test execution and returns the unit to normal operation.

3.6.15.6. Maintenance Debug Page

The Debug page can be accessed by selecting the Debug button in the More Options section of the Maintenance page. It provides additional debug capabilities that can be used for lab testing and in the field

AERONIX 802.16 Tactical Radio

Subscriber Bridging Mode

Status
Admin
Network Config
Profile Config
Radio Control
Save Settings
Version
Maintenance
Video
Contact

PCI Tests

	Offset	Value	Status	
Read		0x00000000		Run
Write				Run

Proc Interface

Current Proc: None Proc List: None Display

Auto Refresh: OFF Auto Refresh: On Off

No Proc Selected

Figure 3-61 Maintenance Debug Page

Table 3-25. Maintenance Debug Page		
	Field/Control	Description
1	PCI Tests	Writing values to FPGA registers can render the unit nonoperational and could leave the unit in a condition where a reboot or power cycle is required. Values must be preceded by a 0x. - Read - Provides the capability to input an offset to an FPGA register and to read the value by selecting the Run button to the right of the row. - Write - Provides the capability to change the value of an FPGA register by supplying the offset of the register and the value in the appropriate locations. Selecting the Run button to the right of the row updates the value.
2	Proc Interface	The proc interface provides supplies debug information for the different interfaces in the unit.

Table 3-25. Maintenance Debug Page		
	Field/Control	Description
		The proc interface is for detailed debugging usually handled by the unit developers. Therefore each parameter will not be described in detail in this document. • Proc List – Provides a pull down list of available proc interfaces for viewing. • Display Button – Displays the debug information for the interface chosen in the Proc List drop down and displays it in display box below • Auto Refresh – ○ On – Enable auto refresh which will update the debug interface every second ○ Off – Disable auto refresh, the display will only be updated when user clicks on the Display button

3.6.15.7. Contact Page

The contact page provides contact information for the 802.16 product.



3.7. SNMP Interface configuration

The user can use SNMP to set most the radios configuration. Aeronix SNMP agent is compatible with SNMPv3.

Aeronix has used the following third party applications to interact with our SNMP agent.

- net-snmp – suite of applications to implement SNMP
- SNMPc – GUI application for SNMP
- iReasoning MIB browser

Aeronix is listed under the enterprise OID,

The Aeronix OID is 1.3.6.1.4.17701.10.1.x.x, where x.x is the object identifier that is defined in the Aeronix MIB, see

Appendix A: SNMP MIB.

Click the advanced button next to the *Address* field. Enter “user” for USM User, “SHA” for Authentication and “DES” for privacy. Then enter “AERONIX1%” for the SHA and DES passwords.

3.7.1. SNMP User Authentication

The Aeronix User-based Security name is “user”. The Aeronix authentication protocol is “SHA”. The privacy type is “DES”. The privacy key or pass phrase to use is “AERONIX1%”.

3.7.2. SNMP examples

Below are some examples on how to query and modify Aeronix tables. The examples are using the net-snmp library of commands.

3.7.2.1. Basic SNMP get request

```
snmpget -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X Aeronix1%  
-u user -m <mib> <ip> <item>
```

Example:

```
snmpget -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X Aeronix1%  
-u user -m /home/general/SNMP/AERONIX-802.16-MIB.mib.txt  
192.168.100.1 txrxEnable.1
```

3.7.2.2. Basic SNMP set request

```
snmpset -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X Aeronix1%  
-u user -m <mib> <ip> <item> <item type> <value>
```

Example:

```
snmpset -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X Aeronix1%  
-u user -m /home/general/SNMP/AERONIX-802.16-MIB.mib.txt  
192.168.100.1 txrxEnable.1 i 0
```

3.7.2.3. Basic SNMP Table request

```
snmptable -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X  
Aeronix1% -u user -m <mib> <ip> <table name>
```

Example:

```
snmptable -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X  
Aeronix1% -u user -m /home/general/SNMP/AERONIX-802.16-  
MIB.mib.txt 192.168.100.1 wmanIfBsSsNameTable
```

3.7.2.4. SNMP Save Database

```
snmpset -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X Aeronix1%  
-u user -m $PWD/AERONIX-802.16-MIB.mib.txt 192.168.8.1  
savedatabase.1 u 1
```

3.7.2.5. SNMP start script

If a data object is not referenced in the snmpset command then it will default to what it was previously set to. This could be what the system default is, or if the value has been changed by the user then the value will remain what the user has set since boot.

Configure Start Script:

```
snmpset -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X Aeronix1%  
-u user -m AERONIX-802.16-MIB.mib.txt 192.168.2.1 basestation.1  
unsigned 0 ssId.1 unsigned 2 webgui.1 unsigned 0 udhcpc.1  
unsigned 0 bridging.1 unsigned 1 sysIP4Address.1 string  
192.168.2.1 sysIP4Netmask.1 string 255.255.0.0
```

Create start script

```
snmpset -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X Aeronix1%  
-u user -m AERONIX-802.16-MIB.mib.txt 192.168.2.1  
makeStartScript.1 u 1
```

3.7.2.6. SNMP frequency

Frequency is in Hertz units.

Display Frequency

```
snmpget -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X Aeronix1%  
-u user -m AERONIX-802.16-MIB.mib.txt 192.168.100.1 customFreq.1
```

Configure Frequency

```
snmpset -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X Aeronix1%  
-u user -m AERONIX-802.16-MIB.mib.txt 192.168.100.1 customFreq.1  
s 18000000000
```

Note Frequency is entered in Hertz

3.7.2.7. SNMP Bandwidth

Display Bandwidth

```
snmpget -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X Aeronix1%  
-u user -m AERONIX-802.16-MIB.mib.txt 192.168.100.1  
freqBandwidth.1
```

Configure Bandwidth

```
snmpset -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X Aeronix1%  
-u user -m AERONIX-802.16-MIB.mib.txt 192.168.100.1  
freqBandwidth.1 u 14000000
```

3.7.2.8. SNMP add service class

This is only done on the BS.

- Poll service class table (wmanIfBsServiceClassTable):

```
snmptable -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X  
Aeronix1% -u user -m <mib> <ip> <table name>
```

Example:

```
snmptable -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X  
Aeronix1% -u user -m /home/general/SNMP/AERONIX-802.16-  
MIB.mib.txt 192.168.100.1 wmanIfBsServiceClassTable
```

Expected Output:

```
wmanIfBsQoSProfileIndex      wmanIfBsQoSServiceClassName bitArray  
wmanIfBsQoSTrafficPriority wmanIfBsQoSMaxSustainedRate wmanIfBsQoSMinReservedRate  
wmanIfBsQoSScSchedulingType wmanIfBsQOSServiceClassRowStatus  
  
1 DL_MULTICAST..... ? 1 6096000 b/s 3657600 b/s bestEffort active  
2 initial..... ? 1 5885696 b/s 1000 b/s bestEffort active  
3 little..... ? 1 1000000 b/s 1000 b/s bestEffort active  
4 middle..... ? 1 2500000 b/s 1000 b/s bestEffort active  
5 BE_MAX..... ? 1 50000000 b/s 1000000 b/s bestEffort active
```

- Add row to basestation service class:

```
snmpset -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X Aeronix1%  
-u user -m <mib> <ip> wmanIfBsQOSServiceClassRowStatus.<row  
index> i <row status (4 = create, 6 = destroy>
```

Since there are five entries in the service class table, to create a new table we reference the sixth.

Example:

```
snmpset -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X Aeronix1%  
-u user -m /home/general/SNMP/AERONIX-802.16-MIB.mib.txt  
192.168.100.1 wmanIfBsQOSServiceClassRowStatus.6 i 4
```

Expected output:

```
AERONIX-80216-MIB::wmanIfBsQOSServiceClassRowStatus.6 = INTEGER:  
createAndGo(4)
```

- Fill in row:

```
snmpset -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X Aeronix1%  
-u user -m <mib> <ip> wmanIfBsQoSServiceClassName.<row index> s  
"<custom service name>" wmanIfBsQoSTrafficPriority.<row index> i  
<priority [0-7]> wmanIfBsQoSMaxSustainedRate.<row index> u
```

<value in bits> wmanIfBsQoSMinReservedRate.<row index> u <value in bits> wmanIfBsQoSScSchedulingType.<row index> i <scheduling type [2-5]>

Example:

```
snmpset -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X Aeronix1%
-u user -m /home/general/SNMP/AERONIX-802.16-MIB.mib.txt
192.168.100.1 wmanIfBsQoSServiceClassName.6 s "data"
wmanIfBsQoSTrafficPriority.6 i 1 wmanIfBsQoSMaxSustainedRate.6 u
2500005 wmanIfBsQoSMinReservedRate.6 u 1000005
wmanIfBsQoSScSchedulingType.6 i 2
```

Expected output:

```
AERONIX-80216-MIB::wmanIfBsQoSServiceClassName.6 = STRING: data
AERONIX-80216-MIB::wmanIfBsQoSTrafficPriority.6 = INTEGER: 1
AERONIX-80216-MIB::wmanIfBsQoSMaxSustainedRate.6 = Gauge32:
2500005 b/s
AERONIX-80216-MIB::wmanIfBsQoSMinReservedRate.6 = Gauge32:
1000005 b/s
AERONIX-80216-MIB::wmanIfBsQoSScSchedulingType.6 = INTEGER:
bestEffort(2)
```

- Verify new row added and active:

If new row is added but NOT active, verify all values were set correctly.

```
snmptable -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X
Aeronix1% -u user -m <mib> <ip> wmanIfBsServiceClassTable
```

Example:

```
snmptable -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X
Aeronix1% -u user -m /home/general/SNMP/AERONIX-802.16-
MIB.mib.txt 192.168.100.1 wmanIfBsServiceClassTable
```

Expected output:

SNMP table: AERONIX-80216-MIB::wmanIfBsServiceClassTable

	wmanIfBsQoSProfileIndex		wmanIfBsQoSServiceClassName	bitArray		
	wmanIfBsQoSTrafficPriority	wmanIfBsQoSMaxSustainedRate	wmanIfBsQoSMinReservedRate			
	wmanIfBsQoSScSchedulingType	wmanIfBsQoSServiceClassRowStatus				
1	DL_MULTICAST.....	?	1	6096000 b/s	3657600 b/s	bestEffort active
2	initial.....	?	1	5885696 b/s	1000 b/s	bestEffort active
3	little.....	?	1	100000 b/s	1000 b/s	bestEffort active
4	middle.....	?	1	2500000 b/s	1000 b/s	bestEffort active
5	BE_MAX.....	?	1	50000000 b/s	1000000 b/s	bestEffort active
6	data.....	?	1	2500005 b/s	1000005 b/s	bestEffort active

3.7.2.9. Remove service class:

- Poll service class table (wmanIfBsServiceClassTable):

```
snmptable -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X  
Aeronix1% -u user -m <mib> <ip> <table name>
```

Example:

```
snmptable -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X  
Aeronix1% -u user -m /home/general/SNMP/AERONIX-802.16-  
MIB.mib.txt 192.168.100.1 wmanIfBsServiceClassTable
```

Expected Output:

SNMP table: AERONIX-80216-MIB::wmanIfBsServiceClassTable

wmanIfBsQoSProfileIndex	wmanIfBsQoSServiceClassName	bitArray
wmanIfBsQoSTrafficPriority	wmanIfBsQoSMaxSustainedRate	wmanIfBsQoSMinReservedRate
wmanIfBsQoSScSchedulingType	wmanIfBsQOSServiceClassRowStatus	
1 DL_MULTICAST.....	? 1 6096000 b/s 3657600 b/s bestEffort active	
2 initial.....	? 1 5885696 b/s 1000 b/s bestEffort active	
3 little.....	? 1 1000000 b/s 1000 b/s bestEffort active	
4 middle.....	? 1 2500000 b/s 1000 b/s bestEffort active	
5 BE_MAX.....	? 1 50000000 b/s 1000000 b/s bestEffort active	
6 data.....	? 1 2500005 b/s 1000005 b/s bestEffort active	

- Remove row from basestation service class:

```
snmpset -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X Aeronix1%  
-u user -m <mib> <ip> wmanIfBsQOSServiceClassRowStatus.<row  
index> i <row status (4 = create, 6 = destroy>
```

Example:

```
snmpset -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X Aeronix1%  
-u user -m /home/general/SNMP/AERONIX-802.16-MIB.mib.txt  
192.168.100.1 wmanIfBsQOSServiceClassRowStatus.6 i 6
```

Expected output:

AERONIX-80216-MIB::wmanIfBsQOSServiceClassRowStatus.6 = INTEGER:
destroy(6)

- Verify row deletion:

```
snmptable -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X  
Aeronix1% -u user -m <mib> <ip> <table name>
```

Example:

```
snmptable -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X  
Aeronix1% -u user -m /home/general/SNMP/AERONIX-802.16-  
MIB.mib.txt 192.168.100.1 wmanIfBsServiceClassTable
```

Expected Output:

```
wmanIfBsQoSProfileIndex      wmanIfBsQoSServiceClassName bitArray
wmanIfBsQoSSTrafficPriority  wmanIfBsQoSMaxSustainedRate wmanIfBsQoSMinReservedRate
wmanIfBsQoSScSchedulingType wmanIfBsQoSServiceClassRowStatus
wmanIfBsQoSProfileIndex      wmanIfBsQoSServiceClassName bitArray
wmanIfBsQoSSTrafficPriority  wmanIfBsQoSMaxSustainedRate wmanIfBsQoSMinReservedRate
wmanIfBsQoSScSchedulingType wmanIfBsQoSServiceClassRowStatus
1 DL_MULTICAST..... ? 1 6096000 b/s 3657600 b/s bestEffort active
2 initial..... ? 1 5885696 b/s 1000 b/s bestEffort active
3 little..... ? 1 1000000 b/s 1000 b/s bestEffort active
4 middle..... ? 1 2500000 b/s 1000 b/s bestEffort active
5 BE_MAX..... ? 1 50000000 b/s 1000000 b/s bestEffort active
```

3.7.2.10. Viewing/Adding Subscribers

This is only done on the BS.

- **Viewing Subscriber Table**

```
snmptable -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X
Aeronix1% -u user -m ./AERONIX-802.16-MIB.mib.txt 192.168.100.1
wmanIfBsSsNameTable
```

- **Create new Subscriber Entry**

Assuming we already have two entries we must first create a new row. After running the below command it will create a placeholder entry with Default as the name with a mac address of 00:00:00:00:00:00

```
snmpset -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X Aeronix1%
-u user -m ./AERONIX-802.16-MIB.mib.txt 192.168.100.1
wmanIfBsSsNameRowStatus.3 i 4
```

Then we fill in the MAC address and name separately.

```
snmpset -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X Aeronix1%
-u user -m ./AERONIX-802.16-MIB.mib.txt 192.168.100.1
wmanIfBsSsNameSubscriberName.3 s SS-3
snmpset -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X Aeronix1%
-u user -m ./AERONIX-802.16-MIB.mib.txt 192.168.100.1
wmanIfBsSsNameMACAddress.3 s 112233445566
```

- **Removing a Subscriber Entry**

Remove first entry in table, .1 after wmanIfBsSsNameRowStatus is the row index.

```
snmpset -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X Aeronix1%
-u user -m ./AERONIX-802.16-MIB.mib.txt 192.168.100.1
wmanIfBsSsNameRowStatus.1 i 6
```

3.7.2.11. Add new provisioned SFs

This is only done on the BS.

- Poll provisioned SFs table (wmanIfBsProvisionedSfTable):


```
snmptable -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X  
Aeronix1% -u user -m <mib> <ip> <table name>
```

Example:

```
snmptable -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X  
Aeronix1% -u user -m /home/general/SNMP/AERONIX-802.16-  
MIB.mib.txt 192.168.100.1 wmanIfBsProvisionedSfTable
```

Expected output:

SNMP table: AERONIX-80216-MIB::wmanIfBsProvisionedSfTable

wmanIfBsSfId	wmanIfBsSsProvmacAddress	wmanIfBsSfDirection	wmanIfBsServiceClassName	wmanIfBsSfState	wmanIfBsSfULMulticast	wmanIfBsProvisionedSfRowStatus
4	00:61:65:6E:64:01.	downstream	BE_MAX.....	authorized	off	active
5	00:61:65:6E:64:01.	upstream	BE_MAX...	authorized	off	active
6	00:61:65:6E:64:02.	downstream	BE_MAX...	authorized	off	active
7	00:61:65:6E:64:02.	upstream	BE_MAX...	authorized	off	active

- Add row to provisioned SFs:

```
snmpset -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X Aeronix1%  
-u user -m <mib> <ip> wmanIfBsProvisionedSfRowStatus.<row index>  
i <row status> (4 = create, 6 = destroy)
```

Example:

```
snmpset -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X Aeronix1%  
-u user -m /home/general/SNMP/AERONIX-802.16-MIB.mib.txt  
192.168.100.1 wmanIfBsProvisionedSfRowStatus.5 i 4
```

Expect output:

AERONIX-80216-MIB::wmanIfBsProvisionedSfRowStatus.5 = INTEGER:
createAndGo(4)

- Verify new row created in provisioned SFs table:

```
snmptable -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X  
Aeronix1% -u user -m <mib> <ip> <table name>
```

Example:

```
snmptable -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X  
Aeronix1% -u user -m /home/general/SNMP/AERONIX-802.16-  
MIB.mib.txt 192.168.100.1 wmanIfBsProvisionedSfTable
```

Expected output:

SNMP table: AERONIX-80216-MIB::wmanIfBsProvisionedSfTable

wmanIfBsSfId	wmanIfBsSsProvmacAddress	wmanIfBsSfDirection	wmanIfBsServiceClassName	wmanIfBsSfState	wmanIfBsSfULMulticast	wmanIfBsProvisionedSfRowStatus
4	00:61:65:6E:64:01.	downstream	BE_MAX...	authorized	off	active

5	00:61:65:6E:64:01.	upstream	BE_MAX...	authorized	off	active
6	00:61:65:6E:64:02.	downstream	BE_MAX...	authorized	off	active
7	00:61:65:6E:64:02.	upstream	BE_MAX...	authorized	off	active
8	FF:FF:FF:FF:FF:FF.	downstream	...	255	off	notReady

- Fill in row:

```
snmpset -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X Aeronix1%  
-u user -m <mib> <ip> wmanIfBsSsProvmacAddress.<row index> s <ss  
mac address> wmanIfBsServiceClassName.<row index> s <name of  
service class>
```

Example:

```
snmpset -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X Aeronix1%  
-u user -m /home/general/SNMP/AERONIX-802.16-MIB.mib.txt  
192.168.100.1 wmanIfBsSsProvmacAddress.5 s 0061656E6401  
wmanIfBsServiceClassName.5 s middle
```

Expected output:

```
AERONIX-80216-MIB::wmanIfBsSsProvmacAddress.5 = STRING:  
0061656E6401  
AERONIX-80216-MIB::wmanIfBsServiceClassName.5 = STRING: middle
```

- Verify row has been added to provisioned SFs:

```
snmptable -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X  
Aeronix1% -u user -m <mib> <ip> <table name>
```

Example:

```
snmptable -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X  
Aeronix1% -u user -m /home/general/SNMP/AERONIX-802.16-  
MIB.mib.txt 192.168.100.1 wmanIfBsProvisionedSfTable
```

Expected output:

```
SNMP table: AERONIX-80216-MIB::wmanIfBsProvisionedSfTable
```

	wmanIfBsSfId	wmanIfBsSsProvmacAddress	wmanIfBsSfDirection	wmanIfBsServiceClassName	wmanIfBsSfState	wmanIfBsSfULMulticast	wmanIfBsProvisionedSfRowStatus
4	00:61:65:6E:64:01.	downstream	BE_MAX...	authorized	off	active	
5	00:61:65:6E:64:01.	upstream	BE_MAX...	authorized	off	active	
6	00:61:65:6E:64:02.	downstream	BE_MAX...	authorized	off	active	
7	00:61:65:6E:64:02.	upstream	BE_MAX...	authorized	off	active	
8	00:61:65:6E:64:01.	downstream	middle...	authorized	off	active	
9	00:61:65:6E:64:01.	upstream	middle...	authorized	off	active	

3.7.2.12. Remove provisioned SF:

- Poll provisioned SF table (wmanIfBsProvisionedSfTable):

```
snmptable -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X  
Aeronix1% -u user -m <mib> <ip> <table name>
```

When removing a provisioned SF row, you need only remove the downstream row. The corresponding upstream row will automatically be deleted as well.

Example:

```
snmptable -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X  
Aeronix1% -u user -m /home/general/SNMP/AERONIX-802.16-  
MIB.mib.txt 192.168.100.1 wmanIfBsProvisionedSfTable
```

Expected output:

SNMP table: AERONIX-80216-MIB::wmanIfBsProvisionedSfTable

wmanIfBsSfId	wmanIfBsSsProvmacAddress	wmanIfBsSfDirection	wmanIfBsServiceClassName	wmanIfBsSfState	wmanIfBsSfULMulticast	wmanIfBsProvisionedSfRowStatus
4	00:61:65:6E:64:01.	downstream	BE_MAX...	authorized	off	active
5	00:61:65:6E:64:01.	upstream	BE_MAX...	authorized	off	active
6	00:61:65:6E:64:02.	downstream	BE_MAX...	authorized	off	active
7	00:61:65:6E:64:02.	upstream	BE_MAX...	authorized	off	active
8	00:61:65:6E:64:01.	downstream	middle...	authorized	off	active
9	00:61:65:6E:64:01.	upstream	middle...	authorized	off	active

- Remove provisioned SF row:

```
snmpset -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X Aeronix1%  
-u user -m <mib> <ip> wmanIfBsProvisionedSfRowStatus.<row index>  
i <row status (4 = create, 6 = destroy)>
```

Example:

```
snmpset -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X Aeronix1%  
-u user -m /home/mbersing/projects/nano/nano/mac/SNMP/AERONIX-  
802.16-MIB.mib.txt 192.168.100.1  
wmanIfBsProvisionedSfRowStatus.5 i 6
```

Expected output:

AERONIX-80216-MIB::wmanIfBsProvisionedSfRowStatus.5 = INTEGER:
destroy(6)

- Verify provisioned SF row removed:

```
snmptable -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X  
Aeronix1% -u user -m <mib> <ip> <table name>
```

Example:

```
snmptable -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X  
Aeronix1% -u user -m /home/general/SNMP/AERONIX-802.16-  
MIB.mib.txt 192.168.100.1 wmanIfBsProvisionedSfTable
```

Expected output:

SNMP table: AERONIX-80216-MIB::wmanIfBsProvisionedSfTable

wmanIfBsSfId	wmanIfBsSsProvmacAddress	wmanIfBsSfDirection	wmanIfBsServiceClassName	wmanIfBsSfState	wmanIfBsSfUlmulticast	wmanIfBsProvisionedSfRowStatus
4	00:61:65:6E:64:01.	downstream	BE_MAX...	authorized	off	active
5	00:61:65:6E:64:01.	upstream	BE_MAX...	authorized	off	active
6	00:61:65:6E:64:02.	downstream	BE_MAX...	authorized	off	active
7	00:61:65:6E:64:02.	upstream	BE_MAX...	authorized	off	active

3.7.2.13. Add new downstream burst profile:

- Poll downstream burst profile table (wmanIfBsOfdmDcdBurstProfileTable):

```
snmptable -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X Aeronix1% -u user -m <mib> <ip> <table name>
```

Example:

```
snmptable -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X Aeronix1% -u user -m /home/general/SNMP/AERONIX-802.16-MIB.mib.txt 192.168.100.1 wmanIfBsOfdmDcdBurstProfileTable
```

Expected output:

SNMP table: AERONIX-80216-MIB::wmanIfCmnOfdmDcdBurstProfileTable

wmanIfCmnOfdmDcdBurstProfIndex	wmanIfCmnOfdmDiucValue	wmanIfCmnOfdmDcdFecCodeType	wmanIfCmnOfdmDiucCinrMandatoryExitThresh	wmanIfCmnOfdmDiucCinrMinEntryThresh	wmanIfCmnOfdmDiucFecMandatoryExitThresh	wmanIfCmnOfdmDiucFecMinEntryThresh	wmanIfCmnOfdmAvailableType	wmanIfCmnOfdmDcdBurstProfilerowStatus
1	1	fecBPSK-12	0	7	0	3	2	active
2	2	fecQPSK-12	8	10	15	4	2	active
3	3	fecQPSK-34	9	12	4	1	2	active
4	4	fecQAM-1612	12	16	28	7	2	active
5	5	fecQAM-1634	16	18	8	2	2	active
6	6	fecQAM-6423	20	23	25	6	2	active

- Add row to downstream burst profile:

```
snmpset -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X Aeronix1% -u user -m <mib> <ip> wmanIfCmnOfdmDcdBurstProfilerowStatus.<row index> i <row status (4 = create, 6 = destroy)>
```

Example:

```
snmpset -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X Aeronix1% -u user -m /home/general/SNMP/AERONIX-802.16-MIB.mib.txt 192.168.100.1 wmanIfCmnOfdmDcdBurstProfilerowStatus.7 i 4
```

Expect output:

AERONIX-80216-MIB::wmanIfCmnOfdmDcdBurstProfilerowStatus.7 =
INTEGER: createAndGo(4)

- Verify new row created in provisioned SFs table:

```
snmptable -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X  
Aeronix1% -u user -m <mib> <ip> <table name>
```

Example:

```
snmptable -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X  
Aeronix1% -u user -m /home/general/SNMP/AERONIX-802.16-  
MIB.mib.txt 192.168.100.1 wmanIfBsOfdmDcdBurstProfileTable
```

Expected output:

SNMP table: AERONIX-80216-MIB::wmanIfBsOfdmDcdBurstProfileTable

wmanIfCmnOfdmDcdBurstProfIndex	wmanIfCmnOfdmDiucValue	wmanIfCmnOfdmDcdFecCodeType	wmanIfCmnOfdmDiucCinrMandatoryExitThresh	wmanIfCmnOfdmDiucCinrMinEntryThresh	wmanIfCmnOfdmDiucFecMandatoryExitThresh	wmanIfCmnOfdmDiucFecMinEntryThresh	wmanIfCmnOfdmAvailableType	wmanIfCmnOfdmDcdBurstProfilerowStatus
1	1	fecBPSK-12	0	7	0	3	2	active
2	2	fecQPSK-12	8	10	15	4	2	active
3	3	fecQPSK-34	9	12	4	1	2	active
4	4	fecQAM-1612	12	16	28	7	2	active
5	5	fecQAM-1634	16	18	8	2	2	active
6	6	fecQAM-6423	20	23	25	6	2	active
invalid 0	0		0	0	0		notReady	

- Fill in row:

```
snmpset -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X Aeronix1%  
-u user -m <mib> <ip> wmanIfCmnOfdmDcdFecCodeType.<row index> i  
<fec code [0-9]> wmanIfCmnOfdmDiucCinrMandatoryExitThresh.<row  
index> i <cinr exit threshold>  
wmanIfCmnOfdmDiucFecMandatoryExitThresh.<row index> i <fec exit  
threshold> wmanIfCmnOf  
dmAvailableType.<row index> i <enable=2, disable=3>  
wmanIfCmnOfdmDiucCinrMinEntryThresh.<row index> i <cinr entry  
threshold> wmanIfCmnOfdmDiucFecMinEntryThresh.<row index> i <fec  
entry threshold>
```

Example:

```
snmpset -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X Aeronix1%  
-u user -m /home/general/SNMP/AERONIX-802.16-MIB.mib.txt  
192.168.100.1 wmanIfCmnOfdmDcdFecCodeType.7 i 6  
wmanIfCmnOfdmDiucCinrMandatoryExitThresh.7 i 8  
wmanIfCmnOfdmDiucFecMandatoryExitThresh.7 i 10 wmanIfCmnOf  
dmAvailableType.7 i 2 wmanIfCmnOfdmDiucCinrMinEntryThresh.7 i 0  
wmanIfCmnOfdmDiucFecMinEntryThresh.7 i 9
```

Expected output:

AERONIX-80216-MIB::wmanIfCmnOfdmDcdFecCodeType.7 = INTEGER:
fecQAM-6434(6)

```
AERONIX-80216-MIB::wmanIfCmnOfdmDiucCinrMandatoryExitThresh.7 =  
INTEGER: 8  
AERONIX-80216-MIB::wmanIfCmnOfdmDiucFecMandatoryExitThresh.7 =  
INTEGER: 10  
AERONIX-80216-MIB::wmanIfCmnOfdmAvailableType.7 = INTEGER: 2  
AERONIX-80216-MIB::wmanIfCmnOfdmDiucCinrMinEntryThresh.7 =  
INTEGER: 0  
AERONIX-80216-MIB::wmanIfCmnOfdmDiucFecMinEntryThresh.7 =  
INTEGER: 9
```

- Verify row has been added to downstream burst profile:

```
snmptable -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X  
Aeronix1% -u user -m <mib> <ip> <table name>
```

Example:

```
snmptable -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X  
Aeronix1% -u user -m /home/general/SNMP/AERONIX-802.16-  
MIB.mib.txt 192.168.100.1 wmanIfBsOfdmDcdBurstProfileTable
```

Expected output:

SNMP table: AERONIX-80216-MIB::wmanIfBsOfdmDcdBurstProfileTable

	wmanIfCmnOfdmDcdBurstProfIndex	wmanIfCmnOfdmDiucValue	wmanIfCmnOfdmDcdFecCodeType	wmanIfCmnOfdmDiucCinrMandatoryExitThresh	wmanIfCmnOfdmDiucCinrMinEntryThresh	wmanIfCmnOfdmDiucFecMandatoryExitThresh	wmanIfCmnOfdmDiucFecMinEntryThresh	wmanIfCmnOfdmAvailableType	wmanIfCmnOfdmDcdBurstProfilerowStatus
1	1	fecBPSK-12	0	7	0	3	2		active
2	2	fecQPSK-12	8	10	15	4	2		active
3	3	fecQPSK-34	9	12	4	1	2		active
4	4	fecQAM-1612	12	16	28	7	2		active
5	5	fecQAM-1634	16	18	8	2	2		active
6	6	fecQAM-6423	20	23	25	6	2		active
7	7	fecQAM-6434	21	24	15	0	2		active

3.7.2.14. Remove downstream burst profile:

- Poll downstream burst profile table (wmanIfBsOfdmDcdBurstProfileTable):

```
snmptable -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X  
Aeronix1% -u user -m <mib> <ip> <table name>
```

Example:

```
snmptable -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X  
Aeronix1% -u user -m /home/general/SNMP/AERONIX-802.16-  
MIB.mib.txt 192.168.100.1 wmanIfBsOfdmDcdBurstProfileTable
```

Expected output:

SNMP table: AERONIX-80216-MIB::wmanIfBsOfdmDcdBurstProfileTable

```
wmanIfCmnOfdmDcdBurstProfIndex wmanIfCmnOfdmDiucValue wmanIfCmnOfdmDcdFecCodeType
wmanIfCmnOfdmDiucCinrMandatoryExitThresh wmanIfCmnOfdmDiucCinrMinEntryThresh
wmanIfCmnOfdmDiucFecMandatoryExitThresh wmanIfCmnOfdmDiucFecMinEntryThresh
wmanIfCmnOfdmAvailableType wmanIfCmnOfdmDcdBurstProfilerowStatus
1      1      fecBPSK-12      0      7      0      3      2      active
2      2      fecQPSK-12      8      10     15     4      2      active
3      3      fecQPSK-34      9      12     4      1      2      active
4      4      fecQAM-1612     12     16     28     7      2      active
5      5      fecQAM-1634     16     18     8      2      2      active
6      6      fecQAM-6423     20     23     25     6      2      active
7      7      fecQAM-6434     21     24     15     0      2      active
```

- Remove downstream burst profile row:

```
snmpset -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X Aeronix1%
-u user -m <mib> <ip> wmanIfCmnOfdmDcdBurstProfilerowStatus.<row
index> i <row status (4 = create, 6 = destroy>
```

Example:

```
snmpset -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X Aeronix1%
-u user -m /home/general/SNMP/AERONIX-802.16-MIB.mib.txt
192.168.100.1 wmanIfCmnOfdmDcdBurstProfilerowStatus.7 i 6
```

Expected output:

```
AERONIX-80216-MIB::wmanIfCmnOfdmDcdBurstProfilerowStatus.7 =
INTEGER: destroy(6)
```

- Verify downstream burst profile row removed:

```
snmptable -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X
Aeronix1% -u user -m <mib> <ip> <table name>
```

Example:

```
snmptable -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X
Aeronix1% -u user -m /home/general/SNMP/AERONIX-802.16-
MIB.mib.txt 192.168.100.1 wmanIfBsOfdmDcdBurstProfileTable
```

Expected output:

```
SNMP table: AERONIX-80216-MIB::wmanIfBsOfdmDcdBurstProfileTable
```

```
wmanIfCmnOfdmDcdBurstProfIndex wmanIfCmnOfdmDiucValue wmanIfCmnOfdmDcdFecCodeType
wmanIfCmnOfdmDiucCinrMandatoryExitThresh wmanIfCmnOfdmDiucCinrMinEntryThresh
wmanIfCmnOfdmDiucFecMandatoryExitThresh wmanIfCmnOfdmDiucFecMinEntryThresh
wmanIfCmnOfdmAvailableType wmanIfCmnOfdmDcdBurstProfilerowStatus
1      1      fecBPSK-12      0      7      0      3      2      active
2      2      fecQPSK-12      8      10     15     4      2      active
3      3      fecQPSK-34      9      12     4      1      2      active
4      4      fecQAM-1612     12     16     28     7      2      active
5      5      fecQAM-1634     16     18     8      2      2      active
6      6      fecQAM-6423     20     23     25     6      2      active
```

3.7.2.15. Viewing/Creating/Deleting Classifiers

This is only done on the BS.

- **Viewing classifier rule table**

```
snmptable -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X  
Aeronix1% -u user -m ./AERONIX-802.16-MIB.mib.txt 192.168.100.1  
wmanIfBsClassifierRuleTable
```

- **Creating classifier MAC rule entry**

1) Verify SNMP is classifier mod is set to mac, if not set classifierMacAddrMode.1 to 1.
classifierMacAddrMode :
0 = IP Mode
1 = MAC Mode

```
snmpget -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X Aeronix1%  
-u user -m ./AERONIX-802.16-MIB.mib.txt 192.168.100.1  
classifierMacAddrMode.1
```

2) Create entry row
Assuming an empty classifier table first index will start at 1.

```
snmpset -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X Aeronix1%  
-u user -m ./AERONIX-802.16-MIB.mib.txt 192.168.100.1  
wmanIfBsClassifierRuleRowStatus.1 i 4
```

3) Fill in new entry row

```
snmpset -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X Aeronix1%  
-u user -m ./AERONIX-802.16-MIB.mib.txt 192.168.100.1  
wmanIfBsSfIndex.1 i 4  
wmanIfBsClassifierRuleDestMacAddr.1 s <xxxxxxxxxxxx>  
wmanIfBsClassifierRuleSourceMacMask.1 s <xxxxxxxxxxxx>  
wmanIfBsClassifierRuleSourceMacAddr.1 s <xxxxxxxxxxxx>  
wmanIfBsClassifierRuleDestMacMask.1 s <xxxxxxxxxxxx>
```

4) Create entry row

```
snmpset -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X Aeronix1%  
-u user -m ./AERONIX-802.16-MIB.mib.txt 192.168.100.1  
wmanIfBsClassifierRuleRowStatus.2 i 4
```

5) Fill in new entry row

```
snmpset -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X Aeronix1%  
-u user -m ./AERONIX-802.16-MIB.mib.txt 192.168.100.1  
wmanIfBsSfIndex.2 i 5  
wmanIfBsClassifierRuleDestMacAddr.2 s <xxxxxxxxxxxx>  
wmanIfBsClassifierRuleSourceMacMask.2 s <xxxxxxxxxxxx>  
wmanIfBsClassifierRuleSourceMacAddr.2 s <xxxxxxxxxxxx>  
wmanIfBsClassifierRuleDestMacMask.2 s <xxxxxxxxxxxx>
```


- **Creating classifier IP rule entry**

1) Verify SNMP is classifier mod is set to IP, if not set classifierMacAddrMode.1 to 0
snmpget -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X Aeronix1%
-u user -m ./AERONIX-802.16-MIB.mib.txt 192.168.100.1
classifierMacAddrMode.1
classifierMacAddrMode:
0 = IP Mode
1 = MAC Mode

2) Create entry row

Assuming an empty classifier table first index will start at 1.

```
snmpset -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X Aeronix1%  
-u user -m ./AERONIX-802.16-MIB.mib.txt 192.168.100.1  
wmanIfBsClassifierRuleRowStatus.1 i 4
```

3) Fill in new entry row

```
snmpset -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X Aeronix1%  
-u user -m ./AERONIX-802.16-MIB.mib.txt 192.168.100.1  
wmanIfBsSfIndex.1 i 4 wmanIfBsClassifierRuleIpSourceAddr.1 s  
192.168.100.2 wmanIfBsClassifierRuleIpSourceMask.1 s 255.255.0.0  
wmanIfBsClassifierRuleIpDestAddr.1 s 192.168.1.2  
wmanIfBsClassifierRuleIpDestMask.1 s 255.255.0.0
```

4) Create entry row

```
snmpset -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X Aeronix1%  
-u user -m ./AERONIX-802.16-MIB.mib.txt 192.168.100.1  
wmanIfBsClassifierRuleRowStatus.2 i 4
```

5) Fill in new entry row

```
snmpset -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X Aeronix1%  
-u user -m ./AERONIX-802.16-MIB.mib.txt 192.168.100.1  
wmanIfBsSfIndex.2 i 5 wmanIfBsClassifierRuleIpSourceAddr.2 s  
192.168.1.2 wmanIfBsClassifierRuleIpSourceMask.2 s 255.255.0.0  
wmanIfBsClassifierRuleIpDestAddr.2 s 192.168.100.2  
wmanIfBsClassifierRuleIpDestMask.2 s 255.255.0.0
```

- **Removing classifier rule entry**

Remove first entry in table, .1 after wmanIfBsClassifierRuleRowStatus is the row index

```
snmpset -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X Aeronix1%  
-u user -m ./AERONIX-802.16-MIB.mib.txt 192.168.100.1  
wmanIfBsClassifierRuleRowStatus.1 i 6
```

3.7.2.16. SNMP configure Serial Flow

Serial Flow Types enumerations (unsigned) :

Serial B to Serial B = 0

Serial B To Ethernet Rx Only = 1
Serial B To Ethernet Tx Only = 2
Serial B To Ethernet Both Rx and Tx = 3

Serial Baud Rates (unsigned) : 4800, 9600, 19200, 38400, 57600, 115200

Raw Mode enumeration (integer):
Raw Mode = 1
Normal = 0

```
snmpset -v 3 -l AUTHPRIV -a SHA -A Aeronix1% -x DES -X Aeronix1%  
-u user -m $PWD/AERONIX-802.16-MIB.mib.txt 192.168.8.1  
serialDirection.1 u 0 serialBaudRate.1 u 4800  
enaSerialTransfer.1 i 1 serialTxPort.1 u 3000 serialRxPort.1 u  
3001 serialTxIP.1 s "192.168.2.10" serialRawMode.1 i 0
```

Response:

```
AERONIX-80216-MIB::serialDirection.1 = Gauge32: 0  
AERONIX-80216-MIB::serialBaudRate.1 = Gauge32: 4800  
AERONIX-80216-MIB::enaSerialTransfer.1 = INTEGER: enable(1)  
AERONIX-80216-MIB::serialTxPort.1 = Gauge32: 3000  
AERONIX-80216-MIB::serialRxPort.1 = Gauge32: 3001  
AERONIX-80216-MIB::serialTxIP.1 = STRING: 192.168.2.10  
AERONIX-80216-MIB::serialRawMode.1 = INTEGER: 0
```

3.7.3. SNMP Unsupported configurations

3.7.3.1. BERT and CW test

SNMP does not allow the user to run BERT and CW test.

4. Determining NANO Radio configuration

If the user is not aware of the Radio IP or the radio mode, below are some methods by which they can learn the current configuration the NANO radio.

4.1. Two ways to determine radio IP address

4.1.1. Use Console

- 1) Attach USB to Serial to a Laptop and use Console to get IP address
- 2) Connect to Serial A port with terminal emulator. (Baud = 115200, 8-N-1 no flow control)
- 3) Login by typing “root”
- 4) Enter password “1234”.

- 5) Enter “ifconfig”
- 6) Take note of the “mybridge” interface IP address and netmask

4.1.2. Use radio’s default IP address

The user can always access the radio over its Ethernet alias IP address of 169.254.1.1. This IP is consistent so if the user needs to access the GUI or SNMP.

- 1) Configure laptop/computer with an IP address on the same subnet as radio default IP address for example:
 - a. laptop IP : 169.254.1.10
 - b. laptop mask : 255.255.255.0
- 2) Connect radio’s Ethernet to laptop/computer
- 3) Bring up a web browser (IE or firefox)
- 4) Type in radio’s default IP address at web browser
 - a. 169.254.1.1
- 5) The Status page should be displayed of the radio.
- 6) Multiple ways to view IP address
 - a. Version page
 - i. Go to the Version page of the webgui
 - ii. The IP address will be displayed under network Addresses
 - b. Maintenance page
 - i. Go to Maintenance page
 - ii. Click on Debug button
 - iii. Go to Proc Interface section
 - iv. From scroll down menu select “ifconfig”
 - v. Hit Display Button
 - vi. The IP address and mask will be listed under the “mybridge” interface
 - c. Admin Page
 - i. Go to the Admin Page
 - ii. Look at the left side of the Generate Bridging Start script section
 - iii. This is the current radio IP address, netmask, mode and ID

5. Change Radio IP address via webgui

The start script controls the IP address, IP masks, user interface (webgui or SNMP), and which mode the radio will boot in (BS or SS).

- 1) Bring up radios webgui by typing in current radio’s IP address on a Web Browser
- 2) Go to Admin page
- 3) Scroll down to the Generate Bridging Script
- 4) Select Base Station or Subscriber radio button
- 5) Enter Radio ID if desired
- 6) Enter new IPv4 IP address
- 7) Enter new IPv4 netmask
- 8) Click Generate Script button

- 9) Once the 'Generate Script' button is selected, the old start script will be overwritten with the new start script changes. Once a reboot or power cycle occurs the new changes will take effect.

6. Adding Subscriber example using webgui

This example shows the method for adding a third subscriber to the base station configuration. This example assumes that the radios are configured in bridging mode with IP classifiers and no forwarding classifiers configured. It also assumes the use of preexisting service classes. The picture below shows the physical configuration.




Figure 6-1 Example Adding Subscriber Layout

Adding a subscriber to the Station Names table:

1. Browse to the Admin page of the base station.
2. Click on the ADD ENTRY button in the Station Names section.
3. Add a name for the subscriber and the appropriate MAC address for subscriber number 3 which is 00-61-65-6E-64-03.
 - o Note: The MAC Address needed on the Admin for a Subscriber is the Aeronix MAC address for that subscriber (00-61-65-64-XX where XX is the Subscriber number).
4. Click on the ADD button to the right of the subscriber entry.
5. The subscriber appears in the station names table as show below.

1. Browse to the Network Config page of the base station.
2. Click on the ADD ENTRY button in the Provisioned SFs section.
3. Select the subscriber name for subscriber 3 from the pull down menu.
4. Type the downstream SF Id to be used in the box.
5. Select the service class for the service flow from the pull down menu.
6. Click the ADD button to the right of the service flow entry.
7. The service flow entries appear in the provisioned service flow table as shown below.

AERONIX

uEDL 802.16 Tactical Radio

Base Station
Non-Bridging Mode

Status

Admin

Network Config

Profile Config

Radio Control

Save Settings

Version

Maintenance

Video

Contact

Service Classes

Index	Name	Schedule Type	Max Rate	Min Rate	Priority
1	BE_MULTICAST	Best Effort	6096 Kbps	3657 Kbps	1
2	initial	Best Effort	5885 Kbps	1 Kbps	1
3	little	Best Effort	100 Kbps	1 Kbps	1
4	middle	Best Effort	2500 Kbps	1 Kbps	1
5	BE_MAX	Best Effort	50000 Kbps	1000 Kbps	1

ADD ENTRY
MODIFY ENTRY ...
REMOVE ENTRY ...
CANCEL

Provisioned SFs

Subscriber Name	Downstream SF Id	Upstream SF Id	Service Class	
SS-1	4	5	BE_MAX	
SS-2	6	7	BE_MAX	
SS-3	8		BE_MAX	ADD

ADD ENTRY
MODIFY ENTRY ...
REMOVE ENTRY ...
CANCEL

Aeronix Proprietary
109

At this point the subscriber should register with the base station if it is powered on, on the same channel (frequency), has the same TRANSEC state and key, Tx/Rx is on and has the same channelization.

Add the classifiers for the new service flows so that data can pass to and from the subscriber:

1. Browse to the Network Config page of the base station.
2. Click on the Auto Populate button in the Class Rules section.
3. Provide the proper Station IP and Station Mask for each entry in the table.
 - a. Station IP BS – 192.168.100.1 Station Mask – 255.255.255.0
 - b. Station IP SS1 – 192.168.1.1 Station Mask – 255.255.255.0
 - c. Station IP SS2 – 192.168.2.1 Station Mask – 255.255.255.0
 - d. Station IP SS3 – 192.168.3.1 Station Mask – 255.255.255.0
4. Click the Generate Classifiers button at the bottom of the class rules table.

Base Station
Bridging Mode
(Debug GUI)

Status

Admin

Network Config

Profile Config

Radio Control

Save Settings

Version

Maintenance

Video

Contact

Service Classes

Index	Name	Schedule Type	Max Rate	Min Rate	Priority
1	DL_MULTICAST	Best Effort	6096 Kbps	3657 Kbps	1
2	initial	Best Effort	5885 Kbps	1 Kbps	1
3	little	Best Effort	100 Kbps	1 Kbps	1
4	middle	Best Effort	2500 Kbps	1 Kbps	1
5	BE_MAX	Best Effort	50000 Kbps	1000 Kbps	1
6	ExpRealTime	Real-Time	5000 Kbps	600 Kbps	0

ADD ENTRY MODIFY ENTRY ... REMOVE ENTRY ... CANCEL

Provisioned SFs

Subscriber Name	Downstream SF Id	Upstream SF Id	Service Class	UL Multicast Select
SS-1	4	5	BE_MAX	
SS-2	6	7	BE_MAX	
SS-3	8	9	BE_MAX	

ADD ENTRY MODIFY ENTRY ... REMOVE ENTRY ... CANCEL

Class Rules

Address Mode: IP

Forwarders Enabled: NO

Non-Forwarder Count: 16

Forwarder Count: 0

 Current Page: 1 of 1

Index	Station	SF Indices	Station IP	Station Mask
0	BS	---	192.168.100.1	255.255.255.0
1	SS-1	4,5	192.168.1.1	255.255.255.0
2	SS-2	6,7	192.168.2.1	255.255.255.0
3	SS-3	8,9	192.168.3.1	255.255.255.0

☐ Enable Forwarders BS0 SS0

ADD ENTRY MODIFY ENTRY ... REMOVE ENTRY ... CANCEL

Figure 6-4 Example Adding a Subscriber Class Rules

- Acknowledge the pop-up that the classifier regeneration takes some time.
- The classifiers appear in the class rule table upon completion of the auto populate as shown below. These class rules and masks allow for multiple peripherals to connect in a unit's network and be able to pass data without modifying the class rule configuration.
- Click on the Save Settings button and confirm the selection to save the subscriber 3 information to the database.

AERONIX nEDL 802.16 Tactical Radio

Base Station
Non Bridging Mode

Service Classes

Index	Name	Schedule Type	Max Rate	Min Rate	Priority
1	BE_MULTICAST	Best Effort	6096 Kbps	3657 Kbps	1
2	initial	Best Effort	5885 Kbps	1 Kbps	1
3	little	Best Effort	100 Kbps	1 Kbps	1
4	middle	Best Effort	2500 Kbps	1 Kbps	1
5	BE_MAX	Best Effort	50000 Kbps	1000 Kbps	1

ADD ENTRY MODIFY ENTRY... REMOVE ENTRY... CANCEL

Provisioned SFs

Subscriber Name	Downstream SF Id	Upstream SF Id	Service Class
SS-1	4	5	BE_MAX
SS-2	6	7	BE_MAX
SS-3	8	9	BE_MAX

ADD ENTRY MODIFY ENTRY... REMOVE ENTRY... CANCEL

Class Rules

Address Mode: ☒ IP ☐ MAC

Current Page: 1 of 1

Index	SF Fwd	Src IP	Src Mask	Dest IP	Dest Mask
0	4 N	192.168.100.0	255.255.255.0	192.168.10.1	255.255.255.0
1	6 N	192.168.100.0	255.255.255.0	192.168.20.0	255.255.255.0
2	7 N	192.168.20.0	255.255.255.0	192.168.100.0	255.255.255.0
3	8 N	192.168.100.0	255.255.255.0	192.168.30.0	255.255.255.0
4	9 N	192.168.30.0	255.255.255.0	192.168.100.0	255.255.255.0
5	5 N	192.168.10.1	255.255.255.0	192.168.100.0	255.255.255.0

ADD ENTRY MODIFY ENTRY... REMOVE ENTRY... CANCEL

Figure 6-5 Example Adding a Subscriber Result

6.1. Configuring Multiple Service Flows

Multiple Service Flows can be assigned to a single Subscriber. This allows data from different IP address or MAC Address flowing from one radio to be assigned different Service Classes, which will give them different priorities. To configure a Subscriber to have Multiple Service flows, user must assign two different sets of Service Flows for the Subscriber. Then configure the classifiers using the different Service Flows. The user must disable the ARP Table feature on the Network Config screen.

If the user wanted to differentiate the data coming from different IP address from SS1, then multiple service flows can be used to prioritize the data. For example, the data coming from IP 192.168.1.10 to be treated as Real Time and data from IP 192.168.1.15 to be treated as Best Effort, then the configuration would look similar to below.

The user must setup and enable classifiers. The user cannot rely on the ARP Table feature to discover the correct Service flow to use for incoming IP traffic with different priorities.




Figure 6-6 Example Multiple SF Layout

1. On the Base Station configure the Provisioned SF for the second service flow for SS1 (192.168.1.x network), using a Real Time Service Class (ExpRealTime).
2. We also selected the Real Time Service Flow (10,11) to be our UL Multicast Select, which means any multicast data will use this service flow and priority to transfer data.

Service Classes

Index	Name	Schedule Type	Max Rate	Min Rate	Priority
1	DL_MULTICAST	Best Effort	6096 Kbps	3657 Kbps	1
2	initial	Best Effort	5885 Kbps	1 Kbps	1
3	little	Best Effort	100 Kbps	1 Kbps	1
4	middle	Best Effort	2500 Kbps	1 Kbps	1
5	BE_MAX	Best Effort	50000 Kbps	1000 Kbps	1
6	ExpRealTime	Real-Time	5000 Kbps	600 Kbps	0

ADD ENTRY MODIFY ENTRY ... REMOVE ENTRY ... CANCEL

Provisioned SFs

Subscriber Name	Downstream SF Id	Upstream SF Id	Service Class	UL Multicast Select	
SS-1	4	5	BE_MAX		
SS-2	6	7	BE_MAX		
SS-3	8	9	BE_MAX		
SS-1	10	11	ExpRealTime	☒	SAVE

ADD ENTRY MODIFY ENTRY ... REMOVE ENTRY ... CANCEL

Figure 6-7 Example Multiple SF Add SF

3. On the BS configure the classifiers for the new Service Flows, from our previous example our class rules for SS1 were masked off, the user will have to change this since the IPs are on the same subnet that we want to differentiate.
4. Use Auto Populate to redo the class rules table, SS1 IP address can no longer use the subnet masks.

Title: Aeronix Data Links – EDL Nano Products User Guide

Index	Name	Schedule Type	Max Rate	Min Rate	Priority
1	DL_MULTICAST	Best Effort	6096 Kbps	3657 Kbps	1
2	initial	Best Effort	5885 Kbps	1 Kbps	1
3	little	Best Effort	100 Kbps	1 Kbps	1
4	middle	Best Effort	2500 Kbps	1 Kbps	1
5	BE_MAX	Best Effort	50000 Kbps	1000 Kbps	1
6	ExpRealTime	Real-Time	5000 Kbps	600 Kbps	0

ADD ENTRY
MODIFY ENTRY ...
REMOVE ENTRY ...
CANCEL

Provisioned SFs

Subscriber Name	Downstream SF Id	Upstream SF Id	Service Class	UL Multicast Select
SS-1	4	5	BE_MAX	
SS-2	6	7	BE_MAX	
SS-3	8	9	BE_MAX	
SS-1	10	11	ExpRealTime	

ADD ENTRY
MODIFY ENTRY ...
REMOVE ENTRY ...
CANCEL

Class Rules

Address Mode: IP IP MAC Auto Populate

Forwarders Enabled: NO

Non-Forwarder Count: 6

Forwarder Count: 0

Prev Page
Current Page: 1 of 1
Next Page

Index	Station	SF Indices	Station IP	Station Mask
0	BS	---	192.168.100.1	255.255.255.0
1	SS-1	4,5	192.168.1.1	255.255.255.255
2	SS-1	4,5	192.168.1.10	255.255.255.255
3	SS-1	10,11	192.168.1.15	255.255.255.255
4	SS-2	6,7	192.168.2.0	255.255.255.0
5	SS-3	8,9	192.168.3.0	255.255.255.0

☐ Enable Forwarders
BS 0 SS 1
Extra Count
Generate Classifiers

ADD ENTRY
MODIFY ENTRY ...
REMOVE ENTRY ...
CANCEL

Figure 6-8 Example Multiple SF Add Class Rules

Table 6-1. Adding Multiple Service Flow Class Rule		
	Field/Control	Description
1	Radio Class Rule	This Class Rule is needed if the user wants to log into the SS1 Aeronix Webgui from any of the BS

Table 6-1. Adding Multiple Service Flow Class Rule		
	Field/Control	Description
		peripherals. Need a rule for IP packets flowing between 192.168.100.x <-> 192.168.1.1
2	Best Effort Class Rule	This Class Rule specifies that data with IP address 192.168.1.10 will be classified as Best Effort and transferred based on that priority.
3	Real Time Class Rule	This Class Rule specifies that data with IP address 192.168.1.15 will be classified as Best Effort and transferred based on that priority.

5. Below is the Class Rules after Clicking on the “Generate Classifiers” button.

Title: Aeronix Data Links – EDL Nano Products User Guide

Index	Name	Schedule Type	Max Rate	Min Rate	Priority
1	DL_MULTICAST	Best Effort	6096 Kbps	3657 Kbps	1
2	initial	Best Effort	5885 Kbps	1 Kbps	1
3	little	Best Effort	100 Kbps	1 Kbps	1
4	middle	Best Effort	2500 Kbps	1 Kbps	1
5	BE_MAX	Best Effort	50000 Kbps	1000 Kbps	1
6	ExpRealTime	Real-Time	5000 Kbps	600 Kbps	0

ADD ENTRY
MODIFY ENTRY ...
REMOVE ENTRY ...
CANCEL

Provisioned SFs

Subscriber Name	Downstream SF Id	Upstream SF Id	Service Class	UL Multicast Select
SS-1	4	5	BE_MAX	
SS-2	6	7	BE_MAX	
SS-3	8	9	BE_MAX	
SS-1	10	11	ExpRealTime	X

ADD ENTRY
MODIFY ENTRY ...
REMOVE ENTRY ...
CANCEL

Class Rules

Address Mode: IP MAC Auto Populate

Forwarders Enabled: NO

Non-Forwarder Count: 10

Forwarder Count: 0

Prev Page
Current Page: 1 of 1
Next Page

Index	SF	Src IP	Src Mask	Dest IP	Dest Mask
0	4	192.168.100.1	255.255.255.0	192.168.1.1	255.255.255.255
1	5	192.168.1.1	255.255.255.255	192.168.100.1	255.255.255.0
2	4	192.168.100.1	255.255.255.0	192.168.1.10	255.255.255.255
3	5	192.168.1.10	255.255.255.255	192.168.100.1	255.255.255.0
4	10	192.168.100.1	255.255.255.0	192.168.1.15	255.255.255.255
5	11	192.168.1.15	255.255.255.255	192.168.100.1	255.255.255.0
6	6	192.168.100.1	255.255.255.0	192.168.2.0	255.255.255.0
7	7	192.168.2.0	255.255.255.0	192.168.100.1	255.255.255.0
8	8	192.168.100.1	255.255.255.0	192.168.3.0	255.255.255.0
9	9	192.168.3.0	255.255.255.0	192.168.100.1	255.255.255.0

ADD ENTRY
MODIFY ENTRY ...
REMOVE ENTRY ...
CANCEL

Figure 6-9 Example Multiple SF Result

6. Below are screen shots of how the multiple Service Flows are displayed on the BS (Figure 6-10 Example Multiple SF BS Status Page) Status page and the SS (**Error! Reference source not found.**) Status page.




Figure 6-10 Example Multiple SF BS Status Page




Figure 6-11 SS Example Multiple SF SS Status Page

7. Aeronix Software Features

7.1. NANO output power

7.1.1. View NANO output power calibration

To view NANO transmit output power use the webgui to navigate to the Maintenance Page, then click on the “Debug” Button on the Maintenance Page.

1) Go to Maintenance page, Select Debug button

The screenshot shows the Aeronix 802.16 Tactical Radio web interface. The left sidebar contains a menu with the following items: Status, Admin, Network Config, Profile Config, Radio Control, Save Settings, Version, Maintenance (highlighted), Video, and Contact. The main content area displays various system status sections:

- More Options:** A list of buttons including Reboot, Use Default DB, Registered SSs..., Rx/Tx Loss..., Station Tests..., and Debug... (highlighted with an arrow).
- Tx/Rx Over the Air Status:** A table showing statistics for Rx Frames, Invalid Frames, CRCs Rx, Reset Rx, Tx Frames, and Tx Drop.
- Board Details:** A table showing CPU Temperature (46 C 114.8 F) and RF Temperature (29 C 84.2 F).
- Ethernet Network Status:** A table showing network statistics for Rx and Tx, including Packets, Errors, Dropped, Overruns, Frames, and Carrier.
- Channel Status:** A table showing channel statistics for Station SS-1, including CINR, RSSI, Current Mod Type, Freq Offset, FEC, Reed-Solomon, Time of Arrive Difference, and CP Offset.
- Alarm Interrupts:** A table showing Temperature Protect status (0).

2) In the Proc Interface Section, use drop down menu to select “powerSettings” for GMSK radios. For OFDM radios select “phyEeprom”.

The screenshot shows the Aeronix 802.16 Tactical Radio web interface in Subscriber Bridging Mode. The left sidebar contains a menu with the following items: Status, Admin, Network Config, Profile Config, Radio Control, Save Settings, Version, Maintenance (highlighted), Video, and Contact. The main content area displays the following sections:

- PCI Tests:** A table with columns Offset, Value, and Status. It includes Read and Write buttons.
- Proc Interface:** A section with a Current Proc dropdown menu (set to None), a Proc List dropdown menu (set to None), and a Display button (highlighted with an arrow). Below these are Auto Refresh: OFF and Auto Refresh: On/Off buttons.

3) Click Display and the calibration table will be displayed.

7.1.1.1. OFDM Calibration tables

The OFDM NANO is calibrated to have two power schemes, High Power and High Data. The High power is calibrated to the highest power the radio achieve while maintaining an EVM that will satisfy QAM16 $\frac{3}{4}$ modulation. High Data is calibrated to a power that will maintain a modulation of QAM64 $\frac{3}{4}$. Each power schemes calibrates the power based on the output power of the OFDM preambles.

Title: Aeronix Data Links – EDL Nano Products User Guide




Figure 7-1 802.16 phyEeprom interface

7.1.1.2. GMSK Calibration tables

GMSK transmit power is calibrated to a High power and a Low power . The High power calibration is a target preamble output power 35 dBm. The GMSK Low power has a target preamble output power of 33 dBm.




Figure 7-3 GMSK powerSettings interface

Table 7-1. Transmit Calibration interface		
	Field/Control	Description
1	High Data – OFDM Low Power - GMSK	The transmit calibration results for the listed frequencies for High Data if radio is OFDM and Low Power if radio is GMSK
2	High Power – OFDM High Power - GMSK	The transmit calibration results for the listed frequencies for High Power.
3	Current Transmitter setting	The radio will select the table entry whose frequency is closest to the user configured frequency.

7.2. ARP Table feature

The ARP Table feature does not require the user to enter classifiers for IP traffic to flow through the Aeronix radio network. The Aeronix ARP software relies on the radio and peripherals connected to the radios, to send out IP address resolution protocol (ARP) requests when the IP traffic starts. From the ARP request and replies the Aeronix software deduces the path for each IP source and destination. If for some reason the network surrounding the radios do not send out ARPs, for instance they may have static ARPs configured, then the user will have to create Classifier Rules for their IP traffic to flow through the Aeronix network.

If the ARP Forwarding feature is enabled, then the ARP table allows Subscribers to pass data between each other. This feature is similar to the Classifier Forwarders, where all Subscriber data flows to the BS and the BS will determine if the data is destined for the BS or to be forwarded to another Subscriber.

Since the ARP feature relies on ARPs, IPv6 is not compatible with this feature, so user will have to use the Classifier Rules for IPv6 traffic.

7.2.1. Enable Aeronix ARP feature

The ARP feature has to be enabled on both the Base station and the Subscribers.

1. Browse to the Network Config page
2. Click on the ARP Table Status Enable button

The screenshot shows the Aeronix 802.16 Tactical Radio web interface. On the left is a sidebar with navigation buttons: Status, Admin, Network Config (highlighted), Profile Config, Radio Control, Save Settings, Version, Maintenance, Video, and Contact. The main content area is titled '802.16 Tactical Radio' and contains two sections: 'Network Options' and 'Class Rules'.

Network Options

Classifiers Status: ENABLED
ARP Table Status: ENABLED

Classifiers Status:
ARP Table Status:

Class Rules

Forwards Enabled: NO
Non-Forwarder Count: 1
Forwarder Count: 0

Index	SF	Src MAC	Src Mask	Dest MAC	Dest Mask
0	7	00-00-00-00-00-00	00-00-00-00-00-00	00-00-00-00-00-00	00-00-00-00-00-00

Note: If the Classifier Status and ARP Table Status are both enabled, the software will search the ARP table first for a match, if no match is found then the classifier table will be searched.

7.3. Aeronix Serial Flow Control Feature

The Aeronix serial flow control feature allows serial data to pass through the NANO's Platform RS-232 interface (See Table 2-8. J1: Main IF Pin Definitions). This section will go into further detail on how to setup the Serial B to Serial B Flow Control.

The transmitted serial data is wrapped in a UDP packet and configured with the Destination IP address for the radio the serial data is intended for and a user configured destination port ID. The example below show the BS connected to a GPS serial receiver via the radios platform serial interface. SS1 has a laptop connected to its platform serial interface with a console display. The BS will packetize all data from its RS-232 serial interface and send it over the RF destined for SS1. SS1 will push any data it receives containing destination IP address of its radio and a destination port address matching the "Receive port" of the serial flow control, to its serial device.




Figure 7-4 Serial B to Serial B Exp

7.3.1.1. BS Example Radio setting

Below is the BS radio configuration for example in Figure 7-4 Serial B to Serial B Exp.

The screenshot shows the BS serial configuration interface. It includes the following settings:

- Serial Flow Control: ☒ Serial B to Serial B
- Serial B to Serial B: ☒ Rx ☐ Tx Only ☐ Both (Rx and Tx)
- Serial B to Ethernet: ☐ Rx Only ☐ Tx Only ☐ Both (Rx and Tx)
- Current Direction: Serial B to Serial B
- Serial Baud Rate: 4800
- Serial Raw Mode: Disabled
- Current Dest Port: 31331
- Current Rx Port: 31330
- Current Dest IP: 192.168.1.1
- Current Raw Buffer: 0
- Current Raw Timeout: 0
- Serial Flow: Disabled
- Serial Baud Rate: 4800
- Serial Raw Mode: ☐ Raw ☒ Normal
- Destination Port:
- Receive Port:
- Destination IP Addr:
- Raw Buffer:
- Raw Timeout (deciseconds):
- ☒ Disable Flow ☐ Enable Flow
- Submit

Figure 7-5 BS serial config exp

7.3.1.2. SS Example Radio setting

Below is the SS radio configuration for example in Figure 7-4 Serial B to Serial B Exp.

Figure 7-6 SS serial config exp

8. Radio Performance

8.1. GMSK NANO RF Interference Performance

Insert GMSK Interference info TBD

8.2. NANO GMSK Receiver Sensitivity

The sensitivity of the NANO receiver conforms to Section 8.3.11.1 of the IEEE 802.16D5-2004 specification. The GMSK sensitivity evaluations were performed at 2395 MHz. The sensitivity limit is a bit error rate of 1E-06.

Table 8-1. GMSK Receiver SNR Assumptions			
Modulation	Coding Rate	Receiver Sensitivity (4dB NF)	Sensitivity Bit Error Rate
1PPS	1/2	-94	1.6E-07
2PPS	1/2	-93	0
	3/4	-92	6.0E-08
4PPS	1/2	-92	0
	3/4	-90	7.0E-07
8PPS	1/2	-89	0
	3/4	-88	0

8.3. OFDM NANO RF Interference Performance

TBD

8.4. NANO OFDM Receiver Sensitivity

The sensitivity of the NANO receiver conforms to Section 8.3.11.1 of the IEEE 802.16D5-2004 specification. The OFDM sensitivity evaluations were performed at 2395 MHz. The sensitivity limit is a bit error rate of 1E-06.

Table 8-2 OFDM. 14MHz Receiver SNR Assumptions				
Modulation	Coding Rate	Receiver SNR (dB)	Receiver Sensitivity (4dB NF)	Sensitivity Bit Error Rate
BPSK	1/2	6	-88	1.1E-06
QPSK	1/2	8	-86	1.0E-06
	3/4	10	-84	8.0E-07
16 QAM	1/2	14	-81	9.0E-07
	3/4	16	-78	5.0E-07
64 QAM	2/3	21	-74	6.0E-07
	3/4	22	-72	7.0E-07

Table 8-3 OFDM. 7MHz Receiver SNR Assumptions				
Modulation	Coding Rate	Receiver SNR (dB)	Receiver Sensitivity (4dB NF)	Sensitivity Bit Error Rate
BPSK	1/2	6	-91	8.0E-07
QPSK	1/2	8	-89	9.0E-07
	3/4	10	-87	1.6E-06
16 QAM	1/2	14	-84	1.3E-06
	3/4	16	-81	1.2E-06
64 QAM	2/3	21	-77	8.0E-07
	3/4	22	-75	1.1E-06

Table 8-4 OFDM. 3.5 MHz Receiver SNR Assumptions				
Modulation	Coding Rate	Receiver SNR (dB)	Receiver Sensitivity (4dB NF)	Sensitivity Bit Error Rate
BPSK	1/2	6	-93	1.1E-06
QPSK	1/2	8	-91	7.0E-07
	3/4	10	-89	7.0E-07
16 QAM	1/2	14	-86	5.0E-07
	3/4	16	-84	1.2E-06
64 QAM	2/3	20	-80	1.1E-06
	3/4	22	-77	1.7E-06

8.5. Data Rates

8.5.1. OFDM Max Data Rates

The NANO PHY modulates and de-modulates the data packets as specified in Table 8-5.

Table 8-5. 3.5 MHz BW Max Data Rates

Modulation	Cyclic prefix	Uncoded block size (bytes/symbol)	Coded block size (bytes)	Overall coding rate	RS code	CC code rate	Data rate (Mbs)	SNR Eb/No
BPSK	1/4	12	24	1/2	None	1/2	1.2	6.4
QPSK	1/4	24	48	1/2	(32,24,4)	2/3	2.4	9.4
QPSK	1/4	36	48	3/4	(40,36,3)	5/6	3.6	11.2
16-QAM	1/4	48	96	1/2	(64,48,8)	2/3	4.8	16.4
16-QAM	1/4	72	96	3/4	(80,72,4)	5/6	7.2	18.2
64-QAM	1/4	96	144	2/3	(108,96,6)	3/4	9.5	22.7
64-QAM	1/8	108	144	3/4	(120,108,6)	5/6	11.9	24.4

Table 8-6. 7 MHz BW Max Data Rates

Modulation	Cyclic prefix	Uncoded block size (bytes/symbol)	Coded block size (bytes)	Overall coding rate	RS code	CC code rate	Data rate (Mbs)	SNR Eb/No
BPSK	1/4	12	24	1/2	None	1/2	2.4	6.4
QPSK	1/4	24	48	1/2	(32,24,4)	2/3	4.8	9.4
QPSK	1/4	36	48	3/4	(40,36,3)	5/6	7.2	11.2
16-QAM	1/4	48	96	1/2	(64,48,8)	2/3	9.6	16.4
16-QAM	1/4	72	96	3/4	(80,72,4)	5/6	14.4	18.2
64-QAM	1/4	96	144	2/3	(108,96,6)	3/4	19.0	22.7
64-QAM	1/8	108	144	3/4	(120,108,6)	5/6	23.9	24.4

Table 8-7. 14 MHz BW Max Data Rates

Modulation	Cyclic prefix	Uncoded block size (bytes/symbol)	Coded block size (bytes)	Overall coding rate	RS code	CC code rate	Data rate (Mbs)	SNR Eb/No
BPSK	1/4	12	24	1/2	None	1/2	4.8	6.4
QPSK	1/4	24	48	1/2	(32,24,4)	2/3	9.6	9.4
QPSK	1/4	36	48	3/4	(40,36,3)	5/6	14.4	11.2
16-QAM	1/4	48	96	1/2	(64,48,8)	2/3	19.2	16.4
16-QAM	1/4	72	96	3/4	(80,72,4)	5/6	28.8	18.2
64-QAM	1/4	96	144	2/3	(108,96,6)	3/4	38.0	22.7
64-QAM	1/8	108	144	3/4	(120,108,6)	5/6	47.8	24.4


8.5.2. GMSK Data Rates

The User Data rate below is an estimation of data rate available to the user in point to point mode with minimum distance between the radios.

Table 8-8. 14 MHz BW GMSK Max Data Rates								
Modulation	Cyclic prefix	Uncoded block size (bytes/symbol)	Coded block size (bytes)	Overall coding rate	RS code	CC code rate	Data rate (Kbs)	User Data Rate (Kbs)
1PPS	1/2	12	24	1/2	None		796.8	62.40
2PPS	1/2	24	48	1/2	(32,24,4)		1593.6	124.80
	3/4	36	48	3/4	(40,36,3)		2390.4	187.20
4PPS	1/2	48	96	1/2			3187.2	249.60
	3/4	72	96	3/4			4780.8	374.40
8PPS	1/2	96	192	1/2			6374.4	499.20
	3/4	144	192	3/4			9561.6	748.80

9. Mechanicals

9.1. Part Number AE102429



Appendix A: SNMP MIB

AERONIX-80216-MIB DEFINITIONS ::= BEGIN

```
IMPORTS
    MODULE-IDENTITY,
    OBJECT-TYPE,
    NOTIFICATION-TYPE,
    Unsigned32, Integer32, Counter32,
    Counter64, transmission
    FROM SNMPv2-SMI
    SnmpAdminString
    FROM SNMP-FRAMEWORK-MIB
    TEXTUAL-CONVENTION,
    MacAddress, RowStatus, TruthValue,
    TimeStamp, DateAndTime, DisplayString
    FROM SNMPv2-TC
    InetAddressType, InetAddress, InetAddressIPv4
    FROM INET-ADDRESS-MIB
    OBJECT-GROUP,
    MODULE-COMPLIANCE,
    NOTIFICATION-GROUP
    FROM SNMPv2-CONF
    ifIndex
    FROM IF-MIB;
```

wmanIfMib MODULE-IDENTITY
LAST-UPDATED "200508020000Z" -- August 02, 2005
ORGANIZATION "IEEE 802.16"
CONTACT-INFO

"WG E-mail: stds-802-16@ieee.org
WG Chair: Roger B. Marks
Postal: (U.S.) National Institute
of Standards and Technology
E-mail: r.b.marks@ieee.org

TGf Chair: Phillip Barber
Postal: Huawei Technologies Co., Ltd
E-mail: pbarber@futurewei.com provi

Editor: Joey Chou
Postal: Intel Corporation
5000 W. Chandler Blvd,
Chandler, AZ 85227, USA
E-mail: joey.chou@intel.com"

DESCRIPTION

"This material is from IEEE Std 802.16f
Copyright (c) 2005 IEEE.
This MIB Module defines managed objects for
IEEE 802.16-2004 based Subscriber Station
and Base Station."

REVISION

"200508020000Z"

DESCRIPTION

"The first approved version of WMAN-IF-MIB module."

```
::= { aeronix 1 }

--
private OBJECT IDENTIFIER ::= { iso org(3) dod(6) internet(1) 4 }
enterprises OBJECT IDENTIFIER ::= { private 1 }
bae OBJECT IDENTIFIER ::= { enterprises 17701 }
aeronix OBJECT IDENTIFIER ::= { bae 10 }
--

wmanIfBsObjects OBJECT IDENTIFIER ::= { wmanIfMib 1 }
wmanIfCommonObjects OBJECT IDENTIFIER ::= { wmanIfMib 2 }

-- Textual Conventions
WmanIfSfSchedulingType ::= TEXTUAL-CONVENTION
    STATUS current
    DESCRIPTION
        "The scheduling service provided by a SC for an
        upstream service flow. If the parameter is omitted
        from an upstream QOS Parameter Set, this object takes
        the value of bestEffort (2). This parameter must be
        reported as undefined (1) for downstream QOS Parameter
        Sets."
    SYNTAX INTEGER
    {
        undefined(1),
        bestEffort(2),
        nonRealTimePollingService(3),
        realTimePollingService(4),
        reserved(5),
        unsolicitedGrantService(6)
    }

WmanIfSfState ::= TEXTUAL-CONVENTION
    STATUS current
    DESCRIPTION
        "WmanIfSfState defines the state of a service flow."
    SYNTAX INTEGER
    {
        authorized(1),
        admitted(2),
        active(3)
    }

WmanIfCidType ::= TEXTUAL-CONVENTION
    STATUS current
    DESCRIPTION
        "Type of CID."
    SYNTAX INTEGER (0 .. 65535)

WmanIfOfdmFecCodeType ::= TEXTUAL-CONVENTION
    STATUS current
    DESCRIPTION
        "FEC code type and modulation type"
    REFERENCE
```

"Table 356 and Table 362
in IEEE Std 802.16-2004"

SYNTAX INTEGER

```
{  
    fecBPSK-12(0),  
    fecQPSK-12(1),  
    fecQPSK-34(2),  
    fecQAM-1612(3),  
    fecQAM-1634(4),  
    fecQAM-6423(5),  
    fecQAM-6434(6),  
    fec8PSK-12(7),  
    fec16PSK-12(8),  
    fec16PSK-34(9),  
    invalid(255)  
}
```

WmanIfOnOffToggleType ::= TEXTUAL-CONVENTION

STATUS current

DESCRIPTION

"On Off Toggle Type"

SYNTAX INTEGER

```
{  
    off (0),  
    on (1)  
}
```

WmanIfDownStreamUpStreamType ::= TEXTUAL-CONVENTION

STATUS current

DESCRIPTION

"Downstream Upstream Type"

SYNTAX INTEGER

```
{  
    downstream (1),  
    upstream (2)  
}
```

WmanIfMisoModeType ::= TEXTUAL-CONVENTION

STATUS current

DESCRIPTION

"Miso Type"

SYNTAX INTEGER

```
{  
    miso (0),  
    siso (1)  
}
```

WmanIfDiversityType ::= TEXTUAL-CONVENTION

STATUS current

DESCRIPTION

"Diversity Type"

SYNTAX INTEGER

```
{
```

```
unknown (0),  
auto (1),  
a (2),  
b (3)  
}
```

WmanIfOperatingBwType ::= TEXTUAL-CONVENTION

STATUS current

DESCRIPTION

"Operating BW Type"

SYNTAX INTEGER

```
{  
    bw2400MHz (24),  
    bw4600or5800MHz (58)  
}
```

WmanIfBandwidthType ::= TEXTUAL-CONVENTION

STATUS current

DESCRIPTION

""

SYNTAX INTEGER

```
{  
    tenMhz (10000000),  
    twentyMHz(17500000)  
}
```

WmanIfChannelType ::= TEXTUAL-CONVENTION

STATUS current

DESCRIPTION

""

SYNTAX INTEGER

```
{  
    rfc01 (1),  
    rfc02 (2),  
    rfc03 (3),  
    rfc04 (4),  
    rfc05 (5),  
    rfc06 (6),  
    rfc07 (7),  
    rfc08 (8),  
    rfc09 (9),  
    rfc10 (10),  
    rfc11 (11),  
    rfc21 (21),  
    rfc22 (22),  
    rfc23 (23),  
    rfc24 (24),  
    rfc25 (25),  
    rfc26 (26),  
    rfc27 (27),  
    rfc28 (28),  
    rfc29 (29),  
    rfc30 (30),  
    rfc31 (31),
```

```
rfc32 (32),
rfc33 (33),
rfc34 (34),
rfc35 (35),
rfc36 (36),
rfc37 (37),
rfc38 (38),
rfc39 (39),
rfc40 (40),
rfc41 (41),
rfc42 (42),
rfc43 (43),
rfc44 (44),
rfc45 (45),
rfc46 (46),
rfc47 (47),
rfc48 (48),
rfc49 (49),
rfc50 (50),
rfc51 (51),
rfc52 (52),
rfc53 (53),
rfc54 (54),
rfc55 (55),
rfc56 (56),
rfc57 (57),
rfc58 (58),
rfc59 (59)
}
```

WmanIfEnableType ::= TEXTUAL-CONVENTION

STATUS current

DESCRIPTION

"Enable Type"

SYNTAX INTEGER

```
{
    disable (0),
    enable (1)
}
```

--

-- BS object group containing tables and objects to be implemented in
-- the Base station

--

--

wmanIfBsProvisionedSfTable OBJECT-TYPE

SYNTAX SEQUENCE OF WmanIfBsProvisionedSfEntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"This table contains service flow profiles provisioned by
NMS. The service flow should be created with SS(s)

following instruction given by wmanIfBsSfState object.

1. The QoS parameters of the service flow are provisioned in wmanIfBsServiceClassTable and referenced by wmanIfBsServiceClassIndex.
2. The classifier rules of the service flow are provisioned in wmanIfBsClassifierRuleTable, where they refer to SF via wmanIfBsSfld.

The MAC addresses of SSs the service flow is created with are provisioned in wmanIfBsSsProvisionedForSfTable, where they refer to SF via wmanIfBsSfld."

REFERENCE

"Subclause 6.3.13 and 6.3.14 in IEEE Std 802.16-2004"

::= { wmanIfBsObjects 1 }

wmanIfBsProvisionedSfEntry OBJECT-TYPE

SYNTAX WmanIfBsProvisionedSfEntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"This table provides one row for each service flow provisioned by NMS. The table is indexed by ifIndex and wmanIfBsSfld. ifIndex is associated with the BS sector."

INDEX { snmpRowIndex }

::= { wmanIfBsProvisionedSfTable 1 }

WmanIfBsProvisionedSfEntry ::= SEQUENCE

```
{
    snmpRowIndex          INTEGER,
    wmanIfBsSfld          Unsigned32,
    wmanIfBsSsProvmacAddress  DisplayString,
    wmanIfBsSfDirection  WmanIfDownStreamUpStreamType,
    wmanIfBsServiceClassName  DisplayString,
    wmanIfBsSfState       WmanIfSfState,
    wmanIfBsSfUIMulticast WmanIfOnOffToggleType,
    wmanIfBsProvisionedSfRowStatus  RowStatus
}
```

wmanIfBsSfld OBJECT-TYPE

SYNTAX Unsigned32

MAX-ACCESS read-write

STATUS current

DESCRIPTION

"A 32 bit quantity that uniquely identifies a service flow to both the subscriber station and base station (BS)."

::= { wmanIfBsProvisionedSfEntry 1 }

wmanIfBsSsProvmacAddress OBJECT-TYPE

SYNTAX DisplayString

MAX-ACCESS read-write

STATUS current

DESCRIPTION

"The MAC address of the SS, the service flow is created with."

::= { wmanIfBsProvisionedSfEntry 3 }

wmanIfBsSfDirection OBJECT-TYPE

SYNTAX WmanIfDownStreamUpStreamType

MAX-ACCESS read-write

STATUS current

DESCRIPTION

"An attribute indicating the service flow is downstream or upstream."

::= { wmanIfBsProvisionedSfEntry 4 }

wmanIfBsServiceClassName OBJECT-TYPE

SYNTAX DisplayString

MAX-ACCESS read-write

STATUS current

DESCRIPTION

"Refers to the Service Class Name"

REFERENCE

"Subclause 11.13.3 in IEEE Std 802.16-2004"

::= { wmanIfBsProvisionedSfEntry 5 }

wmanIfBsSfState OBJECT-TYPE

SYNTAX WmanIfSfState

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"wmanIfBsSfState determines the requested state of a service flow.

- authorized state: A service flow is provisioned but not resource is reserved yet
- admitted state: service flow has resources reserved.
- active state: has resources committed by the BS (e.g., is actively sending maps containing unsolicited grants for a UGS-based service flow),"

REFERENCE

"Subclause 6.3.14.6, in IEEE Std 802.16-2004"

::= { wmanIfBsProvisionedSfEntry 6 }

wmanIfBsSfUIMulticast OBJECT-TYPE

SYNTAX WmanIfOnOffToggleType

MAX-ACCESS read-write

STATUS current

DESCRIPTION

""

::= { wmanIfBsProvisionedSfEntry 7 }

wmanIfBsProvisionedSfRowStatus OBJECT-TYPE

SYNTAX RowStatus

MAX-ACCESS read-create

STATUS current

DESCRIPTION

"This object is used to create a new row or modify or delete an existing row in this table.

If the implementator of this MIB has chosen not

to implement 'dynamic assignment' of profiles, this object is not useful and should return noSuchName upon SNMP request."

::= { wmanIfBsProvisionedSfEntry 8 }

snmpRowIndex OBJECT-TYPE

SYNTAX INTEGER (1..1000)

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"SNMP Row Index"

::= { wmanIfBsProvisionedSfEntry 999 }

--

--

--

--

wmanIfBsSsNameTable OBJECT-TYPE

SYNTAX SEQUENCE OF WmanIfBsSsNameEntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

""

REFERENCE

"Subclause 6.3.13 and 6.3.14 in IEEE Std 802.16-2004"

::= { wmanIfBsObjects 4 }

wmanIfBsSsNameEntry OBJECT-TYPE

SYNTAX WmanIfBsSsNameEntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

""

INDEX { snmpRowIndex }

::= { wmanIfBsSsNameTable 1 }

WmanIfBsSsNameEntry ::= SEQUENCE

```
{
  wmanIfBsSsNameNum                Unsigned32,
  wmanIfBsSsNameSubscriberName     DisplayString,
  wmanIfBsSsNameMACAddress          DisplayString
}
```

wmanIfBsSsNameNum OBJECT-TYPE

SYNTAX Unsigned32

MAX-ACCESS read-write

STATUS current

DESCRIPTION

""

::= { wmanIfBsSsNameEntry 1 }

wmanIfBsSsNameSubscriberName OBJECT-TYPE

SYNTAX DisplayString

```
MAX-ACCESS read-write
STATUS current
DESCRIPTION
    ""
 ::= { wmanIfBsSsNameEntry 2 }

wmanIfBsSsNameMACAddress OBJECT-TYPE
    SYNTAX DisplayString
    MAX-ACCESS read-write
    STATUS current
    DESCRIPTION
        ""
 ::= { wmanIfBsSsNameEntry 3 }

--
--
--
--

wmanIfBsServiceClassTable OBJECT-TYPE
    SYNTAX SEQUENCE OF WmanIfBsServiceClassEntry
    MAX-ACCESS not-accessible
    STATUS current
    DESCRIPTION
        "This table is provisioned and is indexed by
        wmanIfBsQoSProfileIndex. Each entry of the table contains
        corresponding service flow characteristic attributes
        (e.g. QoS parameter set). The value of
        wmanIfBsQoSProfileIndex is obtained from
        wmanIfBsServiceClassIndex in wmanIfBsProvisionedSfTable"
    REFERENCE
        "Subclause 6.3.14.4 in IEEE Std 802.16-2004"
 ::= { wmanIfBsObjects 2 }

wmanIfBsServiceClassEntry OBJECT-TYPE
    SYNTAX WmanIfBsServiceClassEntry
    MAX-ACCESS not-accessible
    STATUS current
    DESCRIPTION
        "This table provides one row for each service class"
    INDEX { snmpRowIndex }
 ::= { wmanIfBsServiceClassTable 1 }

WmanIfBsServiceClassEntry ::= SEQUENCE
{
    wmanIfBsQoSProfileIndex          INTEGER,
    wmanIfBsQoSServiceClassName      DisplayString,
    bitArray                         DisplayString,
    wmanIfBsQoSSTrafficPriority        INTEGER,
    wmanIfBsQoSMaxSustainedRate        Unsigned32,
    wmanIfBsQoSMinReservedRate        Unsigned32,
    wmanIfBsQoSScSchedulingType        WmanIfSfSchedulingType,
    wmanIfBsQOSServiceClassRowStatus   RowStatus
}
```

wmanIfBsQoSProfileIndex OBJECT-TYPE

SYNTAX INTEGER

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The index value which uniquely identifies an entry
in the wmanIfBsServiceClassTable"

::= { wmanIfBsServiceClassEntry 1 }

wmanIfBsQoSServiceClassName OBJECT-TYPE

SYNTAX DisplayString

MAX-ACCESS read-write

STATUS current

DESCRIPTION

"Refers to the Service Class Name"

REFERENCE

"Subclause 11.13.3 in IEEE Std 802.16-2004"

::= { wmanIfBsServiceClassEntry 2 }

bitArray OBJECT-TYPE

SYNTAX DisplayString

MAX-ACCESS read-write

STATUS current

DESCRIPTION

"Refers to the Service Class Name"

REFERENCE

"Subclause 11.13.3 in IEEE Std 802.16-2004"

::= { wmanIfBsServiceClassEntry 3 }

wmanIfBsQoSSTrafficPriority OBJECT-TYPE

SYNTAX INTEGER

MAX-ACCESS read-write

STATUS current

DESCRIPTION

"The value of this parameter specifies the priority
assigned to a service flow. For uplink service flows,
the BS should use this parameter when determining
precedence in request service and grant generation,
and the SS shall preferentially select contention
Request opportunities for Priority Request CIDs
based on this priority. Higher numbers indicate higher
priority"

REFERENCE

"Subclause 11.13.5 in IEEE Std 802.16-2004"

::= { wmanIfBsServiceClassEntry 4 }

wmanIfBsQoSMaxSustainedRate OBJECT-TYPE

SYNTAX Unsigned32

UNITS "b/s"

MAX-ACCESS read-write

STATUS current

DESCRIPTION

"This parameter defines the peak information rate"

of the service. The rate is expressed in bits per second and pertains to the SDUs at the input to the system."

REFERENCE

"Subclause 11.13.6 in IEEE Std 802.16-2004"

::= { wmanIfBsServiceClassEntry 5 }

wmanIfBsQoSMinReservedRate OBJECT-TYPE

SYNTAX Unsigned32

UNITS "b/s"

MAX-ACCESS read-write

STATUS current

DESCRIPTION

"This parameter specifies the minimum rate reserved for this service flow."

REFERENCE

"Subclause 11.13.8 in IEEE Std 802.16-2004"

::= { wmanIfBsServiceClassEntry 6 }

wmanIfBsQoSScSchedulingType OBJECT-TYPE

SYNTAX WmanIfSfSchedulingType

MAX-ACCESS read-write

STATUS current

DESCRIPTION

"Specifies the upstream scheduling service used for upstream service flow. If the referenced parameter is not present in the corresponding 802.16 QoS Parameter Set of an upstream service flow, the default value of this object is bestEffort(2)."

REFERENCE

"Subclause 11.13.11 in IEEE Std 802.16-2004"

DEFVAL { bestEffort }

::= { wmanIfBsServiceClassEntry 7 }

wmanIfBsQoSServiceClassRowStatus OBJECT-TYPE

SYNTAX RowStatus

MAX-ACCESS read-create

STATUS current

DESCRIPTION

"This object is used to create a new row or modify or delete an existing row in this table."

If the implementator of this MIB has chosen not to implement 'dynamic assignment' of profiles, this object is not useful and should return noSuchName upon SNMP request."

::= { wmanIfBsServiceClassEntry 8 }

--
--
--
--

wmanIfBsRegisteredSsTable OBJECT-TYPE

SYNTAX SEQUENCE OF WmanIfBsRegisteredSsEntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"This table contains the basic capability information of SSs that have been negotiated and agreed between BS and SS via REG-REQ and REG-RSP messages. An entry in this table indicates the SS has entered and registered into the BS."

REFERENCE

"Subclause 6.3.2.3.7 in IEEE Std 802.16-2004"

::= { wmanIfBsObjects 3 }

wmanIfBsRegisteredSsEntry OBJECT-TYPE

SYNTAX WmanIfBsRegisteredSsEntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"This table provides one row for each SS that has been registered in the BS, and is indexed by wmanIfBsSsMacAddress. The primary index is the ifIndex with an ifType of propBWA2Mp, indicating the BS sector with which the SS is associated. wmanIfBsSsMacAddress identifies the SS being registered."

INDEX { snmpRowIndex }

::= { wmanIfBsRegisteredSsTable 1 }

WmanIfBsRegisteredSsEntry ::= SEQUENCE

```
{
  wmanIfBsSsldIndex          Unsigned32,
  wmanIfBsSsMacAddress       DisplayString,
  wmanIfBsSsBasicCid         WmanIfCidType,
  wmanIfBsSsPrimaryCid       WmanIfCidType,
  wmanIfBsSsMacCrcSupport    WmanIfOnOffToggleType,
  snmpRowIndex               Unsigned32
}
```

wmanIfBsSsldIndex OBJECT-TYPE

SYNTAX Unsigned32

MAX-ACCESS read-only

STATUS current

DESCRIPTION

""

REFERENCE

"Subclause 6.3.2.3.6 in IEEE Std 802.16-2004"

::= { wmanIfBsRegisteredSsEntry 1 }

wmanIfBsSsMacAddress OBJECT-TYPE

SYNTAX DisplayString

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The MAC address of SS is received from the RNG-REQ

message. When SS registers, this MAC address is entered into the table, and used as the identifier to the SS."

REFERENCE

"Subclause 6.3.2.3.5 in IEEE Std 802.16-2004"

::= { wmanIfBsRegisteredSsEntry 2 }

wmanIfBsSsBasicCid OBJECT-TYPE

SYNTAX WmanIfCidType

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The value of this object indicates the SS's basic CID that was sent in the RNG-RSP message."

REFERENCE

"Subclause 6.3.2.3.6 in IEEE Std 802.16-2004"

::= { wmanIfBsRegisteredSsEntry 3 }

wmanIfBsSsPrimaryCid OBJECT-TYPE

SYNTAX WmanIfCidType

MAX-ACCESS read-only

STATUS current

DESCRIPTION

""

REFERENCE

"Subclause 6.3.2.3.6 in IEEE Std 802.16-2004"

::= { wmanIfBsRegisteredSsEntry 4 }

wmanIfBsSsMacCrcSupport OBJECT-TYPE

SYNTAX WmanIfOnOffToggleType

MAX-ACCESS read-only

STATUS current

DESCRIPTION

""

REFERENCE

"Subclause 11.13.18.3 in IEEE Std 802.16-2004"

::= { wmanIfBsRegisteredSsEntry 5 }

snmpRowIndex OBJECT-TYPE

SYNTAX Unsigned32

MAX-ACCESS read-only

STATUS current

DESCRIPTION

""

REFERENCE

""

::= { wmanIfBsRegisteredSsEntry 6 }

--

-- Common object group containing tables and objects to be implemented in
-- both the Base station and the Subscriber station

--

--

aeronixSystemStatusTable OBJECT-TYPE

SYNTAX SEQUENCE OF AeronixSystemStatusEntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"This table contains system status values "

::= { wmanIfCommonObjects 1 }

aeronixSystemStatusEntry OBJECT-TYPE

SYNTAX AeronixSystemStatusEntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"This Table is a unique aeronix strucutre, Used to view the status of the radio. It was ported from the wmanIfMib.h header file"

INDEX { snmpRowIndex }

::= { aeronixSystemStatusTable 1 }

AeronixSystemStatusEntry ::= SEQUENCE

```
{
  statusBaseLight          Unsigned32,
  statusSyncState          Unsigned32,
  statusSyncLight          INTEGER,
  statusTx                 Unsigned32,
  statusRx                 Unsigned32,
  isBsorSs                INTEGER
}
```

statusBaseLight OBJECT-TYPE

SYNTAX Unsigned32

MAX-ACCESS read-only

STATUS current

DESCRIPTION

""

::= { aeronixSystemStatusEntry 1 }

statusSyncState OBJECT-TYPE

SYNTAX Unsigned32

MAX-ACCESS read-only

STATUS current

DESCRIPTION

""

::= { aeronixSystemStatusEntry 2 }

statusSyncLight OBJECT-TYPE

SYNTAX INTEGER

```
{
  nosync(0),
  sync(1)
}
```

MAX-ACCESS read-only

STATUS current

DESCRIPTION

""

::= { aeronixSystemStatusEntry 3 }

statusTx OBJECT-TYPE
SYNTAX Unsigned32
MAX-ACCESS read-only
STATUS current
DESCRIPTION
""
::= { aeronixSystemStatusEntry 4 }

statusRx OBJECT-TYPE
SYNTAX Unsigned32
MAX-ACCESS read-only
STATUS current
DESCRIPTION
""
::= { aeronixSystemStatusEntry 5 }

isBsrSs OBJECT-TYPE
SYNTAX INTEGER
MAX-ACCESS read-only
STATUS current
DESCRIPTION
""
::= { aeronixSystemStatusEntry 6 }

--
--
--
--

aeronixSystemControlTable OBJECT-TYPE
SYNTAX SEQUENCE OF AeronixSystemControlEntry
MAX-ACCESS not-accessible
STATUS current
DESCRIPTION
"This table contains packet classifier rules associated
with service flows."
::= { wmanIfCommonObjects 2 }

aeronixSystemControlEntry OBJECT-TYPE
SYNTAX AeronixSystemControlEntry
MAX-ACCESS not-accessible
STATUS current
DESCRIPTION
"This Table is a unique aeronix strucutre, Used to conotrol the radio.
It was ported from the wmanIfMib.h header file"
INDEX { snmpRowIndex }
::= { aeronixSystemControlTable 1 }

AeronixSystemControlEntry ::= SEQUENCE
{
 txrxEnable WmanIfEnableType,
 transecEnable WmanIfEnableType,
 freqBandwidth Unsigned32,
 freqChannel INTEGER,
 downlinkPercentage INTEGER,

uplinkPercentage	INTEGER,
frameTimeMSec	INTEGER,
ssScanChannel	WmanIfEnableType,
acmUpHysteresis	INTEGER,
acmDownJump	INTEGER,
effectiveKey	DisplayString,
misoMode	WmanIfMisoModeType,
rxDataSwap	WmanIfEnableType,
radioTypeConfig	INTEGER,
enaSerialTransfer	WmanIfEnableType,
serialTxPort	Unsigned32,
serialRxPort	Unsigned32,
serialTxIP	DisplayString,
usingClassifiers	WmanIfEnableType,
usingARPTable	WmanIfEnableType,
customFreq	INTEGER

}

txrxEnable OBJECT-TYPE
SYNTAX WmanIfEnableType
MAX-ACCESS read-write
STATUS current
DESCRIPTION

""

::= { aeronixSystemControlEntry 1 }

transecEnable OBJECT-TYPE
SYNTAX WmanIfEnableType
MAX-ACCESS read-write
STATUS current
DESCRIPTION

""

::= { aeronixSystemControlEntry 2 }

freqBandwidth OBJECT-TYPE
SYNTAX Unsigned32
MAX-ACCESS read-write
STATUS current
DESCRIPTION

""

::= { aeronixSystemControlEntry 3 }

freqChannel OBJECT-TYPE
SYNTAX INTEGER
MAX-ACCESS read-write
STATUS current
DESCRIPTION

""

::= { aeronixSystemControlEntry 4 }

downlinkPercentage OBJECT-TYPE
SYNTAX INTEGER
MAX-ACCESS read-write
STATUS current

DESCRIPTION

""

::= { aeronixSystemControlEntry 5 }

uplinkPercentage OBJECT-TYPE

SYNTAX INTEGER

MAX-ACCESS read-write

STATUS current

DESCRIPTION

""

::= { aeronixSystemControlEntry 6 }

frameTimeMSec OBJECT-TYPE

SYNTAX INTEGER

MAX-ACCESS read-only

STATUS current

DESCRIPTION

""

::= { aeronixSystemControlEntry 7 }

ssScanChannel OBJECT-TYPE

SYNTAX WmanIfEnableType

MAX-ACCESS read-write

STATUS current

DESCRIPTION

""

::= { aeronixSystemControlEntry 8 }

acmUpHysteresis OBJECT-TYPE

SYNTAX INTEGER

MAX-ACCESS read-write

STATUS current

DESCRIPTION

""

::= { aeronixSystemControlEntry 9 }

acmDownJump OBJECT-TYPE

SYNTAX INTEGER

MAX-ACCESS read-write

STATUS current

DESCRIPTION

""

::= { aeronixSystemControlEntry 10 }

effectiveKey OBJECT-TYPE

SYNTAX DisplayString

MAX-ACCESS read-write

STATUS current

DESCRIPTION

""

::= { aeronixSystemControlEntry 11 }

misoMode OBJECT-TYPE

SYNTAX WmanIfMisoModeType

MAX-ACCESS read-write
STATUS current
DESCRIPTION

""

::= { aeronixSystemControlEntry 12 }

rxDataSwap OBJECT-TYPE
SYNTAX WmanIfEnableType
MAX-ACCESS read-write
STATUS current
DESCRIPTION

""

::= { aeronixSystemControlEntry 13 }

radioTypeConfig OBJECT-TYPE
SYNTAX INTEGER
MAX-ACCESS read-write
STATUS current
DESCRIPTION

""

::= { aeronixSystemControlEntry 14 }

enaSerialTransfer OBJECT-TYPE
SYNTAX WmanIfEnableType
MAX-ACCESS read-write
STATUS current
DESCRIPTION

""

::= { aeronixSystemControlEntry 15 }

serialTxPort OBJECT-TYPE
SYNTAX Unsigned32
MAX-ACCESS read-write
STATUS current
DESCRIPTION

""

::= { aeronixSystemControlEntry 16 }

serialRxPort OBJECT-TYPE
SYNTAX Unsigned32
MAX-ACCESS read-write
STATUS current
DESCRIPTION

""

::= { aeronixSystemControlEntry 17 }

serialTxIP OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-write
STATUS current
DESCRIPTION

""

::= { aeronixSystemControlEntry 18 }

usingClassifiers OBJECT-TYPE
SYNTAX WmanIfEnableType
MAX-ACCESS read-write
STATUS current
DESCRIPTION

""

::= { aeronixSystemControlEntry 19 }

usingARPTTable OBJECT-TYPE
SYNTAX WmanIfEnableType
MAX-ACCESS read-write
STATUS current
DESCRIPTION

""

::= { aeronixSystemControlEntry 20 }

customFreq OBJECT-TYPE
SYNTAX INTEGER
MAX-ACCESS read-write
STATUS current
DESCRIPTION

""

::= { aeronixSystemControlEntry 21 }

--

--

--

--

aeronixSnmpControlTable OBJECT-TYPE
SYNTAX SEQUENCE OF AeronixSnmpControlEntry
MAX-ACCESS not-accessible
STATUS current
DESCRIPTION

"This table contains packet classifier rules associated
with service flows."

::= { wmanIfCommonObjects 4 }

aeronixSnmpControlEntry OBJECT-TYPE
SYNTAX AeronixSnmpControlEntry
MAX-ACCESS not-accessible
STATUS current
DESCRIPTION
"This table controls the snmp server and aeronix interface"
INDEX { snmpRowIndex }
::= { aeronixSnmpControlTable 1 }

AeronixSnmpControlEntry ::= SEQUENCE

{
 repopulate Unsigned32,
 savedatabase Unsigned32,
 usedefaultdb Unsigned32,
 rebootSys Unsigned32,
 debugmode Unsigned32,
 classifierMacAddrMode Unsigned32,

```
basestation          Unsigned32,
dbStationId          Unsigned32,
ssid                 Unsigned32,
webgui               Unsigned32,
udhpcp               Unsigned32,
bridging             Unsigned32,
sysIP4Address        DisplayString,
sysIP4Netmask         DisplayString,
sysIP4Gateway         DisplayString,
sysIP4VLan           Unsigned32,
sysIP6Address        DisplayString,
sysIP6Netmask         DisplayString,
sysIP6Gateway         DisplayString,
sysIP6DestNetwork    DisplayString,
sysIP6DestNetmask    DisplayString,
makeStartScript      Unsigned32
}
```

repopulate OBJECT-TYPE

```
SYNTAX Unsigned32
MAX-ACCESS read-write
STATUS current
DESCRIPTION
""
```

::= { aeronixSnmpControlEntry 1 }

savedatabase OBJECT-TYPE

```
SYNTAX Unsigned32
MAX-ACCESS read-write
STATUS current
DESCRIPTION
""
```

::= { aeronixSnmpControlEntry 2 }

usedefaultdb OBJECT-TYPE

```
SYNTAX Unsigned32
MAX-ACCESS read-write
STATUS current
DESCRIPTION
""
```

::= { aeronixSnmpControlEntry 3 }

rebootSys OBJECT-TYPE

```
SYNTAX Unsigned32
MAX-ACCESS read-write
STATUS current
DESCRIPTION
""
```

::= { aeronixSnmpControlEntry 4 }

debugmode OBJECT-TYPE

```
SYNTAX Unsigned32
MAX-ACCESS read-write
STATUS current
```

DESCRIPTION

""

::= { aeronixSnmpControlEntry 5 }

classifierMacAddrMode OBJECT-TYPE

SYNTAX Unsigned32

MAX-ACCESS read-write

STATUS current

DESCRIPTION

""

::= { aeronixSnmpControlEntry 6 }

basestation OBJECT-TYPE

SYNTAX Unsigned32

MAX-ACCESS read-write

STATUS current

DESCRIPTION

""

::= { aeronixSnmpControlEntry 7 }

dbStationId OBJECT-TYPE

SYNTAX Unsigned32

MAX-ACCESS read-write

STATUS current

DESCRIPTION

"Refers to BS Id that can only be set while running as a BS.

Reboot needed after setting this value to cause it to take effect."

::= { aeronixSnmpControlEntry 8 }

ssId OBJECT-TYPE

SYNTAX Unsigned32

MAX-ACCESS read-write

STATUS current

DESCRIPTION

""

::= { aeronixSnmpControlEntry 9 }

webgui OBJECT-TYPE

SYNTAX Unsigned32

MAX-ACCESS read-write

STATUS current

DESCRIPTION

""

::= { aeronixSnmpControlEntry 10 }

udhcpc OBJECT-TYPE

SYNTAX Unsigned32

MAX-ACCESS read-write

STATUS current

DESCRIPTION

""

::= { aeronixSnmpControlEntry 11 }

bridging OBJECT-TYPE

SYNTAX Unsigned32
MAX-ACCESS read-write
STATUS current
DESCRIPTION

::= { aeronixSnmpControlEntry 12 }

sysIP4Address OBJECT-TYPE

SYNTAX DisplayString
MAX-ACCESS read-write
STATUS current
DESCRIPTION

"Refers to the Radios Eth IPv4 Address"

::= { aeronixSnmpControlEntry 13 }

sysIP4Netmask OBJECT-TYPE

SYNTAX DisplayString
MAX-ACCESS read-write
STATUS current
DESCRIPTION

"Refers to the Radios Eth IPv4 netmask"

::= { aeronixSnmpControlEntry 14 }

sysIP4Gateway OBJECT-TYPE

SYNTAX DisplayString
MAX-ACCESS read-write
STATUS current
DESCRIPTION

"Refers to the Radios Eth IPv4 gateway"

::= { aeronixSnmpControlEntry 15 }

sysIP4Vlan OBJECT-TYPE

SYNTAX Unsigned32
MAX-ACCESS read-write
STATUS current
DESCRIPTION

"Refers to the Radios Eth IPv4 gateway"

::= { aeronixSnmpControlEntry 16 }

sysIP6Address OBJECT-TYPE

SYNTAX DisplayString
MAX-ACCESS read-write
STATUS current
DESCRIPTION

"Refers to the Radios Eth IPv6 Address"

::= { aeronixSnmpControlEntry 17 }

sysIP6Netmask OBJECT-TYPE

SYNTAX DisplayString
MAX-ACCESS read-write
STATUS current
DESCRIPTION

"Refers to the Radios Eth IPv6 netmask"

::= { aeronixSnmpControlEntry 18 }

sysIP6Gateway OBJECT-TYPE

SYNTAX DisplayString

MAX-ACCESS read-write

STATUS current

DESCRIPTION

"Refers to the Radios Eth IPv6 gateway"

::= { aeronixSnmpControlEntry 19 }

sysIP6DestNetwork OBJECT-TYPE

SYNTAX DisplayString

MAX-ACCESS read-write

STATUS current

DESCRIPTION

"Refers to the Radios Eth IPv6 Dest Network"

::= { aeronixSnmpControlEntry 20 }

sysIP6DestNetmask OBJECT-TYPE

SYNTAX DisplayString

MAX-ACCESS read-write

STATUS current

DESCRIPTION

"Refers to the Radios Eth IPv6 Dest Netmask"

::= { aeronixSnmpControlEntry 21 }

makeStartScript OBJECT-TYPE

SYNTAX Unsigned32

MAX-ACCESS read-write

STATUS current

DESCRIPTION

""

::= { aeronixSnmpControlEntry 22 }

--

--

--

aeronixRangingParamsTable OBJECT-TYPE

SYNTAX SEQUENCE OF AeronixRangingParamsEntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"This table contains ranging parameters."

::= { wmanIfCommonObjects 5 }

aeronixRangingParamsEntry OBJECT-TYPE

SYNTAX AeronixRangingParamsEntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"This Table is a unique aeronix structure, used to store ranging parameters. It was ported from the wmanIfMib.h header file"

INDEX { snmpRowIndex }

::= { aeronixRangingParamsTable 1 }

```
AeronixRangingParamsEntry ::= SEQUENCE
{
    lnaRxGain          Unsigned32,
    paTxGain           Unsigned32,
    antennaGain        Unsigned32,
    internalRxCableLoss Unsigned32,
    internalTxCableLoss Unsigned32,
    externalRxCableLoss Unsigned32,
    externalTxCableLoss Unsigned32,
    antennaLoss        Unsigned32,
    txPwrControl        INTEGER,
    powerOutputMode     INTEGER,
    externalRxCableList1Length Unsigned32,
    externalRxCableList1Value  Unsigned32,
    externalRxCableList1Comment DisplayString,
    externalRxCableList2Length Unsigned32,
    externalRxCableList2Value  Unsigned32,
    externalRxCableList2Comment DisplayString,
    externalRxCableList3Length Unsigned32,
    externalRxCableList3Value  Unsigned32,
    externalRxCableList3Comment DisplayString,
    externalRxCableListIndex   Unsigned32,
    externalTxCableList1Length Unsigned32,
    externalTxCableList1Value  Unsigned32,
    externalTxCableList1Comment DisplayString,
    externalTxCableList2Length Unsigned32,
    externalTxCableList2Value  Unsigned32,
    externalTxCableList2Comment DisplayString,
    externalTxCableList3Length Unsigned32,
    externalTxCableList3Value  Unsigned32,
    externalTxCableList3Comment DisplayString,
    externalTxCableListIndex   Unsigned32,
    antennaCableList1Length    Unsigned32,
    antennaCableList1Value     Unsigned32,
    antennaCableList1Comment   DisplayString,
    antennaCableList2Length    Unsigned32,
    antennaCableList2Value     Unsigned32,
    antennaCableList2Comment   DisplayString,
    antennaCableList3Length    Unsigned32,
    antennaCableList3Value     Unsigned32,
    antennaCableList3Comment   DisplayString,
    antennaCableListIndex      Unsigned32
}
```

lnaRxGain OBJECT-TYPE

SYNTAX Unsigned32

MAX-ACCESS read-write

STATUS current

DESCRIPTION

""

::= { aeronixRangingParamsEntry 1 }

paTxGain OBJECT-TYPE

SYNTAX Unsigned32
MAX-ACCESS read-write
STATUS current
DESCRIPTION
""

::= { aeronixRangingParamsEntry 2 }

antennaGain OBJECT-TYPE
SYNTAX Unsigned32
MAX-ACCESS read-write
STATUS current
DESCRIPTION
""

::= { aeronixRangingParamsEntry 3 }

internalRxCableLoss OBJECT-TYPE
SYNTAX Unsigned32
MAX-ACCESS read-write
STATUS current
DESCRIPTION
""

::= { aeronixRangingParamsEntry 4 }

internalTxCableLoss OBJECT-TYPE
SYNTAX Unsigned32
MAX-ACCESS read-write
STATUS current
DESCRIPTION
""

::= { aeronixRangingParamsEntry 5 }

externalRxCableLoss OBJECT-TYPE
SYNTAX Unsigned32
MAX-ACCESS read-write
STATUS current
DESCRIPTION
""

::= { aeronixRangingParamsEntry 6 }

externalTxCableLoss OBJECT-TYPE
SYNTAX Unsigned32
MAX-ACCESS read-write
STATUS current
DESCRIPTION
""

::= { aeronixRangingParamsEntry 7 }

antennaLoss OBJECT-TYPE
SYNTAX Unsigned32
MAX-ACCESS read-write
STATUS current
DESCRIPTION
""

::= { aeronixRangingParamsEntry 8 }

txPwrControl OBJECT-TYPE

SYNTAX INTEGER

MAX-ACCESS read-write

STATUS current

DESCRIPTION

"""

::= { aeronixRangingParamsEntry 9 }

powerOutputMode OBJECT-TYPE

SYNTAX INTEGER

MAX-ACCESS read-write

STATUS current

DESCRIPTION

"""

::= { aeronixRangingParamsEntry 10 }

externalRxCableList1Length OBJECT-TYPE

SYNTAX Unsigned32

MAX-ACCESS read-write

STATUS current

DESCRIPTION

"""

::= { aeronixRangingParamsEntry 11 }

externalRxCableList1Value OBJECT-TYPE

SYNTAX Unsigned32

MAX-ACCESS read-write

STATUS current

DESCRIPTION

"""

::= { aeronixRangingParamsEntry 12 }

externalRxCableList1Comment OBJECT-TYPE

SYNTAX DisplayString

MAX-ACCESS read-write

STATUS current

DESCRIPTION

"""

::= { aeronixRangingParamsEntry 13 }

externalRxCableList2Length OBJECT-TYPE

SYNTAX Unsigned32

MAX-ACCESS read-write

STATUS current

DESCRIPTION

"""

::= { aeronixRangingParamsEntry 14 }

externalRxCableList2Value OBJECT-TYPE

SYNTAX Unsigned32

MAX-ACCESS read-write

STATUS current

DESCRIPTION

```
""
::= { aeronixRangingParamsEntry 15 }

externalRxCableList2Comment OBJECT-TYPE
    SYNTAX DisplayString
    MAX-ACCESS read-write
    STATUS current
    DESCRIPTION
        ""
    ::= { aeronixRangingParamsEntry 16 }

externalRxCableList3Length OBJECT-TYPE
    SYNTAX Unsigned32
    MAX-ACCESS read-write
    STATUS current
    DESCRIPTION
        ""
    ::= { aeronixRangingParamsEntry 17 }

externalRxCableList3Value OBJECT-TYPE
    SYNTAX Unsigned32
    MAX-ACCESS read-write
    STATUS current
    DESCRIPTION
        ""
    ::= { aeronixRangingParamsEntry 18 }

externalRxCableList3Comment OBJECT-TYPE
    SYNTAX DisplayString
    MAX-ACCESS read-write
    STATUS current
    DESCRIPTION
        ""
    ::= { aeronixRangingParamsEntry 19 }

externalRxCableListIndex OBJECT-TYPE
    SYNTAX Unsigned32
    MAX-ACCESS read-write
    STATUS current
    DESCRIPTION
        ""
    ::= { aeronixRangingParamsEntry 20 }

externalTxCableList1Length OBJECT-TYPE
    SYNTAX Unsigned32
    MAX-ACCESS read-write
    STATUS current
    DESCRIPTION
        ""
    ::= { aeronixRangingParamsEntry 21 }

externalTxCableList1Value OBJECT-TYPE
    SYNTAX Unsigned32
    MAX-ACCESS read-write
```

STATUS current
DESCRIPTION
""

::= { aeronixRangingParamsEntry 22 }

externalTxCableList1Comment OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-write
STATUS current
DESCRIPTION
""

::= { aeronixRangingParamsEntry 23 }

externalTxCableList2Length OBJECT-TYPE
SYNTAX Unsigned32
MAX-ACCESS read-write
STATUS current
DESCRIPTION
""

::= { aeronixRangingParamsEntry 24 }

externalTxCableList2Value OBJECT-TYPE
SYNTAX Unsigned32
MAX-ACCESS read-write
STATUS current
DESCRIPTION
""

::= { aeronixRangingParamsEntry 25 }

externalTxCableList2Comment OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-write
STATUS current
DESCRIPTION
""

::= { aeronixRangingParamsEntry 26 }

externalTxCableList3Length OBJECT-TYPE
SYNTAX Unsigned32
MAX-ACCESS read-write
STATUS current
DESCRIPTION
""

::= { aeronixRangingParamsEntry 27 }

externalTxCableList3Value OBJECT-TYPE
SYNTAX Unsigned32
MAX-ACCESS read-write
STATUS current
DESCRIPTION
""

::= { aeronixRangingParamsEntry 28 }

externalTxCableList3Comment OBJECT-TYPE

SYNTAX DisplayString
MAX-ACCESS read-write
STATUS current
DESCRIPTION
"""

::= { aeronixRangingParamsEntry 29 }

externalTxCableListIndex OBJECT-TYPE
SYNTAX Unsigned32
MAX-ACCESS read-write
STATUS current
DESCRIPTION
"""

::= { aeronixRangingParamsEntry 30 }

antennaCableList1Length OBJECT-TYPE
SYNTAX Unsigned32
MAX-ACCESS read-write
STATUS current
DESCRIPTION
"""

::= { aeronixRangingParamsEntry 31 }

antennaCableList1Value OBJECT-TYPE
SYNTAX Unsigned32
MAX-ACCESS read-write
STATUS current
DESCRIPTION
"""

::= { aeronixRangingParamsEntry 32 }

antennaCableList1Comment OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-write
STATUS current
DESCRIPTION
"""

::= { aeronixRangingParamsEntry 33 }

antennaCableList2Length OBJECT-TYPE
SYNTAX Unsigned32
MAX-ACCESS read-write
STATUS current
DESCRIPTION
"""

::= { aeronixRangingParamsEntry 34 }

antennaCableList2Value OBJECT-TYPE
SYNTAX Unsigned32
MAX-ACCESS read-write
STATUS current
DESCRIPTION
"""

::= { aeronixRangingParamsEntry 35 }

antennaCableList2Comment OBJECT-TYPE

SYNTAX DisplayString

MAX-ACCESS read-write

STATUS current

DESCRIPTION

""

::= { aeronixRangingParamsEntry 36 }

antennaCableList3Length OBJECT-TYPE

SYNTAX Unsigned32

MAX-ACCESS read-write

STATUS current

DESCRIPTION

""

::= { aeronixRangingParamsEntry 37 }

antennaCableList3Value OBJECT-TYPE

SYNTAX Unsigned32

MAX-ACCESS read-write

STATUS current

DESCRIPTION

""

::= { aeronixRangingParamsEntry 38 }

antennaCableList3Comment OBJECT-TYPE

SYNTAX DisplayString

MAX-ACCESS read-write

STATUS current

DESCRIPTION

""

::= { aeronixRangingParamsEntry 39 }

antennaCableListIndex OBJECT-TYPE

SYNTAX Unsigned32

MAX-ACCESS read-write

STATUS current

DESCRIPTION

""

::= { aeronixRangingParamsEntry 40 }

--

--

--

--

aeronixMaintStatusTable OBJECT-TYPE

SYNTAX SEQUENCE OF AeronixMaintStatusEntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"This table contains maintenance parameters."

::= { wmanIfCommonObjects 6 }

aeronixMaintStatusEntry OBJECT-TYPE

SYNTAX AeronixMaintStatusEntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"This Table is a unique aeronix structure, used to store maintenance parameters. It was ported from the wmanlMib.h header file"

INDEX { snmpRowIndex }

::= { aeronixMaintStatusTable 1 }

AeronixMaintStatusEntry ::= SEQUENCE

```
{
  curChannel                INTEGER,
  curChannelCenterFreq      INTEGER,
  failedResetPhyClock        Unsigned32,
  macAddress                 DisplayString,
  phyTemp                   INTEGER,
  cpuTemp                    INTEGER
}
```

curChannel OBJECT-TYPE

SYNTAX INTEGER

MAX-ACCESS read-only

STATUS current

DESCRIPTION

""

::= { aeronixMaintStatusEntry 1 }

curChannelCenterFreq OBJECT-TYPE

SYNTAX INTEGER

MAX-ACCESS read-only

STATUS current

DESCRIPTION

""

::= { aeronixMaintStatusEntry 2 }

failedResetPhyClock OBJECT-TYPE

SYNTAX Unsigned32

MAX-ACCESS read-only

STATUS current

DESCRIPTION

""

::= { aeronixMaintStatusEntry 3 }

macAddress OBJECT-TYPE

SYNTAX DisplayString

MAX-ACCESS read-only

STATUS current

DESCRIPTION

""

::= { aeronixMaintStatusEntry 4 }

phyTemp OBJECT-TYPE

SYNTAX INTEGER

MAX-ACCESS read-only
STATUS current
DESCRIPTION

""

::= { aeronixMaintStatusEntry 5 }

cpuTemp OBJECT-TYPE
SYNTAX INTEGER
MAX-ACCESS read-only
STATUS current
DESCRIPTION

""

::= { aeronixMaintStatusEntry 6 }

--
--
--
--

wmanIfBsOfdmDcdBurstProfileTable OBJECT-TYPE
SYNTAX SEQUENCE OF WmanIfBsOfdmDcdBurstProfileEntry
MAX-ACCESS not-accessible
STATUS current
DESCRIPTION

"This table provides one row for each DCD burst profile.
This table is double indexed. The primary index is an
ifIndex with an ifType of propBWAp2Mp. The secondary
index is wmanIfCmnOfdmDcdBurstProfilIndex."

REFERENCE

"Table 362, in IEEE Std 802.16-2004"

::= { wmanIfCommonObjects 8 }

wmanIfBsOfdmDcdBurstProfileEntry OBJECT-TYPE
SYNTAX WmanIfBsOfdmDcdBurstProfileEntry
MAX-ACCESS not-accessible
STATUS current
DESCRIPTION

"This table provides one row for each DCD burst profile.
This table is double indexed. The secondary index
is wmanIfCmnOfdmDcdFecCodeType."

INDEX { snmpRowIndex }

::= { wmanIfBsOfdmDcdBurstProfileTable 1 }

WmanIfBsOfdmDcdBurstProfileEntry ::= SEQUENCE
{

wmanIfCmnOfdmDcdBurstProfilIndex INTEGER,
wmanIfCmnOfdmDiucValue INTEGER,
wmanIfCmnOfdmDcdFecCodeType WmanIfOfdmFecCodeType,
wmanIfCmnOfdmDiucCinrMandatoryExitThresh INTEGER,
wmanIfCmnOfdmDiucCinrMinEntryThresh INTEGER,
wmanIfCmnOfdmDiucFecMandatoryExitThresh INTEGER,
wmanIfCmnOfdmDiucFecMinEntryThresh INTEGER,
wmanIfCmnOfdmAvailableType INTEGER,
wmanIfCmnOfdmDcdBurstProfilerowStatus RowStatus

}

wmanIfCmnOfdmDcdBurstProfIndex OBJECT-TYPE

SYNTAX INTEGER

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The Downlink Interval Usage Code indicates the downlink burst profile in the DCD message, and is used along with ifIndex to identify an entry in the wmanIfCmnOfdmDcdBurstProfileTable."

REFERENCE

"Subclause 8.3.6.3.1, in IEEE Std 802.16-2004"

::= { wmanIfBsOfdmDcdBurstProfileEntry 1 }

wmanIfCmnOfdmDiucValue OBJECT-TYPE

SYNTAX INTEGER

MAX-ACCESS read-only

STATUS current

DESCRIPTION

""

::= { wmanIfBsOfdmDcdBurstProfileEntry 2 }

wmanIfCmnOfdmDcdFecCodeType OBJECT-TYPE

SYNTAX WmanIfOfdmFecCodeType

MAX-ACCESS read-write

STATUS current

DESCRIPTION

"Downlink FEC code type and modulation type"

REFERENCE

"Table 362, in IEEE Std 802.16-2004"

::= { wmanIfBsOfdmDcdBurstProfileEntry 3 }

wmanIfCmnOfdmDiucCinrMandatoryExitThresh OBJECT-TYPE

SYNTAX INTEGER

MAX-ACCESS read-write

STATUS current

DESCRIPTION

"DIUC mandatory exit threshold: 0 - 63.75 dB CINR at or below where this DIUC can no longer be used and where this change to a more robust DIUC is required in 0.25 dB units."

REFERENCE

"Table 362, in IEEE Std 802.16-2004"

::= { wmanIfBsOfdmDcdBurstProfileEntry 4 }

wmanIfCmnOfdmDiucCinrMinEntryThresh OBJECT-TYPE

SYNTAX INTEGER

MAX-ACCESS read-write

STATUS current

DESCRIPTION

"DIUC minimum entry threshold: 0 - 63.75 dB The minimum CINR required to start using this DIUC when changing from a more robust DIUC is required, in 0.25 dB units."

REFERENCE

"Table 362, in IEEE Std 802.16-2004"
::= { wmanIfBsOfdmDcdBurstProfileEntry 5 }

wmanIfCmnOfdmDiucFecMandatoryExitThresh OBJECT-TYPE
SYNTAX INTEGER
MAX-ACCESS read-write
STATUS current
DESCRIPTION
"DIUC mandatory exit threshold: 0 - 63.75 dB CINR at or below where this DIUC can no longer be used and where this change to a more robust DIUC is required in 0.25 dB units."
REFERENCE
"Table 362, in IEEE Std 802.16-2004"
::= { wmanIfBsOfdmDcdBurstProfileEntry 6 }

wmanIfCmnOfdmDiucFecMinEntryThresh OBJECT-TYPE
SYNTAX INTEGER
MAX-ACCESS read-write
STATUS current
DESCRIPTION
"DIUC minimum entry threshold: 0 - 63.75 dB The minimum CINR required to start using this DIUC when changing from a more robust DIUC is required, in 0.25 dB units."
REFERENCE
"Table 362, in IEEE Std 802.16-2004"
::= { wmanIfBsOfdmDcdBurstProfileEntry 7 }

wmanIfCmnOfdmAvailableType OBJECT-TYPE
SYNTAX INTEGER
MAX-ACCESS read-write
STATUS current
DESCRIPTION
""
::= { wmanIfBsOfdmDcdBurstProfileEntry 8 }

wmanIfCmnOfdmDcdBurstProfilerowStatus OBJECT-TYPE
SYNTAX RowStatus
MAX-ACCESS read-create
STATUS current
DESCRIPTION
"This object is used to create a new row or modify or delete an existing row in this table.

If the implementator of this MIB has choosen not to implement 'dynamic assignment' of profiles, this object is not useful and should return noSuchName upon SNMP request."
::= { wmanIfBsOfdmDcdBurstProfileEntry 9 }

--
--
--
--

wmanIfBsOfdmUcdBurstProfileTable OBJECT-TYPE

SYNTAX SEQUENCE OF WmanIfBsOfdmUcdBurstProfileEntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"This table contains UCD burst profiles for each uplink channel"

REFERENCE

"Table 356, in IEEE Std 802.16-2004"

::= { wmanIfCommonObjects 9 }

wmanIfBsOfdmUcdBurstProfileEntry OBJECT-TYPE

SYNTAX WmanIfBsOfdmUcdBurstProfileEntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"This table provides one row for each UCD burst profile.

This table is double indexed. The primary index is an ifIndex with an ifType of propBWAp2Mp. The secondary index is wmanIfCmnOfdmUcdBurstProfIndex."

INDEX { snmpRowIndex }

::= { wmanIfBsOfdmUcdBurstProfileTable 1 }

WmanIfBsOfdmUcdBurstProfileEntry ::= SEQUENCE

```
{  
  wmanIfCmnOfdmUcdBurstProfIndex      INTEGER,  
  wmanIfCmnOfdmUiucValue               INTEGER,  
  wmanIfCmnOfdmUcdFecCodeType          WmanIfOfdmFecCodeType  
}
```

wmanIfCmnOfdmUcdBurstProfIndex OBJECT-TYPE

SYNTAX INTEGER (1..11)

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The Uplink Interval Usage Code indicates the uplink burst profile in the UCD message, and is used along with ifIndex to identify an entry in the wmanIfBsOfdmUcdBurstProfileTable."

REFERENCE

"Subclause 8.3.6.3.1, in IEEE Std 802.16-2004"

::= { wmanIfBsOfdmUcdBurstProfileEntry 1 }

wmanIfCmnOfdmUiucValue OBJECT-TYPE

SYNTAX INTEGER

MAX-ACCESS read-only

STATUS current

DESCRIPTION

""

::= { wmanIfBsOfdmUcdBurstProfileEntry 2 }

wmanIfCmnOfdmUcdFecCodeType OBJECT-TYPE

SYNTAX WmanIfOfdmFecCodeType

MAX-ACCESS read-only

STATUS current
DESCRIPTION
"Uplink FEC code type and modulation type"
REFERENCE
"Table 356, in IEEE Std 802.16-2004"
::= { wmanIfBsOfdmUcdBurstProfileEntry 3 }

--
--
--
--

aeronixNetworkStatusTable OBJECT-TYPE
SYNTAX SEQUENCE OF AeronixNetworkStatusEntry
MAX-ACCESS not-accessible
STATUS current
DESCRIPTION
""
::= { wmanIfCommonObjects 11 }

aeronixNetworkStatusEntry OBJECT-TYPE
SYNTAX AeronixNetworkStatusEntry
MAX-ACCESS not-accessible
STATUS current
DESCRIPTION
""
INDEX { snmpRowIndex }
::= { aeronixNetworkStatusTable 1 }

AeronixNetworkStatusEntry ::= SEQUENCE
{
 rxpackets Unsigned32,
 rxerrors Unsigned32,
 rxdropped Unsigned32,
 rxoverruns Unsigned32,
 rxframes Unsigned32,
 txpackets Unsigned32,
 txerrors Unsigned32,
 txdropped INTEGER,
 txoverruns INTEGER,
 txcarrier INTEGER,
 ipaddress DisplayString
}

rxpackets OBJECT-TYPE
SYNTAX Unsigned32
MAX-ACCESS read-only
STATUS current
DESCRIPTION
""
::= { aeronixNetworkStatusEntry 1 }

rxerrors OBJECT-TYPE
SYNTAX Unsigned32

MAX-ACCESS read-only
STATUS current
DESCRIPTION

""

::= { aeronixNetworkStatusEntry 2 }

rxdropped OBJECT-TYPE
SYNTAX Unsigned32
MAX-ACCESS read-only
STATUS current
DESCRIPTION

""

::= { aeronixNetworkStatusEntry 3 }

rxoverruns OBJECT-TYPE
SYNTAX Unsigned32
MAX-ACCESS read-only
STATUS current
DESCRIPTION

""

::= { aeronixNetworkStatusEntry 4 }

rxframes OBJECT-TYPE
SYNTAX Unsigned32
MAX-ACCESS read-only
STATUS current
DESCRIPTION

""

::= { aeronixNetworkStatusEntry 5 }

txpackets OBJECT-TYPE
SYNTAX Unsigned32
MAX-ACCESS read-only
STATUS current
DESCRIPTION

""

::= { aeronixNetworkStatusEntry 6 }

txerrors OBJECT-TYPE
SYNTAX Unsigned32
MAX-ACCESS read-only
STATUS current
DESCRIPTION

""

::= { aeronixNetworkStatusEntry 7 }

txdropped OBJECT-TYPE
SYNTAX INTEGER
MAX-ACCESS read-only
STATUS current
DESCRIPTION

""

::= { aeronixNetworkStatusEntry 8 }

txoverruns OBJECT-TYPE
SYNTAX INTEGER
MAX-ACCESS read-only
STATUS current
DESCRIPTION

""

::= { aeronixNetworkStatusEntry 9 }

txcarrier OBJECT-TYPE
SYNTAX INTEGER
MAX-ACCESS read-only
STATUS current
DESCRIPTION

""

::= { aeronixNetworkStatusEntry 10 }

ipaddress OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-write
STATUS current
DESCRIPTION

""

::= { aeronixNetworkStatusEntry 11 }

--
--
--
--

aeronixTxRxMaintTable OBJECT-TYPE
SYNTAX SEQUENCE OF AeronixTxRxMaintEntry
MAX-ACCESS not-accessible
STATUS current
DESCRIPTION

""

::= { wmanIfCommonObjects 12 }

aeronixTxRxMaintEntry OBJECT-TYPE
SYNTAX AeronixTxRxMaintEntry
MAX-ACCESS not-accessible
STATUS current
DESCRIPTION

""

INDEX { snmpRowIndex }

::= { aeronixTxRxMaintTable 1 }

AeronixTxRxMaintEntry ::= SEQUENCE

{
 rxFrames Unsigned32,
 invalidFrames Unsigned32,
 rxCRCs Unsigned32,
 resetRxCnt Unsigned32,
 rxTimeouts Unsigned32,
 txFrames Unsigned32,

txDrops Unsigned32
}

rxFrames OBJECT-TYPE
 SYNTAX Unsigned32
 MAX-ACCESS read-only
 STATUS current
 DESCRIPTION
 ""
 ::= { aeronixTxRxMaintEntry 1 }

invalidFrames OBJECT-TYPE
 SYNTAX Unsigned32
 MAX-ACCESS read-only
 STATUS current
 DESCRIPTION
 ""
 ::= { aeronixTxRxMaintEntry 2 }

rxCRCs OBJECT-TYPE
 SYNTAX Unsigned32
 MAX-ACCESS read-only
 STATUS current
 DESCRIPTION
 ""
 ::= { aeronixTxRxMaintEntry 3 }

resetRxCnt OBJECT-TYPE
 SYNTAX Unsigned32
 MAX-ACCESS read-only
 STATUS current
 DESCRIPTION
 ""
 ::= { aeronixTxRxMaintEntry 4 }

rxTimeouts OBJECT-TYPE
 SYNTAX Unsigned32
 MAX-ACCESS read-only
 STATUS current
 DESCRIPTION
 ""
 ::= { aeronixTxRxMaintEntry 5 }

txFrames OBJECT-TYPE
 SYNTAX Unsigned32
 MAX-ACCESS read-only
 STATUS current
 DESCRIPTION
 ""
 ::= { aeronixTxRxMaintEntry 6 }

txDrops OBJECT-TYPE
 SYNTAX Unsigned32
 MAX-ACCESS read-only

```
STATUS current
DESCRIPTION
""
 ::= { aeronixTxRxMaintEntry 7 }

--
--
--
--

aeronixVersionsTable OBJECT-TYPE
SYNTAX SEQUENCE OF AeronixVersionsEntry
MAX-ACCESS not-accessible
STATUS current
DESCRIPTION
""
 ::= { wmanIfCommonObjects 13 }

aeronixVersionsEntry OBJECT-TYPE
SYNTAX AeronixVersionsEntry
MAX-ACCESS not-accessible
STATUS current
DESCRIPTION
""
INDEX { snmpRowIndex }
 ::= { aeronixVersionsTable 1 }

AeronixVersionsEntry ::= SEQUENCE
{
    serverIp          DisplayString,
    internalIp        DisplayString,
    macAddr           DisplayString,
    macCVSTag         DisplayString,
    macCreatedOn      DisplayString,
    aecdDriverCreatedOn DisplayString,
    modemId           DisplayString,
    modemVersion      DisplayString,
    modemSVersion     DisplayString,
    filterFpgaVersion DisplayString,
    agcVersion        DisplayString,
    phySerialNum      DisplayString,
    filterFpgaVersionRF1 DisplayString,
    agcVersionRF1     DisplayString,
    phySerialNumRF1   DisplayString
}

serverIp OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-only
STATUS current
DESCRIPTION
""
 ::= { aeronixVersionsEntry 1 }
```

internalIp OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-only
STATUS current
DESCRIPTION
""
::= { aeronixVersionsEntry 2 }

macAddr OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-only
STATUS current
DESCRIPTION
""
::= { aeronixVersionsEntry 3 }

macCVSTag OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-only
STATUS current
DESCRIPTION
""
::= { aeronixVersionsEntry 4 }

macCreatedOn OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-only
STATUS current
DESCRIPTION
""
::= { aeronixVersionsEntry 5 }

aecdDriverCreatedOn OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-only
STATUS current
DESCRIPTION
""
::= { aeronixVersionsEntry 6 }

modemId OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-only
STATUS current
DESCRIPTION
""
::= { aeronixVersionsEntry 7 }

modemVersion OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-only
STATUS current
DESCRIPTION
""

```
::= { aeronixVersionsEntry 8 }

modemSVersion OBJECT-TYPE
    SYNTAX DisplayString
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        ""
::= { aeronixVersionsEntry 9 }

filterFpgaVersion OBJECT-TYPE
    SYNTAX DisplayString
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        ""
::= { aeronixVersionsEntry 10 }

agcVersion OBJECT-TYPE
    SYNTAX DisplayString
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        ""
::= { aeronixVersionsEntry 11 }

phySerialNum OBJECT-TYPE
    SYNTAX DisplayString
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        ""
::= { aeronixVersionsEntry 12 }

filterFpgaVersionRF1 OBJECT-TYPE
    SYNTAX DisplayString
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        ""
::= { aeronixVersionsEntry 13 }

agcVersionRF1 OBJECT-TYPE
    SYNTAX DisplayString
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        ""
::= { aeronixVersionsEntry 14 }

phySerialNumRF1 OBJECT-TYPE
    SYNTAX DisplayString
    MAX-ACCESS read-only
    STATUS current
```

DESCRIPTION

""

::= { aeronixVersionsEntry 15 }

--
--
--
--

aeronixStationTestsTable OBJECT-TYPE

SYNTAX SEQUENCE OF AeronixStationTestsEntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

""

::= { wmanIfCommonObjects 17 }

aeronixStationTestsEntry OBJECT-TYPE

SYNTAX AeronixStationTestsEntry

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

""

INDEX { snmpRowIndex }

::= { aeronixStationTestsTable 1 }

AeronixStationTestsEntry ::= SEQUENCE

```
{
    transmitOutputPower      Unsigned32,
    startTransmit             Unsigned32,
    startReceive              Unsigned32,
    rSSI                      DisplayString,
    modType                   Unsigned32,
    bitPattern                 Unsigned32,
    symbols                   Unsigned32,
    runMaster                  Unsigned32,
    runSlave                   Unsigned32,
    shutdownAllTests          Unsigned32,
    resetBerResults           Unsigned32,
    testLengthInSec           DisplayString,
    totalBits                  Unsigned32,
    correctBits                Unsigned32,
    errorBits                  Unsigned32,
    bitErrorRate               DisplayString,
    mbitsPerSec                DisplayString
}
```

transmitOutputPower OBJECT-TYPE

SYNTAX Unsigned32

MAX-ACCESS read-write

STATUS current

DESCRIPTION

""

::= { aeronixStationTestsEntry 1 }

startTransmit OBJECT-TYPE
SYNTAX Unsigned32
MAX-ACCESS read-write
STATUS current
DESCRIPTION
""
::= { aeronixStationTestsEntry 2 }

startReceive OBJECT-TYPE
SYNTAX Unsigned32
MAX-ACCESS read-write
STATUS current
DESCRIPTION
""
::= { aeronixStationTestsEntry 3 }

rSSI OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-only
STATUS current
DESCRIPTION
""
::= { aeronixStationTestsEntry 4 }

modType OBJECT-TYPE
SYNTAX Unsigned32
MAX-ACCESS read-write
STATUS current
DESCRIPTION
""
::= { aeronixStationTestsEntry 5 }

bitPattern OBJECT-TYPE
SYNTAX Unsigned32
MAX-ACCESS read-write
STATUS current
DESCRIPTION
""
::= { aeronixStationTestsEntry 6 }

symbols OBJECT-TYPE
SYNTAX Unsigned32
MAX-ACCESS read-write
STATUS current
DESCRIPTION
""
::= { aeronixStationTestsEntry 7 }

runMaster OBJECT-TYPE
SYNTAX Unsigned32
MAX-ACCESS read-write
STATUS current
DESCRIPTION

```
""
 ::= { aeronixStationTestsEntry 8 }

runSlave OBJECT-TYPE
    SYNTAX Unsigned32
    MAX-ACCESS read-write
    STATUS current
    DESCRIPTION
        ""
 ::= { aeronixStationTestsEntry 9 }

shutdownAllTests OBJECT-TYPE
    SYNTAX Unsigned32
    MAX-ACCESS read-write
    STATUS current
    DESCRIPTION
        ""
 ::= { aeronixStationTestsEntry 10 }

resetBerResults OBJECT-TYPE
    SYNTAX Unsigned32
    MAX-ACCESS read-write
    STATUS current
    DESCRIPTION
        ""
 ::= { aeronixStationTestsEntry 11 }

testLengthInSec OBJECT-TYPE
    SYNTAX DisplayString
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        ""
 ::= { aeronixStationTestsEntry 12 }

totalBits OBJECT-TYPE
    SYNTAX Unsigned32
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        ""
 ::= { aeronixStationTestsEntry 13 }

correctBits OBJECT-TYPE
    SYNTAX Unsigned32
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        ""
 ::= { aeronixStationTestsEntry 14 }

errorBits OBJECT-TYPE
    SYNTAX Unsigned32
    MAX-ACCESS read-only
```

```
STATUS current
DESCRIPTION
""
 ::= { aeronixStationTestsEntry 15 }

bitErrorRate OBJECT-TYPE
    SYNTAX DisplayString
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        ""
    ::= { aeronixStationTestsEntry 16 }

mbitsPerSec OBJECT-TYPE
    SYNTAX DisplayString
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        ""
    ::= { aeronixStationTestsEntry 17 }

--
--
--
--

aeronixBandwidthTable OBJECT-TYPE
    SYNTAX SEQUENCE OF AeronixBandwidthEntry
    MAX-ACCESS not-accessible
    STATUS current
    DESCRIPTION
        "This table contains bandwidth data."
    ::= { wmanIfCommonObjects 19 }

aeronixBandwidthEntry OBJECT-TYPE
    SYNTAX AeronixBandwidthEntry
    MAX-ACCESS not-accessible
    STATUS current
    DESCRIPTION
        ""
    INDEX { snmpRowIndex }
    ::= { aeronixBandwidthTable 1 }

AeronixBandwidthEntry ::= SEQUENCE
{
    bandwidthIndex          INTEGER,
    transportCid            INTEGER,
    txUserBandwidthKbps     Unsigned32,
    txAllocBandwidthKbps    Unsigned32,
    serviceClass            DisplayString,
    txUserBandwidthMbps     DisplayString,
    txAllocBandwidthMbps    DisplayString,
    serviceFlowId           INTEGER,
    numSFPacketsDropped     Unsigned32,
```


bwPrimaryCid INTEGER
}

bandwidthIndex OBJECT-TYPE
 SYNTAX INTEGER (1..1000)
 MAX-ACCESS read-only
 STATUS current
 DESCRIPTION
 ""
::= { aeronixBandwidthEntry 1 }

transportCid OBJECT-TYPE
 SYNTAX INTEGER
 MAX-ACCESS read-only
 STATUS current
 DESCRIPTION
 ""
::= { aeronixBandwidthEntry 2 }

txUserBandwidthKbps OBJECT-TYPE
 SYNTAX Unsigned32
 MAX-ACCESS read-only
 STATUS current
 DESCRIPTION
 ""
::= { aeronixBandwidthEntry 3 }

txAllocBandwidthKbps OBJECT-TYPE
 SYNTAX Unsigned32
 MAX-ACCESS read-only
 STATUS current
 DESCRIPTION
 ""
::= { aeronixBandwidthEntry 4 }

serviceClass OBJECT-TYPE
 SYNTAX DisplayString
 MAX-ACCESS read-only
 STATUS current
 DESCRIPTION
 ""
::= { aeronixBandwidthEntry 5 }

txUserBandwidthMbps OBJECT-TYPE
 SYNTAX DisplayString
 MAX-ACCESS read-only
 STATUS current
 DESCRIPTION
 ""
::= { aeronixBandwidthEntry 6 }

txAllocBandwidthMbps OBJECT-TYPE
 SYNTAX DisplayString
 MAX-ACCESS read-only

```
STATUS current
DESCRIPTION
""
 ::= { aeronixBandwidthEntry 7 }

serviceFlowId OBJECT-TYPE
    SYNTAX INTEGER
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        ""
    ::= { aeronixBandwidthEntry 8 }

numSFPacketsDropped OBJECT-TYPE
    SYNTAX Unsigned32
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        ""
    ::= { aeronixBandwidthEntry 9 }

bwPrimaryCid OBJECT-TYPE
    SYNTAX INTEGER
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        ""
    ::= { aeronixBandwidthEntry 10 }

--
--
--
--

aeronixRFStatusTable OBJECT-TYPE
    SYNTAX SEQUENCE OF AeronixRFStatusEntry
    MAX-ACCESS not-accessible
    STATUS current
    DESCRIPTION
        "This table contains RF status reports"
    ::= { wmanIfCommonObjects 20 }

aeronixRFStatusEntry OBJECT-TYPE
    SYNTAX AeronixRFStatusEntry
    MAX-ACCESS not-accessible
    STATUS current
    DESCRIPTION
        "This Table is a unique aeronix structure, Used to view the RF Status"
    INDEX { snmpRowIndex }
    ::= { aeronixRFStatusTable 1 }

AeronixRFStatusEntry ::= SEQUENCE
{
    primaryCid                INTEGER,
```

```
cinr          INTEGER,
cinrMu        INTEGER,
rssi          INTEGER,
rssiMu        INTEGER,
rssiCurlLeveled  INTEGER,
rssiAvgLeveled  INTEGER,
fecCorrected   INTEGER,
fecCorrectedMu  INTEGER,
freqOffsetMu   INTEGER,
startTime      INTEGER,
currentModType  INTEGER,
rssiRF1        INTEGER,
rssiMuRF1      INTEGER,
cpOffset       INTEGER,
cpOffsetRF1    INTEGER
}
```

```
primaryCid OBJECT-TYPE
    SYNTAX INTEGER
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        ""
    ::= { aeronixRFStatusEntry 1 }
```

```
cinr OBJECT-TYPE
    SYNTAX INTEGER
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        ""
    ::= { aeronixRFStatusEntry 2 }
```

```
cinrMu OBJECT-TYPE
    SYNTAX INTEGER
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        ""
    ::= { aeronixRFStatusEntry 3 }
```

```
rssi OBJECT-TYPE
    SYNTAX INTEGER
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        ""
    ::= { aeronixRFStatusEntry 4 }
```

```
rssiMu OBJECT-TYPE
    SYNTAX INTEGER
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
```

```
""
 ::= { aeronixRFStatusEntry 5 }

rssiCurLeveled OBJECT-TYPE
    SYNTAX INTEGER
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        ""
 ::= { aeronixRFStatusEntry 6 }

rssiAvgLeveled OBJECT-TYPE
    SYNTAX INTEGER
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        ""
 ::= { aeronixRFStatusEntry 7 }

fecCorrected OBJECT-TYPE
    SYNTAX INTEGER
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        ""
 ::= { aeronixRFStatusEntry 8 }

fecCorrectedMu OBJECT-TYPE
    SYNTAX INTEGER
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        ""
 ::= { aeronixRFStatusEntry 9 }

freqOffsetMu OBJECT-TYPE
    SYNTAX INTEGER
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        ""
 ::= { aeronixRFStatusEntry 10 }

startTime OBJECT-TYPE
    SYNTAX INTEGER
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        ""
 ::= { aeronixRFStatusEntry 11 }

currentModType OBJECT-TYPE
    SYNTAX INTEGER
    MAX-ACCESS read-only
```

```
STATUS current
DESCRIPTION
""
 ::= { aeronixRFStatusEntry 12 }

rssiRF1 OBJECT-TYPE
SYNTAX INTEGER
MAX-ACCESS read-only
STATUS current
DESCRIPTION
""
 ::= { aeronixRFStatusEntry 13 }

rssiMuRF1 OBJECT-TYPE
SYNTAX INTEGER
MAX-ACCESS read-only
STATUS current
DESCRIPTION
""
 ::= { aeronixRFStatusEntry 14 }

cpOffset OBJECT-TYPE
SYNTAX INTEGER
MAX-ACCESS read-only
STATUS current
DESCRIPTION
""
 ::= { aeronixRFStatusEntry 15 }

cpOffsetRF1 OBJECT-TYPE
SYNTAX INTEGER
MAX-ACCESS read-only
STATUS current
DESCRIPTION
""
 ::= { aeronixRFStatusEntry 16 }
--
--
--
--
END
```

Appendix C: Definitions, Acronyms, and Abbreviations

The section provides the necessary definitions, acronyms, and abbreviations relevant to this document and necessary in order to understand this document.

ACID – ARQ Channel ID

ARP – Address Resolution Protocol

ARQ – Automatic Repeat Request

ATM – Asynchronous Transfer Mode

Authentication – Verification of the source of information

BS – Base Station

CCD – Charge-Coupled Device

CCV – Clock Comparison Value

CDMA – Code Division Multiple Access

CID – Connection Identifier

CINR – Carrier to Interference and Noise Ratio

CS – Convergence Sub-layer

DCD – Downlink Channel Descriptor

DFS – Dynamic Frequency Selection

DIUC – Downlink Interval Usage Code

DL – Downlink

EDL – micro Enhanced Data Link

EIRP – Effective Isotropic Radiated Power

GMSK - Gaussian Minimum Shift Keying

GPS – Global Positioning System

H-ARQ – Hybrid Automatic Repeat Request

HMAC – Hashed Message Authentication Code

HW – Hardware

Instantiate – Create an entity from an abstraction.

Integrity – Verification that the information has not been altered.

I/O – Input/Output

IP – Internet Protocol

JTRS – Joint Tactical Radio System

MAC – Media Access Control

MSB – Most Significant Bit

OFDM – Orthogonal Frequency Division Multiplexing

OFDMA – Orthogonal Frequency Division Multiple Access

OID – Object Identifiers

OS – Operating System

PDU – Payload Data Unit

PHS – Payload Header Suppression

PHY – Physical Layer

PKM – Privacy Key Management

PTP – Point To Point

PTMP – Point To Multipoint

QoS – Quality of Service

RSSI – Received Signal Strength Indicator

RTG – Receive/Transmit Transition Gap

SDU – Service Data Unit

SFID – Service Flow ID

SNMP – Simple Network Management Protocol

SPB – Samples Per Bit

SS – Subscriber Station

SW – Software

TCP – Transmission Control Protocol

TLV – Type Length Value

TRANSEC – Transmission Security

TTG – Transmit/Receive Transition Gap

UCD – Uplink Channel Descriptor

UDP – User Datagram Protocol

UIUC – Uplink Interval Usage Code

UL – Uplink

EDL - micro EDL

USM – User-based Security

VLAN – Virtual Local Area Network