V6 CAR ALARM MANUAL

Button	Press	function	Conditions
	0.5 seconds	Arm/door lock	Alarm is disarmed
1		Sound Car finding	Alarm is being armed
		Stop alarm	Alarm is sounding
		Remote lock doors	While driving
₂ 丘	0.5 seconds	Disarm/door unlock	Alarm is being armed
		Remote unlock doors	While driving
		Stop alarm from sounding and disarm	Alarm is sounding
	2 seconds	Open trunk	Any state
1 3 A QX	Within 2 seconds	Bypass shock sensor	Disarmed state
	0.5 seconds	Silent arming	Alarm is disarmed
₃ 4)X		Silent Car finding	Alarm is being armed
		Stop alarm	Alarm is sounding
	2 seconds	Enter ACJ	ACC ON
		Exit ACJ	In anti car-hijacking
4 ≜ /1+2 □ + □	0.5 seconds	panic	Anytime

BASIC FUNCTIONS

1. Arm

Press " button of remote control for 0.5 second, the turning light will flash one time, and siren will beep one time, car door will be locked automatically, and status indicator LED will flash slowly. If the door is not closed properly, the siren will been three times, car light will flash three times. Indicator LED will flash rapidly.

If the ignition key stays at ON position, there is only locking function.

2. Mute arming

Press " UX " button of remote control for 0.5 second. The turning light flash one time without siren sound, door locked, status indicator LED flash slowly after arming, if the door is not closed properly, car light will flash three times, indicator LED will flash rapidly, 3. Disarm

Press " in button remote control for 0.5 second. The turning light flash two times, siren sound two times, car door will be unlocked automatically. If the car door is not opened within 40 seconds after disarming, the car will return to arming status. If the ignition key stays at "ON" position, there is only unlocking function.

4. Sound car finding

Under arming status., press " a" button of remote control for 0.5 second, Siren sound one time, turning light flash 10 times. Press " a" button to stop finding to disarm and unlock.

5. Silent car finding

Under arming status, press " VX " button of remote control for 0.5 second, the turning light flash 10 times without siren sound. Press " button to stop finding to disarm and unlock."

Under alarm status, press button "\(^{\text{T}}\), \(^{\text{T}}\) or "\(^{\text{V}}\)" of remote control for 0.5 second, turning light will stop flashing, siren will stop alarming.

7. Trunk release

Under any state, press the button " of remote control for 2 seconds. Trunk will be released. Note: It is only available for the car equipped with trunk release switch. The switch is optional according to customer request.

8. Emergency panic alarm

Press the button $\triangle_+ \triangle^-$ or " \triangle " of remote control for 0.5 second. Siren continue alarming, turning light continue flashing, indicator LED will flash rapidly, this status will keep for 30 seconds. Press " ar " ." " or " or " to ston alarming"

9. Anti-hijack (Use jumper 4 to select it)

When ACC ON and the doors are closed, press the button for 2 seconds and open the door within 8 seconds to activate anti car-hijacking mode. If the door is not opened within 8 sec, the mode is exit.

Close the door to start the 30 seconds countdown. The LED flashes quickly. When the 30 sec is up, siren will chirp every 1 sec. After 20 seconds, siren sounds continuously, also parking lights will continuously flash and engine will stop (if starter killer relay connected). Siren will stop to sound & parking lights will stop to flash as long as the ignition turns OFF. After ignition is OFF, engine disables to start again (if starter killer relay connected).

Disarm the anti-car-hijacking: Press button $\sqrt[4]{x}$ for two seconds when ignition is ON. The parking lights and siren will act 2 times for confirmation. Use the emergency disarming way can also exit ACJ.

10. Sensor bypass features

When the system is disarmed, Press button 1 then button 3 within 2 seconds, the siren shall chirp once and enter the arming mode then chirp once again (short chirp). This is indicating sensor of shock is now bypassed and disabled;

ALARM STATE DESCRIPTION

Shock alarm

The system shall begin to detect the shock sensor after 3 seconds of arming, if one light shock is detected, the siren shall sound and parking lights shall flash for 2 seconds (continuously sounding). After 3 seconds, if heavy shock is detected, the siren shall keep sounding (sound 1 second, stop one second), and parking light shall flash fast for 30 seconds; if the alarming trigger stops, the siren and parking light shall also stop acting.

Door-opened alarm

The system shall begin to detect the state of the car door after 3 seconds of arming, if the door is opened, the siren shall sound (continously sounding) and parking light shall flash fast for 30 seconds to warn. It shall stop after 30 seconds or once the alarming trigger is stopped.

The system shall begin to detect the state of the ignition key after 3 seconds of arming, if the ignition key is staying on, the siren shall sound and parking light shall flash fastly continously. It shall stop once the key is turned off.

ADDITIONAL FUNCTIONS

1. Auto rearming with door lock (use J2 to select this function)

After disarming, if the door was not opened or engine was not started, indicator LED flash rapidly, the car will be armed and the door will be locked automatically after 40 seconds.

2. Passive arming with door lock (use J2 to select this function)

After ACC off, close the last door, the LED indicator shall flash rapidly, main module will arm car automatically after 40 seconds, and the door shall be locked simultaneously. If opening the door and closing it again within 40 seconds, it will re-count the time. If starting the car within 40 seconds, this function will be cancelled.

3. Door-opened warning (use J3 to select this function)

If the door is opened when ACC on, the parking lights will flash continuously for 30 seconds to warn the other drivers behind. This feature is programmable by jumpers.

4. Memorize triggered alarm

If the alarm is triggered, the system will memorize triggered alarm under arming state, when disarming, turning lights will flash four times, siren will beep four times, reminding the driver to check the car.

5. State memory

The alarm system will memory the condition before the power is cut off.

6. Emergency disarming

If car can't be disarmed owing to the losing of the remote control, invalidation of remote control or any other reason, you can open the door lock using the original key under arming, then insert the key into the ignition switch, continue turning the key from OFF to ON 8 times rapidly, then stop at ON position, 2 seconds later, siren sound 2 times, turning light flash 2 times, arming is cancelled, you can drive the car normally.

7. Code memorizing

Under the disarming state, continue turning the ignition key from OFF to ON 6 times rapidly, then stop at ON position at last, 2 seconds later, siren sound 3 times, press any button of remote control to do code memorizing within 10 seconds, up to three remote control can be memorized. After one remote control was memorized, the system will keep time delay for 10 seconds. Turning the key to OFF position, it will exit the memorizing process or it will exit memorizing process automatically after 10 seconds.

8. Valet mode

Under disarming state, continue turning the key from OFF to ON rapidly for 10 times, then stop at ON position,

2 seconds later, LED keep on, in this condition, there is no alarming function, you can only lock and unlock the car doors. It was usually used under repairing and washing or somebody can keep an eye on the car. If you want to exit this mode, continue turning the key from OFF to ON rapidly for 10 times, then stop at ON position, 2 seconds later, LED light will turn off, you can operate arming and disarming then

9. Headlamp warning

When ACC off, if the door is opened, but the headlamp is on, the siren shall continue sounding for 30 seconds to warn the driver to turn it off. If the headlamp is turned off, the siren shall stop sounding immediately.


10. Door lock upon ignition

Turn ignition from Off to On, the door shall be locked automatically after 10 seconds. The door shall be unlocked when ignition is turned

PROGRAMBLE FEATURES

	Function	Jumper on	Jumper off
Jumper 1	Door lock time	0.5 seconds	3.5 seconds
Jumper 2	Auto arming w/ door lock & Passive arming w/door lock	with	without
Jumper 3	Door open warning	with	Without
Jumper 4	Anti-car jacking	with	Without

When program the above features, the system needs to be powered off at first, then put the jumper on or take the jumper off to select the feature. Then Power the system on, the selected feature would be functional.



FCC REGULATORY STATEMENT:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment"