

Model Number: DA0126-01

CAUTIONARY NOTES: Do not use this equipment for other than intended use.

1. Verify that the line voltage matches the ballast voltage.
2. Installation to be made by a qualified person in accordance with applicable codes.

This device complies with part 18 of the FCC Rules

FCC Warning:

This equipment has been tested and found to comply with the limits for a consumer device, pursuant to Part 18 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference in to radiate communications. However, there is no guarantee that interference will not occur in a particular installation.

If these equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one more of the following measures:

Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This product may cause interference to radio equipment and should not be installed near maritime safety communication equipment or other critical navigation or communication equipment operating between 0.45-30 MHz.

Features

- High power factor.
- Sound rating A.
- Min. Operating TEMP. : - 18°C.
- End of Lamp Life Protection.
- Input : 120V – 230V , 50/60Hz.
- Line Current : 1.0A.
- UL, cUL recognized. UL File # xxxxxxx.

Lamp Type and Power Consumption:

Lamp Type GTD40VO GTD

Power Consumption (Watts)	80W	70W	60W
	GTD22VO	GTD16VO	
	50W	40W	

Before Installation

1. Disconnect line voltage before installing or replacing lamp.
2. Ballast case must be grounded.
3. Place the ballast to a stable support and fix it.

Installation

1. Please connect the lamp with ballast according to the label on the ballast. Ballast supports only the same type lamps specified on the product label.
2. Connect the AC power line. Connect the black wire to **L** terminal and white to **N** terminal of the AC source.
3. The both connection of black and white power wire must be fully insulated.