

Description of Operation

1. The learning method of the transmitter and receiver:

1st step: Power on the receiver and press RESET button, meanwhile press the PGM button and hold over 8 seconds until all the red lamps on the receiver are lit.

2nd step: Install the battery of one transmitter and remove all the other transmitters' battery. Press the PGM button (hold time less than 5 seconds), then the signal lamp (first yellow lamp) will flash and the red lamp corresponding to the tire position will also flash. Now the learning is finished.

3rd step: Removed the battery of the transmitter that already finished learning process. Repeat the process of all other transmitters.

4th step: Install all the transmitters' battery and check the red lamps corresponding to the tire are flashing. If not, go back to step 1, 2, 3.

Note: Rest button means that let the product go back to initial state.

2. Function of the transmitter and the receiver:

When the pressure of the tire is lower than reset pressure, transmitter be activated and transmits signal, then the corresponding red lamp of the receiver will be lit. At the same time, receiver will make alert sound for 30s and stop for 30s and repeat until the pressure of the tire become normal.