Call Telephone

Making a call/videophone call

- Making a call by entering the phone number
- ① Enter the phone number starting with the area code, then (voice call) / (v.phone)
- After the call ends,
 - Videophone operation
 - Adjust zoom
 - (1 second or longer): Mute your voice

Making a call from phonebook

Add the phone number of the other party to the phonebook in advance.

- (Search phonebook) to select a search condition and search the phonebook
 ★ to select an entry, then (voice call) / (V.phone)
 - Making a call with redials/received calls
- (Redial) or (Received calls) to select the other party, then
 (voice call) /
 (V.phone)
 - Notifying your caller ID on the other party's phone

Set whether to show your phone number (caller ID) on the other party's phone (display) when making a call.

"TEL function" | "Dial/Receive setting" | "Caller ID notification" | "Activate/Deactivate" | "ON" or "OFF"



• If you hear a message requesting your caller ID, make a call again with Caller ID notification enabled or with 186 prefix.

Making an international call

Use WORLD CALL to make international calls from Japan.

- · For WORLD CALL, please contact General Inquiries.
- 1010 ► Country code ► Area code (City code) ► The other party's phone number ► ✓ (voice call) / (V.phone)
- 2 After the call ends, -



- Dial the other party's phone number excluding "0" at the beginning of the area code (city code). However, to make a call to some countries/areas, such as in Italy, "0" is required.
- You can make calls from overseas. (→ p.6)

Receiving a call/videophone call

When you receive an incoming call, the ring tone sounds and the illumination flashes.

- 1 When you receive an incoming call,
- After the call ends, —

Adjusting earpiece volume



・During a call, you can adjust the volume with 🏻 (マナー)/ 🔽 (菜).

When you can not answer a call

Setting record message

When you cannot answer a voice or videophone call, the FOMA terminal can record a voice or videophone message.

- "TEL function" "Rec. msg./Voice memo" "Record message setting" "ON" "Phone" or "Videophone" Select an item
- 2 Set ring time (3-digit number between 000 and 120 seconds)
- If you receive a call with Record message setting ON

Record message activates if the set time ends. Press on answer a voice call while recording. Press of (Answer with camera image) or (Subst.) (Answer with substitute image) to answer a videophone call while recording.

■ To play a recorded message

On the standby screen,

"Record message" icon or "Record VP message" icon

Select an item

Setting Public mode (Drive mode)

When Public mode (Drive mode) is set, a caller hears a message that you cannot answer the call because you are driving or in a place where you have to refrain from using a mobile phone (on a train or bus, in a theater, etc.), then the call ends.


On the standby screen, ★ (1 second or longer)

■ To deactivate

On the standby screen, * (1 second or longer)

Setting Public mode (Power OFF)

When Public mode (Power OFF) is set, a caller who made a call while the power is off hears a message that you cannot answer the call because you are in a place where you have to turn off the mobile phone (in a hospital, on an airplane, around a priority seat on a train, etc.), then the call ends.



■ To deactivate



Using various network services

Available network services

Useful DOCOMO network services are available.

- The network services are not available when you are outside the service area or in a place where the signal is weak.
- For details, refer to "Mobile Phone User's Guide [Network Services]".
- For the application and inquiries, please contact General Inquiries.

Service name	Application	Monthly charge	
Voice Mail Service	Required	Charged	
Call Waiting	Required	Charged	
Call Forwarding Service	Required	Free	
Nuisance Call Blocking	Not required	Free	
Caller ID Notification	Not required	Free	
Caller ID Request	Not required	Free	
Dual Network Service	Required	Charged	
English Guidance	Not required	Free	
Multi Number	Required	Charged	
2in1	Required	Charged	
Public mode (Drive mode)	Not required	Free	
Public mode (Power OFF)	Not required	Free	
OFFICEED	Required	Charged	
Melody call	Required	Charged	

 "OFFICEED" requires a subscription and is a fee based service. For details, refer to the NTT DOCOMO corporate website (http://www.docomo.biz/html/service/officeed/ (Japanese)).

Setting voice mail service

- "TEL function" > "Voice mail service" > Select an item
- Setting call waiting
- "TEL function" > "Other network serv." > "Call waiting" > Select an item
 - Setting call forwarding

Emergency call

Emergency call	Phone number
Police emergency	110
Fire brigade/Ambulance emergency	119
Maritime distress call	118

- Your FOMA terminal supports "Emergency Location Report". Calls made to emergency service
 organizations (e.g. by dialing 110, 119 or 118) disclose information on the caller's location to the
 organization receiving the call. The location information may not be correctly sent depending on
 the current location or signal quality. When the location information is disclosed, the organization
 name appears on the standby screen.
 - The location information and phone number are not disclosed when, before each individual call made, "184" or another blocking prefix is dialed first. If the information is deemed necessary for the protection of life, etc., this information may be acquired by the organization being called. Locations/timing planned for adoption of this feature vary according to the status of the preparations by the relevant emergency service organizations.
- When calling 110, 119 or 118 from the FOMA terminal, first say you are calling from a mobile phone, give
 your number, and state your location clearly, because the police or fire department may call you back for
 confirmation. Also, do not move around when making the call. Do not turn off the power immediately
 after ending the call, but leave it turned on for ten minutes or so, so that you can receive a call.
- Depending on the area you are calling from, you may not be connected with the nearest police or fire department, etc.
- When making a videophone call to 110, 119 or 118 from the FOMA terminal, the call automatically changes to a voice call.

Using overseas

To make calls overseas, use international roaming (WORLD WING).

- International roaming (WORLD WING) is the service, which enables you to make calls and perform communication over networks of affiliated telecommunications carriers using the FOMA terminal, phone number and mail address of your own for Japan, even when you are overseas. Voice calls, SMS and i-mode mail services are available without any special settings.
- Supported area

This FOMA terminal can be used in the 3G and GSM/GPRS network service areas. Also it can be used in countries/regions compatible with 3G850 MHz. Check available areas.

- Before overseas use, refer to the following:
 - "海外ご利用ガイド["] (Overseas use guide) (Japanese) in "My document" under Data box
 - "Mobile Phone User's Guide [International Services]"
 - DOCOMO "International Services website"
- Information
- For a country code, international call access code and universal number international prefix, refer to "Mobile Phone User's Guide [International Services]" or DOCOMO "International Services website".
- Overseas usage fees (call charge, packet communications charge) differ from those in Japan.

Available services overseas

Communication services	3G	GSM	GPRS
Voice call*1	0	0	0
Videophone call*1	0	×	×
SMS ^{*2}	0	0	0
i-mode ^{*3}	0	×	0
i-mode mail	0	×	0
i-Channel*3*4	0	×	0
i-concier*5	0	×	0
i-Widget*6	0	×	0
Packet communications via a PC	0	×	0
Obtaining location information using GPS ^{*7}	0	×	0

- *1: When 2in1 is active, dialing using Number B is not available. Dialing using the additional number of Multi number is not available.
- *2: When sending an SMS to FOMA terminal user, enter the other party's phone number as in Japan.
- *3: "i-mode overseas use" setting is required.
- *4: "i-Channel overseas use" setting is required. Packet communications charges will apply when you automatically update information on "Basic Channel". (Included in i-Channel charges in Japan.)
- *5 : Overseas use setting for i-concier is required. Packet communications charges will apply for each reception of information.
- *6: "i-Widget overseas use" setting is required. When you open the i-Widget screen, multiple Widget Appli may establish communications. In this case, packet communications charges will apply for each communication.
- *7 : GPS location service is free of charge. However, packet communications charges will apply, e.g. if you open a map from location information.



 Some services are not available depending on the operator or network overseas. For countries and overseas operators, refer to "Mobile Phone User's Guide [International Services]" or visit the DOCOMO "International Services website".

Making a call to outside the country you stay in

- On the standby screen, (1) (1 second or longer) to enter +
 - Country code ► Area code (City code) ► The other party's phone number ► (voice call) / (v.phone)
- After the call ends,



- •To make an international call to Japan, dial "81" as country code.
- •Dial the other party's phone number excluding "0" at the beginning of the area code (city code). However, to make a call to some countries/areas, such as in Italy, "0" is required.

Making a call in the country of stay

- ◆ Area code (City code)
 ◆ The other party's phone number
 ◆ (voice call) / ¹¹¹ (V.phone)
- After the call ends,

Making a call to WORLD WING user overseas

When making a call to "WORLD WING" user overseas, make a call as an international call to Japan (dial "81" (Japan) as the country code), irrespective whether the other party is in or out of the country you stay.

- On the standby screen, (a) (1 second or longer) to enter +

 8 1 The other party's mobile phone number excluding
 the first "0" (voice call) / (V.phone)
- After the call ends, —