

ATTACHMENT E.

- USER'S MANUAL-2 -

Report No.: HCT-F07-0309




Turning the TV On/Off

Press the Power button on the remote control. The TV will turn on and you will be ready to use its features. You can also use the Power button on the front panel.

Select Source

Press INPUT button on the remote control. Then you can see the current source menu shown as below.



TV Program Selection

- 1 Connect the signal source (TV antenna) to TV input. Press INPUT button on the remote control and select TV on the source.
- 2 Use CH+, CH- button or numeric button to change TV programme you want.
- **3** Press Pre.CH button on the remote control to watch the previous programme.
- **4** Also, you can tune the cable service, provided programmes while using the cable box. For further information regarding cable TV service, contact your TV service provider(s).

Volume Control

Use VOL ▲/VOL ✔ button on the remote control to adjust the volume level. Press MUTE button on the remote control when you need to cut the sound temporarily.

OSD Menu Structure



- OSD (On Screen Display) allows users to control or adjust various features and settings in accordance with his/her preferences.
- Press the Menu button on the remote control to see the main OSD menu.

Example of OSD Menu



1 Main Menu

Press Menu button on the remote control to enter the main OSD menu.

First, select Main menu item you need with 🕞 & 🕞 button.

To select a main menu items, just press (1) or (1) button on the Remote Control.

2 Sub Menu

Each menu item has its own sub menu items to set.

3 Sub Menu items

- A: If there is a empty space part, the item has an sub menu.
 - You can enter the under menu and adjust an item you need.
 - Select sub-menu item with 🖭 🛈 buttons on the remote control and press OK button to enter the submenu.
- **B**: If there is a item part, you can set the item by selecting buttons. Press OK button to set.



Tuning Band

Before your television can begin memorizing the available channels, you must specify the type of signal source that is connected to the TV. (i.e., an antenna, a standard cable system)

- 1 Press Menu button on the remote control to display the main OSD menu.
- 2 Select The Setup main menu with button on the remote control.
- **3** Press (to enter the sub menu.
- 4 Select Tuning Band menu.
- 5 Select the Band by press OK button and press Exit or Menu button. You can select Air or CABLE.



Auto Ch Search

- Press Menu button to display the main OSD menu.
- 2 Select The Setup menu with button on the remote control.
- **3** Press **1** to enter the sub menu.
- 4 Select Auto Ch Search. Press OK Button on the remote control. Then the tuning bar will appear and scanning will start.





(ATV Scan)



(DTV Scan)

Notes

- Auto Ch Search scan first analog channel after then digital channel.
- Add On Ch Search scan new channel except pre-scan channel.



Channel Edit

You can add, erase or store of your favorite channels for each available input Band. Then, when you press the Favorite button on the remote control.


- **1** Press Menu button on the remote control to display the main OSD menu.
- 2 Select the Setup main menu with button on the remote control.
- **3** Press Dutton to enter the sub menu.
- 4 Select Channel Edit menu.
- 5 Select the Viewable/Not Viewable/Favorite with OK button and press Exit button. You Can select Viewable, Not Viewable or Favorite.

You can Viewable, Not viewable or Favorite the current channel by the remote control.

CH ADD/DEL

The current channel into the scanned channel list.







Notes

· Only scanned channels can be stored as Favorite programmes.



Menu Language

You can select of your favorite language for display OSD menu.

- 1 Press Menu button on the remote control to display the main OSD menu.
- 2 Select the Setup main menu with button on the remote control.
- **3** Press Dutton to enter the sub menu.
- 4 Select Menu Language menu.
- 5 Select the English/Spanish/French with OK button and press Exit button.



DTV Signal

You can see digital signal level of current channel.

- 1 Press Menu button on the remote control to display the main OSD menu.
- 2 Select the Setup main menu with button on the remote control
- **3** Press Dutton to enter the sub menu.
- 4 Select DTV Signal menu.
- **5** To see signal level, press **OK** button.





Notes

· DTV Signal level activate on DTV.




You can change the Contrast, Brightness, Color, Sharpness , and Tint according to personal preference in USER mode.

Contrast / Brightness / Sharpness / Color / Tint

- **1** Press Menu button on the remote control to display the main OSD menu.
- 2 Select the Video main menu with button on the remote control.
- **3** Press Dutton to enter the sub menu.
- 4 Select Contrast/Brightness/Sharpness/
 Color/Tint menu with ⚠️▼ button on the remote control.
- 5 Into the adjust, press **OK** button and then set wit button on the remote control.
- **6** To cancel all adjust, select press **Preset** button

For a more detailed description of these settings, see the next page.





Notes

• In adjust you can move directly each adjust menu with press 💇 button.



■ Contrast

Adjust brightness difference between bright part of the screen and dark part.





Distinct ◀

► Vague

■ Brightness

Adjust brightness of the screen.





Dark ◀

▶ Bright

Color

Adjust deep and light color of the screen.





Decrease **◄**

► Increase

Sharpness

Adjust vividness of the screen.





Less sharp ◀

► Sharp

■ Tint

Adjusts the balance between green and yellow



Green color is deeper ◀



► Red color is deeper



Backlight

You can control the LCD Backlight.

- 1 Press Menu button on the remote control to display the main OSD menu.
- 2 Select the Video main menu with () button on the remote control.
- **3** Press Dutton to enter the sub menu.
- 4 Select Backlight menu with \(\(\backsless \) button on the remote control.
- **5** To adjust, press **OK** button.





Aspect Ratio

Your TV has four Screen Formats: **Normal**, **Zoom**, **Wide**, **Cinema**. (For more detail description for these modes, refer to the next page.)

- **1** Press Menu button on the remote control to display the main OSD menu.
- 2 Select the Video main menu with button on the remote control.
- **3** Press Dutton to enter the sub menu.
- 4 Select Aspeck Ratio menu with 🕡 button on the remote control.
- 5 To adjust, press Preset OK button.



You can change Aspect Ratio by the remote control.

V.Size






Screen Aspect Description

Wide

16:9 video: No change.

4:3 video: Expands 4:3 video signal horizontally to

fit the 16:9 screen.




■ Cinema

16:9 video: No change.


4:3 video: Expands 4:3 video horizontally to fit the

16 : 9 screen and to minimize distortion, sides are expanded more than center.



Zoom

Expands 16: 9 mode screen vertically.




Normal

16:9 video: The image is suppressed.

4:3 video: No expansion. There are gray areas

besides the image.



Notes

· Aspect Ratio only active Cinema in DTV.



In Audio Menu, you can adjust Audio Language, Bass, Contrast, Balance and Digital Audio Output.

Audio Language

Select supported audio language in English/Spanish/Korea/French.

- **1** Press Menu button on the remote control to display the main OSD menu.
- 2 Select the Audio main menu with button on the remote control.
- 3 Press (**) button to enter the sub menu.
- **4** Select **Audio Language** menu with **D**
- 5 To set English/Spanish/Korea/French, press OK button.

You can set MTS by the remote control.

MTS

Showing MTS Language number.





Notes

· Audio Language depend on broadcasting and sometimes can't select on OSD.





Bass / Treble / Balance

Adjust Audio Bass, Treble and Balance.

- **1** Press Menu button on the remote control to display the main OSD menu.
- 2 Select the Audio main menu with button on the remote control.
- **3** Press button to enter the sub menu.
- 4 Select Bass/Treble/Balance menu with \(\(\bar{\textsty} \)\)
 button on the remote control.
- 5 Into adjust Bass/Treble/Balance, press OK button and set with on the remote control
- 6 To cancel all adjust, select settings press OK button.







Notes

 In adjust you can move directly each adjust menu with press button.

Digital Audio Output

Select Digital Audio Output.

- 1 Press Menu button on the remote control to display the main OSD menu.
- 2 Select the Audio main menu with button on the remote control.
- 3 Press () button to enter the sub menu.
- 4 Select Digital Audio Output menu with Dividual button on the remote control.
- **5** To Set RAW or AC-3/PCM, press **OK** button on the remote control.



Notes

- · PCM (Pulse Coded Modulation): Digital signal for SPDIF or Coaxial output.
- RAW or AC-3: Compressed Digital signal for 5.1CH or DOLBY output.

Notes



Dolby Trademark Acknowledgement and License Notice:

Manufactures under license from Dolby Laboratories.

"Dolby" and the double-D symbol are trademarks of Dolby Laboratories.



Time Set

You can Set Time and Time zone in America.

- **1** Press Menu button on the remote control to display the main OSD menu.
- 2 Select the Feature main menu with button on the remote control.
- 3 Press (*) button to enter the sub menu.
- 4 Select Time Set menu with button on the remote control.
- 5 To enter Time Set Menu, press OK button.



■ Time Set Menu

- 1 Press Dutton to enter the sub menu.
- 2 To set Time Set Mode manual or Auto with or press **OK** button on the remote control.
- 3 To set Time Zone Eastern, Central, Mountain, Pacific, Alaska or Hawaii with (-) or press OK button on the remote control.
- 4 To set Year, Date, Time with (-) or press **OK** button on the remote control.



Notes

- To set Year, Date, Time you select in Manual of Time Set Mode.
- In the Auto mode Year, Date, Time set automatically depends on Time Zone.

Sleep Timer

You can set the Sleep timer.

- **1** Press Menu button on the remote control to display the main OSD menu.
- 2 Select the Feature main menu with Debutton on the remote control
- **3** Press button to enter the sub menu.
- 4 Select Sleep Timer menu with button on the remote control.
- **5** To set Sleep Timer Off/30 min./60/90 press **OK** button






You can set Sleep Timer by the remote control.

SI FFP

Showing the current set Sleep timer.



Advanced Video Menu

You can select NR, Color Temperature, Auto Contrast Enhancement, 3D Y/C.

- **1** Press Menu button on the remote control to display the main OSD menu.
- 2 Select the Feature main menu with button on the remote control.
- **3** Press Dutton to enter the sub menu.
- 4 Select Advanced Video Menu with press OK button
- 5 Select NR/Auto Contrast Enhancement/ Color Temperature/Black Bar Detection/ 3D Y_C/Adaptive Contrast menu with (1)(T) button on the remote control.
- 6 To Set, press OK button.
- 7 To cancel all set, select **Settings** and press **Preset** button.






You can change Color Temperature by the remote control.

PIC

Cool: Screen seems warm: Strong Blue NORMAL: Normal: Factory default. Warm: Screen seems cool: Strong Red






Password Set

You can change Parental control lock password.

- **1** Press Menu button on the remote control to display the main OSD menu.
- 2 Select the Feature main menu with button on the remote control.
- 3 Press 💇 button to enter the sub menu.
- 4 Select Password Set Menu with press OK button.
- **5** Enter Old Password with number button on the remote control.
- **6** Enter New Password with number button on the remote control.
- **7** Enter Confirm New Password with number button on the remote control.





Notes

· The factory default Password is 0000.



Parental Control

You can Setup restrictions using the "TV Parental Guidelines" of FCC.

- 1 Press Menu button on the remote control to display the main OSD menu.
- 2 Select the Feature main menu with button on the remote control.
- **3** Press Dutton to enter the sub menu.
- 4 Select Parental Control with press **OK** button.
- 5 Enter Password with number button on the remote control





■ Parental Control Menu US

- 1 Press (button to enter the sub menu.
- 2 Select US Ratings with press **OK** button.
- 3 Select MPAA Ratings with \(\bigcap \) button and Lock set press OK button on the remote control
- 4 Move TV Ratings with button on the remote control.
- **5** Select TV Ratings with button and Lock set press **OK** button on the remote control.








■ Parental Control Menu Canadian

- 1 Press button to enter the sub menu.
- 2 Select Canadian Ratings with press OK button.
- 3 Select Canandian English with button and Lock set press OK button on the remote control
- **4** Move Canadian French with button on the remote control.
- 5 Select Canadian French with to button and Lock set press OK button on the remote control.





■ Advanced Rating (TBD)

- 1 Press (button to enter the sub menu.
- 2 Select Advanced Ratings On/Off with press OK button
- **3** If Advanced Ratings On then appear Advanced Parental Lock but this Menu is not Activate.



Notes

- These categories consist of two separate groups: TV-Y and TV-Y7 (Young children through age 7), and TV-G through TV-MA (everybody else).
- The restrictions for these two groups work independently: If a household includes very youngchildren as well as young adults, the TV guidelines must be Setup separately for each age group.



Close Caption Options

You can Setup Size, Font, Text Color, Text Opacity, Background Color, Background Opacity, Edge Effect, Edge Color for Digital close caption.

Setun

Parental Control

Password Set

Advanced Video Menu

Close Caption Optio

Time Set

Sleen Timer

Video

- 1 Press Menu button on the remote control to display the main OSD menu.
- 2 Select the Feature main menu with button on the remote control.
- 3 Press (button to enter the sub menu.
- 4 Select Close Caption Options with press **OK** button then appear Digital Closed Caption
- 5 To set Digital Closed Caption Automatic/ Custom with press **OK** button.
- 6 In Custom of Style you can select Digital Closed Caption item with (or () on the remote control.
- 7 To set Digital Closed Caption item press OK

Digital Closed Caption Style ок Size Automatic oĸ Font Automatic oĸ Text Color ΟK **Automatic** ок Text Opacity Automatic **Background Color** Automatic oĸ **Background Opacity** oĸ Automatic Edge Effect Automatic oĸ Edge Color ок Automatic

0

Audio

Off

Feature

OK

OK

ок

OK

OK





Notes

DCC Setup

Style: Automatic - Set by Broadcasting Custom - Set by User DCC Setup

Size: Normal, Small, Large. Font: Default. Font1 ~ Font7.

Text Color: Black, White, Red, Green, Blue,

Yellow, Magenta, Cyan.

Text Opacity: Solid, Flashing, Transparent,

Translucent

Background Color: Black, White, Red, Green,

Blue, Yellow, Magenta,

Cyan.

Background Opacity: Solid, Flashing,

Transparent, Translucent.

Edge Effect: None. Raised. Uniform.

Leftshadow, Rightshadow.

Edge Color: Black, White, Red, Green, Blue,

Yellow, Magenta, Cyan.

Feature (PC)

In PC mode, you can adjust the H, V-Position, Divide, Native Mode and Phase. Also you can adjust them automatically.

PC Set

You can change H, V-Position, Clock and Phase in PC mode like usual PC TV. You can also adjust them automatically. (Auto adjust function.)


- **1** Press Menu button on the remote control to display the main OSD menu.
- 2 Select the Feature main menu with button on the remote control.
- **3** Press **1** button to enter the sub menu.
- 4 Select PC Set menu with (1) button on the remote control.
- **5** To enter Time Set Menu, press **OK** button.

■ PC Setting Menu

- 1 Press button to enter the sub menu.
- 2 Select H-Pos/V-Pos/Clock/Phase menu with (**) button on the remote control.
- 3 Into the adjust, press **OK** and then set with button on the remote control.
- **4** To cancel all adjust, select press **Preset** button.

For a more detailed description of these settings, see the next page.







■ H-POSITION





V-POSITION





■ PHASE





Mismatch


Match

Notes

• In adjust you can move directly each adjust menu with press 🗘 🚺 button.

■ Auto Adjust

- 1 Press 🕒 button to enter the sub menu.
- 2 Select Auto Adjust menu with button on the remote control.
- **3** Set the Auto Adjust, press **OK** and then appear progress message.



Troubleshooting ///

Before you call a service technician, please scan this list of problems and possible solutions. It may save you time and money.

Problem	Quick Action for Possible Solution.
No picture & No sound	Check whether the TV is turned on. Power cord inserted into wall outlet? Plug another product's power cord into the wall outlet where the TV's power cord was plugged in.
Picture OK & No sound	Press the VOLUME(▶) button. Check the audio input signal.
The remote control doesn't work	Check to see if there is any object between the Plasma Display and the remote control causing obstruction. Check to see if the batteries are installed with the wcorrect polarities.
Digital broadcasting screen problem	Check the digital signal strength and input antenna.
No or Poor color or Poor picture	Select color in the Picture and press VOLUME(▶) button. Keep a certain distance between the TV and the VCR. Activate any function to restore the brightness of the picture. Check to see that both the TV and the source are plugged in and turned on.
The image is too light or too dark	Adjust the Brightness or Contrast settings.
The image is too large or too small	Adjust the Size settings.
No output from one of the speakers	Adjust Balance in the Sound Menu.
Strange sound form the TV	Typical sound due to normal TV operation, TV is not faulty.



Specification – 17.1 Inch LCD

17.1" LCD TV		
Function and Display Specification		
Display Size	17.1-Inch 16 : 9 Diagonal Screen	
Display Mode	Variable 4 Modes (4:3 Mode/ 16:9 x 3 Modes)	
Pixel Format	1280 x 768 Physical Pixel	
Contrast Ratio	600:1	
Brightness	450 cd/m ²	
Max Input Resolution	1280 x 768 / 60Hz	
Input Compatible	Multiple input compatible	
Video	Advanced motion digital/Motion-Adaptive De-interlace process, Digital progressive line scaling.	
Tuner Module	TV/CATV (ATSC)	
Programming	Favorite channel programming, Time Set, Set the Sleep timer	
HDTV Input	480i/p (60Hz), 576ip (50Hz), 720p (60Hz), 1080i (50, 60Hz)	
Color Temperature	Selectable 3 Mode (Warm, Normal, Cool)	
Dimension / Weight		
Main Only	1216 (W) x 732 (H) x 87.3 (D) / 50 kg	
With Stand	1216 (W) x 798 (H) x 299 (D) / 55 kg	
With Stand and Speaker	1416 (W) x 798 (H) x 299 (D) / 59 kg	
Miscellaneous		
Audio	Built-in amplifier and two speaker (7Watt/Typ.) systems (optional), Selectable fixed/variable audio output (optional)	
External Control	Front OSD Button Control, Remote control, RS232C Control	
Power Consumption		
Input Power	DC +18 External Power Adapter	
Power Consumption	54 Watt	
Connectivity		
TV1, 2 Input	RF/CATV (ATSC)	
Composite Input	RCA x 1Port (AV Input)	
S-Video Input	Mini Din 4Pin x 1Port	
PC Input	Mini D-Sub 15Pin x 1Port	
Audio Input	Phone Jack x 1Port	
Speaker Output	Cinch Type x 4Port (Stereo L/R)	
External Control Port	Phone Jack x 1Port	
HDMI Port	HDMI x 1Port	
SPDIF Port	SPDIF (Optical) x 1Port (5.1 Channel)	

2- Year Limited Warranty

Warranty Service is only available in the country of original purchase. This is an important document. Attach your bill of sale to this card and keep it in a safe place. Your bill of sale is your warranty.

Our warranty remains in effect for two years from the date of the first consumer purchase.

WHO IS PROTECTED BY THIS WARRANTY

Our warranty protects the original owner and all subsequent owners, provided that our product was purchased from an authorized dealer.

A copy of the original dated bill of sale must be presented whenever warranty service is required.

WHAT IS COVERED BY THIS WARRANTY

Except as specified below, the warranty covers all defects in material and workmanship. The following are not covered: damage caused by accident, misuse, abuse, product modification or neglect; damage occurring during shipment; damage from failure to follow instructions contained in the instruction manual; damage resulting from the performance of repairs by someone not authorized by us; damage by natural disaster such as lightening, flood etc.; damage caused by installation of parts that do not conform to the specification; units used for other than home and office use; units not used for their intended purpose; any claims based on misrepresentations by the seller; products sold on an "as-is" or final sales basis; or the cost of installing, removing, or reinstalling the unit. Our liability is limited to the repair or replacement, at our option, if any defective product and shall not include incidental or consequential damages. We reserve the right to replace a discontinued model. Any replacement units or parts may be new or rebuilt.

TO OBTAIN WARRANTY SERVICE

For U.S. and Canada if you require warranty service, please contact Premium Distribution Corp. Authorized Support Provider at 866-734-1200.