

User Manual

FX-850C/FX-852C

Dual band Wireless Local Loop Phone

(Back cover)

Motorola, the Stylized M Logo, and other Motorola trademarks and trade dress are

owned by Motorola, Inc. and are used under license from Motorola, Inc. $\,$

MOTOROLA and the Stylized M Logo are registered in the U.S. Patent &

Trademark Office. All other products or service names are the property of their

respective owners. © Motorola, Inc 2006. All rights reserved.

The information contained in the FX-850C user guide is believed to be correct at

the time of printing. We reserve the right to change or modify any information,

product specifications, features or functionality without notice. The contents of the

 $\ensuremath{\mathsf{FX-850C}}$ user guide are provided "as is." Certain features may not be activated by

your service provider, and/or their network settings may limit the feature's

functionality. Additionally, certain features may require a subscription. Contact your

service provider for details.

FX-850C User Guide version 1.0 08/03/2007

© Copyright 2007, Motorola Inc., All rights reserved

2

USER'S GUIDE

This page is intentionally left blank

WELCOME

Congratulations on the purchase of your Motorola FX-850C product!

Please retain your original dated sales receipt for your records.

For warranty service of your Motorola FX-850C product, you will need to provide a

Thank you for choosing a Motorola product.

Please read important safety instructions before use.

copy of your dated sales receipt to confirm warranty status.

Read and understand all instructions before use.

Please retain this guide for future reference.

Index

1. PREPARING YOUR PHONE FOR USE	10
1.1. PLUGGING THE AC/DC ADAPTOR	10
1.2. SIM CARD AND BATTERY	10
1.3. COMBINING BELT CLIP	
2. FEATURE HIGHLIGHTS	14
3. ABOUT THE PHONE	15
3.1. THE FX-850C PHONE	15
3.2. KEY FUNCTIONS	15
3.2.2. Send key	16
3.2.3. End key	
3.2.4. Numeric Keys	
3.2.5. Scroll keys	16
3.2.6. Using the selection keys	
3.2.7. Using the scroll keys	16
3.2.8. Opeaker button	16
3.3. DISPLAY INDICATORS AND ICONS	
3.3.1. Start screen	17
3.3.2. Scroll bar	17
3.4. IDENTIFIERS	17
4. BASIC OPERATIONS	19
4.1. SWITCHING THE PHONE ON AND OFF	19
4.2. MAKING A CALL	19

4.3. Answering a call.	19
4.4. SPEAKER MODE.	19
4.5. ADJUSTING THE VOLUME	20
4.5.1. Adjusting the ringer volume	20
4.5.2. Adjusting earpiece volume	20
4.6. REDIALING THE LAST-DIALED NUMBER	20
4.7. CALLER ID	21
4.8. SMS AND VOICE MAIL	21
5. USING PHONE MENUS	21
5.1. NAVIGATE MENUS	21
5.1.1. Scrolling through menus	22
5.1.2. Exiting menu levels	22
5.2. MENU TREE	22
6. ENTERING LETTERS AND NUMBERS	26
6.1. Entering Letters	26
6.1.1. Editing name or phone number	26
6.1.2. Changing the case of letters and numbers	27
7. USING THE PHONEBOOK	28
7.1. USING THE PHONE BOOK	28
7.2. USING PHONE BOOK MENUS	28
7.3. BROWSE (BY NAME)	29
7.4. ADDING A NEW PHONE BOOK ENTRY	29
7.5. MEMORY STATUS	30
7.6. SPEED DIAL	• •
7.0. SPEED DIAL	30

7.8 DELETE ALL ENTRIES	31
7.9 GROUP	31
7.10. My Number	32
8. SENDING AND RECEIVING TEXT MESSAGES	33
8.1. WRITE MESSAGE	34
8.2. INBOX	34
8.3. OUTBOX	34
8.4 Drafts	35
8.5. Using Voicemail (Network Service)	35
8.6. Broadcast Message	36
8.7. Message Setting	36
8.8. TEMPLATES	36
8.9 Memory Status	37
9. CALL RECORD	38
9.1. CHECKING INCOMING/OUTGOING/MISSED CALL	38
9.2. DELETING CALL LOG	39
9.3. CALL DURATION	39
10.1. PHONE SETTINGS	40
10.1.1. Clock setting	40
10.1.2. Language	41
10.1.3 Answer Mode	
10.2 CALL SETUP	
10.2.1. Call Divert	42
10.2.2. Call Barring (Network Service)	
10.2.3. Call waiting (Network service)	
10.2.4. Auto Redial	

10.2.5. Caller ID	44
10.3. NETWORK SETUP	44
10.3.1. Network Select mode	44
10.4. SECURITY SETUP	45
10.4.1. Phone Lock	45
10.4.2 Change Password	45
10.5. FACTORY DEFAULT	46
11. TONE	47
11.1. TONE SETUP	47
11.2 VOLUME	47
11.3. RING TYPE	47
12. DISPLAY	48
12.1 IDLE DISPLAY	48
12.1.1 Clock and Date	48
12.2.2 Idle Text	48
12.2 CONTRAST	48
12.3 LCD BACKLIGHT	48
13. ACCESSORIES	49
13.1 ALARM	49
13.2. CALCULATOR	50
13.3 CALENDAR	51
14. TECHNICAL INFORMATION	52
14.1. SPECIFIC ABSORPTION RATE DATA	52
14.2 TECHNICAL SPECIFICATION	53


15. SAFETY INFORMATION	54
15.1 EXPOSURE TO RADIO FREQUENCY (RF) ENERGY	54
15.2 OPERATIONAL PRECAUTIONS	54
15.3 EXTERNAL ANTENNA CARE	54
15.4 PHONE OPERATION	55
15.5 DATA OPERATION	55
15.6 APPROVED ACCESSORIES	55
15.8 MEDICAL DEVICES	55
16. WARRANTY	58
16.1 PRODUCTS COVERED	58
16.2 EXCLUSIONS	58
17. REGULATORY	62
18. FCC NOTICE TO USERS	63

1. PREPARING YOUR PHONE FOR USE

Before using your phone, the phone must be set up according to the following instructions.


1.1. Plugging the AC/DC adaptor


- Connect the adaptor to the AC Wall outlet.
- Insert the adaptor plug into the DC jack of the cradle.



1.2. SIM Card and battery

- Remove the battery door.
- Insert SIM card into the SIM slot in the right direction
- · Insert battery in the right direction
- Replace the battery door.





Be sure to carefully match the positive and negative terminals as shown on the battery.


Caution:

- It is prohibited to use the SIM card for this Fixed Wireless Phone in other GSM phone. Once the SIM pin number is entered, the SIM pin is automatically changed so the initial PIN is no longer valid. Therefore, it is highly recommended
 NOT to take out the SIM card once it is installed in this product.
- **DO NOT** bend or scratch your SIM card, and avoid exposing it to static electricity, water, or dirt.

For body worn operation, this phone has been tested and meets FCC RF exposure guidelines when used with an accessory that contains no metal and that positions t he handset a minimum of 1.5cms from the body. Use of other accessories may not ensure compliance with FCC RF exposure guidelines

1.3. Combining Belt Clip

• Combine belt clip into the back of the phone until it's placed on the exact position.




2. FEATURE HIGHLIGHTS

- Dial tone generation
- Codeless Form factor
- Auto Dialing
- Voice mail
- Short Message Service
- Emergency call
- Call logs
- Call restriction
- Caller ID
- Alarm clock
- Calculator
- Graphic display
- Blue back light for LCD and keypad
- Multi-ring tone
- Speaker phone
- Multi-language (English, Spanish, Portuguese, It may vary by market)
- 100 Phone Book memory
- Rechargeable battery
- Belt Clip

3. ABOUT THE PHONE

This phone can operate in different bands (depending on the service provider). It supports dual band(850MHz/1900MHz).

3.1. The FX-850C Phone



3.2. Key functions

3.2.1. Menu / Selection / Name key

- Press the left key **Menu** to perform the function indicated by the text on the screen above the key.
- Press the right key **Phonebook** to directly access the Phone Book list.



- Press to make a call to a name / number shown on the screen.
- · Press to answer a call.
- Press and hold for 2 seconds to access the list of recently dialed numbers.

3.2.3. End key

- · Press to end a call.
- · Press once to exit a function and return to the start screen.

3.2.4. Numeric Keys

- Used for entering numbers and letters.
- · Press and hold to call the voice mailbox.
- Press to toggle between upper case, lower case and numeric modes.
- Press to toggle between letters and symbols.

3.2.5. Scroll keys

- Press to increase the earpiece and ring volume.
- Press to decrease the earpiece and ring volume.

3.2.6. Using the selection keys

The functions of the selection keys depend on the guiding text shown above the keys. For example, when the text **Menu** is above the left selection key, press the left key — enters the menu functions. Similarly, pressing the right selection key under the text **Phonebook** accesses the Phone Book functions.

3.2.7. Using the scroll keys

The phone has two scroll keys, located just below the screen.

The scroll keys have up and down arrows on them; press these to scroll through the phone's menus.

3.2.8. • Speaker button

• Turn the speaker ON and OFF in conversation mode.

3.3. Display indicators and icons

The display indicators and icons provide information about the operation of the phone.

3.3.1. Start screen

The start screen is displayed when the phone is turned ON. Several features can be used only when the phone is at the start screen.

3.3.2. Scroll bar

When you access the phone's menu, there is a scroll bar at the far right of the screen. This bar indicates the user's location in the menu: each "tab" on the bar represents a different menu item.



3.4. Identifiers

On your phone, you have two types of identifiers: indicators and icons. Icons are graphic representations of a specific item or situation. For example, an icon appears when you have a voice message waiting.

Indicators show the status of something. The phone uses three types of indicators:

- Network indicator

- R Cannot make or receive calls
- Phone lock indicator.
- Message indicator

 - Woice message
- Alarm indicator: shows when the alarm is activated
- Mute indicator : shows when the ring-tone is silent
- Battery level indicator: Vertical bars show the battery charge level.
 - (Full) (Empty)
- Ringer volume indicator: When you press, the upper key once during standby, you are able to enter the ringer volume adjustment.
 Scrolling up and down using the key adjusts the ringer volume higher or lower.

4. BASIC OPERATIONS

4.1. Switching the phone ON and OFF

To turn on your phone, press and hold "End key" for a few seconds or until the display turns on. If prompted, enter your 4-digit PIN code.

Caution: If you enter an incorrect PIN code 3 times in a row, your SIM card is disabled and your display shows SIM Blocked. Contact your service provider.

To turn off your phone, press and hold "End key" if or a few seconds

4.2. Making a call

- 1) Enter phone number which you want to call.
- 2) Press "Call key" (2) to make a call.

Tip: In some menus like Phonebook, Message, Call log, etc. which have individual phone number, Press "**Call key**" a directly to make a call.

4.3. Answering a call.

When your phone rings, just raise your receiver to answer, or press "Call key" or "Speaker key" to answer in speaker phone mode.

4.4. Speaker mode.

You can make or answer a phone call by pressing

- Press to turn ON the speaker phone mode.
- If you hear the dial tone, press the number you want to connect to.

Note: The call is automatically made without pressing , approximately 3

seconds after you dial the number.

To answer a call:

• When the phone rings, press to turn ON the speaker phone mode.

4.5. Adjusting the Volume



4.5.1. Adjusting the ringer volume

You can adjust the ring tone volume by pressing the scroll keys on the phone.

- 1) Press up to enter the ring volume control screen.
- 3) Press to decrease the volume.

4.5.2. Adjusting earpiece volume

You can adjust the earpiece volume during a call by pressing the scroll keys on the phone.

- 1) Press to increase the volume.
- 2) Press volume.

Note: You can also adjust the speaker volume with \(\sumsymbol{} \subseteq \subseteq \text{when you are in speaker mode.} \)

4.6. Redialing the last-dialed number

The phone stores up to 10 last dialed numbers. Stored numbers may be up to 20 digits long.

- 1) Press a for about two seconds to find the most recently dialed numbers.
- 2) Press volume to scroll to the number you wish to dial.
- 3) Press once.

Note: If no recently dialed numbers are stored, you will not be able to use this function.

20

4.7. Caller ID

Requires a subscription to a calling plan that supports this feature. Not available in all areas. Contact you telephone service provider for availability and details.

When Caller ID is active, your phone shows the caller's phone number during an incoming call, as long as this number is a part of your service provider's wireless network.

The wireless network lets you know if it does not recognize the caller's phone number.

The wireless network will also let you know if the calling party has blocked the Caller ID feature.

If you have stored the name and number of the calling party in your Phone Book and that number is supported by the wireless network, the caller's name will also appear.

4.8. SMS and Voice Mail

Requires a subscription to a calling plan that supports this feature. Not available in all areas. Contact you telephone service provider for availability and details.

A new SMS or Voice mail arrives:

- The back light of the keypad is ON and the display shows "New Message(s)" on the screen.
- The backlight is OFF if you lift the handset from the base.

5. USING PHONE MENUS

5.1. Navigate menus

A menu is a list of choices you can make. Your phone menu has 7 sub-menus.

Each submenu contains options that allow you to use the Phone Book, change the ring tone, etc.

You can use menus and sub-menus in two ways: by scrolling or by using shortcuts.

5.1.1. Scrolling through menus

- 1) From the Start screen, press **Menu**, and then scroll through the menus using the key.
- 2) Use the scroll and selection keys to navigate the submenus and to return to the Start screen.

5.1.2. Exiting menu levels

- 1) To return to the previous menu level, press Back or Cancel.
- 2) To return to the Start screen, press $\ \ \ \ \ \ \ \ \ \$. No menu setting changes will be saved.

5.2. Menu Tree

Your phone's menu may differ from the following list, depending on the network services to which you have subscribed and the accessories you are using. If you have any questions, please call your service provider.

1. Phonebook	
1. Browse	
2. Create	
1. Save to SIM	
2. Court to phone	
3. Memory Status	
4. Speed dial	
5. Copy	
1. From SIM card to phone	

2. From phone to SIM card
6. Delete all entries
Delete all Phone entries
2. Delete all SIM entries
7. Group
1. Family
2. Friends
3. Office
4. Others
8. My Number
2. Message
1. Write Message
2. Inbox
3. Outbox
4. Drafts
5. Voice Mail
1. Number
2. Erase
3. Connect to Voice Mail
6. Broadcast Message
1. Receive Mode
2. Languages
7. Message Settings
Service Center Number
2. Expire Period
3. Message Type
4. Status Report
5. Alert Period
8. Template
9. Memory Status
3. Call Records
1. Incoming Calls
2. Outgoing Calls
3. Missed Calls

4. Call Duration
Outgoing Duration
2. Incoming Duration
3. Last Duration
4. Settings
1. Phone Settings
1. Clock Settings
2. Language
3. Answer Mode
2. Call Setup
4 Oall Breat
O Call Barriag
2. Call Barring 3. Call Waiting
4. Auto Redial
5. Caller ID
[
3. Network Setup
4. Security Setup
1. Phone Lock
2. Change Password
5. Factory Default
5. Tone
1. Tone Setup
1. Incoming Call
2. Message Tone
2. Volume
1. Call
2. Ring Tone
3. Keypad Tone
3. Ring Type
1. Repeat
2. Ascending
6. Display
1. Idle Display
1) Clock and Date

	2) Idle Text	
	_	
	3. LCD Backlight	
7. Accessories		
1. Alarm		
	1. Alarm 1	
	2. Alarm 2	
	0.41.0	
2. Calcul		
3. Calend	ar	

6. ENTERING LETTERS AND NUMBERS

You can enter letters, as well as numbers, when storing information in your phone by using your phone's keypad. To enter letters, press the key associated with the letter you wish to enter until it appears on the screen (numbers will also appear).

6.1. Entering Letters

When you want to add new names or when you view names in the Phone Book, your phone automatically switches to the ABC mode and displays the ABC icon.

Key Characters Key Characters

Key	Characters	Key	Characters
1	,.?!1	7	Pqrs7β\$
2	abc2åæäàç	8	Tuv8ùü
3	def3èé	9	W x y z 9
4	g h i 4 ì	0	(Space) 0
5	jk 5£	*	,.'?!"@ ¥ \$_'~{}[] ?#
			¤ % & () * + - / : ; < = > § ¿
6	mno6öøò	#	Change letter case(*)

^{*:} abc → Abc → ABC → 123 rotated

6.1.1. Editing name or phone number

To edit a name already stored in the Phone Book:

- From the main screen, use the right soft key.
- From the Phone Book list, select the name you want to edit.
- To edit, press the left soft key and scroll down to the edit option.
- Select the name or the phone number you want to change.
- Press the left soft key to enter edit mode.
- Press to scroll the cursor to the left.

- Press to scroll the cursor to the right.
- Press Delete to correct any mistakes.
- Press the left soft key **OK** to save changes or the right soft key to cancel.

6.1.2. Changing the case of letters and numbers

You can switch the mode among uppercase and lowercase letters and numbers by pressing # key.

7. USING THE PHONEBOOK

7.1. Using the Phone Book



New entries can be stored in the SIM card or in your handset.

You can store up to 100 entries in the phone and an additional 100 in the SIM depending on the SIM limitations.

Entries stored in the phone allow numbers of up to 30 digits, and names of up to 16 characters.

In standby mode, you can press right Phonebook to immediately access the Phone Book list.

When the number is found by pressing **Phonebook**, you can select it and choose to view, edit delete, copy, move or send message.

7.2. Using Phone Book menus

The Phone Book has several menus to select from. These menus appear when you press **Phonebook** and select number. Press right \(\subseteq \) move back to the main menu.

- Browse: Browse name you selected.
- Create: Create new entry(s)
- Memory Status: Memory status of phone and SIM
- Speed Dial: One button dialing
- Copy: Copy from SIM(Phone) to Phone(SIM)

28

- Delete All Entries: Delete all Phone or SIM entries
- Group: Organizing group of phone book
- My number: Inputting your own number

7.3. Browse (by name)

- : From the Phone Book menu, select Browse and press right OK or just press 1.
- : Enter the first letters of the name you need and the cursor goes to the name you wanted directly after two seconds.

Select name using to scroll and press left option to select menu. Use to scroll to the menu you want to use.

- : After choosing one of the name, you can select left $\begin{tabular}{c} \end{tabular}$ option and you can choose five sub menus
 - 7.3.1 Send Message To: You can send SMS to this entry
 - 7.3.2 View: You can see the name and number of this entry
 - 7.3.3 Delete: You can delete this entry only(You need to re-confirm)
- **7.3.4 Add to group:** You can put this entry to group(See 7.8 'Group'), but you cannot use SIM entry to a group.
- **7.3.5 Copy:** If you select a SIM card's entry and select **Copy**, you can copy it to phone memory. If your selection is Phone memory's entry, **Copy** means copy chosen entry to SIM card

7.4. Adding a new Phone Book Entry

To create a Phone Book entry:

- 1) Press Menu > Phone Book > Scroll to Create and press OK
- Press Save To SIM or Save To Phone depending on where you want to store the phone entry.
- 3) Select 'Name', Press left Option and choose Edit.
- 4) Add Name

5) Press left Option and select Accept to complete input.
6) Select 'Number', Press left Option and choose Edit.
7. Add Number
8. Press left Option and select Accept to complete input.

7.5. Memory Status

: To press 'Storage Status' and you can see the SIM card Total / SIM card used and NVM Total capacity

7.6. Speed Dial

- 1) Press Menu > Phone Book.
- 2) Scroll to Speed Dial and press OK
- Select one entry. If the numbers are Empty, Press OK > Select Set/Change and press OK, you can assign one phone number. After choosing one, press OK
- 4) If you assigned one phone number already, you can see four sub categories
 - Set/Changes: You can change the assigned number
 - Detail: You can see the number of this entry
 - Delete: You can delete this entry
 - Dial to: You can dial to this entry
- : You can use only phone entries (No SIM entries)
- : You can use appoint 8 entries.
- : On the idle display, press one assigned button and press Call button Ex> If the number assigned in 2 is 022-334-5567, just press 2 and

7.7. Copy

You can use this function to copy numbers from the SIM card to your fixed phone, 30

or vice versa:

- 1) Press Menu > Phone Book.
- 2) Scroll to Copy and press OK
- Press From SIM card to phone or From Phone to SIM Card depending on where you want to copy all Phone Book entries.
- 4) Press OK then the copy process is done promptly

7.8 Delete All Entries

You can delete all Phone Book entries:

- 1) Press Menu > Phone Book
- 2) Scroll to Delete all Entries and press OK
- Press Delete All Phone Entries or Delete All SIM Entries, depending on where you want to delete all Phone Book entries.
- 4) Press **OK** to confirm the deletion of all Phone Book entries.
- Select Yes if you want to delete. Otherwise, select No to go back to the previous menu.

Caution: When complete all information stored in your Phone Book will be deleted and can no longer be restored.

7.9 Group

- : You can see four groups 1) Family 2) Friends 3) Office 4) Others
- : Select one and press left OK and you can see the sub menus
- : In one group, you can select three sub menus
 - 7.8.1 Group Member: You can see entry(s) belongs to the group
 - **7.3.2 View:** You can edit the name of this group itself (Ex> Family → Home)
- **7.3.3 Alert Tone:** You can change the tone when the member of this group called you.

7.10. My Number

You can check, edit, erase and save your owner number

- 1) Press Menu > Phone Book
- 2) Scroll to **My number** and press **OK**.

8. SENDING AND RECEIVING TEXT MESSAGES



Requires a subscription to a calling plan that supports this feature. Not available in all areas. Contact you telephone service provider for availability and details.

You can send or receive text messages with your phone. Text messages that you receive may contain ring tones that you can store in your phone. It supports 160 characters and you can insert Use Template (already 10 sentences are recorded in your phone) to shorten the editing time.

You can also send maximum 480 characters. If your message is 480 characters, the phone divides your message into three parts(160 + 160 + 160) and send these in each time. This function is called SMS concatenation.

After completing the message content, you can choose to send it out right away, or save it as a draft.

- 1. Write Message
- 2. Inbox
- 3. Outbox
- 4. Draft box
- 5. Voice Mail
- 6. Broadcast Message
- 7. Message Settings
- 8. Template
- 9. Memory Status

8.1. Write Message

You can send a text message to one recipient. You can manually enter each recipient's phone number, or you can select the numbers from the Phone Book.

Note: The maximum length of a text message differs, depending on the capabilities of the network from which it originated. Also, text messages may appear different at different times because messages can originate in networks other than your own. Contact your service provider for more information about this feature.

- 1) Press Menu > Short Messages.
- 2) Scroll to Write Message and press OK
- 3) You can create the message.
- 4) When you press **OK**, you can see three submenus;
 - Only Send: After sending, the message is deleted
 - Only save: No sending. The message is saved into Drafts.
 - Send and Save: After sending the message is saved into Outbox

8.2. Inbox

When a message arrives, a pop-up message is displayed and a new message icon appears. You can read it immediately, or read it later in your Inbox. You can see the icon \boxtimes

8.3. Outbox

The Outbox stores messages sent and saved.

- 1) Press Menu > Short Messages.
- 2) Scroll to the Outbox and press OK.

34

- 3) From the list, highlight the one you need and press OK.
- 4) You can choose four options
 - Forward: You can send the chosen message.
 - Edit: You can edit the chosen message.
 - Delete: You can delete the chosen one.
 - Delete All: You can empty the Out box

8.4 Drafts

: You can see draft messages which you already saved. After choosing one of them, you can have five choices

- Forward: You can send the chosen message.
- Edit: You can edit and save the chosen message.
- Delete: You can delete the chosen one.
- Delete All: You can empty the draft box.

8.5. Using Voicemail (Network Service)

You can listen to your voicemail messages by calling your network voicemail phone number. Voicemail messages are stored in the network voicemail box, not in your phone.

- 1) Press MENU > Short Messages.
- 2) Scroll to Voice Mail and press OK.
- 3) There are three submenus. Select one and press OK
 - Number: Enter or modify the network service number.
 - Delete: Delete Pre-saved service number
 - Connect to Voice Mail: Dial the network service number and connect to the Voicemail Server.

8.6. Broadcast Message

There are 2 submenus you can choose

- 1) Receive Mode
- 2) Languages

8.7. Message Setting

There are 5 submenus you can choose

- Service Center Number: The SMS Center Number is required in order to send messages. Ask your service provider for this number.
- 2) Expire Period: Set the period of time the message is stored in the service center. You can set the period for 1 hour, 12 hours, 1 day, 1 week, maximum. When the set period expires, the service center will delete all messages, even if the user has not received the message.
- Message Type: When you set the message type, the network will convert the message to the type you have set. (Text//Fax//E-mail)
- Status Report: If you turn On this option, you can be notified if the recipient read your message.
- 5) Alert Period: you can choose one time // Every 2 min // Off

Note: After the SMS memory in the SIM card is full, the phone starts using the memory in the phone.

8.8. Templates

You can see ten (10) pre-saved texts.

- I'm busy now. I will call you later
- How are you?
- How about Lunch?
- I'm sorry!

- Long time, no see!
- I arrived safely
- Happy Birthday
- Happy New Year!
- Thank you!
- I will be there soon!

: You can select left Option (Edit/Forward)

- Edit: You can modify pre-saved texts
- Forward: You can send selected text to others

8.9 Memory Status

: Check memory status in the SIM and in the Phone. The total capacity of SIM is 20, total capacity of phone is 100. Also you can see used area of SIM and phone.

9. CALL Record



The Call History function keeps track of:

- Incoming Calls
- Outgoing Calls
- Missed Calls
- Call Duration

Note: Your phone can store up to 30 call numbers including missed, received and dialed calls.

When you miss a call(s), the Missed Calls icon appears on your phone's screen. You can press Read to view the Missed Calls list or press Back to ignore the message and go back to Standby. The records will be stored in Call History.

You are notified of missed calls only when your phone is turned ON in the service area from which the missed call originated.

9.1. Checking Incoming/Outgoing/Missed Call

- 1) Press Menu > Call Records
- 2) Select Incoming // Outgoing // Missed Call and press OK
- 3) From the list of records, select the one you need and press OK
- The screen shows Call Information including Number, Date and Time of receiving.

Note: In Standby, the icon indicates there are unread missed call records.

9.2. Deleting Call Log

You can choose to delete Missed Calls, Dialed Calls or Received Calls and Delete All when you have any call log.

- 1) Press Menu > Call Records
- 2) Choose one of them;
- 3) Incoming call 2) Outgoing call 3) Missed call and press OK
- 4) You can press left Option
- 5) You can see six different menus
 - Dial To: When you choose one entry and select OK, directly calls to.
 - Send Message To: You can send this entry the SMS message without selecting recipient.
 - Delete: You can delete chosen entry
 - Save Number: You can save chosen number to SIM or Phone.
 - Delete all: You can delete all entries in the category (If you select
 Outgoing call all the Outgoing call entries are deleted)
 - Show Number: You can see the number of chosen entry

Caution: Note that this action cannot be undone once you perform it. All the stored information in your log will be deleted.

9.3. Call Duration

- : You can check the total duration of incoming call and last call duration
- : You can see **Outgoing Duration**, **Incoming Duration** and **Last Call Duration** in one display.
- : The type of checking time is hh:mm:ss (h: Hours, m: Minute, s: Second)
- : You can press left Reset to erase all call duration time.

10. SETTINGS



Setting menu includes:

- Phone Settings
- Call Setup
- Network Setup
- Security Setup
- Factory Default

10.1. Phone Settings

10.1.1. Clock setting

- 10.1.1.1 This menu guides you to set Time/Date.
 - Set Time/Date Set the correct time and date to ensure the Alarm is working correctly.
 - Setting Time / Date:
 - 1) Press Menu > Settings
 - 2) Press Phone Settings and press OK.
 - 3) Select Clock Settings then press OK.
 - 4) Select Date & Time setting and press **OK**.
 - 5) Input day/month/year by using numeric keys and press option
 - 6) Select **Time setting** and input hour/minute
 - 7) Press option and select Save
- 10.1.1.2. Date Display format: There are four types of expressions of dates

40

- DD/MM/YY(day/month/last two digits of this year)
- MM/DD/YY
- DD/MM/YYYY(day/month/full digits of this year)
- MM/DD/YYYY

10.1.1.3 Date Separator: There are four types of separators of date digits

- OO-OO-OO (Hyphen)
- OO/OO/OO (Slash)
- OO.OO.OO (Dot)
- OO OO OO (Blank)

10.1.1.4 Time Display format: You can choose 12h or 24 hours. For example, if the time is 1:22 pm(12h expression), it can be shown as 13:22 (24h expression)

10.1.2. Language

Three languages can be selected: English / Spanish / Portuguese. Also you may choose automatic option. Your native language can be chosen without manual selection.

- 1) Press Menu > Settings
- 2) Press Phone Settings and press OK
- 3) Select Language and then press OK
- 4) Select the language you need and press **OK**

10.1.3 Answer Mode

- Normal answer: After picking up the handset, you have to press
 answer key (2) to call
- Any key answer: To answer your receiving call, you can press any key except End key

10.2 Call Setup

The following features may require a subscription to a calling plan that supports

Not available in all areas. Contact you telephone service provider for availability and details

10.2.1. Call Divert

Call Divert is a network or subscription dependent service. It allows you to forward a call to another number, based on various conditions.

- 1) Press Menu > Settings
- 2) Press Call Setup and press OK
- 3) Press Call Divert and press OK
- 4) Select one of the options below, and then press OK
 - All Voice Calls Divert: All incoming calls to a designated number
 - On Busy: Divert all incoming calls when there is at least one call in progress.
 - No Answer: Divert the incoming call if it is not answered
 - Unreachable: Divert all incoming calls when the phone is not reachable due to a network error or some other reason.
- 5) Select Check Status, Activate, or Deactivate and press OK
 - Check Status: Check current Call Divert setting status.
 - Activate: Activate the chosen Call Divert option. Type the number you want a call to be forwarded to.
 - Deactivate: Deactivate the chosen Call Divert option.

10.2.2. Call Barring (Network Service)

Call Barring is a network or subscription dependent service.

42

This feature allows you to restrict or bar certain or all types of calls to and from your phone.

- 1) Press Menu > Settings
- 2) Press Call Setup and press OK
- 3) Press Call Barring and press OK
- 4) Select one of the options below, and then press OK
 - All Outgoing Calls: Bar all outgoing calls.
 - All Int'l Calls: Bar all outgoing international calls.
 - Int'l Except to Home: Prevent users from making any international calls other than to home
 - All Incoming Calls: All Calls Bar all incoming calls.
 - Incoming While Roaming: Bar all incoming calls when the phone is roaming.
- 5) Select Activate, Deactivate or Query Status, and press OK
 - Check Status: Check current Call Barring setting status.
 - Activate: the chosen Call Barring option.
 - Deactivate: the chosen Call Barring option.

Note: To activate and deactivate Outgoing, Incoming, and Cancel Calls, the SIM password is required. Contact your cellular phone provider.

10.2.3. Call waiting (Network service)

Call Waiting is a network or subscription dependent service.

If set to Activate, the Call Waiting feature enables the network to remind you of other incoming calls during a call in progress.

- 1) Press Menu > Settings
- 2) Press Call Setup and press OK
- 3) Press Call Waiting and press **OK**
- 4) Select Activate, Deactivate or check, and then press OK

- Active: Activate Call Waiting function.
- Deactivate: Call Waiting function.
- Check Status: Check current Call Waiting setting status.

10.2.4. Auto Redial

Setting the Auto Redial to ON enable the phone to keep dialing if the called party is not available.

- 1) Press Menu > Settings
- 2) Press Call Setup and press OK
- 3) Press Auto Redial and press OK
- 4) Toggle ON or OFF, and then press OK

10.2.5. Caller ID

Caller ID is a network or subscription dependent service.

You can choose to send/hide your phone number to/from the calling party.

- 1) Press Menu > Settings
- 2) Press Call Setup and press OK
- 3) Press Caller ID and press OK
- 4) Toggle Set by Network, Hide Number or Show Number and then
- 5) press OK
 - Set By Network: Accepts the default value set by Network.
 - Hide ID: Does not show your phone number to the calling party.
 - Show ID: Shows your phone number to the calling party.

10.3. Network Setup

10.3.1. Network Select mode

You can set the phone to automatically search the most suitable network to camp

44

on or to manually select the network you need.

- 1) Press Menu > Settings.
- 2) Press Network Setup and press OK
- 3) Press Network Select mode and press OK
- 4) Select Automatic selection or Manual selection and then press OK
 - Manual mode: The phone starts searching available networks. Use the up and down key to browse the network list, and press OK to set the highlighted network.

10.4. Security Setup

There are two options available:

- Phone Lock: Prevent unauthorized use of the phone.
- Change Password: Change by inputting the password two times

10.4.1. Phone Lock

The default password is "0000".

- 1) Press Menu > Settings
- 2) Press Security Set Up and press OK
- 3) Press Phone Lock and press OK
- 4) When 'On' is chosen, there are two options.
 - Verify when Power-on: Every time you must enter password when power on
 - Verify with new SIM: When you change SIM card, you enter the password

10.4.2 Change Password

This feature allows you to change the password.


- 1) Press Menu > Settings
- 2) Press Security Setup and press OK
- 3) Press Change Password and press OK
- 4) You need to input three times. Old password, the new password and confirmation. Every time you enter the input, press **OK**

10.5. Factory Default

This feature resets the current settings to the factory default values. The default phone code is "0000".

- 1) Press Menu > Settings
- 2) Press Call Setup and press OK
- 3) Enter the 4-digit password and press OK

11. Tone



11.1. Tone setup

Set tones for Incoming Call and Message Tone.

Note: For each tone setup, you can choose one of 10 singing ring tones and 4 MIDI tones.

11.2 Volume

Eight volume levels are available for Call, ring tone and keypad tone. Adjust the volume to your preference.

11.3. Ring Type

You can set the ringer to play repeatedly or to play in ascending volume mode.

- 1) Select Ring Type and press OK
- 2) Toggle Ring Once or Repeat ring and press OK

12. Display



12.1 Idle Display

12.1.1 Clock and Date

When you choose **Enable**, you can see the date and clock on your idle display

12.2.2 Idle Text

When you choose **Enable**, you input your own text which will be shown on the idle display.

12.2 Contrast


There are 21 levels for LCD contrast. Press then the contrast goes up. Press then the contrast is down

12.3 LCD Backlight

Set Specific LCD and Keypad Backlight time.

- 1) Select LCD Backlight and press OK
- 2) Toggle Always off, 5 sec, 15 sec, 30 sec or 45 sec and press OK

13. Accessories



Accessories includes:

- Alarm
- Calculator
- Calendar

13.1 Alarm



When alarm is set, the icon appears on the standby screen.

- 1) Press Menu > Accessories and press OK
- 2) Select Alarm and press OK
- 3) Select Alarm 1, 2 or 3 and Press OK
- 4) Select Option > Edit and press OK
- 5) You can select four cases. Off//One time // Mon~Fri // Everyday. Select your favorite and press **OK**
- 6) After selecting one type, you go back to previous display.
- 7) Press and press Option

- 8) Press Edit and OK
- 9) You can select time. Use your numeric key. After finishing input, press OK
 - 10) Press and press **Option** to choose Alarm ring. You can select three different rings.

13.2. Calculator

You can calculate 9 digits.

Key description:

+, -, /, x: Use up and down arrow keys to select.

Back: Press once to clear one digit.

- 1) Press Menu > Accessories and press OK
- 2) Select Alarm and press OK
- Enter the first value by number keys



Select the calculating mark by the upper/lower navigation key



The calculating mark will toggle among $lackbox{1.5}$, $lackbox{1.5}$, $lackbox{1.5}$

Enter the second value by number keys



 Press left to display the result of calculation. And you can continue the next calculation from step3.

13.3 Calendar

- 1) Press Menu > Accessories and press OK
- 2) Select Calendar and press OK



14. TECHNICAL INFORMATION

14.1. Specific Absorption Rate Data

This wireless phone meets the government's requirements for exposure to radio waves.

Your wireless phone is a radio transmitter and receiver. It is designed and manufactured not to exceed limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission (FCC) of the U.S. Government. These limits are part of comprehensive guidelines and establish permitted levels of RF energy for the general population. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons, regardless of age or health.

The exposure standard for wireless fixed phoned employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limits set by the FCC are 1.6W/kg. Tests for SAR are conducted using standard operating positions accepted by the FCC with the phone transmitting as its highest certified power level in all tested frequency bands.

Although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station, the lower the output power.

This phone was tested and certified that it does not exceed the limit established by each government for safe exposure. The tests are performed in positions and locations (worn on the body) reported to the FCC. The highest SAR values for this model phone when tested for use on the body were 1.42 W/kg (GSM band 1900)

MHz or 900 MHz), While there may be differences between the SAR levels of various phones and at various positions, they all met the governmental requirements for safe exposure. Please note that improvements to this product model could cause differences in the SAR value for later products; in all cases, products are designed to be within the guidelines.

14.2. Technical Specification

Weight	Handset: 156.1g (0.344 lbs)
	Base: 555g (1.22 lbs)
Size	Handset: 47 x 199 x 38mm(7.8" x 1.85" x 1.49")
	Base: 207.7 x 192 x 45mm(8.17" x 7.55" x 1.77")
	(Antenna adds 20mm(0.78") to the width)
Wireless Network	GSM 850 & 1900
Frequency Range	824 ~849MHz
	1850 ~1910MHz
Backup Battery	Rechargeable battery pack.

15. SAFETY INFORMATION

SAFETY INFORMATION FOR FIXED PHONES
IMPORTANT INFORMATION ON SAFE AND EFFICIENT OPERATION.
READ THIS INFORMATION BEFORE USING YOUR PHONE.

15.1 EXPOSURE TO RADIO FREQUENCY (RF) ENERGY

Your phone contains a transmitter and a receiver. When it is ON, it receives and also sends out radio frequency (RF) signals. When you communicate with your phone, the system handling your call controls the power level at which your phone transmits.

Your Motorola phone is designed to comply with local regulatory requirements in your country concerning exposure of human beings to RF energy.

15.2 OPERATIONAL PRECAUTIONS

To assure optimal phone performance and make sure human exposure to RF energy is within the guidelines set forth in the relevant standards; always adhere to the following procedures.

For body worn operation, this phone has been tested and meets FCC RF exposure guidelines when used with an accessory that contains no metal and that positions the handset a minimum of 1.5cms from the body. Use of other accessories may not ensure compliance with FCC RF exposure guidelines

15.3 EXTERNAL ANTENNA CARE

Use only the supplied Motorola approved antenna. Unauthorized antennas, modifications, or attachments could damage the phone.

Do NOT hold the antenna when the phone is IN USE. Holding the antenna affects call quality and may cause the phone to operate at a higher power level than needed. In addition, use of unauthorized antennas may result in non-compliance with the local regulatory requirements in your country.

15.4 PHONE OPERATION

When placing or receiving a phone call, hold your phone as you would a wireless telephone.

To maintain compliance with RF energy exposure guidelines, ensure the phone antenna is at least 8 inches (20 centimeters) from your body when transmitting.

15.5 DATA OPERATION

When using any data feature of the phone, with or without an accessory cable, position the phone antenna at least 8 inches (20 centimeters) from your body.

15.6 APPROVED ACCESSORIES

Use of accessories not approved by Motorola, including but not limited to batteries and antennas, may cause your phone to exceed RF energy exposure guidelines.

15.7 RF ENERGY INTERFERENCE / COMPATIBILITIES

Note: Nearly every electronic device is susceptible to RF energy interference from external sources if inadequately shielded, designed, or otherwise configured for RF energy compatibility. In some circumstances your phone may cause interference.

15.8 MEDICAL DEVICES

Pacemakers

Pacemaker manufacturers recommend that a minimum separation of 8 inches (20centimeters) be maintained between the fixed wireless phone and a pacemaker.

Persons with pacemakers should:

- Always keep the phone more than 8 inches (20 centimeters) from your pacemaker when the phone is turned ON.
- Turn OFF the phone immediately if you have any reason to suspect that interference is taking place.

Hearing Aids

Some digital wireless phones may interfere with some hearing aids. In the event of such interference, you may want to consult your hearing aid manufacturer to discuss alternatives.

Other Medical Devices

If you use any other personal medical device, consult the manufacturer of your device to determine if it is adequately shielded from RF energy. Your physician may be able to assist you in obtaining this information.

BATTERIES

Batteries can cause property damage and / or bodily injury such as burns if a conductive material such as jewelry, keys, or beaded chains touches exposed terminals. The conductive material may complete an electrical circuit (short circuit) and become quite hot. Exercise care in handling any charged battery, particularly when placing it inside a pocket, purse or other container with metal objects. Use only original batteries and chargers.

Your battery or phone may contain symbols, defined as follows.



Important safety information will follow



Your battery or phone should not be disposed of in a fire



Your battery or phone may require recycling in accordance with local laws. Contact your local regulatory authorities for more information.



Your battery or phone should not be thrown in the trash

Please don't use any damaged battery or charger and use the battery only for its intended purpose.

Don't apply extreme shock to the battery. It's dangerous to disassemble a battery or to apply extreme shock to the battery via nail or heavy metal objects.

Keep the charger or batteries out of reach of small children or babies. Please instruct children the proper ways of handling phone during usage.

Shock circuit and breakdown may occur and cause severe danger to user due to improper usage.

Always try to keep the battery between -10 \sim 55 Celsius.

Use only manufacturer approved rechargeable batteries and charger designated for this devise

Seizures / Blackouts

Some people may be susceptible to epileptic seizures or blackouts when exposed to flashing lights, such as when watching television or playing video games. These seizures or blackouts may occur even if a person never had a previous seizure or blackout.

If you experienced seizures or blackouts, or if you have a family history of such occurrences, please consult with your doctor.

16. WARRANTY

Limited Warranty for Personal Communication Products, Accessories and Software. What Does this Warranty Cover? Subject to the exclusions contained below, BRIGHTSTAR warrants the Motorola branded FX-850C that it manufactures ("Products"), to be free from defects in materials and workmanship under normal consumer usage for the period(s) outlined below. This limited warranty is a consumer's exclusive remedy, and applies as follows to new Motorola branded Products manufactured by BRIGHTSTAR, and purchased by consumers around the world, which are accompanied by this written warranty:

16.1 PRODUCTS COVERED

- A. Products as defined above.
- 1. The Fixed Wireless Telephone.
- 2. The accessories included with the Fixed Wireless Telephone.

LENGTH OF COVERAGE

A. One (1) year from the date of purchase by the original consumer/purchaser of the product.

16.2 EXCLUSIONS

Batteries. Only batteries whose fully charged capacity falls below 80% of their rated capacity and batteries that leak are covered by this limited warranty.

Abuse & Misuse. Defects or damage that results from: (a) improper operation, storage, misuse or abuse, accident or neglect, such as physical damage (cracks, scratches, etc.) to the surface of the product resulting from misuse; (b) contact with liquid, water, rain, extreme humidity or heavy perspiration, sand, dirt or the like, **58**

extreme heat, or food; (c) use of the Product for commercial purposes or subjecting the Product to abnormal usage or conditions; or (d) other acts which are not the fault of BRIGHTSTAR, are excluded from coverage.

Use of Non-Motorola branded Products and Accessories. Defects or damage that results from the use of non-Motorola branded or certified Products, Accessories, Software or other peripheral equipment are excluded from coverage.

Unauthorized Service or Modification. Defects or damages resulting from service, testing, adjustment, installation, maintenance, alteration, or modification in any way by someone other than BRIGHTSTAR or its authorized service centers are excluded from coverage.

Altered Products. Products or Accessories with (a) serial numbers or date tags that have been removed altered or obliterated; (b) brOKen seals or those that show evidence of tampering; (c) mismatched board serial numbers; or (d) nonconforming or non-Motorola branded housings, or parts, are excluded from coverage.

Communication Services. Defects, damages, or the failure of products, due to any communication service or signal you may subscribe to or use with the Products is excluded from coverage.

Who is covered? This warranty extends only to the first consumer/purchaser, and is not transferable.

What will BRIGHTSTAR Do? BRIGHTSTAR, at its option, will at no charge repair, replace or refund the purchase price of any Product that does not conform to this warranty. We may use functionally equivalent reconditioned / refurbished / pre-

owned or new Products, Accessories or parts. No data, software or applications added to your Product, Accessory or Software, including but not limited to personal contacts, games and ringer tones, will be reinstalled. To avoid losing such data, software and applications please create a back up prior to requesting service.

How to Obtain Warranty Service or Other Information

For information on how to obtain service, contact the place where the product was purchased or a BRIGHTSTAR Service Center in your country.

In order for this Warranty to take effect, take your unit, along with this policy, to the place of purchase or to a BRIGHTSTAR Authorized Service Center.

You will receive instructions on how to ship the Products, at your expense, to a BRIGHTSTAR Authorized Repair Center. To obtain service, you must include: (a) a copy of your receipt, bill of sale or other comparable proof of purchase; (b) a written description of the problem; (c) the name of your service provider, if applicable; (d) the name and location of the installation facility (if applicable) and, most importantly; (e) your address and telephone number.

What Other Limitations Are There? ANY IMPLIED WARRANTIES, INCLUDING WITHOUT LIMITATION THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED TO THE DURATION OF THIS LIMITED WARRANTY, OTHERWISE THE REPAIR, REPLACEMENT, OR REFUND AS PROVIDED UNDER THIS EXPRESS LIMITED WARRANTY IS THE EXCLUSIVE REMEDY OF THE CONSUMER, AND IS PROVIDED IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED. IN NO EVENT SHALL BRIGHTSTAR BE LIABLE, WHETHER IN CONTRACT OR TORT (INCLUDING NEGLIGENCE) FOR DAMAGES IN EXCESS OF THE PURCHASE PRICE OF THE PRODUCT, OR FOR ANY INDIRECT, INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES OF ANY

60

KIND, OR LOSS OF REVENUE OR PROFITS, LOSS OF BUSINESS, LOSS OF INFORMATION OR DATA OR OTHER FINANCIAL LOSS ARISING OUT OF OR IN CONNECTION WITH THE ABILITY OR INABILITY TO USE THE PRODUCTS, TO THE FULL EXTENT THESE DAMAGES MAY BE DISCLAIMED BY LAW.

Some states and jurisdictions do not allow the limitation or exclusion of incidental or consequential damages, or limitation on the length of an implied warranty, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights that vary from state to state or from one jurisdiction to another.

17. REGULATORY



Brightstar Corp. hereby declares this unit to be in compliance with the relevant Provisions of the Low Voltage Directive 73/23/EEC and the EMC Directive 89 / 336 / EEC.

Brightstar Corp. hereby declares this unit to be in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EEC.

This product carries the CE-Mark in accordance with the related European Directives.

18. FCC Notice To Users

We have not approved any changes or modifications to this device by the user. Any changes or modifications could void the user's authority to operate the equipment. See 47 CFR Sec. 15.19(3).

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions

- : (1) This device may not cause harmful interference, and
- : (2) this device must accept any interference received, including interference that may cause undesired operation. See 47 CFR Sec. 15.19(3).

If your mobile device or accessory has a USB connector, or is otherwise considered a computer peripheral device whereby it can be connected to a computer for purposes of transferring data, then it is considered a Class B device and the following statement applies:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- · Connect the equipment to an outlet on a circuit different from that to which the

receiver is connected.

• Consult the dealer or an experienced radio/TV technician for help.

19. Trouble shooting

Before contacting the after-sales service, perform the following simple checks.

They may save you the time and expense of an unnecessary service call.

When you switch your phone on, the following messages appear

Insert SIM Card

· Check that the SIM card is correctly installed. (Try opposite direction)

Phone Locked

• The automatic locking function has been enabled. You must enter the phone's password before you can use the phone.

Enter PIN

- You are using your phone for the first time. You must enter the Personal Identification Number supplied with the SIM card.
- The option requiring that the PIN be entered each time the phone is switched on has been enabled. You must enter your PIN and then disable this option if so required.

Enter PUK

 The PIN code was entered wrongly three times in succession and the phone is now blocked. Enter the PUK supplied by your network operator.

"No service" is displayed

- The network connection was lost. You may be in a weak reception area (in a tunnel or surrounded by buildings). Move and try again.
- You are trying to access an option for which you have not taken out a subscription with your service provider. Contact the service provider for further details.

You have entered a number but it was not dialed

· Have you pressed?

- · Are you accessing the right cellular network?
- You may have set an outgoing call barring option.

Your correspondent cannot reach you

- Is your phone switched on (pressed for more than one second)?
- Are you accessing the right cellular network?
- · You may have set an incoming call barring option.

Your correspondent cannot hear you speaking

- Have you switched off the microphone (appears)?
- Are you holding the phone close enough to your mouth? The microphone is located in the bottom center of the phone.

The phone starts beeping and "** Warning ** Battery Low" flashes in the display

• The battery is insufficiently charged. Replace the battery with a charged one and recharge it or connect the battery charger.

The audio quality of the call is poor

• Check the signal strength indicator in the display. The number of bars after it indicates the

Signal strength from strong to weak.

• Try moving the phone slightly or moving closer to a window if you are in a building.

No number is dialed when you recall a phonebook entry

- Check that the numbers have been stored correctly, by using the Phonebook Search feature.
- · Re-store them, if necessary.

Access Codes

There are several access codes that are used by your phone and its SIM card. These codes help you protect the phone against unauthorized use.

The access codes (except for the PUK codes) can be changed using the Security

66

Settings menu options.

Phone Password

The phone password can be set to avoid unauthorized use of the phone. The password generally supplied with the phone is 0000. You are advised to change it before you start using your phone.

Keep the new password secret and in a safe place, separate from the phone.

PIN

The PIN (Personal Identification Number) protects your SIM card against unauthorized use. The PIN is usually supplied with the SIM card. When the PIN Check feature is enabled, the PIN is needed each time the phone is switched on. If you key in an incorrect PIN three times in succession, key in the PUK and press the OK soft key.

Key in a new PIN and press the OK soft key. Key in the new PIN again and press the OK soft key.

PUK

The PUK (Personal Unblocking Key) is required to change a blocked PIN. The PUK may be supplied with the SIM card. If not, contact your local service provider.

If you key in an incorrect PUK ten times in succession, the SIM card cannot be used anymore.

Contact your service provider for a new card.

You cannot change the PUK. If you lose it, contact your service provider.