



EN Installation Instructions.....2


This documentation can be downloaded from our websites in English, German, French, Spanish, Italian, Portuguese, Czech, Polish, Russian, Turkish and Mandarin.

GLOBAL: www.security.honeywell.com


DACH: www.security.honeywell.de

Model name	Smart	proX	Mobile	Color	Item. no.
OmniAssure Touch Mullion	X	X	X	Black	OT3300BHONG
	X		X	Black	OT3200BHONG
OmniAssure Touch Mullion 12 key	X	X	X	Black	OT3312BHONG
	X		X	Black	OT3212BHONG
OmniAssure Touch Mullion	X	X	X	White	OT3300WHONG
	X		X	White	OT3200WHONG
OmniAssure Touch Mullion 12 key	X	X	X	White	OT3312WHONG
	X		X	White	OT3212WHONG


→ I



→ II



→ III



EN

Subject to change without notice.

1 Scope of delivery

- 1 Installation instructions
- 1 Reader front
- 1 Mounting backplate
- 3 Wall anchors (5 x 25 mm or #8 x 1")
- 3 Screws (panhead, 3 x 30 mm or #4 x 1 1/4")
- 2 Enclosure screws (metric, M2 x 5 mm panhead)
- 2 Enclosure screw caps

2 General

The OmniAssure Touch Mullion Reader was tested at the panels:

- NetAXS 123 V6 (Wiegand)
- ProWatch 6k (Wiegand)
- Pro32 (Wiegand)
- Mercury EP1502 (OSDP)

Mobile credentials:

- proX (EM4102)
- MIFARE classic
- MIFARE DESFire EV1/EV2
- OmniAssure OES
- QKey
- HID
- ISO-SNR Quadrakey
- Bluetooth Low Energy

Physical interfaces:

- Wiegand
- RS-485 (OSDP 2.1.7.)

The Reader Utility Application is used to configure:

- credential bit formats and length

3 Installation

All dimensions in drawings are in inch and (mm).



All wiring shall be in accordance with applicable codes and regulations. Observe applicable building codes and safety regulations in determining the reader position.

UL 294: Installation must be done in accordance with National Electrical Code, ANSI/NFPA 70.

General terms

- The mounting backplate can be used as a drilling template where necessary.
- When positioning the reader base, ensure that the backplate tamper mechanic can be securely screwed in; otherwise the tamper detection is reduced to opening monitoring.
- Secure the reader base without exerting excessive force.
- Use the mounting material included in the accessories. If you need more materials, ensure that these have the same diameter.
- **The power supply of the reader must be switched off while the reader is connected. Risk of damage!**

3.1 Important notes on mounting

- Pay attention to the **minimum distances** ([see "III", page 1](#)). Mounting readers in close proximity of each other will reduce performance, the minimum recommended mounting distance side-by-side or back-to-back is 5" (125 mm).
- Mounting the reader on a metal surface may reduce performance, a plastic separator of at least 1/4" (6 mm) is recommended.

3.1.1 Mounting height

In order to operate the keypad and read the indications optimally, install the reader at a height of 130 to 140 cm (51 to 55") above the floor.

3.1.2 Necessary cable reserve

In order for the reader to be able to be dismantled when necessary, there must be a sufficient cable reserve in the direct vicinity of the reader. Depending on the type of mounting, the cable reserve can be placed in a nearby junction box.

3.2 Mounting for flush mounted wiring

[see "I", page 1](#)

Screw the reader base directly onto the wall.

Screw the backtamper - with reference to drawing in page 1: [1] onto the wall, so that if the reader is torn off the wall, the actuator pin - with reference to drawing in page 1: [2] remains secured to the wall, thus releasing the cover contact and signalling a tamper situation.

3.3 Fasten the reader

[see "II", page 1](#)

[3] Hang the reader from above in the reader base.

[4] Snap shut below.

[5] Close with the supplied enclosure screw.

After completing the mounting and functional testing seal the housing.

To do this, press the supplied enclosure screw cap into screw hole. Destroying the seal for removing.

3.4 Test the reader / Commissioning

Apply power (the green LED indicates power) and present a valid credential. The light ring should flash and the sounder should produce a short tone indicating a successful read. If the Host system is connected the light ring and sounder should follow the functionality of the Host system.

3.5 Cable specification

- The reader is supplied with 6 ft. (2 m) of shielded, 8-conductor AWG 26 (0,14 mm²) cable which may be extended with the length and size of cable listed below.

Interface	max. cable length		min. conductor size for panel power supply					
			9.5 V ¹⁾		12 V		18 V	
	feet	meters	AWG	mm ²	AWG	mm ²	AWG	mm ²
Wiegand / RS-485 (cable power)	200	61	20	0,55	22	0,33	24	0,22
	300	91	18	0,82	20	0,5	22	0,33
	500	152	16	1,35	18	0,81	20	0,54
RS-485 (local power)	4000	1220	AWG 25 / 0,16 mm ²					

1) to ensure that the reader power supply is at least 7 V DC

3.6 Wire assignments

The connection must be carried out in de-energized state! Risk of damage!

To ensure reliable functioning, ensure that a possible extension of the 4 m connecting cable does not exceed 152 m (condition: no external voltage supply unit is required). For extension purposes up to 152 m an additional JY(ST)Y (6x2x0.6 mm) cable can be used.

The reader can be used remotely for extension purposes at a distance of max. 1220 m. We recommend using a Cat 5 connecting cable (condition: an external voltage supply unit for the reader is required).

In general, by use of RS-485 interface: When the reader is the last user on the RS-485 bus, a 120 Ω end-of-line resistor (from TRX+ to TRX-) must be installed in front of the reader. For further information, refer to the description of the corresponding controller.


Wire color	Interface	
	Wiegand	RS-485
red	POWER (+U_b)	POWER (+U_b)
black	GND (0 V)	GND (0 V)
white	D1	TRX+
green	D0	TRX-
blue	Hold line	do not connect
yellow	Buzzer	do not connect
orange	LED green	do not connect
purple	Tamper	do not connect

Caution

Floating communication lines may cause spurious emissions, invalidating certification. Ensure all communication lines are properly biased and terminated.

Input Hold line

This input makes it possible to connect 2 readers in parallel (e.g. at NetAXS).




Tamper line

Physical tamper switches:

- tear-off
- enclosure

The electronic switch opens when the operating voltage +U_b fails.



4 Operation


When a credential is read successfully, the light ring lights briefly, the sounder sounds a short tone and the credential associated code is sent to the Host system.

The light ring and sounder are also controllable by the Host system.

Reader output formats are determined by the personalization of the credential and/or configuration of the reader; on SmartTech and MultiTech readers the behaviour of the light ring and sounder can be modified through configuration.


4.1 Short briefing of buttons and LEDs

4.1.1 OmniAssure Touch Mullion



- A LED light ring
- B LED green
- C LED yellow
- D Duo LED red/green
- E Activate the BLE credential by touching the touch-sensitive surface

4.1.2 OmniAssure Touch Mullion 12 key



- A LED light ring
- B LED green
- C LED yellow
- D Duo LED red/green
- E Activate BLE / Acknowledge: execute the PIN code
- F Clear PIN code entry
- G Numeric keypad for PIN entry (PIN= Personal identification number)

4.2 Requirements to credential type and operation

The following notes and information can be found in the product accompanying documents of the panels:

- NetAXS 123 V6 (Wiegand)
- ProWatch 6k (Wiegand)
- Pro32 (Wiegand)
- Mercury EP1502 (OSDP)

All credential type, i.e. Bluetooth authentication requirements including the following:

1. Electronic credential transmission technology Bluetooth and RFID.

Bluetooth and RFID protocol names:	
Default Mullion OES WG38,BLE,HID-Prox,Quadrakey	
DF UID WG26	
DF UID WG32	
DF UID WG37	
DF UID WG56	
DF UID-L WG26	
DF UID-L WG32	
DF UID-L WG37	
DF UID-L WG56	
EM-Prox WG26	
EM-Prox WG32	
EM-Prox WG34	
EM-Prox WG40	
HID	
MF UID WG26	
MF UID WG32	
MF+DF UID WG26	
MF+DF UID WG32	
MF+DF UID WG37	
MF+DF UID WG56	
MF+DF UID-L WG26	
MF+DF UID-L WG32	
MF+DF UID-L WG37	
MF+DF UID-L WG56	
OSDP OmiAssure OES WG38 HID UniKey	
OSDP OmiAssure OES WG38	
OmniAssure OES WG38	
OmniAssure OES WG38 UniKey 38 bit	
EM-Prox(+EM4450)WG32	
QKey WG34	

2. Config App for programming the reader (Reader Utility by HON). Also the credential bit format and length will be configured by the App during the configuration, so find details in description of App. The following abbreviations are used in the Config App:

DF	DesFire
MF	Mifare Classic
UID	Serial Number, continuous numbers like Omni-Assure
UID-L	Serial Number, format like LuminAXS, Omniprox
WGxx	Wiegand xx Bit
EM-Prox	EM-Marin 125 kHz H4102 + H4450
HID	HID 125 kHz
OES WG38	38 Bit Wiegand Diversified Keys, card ODPEV28N38
BLE	Bluetooth UniKey format
QKey WG34	Quadrakey Wiegand 34 Bit

3. Use the following operating system (OS) and revision level, along with the credential device application software with following level: Boot-loader V4.2.xxx / Application 4.2.xxx / OS 4.2.xxx
4. Installer/dealer can access the reader via config app 'Reader Utility by Honeywell' (Google Play store). Verification is required (SITE code). The access control system uses 3 types of verification for the user: Available are pin code, physical credential and mobile credential.
 - The reading of a physical credential and an electronic device (BLE), transmitting user data to the reader interface is the same.
 - Have a look at the manual of the system for more details like instructions on how to silence a trouble, functions of all switches/buttons, description of the conditions that might be expected to result in false alarms or impaired operation of the product and service information.

5 Classifications

- UL 294: Destructive attack level **IV**, line security level **I**, endurance level **IV**, power level **I**.
Access Control Feature: Single Point Locking Device with Key Locks Level **I**.
- EN 60839-11-1 Grade 3, environmental class III

6 Certifications

- CE, FCC, UL294
- FCC ID:** UA2OT3XXXBHON
UA2OT3XXXWHON
- Intertek:** ETL listed Intertek 5014020

7 FCC Regulations

7.1 Warning (Part 15.21)

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

7.2 Compliance statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

7.3 Information to the user (Part 15.105 (b))

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

8 CE Declaration of conformity



Hereby, the Novar GmbH declares that the radio equipment readers OmniAssure, item no. OT3300BHONG, OT3200BHONG, OT3312BHONG, OT3212BHONG, OT3300WHONG, OT3200WHONG, OT3312WHONG and OT3212WHONG are in compliance with Directive 2014/53/EU.



This symbol on our product shows a crossed-out "wheeled bin" as required by law regarding the Waste of Electrical and Electronic Equipment (WEEE) disposal. This indicates your responsibility to contribute in saving the environment by proper disposal of this Waste i.e. Do not dispose of this product with your other wastes. To know the right disposal mechanism please check the applicable law.

The full text of the EU declaration can be downloaded from our homepage <https://www.security.honeywell.de/> in the service/download area.

9 Technical specification

Dimensions	1.97 x 5.67 x 0.87 inch / 50 x 144 x 22,3 mm							
Operating temperature	-40 °F to 151 °F / -40 °C to 66 °C							
Protection class	IP65							
Environmental class	III							
Protection class UL	IP4X / IK04 (enclosure)							
Humidity condition	max. 93±2% at 32±2 °C / 89.6±3.6 °F 0 - 95% non-condensing							
Installation and use	Indoor and outdoor usage							
Interfaces	Wiegand; RS-485							
Reading range	0 ... ≈2.75" / 0 ... ≈70 mm (depending on credential)							
BLE range	0 ... ≈197" / 0 ... ≈5 m							
Power supply reader	7.0 V to 18 V DC (12 V recommended)							
Power consumption Current consumption	Watt		mA					
			at 7 V DC		at 12 V DC		at 18 V DC	
	avg	peak	avg1)	peak2)	avg1)	peak2)	avg1)	peak2)
	1.8	4.0	250	530	150	320	100	220
Used frequency bands	Transmitted power							
- 119 kHz to 135 kHz	< 10 dBμA/m							
- 13.56 MHz	< 0 dBμA/m							
- 2400 to 2483.5 MHz	< 1 mW e.i.r.p.							

- 1) The "average" current is measured in Idle mode (factory setting, light ring is slightly blue)
- 2) The "peak" current is measured with card activation (factory setting, light ring is on)





Honeywell Commercial Security

Novar GmbH
Johannes-Mauthe-Straße 14
D-72458 Albstadt
www.honeywell.com/security/de

P30743-10-0G0-01
2019-12-06
© 2019 Novar GmbH

Honeywell

