

ENGLISH

⊕ LG

11.4.7

MG140a USER GUIDE

Please read this manual carefully before operating your mobile phone. Retain it for future reference.

MG140a USER GUIDE

LG Electronics In

LG Electronics Inc.

http://www.lge.com

P/N:

(1.0)

G

MG140a USER GUIDE

Please read this manual carefully before operating your mobile phone. Retain it for future reference.

FCC Part 15 statement

This device complies with part 15, part 22 and part 24 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no ourarnate that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different form that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.
WARNING

Changes or modifications made to this equipment no expressly approved by LG for compliance could void the user's authority to operate the equipment.



Table of Contents

Introduction	
For Your Safety	(
Guidelines for safe and efficient use	7
MG140a Features	11
Parts of the phone	11
Front view	11
Rear view	12
Key description	13
On-Screen icons	14
Getting started	15
Installing the SIM card and the battery	19
Inserting the SIM card	15
Removing the SIM card	1.5
Installing the battery	16
Charging the Battery	16
Disconnecting the adapter	17

General functions	18
Making and answering calls	18
iignal strength	19
intering text	19
Phonebook	22
n-call menu	22
Multiparty or conference calls	24
Selecting functions and options	26
Menu tree	27
Messaging	29
New message	29
nbox	31
Prafts Prafts	32
Dutbox	32
ent	33
isten voicemail	33
nfo messages	33
- emplates	34
ettings	34

Call history	37	My stuff	47
All calls	37	Images	47
Missed calls	37	Sounds	47
Dialled calls	37	Others	47
Received calls	38	Games & Apps	48
Call duration	38		
Call costs	38	Browser	49
Data information	39	Home	49
		Bookmarks	50
Contacts	40	Go to URL	50
Search	40	History	50
New contact	40	Settings	50
Speed dials	41	Information	50
Groups	41		
Copy all	42	Tools	51
Delete all	42	Alarm clock	51
Settings	42	Calendar	51
Information	43	Calculator	51
		Memo	52
Multimedia	44	To do	52
Camera	44	Stopwatch	52
FM Radio	45	Unit converter	52
Voice recorder	46	World clock	53

Table of Contents

SIM Service	54
Settings	55
Date & Time	55
Languages	55
Profiles	55
Display	56
Network	57
Call	58
Security	60
Flight mode	62
Power save	62
Reset	62
Memory status	62
Accessories	63
Technical data	64

Introduction

Congratulations on your purchase of the advanced and compact MG140a mobile phone, designed to operate with the latest digital mobile communication technology.



This user's guide contains important information on the use and operation of this phone. Please read all the information carefully for optimal performance and to prevent any damage to or misuse of the phone. Any changes or modifications not expressly approved in this user's guide could void your warranty for this equipment. Use of phone cases with magnetic locks with flip type phones has caused problems such as loss of network signal and phones powering off.

For Your Safety

Please read these simple guidelines. Not following these guidelines may be dangerous or illegal. Further detailed information is given in this manual.

WARNING

- Mobile Phones must be switched off at all times in aircrafts.
- ▶ Do not hold the phone in your hand while driving.
- ▶ Do not use your phone near petrol stations, fuel depots, chemical plants or blasting operations.
- ► For your safety, use ONLY specified ORIGINAL batteries and chargers.
- Do not handle the phone with wet hands while it is being charged. It may cause an electric shock or seriously damage your phone.
- ► Keep the phone in a safe place out of small children's reach. It includes small parts which, if detached, may cause a choking hazard.

CAUTION

- Switch off the phone in any area where required any special regulations. For example, do not use your phone in hospitals or it may affect sensitive medical equipment.
- Emergency calls may not be available under all mobile networks. Therefore, you should never depend solely on your mobile phone for emergency calls.
- ► Only use ORIGINAL accessories to avoid damage to your phone.
- ► All radio transmitters carry risks of interference with electronics in close proximity. Minor interference may affect TVs, radios, PCs, etc.
- ▶ Batteries should be disposed off in accordance with relevant legislation.
- ▶ Do not dismantle the phone or battery.

Guidelines for safe and efficient use

Please read these simple guidelines. Not following these guidelines may be dangerous or illegal. Further detailed information is given in this manual.

Exposure to radio frequency energy

Radio wave exposure and Specific Absorption Rate (SAR) information

This mobile phone model MG140a has been designed to comply with applicable safety requirements for exposure to radio waves. This requirement is based on scientific guidelines that include safety margins designed to assure the safety of all persons, regardless of age and health.

- The radio wave exposure guidelines employ a unit of measurement known as the Specific Absorption Rate, or SAR. Tests for SAR are conducted using standardised methods with the phone transmitting at its highest certified power level in all used frequency bands.
- While there may be differences between the SAR levels of various LG phone models, they are all

- designed to meet the relevant guidelines for exposure to radio waves.
- The SAR limit recommended by the International Commission on Non-Ionizing Radiation Protection (ICNIRP) is 2W/kg averaged over ten (10) gram of tissue.
- SAR data information for residents in countries/regions that have adopted the SAR limit recommended by the Institute of Electrical and Electronics Engineers (IEEE) is 1.6 W/kg averaged over one (1) gram of tissue (for example USA, Canada, Australia and Taiwan).
- ▶ The highest SAR value for this model phone tested by DASY4 is 0.409W/kg (1g) for body worn use in GPRS mode.

Guidelines for safe and efficient use

Product care and maintenance

Warning! Only use batteries, chargers and accessories approved for use with this particular phone model. The use of any other types may invalidate any approval or warranty applying to the phone, and may be dangerous.

- ▶ Do not disassemble this unit. Take it to a qualified service technician when repair work is required.
- ▶ Keep away from electrical appliances such as a TV's, radios or personal computers.
- ▶ The unit should be kept away from heat sources such as radiators or cookers.
- Never place your phone in a microwave oven as it will cause the battery to explode.
- ▶ Do not drop.
- Do not subject this unit to mechanical vibration or shock.
- ► The coating of the phone may be damaged if covered with wrap or vinyl wrapper.
- Do not use harsh chemicals (such as alcohol, benzene, thinners, etc.) or detergents to clean your phone. There is a risk of this causing a fire.
- ▶ Do not subject this unit to excessive smoke or dust.

- Do not keep the phone next to credit cards or transport tickets; it can affect the information on the magnetic strips.
- Do not tap the screen with a sharp object as it may damage the phone.
- ▶ Do not expose the phone to liquid or moisture.
- Please remove the data cable before powering on the handset.

Electronic devices

All mobile phones may get interference, which could affect performance.

- Do not use your mobile phone near medical equipment without requesting permission. Avoid placing the phone over pacemakers (i.e. in your breast pocket.)
- ▶ Some hearing aids might be disturbed by mobile phones.
- ▶ Minor interference may affect TVs, radios, PCs, etc.

Road safety

Check the laws and regulations on the use of mobile phones in the areas when you drive.

- ▶ Do not use a hand-held phone while driving.
- Give full attention to driving.
- Use a hands-free kit, if available.
- Pull off the road and park before making or answering a call if driving conditions so require.
- RF energy may affect some electronic systems in your motor vehicle such as a car stereo or safety equipment.
- If your vehicle is equipped with an air bag, do not obstruct it with installed or portable wireless equipment. It can cause serious injury due to improper performance.

If you are listening to music whilst out and about, please ensure that the volume is at a reasonable level so that you are aware of your surroundings. This is particularly imperative when attempting to cross the street.

Avoid damage to your hearing

Damage to your hearing can occur if you are exposed to loud sound for long periods of time. We therefore recommend that you do not turn on or off the handset close to your ear. We also recommend that music and call yolumes are set to a reasonable level.

Blasting area

Do not use the phone where blasting is in progress. Observe restrictions, and follow any regulations or rules.

Potentially explosive atmospheres

- Do not use the phone at a refuelling point. Don't use near fuel or chemicals.
- Do not transport or store flammable gas, liquid, or explosives in the compartment of your vehicle, which contains your mobile phone and accessories.

and efficient use

Guidelines for safe and efficient use

In aircraft

Wireless devices can cause interference in aircraft.

- ► Turn off your mobile phone before boarding any aircraft.
- ▶ Do not use it on the ground without crew permission.

Children

Keep the phone in a safe place out of small children's reach. It includes small parts which if detached may cause a choking hazard.

Emergency calls

Emergency calls may not be available under all mobile networks. Therefore, you should never depend solely on your mobile phone for emergency calls. Check with your local service provider.

Battery information and care

- You do not need to completely discharge the battery before recharging. Unlike other battery systems, there is no memory effect that could compromise the battery's performance.
- Use only LG batteries and chargers. LG chargers are designed to maximize the battery life.
- ▶ Do not disassemble or short-circuit the battery pack.
- ▶ Keep the metal contacts of the battery pack clean.
- Replace the battery when it no longer provides acceptable performance. The battery pack may be recharged hundreds of times until it needs replacing.
- Recharge the battery if it has not been used for a long time to maximize usability.
- Do not expose the battery charger to direct sunlight or use it in high humidity, such as the bathroom.
- ▶ Do not leave the battery in hot or cold places, this may deteriorate the battery performance.

MG140a Features

Parts of the phone

Front view



Rear view



Key description

The following shows key components of the phone.

Keypad description

Key	Description
Key	Description
	Left soft key / Right soft key
-	Each of these keys performs the function indicated by the text on the display
	immediately above it.
· 🕠	Navigation keys
	Use to scroll through menus and move the
	cursor. You can also use these keys for quick access to the following functions.
	• Up navigation key (): A shortcut key to access Favorites.
	• Down navigation key (): A shortcut key to search the phonebook list.
	• Left navigation key (): A shortcut key to the Profile menu.
	 Right navigation key (): A shortcut key to List of Messages.

Key	Description
	Send Key You can dial a phone number and answer a call. If you press this key without entering a number, your phone shows the most recently dialled, received and missed calls.
0 <u>2</u> 2	Numeric keys These keys are used mainly to dial in standby mode and enter numbers or characters in editing mode. When you press these keys for a long time. • Used to call your voicemail box • Used to add the international prefix • Used to call Speed dials from • Used to enter a pause
•	END/PWR key Used to end or reject a call. This key is also used as Power Key by pressing and holding this key for a few seconds.
cta	Clear key Deletes a character by each press. Hold the key down to clear all input. Also use this key to go back to the previous screen.

MG140a Features

The table below describes various display indicators or icons that appear on the phone's display screen.

On-Screen icons

Icon/Indicator	Description
Y.ull	Tells you the strength of the network signal.
•	Call is connected.
Guttl	You can use GPRS service.
R	Shows that you are using a roaming service.
2	Line 1/2 is in use for outgoing calls – if you subscribe to the Two Line Service.
Œ	The alarm has been set and is on.
•	Tells you the status of the battery.
\bowtie	You have received a text message.
00	You have received a voice message.
\tag{\tag{\tag{w}}	You have received a push message.

Icon/Indicator	Description
<u> </u>	You can view your schedule.
u e u	Vibrate only menu in profile.
→	General menu in profile.
7	Loud menu in profile.
X	Silent menu in profile.
- -	Headset menu in profile.
49	You can divert a call.

Getting started

Installing the SIM card and the battery

1. Inserting the SIM card

Locate the SIM card socket in the back of the phone. Follow the steps below to install the SIM card.

- 1. Remove the battery if attached.
- 2. Slide the SIM card into the slot, under the silvery holders, with the golden connectors facing down.



2. Removing the SIM card

Follow the steps below to Remove the SIM card.

- 1. Remove the battery if attached.
- 2. Take out the SIM card from the slot.



Notice

- ▶ Removing the battery from the phone whilst it is switched on may cause it to malfunction.
- ► The metal contact of the SIM card can be easily damaged by scratches. Pay special attention to the SIM card when you handle and install. Follow the instructions supplied with the SIM card.

Getting started

3. Installing the battery

1. Position the lugs on the bottom of the battery into the retaining holder.



2. Then push the half of the battery into position.



Charging the Battery

To connect the travel adapter to the phone, you must have installed the battery.



- With the arrow facing you as shown in the diagram push the plug of the battery adapter into the socket on the bottom of the phone until it clicks into place.
- Connect the other end of the travel adapter to the mains socket. Only use the charger provided in the box.

3. The moving bars of battery icon will stop after charging is complete.

Caution

- Do not force the connector as this may damage the phone and/or the charger.
- If you use the battery pack charger out of your own country, use an attachment plug adapter for the proper configuration.
- Do not remove your battery or the SIM card while charging.

Warning

- Unplug the power cord and charger during lightning storms to avoid electric shock or fire.
- ▶ Make sure that no sharp-edged items such as animal teeth or nails come into contact with the battery. There is a risk of this causing a fire.

Disconnecting the adapter



Disconnect the travel adapter from the phone by pressing its side buttons as shown in the diagram.

Note

- ► Ensure the battery is fully charged before using the phone for the first time.
- In the case the battery is not properly charged, please turn the phone off and on using the power key. Then detach and reattach the battery, and recharge the phone.

General functions

Making and answering calls

Making a call

- 1. Make sure your phone is switched on.
- 2. Enter a phone number, including the area code.
- ► To delete numbers press the wey. Press and hold the clear key to erase the entire number.
- 3. Press the send key at to call the number.
- 4. To end the call, press the end key or the right soft key.

Making a call from the call history list

- In standby mode, press the send key and the latest incoming, outgoing and missed calls will be displayed.
- 2. Select the desired number by using the up/down navigation keys.
- 3. Press a to call the number.

Making an international call

- Press and hold the sey for the international prefix. The '+' character automatically selects the international access code.
- Enter the country code, area code, and the phone number.
- 3. Press a to call the number.

Ending a call

When you have finished your call, press the end key.

Making a call from the address book

You can save the names and phone numbers dialled regularly in the SIM card and/or phone memory. You can dial a number by simply looking up the desired name in the contacts and pressing the key.

Answering a call

When you receive a call, the phone rings and the flashing phone icon appears on the screen. If the caller can be identified, the caller's phone number (or name if saved in the phonebook) is displayed.

 To answer an incoming call, Press left soft key or Send key.

Note

- ▶ If Press any key has been set as the answer mode, any key press will answer a call except for the or the right soft key.
- You can answer a call whilst using the phonebook or other menu features.
- 2. To end the call, press the key.

Signal strength

You can check the strength of your signal by the signal indicator (\(\mathbb{T}_{\text{-till}} \)) on the LCD screen of your phone. Signal strength can vary, particularly inside buildings. Moving near to a window may improve reception.

Entering text

You can enter alphanumeric characters by using the phone's keypad. For example, storing names in the phonebook, writing a message, creating a personal greeting.

The following text input methods are available in the phone.

General functions

T9 Mode

This mode lets you enter words with only one keystroke per letter. Each key on the keypad has more than one letter. The T9 mode automatically compares your keystrokes with an internal dictionary to determine the correct word, thus requiring far fewer keystrokes than the traditional ABC mode. This is sometimes known as predictive text.

ABC Mode

This mode lets you enter letters by pressing the key labeled with the required letter once, twice, three or four times until the letter is displayed.

123 Mode (Numbers Mode)

Type numbers using one keystroke per number. To change to 123 mode in a text entry field, press the see key until 123 mode is displayed.

Changing the text input mode

- When you are in a field that allows characters to be entered, you will notice the text input mode indicator in the top right corner of the LCD screen.
- Change the text input mode by pressing . You can check the current text input mode in the top right corner of the LCD screen.



▶ Using the T9 mode

The T9 predictive text input mode lets you enter words easily with a minimum number of key presses. As you press each key, the phone begins to display the characters that it thinks you are typing based on the built-in dictionary. You can also add new words in the dictionary. As new words are added, the word changes to reflect the most likely candidate from the dictionary.

- When you are in the T9 predictive text input mode, start entering a word by pressing keys
 Press one key per letter.
 - The word changes as letters are typed. Ignore what's on the screen until the word is typed completely.
 - If the word is still incorrect after you have finished typing, press the down navigation key once or more to cycle through the other word options.
 - Example: Press Fress Fre
 - ▶ If the desired word is missing from the word choice list, add it using the ABC mode.
 - ▶ You can select the language of the T9 mode. Press the left soft key [Option], then select T9 languages. Select the desired language of T9 mode. You can also turn off the T9 mode by selecting T9 off. The default setting on the phone is T9 enabled mode.

- 2. Enter the whole word before editing or deleting any keystrokes.
- Complete each word with a space by pressing the
 key. To delete letters, press
 . Press and hold down
 to erase entire words.

Note

- ➤ To exit from the text input mode without saving your input, press . The phone goes back to standby mode.
- ▶ Using the ABC mode

Use the to keys to enter your text.

- 1. Press the key labeled with the required letter:
 - ▶ Once for the first letter
 - ▶ Twice for the second letter.
 - And so on.
- To insert a space, press the key once.
 To delete letters, press the key. Press and hold down the key to clear the whole display.

Note

▶ Refer to the table below for more information on the characters available using the alphanumeric keys.

General functions

Vov	Characters in the order display	
Key	Upper Case	Lower Case
100	.,/?!-:'"1	.,/?!-:'"1
2≈	ABC2	abc2
3 44	DEF3	def3
40	GHI4	ghi4
1 5 at 1	JKL5	jkl5
6100	MNO6	m n o 6
7.000	PQRS7	pqrs7
8 to	T U V 8	tuv8
9 402	WXYZ9	wxyz9
0:	Space 0	Space 0

▶ Using the 123 (Number) mode

The 123 mode enables you to enter numbers in a text message (a telephone number, for example).

Press the keys corresponding to the required digits before manually switching back to the appropriate text entry mode.

Phonebook

You can store phone numbers and their corresponding names in the memory of your SIM card.

In addition, you can store up to 500 numbers and names in the phone memory.

The SIM card and phone are both used in the same way in the Contacts menu.

In-call menu

Your phone provides a number of control functions that you can use during a call. To access these functions during a call, press the left soft key [Options].

During a call

The menu displayed on the handset screen during a call is different to the default main menu displayed when in standby mode, and the options are described below.

Making a second call

You can make a second call while currently on a call. Enter the second number and press the send key. When the second call is connected, the first call is automatically placed on hold. You can get a number you wish to dial from the phonebook to make a second call. Press the right soft key then select Search. To save the dialled number into the phonebook during a call, press the right soft key then select Add new.

Switching between two calls

To switch between two calls, press the left soft key then select **Swap** or by pressing key.

Answering an incoming call

To answer an incoming call when the handset is ringing, simply press the key. The handset is also able to warn you of an incoming call while you are already on a call. A tone sounds in the earpiece, and the display will show that a second call is waiting.

This feature, known as **Call waiting**, is only available if your network supports it.

For details of how to activate and deactivate it see Call waiting.

If Call waiting is activated, you can put the first call on hold and answer the second, by pressing or by selecting the left soft key [Answer].

Rejecting an incoming call

You can reject an incoming call without answering by simply pressing the key.

During a call, you can reject an incoming call by pressing the right soft key [End] key or by pressing the ...

Muting the microphone

You can mute the microphone during a call by pressing the left soft key then selecting Mute. The handset can be unmuted by selecting Unmute.

When the handset is muted, the caller cannot hear you, but you can still hear them.

Switching DTMF tones on during a call

To turn DTMF tones on during a call, press the left soft key, and then select DTMF on. DTMF tones can be turned off the same way. DTMF tones allow your phone to make use of an automated switchboard.

Multiparty or conference calls

The multiparty or conference service provides you with the ability to have a simultaneous conversation with more than one caller, if your network operator supports this feature. A multiparty call can only be set up when you have one active call and one call on hold, both calls having been answered. Once a multiparty call is set up, calls can be added, disconnected or separated (that is, removed from the multiparty call but still connected to you) by the person who set up the multiparty call. These options are all available from the In-Call menu. The maximum callers in a multiparty call are five. Once started, you are in control of the multiparty call, and only you can add callers to the multiparty call.

Making a second call

You can make a second call while currently on a call. Enter the second number and press the key.

When the second call is connected, the first call is automatically placed on hold. You can swap between calls by pressing the left soft key then selecting **Swap.**

Setting up a conference call

Place one call on hold and while the active call is on, press the left soft key and then select the Conference/Join all.

Putting a conference call on hold

Press the left soft key, then select the Conference/Hold all.

Activate the conference call on hold

Press the left soft key, then select the Conference/Join all.

Adding calls to the conference call

To add a call to an existing conference call, press the left soft key, then select the Multiparty/Join all.

Displaying callers in a conference call

To scroll through the numbers of the callers who make up a conference call on the handset screen, use the up/down navigation keys.

Taking a private call during a conference call

To have a private call with one caller from a conference call, display the number of the caller you wish to talk to on the screen, then press the left soft key. Select the **Conference/Private** to put all the other callers on hold.


Ending a conference call

The currently displayed caller from a conference call can be disconnected by pressing the key. To end a conference call, press the left soft key, then select the Multiparty/End multiparty. After pressing the left soft key, selecting Multiparty/End all will end all the active and on-hold calls.

Selecting functions and options

Your phone offers a set of functions that allow you to customise the phone. These functions are arranged in menus and sub-menus, accessed via the two soft keys marked and sub-menu and sub-menu lets you view and alter the settings of a particular function.

The roles of the soft keys vary according to the current context or the label on the bottom line of the screen just above each key indicates its current role.



Press the left soft key to access the available menu.

Press the right soft key to activate the corresponding action.

Menu tree

1. Messaging
1.1 New message
1.2 Inbox
1.3 Drafts
1.4 Outbox
1.5 Sent
1.6 Listen voicemail
1.7 Info messages
1.8 Templates
1.9 Settings

2. Call history
2.1 All calls
2.2 Missed calls
2.3 Dialled calls
2.4 Received calls
2.5 Call duration
2.6 Call costs
2.7 Data information

3. Contacts
3.1 Search
3.2 New contact
3.3 Speed dials
3.4 Groups
3.5 Copy all
3.6 Delete all
3.7 Settings
3.8 Information
4. Multimedia
4.1 Camera
4.2 FM Radio
4.3 Voice recorder

5. My stuff
5.1 Images
5.2 Sounds
5.3 Others
5.4 Games & Apps
6. Browser
6.1 Home
6.2 Bookmarks
6.3 Go to URL
6.4 History
6.5 Settings
6.6 Information
I .

7. Tools
7.1 Alarm clock
7.2 Calendar
7.3 Calculator
7.4 Memo
7.5 To do
7.6 Stopwatch
7.7 Unit converter
7.8 World clock
8. SIM Service

9. Settings
9.1 Date & Time
9.2 Languages
9.3 Profiles
9.4 Display
9.5 Network
9.6 Call
9.7 Security
9.8 Flight mode
9.9 Power save
9.0 Reset
9.* Memory status

Messaging

New message

Menu 1.1

This menu includes functions related to SMS (Short Message Service), MMS (Multimedia Message Service), Email, voice mail, as well as the network's service messages.

Text (Menu 1.1.1)

You can write and edit text messages up to 10 pages.

- 1. Enter the Messages menu by pressing [OK].
- 2. If you want to write a new message, select Write text message.
- 3. To make text input easier, use T9. For details, refer to page 19 through 22 (Entering text).
- 4. Press [Insert] to attach the following:

Insert

- ► Symbol: You can add special characters.
- Picture: You can insert the Default graphics or graphics in My folder that are available for short messages.
- Sound: You can insert sounds that are available for short messages.

- ► Text templates: You can use Text templates already set in the phone.
- ► Contacts: You can add phone numbers or e-mail addresses in the address book.
- Signature: You can add your business card to the message.
- After you have completed the message, to select the required option, press the left soft key [Options].

Options

- ▶ Send: Sends the text message.
- 1. Enter the number of the recipient.
- 2. Press key to add more recipients.
- 3. You can add phone numbers from the address book.
- 4. Once the numbers have been entered, press the left soft key to send the message.

All messages will automatically be saved in the outbox folder, even after a sending failure.

▶ Save: Stores messages in the Drafts folder.

Messaging

- ▶ Font: You can select the Size and Style of font.
- ► Colour: You can also set the Colour of the text (foreground) and the background.
- ► Alignment: You can select the alignment of text. [Left/Centre/Right]
- Add T9 dictionary: You can add your own words. This menu will only be shown when the edit mode has been set to T9ABC/T9Abc/T9abc.
- ▶ T9 languages: Select the desired language for T9 input mode. You can also deactivate the T9 input mode by selecting 'T9 off'.
- Exit: If you press Exit whilst writing a message, you will be taken back to the message menu. Also the written message will not have been saved.

Note

This phone supports EMS release 5, so is available to send colour pictures, sounds, text styles, etc.. If the other parties handsets do not support such options, the pictures, sounds or texts sent may not be displayed correctly on their phones.

Multimedia

(Menu 1.1.2)

A multimedia message can contain text, images, and/or sound clips. This feature can be used only if it is supported by your network operator or service provider. Only devices that offer compatible multimedia message or e-mail features can receive and send multimedia messages.

Press Insert to add Image, Sound, Contacts, Symbol, New photo, New sound, Text templates, My business card. Maximum available file size, that can be inserted to MMS-message, is 100 kb.

Options

 Send: You can send multimedia messages to multiple recipients, as well as save it to send at a later time.

Note

- All messages will be automatically saved in the outbox slide, even after a sending failure.
- Preview: You can preview multimedia messages you have created.
- Save: You can save multimedia messages To drafts or As template.
- Edit subject: Allows you to modify the multimedia message you have chosen.

- Add slide: You can add a slide before or after current slide.
- Move to slide: You can move to the previous or the next slide.
- ▶ Delete slide: You can delete current folders.
- ▶ Set slide format

Inbox Menu 1.2

You will be alerted when you have received messages. They will be stored in the Inbox.

In the Inbox, you can identify each message by their icons. For detail, see the icon directive.

▶ Icon directive

Icon	Description
\bowtie	Short message
	SIM message
	Read text message

If the phone shows 'No space for SIM message', you have to only delete some SIM messages from the Inbox. If the phone displays 'No space for message', you can make space for each repository as deleting messages, media and applications.

Note

SIM message: SIM message means the message is exceptionally stored in the SIM card.

To read a message, select one of the messages by pressing .

- ▶ View: You can view the selected message.
- ▶ Delete: You can delete the current message..
- ▶ Reply: You can reply to the sender.
- Forward: You can forward the selected message to another party.
- ▶ Return call: You can call the sender back.
- ▶ Delete: You can delete the current message.
- ▶ Information: To view the information of the message..
- ▶ Multi delete: Selects and delete several items at one time.
- Delete all read: Deletes all the read messages from drafts folder.
- ▶ Delete all: You can delete all messages.

Drafts Menu 1.3

You can view the messages saved as a draft. The draft messages are listed with the date and time when they were saved. Scroll through the list using up/down navigation keys.

Each draft has the following options. Press [Options].

- ▶ View: You can view the selected message.
- ▶ Edit: You can edit the selected message.
- Delete: Deletes the selected message from the drafts folder.
- ▶ Send: You can send the selected message.
- Information: To view the information of the message.
- ▶ Multi delete: Selects and delete several items at one time.
- ▶ Delete all: Deletes all the messages from drafts folder.

Outbox

You can view the list and contents of sent messages in this menu and can also verify if the transmission was successful.

Menu 1.4

▶ Icon directive

lcon	Description
\otimes	SMS sent
ŒQ	Failed SMS
-05 -05	SMS Delivery confirmed

- ▶ View: You can view the selected message.
- ▶ Delete: Deletes the selected message from outbox.
- ▶ Edit: You can edit the selected message.
- Resend: You can resend the selected message to some receiver.
- Information: You can check the information of each message.
- ▶ Delete all: Deletes all the messages in the outbox folder

Sent Menu 1.5

You can view the list and contents of sent messages in this menu and can also verify if the transmission was successful.

- ▶ View: You can view the selected message.
- ▶ Delete: Deletes the selected message from outbox.
- ▶ Edit: You can edit the selected message.
- ► Forward: You can forward the selected message to another party.
- ▶ Information: You can check the information of each message.
- Multi delete: Selects and delete several items at one time.
- Delete all: Deletes all the messages in the outbox folder.

Listen voicemail

Menu 1.6

Once this menu has been selected, simply press the OK to listen to voice mail. You can also hold down in standby mode to listen to voice mail.

Note

When you receive a voice mail, your phone will display an icon and you will hear an alert. Please check with your network provider for details of their service in order to configure the handset correctly.

Info messages

Menu 1.7

(Dependant to network and subscription)

Info service messages are text messages delivered by the network to your handset. They provide general information such as weather reports, traffic news, taxis, pharmacies, and stock prices. When you receive an info service message, a popup message will indicate a new message receipt or the info service message will be displayed directly. In standby mode, the following options are available when viewing info service messages.

Read

(Menu 1.7.1)

When you have received an info service message and select Read to view the message, it will be displayed on the screen. You can read another message by scrolling or leaving l

Topics

(Menu 1.7.2)

- ▶ Add new: You can add Info service message numbers in the Phone memory with its nickname.
- ➤ View list: You can see Info service message numbers which you have added. If you press [Options], you can edit and delete info message categories which you have added.
- Active list: You can select Info service message numbers in the active list.
 If you activate an info service number, you can receive messages sent from the number.

Templates

Menu 1.8

There are pre-defined messages in the list. You can view and edit the template messages or create new messages. Two types of templates are available: Text and Signature.

Text

(Menu 1.8.1)

You can insert the text template on writing a message.

Multimedia templates

(Menu 1.8.2)

You can insert the multimedia template which is included of picture, sound and photo on writing a message.

Settings

Menu 1.9

Text message

(Menu 1.9.1)

Message types:

Text, Voice, Fax, Nat'l.paging, X.400, Email, ERMES

Usually, the type of message is set to Text. You can convert your text into alternative formats. Contact your service provider for the availability of this function.

- Validity period: This network service allows you to set how long your text messages will be stored at the message centre.
- ▶ Delivery report: If you set to Yes, you can check whether your message is sent successfully.
- ▶ Reply via same service: When a message is sent, it

allows the recipients to reply and charge the cost of the reply to your telephone bill.

 SMS centre: If you want to send the text message, you can receive the address of SMS centre through this menu.

Mulitimedia message

(Menu 1.9.2)

- Priority: You can set the priority of the message you choose.
- Validity period: This network service allows you to set how long your text messages will be stored at the message centre.
- ► Subject: You can enter multimedia messages subject when this menu is on.
- Delivery report: If it is set to Yes in this menu, you can check whether your message is sent successfully.
- Auto retrieve: If you select On, you receive multimedia messages automatically. If you select Off, you receive only notification message in the inbox and then you can check this notification. If you select Home network only, you receive

- multimedia messages depends on Homenetwork.
- Network settings: If you select multimedia message server, you can set URL for multimedia message server.
- ▶ Permitted message types

Personal: Personal message.

Advertisements: Commercial message.

Information: Necessary information.

Voice mail number

(Menu 1.9.3)

You can receive voicemail if this feature is supported by your network service provider. When a new voicemail has arrived, the symbol will be displayed on the screen. Please check with your network service provider for details of their service in order to configure the phone accordingly.

- 1. Hold down we key in standby mode.
- 2. You can check the following submenus.
- Home: You can listen to voice mails by selecting Home.
- ▶ Roaming: Even when you are abroad, you can listen

Messaging

to voice mails if a roaming service is supported.

Info message

(Menu 1,9.4)

(Dependent to network and subscription)

▶ Receive

- Yes: If you select this menu, your phone will receive Info service messages.
- No: If you select this menu, your phone will not receive Info service messages any more.

▶ Alert

- Yes: Your phone will beep when you have received Info service message numbers.
- No: Your phone will not beep even though you have received info service messages.

Languages

 You can select the language you want by pressing [On/Off]. Then, the info service message will be shown in the language that you have selected.

Call history

You can check the record of missed, received, and dialled calls only if the network supports the Calling Line Identification (CLI) within the service area.

The number and name (if available) are displayed together with the date and time at which the call was made. You can also view call times.

All calls Menu 2.1

You can view all list of outgoing, incoming and missed calls. By pressing (LSK) (options), you can also:

- ► View the number if available and call it, or save it in the Address Book
- Enter a new name for the number and save both in the Address Book
- ▶ Send a message to this number
- ▶ Delete the call from the list

Missed calls

Menu 2.2

This option lets you view the last 20 unanswered calls. You can also:

- View the number if available and call it, or save it in the phonebook.
- ▶ Enter a new name for the number and save both in the phonebook.
- ▶ Send a message to this number.
- ▶ Delete the call from the list.

Dialled calls

Menu 2.3

This option lets you view the last 40 outgoing calls (called or attempted).

You can also:

- View the number if available and call it, or save it in the phonebook.
- ▶ Enter a new name for the number and save both in the phonebook.
- ▶ Send a message to this number.
- ▶ Delete the call from the list.

Call history

Received calls

Menu 2.4

This option lets you view the last 40 incoming calls. You can also:

- ▶ View the number if available and call it, or save it in the phonebook.
- ▶ Enter a new name for the number and save both in the phonebook.
- ▶ Send a message to this number.
- ▶ Delete the call from the list.

Call duration

Menu 2.5

Allows you to view the duration of your incoming and outgoing calls. You can also reset the call times. The following timers are available:

- ▶ Last call: Duration of the last call.
- ▶ Dialled calls: Duration of the outgoing calls.
- Received calls: Duration of the incoming calls.
- ▶ All calls: Total duration of all calls made and received since the timer was last reset.

Call costs

Menu 2.6

This network service allows you to check the cost of your last call, all calls, remaining and clear all. To reset you will be requested to enter the PIN2 code.

Note

The actual cost invoiced for calls by your service provider may vary, depending on network features, rounding-off for billing, taxes, etc.

Data information

Menu 2.7

You can check the amount of data transferred over the network through the GPRS information option. In addition, you can also view how much time you were online.

Data volume

(Menu 2.7.1)

You can check The Sent, Received or All data volumes for Last data session or All data session and can clear all.

Call time

(Menu 2.7.2)

You can check the duration of Last data session and All data session. You can also reset the call timers by selecting Reset all.

Contacts

Search

Menu 3.1

- 1. In standby mode, press [Contacts].
- 2. Search by pressing [OK].
- If you want to edit, delete, copy an entry, or to add the voice to one, select [Options]. The following menu will be displayed.
- ▶ View: You can see the detail.
- ▶ Edit: You can edit the name and number by using the navigation key.
- New message: After you have found the number you want, you can send a text message to the selected number.
- ▶ Send via: You can send the selected contact via text message or multimedia message.
- ▶ Delete: You can delete an entry.
- ▶ New contact: You can add a new phonebook entry by using this function.
- ▶ Multi delete: You can delete several entries at one time by using this function.
- ► Copy to SIM (Copy to phone): You can copy an entry from SIM to phone or from phone to SIM.

 Main number: You can select a number as main number.

New contact

Menu 3.2

You can add a contact entry using this function. There are 2 memories: Phone memory and SIM memory. To select the memory, go to Contacts - Settings - Memory in use option.

The phone memory capacity is 500 entries. You can enter up to 14 characters in each name in the phone memory. The SIM card memory capacity depends on the SIM card.

Note

- Maximum stored name and number length depends on SIM-card type.
- Press the Menu key and select Contacts → New contact.
- You can add new contact entries to the SIM memory or the phone memory. use (left and right soft key icon) to select the memory.

- Adding new entries into SIM memory: You can enter a name and number, and select the required group. (Depends on the SIM)
- Adding new entries into the phone memory: You can enter a name, and number, and select the required group.

Speed dials

Menu 3.3

You can assign any of the keys, to with a Name list entry. You can call directly by Long pressing this key.

- 1. Open the phonebook first by pressing the Right soft key [Contacts] in standby mode.
- 2. Scroll to Speed dial, then press the left soft key [Select].
- 3. If you want to add Speed dial, select (empty). Then, you can search the name in phonebook.
- Select allocated a name by speed dial, and choose Edit or Delete to edit the name.

Groups

Menu 3.4

You can add up to 20 members per group, with up to a maximum of 5 groups in total.

- Scroll to Caller groups item and every Group list will be displayed.
- 2. Select Group name you want by pressing [Options].
- ▶ View members: Displays the member list in the group.
- Group ringtone: Use this to select the ring tone to be used when you receive a voice phone call from a person in the group.
- Group icon: Allows you to select the icon dependent on Group.
- ▶ Add member: Add a member to the group. You can add up to 20 members per group.
- Remove member: Removes the member from the group member list. The contact entry still remains in Contacts.

Contacts

- Remove all member: Allows you to delete all the members in the group.
- ▶ Rename: Allows you to rename the groups.
- ▶ Reset all: Allows you to reset all group settings.

Copy all

Menu 3.5

You can copy/move entries from the SIM card memory to the phone memory and vice versa.

- 1. Open the Phonebook first by pressing the [Contacts] in standby mode.
- 2. Scroll to Copy all, and then press the [OK] to enter this menu.
- ▶ SIM to Phone: Use this to copy the entries from the SIM Card to Phone memory.
- ▶ Phone to SIM: Use this to copy the entries from the Phone memory to the SIM Card.

Delete all

Menu 3.6

You can delete all entries in SIM and Phone. This function requires Security code.

- 1. Press [Contacts] in standby mode and select Delete all, press [OK].
- 2. Then select a memory to erase.
- 3. Enter security code and Press [OK].

Settings

Menu 3.7

- 1. Press the [Contacts] in standby mode.
- 2. Scroll to Settings, then press the [OK].

View options

You can set the Contact display option.

- ▶ Name only: When you search Contacts, the list displays the names only.
- ▶ Name and number: When you search Contacts, the list displays the names and numbers.
- With pictures: Set the phonebook list with the information and picture of contact.

Information

Menu 3.8

- Service dial number Use this function to access a particular list of services provided by your network operator (if supported by the SIM card).
- ▶ Own number (SIM dependent): You can check your own number in SIM card.
- My business card: This option allows you to create your own business card featuring Name and a mobile phone number. To create a new business card, press the left soft key [[Add]and enter the information into the fields.

Multimedia

Camera

Menu 4.1

This application enables you to take a still picture. You can take a picture in your desired size, and use it for the contacts photo, home screen and other more general purposes. Once taken, a still image can be sent via Multimedia msg or Email.

FM Radio

Menu 4.2

Allows you to receive the FM radio programs.

Voice recorder

Menu 4.3

With the voice memo feature you can record up to 20 voice messages and each memo can be up to 20 seconds long.

My stuff

Images Menu 5.1

- ▶ View: You can see the JPG file by pressing the OK key or selecting View from the Option menu.
- ► Send via multimedia message: You can write and send multimedia messages.
- Send via email: Send the selected file to another device via email if the file size is less than 300Kbytes.
- ► Send via Bluetooth: Send the selected file to another device via Bluetooth.
- Rename: change the file name of selected file. The maximum length of characters is 200. And You can not change the extension of file.
- ▶ Delete: Delete a file.
- ▶ Delete all: Deletes all the files in the list
- ▶ Information: Shows the file information.

Sounds Menu 5.2

After selecting a sound, press the left key [Options]. You can check the options as follow:

- ▶ Set as ringtone: Currently selected sound can be set as a ringtone.
- Write messages: The sound downloaded from network can be sent by SMS or MMS, Email service. Maximum MMS message is 100 kb, and for e-mail is 300 kb.
- Send via Bluetooth: The sound downloaded from network can be sent by Bluetooth.

Others

Menu 5.3

Any type of file can be stored here. This folder is mainly used for transporting files from one PC to another.

- View: You can view a file if it is one of the following types; JPG, GIF, WBMP, PNG and TXT. The handset can preview JPG (Max 460K), GIF (Max 100K).
- ► Send via Bluetooth: Send the selected file to another device via Bluetooth

Games & Apps

Menu 5.4

Default Games: In this menu, you can manage the Java applications installed in your phone. You can play or delete downloaded applications, or set the connect option. The downloaded applications are organised in folders. Press the left soft key [OK] to open the selected slide or launch the selected midlet

Browser

You can access various WAP (Wireless Application Protocol) services such as banking, news, weather reports and flight information. These services are specially designed for mobile phones and they are maintained by WAP service providers.

Check the availability of WAP services, pricing and tariffs with your network operator and/or the service provider whose service you wish to use. Service providers will also give you instructions on how to use their services.

Once connected, the homepage is displayed.

The content depends on the service provider. To exit the browser at any time, press the () key. The phone will return to the idle menu.

Navigating with the WAP browser

You can surf the Internet using either the phone keys or the WAP browser menu.

Using the phone keys

When surfing the Internet, the phone keys function differently to phone mode.

lcon	Description
Ĉ	Scrolls each line of the content area
CLR	Returns to the previous page
	Selects options and confirmation and confirms actions

Using the WAP browser menu

There are various menu options available when surfing the Mobile Web.

Note

► The WAP browser menus may vary, depending on your browser version.

Home

Menu 6.1

Connect to a homepage. The homepage may be the site which is defined in the activated profile. It will be defined by Service Provider if you don't make in activated profile.

Bookmarks

Menu 6.2

This menu allows you to store the URL of favourite web pages for easy access at a later time.

To create a bookmark

- 1. Press the left soft key [Options].
- 2. Select Add new and press the OK key.
- After entering the desired URL and title, press the OK key.

After selecting a desired bookmark, the following options are available.

- ▶ Connect: Connects to the selected bookmark.
- ▶ Add new : Select this to create a new bookmark.
- Edit: You can edit the URL and/or the title of the selected bookmark.
- ▶ Delete : Deletes the selected bookmark.
- ▶ Delete all: Deletes all the bookmarks.

Go to URL

Menu 6.3

You can connect directly to the site you want. After entering a specific URL, press the OK key.

History

Menu 6.4

Keep the history you have browsed.

Settings

Menu 6.5

You can set the profile, cache, cookie and security related to internet service.

Information

Menu 6.6

To view the detail information of the borwser menu.

Alarm clock

Menu 7.1

You can set up to 5 alarm clocks to go off at a specified time.

- 1. Select On and enter the alarm time you want.
- 2. Select the repeat period : Once, Mon ~ Fri, Mon ~ Sat, Everyday.
- 3. Select the alarm tone you want and press [OK].
- 4. Edit the alarm name and press [OK].

Calendar Menu 7.2

When you enter this menu, a calendar appears. A square cursor is located on the current date. You can move the cursor to another date using the navigation keys. On the calendar, you can use the following keys. You can enter a schedule or memo in the scheduler by pressing the left soft key [Options].

Add new: Select this to enter a new schedule or memo. After a schedule note is entered on a date, the date is shown in a different colour and appears on the right bottom of the screen. This function

- reminds you of your schedule. And the phone will sound an alarm tone if you set the phone to do so.
- View: Shows the schedule note or memo for the chosen day. Press the left soft key [Options] to edit or delete the note you selected.
- ▶ Delete entries: Select this to delete Past entries, Date entries and All entries.
- Go to: You can view the enter date in scheduler quickly by use this menu.

Calculator

Menu 7.3

The calculator provides the basic arithmetic functions: addition, subtraction, multiplication and division.

- 1. Enter the first number using the numeric keys.
- Press the corresponding navigation key to select a mathematical function.

Note

- ➤ To erase any mistake or clear the display, use the weekey.
- ▶ To include a decimal point, press the 🖿 key.
- ▶ To include a minus sign, press the 📷 key.

- 3. To calculate the result, press the left soft key [Result] or OK key.
- 4. After calculation, press the left soft key [OK] to return to the initial state.

Memo

Menu 7.4

- 1. Select the Memo by pressing the [OK].
- 2. If the entry is empty, press the [Add].
- 3. Input the memo and then press the [OK].

Note

If you want to change the text input mode, press the <a> in order.

To do

Menu 7.5

This option allows you to set your own to do list.

Stopwatch

Menu 7.6

This option allows you to use the function of stopwatch.

Unit converter

Menu 7.7

This converts any measurement into a unit you want. There are 6 types that can be converted into units: Surface, Length, Weight, Temperature, Volume and Velocity.

- 1. Select one of six unit types by pressing the left soft key [Unit].
- 2. Select the standard value by using **[**].
- 3. Select the unit you want to convert by pressing
- You can check the converted value for the unit you want. Also, you can input a decimal number by pressing

World clock

Menu 7.8

You can check the current time of Greenwich Mean Time (GMT) and major cities around the world, using the left/right navigation keys.

The screen shows the city name, current date and time.

To select the time zone in which you are located, proceed as follows:

- Select the city corresponding to your time zone by pressing the left/right navigation keys one or more times. The local date and time are displayed.
- If you want to change the time display in standby mode to the selected time, press the left soft key and select Set.

SIM Service

Your service provider can offer special applications through the SIM card. If you are registered for one of these services, the service name will appear at the end of the Main Menu. With the SIM Services menu your phone is future-proof and will support additions to your service provider's service. For more information contact your service provider.

Settings

Settings

You can set the following menus for your convenience and preferences.

Date & Time

Menu 9.1

You can set functions relating to the date and time.

Set date

Set date

You can enter the current date.

Date format

You can set the Date format such as DD/MM/YYYY, MM/DD/YYYY, YYYY/MM/DD. (D: Day / M: Month / Y: Year)

Set time

Set time

You can enter the current time.

Time format

Your can set the time format between 24-hour and 12-hour.

Languages

Menu 9.2

You can change the language for the display texts in your phone. This change will also affect the Language Input mode.

Profiles

Menu 9.3

Allowing you to active, change or personalize phone's profiles.

Display

Menu 9.4

Wallpaper

(Menu 9.4.1)

You can select the background pictures in standby mode.

- Default: You can select a picture or an animation of wallpaper by pressing .
- My folder: You can select a picture or an animation as wallpaper.

Backlight timer

(Menu 9.4.2)

You can set the light-up duration of the display.

Brightness

(Menu 9.4.3)

The screen brightness can be adjusted from 40% to 100%.

Home screen shortcut

(Menu 9.4.4)

Selecting On displays the functionalities of 4 Navigation keys and Menu key as pictures on the middle of the idle window.

Theme

(Menu 9.4.5)

You can select the themes of wallpaper.

Menu style

(Menu 9.4.6)

Selecting the menu display style.

Standby text

(Menu 9.4.7)

If you select On, you can edit the text which is displayed in standby mode.

Network name

(Menu 9.4.8)

If this function is activated, network name will be displayed on main LCD.

Colourful dial font

(Menu 9.4.9)

You can select the background pictures in standby

Network

Menu 9.5

You can select a network which will be registered either automatically or manually. Usually, the network selection is set to Automatic.

Network selection

(Menu 9.5.1)

Automatic

If you select Automatic mode, the phone will automatically search for and select a network for you. Once you have selected "Automatic", the phone will be set to "Automatic" even though the power is off and on.

Manual

The phone will find the list of available networks and show you them. Then you can select the network which you want to use if this network has a roaming agreement with your home network operator.

Preferred

You can set a list of preferred networks and the phone attempts to register with first, before attempting to register to any other networks. This list is set from the phone's predefined list of known networks.

Change frequency band

(Menu 9.5.2)

The following 2 frequency band are available for selection:

GSM850 PCS

DCS_only

GPRS attach

(Menu 9.5.3)

You can set the GPRS service depending on various situations.

Power on

If you select **Power on** and you are in a network that supports GPRS, the phone registers to the GPRS network and sending short messages will be done via GPRS.

When needed

If you select When needed, the phone will use a GPRS connection only if you start an application or action that needs it. The GPRS connection is closed after it is no longer required by any application.

Access point

(Menu 9.5.4)

Allows you to view, edit or reset the access point list.

Call

Menu 9.6

You can set the menu relevant to a call by pressing OK in the Setting menu.

Call divert

(Menu 9.6.1)

The Call divert service allows you to divert incoming voice calls, fax calls, and data calls to another number.

For details, contact your service provider.

- ▶ All voice calls: Diverts voice calls unconditionally.
- ▶ If busy: Diverts voice calls when the phone is in use.
- ▶ If no reply: Diverts voice calls which you do not

Settings

answer.

- ▶ If out of reach: Diverts voice calls when the phone is switched off or out of coverage.
- All data calls: Diverts to a number with a PC connection unconditionally.
- ▶ All fax calls: Diverts to a number with a fax connection unconditionally.
- Deactivate all: Cancels all call divert service.

The submenus

Call divert menus have the submenus shown below.

- ▶ Activate: Activate the corresponding service.
 - To voice mail centre: Forwards to message centre. This function is not shown at All data calls and All fax calls menus.
 - To other number: Inputs the number for diverting.
- To favourite number: You can check back to last five diverted numbers.
- ▶ Cancel : Deactivate the corresponding service.
- View status: View the status of the corresponding service.

Answer mode

(Menu 9.6.2)

▶ Flip open

If you select this menu, you can receive an incoming call when only opening flip.

► Any key

If you select this menu, you can receive a call by pressing any key except [End] key.

► Send Key only

If you select this menu, you can receive a call by only pressing [Send] key.

Send my number

(Menu 9.6.3)

(network and subscription dependent)

▶ On

You can send your phone number to another party. Your phone number will be shown on the receiver's phone.

▶ Off

Your phone number will not be shown.

▶ Set by network

If you select this, you can send your phone number depending on two line service such as line 1 or line 2.

Call waiting (network dependent) (Menu 9.6.4)

Activate

If you select On, you can accept a waiting (receiving) call.

▶ Deactivate

If you select Off, you cannot recognize the waiting (receiving) call.

View status

Shows the status of Call waiting.

Minute minder

(Menu 9.6.5)

If you select On, you can check the call duration by beep sound every minute during a call.

Auto redial

(Menu 9.6.6)

▶ On

When this function is activated, the phone will automatically try to redial in the case of failure to connect a call.

▶ Off

Your phone will not make any attempts to redial when the original call has not connected.

Select line

(Menu 9.6.7)

You can select from line 1 and line 2.

Closed user group

(Menu 9.6.8)

You can set this function to be on or off.

Send DTMF tones

(Menu 9.6.9)

Sets the DTMF tones on or off.

Answering phone

(Menu 9.6.0)

Sets the time when the answering phone function to be deactivated.

Carrier selection

(Menu 9.6.*)

Carrier Selection

CSP(Carrier Selection Provisioning) makes easier for the user choose any carrier whenever s/he wants and mobile phones insert automatically the chosen carrier number when a long distance call is made.

When making a long distance call, user has to dial a CSP number that corresponds to the carrier s/he wants to request the service.

0XX99803311, XX = CSP number.

099803311 = calling number

CSP feature has three modes: Manual / List/ Automatic.

Manual: The mobile phone shall ask the CSP number (two digits) before attempt to make a long distance call.

List: The mobile phone shall display a list of carriers that has been defined by the user before. Phone will add the CSP number according to the chosen carrier.

Automatic: The mobile phone shall automatically insert CSP numbers of carrier previously defined as favorite by the user.

- 1. Press , , , .
- 2. Press Left Soft Key Select or .
- On/Off
- Operation mode: Manual / List / Automatic
- Carrier List: allows you to add/ delete/ edit/set favorite carriers on the list.

Security

Menu 9.7

PIN code request

(Menu 9.7.1)

In this menu, you can set the phone to ask for the PIN code of your SIM card when the phone is switched on. If this function is activated, you'll be requested to enter the PIN code.

- 1. Select PIN code request in the security settings menu, and then press [OK].
- 2. Set Enable/Disable.
- If you want to change the setting, you need to enter PIN code when you switch on the phone.
- 4. If you enter the wrong PIN code more than 3 times, the phone will lock out. If the PIN is

blocked, you will need to key in the PUK code.

 You can enter your PUK code up to 10 times. If you enter the wrong PUK code more than 10 times, you can not unlock your phone. You will need to contact your service provider.

Phone lock

(Menu 9.7.2)

You can use a security code to avoid unauthorised use of the phone. Whenever you switch on the phone, the phone will request a security code if you set the handset lock to **On**.

Call barring

(Menu 9.7.3)

The Call barring service prevents your phone from making or receiving certain category of calls. This function requires the call barring password. You can view the following submenus.

▶ All outgoing

The barring service for all outgoing calls.

Outgoing international
 The barring service for all outgoing international calls.

Outgoing international when roaming The barring service for all international outgoing calls except home network.

▶ All incoming

The barring service for all incoming calls.

Incoming when abroad

The barring service for all incoming calls when roaming.

Deactivate all

You can cancel all barring services.

▶ Change password

You can change the password for Call Barring Service.

The submenus:

Activate

Allows to request the network to set call restriction on.

Disable

Set the selected call restriction off.

View status

View the status whether the calls are barred or not.

Fixed dial number

(Menu 9.7.4)

(SIM dependent)

You can restrict your outgoing calls to selected phone numbers. The numbers are protected by your PIN2 code.

Activate

You can restrict your outgoing calls to selected phone numbers.

Deactivate

You can cancel fixed dialling function.

▶ Number list

You can view the number list saved as Fixed dial number.

Change codes

(Menu 9.7.5)

PIN is an abbreviation of Personal Identification Number to prevent use by an unauthorised person.

You can change the access codes: PIN2 code, Security code.

- If you want to change the Security code/PIN2 code input your original code, and then press
 [OK].
- Input new Security code/PIN2 code and verify them.

Flight mode

Menu 9.8

Allows you to set the phone to be flight mode.

Power save

Menu 9.9

Setting the phone to be power save mode.

Reset

Menu 9.0

You can initialise all factory defaults. You will need the Security code to activate this function.

Memory status

Menu 9.*

You can check the capacity of free memory.

Accessories

There are various accessories for your mobile phone. You can select these options according to your personal communication requirements.

Standard Battery



Travel Adapter

This charger allows you to charge the battery.



Note

- Always use genuine LG accessories. Failure to do this may invalidate your warranty.
- Accessories may be different in different regions; please check with our regional service company or agent for further inquires.

Technical data

General

Product name: MG140a

System : GSM 900 / DCS 1800

Ambient temperatures

 $Max: +55^{\circ}C$

Min : -10°C

Declaration of Conformity



Suppliers Details

LG Electronics Inc Address : LG Twin Tower 20, Yeouido-dong, Yeongdeunpo-gu, Seoul, Korea 150-721

Product Details

Product Name

E-GSM 900 / DCS 1800 Dual Band Terminal Equipment

Model Name

MG140a

Frade Name 2

Applicable Standards Details

R&TTE Directive 1999/5/EC

EN 301 511 V9.0.2 EN 300 528 9 V16. EN 301 489-01 V15.1 FN 301 489-07 v12.1 / EN 301 489-17 v12.1 EN 50360: 2001 / EN 50361: 2001

EN 60950-1: 2001

Supplementary Information

The conformity to above standards is verified by BABT.

Declaration

I hereby declare under our sole responsibility that the product mentioned above to which this declaration relates compiles with the above mentioned standards and Directives

LG Electronics Logistics and Service B.V. Veluwezoom15, 1327 AE Almere, The Netherlands Tel:+31-36-547-8940, e-mail:seokim @ Ige.com

29 Jun 2006 ssued Date

Jin Seog, Kim / Director

Name

Signature of representative

63