outside line ringing tone.

- 5) press L1 button to answer the PSTN call
- 6) OFF button to quit when finishing the conversation
- 7) Press IP button to retrieve skype call which was put on hold

## 7.skypein/skypeout conference

To conduct conference (the max people is followed by skype rule) via Dual Cordless handset

- 1) Press IP button, the LCD displays Phonebook SK,
- 2) Press OK to get the first record of contact,
- 3) Use UP or DOWN button to scroll the contact your want
- 4) Press OK to get the contact into the conference pool
- 5) Keep scrolling UP or DOWN button to select the next contact
- 6) Press OK to get the second contact into the pool,
- 7) Repeat the step 3 to step 4 to select more contacts
- 8) Press IP button to link with all contacts you've selected

# 8. the calls of skypein/skypeout from one handset to another

The first handset can make skype call transfer to the second handset.

Under the skype/SkypeOut talking mode, the Dual Cordless handset LCD display: "HS01 HOLD",

- 1) Select HOLD by pressing right softkey,
- 2) Dial HS number, for example "02", the handset 02 will be ringing
- 3) Handset 01 may talk to Handset 02, then handset 01 press OFF to leave
- 4) The skype call is transferred to Handset 02.
- 5) Handset 02 to press OFF to end skype conversation.

# 9. volume control during skype conversation

Under skype conversation,

- 1) Press Left Shift button to reduce the volume..
- 2) Press Right Shift button to increase the volume

## 10. skype caller ID

User may check the skype caller ID status: 01 Received Calls,

- 02 Missed Calls, 03 Dialed Calls
- 1) Press PC button to enter into skype mode,
- 2) Press UP or DOWN button to review: 01 Received Calls, 02 Missed Calls, 03 Dialed Calls,
- 3) to select missed calls, press OK button,
- 4) the LCD displays the first record of missed call, the online status (ON status or OFF status), the date and time, the ON status is the contact is on the line; the OFF status is the contact is off the line.

#### 11. skype caller ID call back

User may check the skype caller ID status: 01 Received Calls, 02 Missed Calls, 03 Dialed Calls,

- 1) Press IP button to enter into skype mode,
- 2) Press UP or DOWN button to review: 01 Received Calls, 02 Missed Calls, 03 Dialed Calls,
- 3) to select missed calls, press OK button,
- 4) the LCD displays the first record of missed call, the online status (ON status or OFF status), the date and time, the ON status is the contact on the line; the OFF status is the contact off the line
- 5) to call back the caller ID, just press IP to dial out.

# chapter3 Normal phone operation

## 1.place a call via handset unit

- 1) Press LINE 1 button to get a dial tone.
- 2). Dial the wanted number,
- 3). You will hear the dial tone.
- 4). to end conversation, press OFF button.

#### 2.To answer a call via handset

- 1) To lift the handset from cordless base.
- 2) When the handset is not in charger cradle, press any key to answer the call
- 3)to end of conversation, press OFF button

## 3. Putting a call on hold via handset

When handset is under conversation, the display showing "  $\mbox{CONF}$  HOLD "

- 1) to select HOLD function by press left soft key, the display shows that the call is on hold. The Line 1 indicator is lighting on.
- 2) Handset to retrieve the call, press the LINE 1 button which is still lighting on.

#### 4. To make a call from redial list

- 1) Under Standby mode, press RD button
- 2) scroll UP and DOWN to select the number,
- 3) Press L1 button to dial out.

The system will automatically assign the free C/O line for dialing out. The top on LCD display LI is displayed which indicates the line are in use. There are 10 recent dialed numbers saved on handset.

## 5. Control the receiver volume

While you are on the telephone, you can press UP button or the DOWN button for soft or loud receiver volume. When you have completed your call, the receiver volume returns to default.

## 6. Handset-to-Handset Inter com

Under standby mode,

- 1) Handset-01 press INT button, and dial the handset number, for example, 02
- 2) the handset-02 will ring. Handset-02 to pick up the phone by pressing any key.

## 7. Base page to Handset

- 1) Base press Page button,
- 2) All handsets will be ringing.
- 3) Any handset is pick up, the ringing tone is stop.

Note: When base page to handset, handset will be ringing, but base couldn't talk to handset.

#### 8. Caller ID call back

Place Call by Caller ID record

- 1) Under Standby mode, press UP or DOWN button, the screen shows
- " NEW CALL # TOTAL CALL# ", for example " 01 16 ", means 1 new call, and total 16 calls of caller ID. If user has reviewed the new call, then the display become to show " 00 16 ".
- 2) press UP button, the screen shows the latest (the last) Caller ID number, keep pressing UP button again, it shows the next latest Caller ID number. Keep pressing UP button to review the rest of caller ID records until to display "END OF LIST", then to start to show the latest caller ID record again. (press DOWN button, the screen shows the first caller ID number)
- 3) Select the phone number & name by scroll UP or DOWN button,
- 4) Press OK to dial out the wanted number.

#### 9. To save Caller ID into handset Phone book

- 1. Under Standby mode, press UP or DOWN button, the screen shows "NEW CALL # TOTAL CALL#". Press UP or DOWN button again, the screen shows the latest caller ID number.
- 2. Scroll UP or DOWN button to select the phone number

## 6. Handset-to-Handset Inter com

Under standby mode,

- 1) Handset-01 press INT button, and dial the handset number, for example, 02
- 2) the handset-02 will ring. Handset-02 to pick up the phone by pressing any key.

## 7. Base page to Handset

- 1) Base press Page button,
- 2) All handsets will be ringing.
- 3) Any handset is pick up, the ringing tone is stop.

Note: When base page to handset, handset will be ringing, but base couldn't talk to handset.

#### 8. Caller ID call back

Place Call by Caller ID record

- 1) Under Standby mode, press UP or DOWN button, the screen shows
- " NEW CALL # TOTAL CALL# ", for example " 01 16 ", means 1 new call, and total 16 calls of caller ID. If user has reviewed the new call, then the display become to show " 00 16 ".
- 2) press UP button, the screen shows the latest (the last) Caller ID number, keep pressing UP button again, it shows the next latest Caller ID number. Keep pressing UP button to review the rest of caller ID records until to display "END OF LIST", then to start to show the latest caller ID record again. (press DOWN button, the screen shows the first caller ID number)
- 3) Select the phone number & name by scroll UP or DOWN button,
- 4) Press OK to dial out the wanted number.

#### 9. To save Caller ID into handset Phone book

- 1. Under Standby mode, press UP or DOWN button, the screen shows "NEW CALL # TOTAL CALL#". Press UP or DOWN button again, the screen shows the latest caller ID number.
- 2. Scroll UP or DOWN button to select the phone number

3. Press & hold down the FLASH button (long key) to save the caller ID number into handset phonebook..

#### 10. Phonebook Dialing(via handset)

- 1) Under the Standby mode, press Right softkey (MENU) button,
- 2) scroll UP or DOWN button to select "PHONE BOOK on screen, press OK button,
- 3) The screen displays the recent new phonebook number,
- 4) scroll UP or DOWN button to locate the wanted phone book number,
- 5) press OK button to dial out

## 11. Handset out-of-range warning

If you are too far away from base unit while talking via handset, the Handset emits "beep - beep" sounds to warn you. The sound from handset will be mute when you step out of talking range, at this time, you should go back to base range to resume handset conversation. Otherwise, the call will automatically cut off if handset leaving base range too long.

#### 12. Call transfer

When Handset is in conversation with outside line, you can transfer the call from handset to another handset. ( Handset use two soft keys under LCD screen: Right button and Left button to operate Call transfer function)

#### 13.Call transfer from handset to handset

- 1) Under the talking mode on handset, screen shows "CONF HOLD",
- 2) Select HOLD by pressing Right softkey on handset, screen shows "NO: RETRV ",
- 3) press Left softkey, the screen shows "HS NO: "waiting for dialing handset number,
- 4) Dial handset number, for example, "02" (the second handset #), then press OK button.
- 5) the hanset-02 will ring. The handset-02 press any key (or OK button) to pick up the call.
- 6) The first handset press OFF button.