



### Multimedia system overview




① Touch control

② Media display

③ NAVI, RADIO, MEDIA, TEL,   
keys, call main functions

④ Controller

⑤ Control dial, set volume and switch  
sound on and off

⑥  button, switch multimedia  
system on and off

⑦ Touchpad

Touch control ①, controller ④ and  
touchpad ⑦ are the central operating  
controls.

Further aspects:

- Display
- Central operating controls
- Touchpad
- Controller
- Touch control
- Call main functions
- Switch sound on and off
- Switch volume on and off
- Use character input

### Media display instructions

**! NOTE** Scratches on the display

The display has a very sensitive high-gloss surface. There is a scratch risk. Avoid touching the display. Follow the cleaning instructions.

Follow the instructions on maintaining the interior compartment.

#### **Automatic temperature shutoff:**



If the temperature is too high, the brightness will be reduced first. The media display can then temporarily shut down completely.

**i** If you wear polarized sunglasses, readability of the display can be made more difficult or may be limited.

## Telephony

### Telephone menu overview

Language-neutral

- ① Cell phone network provider
- ② Cell phone network strength
- ③ Handset symbol  or 
- ④ Bluetooth® device name of the cell phone currently connected

- ⑤ Telephone menu character list
- ⑥ Character input via touchpad
- ⑦ Display telephone book

For telephony the Bluetooth® interface and optional telephone module with Bluetooth® (SAP profile) are available. In the **Telephony via Bluetooth® interface** mode the cell phone is connected directly via the multimedia system.

Descriptions ① to ④ will only be shown once a cell phone is connected to the multimedia system. The descriptions are dependent on your cell phone and cell phone network provider.

If the connected cell phone supports the Bluetooth® profile MAP (**M**essage **A**ccess **P**rofile), the menu item **SMS** shall be available.

### General instructions for telephony

**⚠ WARNING** Risk of distraction from using integrated communication devices while driving

Using integrated communication devices while driving distracts you from traffic events. In addition you could lose control of the vehicle.

- ▶ Only use these devices if traffic conditions permit it.
- ▶ If this cannot be guaranteed, stop in keeping with traffic regulations and make the entries when the vehicle is stationary.

**⚠ WARNING** Risk of distraction from using mobile communication devices while driving

Using mobile communication devices while driving distracts you from traffic events. In addition you could lose

control of the vehicle.  
Only use these devices when the vehicle is stationary.

**⚠ WARNING** Risk of accident due to improper use of RF transmitter.

If you use RF transmitters improperly their electromagnetic radiation can damage the vehicle electronics, e.g. if

- the RF transmitter is not connected to an external antenna.
- the external antenna is mounted incorrectly or is non-reflecting.

By doing this you could damage the operational safety of the vehicle.

- ▶ Have the non-reflecting antenna installed by a qualified specialist workshop.

- ▶ During use in the vehicle, always connect RF transmitters to the non-reflecting external antenna.

Telephony is possible via the following connections:

- Bluetooth® interface
- Telephone module with Bluetooth® (SAP profile)

Bluetooth® profile	Function
PBAP (Phone Book Access Profile)	Contacts are automatically displayed in the multimedia system
MAP (Message Access Profile)	Message functions can be used

When connecting, the multimedia system always searches for the most recently connected telephone.

Further information is available at a Mercedes-Benz service point or at: <http://www.mercedes-benz.com/connect>

## Connecting a cell phone

### Prerequisite


Switch on Bluetooth®.

Multimedia system:

 **Telephone**  **Connect new device**

### Searching for a cell phone

- ▶ Select **Start search**.

The cell phones available will be displayed. A newly found cell phone will be marked with the symbol .

### Connecting a cell phone

#### Authorization via Secure Simple

#### Pairing

- ▶ Select cell phone.

A code will be displayed in the multimedia system and on the cell phone.


#### Codes concur

- ▶ **Multimedia system:** Select **Yes**.
- ▶ **Cell phone:** Confirm code.

#### Codes are different

- ▶ **Multimedia system:** Select **No**.  
The operation will be canceled.

## Authorization via Passkey entry (identification)

- ▶ Select the Bluetooth® name of the cell phone.
- ▶ Choose a one to six-digit sequence of numbers as a Passkey.
- ▶ **Multimedia system:** Enter Passkey.
- ▶ Confirm with .
- ▶ **Cell phone:** Enter Passkey again and confirm.
- Depending on the cell phone you may have to confirm the connection to the multimedia system both for Bluetooth® and MAP.
- Up to 15 cell phones can be authorized on the multimedia system.  
All phones are automatically reconnected.

## Disconnecting (deauthorizing) cell phones

Multimedia system:

 Telephone  Connect new device

- ▶ Select the desired cell phone.

- ▶ Select .
- ▶ Select [Deauthorize](#).
- ▶ Confirm with [Yes](#).

## Changing cell phone

### Prerequisite

Cell phones must be first authorized (▶ page 54).

Multimedia system:

 Telephone  Connect new device

- ▶ Select the desired cell phone from the list of devices.

- ❗ Only one cell phone can be connected at one time. The currently connected cell phone is indicated with a point ●.


## Setting the receiving and transmitting volume

### Prerequisite

Cell phones must be first authorized (▶ page 54).

Multimedia system:

 Telephone  Connect new device

- ▶ Mark the desired cell phone from the list of devices.
- ▶ Select .
- ▶ Select [receiving or transmitting volume](#).
- ▶ Select desired volume.

## Making a phone call

### Making a phone call

Multimedia system:

 Phone  Contacts

### Making a call

- ▶ Enter number.
- ▶ Select [Select number](#).
- The call will be made.

### Accepting a call.

- ▶ Select [Accept](#).

### Rejecting a call.

- ▶ Select [Reject](#).

### Ending a call

- ▶ Select .



## Internet connection

### Internet connection restrictions

**⚠ WARNING** Risk of distraction from information systems and communications devices

Using information systems and communication devices while driving distracts you from traffic events. In addition you could lose control of the vehicle.

- ▶ Only use these devices if traffic conditions permit it.
- ▶ If this cannot be guaranteed, stop in keeping with traffic regulations and make the entries when the vehicle is stationary.

### Unhandled element [section/context]

When using the multimedia system, observe the legal requirements of the country in which you are located at the time.

Internet access may be impaired or not functional if:

- The cell phone is switched off.
- There is insufficient cell phone network coverage.
- Internet access has not been enabled on the cell phone.
- The Bluetooth® function on the multimedia system is switched off and the desired phone is supposed to be connected via Bluetooth®.
- The Bluetooth® function on the cell phone is switched off and the phone needs to be connected via Bluetooth®.
- The cell phone network or the cell phone do not allow a phone and Internet connection to be used simultaneously.
- Internet capability via Bluetooth® is not enabled on the cell phone.

While driving, the Internet functions can only be used to a limited extent.

## Establishing an Internet connection

### Prerequisites

- Connect a cell phone to the multimedia system via Bluetooth® or USB.
  - Set up the login details of the cell phone network provider for the connected cell phone in the multimedia system. Using incorrect login details can incur additional charges.
  - If you use the telephone module for the Internet function, you require a SIM card in the phone module or a Bluetooth®-enabled cell phone.
- In order to connect via Bluetooth® the cell phone must support one of the following Bluetooth® profiles:
- DUN (Dial-Up Networking)
  - PAN (Personal Area Network)

### 3 Online and Internet functions

In order to connect via USB the cell phone must support one of the following USB classes:


- RNDIS (Remote Network Driver Interface Specification)
- CDC/NCM (Network Control Model)
- CDC/ECM (Ethernet Control Model)
- CDC/ACM (Access Control Model)

More details are available at <http://www.mercedes-benz.com/connect> or at a Mercedes-Benz service point.

Multimedia system:

 [System settings](#)  [Connectivity](#)

 [Internet settings](#)

- ▶ Select cell phone.
- ▶ Select .
- ▶ Select [Change configuration](#).
- ▶ Switch on [Automatic configuration](#) ☒. If the cell phone supports the Bluetooth® profile PAN or the USB classes RNDIS, CDC/NCM or CDC/ECM, an Internet connection will be established. You can use

the Internet function. If the cell phone does not support the specified Bluetooth® profile or USB classes, pre-defined or manual login details must be set up.

#### Selecting pre-defined cell phone network provider login details

- ▶ Select [Configure using COMAND](#).
- ▶ Select [Pre-defined settings](#).
- ▶ Select your cell phone network provider's country.  
A list of the available providers will appear.
- ▶ Select your own cell phone network provider.  
An overview of the provider settings will appear.
- ▶ Select [Confirm setting](#).

#### Manually setting up cell phone network provider login details

- ▶ Select [Configure using COMAND](#).
- ▶ Select Manual settings.  
An overview of the provider settings will appear.
- ▶ Set up the login details.

- ▶ Select [Confirm setting](#).

- ❗ Set the login details up according to your data tariff. You can request the exact login details from your cell phone network provider.

#### [Setting up an Internet connection](#)

##### Prerequisites

- Hermes data module is activated and ready for use.
- Hermes data module is activated for Mercedes-Benz Apps and Internet access.
- Mercedes-Benz Connect is activated and ready for use.
- Mercedes-Benz Connect is activated for Mercedes-Benz Apps and Internet access.

**USA:** In order to use Mercedes-Benz Apps and Internet access, mbrace must be activated and ready for use. In addition, mbrace must be activated for Mercedes-Benz Apps and Internet access.



**Canada:** Cell phones must be connected to the multimedia system via Bluetooth® or USB. In addition, you require a valid cell phone contract with a data option through which the connection costs arising are charged.

Multimedia system:

 [Connect](#)







 e.g. Select [Browser](#)

### Editing login details

Multimedia system:

 [System settings](#)  [Connectivity](#)

 [Internet settings](#)

-  Select cell phone.
-  Select .
-  Select [Change configuration](#).
-  Select [Configure using COMAND](#).
-  Select [Predefined Settings](#) or [Manual settings](#).

The provider's settings will be displayed.






-  Set up login details.

### Removing a cell phone's Internet access

Multimedia system:

 [System settings](#)  [Connectivity](#)

 [Internet settings](#)





-  Select cell phone.
-  Select .
-  Select [Delete configuration](#).
-  Select [Yes](#).

### Displaying cell phone details

Multimedia system:

 [System settings](#)  [Connectivity](#)

 [Internet settings](#)






-  Select cell phone.
-  Select .
-  Select [Details](#).

### Setting up a permanent Internet connection

Multimedia system:

 [System settings](#)  [Connectivity](#)

 [Internet settings](#)






-  Select cell phone.
-  Select .
-  Select [Permanent Internet connection](#).
-  Switch function off ☐ or on ☒.

### Setting up an automatic Internet disconnection

Multimedia system:

 [System settings](#)  [Connectivity](#)


 [Internet settings](#)

-  Select cell phone.
-  Select .
-  Select [Disconnect if inactive](#).
-  Select [5 minutes](#), [10 minutes](#) or [Unlimited](#).

### Connection status



#### Connection status overview



- i** Existing connection and signal strength of the cell phone network are displayed here.

#### Displaying connection status

##### Multimedia system:

-  **System settings**  **Connectivity**  
 Select **Internet status**.

##### Disconnecting

-  Select **Disconnect**.

#### Calling Mercedes-Benz Apps

##### Prerequisites

- Register to use Mercedes-Benz Apps.
- Confirm the terms and conditions.

##### Multimedia system:

-  **Connect**  **MB Apps**  
 Select App.

Further Mercedes-Benz Apps and information are available at:  
<http://apps.mercedes-benz.com/apps/>

- i** The offer depends on country.  
**i** License fees may apply.

#### Web browser



##### Viewing websites


Multimedia system:

 **Connect**  **Browser**


 **Enter URL**

 Enter web address.

 **To end the input and view website:**  
select .

 While driving websites cannot be displayed.

## Web browser overview



① URL input

② Previous page

③ Next page

④ Refresh/cancel

⑤ Options

⑥ Close browser

## Viewing web browser options

Multimedia system:



 **Connect**  **Browser**

  **Options**

The following functions can be selected:

- **Bookmark**
- **Zoom**
- **Font size**
- **Browser settings**

- **Delete browser data**

 Select Option.  
 Adjust settings.

## Viewing web browser settings

Multimedia system:

### 3 Online and Internet functions

 [Connect](#)  [Browser](#)

  [Options](#)

 [Browser settings](#)

The following functions can be selected:

- [Block popups](#)
- [Activate Javascript](#)
- [Allow cookies](#)
- [Smart scroll](#)
- ▶ Switch function off ☐ or on ☒.

#### Deleting Internet history

Multimedia system:

 [Connect](#)  [Browser](#)

  [Options](#)

 [Delete browser data](#)

The following functions can be selected:

- [All](#)
- [Cache](#)
- [Cookies](#)
- [Entered URLs](#)
- [Form data](#)

▶ Select option

▶ Select [Yes](#).

#### Setting up Internet favorites

Multimedia system:

 [Connect](#)  [Browser](#)

  [Options](#)  [Bookmarks](#)

#### **Selecting favorites**

▶ Select bookmarks.

#### **Creating favorites**

▶ Select [Add new bookmark](#).

▶ Enter URL and name.

▶ Select .

#### **Editing favorites**

▶ Select bookmarks.

▶ Select [Edit](#).

▶ Enter URL and name.

▶ Select .

#### **Deleting favorites**

▶ Select [Delete](#).

▶ Select [Yes](#).

#### Ending a browser session

Multimedia system:

 [Connect](#)  [Browser](#)

▶ Select [Close browser](#).

▶ Select [Yes](#).

#### **Internet radio**

#### Calling up Internet radio


#### **Prerequisites**

- Purchase data volume.
- A fast Internet connection for an interference-free transmission.
- Activate the service via Mercedes connect me.
- ❗ The connection quality depends on the local cell phone reception.

Multimedia system:

 [Radio](#)  [Online services](#)

## Audio overview



① Active data carrier

② Cover

③ Artist, track and album

④ Track number and number of tracks in the track list

⑤ Search

⑥ Devices

⑦ Online services

⑧ Media favorites

⑨ Options

⑩ Sound settings

## Connecting USB devices

**! NOTE** Damage at high temperatures

High temperatures can damage USB devices.

▶ After use extract USB devices and remove them from the vehicle.

The multimedia connection unit is located in the storage compartment under the armrest. Two USB ports are available.

▶ Connect the USB device to the USB port.  
If the related media display is switched on, playable music data will be played.

## Selecting tracks


Multimedia system:

 **Media** 

### By skipping track

- ▶ **Skip forwards or backwards to a track:** Navigate up or down.

### Via current track list

- ▶ Select .
- ▶ Select **Current track list**.
- ▶ Select track.

## Selecting playback options

Multimedia system:

 **Media**   **Options**

### Playing similar tracks




- ▶ Select **Play similar tracks**.
- A track list with comparable tracks will be created and played.

## Play mode

- ▶ Select **Play mode**.
- ▶ Select **Standard track order**.  
The current track list will be played in the order existing on the data carrier.
- ▶ Select **Shuffle current track list**.  
The current track list will be played in random order.
- ▶ Select **Shuffle current data carrier**.  
All tracks on the data carrier will be played in random order.

## Pause and playback option

Multimedia system:

-  **Media** 
- ▶ Press touchpad or controller.
- ▶ **Pause playback:** select .

- ▶ **Resume playback:** select .

### Fast forward/rewind

- ▶ Move controller left or right .

## Video


### Switching on video

Multimedia system:

 **Media**  **Devices**

- ▶ Select data carrier.  
Playable video files will be played.
- ▶ **i** The multimedia system supports the MPEG, AVI and MP4 formats.  
Due to the wide variety of available video files with respect to encoders, refresh rate and bit rate, playback cannot be guaranteed.

## Video overview



① Active data carrier

② Cover

③ Track and scene

④ Track number and number of tracks in the track list

⑤ Search

⑥ Devices

⑦ Media list

⑧ Options

⑨ Sound settings

⑩ Full screen

## Turning full screen mode on/off

Multimedia system:

Media Devices

▶ Select data carrier.

Playable video files will be played.

### ▶ Turning on full screen mode:

Select Full screen.

### ▶ Turning off full screen mode:

Press touchpad or controller.

## Adjusting video settings

Multimedia system:

Media Options

### Image format

The following image formats are available:

- Automatic
- 16:9
- 4:3

- [Zoom](#)

 Select image format.

### Setting brightness manually

 Select [brightness](#)

 Set brightness

## Media search

### Start media search


Multimedia system:

 [Media](#)   [Search](#)

Depending on the connected media sources and files, the following categories are available:

- [Albums](#)
- [Artists](#)
- [Tracks](#)
- [Key word search](#)
- [Playlists](#)
- [Videos](#)
- [Folders](#)

- [Year](#)
- [Genres](#)
- [Current track list](#)
- [Music styles](#)
- [Composers](#)
- [Genius mixes](#) (Apple® devices)
- [Podcasts](#) (Apple® devices)
- [iTunes U](#) (Apple® devices)
- [Audiobooks](#) (Apple® devices)

 Select category.

## Media Interface

### Information on Media Interface

Media Interface is an universal interface for connecting mobile audio devices. The multimedia system has two USB ports. The USB connections are located in the storage compartment under the armrest.

## Supported devices

You can connect the following data carriers via the Media Interface:



- iPod®
- iPhone®
- iPad®
- Mp3-players
- USB devices

For details and a list of supported devices visit the website <http://www.mercedes-benz-mobile.com/>. Read the information under the "Media Interface" heading.

### Switching on Media Interface


Multimedia system:

 [Media](#)  [Devices](#)

-  Connect data carrier to USB socket.
-  Select media device.  
Playable video files will be played.



## Media Interface overview



① Active data carrier

② Cover

③ Artist, track and album

④ Track number and number of tracks in the track list

⑤ Search

⑥ Devices

⑦ Media list

⑧ Media favorites

⑨ Options

⑩ Sound settings

### Bluetooth® audio Information on Bluetooth® audio

When using your Bluetooth® audio device for the first time in conjunction with the multimedia system you must authorize this.

### Searching for and authorizing Bluetooth® audio devices

#### Prerequisites

Switch on Bluetooth® function on multimedia system

Check the following on your Bluetooth® audio device (see manufacturer's user manual):

- The Bluetooth® audio device must support the A2DP and AVRCP Bluetooth® audio profiles.

- The Bluetooth® function must be switched on.
- Bluetooth® audio device must be "visible" to other devices.

Multimedia system:

 **Media**  **Devices**

 **Bluetooth audio**  **Options**

 **Add new Bluetooth audio device**

- ▶ Select **Start search**.  
The multimedia system will search for audio devices within range and enter them in the Bluetooth® device list.
- ▶ Select Bluetooth® audio device  
The query appears as to whether you want to connect the device as an audio device.
- ▶ Select Yes.  
Authorization will be started.

### Option 1: Secure Simple Pairing

**A code is displayed on the**

multimedia system and on the cell phone.

- ▶ If the codes are identical, confirm on both devices.

### Option 2: Entering passkey

The input menu for the passkey is displayed.

- ▶ **Multimedia system:** Choose a one to six-digit sequence of numbers as a passkey.
- ▶ After entering all digits select OK.
- ▶ **Cell phone:** Enter the same passkey and confirm.  
After successful authorization the Bluetooth® audio device will be connected and playback will start.

### Creating a connection from the Bluetooth® audio device

The Bluetooth® device name of the multimedia system is **MB BLUETOOTH XXXX**.

- ▶ Select **Search in device**.

- ▶ Start the authorization on the Bluetooth® audio device (see manufacturer's user manual).  
After successful authorization the Bluetooth® audio device will be connected and playback will start.

With some Bluetooth® audio devices playback must first be started on the device itself so that the multimedia system can play the audio files.

- ❗ Device-specific instructions on authorizing and connecting Bluetooth®-enabled cell phones are available at <http://www.mercedes-benz.com/connect> or at a Mercedes-Benz service point.

### Switching on Bluetooth® audio

Multimedia system:

 **Media**  **Devices**


- ▶ Select **Bluetooth Audio**.  
The multimedia system will activate the connected Bluetooth® audio device.




## Turning on radio

Multimedia system:

 **Radio**

Alternatively: press  key.  
The radio display will appear. You will now be listening to the last tuned station on the last tuned frequency band.

## Overview Radio





- ① Active frequency band
- ② Station name
- ③ Artist, track and album


- ④ Search
- ⑤ Frequency bands
- ⑥ Online services

- ⑦ Favorites
- ⑧ Options
- ⑨ Sound settings

## Setting a frequency band

Multimedia system:


 **Radio**  **Waveband**

 Select frequency band.

## Tuning in to a radio station

Multimedia system:

 **Radio** 

 Navigate up or down.

## Viewing a radio station list

Multimedia system:

 **Radio**  

 **Current station list**


 Select station.

## Searching for a radio station

Multimedia system:

 **Radio**  

 **Current station list**  

- ▶ Enter search term
- ▶ Select 
- ▶ Results will be displayed.
- ▶ Select station.

## Selecting a radio category

Multimedia system:

 **Radio**    **Genres**

- ▶ Select category.

## Saving a radio station

Multimedia system:

 **Radio**  **Radio station favorites**

- ▶ Select Save current station in favorites.

## Editing saved stations

Multimedia system:

 **Radio**  **Radio station favorites**

### Deleting a station

- ▶ Select saved entry and navigate left.
- ▶ Select **Delete selected station**.
- ▶ Select **Yes**.

### Moving a station

- ▶ Select **Move selected station**.
- ▶ Select storage space.

## Frequency fix function (FM radio)

Multimedia system:

 **Radio**   **Options**

- ▶ Select **Station fix**.  
The multimedia system remembers the tuned frequency in case of poor reception.

## Tagging music tracks

Multimedia system:

 **Radio**   **Options**

If the broadcasting stations prepare corresponding information, with this function you can transfer information about the currently played music track


to an Apple® device. You can then purchase the audio file in the iTunes Store®.

- ▶ Select **Tag this song**.  
The track information will be saved.

## Displaying artist, track and album

Multimedia system:

 **Radio**   **Options**

-  **Display radio text information**
- ▶ Turn function on ☒.

## Turning on/off traffic information broadcast


Multimedia system:

 **Radio**   **Options**

-  **Traffic information announcements**

- ▶ Turn function off ☐ or on ☒.

or

- ▶ On the multifunction steering wheel press and hold the  key until the display **TA** goes on or off in the status bar.

This device complies with part 15 of FCC Rules and Innovation, Science and Economic Development Canada's licence-exempt RSSs. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Le présent appareil est conforme à la partie 15 des règles de la FCC et aux normes des CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'appareil doit accepter tout brouillage subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This transmitter must not be co-located or operated in conjunction with any other antenna or transmitter.

This equipment complies with FCC/ISED radiation exposure limits set forth for an uncontrolled environment and meets the FCC radio frequency (RF) Exposure Guidelines and RSS-102 of the ISED radio frequency (RF) Exposure rules. This equipment should be installed and operated keeping the radiator at least 25mm or more away from person's body.

Cet équipement est conforme aux limites d'exposition aux rayonnements énoncées pour un environnement non contrôlé et respecte les règles des radioélectriques (RF) de la FCC lignes directrices d'exposition et d'exposition aux fréquences radioélectriques (RF) CNR-102 de l'ISDE. Cet équipement doit être installé et utilisé en gardant une distance de 25mm ou plus entre le radiateur et le corps humain.

High-power radars are allocated as primary users (i.e. priority users) of the bands 5250-5350 MHz and 5650-5850 MHz and that these radars could cause interference and/or damage to LE-LAN devices.

Les radars de haute puissance sont désignés utilisateurs principaux (c.-à-d., qu'ils ont la priorité) pour les bandes 5250-5350 MHz et 5650-5850 MHz, et ces radars pourraient causer du brouillage et/ou des dommages aux dispositifs LAN-EL.