



Azalea Networks

Wireless Broadband
Anywhere Anytime

MSR SERIES WIRELESS MESH ROUTER

CLI CONFIGURATION GUIDE

AOS-v1.5.0

Copyright 2007 Azalea Networks

All rights reserved. Printed in the USA. 2007

Azalea Networks reserves the right to change, modify, revise this publication without notices

Trademarks

Copyright 2007 by Azalea Networks, Inc. All right reserved. Azalea, the Azalea logo, and MSR1000/MSR2000/MSR4000 are trademarks of Azalea Networks, Inc. All other brand and product names are registered trademarks or trademarks of their respective holders.

Statement of Conditions

In the interest of improving internal design, operation function, and/or reliability, Azalea Networks reserves the right to make changes to products described in this document without notice.

Azalea Networks does not assume any liability that may occur due to the use or application of the product(s) described herein.

Contact

Azalea Networks Inc.
673 S. Milpitas Blvd, Suite 105,
Milpitas CA
95035 USA

sales@azaleanet.com
<http://www.azaleanet.com>

Contents

Scope.....	8
Audience.....	8
Related Documents.....	8
CLI Modes.....	9
CLI Modes.....	9
The LIST Command.....	11
CLI Navigation.....	12
Deleting Command Lines in the Configuration File.....	14
Obtaining Help.....	14
Entering and Edition Commands.....	15
Basic Configuration Information.....	16
System Information.....	16
Host Name Configuration.....	17
Password Configuration	17
Viewing Configuration File Information.....	18
Setting CONFIGURATION Mode Parameters.....	18
Software Image Upgrade.....	19
Interface Modes.....	20
Configuring Fast-ethernet Interfaces.....	20
Configuring Dot11Radio Interfaces (Layer 2 Interfaces).....	22
Radio Operation Mode.....	22
Common settings.....	23
Backhaul mode Configuration.....	25
Access mode settings.....	26
Client mode settings.....	27
802.11 Security Configuration.....	31
Basic BSS configuration.....	33
802.11 Security Configuration.....	35
Basic Client Mode configuration.....	37
. 802.11 Security Configuration.....	40
Auto neighbor discovery and WDS link creation.....	42
WDS link quality monitoring.....	42
RFM related configuration commands.....	43
Static Routing.....	46
Dynamic Routing through the AWR protocol.....	46
Displaying current routing status.....	47
Motrix Protocol Overview.....	50
Motrix Configuration.....	50
Motrix-related configuration information.....	50
Configuring Motrix Service.....	51
Displaying Motrix Configuration and Status.....	52
DHCP Protocol Overview.....	54
Configuring DHCP Server.....	54

Configuring DHCP Server Parameters.....	54
Configuring DHCP Pools.....	55
Attaching DHCP pools to Ethernet interfaces and BSSs.....	57
Show DHCP Server Information and Status.....	57
Configuring DHCP Relay.....	58
Configuring DHCP Relay Parameters.....	58
Enabling DHCP Relay on specific BSSs.....	59
Show DHCP Relay Information.....	59
Configuring NAT.....	60
Show the configuration of NAT.....	60
802.11 standard overview.....	62
MAC-based Access Control Configuration.....	62
Show the configuration of MAC-List.....	62
RADIUS AAA Configuration.....	63
Certificate Configuration.....	65
Security-Profile Configuration.....	65
BSS Security Configuration.....	70
WDS Security Configuration.....	71
CLIENT Security Configuration.....	72
Enable/Disable QoS Service.....	74
Configuring QoS over ManualWDS Interface.....	74
Configuring QoS over Auto WDS Interface.....	76
Configuring SNMP Community.....	78
Configuring SNMP Trap.....	78
Configuring SNMPv3 users.....	79
Save & Reboot.....	80
Ping & Traceroute.....	80
Telnet Client & Server.....	82
Auto Recovery.....	82
Supported MIBs.....	84

List of Figures

Figure 1 CLI Modes.....	10
Figure 2 list Command Examples.....	12
Figure 3 Output of help command.....	14
Figure 4 Example of ? command.....	15
Figure 5 Keyword ? Combination for the snmp-server Keyword.....	15
Figure 6 Various Keyword ? Combinations.....	15
Figure 7 Output of firmware upgrade.....	19
Figure 8 Output of Fast-Ethernet.....	22
Figure 9 Output of dot11radio interface.....	28
Figure 10 Output of dot11wds interface.....	32
Figure 11 Output of BSS under dot11radio interface.....	36
Figure 12 Output of station information under dot11radio interface.....	41
Figure 13 Output of Rf-management.....	45

Figure 14 Output of routing information.....	49
Figure 15 Output of Motrix	53
Figure 16 Output of DHCP Server configuration.....	58
Figure 17 Output of DHCP Relay configuration.....	60
Figure 18 Output of MAC-List configuration.....	62
Figure 19 Output of AAA configuration.....	64
Figure 20 Output of WPA profile configuration.....	69
Figure 21 Output of WPA2 profile configuration.....	69
Figure 22 Output of 8021x profile configuration.....	69
Figure 23 Output of snmp-server configuration.....	79
Figure 24 Output of ping & traceroute information.....	82

List of Tables

Table 1 CLI Mode Information.....	12
Table 2 CLI Mode Information (no command).....	14
Table 3 Short-Cut Keys and their actions.....	16
Table 4 System Information for Initial Setup.....	16
Table 5 Configuring a host name.....	17
Table 6 Configuring login password.....	17
Table 7 Save the running configuration to startup configuration.....	18
Table 8 Display running configuration and startup configuration.....	18
Table 9 Enter CONFIGURATION mode.....	18
Table 10 Upgrade firmware.....	19
Table 11 List of Interface types and modes.....	20
Table 12 Configuring Fastethernet Interface.....	20
Table 13 Configuring WDS Interface.....	29
Table 14 Configuring Basic BSS.....	33
Table 15 Configuring Basic Client Mode.....	37
Table 16 Configuring Static Route.....	46
Table 17 Display roaming status.....	52
Table 18 Configuring DHCP Server.....	54
Table 19 Display DHCP Server Information.....	57
Table 20 Configuring DHCP Relay.....	58
Table 21 Configuring DHCP Server.....	59
Table 22 Configuring NAT.....	60
Table 23 Display NAT interface and NAT table.....	60
Table 24 Configuring MAC-List.....	62
Table 25 Display MAC-List and information.....	62
Table 26 Configuring AAA.....	63
Table 27 Display AAA configuration.....	64
Table 28 Displaying Installed Certificates.....	65
Table 29 Configuring Security Profiles.....	66
Table 30 Display configuration of security profile.....	68
Table 31 Configuring BSS Security.....	70
Table 32 Configuring WDS security.....	71
Table 33 Configuring client-mode security.....	72
Table 34 Enable/Disable QoS.....	74
Table 35 Configuring QoS Classes.....	75
Table 36 Attaching QoS Class to ManualWDS.....	75
Table 37 Configuring snmp-server community.....	78
Table 38 Configuring snmp-server host.....	78
Table 39 Configuring SNMPv3 users.....	79
Table 40 Save the running configuration to startup configuration.....	80
Table 41 Reboot configuration.....	80
Table 42 ping & traceroute configuration.....	81
Table 43 Telnet Client & Server configuration.....	82

Table 44 Auto Recovery configuration.....	83
---	----

Chapter 1 About this Guide

This chapter covers the following topics:

- Scope
- Audience
- Related Documents

Scope

This document provides the configuration instructions and examples for MSR series wireless mesh routers. It contains information on current features and protocols supported by MSR series.

Note: The command examples and outputs are created with an MSR2000 router and is for demonstration purposes only. The exact output of the commands may vary depending on the router model and its firmware version.

The scope of this document only includes the command-line interface of MSR series; for Web-based configuration, please see related documents.

Audience

This document is intended for system/IT or network administrator who is responsible for configuring or maintaining MSR series; this guide is also assumed the user is knowledgeable in wireless/wire Layer2 and Layer 3 networking technologies.

Related Documents

For more information about MSR series, please refer to the following documents:

- MSR series Quick Start Guide
- MSR series Web-based Configuration Guide

Chapter 2 Configuration Fundamentals

This section covers the following main topics:

- [CLI Modes](#)
- [Basic Configuration Information](#)
- [Software Image Upgrade](#)

CLI Modes

- [CLI Modes](#)
- [The List Command](#)
- [CLI Navigation](#)
- [Deleting Command Lines in the Configuration](#)
- [Obtaining Help](#)
- [Entering and Editing Commands](#)

CLI Modes

The CLI is organized into multiple modes that allow navigation between different protocols and interface. Figure 1 displays the CLI modes and CLI structures that are available if you have full access to the CLI.




Figure 1 CLI Modes

When you login, you are in the User EXEC mode where you can enter a limited number of commands, mostly **show** commands. In this mode, you can not make or change any configuration. You can only view system information or execute limited commands. In EXEC mode, the **enable** command prompts you for your password to allow you into Privileged EXEC mode.

Privileged EXEC mode has commands to view configuration, manage configuration files, run diagnostics, enable or disable debug operations, reboot the router. By default, the privilege level is 15. To configure the router, use the **configure terminal** command to enter the CONFIGURATION mode.

CONFIGURATION mode enables you to configure security features, setup various service and SNMP functions, configure static route, and you can enter protocol, interfaces, and line CLI modes to configure setting, and save the configuration.

AAA mode enables you to configure Radius servers used by the router's security features.

INTERFACE DOT11RADIO mode enables you to configure wireless and IP-layer settings for each radio card.

INTERFACE FAST-ETHERNET mode enables you to configure layer-2 and layer-3 settings for each Ethernet port.

IP DHCP RELAY mode enables you to configure the DHCP relay feature of the router. You may configure multiple DHCP Servers by IP address.

IP DHCP SERVER mode enables you to configure the built-in DHCP services provided by the router. You may configure the DNS, Domain name, lease time, etc.

IP NAT mode enables you to configure the NAT service for the router. You may configure choose an out-going network port to activate the NAT service on.

PROFILE MESH mode enables you to configure profiles containing mesh-specific settings. You may configure the mesh network ID in each profile.

ROUTER AWR mode enables you to configure the wireless routing protocol (AWR). You may enable or disable the protocol.

QOS mode enables you to configure the Quality of Service (QoS) features provided by the router. You may define traffic classes and specify bandwidth control.

SECURITY PROFILE mode enables you to configure security profiles to be used on the router. You may configure MAC, IP, and WPA2 profiles.

SERVICE RECOVERY mode enables you to configure the automatic fault recovery service provided by the router.

SERVICE RF-MANAGEMENT mode enables you to configure the intelligent radio-frequency management service provided by the router.

SERVICE ROAMING-MOTRIX mode enables you to configure the Motrix roaming service provided by the router.

The LIST Command

The LIST command allows a user to list all available commands for the current mode.

Command Syntax	Command Mode	Purpose
<i>List command</i>	All modes	The LIST command lists all commands that may be entered in the current mode.

The following are examples of using the list command:

```
MSR2000 (config) # interface fast-ethernet 0
MSR2000 (config-if-ethernet) # list
  dhcp relay
  dhcp server POOL-NAME
  dhcp server automatic
  end
  exit
```

```

help
interface fast-ethernet <0-1>
ip address A.B.C.D/M
ip address dhcp
list
mode access
mode gateway A.B.C.D
mode none
mtu <256-1500>
no dhcp
no ip address
no mode
no mtu
no shutdown
quit
show config
show running-config
shutdown
write file
write memory
write terminal

```

Figure 2 list Command Examples

CLI Navigation

To assist with navigation as you move among the CLI modes, the prompt changes to indicate the mode. Table 1 lists the CLI mode, its corresponding prompt, and information on how to access and exit this CLI mode.

Table 1 CLI Mode Information

CLI Command Mode	Prompt	To Enter Mode	To Exit mode
User EXEC	MSR2000>	Access the router through Telnet and successfully log in	User the exit commands.
Privileged EXEC	MSR2000#	From the EXEC mode, use the enable command. From any other mode, use the end command.	Use the either the exit command.
CONFIGURATION	MSR2000(config)#	From the Privileged EXEC mode, use the configure terminal commands. From every other modes except the EXEC and Privileged EXEC modes, use the exit command.	Use the either the exit or end command.

AAA	MSR2000(config-aaa)#	From the CONFIGURATION mode, use the aaa command.
SERVER-GROUP	MSR2000(config-aaa-server-group)#	From the AAA mode, use the server-group command.
INTERFACE DOT11RADIO	MSR2000(config-if-dot11radio)#	From the CONFIGURATION mode, use the interface dot11radio command.
BSS	MSR2000(config-if-dot11radio-bss)#	From the INTERFACE DOT11RADIO mode, use the bss command.
WDS	MSR2000(config-if-dot11radio-wds)# MSR2000(config-if-dot11radio-wds-auto)#	From the INTERFACE DOT11RADIO mode, use the wds or wds auto command.
STATION	MSR2000(config-if-dot11radio-sta)#	From the INTERFACE DOT11RADIO mode, use the station command.
INTERFACE FAST-ETHERNET	MSR2000(config-if-ethernet)#	From the CONFIGURATION mode, use the interface fast-ethernet command.
IP DHCP RELAY	MSR2000(config-dhcp-relay)#	From the CONFIGURATION mode, use the ip dhcp relay command.
IP DHCP SERVER	MSR2000(config-dhcp-server)#	From the CONFIGURATION mode, use the ip dhcp server command.
IP NAT	MSR2000(config-nat)#	From the CONFIGURATION mode, use the ip nat command.
PROFILE MESH	MSR2000(config-profile-mesh)#	From the CONFIGURATION mode, use the profile mesh command.
QOS	MSR2000(config-qos)#	From the CONFIGURATION mode, use the qos command.
CLASS	MSR2000(config-qos-class)#	From the QOS mode, use the class <name> command.
ROUTER AWR	MSR2000(config-awr)#	From the CONFIGURATION mode, use the router awr command.
SECURITY-PROFILE	MSR2000(config-security-profile)#	From the CONFIGURATION mode, use the security-profile command.
SERVICE RECOVERY	MSR2000(config-recovery)#	From the CONFIGURATION mode, use the service recovery command.
SERVICE RF-MANAGEMENT	MSR2000(config-rfm)#	From the CONFIGURATION mode, use the service rf-management command.
SERVICE ROAMING-MOTIX	MSR2000(config-roaming)#	From the CONFIGURATION mode, use the service roaming-motrix command.

Deleting Command Lines in the Configuration File

Each command enters a command line in the MSR series running configuration file and the “no” form of the command removes the command line from the running configuration file. To disable a command, use the “no” form of that command. The majority of the commands in the CLI have a “no” command that disables the command or re-enable a disabled function. For example, to delete a static route, use the **no ip route <IP destination prefix> <Gateway IP address>** command syntax. For both the command syntax and the “no” syntax, refer to *CLI Command Line Interface Reference*.

Table 2 CLI Mode Information (**no** command)

MSR2000(config) # no ip route 10.2.2.0/24 10.1.1.1
--

Obtaining Help

CLI mode enables several ways for you to obtain help and list the available commands in that mode for a specific keyword.

To obtain a list of keywords and a brief functional description of those keywords at any CLI mode, do either of the following.

- Type **help** at the prompt
- Type **?** at the prompt or after a keyword.

Figure 3 illustrated the output that appears when you type **help** at any modes prompt. The output tells your how to use **?** to get help.

MSR2000(config) # help When you need help, anytime at the command line please press '?'. If nothing matches, the help list will be empty and you must backup until entering a '?' shows the available options. Two styles of help are provided: 1. Full help is available when you are ready to enter a command argument (e.g. 'show ?') and describes each possible argument. 2. Partial help is provided when an abbreviated argument is entered and you want to know what arguments match the input (e.g. 'show me?').
--

Figure 3 Output of help command

Figure 4 illustrates the output that appears when you type **?** at the INTERFACE mode prompt. All keywords are listed on the left with a brief description of the commands on the right.

MSR2000(config-if-ethernet) # ?

```

dhcp          DHCP (Dynamic Host Configuration Protocol) method (server or
relay) to assign IP addresses
end          End current mode and return to privilege EXEC mode
exit          Exit current mode and down to previous mode
help          Description of the interactive help system
interface    Select interface to operate
ip            Interface Internet Protocol config commands
list          Print command list
mode          set usage of this interface
mtu          Set the interface's Maximum Transmission Unit (MTU)
no            Negate a command or set its defaults
quit          Exit current mode and down to previous mode
show          Show running system information
shutdown     Shutdown this interface
write         Write running configuration to memory, network, or terminal

```

Figure 4 Example of ? command

To obtain a list of available options for a keyword or partial keyword, use the ?. In figure 4, the keywords are listed on the left with a brief description of the commands on the right. The output is the same if you enter the **help**.

```

MSR2000(config)# snmp-server ?
  community  server read only or read write community string
  host       Set SNMP trap target ip
  v3user     set SNMPv3 user
MSR2000(config)#

```

Figure 5 Keyword ? Combination for the snmp-server Keyword

```

MSR2000(config)# s?                      ← Enter a partial keyword, in the case "s"
followed
  security-profile  Config security profile
  service          Configure a service
  show             Show running system information
  snmp-server      Set SNMP server read only or read write community string
MSR2000(config)#
MSR2000(config)# sn?                      ← Enter a partial keyword, in the case "sn"
followed
  snmp-server      immediately by a ?. All keywords that begin with
MSR2000(config)#
  snmp-sever      "sn" in the CONFIGURATION mode are listed.

```

Figure 6 Various Keyword ? Combinations

Entering and Edition Commands

- The CLI is case sensitive. All CLI commands MUST be in lower case.
- It is convenient to use the TAB key to complete keywords in commands. As long as the letters you type are unique to all available commands, it will auto-complete the commands.
- You can use the up arrow key to display the last enabled command syntax.
- You can use either the BACKSPACE key or DELETE key to erase the previous letter.

Table 3 lists the different key combinations available.

Table 3 Short-Cut Keys and their actions

Key Combinations	Action
CTRL-A	Moves the cursor to the beginning of the command line.
CTRL-B	Moves the cursor back on character.
CTRL-D	Deletes character at cursor.
CTRL-E	Moves the cursor to the end of the line.
CTRL-F	Moves the cursor forward one character.
CTRL-I	Completes a keyword.
CTRL-K	Deletes all characters form the cursor to the end of the command line.
CTRL-L	Re-enters the previous command.
CTRL-N	Return to more recent commands in the history buffer after recalling commands with CRTL-P or the up arrow key.
CTRL-P	Recalls commands, beginning with the last command.
CTRL-U	Deletes the line.
CTRL-W	Deletes the previous word.
CTRL-Z	Ends continuous scrolling of command output.
Esc B	Moves the cursor back one word.
Esc F	Moves the cursor forward one word.
Esc D	Deletes all characters form the cursor to the end of the word.

Basic Configuration Information

This section provides information to configure your system to access the network or enable other hosts in your network after the initial system boot. Detailed feature or protocol configuration information is provided in subsequent chapters.

- [System Information](#)
- [Host name configuration](#)
- [Password configuration](#)
- [Viewing configuration file information](#)
- [Setting CONFIGURATION mode parameters](#)

System Information

When booting up the router, the system configuration program is not implemented automatically, user has to configure the router by using CLI commands to enable and manage the system.

Table 4 System Information for Initial Setup

System Information	Purpose
Hostname	Allows you to set the host name of the MSR series. Enter a new host name in the form of an alphanumeric string.

Router-password	Default password is public , it can be changed by using this CLI command
Ethernet port IP address	By default, IP address 192.168.0.1/24 is configured on FastEthernet 0, user can change it if needed.
Node-id and router-id	Default node-id is 1 and router-id is 192.168.10.1; these must be set such that they are unique in a single mesh network formed by MSR series routers.

Host Name Configuration

The host name appears in the prompt. The default host name is MSR series. Names must start with a letter and end with a letter or digit. Characters within the string can be letters, digits, and hyphens.

To configure a host name, use the following command in the CONFIGURATION mode:

Table 5 Configuring a host name

Command Syntax	Command Mode	Purpose
hostname <name>	CONFIGURATION	Allows you to set the host name of the MSR series. Enter a new host name in the form of an alphanumeric string.
no hostname		Remove the hostname, it goes back to default. Default hostname = MSR series

Password Configuration

MSR series has a default password configured, the default password is **public**.

To configure the login password, configure the following command in the Privileged EXEC mode.

Table 6 Configuring login password

Command Syntax	Command Mode	Purpose
router-password root	Privileged EXEC	Change the login password for the user root command.

```
MSR2000# router-password
      root  Set login password for root

MSR2000# router-password root
Changing password for root
Enter the new password (minimum of 5, maximum of 8 characters)
Please use a combination of upper and lower case letters and numbers.
Enter new password:
Re-enter new password:
Password changed.
```

Viewing Configuration File Information

It is highly recommended that you save your configuration often.

To save a configuration file, use either of the following commands in the Privileged EXEC mode:

Table 7 Save the running configuration to startup configuration

Command Syntax	Command Mode	Purpose
copy running-config startup-config	Privileged EXEC	Save the current running configuration to the startup-config file.
write memory	Privileged EXEC	Save the current running configuration to the startup-config file. (old way to save configuration)

Use any of the following commands to display information about the configuration file:

Table 8 Display running configuration and startup configuration

Command Syntax	Command Mode	Purpose
show startup-config	Privileged EXEC	Displays the configuration information stored in the internal memory.
show running-config	Privileged EXEC	Displays current configuration information on the system.

Setting CONFIGURATION Mode Parameters

The configure command places you in the CONFIGURATION mode where you can configure interfaces and routing protocols.

From the CONFIGURATION mode, enter any of the following commands to configure protocols or interfaces:

Table 9 Enter CONFIGURATION mode

Command Syntax	Command Mode	Purpose
node-id <1-255>	CONFIGURATION	Set node ID, should be value between 1 and 255.
router-id <A.B.C.D>	CONFIGURATION	Set router ID
		A.B.C.D The ip address to be the loopback id of the router
Interface <interface>	CONFIGURATION	Configure a physical or logical interface on MSR series.
		1.) dot11radio 2.) fast-ethernet
show running-config	CONFIGURATION	Display current configuration information on the system.

Software Image Upgrade

You may upgrade the firmware installed on the routers.

Table 10 Upgrade firmware

Command Syntax	Command Mode	Purpose
upgrade [FTP <ftp server ip> <image file> <ftp user> <ftp mode> <password> URL <URL to image file>]	Privileged EXEC	Upgrade the software image on the router using an FTP or HTTP server.

```
MSR2000# upgrade ftp 192.168.1.107 /tftpboot/AOS-v1.2.1.img upimg
upimg
% Start downloading image
Connecting to 192.168.1.107[192.168.1.107]:21
new.img      100% |*****| 5405 KB  00:00
ETA
% Start upgrading image, this will take several minutes
!!!!!!!
!!!
% Upgrade successful MSR2000#
```



```
MSR2000# upgrade url http://192.168.1.107/tftpboot/AOS-v1.2.1.img
% Start downloading image
Connecting to 192.168.1.107[192.168.1.107]:21
new.img      100% |*****| 5405 KB  00:00
ETA
% Start upgrading image, this will take several minutes
!!!!!!!
!!!
% Upgrade successful
```

Figure 7 Output of firmware upgrade

Chapter 3 Physical Interfaces

This chapter contains information on defining and configuring and physical interfaces on the MSR series, it has the following sections:

- [Interface Modes](#)
- [Configuring Fast-Ethernet Interfaces](#)
- [Configuring Dot11Radio Interfaces](#)

Interface Modes

The wireless mesh router contains physical and logical interfaces in both Layer 2 and Layer 3 modes.

Table 11 List of Interface types and modes

Type of Interface	Mode	Dynamic Creation
fast-ethernet	Physical Layer 3	No
dot11radio	Physical Layer 2	No

Configuring Fast-ethernet Interfaces

MSR series has two physical fast-ethernet interfaces¹ that could connect the wireless mesh network with a wired network or device. Both interfaces support auto-negotiation between 10Mbps and 100Mbps as well as between half-duplex and full-duplex modes.

Table 12 Configuring Fastethernet Interface

Command Syntax	Command Mode	Purpose
interface fast-ethernet <0-1>	CONFIGURATION or INTERFACE FAST-ETHERNET	Configure a Fast-ethernet interface, it can be either fast-ethernet 0 or fast-ethernet 1
ip address [ip address/mask]	INTERFACE FAST-ETHERNET	Set IP address of fast-ethernet interface.
ip address dhcp		Set IP address to be automatically obtained by using the DHCP protocol; a DHCP server must be running on the network this fast-ethernet interface is connected to
no ip address		Remove IP address from Fast-ethernet interface
release-dhcp fast-ethernet <0-1>	Privileged EXEC	Release the fast-ethernet interface's IP address acquired from DHCP Server

¹ On some router models, only one Ethernet port (FastEthernet 0) is usable. It is recommended that the FastEthernet1 configuration to be left at default (disabled) for these models.

renew-dhcp fast-ethernet <0-1>		Renew the fast-ethernet interface's IP address via DHCP Server
restart-dhcp fast-ethernet <0-1>		Restart DHCP client for the fast-ethernet interface
mode access	INTERFACE FAST-ETHERNET	Set this fast-ethernet interface as a LAN interface, for connecting with client devices
mode gateway <gateway IP>		Set this fast-ethernet interface as a WAN interface, for connecting with a wired network. The gateway IP parameter is optional; if specified, the router will use it as the default gateway.
mtu <256-1500>	INTERFACE FAST-ETHERNET	Set Maximum Transmission Unit (MTU) ² size, 1500 is default <i>Setting of MTU is optional and should be done with care.</i>
no mtu		Reset the MTU to the default value
shutdown	INTERFACE FAST-ETHERNET	Administratively shutdown the interface
no shutdown		Administratively activate the interface (Default)
exit, end, or quit	INTERFACE FAST-ETHERNET	Leave Interface mode and commit the change
dhcp server	INTERFACE FAST-ETHERNET	Configure DHCP server or relay for this Ethernet interface; for details, please refer to the chapter on DHCP and NAT.
dhcp relay		

Viewing fast-ethernet Interface information.

The fast-ethernet interface information may be viewed using the 'show' command. The "show run" command displays the intended configuration of the interface, while the "show interface fast-ethernet" command displays the current state of the interface.

```
MSR2000# show run
...
!
interface fast-ethernet 0
 ip address 192.168.1.162/24
 mode gateway 192.168.1.1
!
...
MSR2000# show int fast-ethernet 0
Interface FastEthernet0
```

² MTU (Maximum Transmission Unit) is the threshold at which single layer-3 IP packets become fragmented into multiple, smaller-size packets.

```

mode: gateway    gateway ip: 192.168.1.1
admin status: up    physical status: up
DHCP: disabled    DHCP client: disabled
index 1 metric 1 mtu 1500 <UP,BROADCAST,RUNNING,MULTICAST>
HWaddr: 00:17:7b:18:18:30
inet 192.168.1.162/24 broadcast 192.168.1.255
    input packets 52320, bytes 4810521, dropped 0, multicast packets 0
    input errors 0, length 0, overrun 0, CRC 0, frame 0, fifo 0, missed 0
    output packets 23738, bytes 3268042, dropped 0
    output errors 0, aborted 0, carrier 0, fifo 0, heartbeat 0, window 0
    collisions 0

```

Figure 8 Output of Fast-Ethernet

Configuring Dot11Radio Interfaces (Layer 2 Interfaces)

The sections describe the default interface configuration and the optional features that you can configure on the physical interfaces:

- Operation Mode
- Common settings (Wireless Mode, Channel, etc)
- Operation-mode specific settings

Radio Operation Mode

Radio Interface supports three operation modes, Access, Backhaul and Client. When configured for Access mode, 802.11 client devices such as personal computers, PDAs, and WiFi-phones are able to associate with the BSSs configured on the radio interface. When configured for Backhaul mode, other routers are able to connect to the radio interface through manually or automatically created WDS links. When configured for Client mode, the router can connect as a WiFi client to other APs within the range. There are commands that only take effect in one mode but not the others.

An operation mode must be configured on a radio before it could operate in a mesh network.

Command Syntax	Command Mode	Purpose
Interface dot11radio <0-N>	CONFIGURATION	Configure one of the dot11radio interfaces; index starts from 0 and ends with one less than the number of radios installed.
mode access	INTERFACE DOT11RADIO	Configure radio interface for client access, allowing BSS association
mode backhaul mode backhaul <Mesh Profile>		Configure radio interface for backhaul operation, allowing connection with other MSR series routers. If <Mesh Profile> is specified, then the mesh settings in that profile are used for this backhaul radio; otherwise, the backhaul radio uses default mesh settings. See the later

section on mesh profiles for details.

mode client

Configure radio interface to work as a 802.11 client, allowing connection with a generic 802.11 Access Point including BSSs provided by other MSR series routers. A router may only have one radio in client mode.

Common settings

Radio Interface supports three types of hard-ware mode: 802.11a, 802.11b (legacy mode), and 802.11g (can be configured to be backward-compatible with 802.11b). Each mode is associated with country codes and specific radio channels. The channel settings on the wireless device correspond to the frequencies available in the regulatory domain.

The following table outlines the physical, layer-2 settings that may configured on each radio interface. These settings apply in both access and backhaul modes.

Command Syntax	Command Mode	Purpose
wireless-mode <mode> <channel> [country code]	INTERFACE DOT11RADIO	<p>Configure the physical wireless settings of this radio interface.</p> <p>mode: a, g, or b a: Use 802.11a b: Use 802.11b g: Use 802.11g; compatible with 802.11b in some configurations</p> <p>channel: Mode and country-specific channel number</p> <p>Modes b,g and US: 1-11 Modes b,g and JP: 1-14; Modes b,g and CN: 1-13; Mode a and US: 36, 40, 44, 48, 52, 56, 60, 64, 149, 153, 157, 161, 165; Mode a and JP: 36, 40, 44, 48 Mode a and CN: 149, 153, 157, 161, 165</p> <p>country-code: US, CN, or JP US: United States CN: P.R. China JP: Japan</p>
shutdown	INTERFACE DOT11RADIO	Administratively shutdown this radio; all existing operations on this radio will stop
no shutdown		Activate the interface

antenna <0-2>	INTERFACE DOT11RADIO	Configure this radio interface to use one of the two antennas connected to the physical radio card
antenna	0	Automatically choose the best antenna (default for indoor models)
antenna 1		Always use antenna 1 (default for outdoor models)
antenna 2		Always use antenna 2
no antenna		Restore default antenna setting.
<i>Setting of antenna is optional and should be done with care.</i>		
cts-protection <0-3>	INTERFACE DOT11RADIO	Enable or disable CTS protection on this radio interface.
cts-protection 0		0: Automatically enable/disable CTS using OLBC detection ³ (Default)
no cts-protection		
cts-protection 1		Always enable CTS protection
cts-protection 2		Always disable CTS protection
cts-protection 3		Automatically enable/disable CTS without using OLBC detection ⁴
<i>Setting of cts-protection is optional and should be done with care.</i>		
mtu <256-2274>	INTERFACE DOT11RADIO	Set the layer-3 MTU of this radio interface.
no mtu		Reset the MTU to the default value
<i>Setting of radio MTU is not recommended and should be done with extreme caution.</i>		
retry <1-32> <1-32>	INTERFACE DOT11RADIO	Sets the 802.11 MAC layer's packet retransmission limit. The first argument is the short retry limit and the second is the long retry limit.
retry 4 7		Reset retry to default (short retry of 4, long retry of 7)
no	retry	
tx-power-reduction <0-65535>	INTERFACE	Set the reduction in transmission power of

³ This setting will enable CTS protection when there are both 802.11g and 802.11b clients associated on one of the BSSs of the current radio or when Overlapping Legacy BSS Condition (OLBC) is detected

⁴ This setting will enable CTS protection when there are both 802.11g and 802.11b clients using the current radio, but not when OLBC is detected

DOT11RADIO	this radio interface. The reduction is in 0.1dBm increments. For example, a setting of 10 causes a reduction of 1 dBm. The maximum possible reduction is a setting of 65535 or 6553.5 dBm
no tx-power-reduction	Reset the power reduction to the default value.

Transmission power settings should only be changed with extreme caution.

A note regarding CTS protection:

IEEE 802.11g uses CTS frames to allow IEEE 802.11b clients notice frames sent at higher rates. This is useful in mixed mode networks consisting of both 802.11b and 802.11g stations. It is disabled automatically if there are no 802.11b stations associated to the AP. This behavior can be changed to enable CTS protection on IEEE 802.11g AP only, if there are IEEE 802.11b stations on the same channel using another AP. In addition, disabling this even when IEEE 802.11b stations are present can improve performance, if most traffic is between IEEE 802.11g devices.

Backhaul mode Configuration

This section describes settings that only take affect in **backhaul** operation mode: The backhaul mode is used to create backhaul wireless links to other mesh routers.

Mesh Profiles and Settings

Each backhaul radio interface on the MSR series router must participate in a single wireless mesh network. Because each mesh network has its unique characteristics, mesh profiles can be created to specify unique settings for each mesh network.

The following table outlines the mesh profile-related commands:

Command Syntax	Command Mode	Purpose
profile mesh <NAME>	CONFIGURATION	Configure a new or existing mesh profile with the specified name on this router.
no profile mesh <NAME>		Remove an existing mesh profile configuration on this router.
mesh-id <WORD>	PROFILE MESH	Specify the mesh ID for this mesh profile; all mesh routers that forms the single mesh network should use the same mesh ID.
no mesh-id		Remove the mesh ID from this mesh profile.

mode backhaul <Mesh Profile>	INTERFACE DOT11RADIO	Set a radio interface for backhaul operation and use the settings in the specified mesh profile.
---	-------------------------	--

Backhaul radio settings

The following table outlines settings that only take affect in **backhaul** operation mode:

Command Syntax	Command Mode	Purpose
wds <0-5>	INTERFACE DOT11RADIO	Configure a new or existing manual WDS interface on this radio; this command is mutually exclusive with the wds auto command below ⁵ ;
no wds <0-5>		Remove an existing manual WDS interface from this radio
wds auto	INTERFACE DOT11RADIO	Enable automatic WDS provisioning on this radio interface and enter the auto WDS configuration mode; this command is mutually exclusive with the wds <0-5> command. ⁶
no wds auto		Disable auto WDS on this radio interface.
wds-unicast-rate [rate]	INTERFACE DOT11RADIO	<p>Set the forced unicast rate of this radio interface's WDS links; once set, WDS links will attempt to consistently use the specified transmission rate.</p> <p>The rate is specified in units of 100kbps; the available rates are: 10, 20, 55, 110, 60, 90, 120, 180, 240, 360, 480, 540</p> <p>(Example: if choose 20, then RATE=20*100kbps=2Mbps)</p>
no wds-unicast-rate		Disables unicast rate setting; WDS links will automatically select the transmission rate and may dynamically vary depending on link quality (default setting)

Access mode settings

The following table outlines settings that only take affect in **access** operation mode:

Command Syntax	Command Mode	Purpose
bss <SSID>	INTERFACE DOT11RADIO	Configure a new or existing BSS on this radio interface ⁷

⁵ Please see the next chapter on WDS interfaces for more information.

⁶ Please see chapter 7, Radio Frequency Management, for more information about auto WDS discovery and provisioning.

⁷ Please see the later chapter on BSS for more information.

no bss <SSID>		Remove an existing BSS from this radio interface
		SSID: The 802.11 Service Set ID (SSID) that identifies a BSS on this radio interface
station-isolation	INTERFACE DOT11RADIO	Disable the internal bridge for the client's data packets; this prevents the layer-2 broadcast traffic from one client to reach another. Broadcasts from the AP can still reach all clients.
no station-isolation		Enable the internal bridge for client's data packets; allows clients to communicate with each other through layer-2 broadcasting (default)

It is highly recommended that station-isolation be enabled for security reasons. For example, it can prevent clients on the same AP from discovering each other through Microsoft Windows' Network Neighborhood feature.

Client mode settings

The following table outlines settings that only take affect in **client** operation mode:

Command Syntax	Command Mode	Purpose
station <station name>	INTERFACE DOT11RADIO	Configure a 802.11 client station on this radio interface ⁸
no station <station name>		Remove 802.11 client station setting from this radio interface

Note: currently only one station is allowed on each router

Viewing the dot11radio interface information

The “show run” command displays the intended configuration of the dot11radio interface, while the “show interface dot11radio” command displays the current state of the interface.

```
MSR2000# show run
...
interface dot11radio 0
wireless-mode a 149 US
antenna 0
cts-protection 2
mode backhaul
...
```

⁸ Please see the later chapter on client mode for more information.

```
MSR2000# show interface dot11radio 0
Interface Dot11Radio0
  operation_mode:backhaul, mesh  id:AzaleaMesh,  country  code:US,  channel
  policy:0,
  antenna:0,  cts protection:2,
  admin status: up  physical status: up
  index 3 metric 1 mtu 1500 <UP,BROADCAST,RUNNING,MULTICAST>
  HWmode: a, channel: 149, Fragment thr: 2346, RTS thr: 2347
  HWaddr: 00:17:7b:18:38
    input packets 3517383, bytes 627088483, dropped 0, multicast packets 0
    input errors 637111, length 0, overrun 0, CRC 0, frame 12, fifo 0, missed
    0
    output packets 254080, bytes 35293576, dropped 0
    output errors 0, aborted 0, carrier 0, fifo 0, heartbeat 0, window 0
    collisions 0
```

Figure 9 Output of dot11radio interface

Chapter 4 Logical Interfaces (WDS)

Wireless Distribution System (WDS) is the underlying technology that allows MSR series routers to communicate each other wirelessly and form the backhaul links of the mesh network. A WDS link is formed between two routers by creating logical WDS interfaces on each router, either through manual configuration or automatic discovery⁹.

Each logical WDS interface is bound to a physical Dot11Radio interface. Therefore, WDS interface configuration commands are placed within the ‘interface dot11radio’ mode. Because WDS is used to form backhaul links, its configuration only takes effect on radio interfaces configured for backhaul mode.

Note: The MSR series can only form backhaul links with the radios on other MSR series routers that has the same mesh-ID configured. Please ensure all the routers in your wireless mesh network use the same mesh-ID and different networks use different IDs. The section on “Mesh Profiles” in the previous chapter describes how mesh profiles and IDs are configured.

Table 13 Configuring WDS Interface

Command Syntax	Command Mode	Purpose
wds <0-5>	INTERFACE DOT11RADIO	Configure a new or existing manual WDS interface on this radio; enters the INTERFACE DOT11RADIO WDS command mode. This command is mutually exclusive with the wds auto command below.
no wds <0-5>		Remove an existing manual WDS interface from this radio
wds auto	INTERFACE DOT11RADIO	Enable automatic WDS provisioning on this radio interface and enter the INTERFACE DOT11RADIO WDS AUTO mode for auto WDS configuration; this command is mutually exclusive with the wds <0-5> command. ¹⁰
no wds auto		Disable auto WDS on this radio interface.
max-auto-wds <1-6>	INTERFACE DOT11RADIO WDS AUTO	Set the maximum number of auto WDS interfaces that could be created on this radio by RFM ¹¹

⁹ Please see chapter 5 for more information about automatic discovery of WDS links

¹⁰ Please see chapter 7, Radio Frequency Management, for more information about auto WDS discovery and provisioning.

¹¹ This setting is related to the automatic WDS link discovery feature of RFM. Please refer to chapter 5 for details.

authentication open	INTERFACE	Allow all compatible mesh routers to
no authentication	DOT11RADIO WDS	form WDS links with this radio interface.
authentication open key-management wpa <wpa-profile-name>		Enable WPA security for this WDS; only allow mesh routers with correct WPA authentication and encryption settings to form WDS links.
authentication shared wep <wep-profile-name> default-key <1-4>		Enable WEP authentication for this WDS; only allow routers with the correct WEP key settings to form WDS links.
ip address [ip address/mask]	INTERFACE	Configure IP address of WDS interface.
no ip address	DOT11RADIO WDS	
		Remove IP address from WDS interface
mtu <256-2274>	INTERFACE	Configure MTU size of WDS interface
no mtu	DOT11RADIO WDS	
		Restore default MTU size (1500)
		<i>Setting of MTU is optional and should be done with care.</i>
qos class <class>	INTERFACE	Specify the Quality of Service (QoS) class policy ¹² that should be applied for this WDS interface
no qos class	DOT11RADIO WDS	
		Disable QoS on this interface (default)
remote mac <HH:HH:HH:HH:HH:HH>	INTERFACE	Specify the MAC address of the remote radio on the other router that this WDS interface will establish a link with
remote node <1-255> <0-N>	DOT11RADIO WDS	
		Specify the node ID and the index of the radio on the remote router that this WDS interface will establish a link with
		1-255: The node ID of the other router
		0-N: The index of the radio on the other router that will form the link.
role <ap station>	INTERFACE	Specify the role of this WDS interface in the link; each link
	DOT11RADIO WDS	

¹² Please see chapter 9, Quality of Service (QoS), for more information.

role auto	requires a WDS interface as an ap and the other as station.
no role	Allow routers to automatically assign roles to the WDS interface (default, recommended setting)
ssid <NAME>	INTERFACE DOT11RADIO WDS Specify the SSID of this WDS link (required for WPA)
no ssid	Do not use a SSID (default)
shutdown	INTERFACE DOT11RADIO WDS Administratively shutdown this WDS interface; stops the operation of the WDS link
no shutdown	Activate this WDS interface so it may establish a link with another router

A note regarding WDS configuration:

To set up a manual WDS link between two routers, a backhaul radio interface should be configured on each router. Both radio should use the same wireless mode and channel.

802.11 Security Configuration

The 802.11 security standard defines a suite of wireless security protocols and implementations. The MSR series allows each WDS link to use a different 802.11 security profile such as WEP or WPA. Refer to the chapter on 802.11 Security for more information.

Viewing a list of all interfaces

The “**show interface brief**” command can be used to display a list of all interfaces on the router that includes both physical and logical interfaces.

```
MSR2000# show interface brief
Name          IP address      State
Dot11Radio0   unassigned      up
Dot11Radio1   unassigned      up
Radio0MWds0   10.1.6.2/28    up
Radio0MWds1   10.2.6.2/28    up
Radio1MWds0   10.4.6.1/28    up
Radio1MWds1   10.5.6.1/28    up
FastEthernet0  192.168.1.136/24 up
FastEthernet1  unassigned      administratively down
```

In the above list, two physical radio interfaces and two physical fast-ethernet interfaces were included. In addition, one auto WDS¹³ logical interface bound to Dot11Radio0 (Radio0AWds0), two manual WDS interfaces bound to Dot11Radio0 (Radio0MWds0-1), and two manual WDS interfaces bound to Dot11Radio1 (Radio1MWds0-1) were displayed. The prefix of the WDS interface name indicates the radio that the WDS interface uses.

¹³ See the next chapter on RFM for information on auto WDS link discovery.

Viewing WDS Interface information.

```
MSR2000# show run
...
interface dot11radio 0
...
wds 0
  remote mac 00:17:7b:35:36:bc
  ip address 10.1.6.2/28
  no shutdown
...
interface dot11radio 1
wds 0
  remote node 5 0
  ip address 10.4.5.1/28
  no shutdown
!
...
MSR2000# show interface dot11radio 0 wds 0
Interface Radio0MWds0
  neighbor specified using: mac address
  remote mac address: 00:17:7b:35:eb:0d, remote node: 152, remote radio: 0
  admin status: up  physical status: up  neighbor ip: 200.151.152.2
  rssi: 69, snr: 69, link quality: 86%, datarate: 60
  role:auto, physical interface:0,
  index 20 metric 1 mtu 1500 <UP,BROADCAST,RUNNING,MULTICAST>
  HWmode: a, channel: 149, Fragment thr: 2346, RTS thr: 2347
  HWaddr: 00:17:7b:18:18:38
  inet 200.151.152.1/24 broadcast 200.151.152.255
    input packets 280, bytes 46812, dropped 0, multicast packets 0
    input errors 0, length 0, overrun 0, CRC 0, frame 0, fifo 0, missed 0
    output packets 186, bytes 38728, dropped 0
    output errors 0, aborted 0, carrier 0, fifo 0, heartbeat 0, window 0
    collisions 0
```

Figure 10 Output of dot11wds interface

Chapter 5 Access and BSS Configuration

When a Dot11Radio interface is put into Access mode, a BSS configured for that interface becomes a virtual AP that client devices may associate with. Each BSS is bound to a physical dot11radio interface; therefore, BSS is configured within the 'interface dot11radio' mode. The MSR series router supports up to four BSSs on each radio interface.

Basic BSS configuration

The following table outlines the basic settings for each BSS.

Table 14 Configuring Basic BSS

Command Syntax	Command Mode	Purpose
bss <SSID>	INTERFACE DOT11RADIO	Configure a new or existing BSS on this radio interface
no bss <SSID>		Remove an existing BSS from this radio interface
		SSID: The 802.11 Service Set ID (SSID) that identifies a BSS on this radio interface.
ip address A.B.C.D/M	INTERFACE DOT11RADIO BSS	Configure IP Address for this BSS.
authentication open no authentication	INTERFACE DOT11RADIO BSS	Allow all clients to associate with this BSS
authentication open wep <wep-profile-name> default-key <1-4>		Enable WEP encryption for this BSS using the key settings in the WEP profile and the specified default key
authentication open key-management wpa <wpa-profile-name>		Enable WPA security for this BSS; only allow clients with correct WPA authentication and encryption settings to associate with this BSS.
authentication open key-management wpa2 <wpa2-profile-name>		Enable WPA2 security for this BSS; only allow clients with correct WPA2 authentication and encryption settings to associate with this BSS.
authentication shared wep <wep-profile-name> default-key <1-4>		Enable WEP authentication and encryption for this BSS using the key settings in the WEP profile and the specified default key
mac-address accept <mac-list-name>	INTERFACE DOT11RADIO BSS	Only accept clients with MAC addresses in the specified list; deny all other clients

mac-address deny <mac-list-name>		Only deny clients with MAC addresses in the specified list; allow all other clients.
mac-address accept-all no mac-address		Restore to default configuration (accept all MAC addresses)
ignore-broadcast-ssid	INTERFACE DOT11RADIO BSS	Disable broadcasting of this BSS's SSID
no ignore-broadcast-ssid		Enable broadcasting of this BSS's SSID (Default)
max-rate <rate>	INTERFACE DOT11RADIO BSS	Select the maximum allowed transmission rate for this BSS in units of 100kbps. Available rates: 10, 20, 55, 110, 60, 90, 120, 180, 240, 360, 480, 540.
no max-rate		Allow the maximum transmission rate supported by the client and radio hardware (Default)
max-station-allowed <0-240>	INTERFACE DOT11RADIO BSS	Configure the maximum number of stations allowed to associate with this BSS at the same time.
max-station-allowed 240 no max-station-allowed		Allow up to 240 stations to associate with this BSS at the same time (default).
station-inactivity-limit <1-65535>	INTERFACE DOT11RADIO BSS	Configure the maximum amount of time (in seconds) a station is allowed to be inactive before the action specified by the inactivity-policy (see next) is taken
station-inactivity-limit 300 no station-inactivity-limit		Set the inactivity limit to the default value of 300 seconds
station-inactivity-policy <0-1>	INTERFACE DOT11RADIO BSS	Configure the action taken when a station exceeds the inactivity limit.
station-inactivity-policy 0 no station-inactivity-policy		Poll the station and de-authenticate station if it does not respond (default)
station-inactivity-policy 1		De-authenticate station immediately

unicast-rate <rate>	INTERFACE DOT11RADIO BSS	Set the unicast rate of this BSS; once set, the radio interface will attempt to consistently use the specified transmission rate for stations associated with this BSS. Setting this option will also prevent stations that do not support the specified rate from associating with the BSS.
no unicast-rate		The rate is specified in units of 100kbps; the available rates are: 10, 20, 55, 110, 60, 90, 120, 180, 240, 360, 480, 540
dhcp server	INTERFACE DOT11RADIO BSS	Disables unicast rate setting for this BSS; radio interfaces will automatically select transmission rates (default setting)
dhcp relay		Configure DHCP server or relay for this BSS; for details, please refer to the chapter on DHCP and NAT.

802.11 Security Configuration

The 802.11 security standard defines a suite of wireless security protocols and implementations. It provides open and shared key authentication, is compatible with WPA /WPA2, and interoperates with 802.1x.

The mesh router allows each BSS to use a different 802.11 security profile. Please refer to the chapter on 802.11 Security for more information.

Viewing BSS of dot11radio interface information.

```
MSR2000# show run
...
interface dot11radio 0
...
bss demo
  station-inactivity-policy 1
  station-inactivity-limit 300
  max-rate 60
  authentication open wep test-supplicant default-key 1
  mac-address accept AAA
...
!
security-profile wep test-supplicant
  wep-key 1 1234567890
  wep-key 2 2345678901
  wep-key 3 3456789012
  wep-key 4 4567890123
!
mac-list AAA
  mac-addr 22:22:22:bc:22:44
```

```
mac-addr 22:22:22:bc:22:45
mac-addr 22:22:22:bc:22:08
...
!
MSR2000# show interface dot11radio 0 bss demo
BSS:demo

ignore broadcast ssid:disable, maximum station allowed:240,
transmission fail percentage:0, transmission fail check interval:0,
station inactivity policy:1, station inactivity limit:300,
maximum rate control rate:60, authentication:open wep test-supplicant
default-key 1,mac authentication:accept AAA,
HWaddr: 00:17:7b:18:18:40
```

Figure 11 Output of BSS under dot11radio interface

Chapter 6 Client Mode Configuration

When a Dot11Radio interface is configured for client mode, an 802.11 client station configured under that interface can associate to any matching 802.11 access points as any other 802.11 client. The access point can be BSSs provided by other MSR series or an AP from another vendor. On each MSR series router, only one radio interface can operate in client mode.

Basic Client Mode configuration

The following table outlines the basic settings for a client station

Table 15 Configuring Basic Client Mode

Command Syntax	Command Mode	Purpose
station <station name>	INTERFACE DOT11RADIO	Configure a 802.11 client station on this radio interface
no station <station name>		Remove 802.11 client station setting from this radio interface
		<i>Note: only one client can be created on a radio interface</i>
ip address [ip address/mask]	INTERFACE DOT11RADIO STATION	Set IP address of this client station.
ip address dhcp		Set IP address to be automatically obtained by using the DHCP protocol; a DHCP server must be running on the network this station associates to.
no ip address		Remove IP address from this client station.
client-authentication open wep <wep-profile-name> default-key <1-4>	INTERFACE DOT11RADIO STATION	Enable WEP encryption for this client using the key settings in the WEP profile and the specified default key
client-authentication open client-8021x <client-8021x-profile-name>		Enable 802.1X authentication for this client, using the authentication settings in the client-8021x profile
client-authentication open key-management wpa client-8021x <client-8021x-profile-name>		Enable WPA security for this client; using the authentication settings in the client-8021x

		profile
client-authentication open key-management wpa2 client-8021x <client-8021x-profile-name>		Enable WPA2 security for this client; using the authentication settings in the client-8021x profile
client-authentication open key-management wpa-psk hex <string>		Enable WPA PSK on client and configure pre-shared key using hexadecimal format.
client-authentication open key-management wpa-psk ascii <string>		Enable WPA PSK on client and configure pre-shared key using ascii format.
client-authentication shared wep <wep-profile-name> default-key <1-4>		Enable WEP encryption for this client using the key settings in the WEP profile and the specified default key
no client-authentication		Disable authentication for this client interface.
access-point ssid <SSID>	INTERFACE DOT11RADIO STATION	SSID of the access point that this client station wants to associate with. Default is no SSID.
no access-point ssid		Remove access-point SSID configuration.
		SSID: 802.11 Service Set ID
access-point <HH:HH:HH:HH:HH:HH>	bssid	INTERFACE DOT11RADIO STATION
		BSSID of the access point that this client station wants to associate with. Default has no BSSID specified.
no access-point bssid		Remove the setting of BSSID for an access point.
access-point bssid-filter acceptable prefix <HH:HH:HH:HH:HH:HH> <HH:HH:HH:HH:HH:HH>	INTERFACE DOT11RADIO STATION	This command provides a filter when the client is selecting an Access Point during scanning. The first MAC address is the prefix of BSSID you allow the client to associate with. The second MAC address is a mask of the prefix. If configured, only an access point with matching BSSID will be selected. For example, if you want the client

		to only connect to MSR series routers, you can specify a prefix of 00:17:7b:00:00:00 with mask of ff:ff:ff:00:00:00 Multiple filters can be configured if you want to allow multiple BSSID prefix choices. Default allows all BSSIDs.
no access-point bssid-filter acceptable-prefix <HH:HH:HH:HH:HH:HH> <HH:HH:HH:HH:HH:HH>		Remove a certain BSSID filter
no access-point bssid-filter acceptable-prefix		Remove all the BSSID filters
scanning channel-list <channel list>	INTERFACE DOT11RADIO STATION	Configure a list of channels that you allow the client to look at when doing access point scanning. Only one channel list is allowed. Default has no channel list and it scans in all legal channels of the configured hardware modes. (See “scanning hardware-modes” command). <channel list>: a list of comma separated channel numbers, no space in between
no scanning channel-list		Remove the current configured channel list
scanning hardware-modes <mode string>	INTERFACE DOT11RADIO STATION	Configure the hardware modes that you allow the client to stay in when doing access point scanning <mode string>: a, g, ag It means do scanning only in 802.11a mode, 802.11g mode or in both modes. Default value is both 802.11a and 802.11g.
no scanning hardware-modes		Remove the hardware scanning mode setting and return to default.
scanning minimum-interval <seconds>	INTERFACE DOT11RADIO STATION	Configure the minimum allowed time interval between two consecutive scans. <seconds>: a number between 1 and 300, the unit is second. Default value is 60 seconds.

no scanning minimum-interval	Restore default setting of minimum scan interval				
scanning threshold rssi <rssi value>	INTERFACE DOT11RADIO STATION	Configure the RSSI value threshold to trigger a new scan. If the current RSSI is lower than configured threshold, the client will start a new scan. <rssi value>: a number between 0 and 100. 0 means no such trigger. Default value is 15.	RSSI stands for Received Signal Strength Index		
no scanning threshold rssi	Restore the default RSSI threshold value.				
release-dhcp dot11radio <0-N> station <station name>	Privileged EXEC	Release the station's IP address acquired from DHCP server			
renew-dhcp dot11radio <0-N> station <station name>	Renew the station's IP address via DHCP server				
restart-dhcp dot11radio <0-N> station <station name>	Restart DHCP client for the station				

. 802.11 Security Configuration

The 802.11 security standard defines a suite of wireless security protocols and implementations. The MSR series allows the client mode to use a specific 802.11 security profile such as WEP or WPA. Refer to the chapter on 802.11 Security for more information.

Viewing information of a station in a dot11radio interface.

```
MSR2000# show run
...
!
interface dot11radio 0
...
station demo
  ip address dhcp
  access-point ssid demo
...
MSR2000# sh interface dot11radio 0
  Interface Dot11Radio0
  operation_mode:client, country code:US, channel policy:0, antenna:1,
  cts protection:2,
  distance:0, short retry:7, long retry:4,
  admin status: up  physical status: up
  index 35 metric 1 mtu 1500 <UP,BROADCAST,RUNNING,MULTICAST>
  HWmode: g, channel: 1, Fragment thr: 2346, RTS thr: 2347
```

```
HWaddr: 00:17:7b:00:27:40
  input packets 823925, bytes 96825419, dropped 0, multicast packets 0
  input errors 88069, length 0, overrun 0, CRC 0, frame 0, fifo 0, missed 0
  output packets 457, bytes 26006, dropped 0
  output errors 2, aborted 0, carrier 0, fifo 0, heartbeat 0, window 0
  collisions 0
Station Information:
Station demo
  State: Associated
  SSID: "demo", Access Point: 00:17:7b:35:e8:53 RSSI: 55
  Previous Access Point: NA
  IP Address: 172.16.21.249 (DHCP acquired)
  Security: None
  Scanning threshold: RSSI 15
  Minimum scan interval: 60 seconds
  scanning in hardware modes: ag
  scanning in channels:
    mode A: 36 40 44 48 52 56 60 64 149 153 157 161 165
    mode G: 1 2 3 4 5 6 7 8 9 10 11
```

Figure 12 Output of station information under dot11radio interface

Chapter 7 Radio Frequency Management

Radio Frequency Management (RFM) is an advanced feature of MSR series that allows automatic discovery and quality monitoring of wireless mesh links. RFM automatically scans for compatible mesh routers in the neighboring area and create automatic WDS links to these routers. With RFM, multiple mesh routers can form a mesh network without any manually configured WDS interfaces. In addition, an RFM-aware routing protocol could use the link quality information from RFM to optimize the routing path in the wireless mesh network.

Auto neighbor discovery and WDS link creation

RFM discovers neighboring mesh routers using ***passive-scanning***, a process that is automatically started when a backhaul radio interface is operating without any manually configured WDS interfaces. Passive-scanning automatically changes the channel of the radio interface and listens for 802.11 beacons from other mesh routers. If one or more routers are heard, RFM selectively attempts to create WDS links with these other routers. Auto WDS interfaces are automatically created and configured if the WDS connection is successfully established.

The configuration commands that controls auto-discovery is **wds auto**, which enables Auto WDS discovery for a radio interface, and **max-auto-wds**, which controls how many automatic WDS links RFM is allowed to create on that interface. If **wds auto** is not set for a radio interface, RFM will not perform any scanning or WDS interface creation on that radio.

Note: As previously mentioned in the chapter on WDS configuration, the MSR series can only form WDS links with other MSR series routers that use the same mesh ID.

WDS link quality monitoring

RFM could monitor the link quality for all WDS links present on an MSR series router, regardless of whether the link is manually configured or automatically created. The WDS interface for the link must be active¹⁴. The link quality is displayed in the results of the “show interface dot11radio X wds” command:

```
MSR2000# show interface dot11radio 0 wds 0
Interface Radio0MWds0
neighbor specified using: mac address
remote mac address: 00:17:7b:35:eb:0d, remote node: 152, remote radio: 0
admin status: up physical status: up neighbor ip: 200.151.152.2
rssi: 71, snr: 71, link quality: 87%, datarate: 60
role:auto, physical interface:0,
index 20 metric 1 mtu 1500 <UP,BROADCAST,RUNNING,MULTICAST>
HWmode: a, channel: 149, Fragment thr: 2346, RTS thr: 2347
HWaddr: 00:17:7b:18:18:38
inet 200.151.152.1/24 broadcast 200.151.152.255
    input packets 1046, bytes 164912, dropped 0, multicast packets 0
    input errors 0, length 0, overrun 0, CRC 0, frame 0, fifo 0, missed 0
```

¹⁴ An active WDS interface is one that is bound to an active backhaul radio interface and not administratively shutdown.

```

output packets 862, bytes 160520, dropped 0
output errors 4, aborted 0, carrier 0, fifo 0, heartbeat 0, window 0
collisions 0
output packets 6082, bytes 1602424, dropped 0
output errors 0, aborted 0, carrier 0, fifo 0, heartbeat 0, window 0
collisions 0

```

The link quality parameters monitored by RFM include RSSI, SNR, overall quality¹⁵, and data rate.

RFM related configuration commands

The following table summarizes the commands used to configure RFM's auto-discovery and link monitoring functions:

Command Syntax	Command Mode	Purpose
wds auto	INTERFACE DOT11RADIO	Enable automatic WDS provisioning on this radio interface and enter the INTERFACE DOT11RADIO WDS AUTO mode for auto WDS configuration; this command is mutually exclusive with the wds <0-5> command.
no wds auto		Disable auto WDS on this radio interface.
max-auto-wds <1-6>	INTERFACE DOT11RADIO WDS AUTO	Set the maximum number of auto WDS interfaces that could be created on this RFM
service rf-management	CONFIGURATION	Start the configuration of the RFM service
enable	SERVICE RF-MANAGEMENT	Activate the RFM function
debug	SERVICE RF-MANAGEMENT	Set the RFM debug log level
debug none		Disable RFM debug log
debug error		Set RFM debug log to record errors
debug state		Set RFM debug log to record errors & state changes
debug information		Log error, state, and other detailed information
debug frame		Log error, state, information, and RFM control packet frames
debug dump		Log all RFM debug information

¹⁵ The link quality percentage measurement is based on the level of RFM control packet loss.

The following commands can be entered at the privileged EXEC prompt to display information about the RFM service:

Command Syntax	Command Mode	Purpose
show log rf-management	Privileged EXEC	Display the debug log of RFM (see debug command above)
show rf-management active-neighbors	Privileged EXEC	Display a list of neighboring MSR series routers and radios discovered by RFM
show rf-management interface	Privileged EXEC	Display a list of WDS interfaces currently monitored by RFM; may include both auto and manual WDS interfaces.
show rf-management configuration	Privileged EXEC	Display the current configuration parameters of RFM

Viewing rf-management information.

```
MSR2000# show rf-management active-neighbors
RF Management active neighbor table:
RFM has 2 active radio interfaces, 2 total WDS interfaces
Dot11Radio0 has 1 active neighbors:
Ngh 1: Mac: 00:00:00:00:00:00 Learned: No
    IP: 10.140.141.1, node_id: 0, radio_idx: 0
    local WDS if: Radio0MWds0, local IP: 10.140.141.2
    admin status: Up, physical status: Down, state: Initial, flag: 0x13
    phytpe: IEEE 802.11a, ch: 161, mode: WDS
    link quality: 93%, rssi: 70, snr: 70
Dot11Radio1 has 1 active neighbors:
Ngh 1: Mac: 00:17:7b:36:a3:5b Learned: No
    IP: 10.141.143.2, node_id: 143, radio_idx: 0
    local WDS if: Radio1MWds0, local IP: 10.141.143.1
    admin status: Up, physical status: Up, state: Established, flag: 0x13
    phytpe: IEEE 802.11a, ch: 52, mode: WDS
    link quality: 86%, rssi: 69, snr: 69

MSR2000# show rf-management interface
RF Management WDS Interfaces:
Dot11Radio0:    mesh ID: TestMesh, peer capacity: 5
Radio0MWds0:    Radio: Dot11Radio0, node ID: 141
                admin status: Up, physical status: Down
                IP: 10.140.141.2, Netmask: 255.255.255.0, Bcast: 10.140.141.255
                NGH MAC: 00:00:00:00:00:00, NGH node ID: 0, NGH radio_index: 0
                NGH IP: 10.140.141.1, NGH Netmask: 255.255.255.0, NGH Bcast:
10.140.141.255
                link state: Initial, Link quality: 93%
                RSSI: 70, SNR: 70
Radio1MWds0:    Radio: Dot11Radio1, node ID: 141
                admin status: Up, physical status: Up
                IP: 10.141.143.1, Netmask: 255.255.255.0, Bcast: 10.141.143.255
                NGH MAC: 00:17:7b:36:a3:5b, NGH node ID: 143, NGH radio_idx: 0
                NGH IP: 10.141.143.2, NGH Netmask: 255.255.255.0, NGH Bcast:
10.141.143.255
                Link State: Established, Link quality: 86%
```

RSSI: 69, SNR: 69

Figure 13 Output of Rf-management

Chapter 8 Configuring Routing

This chapter contains information on configuring layer-3 routing on the MSR series, it has the following sections:

- [Static Routing](#)
- [Dynamic Routing through AWR](#)

Static Routing

Static routing allows the network administrator full control over the layer-3 topology and data forwarding behavior of the network. The administrator constructs the routing table for a router by specifying a route for each destination network.

A configured static route is installed in the routing table only when the route is active; that is, the route's next-hop must be bound to an operational interface. The following table summarizes the command to add/remove static route:

Table 16 Configuring Static Route

Command Syntax	Command Mode	Purpose
ip route <A.B.C.D/M> <A.B.C.D> [<1-255>]	CONFIGURATION	Add a indirect static route
no ip route <A.B.C.D/M> <A.B.C.D>		Remove a gateway static route
		A.B.C.D/M: destination network prefix/mask A.B.C.D: gateway IP address 1-255: the distance value for this route, lower is better with 255 being unreachable. (optional, default is 1)
ip route <A.B.C.D/M> station <name> <0-N>		Add a directly-connected static route that binds to a client mode station
no ip route <A.B.C.D/M> station <name> <0-N>		Remove a directly-connected route
		A.B.C.D/M: destination network prefix/mask name: Station name 0-N: Index of radio interface the station belongs to

Dynamic Routing through the AWR protocol

Dynamic routing is the process through which a router learns and updates routes to the other nodes in the network. For optimal performance in a wireless mesh environment, MSR series supports the intelligent Adaptive Wireless Routing (AWR) protocol. When AWR is activated, each MSR series will automatically maintain a table of optimal routes to the other MSR series nodes in the network, the clients associated to these nodes, and to the internet gateway. AWR ensures high-performance data forwarding in a wireless mesh environment by minimizing the number of hops used in data communication, regardless of whether that communication is within the mesh network itself, or between a host in the network and the internet.

The following table summarizes the configuration commands that control the operation of AWR:

Command Syntax	Command Mode	Purpose
router awr	CONFIGURATION	Start the configuration of the AWR routing protocol
no router awr		Disable AWR and remove its configuration
enable	ROUTER AWR	Administratively activate the AWR routing protocol ¹⁶
disable	ROUTER AWR	Administratively disable the AWR routing protocol
debug	ROUTER AWR	Set the AWR debug log level
debug none		Disable AWR debug log
debug error		Set AWR debug log to record errors
debug state		Set AWR debug log to record errors & state changes
debug information		Log error, state, and other detailed information
debug dump		Log all AWR debug information

Displaying current routing status

The following commands can be entered at the privileged EXEC prompt to display information about the system routing table and/or the AWR protocol state:

Command Syntax	Command Mode	Purpose
show ip route	Privileged EXEC	Display the current routing table
show ip forwarding	Privileged EXEC	Display the current layer-3 forwarding information
show log awr	Privileged EXEC	Display the debug log of AWR (see

¹⁶ If AWR is administratively enabled, it should be running as long as it has a valid configuration.

		debug command above)
show ip awr configuration	Privileged EXEC	Display the current AWR configuration and status
show ip awr database	Privileged EXEC	Display the routing data currently tracked by the AWR protocol
show ip awr neighbor	Privileged EXEC	Display the list of IP addresses of neighboring MSR series routers

Viewing routing information.

```
MSR2000# show ip route
Codes: K - kernel route, C - connected, S - static, H - host,
       A - AWR, > - selected route, * - FIB route

A>* 0.0.0.0/0 [50/2] via 10.2.6.1, Radio0MWds1, 01:43:57
A>* 10.0.0.0/8 [50/2] via 10.2.6.1, Radio0MWds1, 02:23:46
A>* 10.1.5.1/32 [50/2] via 10.1.6.1, Radio0MWds0, 02:30:56
A>* 10.1.5.2/32 [50/2] via 10.5.6.2, Radio1MWds1, 02:30:44
A>* 10.2.5.1/32 [50/2] via 10.2.6.1, Radio0MWds1, 02:23:37
A>* 10.2.5.2/32 [50/2] via 10.5.6.2, Radio1MWds1, 02:23:37
C>* 10.6.7.0/24 is directly connected, Radio0MWds0
H>* 10.6.7.1/32 [0/0] is directly connected, Radio0MWds0
A 10.6.7.2/32 [50/2] via 10.6.7.2, 02:30:56
C>* 192.168.1.0/24 is directly connected, fast-ethernet 0
H>* 192.168.1.136/32 [0/0] is directly connected, fast-ethernet 0
A>* 192.168.2.131/32 [50/2] via 10.1.6.1, Radio0MWds0, 02:31:01
A>* 192.168.2.132/32 [50/2] via 10.2.6.1, Radio0MWds1, 02:23:46
A>* 192.168.2.134/32 [50/2] via 10.4.6.2, Radio1MWds0, 02:30:56
A>* 192.168.2.135/32 [50/2] via 10.5.6.2, Radio1MWds1, 02:30:56
C>* 192.168.2.136/32 is directly connected, lo:2
A>* 192.168.2.137/32 [50/2] via 10.6.7.2, Radio0MWds0, 02:30:56
A>* 10.1.2.1/32 [50/2] via 10.1.6.1, Radio0MWds0, 02:23:46
A>* 10.1.2.2/32 [50/2] via 10.2.6.1, Radio0MWds1, 02:23:46
C>* 10.1.6.0/28 is directly connected, Radio0MWds0
A 10.1.6.1/32 [50/2] via 10.1.6.1, 02:31:01
H>* 10.1.6.2/32 [0/0] is directly connected, Radio0MWds0
A>* 10.1.7.1/32 [50/2] via 10.1.6.1, Radio0MWds0, 02:31:01
A>* 10.1.7.2/32 [50/2] via 10.6.7.2, Radio0MWds0, 02:30:56
C>* 10.2.6.0/28 is directly connected, Radio0MWds1
H>* 10.4.6.1/32 [0/0] is directly connected, Radio1MWds0
A 10.4.6.2/32 [50/2] via 10.4.6.2, 02:30:56
A>* 10.4.7.1/32 [50/2] via 10.4.6.2, Radio1MWds0, 02:30:56
A>* 10.4.7.2/32 [50/2] via 10.6.7.2, Radio0MWds0, 02:30:56
C>* 10.5.6.0/28 is directly connected, Radio1MWds1
H>* 10.5.6.1/32 [0/0] is directly connected, Radio1MWds1
A 10.5.6.2/32 [50/2] via 10.5.6.2, 02:30:56
A>* 10.5.7.1/32 [50/2] via 10.5.6.2, Radio1MWds1, 02:30:53
A>* 10.5.7.2/32 [50/2] via 10.6.7.2, Radio0MWds0, 02:30:56

MSR2000# show ip awr neighbor
AWR internal neighbor table:
Neighbor IP address=10.2.6.1
Neighbor IP address=10.5.6.2
Neighbor IP address=10.6.7.2
Neighbor IP address=10.4.6.2
Neighbor IP address=10.1.6.1
```

Figure 14 Output of routing information

Chapter 9 Configuring Motrix Roaming

This chapter contains information on configuring the Motrix Roaming Service on the MSR series.

Motrix Protocol Overview

Motrix is the roaming service MSR series provides to support the seamless roaming of wireless clients across different mesh network subnets. Such support is necessary because every MSR series is a layer-3 router and each BSS within the mesh network is associated with a single layer-3 subnet. These subnets are interconnected via IP routing functions of the MSR series. When a client joins the network on one router's BSS, it would have an IP that belongs to that BSS's subnet. If the client subsequently roams to another router's BSS, the Motrix service enables the client to retain its connectivity to the network using its previous IP address (which would actually belong to a different subnet). Without Motrix, the client would have to change its IP address and thus lose all of its existing connections.

To support inter-subnet roaming, each participating access router must enable the Motrix service and have the same BSS settings (SSID, authentication, etc) configured. We emphasize "access router" here because it is not necessary for a MSR series configured only for backhaul or client to enable the Motrix service.

When using the built-in wireless functions of a Centrino® certificated notebook, one is recommended to upgrade the notebook to the latest official driver from the Download/Support webpage of the notebook vendor.

It is highly recommended that the participating clients use dynamic IP addressing (DHCP). If the clients must be configured with static IP addresses, then only one router may act as the gateway for the mesh network and a "Static IP client list" must be specified on the gateway router and each access router. For more information, see the item "Static IP Client List" in the section "Motrix-related configuration information."

Motrix Configuration

This section covers the following main topics:

- Motrix-related configuration information
- Motrix-related configuration commands
- [Show motrix configuration](#)

Motrix-related configuration information

1) The roaming gateway

Motrix requires the specification of a single gateway router on each access router that provides roaming support. Even when there are multiple gateways connected to the same mesh network, one of them needs to be specified as the “roaming gateway” router.

2) The MAC-IP mapping of other BSSs

The Motrix service also requires the IP and MAC address of every BSS (or virtual AP) within the mesh network. This information is automatically learned if the AWR routing protocol is enabled. However, if Motrix is to be used while AWR is not running, then the MAC-IP mapping must be configured manually through the **mac-ip-list** command described below. Each entry in the MAC-IP list is a mapping that associates a BSS’s MAC address with its router ID.

Note: The MAC-IP list is indexed by the BSS MAC address, and each MAC address may be associated with only one IP address.

3) Static IP client list

In some applications, clients use preconfigured static IP addresses. To support such clients, only one wired-gateway router could be present in the mesh network and a station list need to be specified on each participating access router and the gateway router. The station list contains MAC-IP mappings that associate the static IP clients’ IP addresses with their MAC addresses. This information can only be configured manually.

Configuring Motrix Service

The following table summarizes the configuration commands for Motrix:

Command Syntax	Command Mode	Purpose
service roaming-motrix	CONFIGURATION	Start configuration of the Motrix Roaming Service
no service roaming-motrix		Disable Motrix Roaming Service and remove its configuration
enable	SERVICE ROAMING-MOTRIX	Activate the Motrix roaming service ¹⁷
disable		Shutdown the Motrix Roaming service
gateway A.B.C.D	SERVICE ROAMING-MOTRIX	Specify the IP address of the roaming gateway router
mac-ip-list <HH:HH:HH:HH:HH:HH> <A.B.C.D>	SERVICE ROAMING-MOTRIX	Add an entry to the MAC-IP list

¹⁷ When enabled, Motrix should be running as long as it has a valid configuration.

no mac-ip-list			Clear all entries of the MAC-IP list
no mac-ip-list <HH:HH:HH:HH:HH:HH>			Remove an entry from the MAC-IP list HH:HH:HH:HH:HH:HH: The MAC address of a BSS in the network
station-list <HH:HH:HH:HH:HH:HH> <A.B.C.D/M>	SERVICE ROAMING-MOTRIX		Add an entry to the station list
no station-list			Clear all entries of the station list
no station-list <HH:HH:HH:HH:HH:HH>			Remove an entry from the station list HH:HH:HH:HH:HH:HH: The MAC address of a static-IP client in the network
debug	SERVICE ROAMING-MOTRIX		Set the Motrix debug log level
debug none			Disable Motrix debug log
debug error			Set Motrix debug log to record errors
debug information			Log errors and other important information
debug dump			Log all Motrix debug information

Displaying Motrix Configuration and Status

Table 17 Display roaming status

Command Syntax	Command Mode	Purpose
show log motrix	Privileged EXEC	Display the debug log of Motrix (see debug command above)
show ip mobility motrix	Privileged EXEC	Display Motrix configuration and status
show ip mobility motrix mac-ip-list	Privileged EXEC	Display the MAC-IP list used by Motrix
show ip mobility motrix stations	Privileged EXEC	Display the list of clients/stations that are Home associated or roaming from other MSR series

```

!
!
! Configuration
!
service roaming-motrix
  enable
  debug information
  mac-ip-list 00:00:65:43:21:00 172.16.21.1
  mac-ip-list 00:17:7b:37:ab:53 172.16.20.1
  mac-ip-list 00:17:7b:36:a1:0a 172.16.19.1
  station-list 00:14:bf:c2:09:4c 10.1.1.249/32
  station-list 00:17:7b:00:27:38 10.2.2.99/32
  gateway 192.168.15.97
!

MSR2000# show ip mobility motrix
<cr>
  mac-ip-list  Display mac-ip table
  stations      Display roaming stations
MSR2000# show ip mobility motrix
  status RUNNING
  enable
  tcp
  debug information
  keepalive on

MSR2000# show ip mobility motrix mac-ip-list
Learned from configuration:
00:17:7b:43:21:00 172.16.21.1
00:17:7b:37:ab:53 172.16.20.1
00:17:7b:36:a1:0a 172.16.19.1
MSR2000# show ip mobility motrix stations
STATIONS:
Total number of stations: 2

  MAC: 00:40:96:a2:be:e3
  IP: 172.16.20.242
  State: Roam Associated
  Time since last (re)association: 448(s)
  Associated interface: Dot11Radio0(00:17:7b:36:a1:0a)
  Previous AP: 00:17:7b:37:ab:53
  Home AP: 00:17:7b:37:ab:53/172.16.20.1
  No tunnel

  MAC: 00:14:78:72:10:01
  IP: 0.0.0.0
  State: Home Associated
  Time since last (re)association: 7(s)
  Associated interface: Dot11Radio0(00:17:7b:36:a1:0a)
  Previous AP: 00:00:00:00:00:00
  No tunnel
  Tunnel from gateway 192.168.15.97 is established

```

Figure 15 Output of Motrix

Chapter 10 DHCP and NAT

This chapter contains information on configuring the DHCP and NAT services on the MSR series, it has the following sections:

- [DHCP Protocol Overview](#)
- [Configuring DHCP Server](#)
- [Configuring DHCP Relay](#)
- [Configuring NAT](#)

DHCP Protocol Overview

Dynamic Host Configuration Protocol (DHCP) is a communications protocol that lets network administrators manage and automate the assignment of Internet Protocol (IP) addresses in an organization's network. DHCP allows devices connecting to a network to automatically obtain an IP address.

In order to ensure that each STA can communicate with external internet and/or between each other, it should be assigned an IP address. The MSR series provides DHCP services such as DHCP server and DHCP Relay to dynamically assign such addresses.

Configuring DHCP Server

On MSR series, each BSS has its own private subnet. Each STA associated with a BSS obtains an IP address from the DHCP server.

- [Configuring DHCP Server Parameters](#)
 - [Configuring DHCP pools](#)
 - [Attaching DHCP pools to BSSs](#)
- [Showing DHCP Information and Status](#)

Configuring DHCP Server Parameters

DHCP configurations are performed in CONFIGURATION mode. The following table outlines the general DHCP configuration commands:

Table 18 Configuring DHCP Server

Command Syntax	Command Mode	Purpose
ip dhcp server	CONFIGURATION	Start configuration of DHCP server
no ip dhcp server		Stop the DHCP server and remove its configuration
enable	IP DHCP SERVER	Enable the DHCP server ¹⁸

disable	IP DHCP SERVER	Temporarily disable the DHCP server
default-lease-time <0-31536000>	IP DHCP SERVER	Set the time (in seconds) given to each DHCP lease request that does not specify a lease time. The maximum is 31536000 seconds (one year).
no default-lease-time		Set this parameter to the default value of 86400 seconds (1 day)
dns [DNS-list]	IP DHCP SERVER	Enter DNS addresses that will be included in a DHCP lease. Multiple DNS servers may be specified by separating them with commas (,).
no dns		Clear the DNS list; no DNS information will be included in leases
max-lease-time <0-31536000>	IP DHCP SERVER	Set the maximum allowed lease time in seconds; can be set as high as 3153600 (one year)
no max-lease-time		Set this parameter to the default value of 86400 seconds (one day)
pool [NAME]	IP DHCP SERVER	Configure a new or existing DHCP pool (see below for details)
no pool [NAME]		Remove an existing DHCP pool
		NAME: An alphanumeric string that identifies the DHCP pool

Configuring DHCP Pools

The MSR series DHCP server supports multiple DHCP pools. Each DHCP pool is a separate IP address space that the DHCP server uses to respond to lease requests for specific pools. Each pool may be on different networks or uses different gateways and domain-names. The pool-specific configuration controls the IP address, gateway, and domain-name information the client devices would obtain through their DHCP requests.

Usually, pools are bind to specific BSSs and DHCP requests received from clients associated to these BSSs would use different DHCP pools to honor the request. DHCP pools may be configured manually on the MSR series or be automatically created. Automatically created DHCP pools use the IP address prefix 172.16 through 172.31, while manual DHCP pools may use any IP address prefix. **Note: the DHCP pool IP address prefix must not duplicate any other IP addresses or networks needed by the mesh network.**

The following table outlines the manual DHCP pool configuration commands:

pool [NAME]	IP DHCP SERVER	Configure a new or existing DHCP pool (see below for details)
--------------------	----------------	---

¹⁸ Once enabled, DHCP server will be running as long as it has a valid configuration.

no pool [NAME]		Remove an existing DHCP pool
		NAME: An alphanumeric string that identifies the DHCP pool
domain-name [name]	IP DHCP SERVER POOL	Set the domain name to be included in DHCP leases for this pool
no domain-name		Do not include any domain name information in DHCP leases for this pool
		name: A domain name such as "azaleanete.com"
gateway <A.B.C.D>	IP DHCP SERVER POOL	Set the gateway IP to be included in DHCP leases for this pool
no gateway <A.B.C.D>		Do not include gateway in DHCP leases
		A.B.C.D: A gateway IP address that should conform to a IPv4 unicast address, where A is 1-223, B & C is 0-254, and D is 1-254.
host <HH:HH:HH:HH:HH:HH> <A.B.C.D>	IP DHCP SERVER POOL	Add a fixed DHCP IP address entry for a client host
no host <HH:HH:HH:HH:HH:HH>		Remove a fixed DHCP IP address entry
		HH:HH:HH:HH:HH:HH: MAC address of the client host
		A.B.C.D: Fixed IP address to be assigned to the host
network {<A.B.C.D Mask> <A.B.C.D/M>}	IP DHCP SERVER POOL	Specify the subnet that this pool belongs to
		<A.B.C.D Mask>: Address and mask of the subnet, e.g. 10.1.1.0 255.255.255.0
		A.B.C.D/M: Address/mask of the subnet, e.g. 10.1.1.0/24
range <begin IP> <end IP>	IP DHCP SERVER POOL	Add a range of IP addresses to this DHCP pool
no range <begin IP> <end IP>		Remove a range from this DHCP pool
		Begin IP: The first IP address of the range End IP: The last IP address of the range.

Both begin and end IP should be a valid IPv4 unicast address.

Attaching DHCP pools to Ethernet interfaces and BSSs

Different BSSs and/or different Ethernet interfaces may use different DHCP pools. You can use the following command in the **BSS** and **INTERFACE DOT11RADIO BSS modes** to attach DHCP pools to BSSs and Ethernet interfaces:

Command Syntax	Command Mode	Purpose
dhcp server <POOL-NAME>	INTERFACE DOT11RADIO BSS	Attach a manual DHCP pool to the current BSS ¹⁹
dhcp server automatic		Attach an automatic DHCP pool to the current BSS
no dhcp		Detach DHCP service from the current BSS
ip address [ip address/mask]	INTERFACE DOT11RADIO BSS	Set IP address of this BSS. This command is required when using a manual DHCP pool.
no ip address		Remove IP address from this BSS

Show DHCP Server Information and Status

You can use the following commands to show current configuration about DHCP server.

Table 19 Display DHCP Server Information

Command Syntax	Command Mode	Purpose
show dhcp server all	Privileged EXEC	Show all DHCP server information
show dhcp server default-lease-time	Privileged EXEC	Show the current value of default lease time
show dhcp server dns	Privileged EXEC	Show the current dns value
show dhcp server lease	Privileged EXEC	Show the current IP address assignments
show dhcp server max-lease-time	Privileged EXEC	Show the current value of maximal lease time
show dhcp server pool	Privileged EXEC	Show the current DHCP pools

¹⁹ Only one of DHCP pool and DHCP relay can be used on a BSS, so if this BSS had DHCP relay enabled (see next section), it will be disabled.

Viewing DHCP Server configuration

```
!
! Configuration
!
router dhcp server
  domain-name azaleanete.com
  dns 10.13.28.12,10.13.31.12
  max-lease-time 100000
!
!
MSR2000# show dhcp server all
domain-name: azaleanete.com
DNS servers: 10.13.28.12,10.13.31.12
default-lease-time: 86400 (unit: seconds)
max-lease-time: 100000 (unit: seconds)
!
!
MSR2000# show dhcp server default-lease-time
default-lease-time: 86400 (unit: seconds)
!
!
MSR2000# show dhcp server dns
DNS servers: 10.13.28.12,10.13.31.12
!
!
MSR2000# show dhcp server max-lease-time
max-lease-time: 86400 (unit: seconds)
!
```

Figure 16 Output of DHCP Server configuration

Configuring DHCP Relay

DHCP Relay is responsible for forwarding the DHCP requests and responses sent by the DHCP clients and server. It allows clients associated to BSSs on the MSR series routers to obtain IP address from pools defined on an external DHCP server.

- [Configuring DHCP Relay Parameters](#)
 - [Enabling DHCP relay on specific BSSs](#)
- [Show DHCP Relay Information](#)

Configuring DHCP Relay Parameters

Configuring DHCP relay has to be in CONFIGURATION mode. The following table summarizes the commands to configure DHCP relay.

Table 20 Configuring DHCP Relay

Command Syntax	Command Mode	Purpose
----------------	--------------	---------

ip dhcp relay	CONFIGURATION	Start configuration of DHCP relay
no ip dhcp relay		Stop DHCP relay service and remove its configuration
enable	IP DHCP RELAY	Start the DHCP relay service
disable	IP DHCP RELAY	Temporarily stop the DHCP relay service
dhcp-servers [<i>SERVER-list</i>]	IP DHCP RELAY	Configure a list of DHCP servers to which the DHCP requests would be relayed. Multiple servers may be specified by separating them with commas (,).
no dhcp-servers		Clear the DHCP server list

Enabling DHCP Relay on specific BSSs

Not all BSSs have to use DHCP relay; some may use DHCP pools or no DHCP service at all. You can use the following command in the “**BSS mode**” to enable DHCP relay for a BSS:

Command Syntax	Command Mode	Purpose
dhcp relay	INTERFACE DOT11RADIO BSS	Enable DHCP relay on this BSS ²⁰
no dhcp		Disable DHCP service from the current BSS

Show DHCP Relay Information

You can use the following commands to show current configuration about dhcp relay. Note that it should be in ENABLE mode.

Table 21 Configuring DHCP Server

Command Syntax	Command Mode	Purpose
show dhcp relay dhcp-servers	Privileged EXEC	Show DHCP servers are used by DHCP relay

Viewing DHCP Relay configuration

```
!
!DHCP Relay Configuration
!
router dhcp relay
  dhcp-servers 192.168.1.1,192.168.1.2
```

²⁰ Only one of DHCP pool and DHCP relay can be used on a BSS, so if this BSS had DHCP pool attached (see previous section), it will be removed.

```
!
!Display DHCP Relay Information
!
MSR2000# show dhcp relay dhcp-servers
dhcp-servers: 192.168.1.1 192.168.1.2
!
```

Figure 17 Output of DHCP Relay configuration

Configuring NAT

Network Address Translation (NAT) is an Internet standard that enables a local-area network (LAN) to use one set of IP addresses for internal traffic and a second set of addresses for external traffic. A NAT box located where the LAN meets the Internet makes all necessary IP address translations. This chapter contains the information of configuring NAT on the MSR series.

The service NAT runs only in the mesh gateway. You can use the following commands to configure the NAT service:

Table 22 Configuring NAT

Command Syntax	Command Mode	Purpose
ip nat	CONFIGURATION	Enter NAT configuration mode
no ip nat		Disable NAT and remove NAT configuration
Enable	IP NAT	Enable NAT service
Disable	IP NAT	Disable NAT service temporarily
out-interface fast-ethernet <0-1>	IP NAT	Add a FastEthernet interface as external NAT interface
out-interface dot11radio <0-N> station <name>		Add a client station as external NAT interface.
no out-interface fast-ethernet <0-1>		Remove a FastEthernet as the NAT interface.
no out-interface dot11radio <0-N> station <name>		Remove a client station as the NAT interface.

Show the configuration of NAT

You can use the following commands to show current configuration about NAT.

Table 23 Display NAT interface and NAT table

Command Syntax	Command Mode	Purpose

show nat out-interface	Privileged EXEC	Display NAT Outside interface
-------------------------------	-----------------	-------------------------------

show nat table	Privileged EXEC	Display NAT Table
-----------------------	-----------------	-------------------

Chapter 11 802.11 Security

This chapter describes how to configure security policies as defined by the 802.11i standard on the MSR series router. It contains the following sections:

- 802.11 security standard overview
- MAC-based access control configuration
- RADIUS AAA Configuration
- Security Profile Configuration
- BSS security
- WDS security

802.11 standard overview

The 802.11 security standard defines a suite of wireless security protocols and implementations. It provides open and shared key authentication, is compatible with WPA /WPA2, and interoperates with 802.1x.

MAC-based Access Control Configuration

MSR series allows MAC address-based access control. For each BSS hosted by the router, one can allow or disallow a list of client MAC addresses proper association with the AP. Creation of the MAC list and the specification of the MAC addresses are performed by the mac-list command under CONFIGURATION TERMINAL mode.

Table 24 Configuring MAC-List

Command Syntax	Command Mode	Purpose
mac-list <listname>	CONFIGURATION	Create or modify a MAC address list with the specified name
no mac-list <listname>	CONFIGURATION	Remove a MAC address list
mac-addr <HH:HH:HH:HH:HH:HH>	MAC-LIST	Add a MAC address to the MAC list
no mac-addr <HH:HH:HH:HH:HH:HH>	MAC-LIST	Remove a MAC address from MAC list

Show the configuration of MAC-List

You can use the following commands to show current configuration about MAC-List.

Table 25 Display MAC-List and information

Command Syntax	Command Mode	Purpose
show mac-list	Privileged EXEC	Show all configured MAC address list

View MAC-List configuration

Figure 18 Output of MAC-List configuration

!

```

mac-list aaa
mac-addr 00:00:11:11:11:11
mac-addr 00:00:11:11:11:12
mac-addr 00:00:11:11:11:13
mac-addr 00:00:11:11:11:14
mac-list bbb
mac-addr 00:00:22:22:22:22
mac-addr 00:00:22:22:22:23
mac-addr 00:00:22:22:22:24
!

MSR2000# show mac-list
mac-list aaa
mac-addr 00:00:11:11:11:11
mac-addr 00:00:11:11:11:12
mac-addr 00:00:11:11:11:13
mac-addr 00:00:11:11:11:14
mac-list bbb
mac-addr 00:00:22:22:22:22
mac-addr 00:00:22:22:22:23
mac-addr 00:00:22:22:22:24

```

RADIUS AAA Configuration

This section describes how to enable and configure the RADIUS (Remote Authentication Dial-In User Service), which provide flexible administrative control over authentication and authorization processes. RADIUS is configured with the AAA mode command.

Table 26 Configuring AAA

Command Syntax	Command Mode	Purpose
Aaa	CONFIGURATION	Configuring AAA parameters, including authentication and accounting servers and ports
radius-server <A.B.C.D> auth-port <1-65535> key <string>	AAA	Add a radius authentication server using the specified port and secret key.
radius server <A.B.C.D> auth-port default key <string>		Add a radius authentication server using the default port of 1812 and the specified secret key.
no radius-server <A.B.C.D> auth		Remove a radius authentication server
radius-server <A.B.C.D>acct-port <1-65535> key <string>	AAA	Add a radius accounting server using the specified secret key and authentication port
radius server <A.B.C.D> acct-port default key <string>		Add a radius accounting server using the default port of 1813 and the specified secret key.

no radius-server <A.B.C.D> acct		Remove a radius accounting server
server-group²	AAA	Enter server group configuration
server <A.B.C.D> auth	SERVER GROUP	Add a authentication server to server group
no server <A.B.C.D> auth		Remove authentication server from server group
server <A.B.C.D> acct		Add a accounting server to server group
no server <A.B.C.D> acct		Remove a accounting server from server group

Notes:

1. The radius-server command defines a radius server; the definition includes the ip address and port of an authentication or the ip address and port of an accounting server, Specifying a radius-server only make it available for use to the MSR series, but would not be used until included by a server group.
2. The server-group contains the radius server information for authentication or accounting, it is the current running-configuration that allow user to configure multiple servers under the server-group. The first authentication and accounting radius server is the primary server, the second server is the backup server, and the second server takes effect only when the first server fail to communicate with MSR series.

Table 27 Display AAA configuration

Command Syntax	Command Mode	Purpose
show aaa	PRIVILEGE EXEC	show aaa configuration, including radius server and server-group configuration

View AAA configuration**Figure 19** Output of AAA configuration

```
!
aaa
radius-server 192.168.10.69 auth-port 1812 key secret
radius-server 192.168.20.234 auth-port 1812 key 123456
server-group
  server 192.168.10.69 auth
  server 192.168.20.234 auth
!
MSR2000# show aaa
!
aaa
radius-server 192.168.10.69 auth-port 1812 key secret
```

```

radius-server 192.168.20.234 auth-port 1812 key 123456
server-group
  server 192.168.10.69 auth
  server 192.168.20.234 auth
MSR2000#

```

Certificate Configuration

This section describes how to download and install certificates which are used for authenticating the MSR series as an allowed client for other 802.11 APs.

Table 27 Installing Authentication Certificates

Command Syntax	Command Mode	Purpose
install certificate ca <URL>	Privilege EXEC	Download and install the CA certificate from the provided URL
install certificate client <URL>	Privilege EXEC	Download and install the client certificate from the provided URL
install client-key <URL>	Privilege EXEC	Download and install the client key file from the provided URL

Table 28 Displaying Installed Certificates

Command Syntax	Command Mode	Purpose
show certificate ca	Privilege EXEC	Show the information of the installed CA certificate.
show certificate client	Privilege EXEC	Show the information of the installed client certificate.

Configuration example:

```

MSR2000# install certificate ca http://192.168.1.1/certs/cert-ca.pem
MSR2000# install certificate client http://192.168.1.1/certs/cert-clt.pem
MSR2000# install client-key http://192.168.1.1/certs/cert-clt-key.pem
MSR2000# show certificate ca
MSR2000# show certificate client

```

Security-Profile Configuration

This section describes the authentication types and encryption methods that you can configure on the router. Security profile on MSR series defines all security policy supported by router software. Now router supports WEP, WPA, WPA2 and 8021X security suites. This block is only a definition of security policy, and it will take effect after attached in BSS or WDS. You can add multi profile for the same methods, and that will be flexible to change security policy on router for user.

Table 29 Configuring Security Profiles

Command Syntax	Command Mode	Purpose
security-profile wep <wep-profile-name>	CONFIGURATION	Create or modify a WEP security profile of the given name
no security-profile wep <wep-name>		Remove a WEP profile
wep-key <1 2 3 4> <key-string>	SECURITY-PROFILE WEP	Add a WEP key to the WEP profile
no wep-key <1 2 3 4>		Remove a WEP key from WEP profile
security-profile wpa <wpa-profile-name>	CONFIGURATION	Create or modify a WPA security profile of the given name
no security-profile wpa <wpa-profile-name>		Remove a WPA profile
encryption-mode-cipher tkip no encryption-mode-cipher	SECURITY-PROFILE WPA	Enable TKIP encryption mode for WPA
wpa-type 8021x <8021x-profile-name>	SECURITY-PROFILE WPA	Enable 8021X authentication for WPA profile
no wpa-type 8021x		Remove 8021X authentication on WPA profile
wpa-type psk hex <string> wpa-type psk ascii <string> no wpa-type psk	SECURITY-PROFILE WPA	Enable WPA PSK authentication on WPA profile and configure pre-shared key using hexadecimal format. Enable WPA PSK and configure pre-shared key using ASCII format Remove WPA PSK authentication from WPA profile
security-profile wpa2 <wpa2-profile-name>	CONFIGURATION	Add a WPA2 profile
no security-profile wpa2 <wpa2-profile-name>		Remove a WPA2 profile from current configuration
encryption-mode-cipher ccmp encryption-mode-cipher tkip no encryption-mode-cipher	SECURITY-PROFILE WPA2	Enable CCMP encryption for WPA2 profile Enable TKIP encryption for WPA2 profile

wpa2-type 8021x <8021x-profile-name>	SECURITY-PROFILE WPA2	Enable 8021X authentication for WPA2 profile
no wpa2-type 8021x		Remove 8021X authentication from WPA2 profile
wpa2-type psk hex <string>	SECURITY-PROFILE WPA2	Enable WPA2 PSK authentication on WPA2 profile and configure pre-shared key using hexadecimal format.
wpa2-type psk ascii <string>		Enable WPA2 PSK and configure pre-shared key using ASCII format
no wpa2-type psk		Remove WPA2 PSK authentication from WPA2 profile
security-profile 8021x <8021x-profile-name>	CONFIGURATION	Add a 8021X authentication profile
no security-profile 8021x<8021x-profile-name>		Remove a 8021X authentication profile
eap-reauth-period <0-65535>	SECURITY-PROFILE 8021x	Set EAP re-authentication period
eap-reauth-period 3600 no eap-reauth-period		Restore EAP re-authentication to default value of 3600 seconds
security-profile client-8021x <client-8021x-profile-name>	CONFIGURATION	Add a client 8021X authentication profile
no security-profile client-8021x <client-8021x-profile-name>		Remove a client 8021X authentication profile
eap-method peap	SECURITY-PROFILE CLIENT-8021x	Enable PEAP authentication method for client-8021x profile
eap-method ttls		Enable TTLS authentication method for client-8021x profile
eap-method tls		Enable TLS authentication method for client-8021x profile
no eap-method		Remove eap method for client-8021x profile.

password <string>	SECURITY-PROFILE CLIENT-8021x	Set the user password for authentication
no password		Remove password for client-8021x profile
user-name <string>	SECURITY-PROFILE CLIENT-8021x	Set the user name for authentication
no user-name		Remove user name for client-8021x profile

Table 30 Display configuration of security profile

Command Syntax	Command Mode	Purpose
show security-profile wep	Privilege EXEC	Show WEP profile configuration
show security-profile wpa	Privilege EXEC	Show WPA profile configuration
show security-profile wpa2	Privilege EXEC	Show WPA2 profile configuration
show security-profile 8021x	Privilege EXEC	Show 8021x profile configuration
show security-profile client-8021x	Privilege EXEC	Show client-8021x profile configuration

Figure Output of WEP profile configuration

```

security-profile wep wep1
wep-key 1 1234567890abcdef1234567890
wep-key 2 "abcde"
wep-key 3 "abcdefabcde"
wep-key 4 abcdefabcdefabcdefabcdefab
security-profile wep wep2
wep-key 1 "abcde"
wep-key 2 "1234567890123"
wep-key 3 "1234567890abcdef"
wep-key 4 1234567890
security-profile wep wep3
wep-key 3 abcdefabcdefabcdefabcdefab
security-profile wep wep4

MSR2000# show security-profile wep
security-profile wep wep1
wep-key 1 1234567890abcdef1234567890
wep-key 2 "abcde"
wep-key 3 "abcdefabcde"

```

```
wep-key 4 abcdefabcdefabcdefabcdefabcdef
security-profile wep wep2
wep-key 1 "abcde"
wep-key 2 "1234567890123"
wep-key 3 "1234567890abcdef"
wep-key 4 1234567890
security-profile wep wep3
wep-key 3 abcdefabcdefabcdefabcdef
security-profile wep wep4
MSR2000#
```

Figure 20 Output of WPA profile configuration

```
security-profile wpa wpa1
  encryption-mode-cipher tkip
    wpa-type psk
    hex
1234567890abcdef1234567890abcdef1234567890abcdef
security-profile wpa wpa2
  encryption-mode-cipher tkip
  wpa-type 8021x 802.1xprofile
security-profile wpa wpa3
  encryption-mode-cipher tkip
```

Figure 21 Output of WPA2 profile configuration

```
security-profile wpa2 wpa2-pskprofile
  encryption-mode-cipher ccmp
  wpa2-type 8021x 802.1xprofile
!
```

Figure 22 Output of 8021x profile configuration

```
!
security-profile 8021x 8021xprofile
  eap-reauth-period 3600
security-profile 8021x 8021x1

MSR2000# show security-profile 8021x
security-profile 8021x 8021xprofile
  eap-reauth-period 3600
security-profile 8021x 8021x1
MSR2000#
```

Figure 23 Output of client-8021x profile configuration

```
security-profile client-8021x client-8021x1
  eap-method tls
  user-name test-tls
security-profile client-8021x client-8021x2
  eap-method peap
```

```

user-name test-peap
password whatever
security-profile client-8021x client-8021x3
eap-method ttls
user-name test-ttls
user-name ttls
password whatever

```

BSS Security Configuration

This section describes how to apply security profiles and MAC lists to the router's BSS configurations.

Table 31 Configuring BSS Security

Command Syntax	Command Mode	Purpose
authentication open no authentication	INTERFACE DOT11RADIO BSS	Allow all clients to associate with this BSS
authentication open wep <wep-profile-name> default-key <1-4>		Enable WEP encryption for this BSS using the key settings in the WEP profile and the specified default key
authentication open key-management wpa <wpa-profile-name>		Enable WPA security for this BSS; only allow clients with correct WPA authentication and encryption settings to associate with this BSS.
authentication open key-management wpa2 <wpa2-profile-name>		Enable WPA2 security for this BSS; only allow clients with correct WPA2 authentication and encryption settings to associate with this BSS.
authentication shared wep <wep-profile-name> default-key <1-4>		Enable WEP authentication and encryption for this BSS using the key settings in the WEP profile and the specified default key
mac-address accept <mac-list-name>	INTERFACE DOT11RADIO BSS	Only accept clients with MAC addresses in the specified list; deny all other clients
mac-address deny <mac-list-name>		Only deny clients with MAC addresses in the specified list; allow all other clients.
mac-address accept-all no mac-address		Restore to default configuration (accept all MAC addresses)

Table Display security configuration on BSS

show interface dot11radio <0 1> bss <SSID> accept-macs	Privileged EXEC	Show attached accept macs address on SSID of the Radio
show interface dot11radio <0 1> bss <SSID> deny-macs	Privileged EXEC	Show attached deny macs address on SSID of the Radio
show interface dot11radio0 bss <SSID> wep-keys	Privileged EXEC	Show BSS WEP configuration

```

MSR2000# show interface dot11radio 0 bss public accept-macs
accept mac list:
00:00:22:22:22:22, 00:00:22:22:22:23, 00:00:22:22:22:24,

MSR2000# show interface dot11radio 0 bss public1 deny-macs
deny mac list:
00:00:11:11:11:11,           00:00:11:11:11:12,           00:00:11:11:11:13,
00:00:11:11:11:14,          

MSR2000# show interface dot11radio 0 bss public wep-keys
<cr>
MSR2000# show interface dot11radio 0 bss public wep-keys
wep key 1=1234567890abcdef1234567890
wep key 2="abcde"
wep key 3="abcdefabcdefa"
wep key 4=abcdefabcdefabcdefabcdefab
MSR2000#

```

WDS Security Configuration

This section describes how to apply security profiles and MAC lists to the router's manual WDS interfaces.

Table 32 Configuring WDS security

Command Syntax	Command Mode	Purpose
authentication open no authentication	INTERFACE DOT11RADIO WDS	Disable authentication for this WDS interface (open system).
authentication open key-management wpa <wpa-profile-name>		Enable WPA security for this WDS interface using the specified profile settings.
authentication shared wep <wep-profile-name> default-key <1-4>		Enable WEP security for this WDS interface using the key settings in the WEP profile and the specified default key

CLIENT Security Configuration

This section describes how to apply security profiles and WEP key to the router's configured clients.

Table 33 Configuring client-mode security

Command Syntax	Command Mode	Purpose
<code>client-authentication open wep <wep-profile-name> default-key <1-4></code>	INTERFACE DOT11RADIO STATION	Enable WEP encryption for this client using the key settings in the WEP profile and the specified default key
<code>client-authentication open client-8021x <client-8021x-profile-name></code>		Enable 802.1X authentication for this client, using the authentication settings in the client-8021x profile
<code>client-authentication open key-management wpa client-8021x <client-8021x-profile-name></code>		Enable WPA security for this CLIENT, using the authentication settings in the client-8021x profile
<code>client-authentication open key-management wpa2 client-8021x <client-8021x-profile-name></code>		Enable WPA2 security for this CLIENT, using the authentication settings in the client-8021x profile
<code>client-authentication open key-management wpa-psk hex <string></code>		Enable WPA PSK on client and configure pre-shared key using hexadecimal format.
<code>client-authentication open key-management wpa-psk ascii <string></code>		Enable WPA PSK on client and configure pre-shared key using ascii format.
<code>client-authentication shared wep <wep-profile-name> default-key <1-4></code>		Enable WEP encryption for this client using the key settings in the WEP profile and the specified default key
<code>no client-authentication</code>		Disable authentication for this client interface.

Notes:

1. Open: Open authentication allows any clients to authenticate and then attempts to communicate with the router.
2. Shared-key :
 - a) Shared Key authentication seeks to authenticate clients as either a member of those who know a shared secret key or a member of those who do not.
 - b) Shared Key authentication can be used if and only if WEP has been selected.
 - c) Not recommended because of known security flaws.
3. WEP: Wired Equivalent Privacy
 - a) WEP have three keys, 64bits, 128bits and 152bits, and based on RC4 algorithm.
 - b) WEP was defined as a means of protecting the confidentiality of data exchanged among authorized users of a wireless LAN from casual eavesdropping.
4. WPA :
 - a) Wi-Fi Protected Access (WPA) is a standards-based, interoperable security enhancement that strongly increases the level of data protection and access control for existing and future wireless LAN systems.
 - b) WPA leverages TKIP (Temporal Key Integrity Protocol) for data protection and 802.1X for authenticated key management.
 - c) WPA key management supports two mutually exclusive management types: WPA(802.1X) and WPA-Pre-shared key (WPA-PSK)
5. WPA2: WPA version 2, add AES encryption algorithm than WPA.
6. 802.1X:
 - a) Port-Based Networks Access Control;
 - b) 8021X is consisting of supplicant, authenticator and server.
 - c) After clients associate to BSS successful, clients start authentication process of 8021X. IEEE 8021X think an associate to be a controlled port.

Chapter 12 QoS Configuration

Traffic over-subscription is a common cause for the instability of network links; if many links in the mesh network is over-subscribed, the performance of the overall network becomes unstable. In order to avoid over-subscribing any individual WDS link, we strongly recommend enabling QoS to control and limit the traffic flows injected into the network. This chapter contains information on defining and configuring QoS on MSR series.

- Enable/Disable QoS Service
- Configuring QoS over ManualWDS Interface
 - Configuring QoS class
 - Attaching QoS class to ManualWDS
- Configuring QoS over AutoWDS Interface
- Showing QoS Information and Status

Enable/Disable QoS Service

By default, QoS doesn't take effect on MSR series. Use the following commands to start or stop the QoS in CONFIGURATION mode.

Table 34 Enable/Disable QoS

Command Syntax	Command Mode	Purpose
qos	CONFIGURATION	Enter QoS configuration mode
enable	QOS	Enable QoS, start QoS service and all QoS classes attached to WDS interface will take effect
disable	QOS	Disable QoS, stop QoS service and all QoS classes attached to WDS interface will be disabled

When enable QoS globally, user should attach QoS to WDS Interface. There are two kinds of WDS interfaces, ManualWDS interface created by users and AutoWDS interface created by RF-Management service. Correspondingly, for ManualWDS interface, user should manually configure QoS settings. On the other hand, for AutoWDS interface, it will automatically configure QoS settings if QoS service is enabled.

Configuring QoS over ManualWDS Interface

There are two steps to run QoS service over one ManualWDS interface: creating one QoS class and attaching it to ManualWDS interface. First, user should configure one QoS class which specifies the maximal and minimal bandwidth of this ManualWDS interface. After creating one specific QoS class, user should attach this QoS class to ManualWDS interface.

Configuring QoS Classes

The QoS class is targeted to let user specify acceptable bandwidth of one WDS link. For each QoS class, user must specify one maximal bandwidth value and one minimal bandwidth value. Use the following commands to configure QoS classes.

Table 35 Configuring QoS Classes

Command Syntax	Command Mode	Purpose
class <name>	QOS	Create/configure one QoS class. The class name is unique identifier for all QoS classes. Meanwhile, user enters the CLASS configuration mode to configure the QoS class
no class <name>	QOS	Delete the QoS class with specific name
maxbw <1-500>	QOS CLASS	Specify the maximal bandwidth that this QoS class can obtain. (Unit: 100kbps)
no maxbw		Set the maximal bandwidth to default value (30Mbps).
minbw <1-200>	QOS CLASS	Specify the minimal bandwidth guarantee to this class. (Unit: 100kbps)
no minbw		Set the minimal bandwidth to default value (5Mbps)

Attaching QoS Class to ManualWDS Interface

After configuring one preferable QoS class, user should indicate which ManualWDS interface to use this specific QoS class. Use the following commands to attached one specific QoS class to one ManualWDS interface.

Table 36 Attaching QoS Class to ManualWDS

Command Syntax	Command Mode	Purpose
qos class <classname>	INTERFACE DOT11RADIO WDS	Attach one specific QoS class with <i>classname</i> to this ManualWDS Interface. Correspondingly, start QoS service over this interface if QoS service is enabled on router.
no qos class	INTERFACE DOT11RADIO WDS	Deattach QoS class from this ManualWDS interface. Furthermore, one default QoS class will take effect on this interface if enable QoS globally.

Note that one QoS class can be attached to multiple different ManualWDS interfaces. It must ensure that user is in the WDS configuration mode for attaching one QoS class to ManualWDS interface.

Additionally, one default QoS class will be automatically created once QoS service is enabled on router. For the ManualWDS interfaces to which a QoS class doesn't be

attached, it will automatically apply the default QoS class to these ManualWDS interfaces. But, it needs to further note that all of the special ManualWDS interface share the maximal and minimal bandwidth indicated by the default QoS class. **Max** bandwidth of the default class is **30/(wdsnumber+1) Mbps** and and **Min** bandwidth is minimal value of **2M** and **30/(wdsnumber+1)*25%Mbps**, where wdsnumber is the number of WDS interfaces on the radio over which .QoS service is started.

Configuring QoS over Auto WDS Interface

By default, for all AutoWDS interfaces, QoS service will be automatically take effect on them once QoS service is enabled on router. The QoS class for auto WDS interfaces is created based on the following rules:

- Each AutoWDS's max bandwidth is 30Mbps;
- Each AutoWDS's min bandwidth is 30/(wdsnumber+1) Mbps;
- If wds-unicast-rate of the radio to which this auto WDS interface is attached has been specified, the maximal bandwidth of one auto WDS interface will be set to wds-unicast-rate.value (under the condition that this value is smaller than 30Mbps).

Showing QOS Information and Status

Command Syntax	Command Mode	Purpose
show qos configuration	Privileged EXEC	Show configuration of QoS
show qos dot11radio <Radio> class	Privileged EXEC	Show class rules on specific radio
show qos dot11radio <Radio> qdisc	Privileged EXEC	Show queue discipline rules on specific radio
show qos interface	Privileged EXEC	Show class name applied on interfaces and running state

View QOS configuration

```
MSR2000# show running-config
!
node-id 54
router-id 192.168.15.54
!
.....
interface dot11radio 0
  wireless-mode a 136 DK
  antenna 1
  mode backhaul
  max-auto-wds 5
  wds 0
    remote mac 00:17:7b:37:a0:00
    ip address 10.53.54.2/24
    qos class band1
    no shutdown
  wds 1
    remote mac 00:17:7b:37:a1:00
    ip address 10.52.54.2/24
    qos class band2
    no shutdown
```

```
!
.....
!
qos
  enable
  class band1
    maxbw 200
    minbw 100
  class band2
    maxbw 150
    minbw 60
  class band3
    maxbw 100
    minbw 40
!
```

Chapter 13 Configuring SNMP

This section describes commands used to configure the Simple Network Management Protocol (SNMP) Agent on the MSR2000 for the purposes of network monitoring and management.

Configuring SNMP Community

To set the community string for controlling access to the Management Information Base (MIB) on the SNMP Agent, use the **snmp-server community** command. The **no** form of this command removes the specified community string.

Table 37 Configuring snmp-server community

Command Syntax	Command Mode	Purpose
snmp-server community [community] [ro rw]	CONFIGURATION	Add an SNMP community string that identifies an access control domain for the SNMP agent.
		ro: Specifies read-only access. Authorized management stations are able to retrieve, but not modify, MIB objects.
		rw: Specifies read-write access. Authorized management stations are able to both retrieve and modify MIB objects.
no snmp-server community [community]		Remove SNMP community string
show snmp-server community	Privileged EXEC	Display all configured community strings

Configuring SNMP Trap

To specify the recipient of a SNMP trap (a mechanism used to notify Network Management Servers of a change in the network device state), use the **snmp-server host** configuration command. To remove the specified host, use the no form of this command.

Table 38 Configuring snmp-server host

Command Syntax	Command Mode	Purpose
snmp-server host [ip-address] [community] [udp-port]	CONFIGURATION	Configure IP address of SNMP host to receive traps using the specified community string and SNMP port.
no snmp-server host [ip-address]		
show snmp-server host	Privileged EXEC	Display all SNMP trap hosts with associated community strings and ports

Configuring SNMPv3 users

MSR series also supports SNMPv3, which introduces the concept of users. The following commands controls the SNMPv3 user database on each MSR series router:

Table 39 Configuring SNMPv3 users

Command Syntax	Command Mode	Purpose
snmp-server v3user <name> <ro rw> <MD5 pass> <DES pass> <user-type>	CONFIGURATION	Configure a new or existing SNMPv3 user account.
no snmp-server v3 user <name>		Remove an existing SNMPv3 user account
		name: SNMPv3 user name ro rw: whether the user is read-only or read-write MD5 pass: Authentication password DES pass: Encryption password user-type: auth auth, no priv noauth no auth, no priv priv auth, priv
show snmp-server v3user	Privileged EXEC	Display all configured SNMP V3 user accounts

Viewing the snmp-server information

```
MSR2000# show snmp-server community
community string          access mode
public                     read-only
private                    read-write
!
MSR2000# show snmp-server host
host                      community string      port
192.168.10.55             public              162
192.168.10.10              trap                162
192.168.10.64              trap                162
192.168.10.130             trap                162
192.168.10.44              public              162
MSR2000# show snmp-server v3user
user          access      usm-level  auth-pass      priv-pass
read          read-only   noauth     12345678    12345678
```

Figure 23 Output of snmp-server configuration

Chapter 14 Other commands and utilities

This chapter contains other commands and troubleshooting utilities on the MSR series, it has the following sections:

- [Save & Reboot](#)
- [Ping & Traceroute](#)
- [Telnet Client & Server](#)
- [Auto Recovery](#)

Save & Reboot

Save

Azalea recommends that you save your configuration often.

To save a configuration file, use either of the following commands in the Privileged EXEC mode:

Table 40 Save the running configuration to startup configuration

Command Syntax	Command Mode	Purpose
<code>copy running-config startup-config</code>	Privileged EXEC	Save the current running configuration to the startup-config file.
<code>write memory</code>	Privileged EXEC	Save the current running configuration to the startup-config file. (old way to save configuration)

Reboot

Azalea provides command **reboot** to hot restart MSR series. After upgraded, user can use command **reboot** to restart MSR series, then the new image takes effects.

Table 41 Reboot configuration

Command Syntax	Command Mode	Purpose
<code>reboot</code>	Privileged EXEC	Restart MSR series without turning off power.

Ping & Traceroute

Commands **ping** and **traceroute** are very helpful utilities to troubleshoot network access problems.

Ping

Command **ping** a very common method for troubleshooting the accessibility of devices. It uses a series of Internet Control Message Protocol (ICMP) Echo messages to determine:

- Whether a remote host is active or inactive.
- The round-trip delay in communicating with the host.
- Packet loss.

Command **ping** first sends an echo request packet to an address, then waits for a reply, the reply will be recorded with latency. The default **ping** packet is 6, **Ctrl+c** can terminate **ping**.

Traceroute

Command **traceroute** is used to discover the routes that packets actually take when traveling to their destination. The network device sends out a sequence of User Datagram Protocol (UDP) datagrams to an invalid port address at the remote host.

Three datagrams are sent, each with a Time-To-Live (TTL) field value set to one. The TTL value of 1 causes the datagram to "timeout" as soon as it hits the first router in the path; this router then responds with an ICMP Time Exceeded Message (TEM) indicating that the datagram has expired.

Another three UDP messages are now sent, each with the TTL value set to 2, which causes the second router to return ICMP TEMs. This process continues until the packets actually reach the other destination. Since these datagrams are trying to access an invalid port at the destination host, ICMP Port Unreachable Messages are returned, indicating an unreachable port; this event signals the Traceroute program that it is finished.

The purpose behind this is to record the source of each ICMP Time Exceeded Message to provide a trace of the path the packet took to reach the destination.

Table 42 ping & traceroute configuration

Command Syntax	Command Mode	Purpose
ping { <A.B.C.D> <hostname> }	Privileged EXEC	Detect remote device accessibility or not.
traceroute { <A.B.C.D> <hostname> }	Privileged EXEC	Trace the path of the packet to destination.

```
MSR2000# ping 192.168.15.126
PING 192.168.15.126 (192.168.15.126): 56 data bytes
84 bytes from 192.168.15.126: icmp_seq=0 ttl=64 time=8.7 ms
84 bytes from 192.168.15.126: icmp_seq=1 ttl=64 time=0.8 ms
84 bytes from 192.168.15.126: icmp_seq=2 ttl=64 time=1.0 ms
84 bytes from 192.168.15.126: icmp_seq=3 ttl=64 time=0.9 ms
84 bytes from 192.168.15.126: icmp_seq=4 ttl=64 time=1.0 ms
84 bytes from 192.168.15.126: icmp_seq=5 ttl=64 time=0.9 ms

--- 192.168.15.126 ping statistics ---
6 packets transmitted, 6 packets received, 0% packet loss
round-trip min/avg/max = 0.8/2.2/8.7 ms

MSR2000# ping 192.168.15.11
```

```

PING 192.168.15.11 (192.168.15.11): 56 data bytes
--- 192.168.15.11 ping statistics ---
6 packets transmitted, 0 packets received, 100% packet loss

MSR2000# traceroute 192.168.15.126
traceroute to 192.168.15.126 (192.168.15.126), 30 hops max, 40 byte packets
 1  192.168.15.126 (192.168.15.126)  7.134 ms  1.323 ms  0.821 ms
MSR2000#

```

Figure 24 Output of ping & traceroute information

Telnet Client & Server

MSR series can play role as Telnet Client and Telnet Server.

Telnet Client

When MSR series acts as Telnet client, you can use command **telnet** to access other device.

Telnet Server

When MSR series acts as Telnet server, you should use command **ip telnet server** to enable the service. Telnet Server disable by default.

Table 43 Telnet Client & Server configuration

Command Syntax	Command Mode	Purpose
telnet { <A.B.C.D> <hostname> } [port]	Privileged EXEC	Access remote device through Telnet.
ip telnet server	Configuration	Enable telnet server.
no ip telnet server		Disable telnet server

Viewing Telnet Server configuration

```

!
ip telnet server
!
```

Auto Recovery

Auto Recovery is an advanced feature provided by MSR series, When enabled, Auto Recovery will automatically detect and recover from system fault. When configured with a portal IP, auto recovery would also monitor its connectivity with the portal node. If the connectivity is lost and auto recovery believes it is due to a local problem, it will automatically reboot the router as an attempt to restore its normal working state.

Table 44 Auto Recovery configuration

Command Syntax	Command Mode	Purpose
service recovery	CONFIGURATION	Enter Auto Recovery configuration mode
enable	SERVICE RECOVERY	Administratively activate Auto Recovery
disable	SERVICE RECOVERY	Administratively disable Auto Recovery
portal ip <A.B.C.D> no portal ip <A.B.C.D>	SERVICE RECOVERY	Set an IP address for the device to check the state of connection wire network Delete portal IP address

Viewing Auto Recovery configuration

```
!  
service recovery  
enable  
!
```

Chapter 15 MIBs and RFCs

Supported MIBs

The following is a list of Management Information Bases (MIBs) supported by MSR series.

- RFC 1213 Network Management of TCP/IP-based internet: MIB-II
- RFC 1157 Simple Network Management Protocol
- RFC 1573 Interfaces Group MIB
- RFC 2012 SNMPv2 Management Information Base for the TCP
- RFC 2013 SNMPv2 Management Information Base for the User Datagram Protocol
- RFC 2271 An Architecture for Describing SNMP Management Frameworks
- RFC 1901 Introduction to Community-based SNMPv2
- RFC 1902 Structure of Management Information for Version 2 of the SNMPv2
- RFC 1903 Textual Conventions for SNMPv2
- RFC 1904 Conformance Statements for SNMPv2
- RFC 1905 Protocol Operations for SNMPv2
- RFC 1906 Transport Mappings for SNMPv2
- RFC 1907 Management Information Base for SNMPv2
- RFC 2571 Architecture for SNMP Frameworks
- RFC 2572 Message Processing and Dispatching
- RFC 2573 SNMP Applications
- RFC 2574 User-based Security Model (USM) for SNMPv3
- RFC 2575 View-based Access Control Model (VACM) for SNMP
- RFC 2578 Structure of Management Information Version 2 (SMIv2).
- RFC 2579 Textual Conventions for SMIv2
- RFC 2580 Conformance Statements for SMIv2
- MIB II
- IF-MIB
- IP-MIB, TCP-MIB, UDP-MIB
- SNMP-FRAMEWORK-MIB
- SNMP-TARGET-MIB
- SNMP-NOTIFICATION-MIB
- SNMP-USM-MIB
- SNMP-VACM-MIB
- AZALEA-REF-MIB
- AZALEA-DOT11-IF-MIB
- AZALEA-ROUTER-MIB

Chapter 16 List of Commands

```

<cr>
A
  aaa
    Accept-point bssid HH:HH:HH:HH:HH:HH
      access-point bssid-filter acceptable-prefix HH:HH:HH:HH:HH:HH
      HH:HH:HH:HH:HH:HH
      access-point ssid WORD
      antenna {0|1|2}
      authentication-algorithm {open|shared-key}
      authentication open [{wep WEP-LIST-NAME default-key <1-4> | key-management {wpa|wpa2} PROFILE-NAME}]
B
  bss WORD
C
  class NAME
    clear counters interface dot11radio INDEX
    clear counters interface dot11radio INDEX (wdsauto|wdsmanu) <0-5>
    clear counters interface fast-ethernet INDEX
    clear log {awr|cli|hostapd|rf-management|motrix}
    clear log {awr|cli|hostapd|rf-management|motrix|station}
      client-authentication (open|shared) wep PROFILE-NAME default-key <1-4>
      client-authentication open client-8021x PROFILE-NAME
      client-authentication open key-management (wpa|wpa2) client-8021x PROFILE-NAME
      client-authentication open key-management wpa-psk (hex|ascii) WORD
    configure terminal
    copy running-config startup-config
    cts-protection {0|1|2|3}
D
  debug {hap|cli} {dump|error|frame|info|none|state}
  debug rf-management ping
    debug dot11radio <0-N> distance [{default<a|b|g> |timeout VALUE}]
    debug dot11radio <0-N> scan [{bssid HH:HH:HH:HH:HH:HH|channel N}]
    debug phm (error|info|dump)
  default-lease-time <0-31536000>
  dhcp relay
  dhcp server {<POOL-NAME> | automatic}
  dhcp-servers SERVER-list
  disable
  dns DNS-list
  domain-name NAME
E
  eap-method (peap|ttls) phase2 (md5|mschapv2|tls)
  eap-method tls
  eap-reauth-period <0-65535>
  enable

```

```

encryption-mode-cipher {tkip|ccmp}
encryption-mode-cipher tkip ccmp
end
exit
G gateway A.B.C.D
H help
hostname WORD
host HH:HH:HH:HH:HH A.B.C.D
I ignore-broadcast-ssid
interface dot11radio <0-N>
interface fast-ethernet <0-1>
install certificate ca URL
install certificate client URL
install client-key URL
install client-key URL password PRIVATE-KEY-PASSWORD
ip address A.B.C.D/M
ip address dhcp
ip address STANAME A.B.C.D A.B.C.D
ip dhcp {relay|server}
ip nat
ip route A.B.C.D/M A.B.C.D [<1-255>]
ip route A.B.C.D/M station <name> <0-N>
ip telnet server
L List
M mac-addr HH:HH:HH:HH:HH:HH
mac-address {deny|accept} MAC-LIST-NAME
mac-address accept-all
mac-list WORD
max-auto-wds <1-6>
max-lease-time <0-31536000>
max-rate RATE
max-station-allowed <0-240>
mode {access|backhaul|client}
Mode backhaul WORD
mode {access|gateway A.B.C.D/M|none}
mtu <256-1500>
mtu <256-2274>
N network {A.B.C.D|A.B.C.D/M}
no access-point bssid
no access-point bssid-filter acceptable-prefix
    no access-point bssid-filter acceptable-prefix
HH:HH:HH:HH:HH:HH HH:HH:HH:HH:HH:HH
no access-point ssid
no antenna
no authentication
no authentication-algorithm
no bss WORD
no class NAME

```

```
no client-authentication
no cts-protection
no default-lease-time
no dhcp
no dhcp-servers
no dns
no domain-name
no eap-method
no eap-reauth-period
no encryption-mode-cipher
no gateway A.B.C.D
no hostname [HOSTNAME]
no host HH:HH:HH:HH:HH:HH
no ignore-broadcast-ssid
no ip address
no ip dhcp {relay|server}
no ip nat
no ip route A.B.C.D/M {A.B.C.D|station WORD <0-N>}
no ip telnet server
no mac-address
No mac-addr HH:HH:HH:HH:HH:HH
no mac-list WORD
no mac-ip-list
no mac-ip-list HH:HH:HH:HH:HH:HH
no max-lease-time
no max-rate
no max-station-allowed
no mode
no mtu
no out-interface dot11radio INDEX station WORD
no out-interface fast-ethernet <0-1>
no pool [NAME]
no password
no profile mesh <WORD>
no qos class
no radius-server A.B.C.D (auth_acct)
no range A.B.C.D A.B.C.D
no retry
no role
no router awr
  no scanning {channel-list| hardware-modes| mininum-interval|
threshold rssi}
no security-profile {8021x|client-8021x|wep|wepa|wpa2} WORD
no service roaming-motrix
no server A.B.C.D
no shutdown
no snmp-server community COMMUNITY
no snmp-server host A.B.C.D
```


```
no snmp-server v3user USERNAME
no ssid
no station WORD
no station-inactivity-limit
no station-inactivity-policy
no station-isolation
no station-list
no station-list HH:HH:HH:HH:HH:HH
no tx-power-reduction
no unicast-rate
no user-name
no wds {<0-5>|auto}
no wds-unicast-rate
no wep-key <1-4>
no wireless-mode
no wpa-type {8021x|psk}
no wpa2-type {8021x|psk}
node-id <1-255>
O  out-interface dot11radio INDEX station WORD
out-interface fast-ethernet <0-1>
P  password PASSWORD-STRING
ping WORD
pool [NAME]
profile mesh <WORD>
Q  qos
qos class NAME
quit
radius-server A.B.C.D {auth-port {<1-65535>|default}|acct-
R  port{<1-65535>|default} key <string>
range A.B.C.D A.B.C.D
reboot
remote-mac HH:HH:HH:HH:HH:HH
release-dhcp {dot11radio <0-N> station WORD | fast-ethernet<0-
1>}
remote node <1-255> INDEX
renew-dhcp {dot11radio <0-N> station WORD | fast-ethernet<0-1>}
restart-dhcp {dot11radio <0-N> station WORD| fast-ethernet<0-
1>}
retry <1-32> <1-32>
role (ap|station|auto)
router awr
router-id A.B.C.D
router-password
S  scanning automatic
scanning hardware-modes WORD
scanning mininum-interval <1-300>
scanning threshold rssi <0-100>
security-profile {8021x|client-8021x|wep|wpa|wpa2}
```

```
server-group
server A.B.C.D
service recovery
service rf-management
service roaming-motrix
setup ap {US|CN|JP} <1-255> A.B.C.D A.B.C.D/M WORD WORD
setup factory
setup point {US|CN|JP} <1-255> A.B.C.D A.B.C.D/M
setup portal {US|CN|JP} <1-255> A.B.C.D A.B.C.D/M SSID DNS-
SERVER-LIST
setup portal {US|CN|JP} <1-255> A.B.C.D A.B.C.D/M SSID DNS-
SERVER-LIST nat-off
setup portal {US|CN|JP} <1-255> A.B.C.D dhcp SSID DNS-SERVER-
LIST
setup portal {US|CN|JP} <1-255> A.B.C.D dhcp SSID DNS-SERVER-
LIST nat-off
show aaa
show arp [<A.B.C.D>|interface {dot11radio <0-N>| dot11wds <0-
31>| fast-ethernet <0-1>}]
show arp count [interface {dot11radio <0-N>| dot11wds <0-31>|
fast-ethernet <0-1>}]
show certificate (ca|client)
show clock
show cpu
show dhcp relay dhcp-servers
show dhcp server {all| default-lease-time|dns|lease|max-lease-
time|pool|pool POOL-NAME}
show dot11radio <0-N> stations
show hardware
show hostname
show interface brief
show interface dot11radio <0-N> [{stations|states|txpower|node-
database}]
show interface dot11radio <0-N> [<ssid> {accept-macs| deny-
macs| stations| wep-keys}]
show interface dot11radio <0-N> {wds|wdsauto} <0-5>
show interface fast-ethernet <0-1>
show ip awr {configuration|database|neighbor}
show ip forwarding
show ip mobility motrix {mac-ip-list|stations}
show ip route [{awr|connected|static| A.B.C.D| A.B.C.D/M|
A.B.C.D/M longer-prefixes|fib|summary}]
show log {awr|cli|hostapd|rf-management|motrix|station|phm}
Show mac-list
show nat {out-interface|configuration|table}
show node-id
show process
Show profile mesh
show qos dot11radio <0-N> {class|qdisc}
show qos {configuration|interface}
show recovery configuration
```


```
show rf-management {active-neighbors|interface|configuration}
show router id
show running-config
show security-profile {wep|wpa|wpa2|8021x|client-8021x}
show snmp-server {community|host|v3user}
show startup-config
show version
ssh HOST {USER|USER PORT}
Shutdown
snmp-server community COMMUNITY {rw|ro}
snmp-server host A.B.C.D COMMUNITY <1-65535>
snmp-server v3user USERNAME {ro|rw} MD5PWD DESPWD {noauth|auth|priv}
ssh HOST {USER|USER PORT}
ssid <WORD>
station <WORD>
station-inactivity-limit <1-65535>
station-inactivity-policy {0|1}
station-isolation
switch image
T
telnet WORD [PORT]
time <2005-2008> <1-12> <1-31> <0-23> <0-59> <0-59>
traceroute WORD
tx-power-reduction <0-65535>
U
unicast-rate RATE
upgrade ftp A.B.C.D FILENAME USERNAME PASSWORD [reboot]
upgrade url URL [reboot]
user-name NAME-STRING
W
wds-unicast-rate RATE
wep-key <1-4> (ascii|hex) WORD
wds <0-5>
wds auto
wireless-mode {a|g|b} CHANNEL [country-name] <0|1|2>
wireless-mode {a|g|b} <channel> [country-name]
write {file|memory|terminal}
wpa-type 8021x NAME
wpa-type psk (hex|ascii) WORD
wpa2-type 8021x NAME
wpa2-type psk (hex|ascii) WORD
```

MSR1000 Wireless Mesh Router

— Hardware Installation Flyer



www.azaleanet.com



1. Connect the DC power adapter to the power connector socket on the rear panel. The Power LED should be on to indicate a proper connection.
2. Connect an Ethernet cable to the ETH1 port on the rear panel. Connect the other end of the Ethernet cable to a switch/hub. The LED of this WAN port should be on to indicate a proper connection.
3. Connect an Ethernet cable to one of ETH0 ports on the rear panel. Connect the other end of the Ethernet cable to a switch/hub, pc or AP. The LED of ETH0 should be on to indicate a proper connection.

www.azaleanet.com

FCC Statement:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communication. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution:

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

IMPORTANT NOTICE:**FCC Radiation Exposure Statement:**

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

The availability of some specific channels and/or operational frequency bands are country dependent and are firmware programmed at the factory to match the intended destination. The firmware setting is not accessible by the end user.