PhotoViewer with Outlook Sync

USER MANUAL DPF-1102R

PLEASE READ THIS OPERATING MANUAL COMPLETELY BEFORE OPERATING THIS UNIT AND RETAIN THIS BOOKLET FOR FUTURE REFERENCE.

Read this user guide carefully to ensure proper use of the product and to avoid any danger or physical damage.

- Do not use the viewer in extremely hot, cold, dusty and moist environment.
- Do not drop the viewer, this could cause external damage or damage to internal components.
- Do not repair the viewer by yourself, or it will cause damage.
- Do avoid getting the viewer wet or drop it in water.
- We don't suggest you to use the viewer when driving or doing other things that you must fully concentrate in. it may cause distraction.
- To avoid static electricity, do not operate the viewer in extremely dry environment.
- Always use the accessories provided by or approved by our company, also do not spray water on the player.
- Please follow the right way to upload/download data, we won't be responsible for the lost of data due to wrong operation.

This device complies with part 15 of the

FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Shield cables must be used with this unit to ensure compliance with the Class FCC limits.

1

KEY NAME FUNCTIONS OF KEYS

UP Item switch - Value increase while inputting
DOWN Item switch - Value decrease while inputting
LEFT Item switch - Cursor move left while inputting
RIGHT Item switch - Cursor move right while inputting

MENU Outlook, Shopping List, Calendar, Gallery

ON/OFF Press and hold to turn off,

Press and hold to turn on.

CONFIRM Press to confirm the enter,

Press and hold to enter settings,

CANCEL Press to cancel

POWER UP/AUTO POWER OFF

· If no key has been pressed for a few minutes (refer to Automatic power off setting), the unit will automatically enter the off mode. Press and hold [On/Off] to turn on the unit again.

MAIN MENU

- · Press and hold [Menu] key to leave any modes and go to main menu screen.
- · Use [Left]/ [Right]/ [Up]/ [Down] to select function icons.
- · Press [Confirm] to enter that mode.

OUTLOOK - CONTACT:

- · Press [Confirm] to view the detail of selected person.
- · Press [Cancel] to exit.
- · Press and hold MENU to go to main menu.

OUTLOOK - TASKS:

- · Press [Up]/[Down] to scroll all items.
- · Press [Confirm] to enter and read details.
- · Only data read out. Not data edit/create function.
- Press [Up]/[Down] to scroll text.
- · Press [Left]/[Right] to change previous/next task.
- · Press [Cancel] to exit.

OUTLOOK - NOTES:

- · Press [Up]/[Down] to scroll all items.
- · Press [Confirm] to enter and read details.
- · Press [Up]/[Down] to scroll text.
- · Press [Left]/[Right] to change previous/next notes.
- Press [Cancel] to exit.

SHOPPING LIST:

- · Press [Up]/[Down] to scroll all items.
- Press [Confirm] to enter and read details.

While in reading details,

- · Press [Up]/[Down] to scroll text.
- Press [Left]/[Right] to change previous/next shopping list.
- · Press [Cancel] to exit.

CALENDAR - CALENDAR:

- · Press [Left]/[Right]/ [Up]/[Down] to scroll day.
- · Press and hold [Up]/[Down] to scroll month.
- Press [Confirm] to enter and read details events of that day.

While in reading details,

- · Press [Up]/[Down] to scroll text.
- · Press [Left]/[Right] to change previous/next day.
- · Press [Cancel] to exit.

CALENDAR - TIME:

· Time, date and week will be shown on clock mode

SETTING DATE & TIME

- · In Time mode, Press and hold the [Confirm] key for 2 seconds to edit.
- · Press [Up]/[Down] key to select year (2000~2099)
- · Press [Confirm] key to confirm year. Then start set month
- Press [Up]/[Down] key to select Month.
- · Press [Confirm] key to confirm month. Then start set day
- · Press [Up]/[Down] key to select day.
- Press [Confirm] key to confirm day. Then start set hour
- · Press [Up]/[Down] key to select hour.
- Press [Confirm] key to confirm hour. Then start set minute
- Press [Up]/[Down] key to select minute.
- Press [Confirm] key to confirm minute. Then go back to clock mode.

CALENDAR - ALARM:

- · Press [Up] key to turn on Alarm.
- · Icon will be shown on the top right corner to represent the Alarm function is turned on.
- · Press [Down] key to turn off Alarm icon will be turned off.

SETTING ALARM

- · Press and hold [Confirm] key for 2 seconds to edit the alarm time.
- · Hour digits will flash.
- · Press [Up]/[Down] key to select hour.
- Press [Confirm] key to confirm hour. Then start set minute
- · Minute digits will flash.
- · Press [Up]/[Down] key to select minute.
- · Press [Confirm] key to confirm and back to Alarm mode.
- · Icon will be shown on the top right corner to represent the Alarm function is turned on.

ALARM TONE

- · When Alarm in enabled and alarm time reach, Alarm tone will come out for 1 minute. (Beep...Beep...Beep...)
 - Press any key to stop the alarm tone.

GALLERY:

- If auto scroll is selected, then each photo will display for 10 seconds and then change to another photo.
- · If manual scroll is selected, press [Up]/[Down] to view another photo.

SETUP:

- · On Main Menu screen, press and hold [Menu] to enter setup mode.
- Photo Frame
 - · Select Auto or Manual Scroll

Auto Sleep

- Turn on or turn off Auto Sleep function, select auto sleep time for 30 second, 1 minute, 3 minute and 5 minute.
- · Turn off auto sleep is not recommended because batteries will dry out after a few hours of continuous operation.

Transition

Enable or disable transition effect in Gallery.

Date Format

- · Select DD/MM or MM/DD date format.
- Time Format
 - · Select 12-Hour or 24-Hour Time format.

Calendar

- · Select SMTWTFS or MTWTFSS Calendar
- Kev Tone
 - · Turn on or off key tone.
- Language
 - · Select prompt message among 5 languages.

USB mode

- · Turn on the device.
- · Connect the device to PC with the USB cable provided.
- Once the USB cable is plugged, it will enter USB mode and show the below screen.



- · Press [Up]/[Down] key to select USB Charge or USB Update.
- · Press [Confirm] key to confirm.

USB Charge


- · This unit uses built-in rechargeable lithium battery.
- · Select USB Charge to charge up the rechargeable battery.



- · The battery animation on the screen shows that the unit is being charged.
- The unit can be operated while it is being charged.
- · Please charge in the following conditions:
 - A. The low battery icon is display on the screen.
 - B. Press and hold [On/Off] key does not turn on the unit.

USB Download

· If USB Download is selected, the unit will show the following.



- · Windows will detect a removable disk.
- · Open the PC software to add / delete the photos in the memory.
- · If no photo is store in the memory, the right panel will be blank.


WARNING:
DON'T DIRECTLY READ/WRITE TO THE USB DEVICE USING OTHER
PROGRAM. ONLY USE THE PC PROGRAM PROVIDED TO DOWNLOAD
PICTURE TO THE PHOTO FRAME.
DON'T FORMAT THE USB DRIVE; OTHERWISE THE UNIT WILL BE DAMAGE!!!

Installation


- 1. Insert the CD to the CD drive. Installation software will start automatically.
- 2. If your CD does not have autorun, go to the setup directory and double click "PhotoViewer Setup.exe" to start.
- 3. The setup program will guide you through the installation procedure.
- 4. Shortcut will be created on Desktop and Start Menu.

Uninstall

1. You can uninstall the program by clicking on the "Uninstall Photo Viewer" shortcut.




- PhotoViewer will automatically upload all images from the device and display it on the right panel.
- Browser any picture in JPG or BMP format and click it to add it to the right panel.




Click "Synchronize" to start download.



· Click the "MS Outlook" tab.




· Click "Refresh" to update data from MS Outlook.



- · Name, Home Tel, Mobile, Office Fax, e-mail, Company and Job Title will be imported from Outlook Contact.
- · Due Date, Start Date and Subject will be imported from Outlook Task.
- · Date and Subject will be imported from Outlook Calendar.
- · Date and Subject will be imported from Outlook Note.
- · Click "Copy To Device" to transfer all data to the right panel.

Click "Sync" to download all data to the device.



- · Only Shipping List record can be created in the program.
- · Contact, Tasks, Calendar and Notes record should be edited by Outlook.
- · Click "Safely remove USB Mass Storage Device" on Windows Task Bar.
- Disconnect the USB cable.
- · All downloaded data can be viewed on the device.

Compatible Operation System Windows Vista/XP/2000

Picture Format JPG, BMP

USB Interface USB2.0 (Full speed), Mini 4-pin USB

Internal Memory Size 2MB

LCD Display 128x128 graphic LCD Battery 3.7V Li-ion battery

Operating Temperature 5 °C - 35 °C (41 F - 95 F)

Operating Moisture 10%-75%