


TP2 Tire !

2 Warning mode

Alerts and Warnings	Threshold and conditions	
Low pressure Alert	Lower than 18 PSI or sudden pressure drop	
Low pressure warning	When tire pressure falls below 20% or 25% of recommended tire pressure. The percentage can be preset in MENU2 .	
High pressure Alert	Tire pressure is higher than 49 PSI (2 bar)	
High temperature Alert	When the tire temperature is higher than 80 ℃ (176 °F)	
Battery low warning	attery low warning The battery of tire sensor is discharged	
Broken sensor warning	warning No transmission from the sensor	

Under alert and warning mode, the red alarm backlight warning and alert icons and the audible alarm turn on and off continuously. Also, the warning and alert icons and tire location and the elapsed time information are displayed in sequence. The icons and displays are as bellows;



Press any button to acknowledge and stop the flashing and alarm.

Press any button once to stop the audible alarm and press any button again to revert to a normal run mode. But the alert icons and alarm red backlight on LCD screen remains on and the display reverts to a normal run mode.





Reverted display from low pressure warning

Reverted display from broken sensor warning

* NOTE: Under low pressure alert mode, the visible and audible alarms remain after pressing twice but display of run mode is added in sequence of alert display.




When the alert occurs, reduce speed and proceed to a safe location to check tires. The warnings and alerts is cancelled when the tire are properly re-inflated to correct level.

* NOTE: The elapsed time of warning can provide a guide of limited mileage for RUN-Flat tire and PAX tire after puncture.






Program mode



Press the **PRG**\ button over 2 seconds to move to program mode.

Press the PRG button over 2 seconds to revert to RUN mode or select MENU9 EXIT using **PRG** button.



* NOTE: How to use function keys;

- 1) PRG button: enter key
- 2) /SET/ button: secondary selection key: use in MENU1 tire pressure to select the axle and MENU4 tire rotation to select tire position and MENU8 unit to shift.
- 3) button: shift and scroll

MENU1. Recommended tire pressure in clod

Programming steps

PRG

1. To enter, press PRG button

2. Input the recommended pressure using \land / \lor button for front axle.

PRG

3. Press PRG button to return.

SET/

- 4. The front axle pressure is copied to real axle automatically but press SET button to input the real tires pressure differently, if required.
- * Caution: Locate the recommended tire pressure on the vehicle's tire information placard, certification label, or in the owner's manual.
- * Caution: The cold pressure is the air pressure inside the tire inflated at the ambient temperature before driving a vehicle.



MENU2. Alert setting

Set the low pressure warning threshold.



Programming steps

PRG

1. To enter, press PRG button



- 2. Select under-pressure value 20% or 25% using \(\tau\) button
 - 3. Press PRG button to save the threshold value
 - 4. The monitor displays the threshold of low pressure warning shortly and return to menu
- * NOTE: 20% warning threshold: recommended by tire manufacturers 25% warning threshold: recommended by NHTSA in USA

The example: calculation of threshold

Recommended tire pressure = 30 PSI, Under-pressure value = 20 %

 $30 - (30 \times 20/100) = 24 \text{ PSI}.$



MENU3. LIGHT ON TIME

The monitor has an energy saving feature that turns light on/off to selected time only and it turns light on automatically when required to display alert or program the unit



Programming steps

PRG

1. To enter, press PRG button



 \nearrow / \nearrow 2. Select the light on time using \land / \lor button


PRG

3. Press PRG button to return.

* NOTE : Factory default = 10 sec.

MENU4. TIRE ROTATION

Used for tire rotation and replacement of located tire to spare tire



Programming steps



- 1. To enter, press PRG button
- 2. Without spare tire sensor, it goes to Rotation mode first
- 3. When a spare tire sensor is registered, you should select rotation or replacement first.




- 4. Select Spare or Rotation cursor using \land/\lor button.
 - 5. See the **MENU4.1** Rotation for tire rotation
 - 6. See the MENU4.2 Spare for replacement of located tire to spare tire

* The icon and tire location with color code.

ICON	Tire Location	NO.	Color code
1R	LEFT FRONT	1	RED
2Y	RIGHT FRONT	2	YELLOW
3G	RIGHT REAR	3	GREEN
4B	LEFT REAR	4	BLUE
5W	SPARE TIRE	5	WHITE

MENU4.1. Tire Rotation (without spare tire sensor)



Programming steps

PRG

1. To enter, press PRG button

2. Press \(\tau\) button to scroll through a tire positions

SET/

3. Press SET button to select it for editing ()

4. Locate the editing tire to rotated position using \wedge/\vee button

SET/

5. Press SET button to set it as rotated tire (113)

PRG

6. Press PRG button to enter it

7. Select \(\vec{\mathbf{Y}} \) to save and return to menu or select \(\vec{\mathbf{N}} \) or \(\vec{\mathbf{C}} \) using \(\lambda / \lambda \) button to cancel the editing and press PRG button to enter it

* NOTE: Y.N.C icons


- □ **y** for Yes : save it and return to menu
- □ N for No : do not save it and return to menu
- □ **©** for Cancel: Cancel the editing and program it again.





Easy guide of tire rotation

To rotate Front Right tire to Real Left




- * NOTE : Press PRG button to cancel the editing or select N or C icons
- * NOTE: Error message:

If press the save button before completion of editing, the error message is displayed. Press PRG button or C to return from error



MENU4.2. Replacement of located tire to spare tire



Programming steps

PRG

PRG 8. To enter, select Spare 1 cursor using PRG button

11. Press PRG button to enter it

√ / ✓ 9. Press ∧/∨ button to scroll through a tire position (③⑥)

10. Press SET button to select it for replacement (5W) SET/

12. Select Y to save and return to menu or select \mathbb{N} or \mathbb{C} using \wedge/\vee button to cancel the editing and press PRG button to enter it


* NOTE: Once the 5W spare tire replaced, the punctured tire sensor (3G) becomes spare tire sensor automatically.

* NOTE : To delete the punctured tire sensor (3G), go to MENU6.2 spare tire mode and select OFF 3

* NOTE: When select Rotation; cursor to enter the tire rotation, the programming steps is same as MENU4.1 tire rotation.

MENUS. SENSOR ID

All TP2 sensors have unique identification number and the sensor ID is saved in monitor at the factory.



To see each sensor ID, press **PRG** button.

Press // button to see the ID of spare tire sensor after registration.

* NOTE: The display of sensor ID will provide the correct information for registration and initiation of sensor.






MENU6. SENSOR SETUP

This mode is used to replace the broken sensor and register new sensor.

MENU6.1. INITIATION

This mode is used to replace and register the new sensor.



Programming steps

PRG

1. To enter MENU6.1, press PRG button



2. Press A/V button to scroll through a tire location



- 3. Press SET button to select it for initiation
- 4. Inflate the tire with new sensor to wake up and transmit data
- 5. Wait to receive the transmission of new sensor ID. (waiting mode)
- 6. Confirm the new sensor ID in display



- 7. Select Y to save and return to menu or select N or C using △/✓ button to cancel the editing and press PRG button to enter it
- * NOTE: To stop the programming and return to menu, press PRG button during waiting mode
- * NOTE: To make the transmission of sensor, inflate the tire pressure after mounting new sensor or deflate the tire pressure below 18 PSI.
- * NOTE: Error message;

If press the save icon Y for overwriting or duplication of registered sensor, the error message is displayed. Press PRG button to return from error



MENU6.2. SPARE TIRE

m this mode is used to register or delete the spare tire sensor



Programming steps

PRG

1. To enter MENU6.2. press PRG button



- 2. Press \(\tau\) button to scroll through on/off cursor
 - 3. Select ON cursor to register new tire sensor to spare tire location
 - 4. Inflate the tire with new sensor to wake up and transmit data
 - 5. Wait to receive the transmission of new sensor ID. (waiting mode)
 - 6. Confirm the new sensor ID in display



7. Select 🕅 to save and return to menu or select 🐚 or 뎌 using 🗥 button to cancel the editing and press PRG button to enter it.


* NOTE: the information of cursor

OFF : no spare tire sensor registered, or delete the registered sensor

ON 1 : spare tire sensor registered already or register new spare tire sensor

BACK : return to menu

MENU7. LANGUAGE



Programming steps

PRG

1. To enter MENU7, press PRG button






3. Press PRG button to return.



TPE Tire S

MENU8. UNIT

■ Use this mode to select unit of pressure and temperature.



Programming steps

PRG

1. To enter MENU8, press PRG button



2. Press \land/\lor button to scroll through unit cursor of pressure



3. Press SET button to shift to unit of temperature



4. Press A/V button to scroll through unit cursor of temperature

PRG

5. Press PRG button to save and return to menu.

* NOTE: The pressure unit cursor: PSI, bar, KPA, Kg/cm2

The temperature unit cursor: C°, F°

* unit conversion : 1psi=0.06895 bar= 6.895 kPa = 0.0703kgf/cm²

* unit conversion : °C=1.8 × (°F-32)

MENU9. EXIT

■ Use this mode to go to run mode

MENU10. FACTORY

This mode is for factory use only.

Trouble shooting

Symptom	Solution
No display on LCD	Check the power connection. Plug in the power adaptor tightly to confirm the contact. Check the fuse in a flexible power adaptor.
Display is not clear	You cannot see the display clearly exposed to the sun. Place the monitor in location not exposed to the sun and check it. When it is too hot or cold over operating temperature range of monitor, the graphic display is not clear. Turn on air-condition or heater on vehicle.
No tire pressure is displayed.	The tire sensor will transmit the data from acceleration over 10km continuously.
The vehicle icon does not move	Press SET button for 2 seconds. You can hear a beep to indicate the vehicle icon will move. To stop the moving vehicle icon, press SET button again.





Additional information



MIC registered NO TP2-RV1

Trademarks

TP2 is a trademark of SEETRON Inc.

US patent NO. 6,945,103 Korean patent NO. 0497112

Quick location tips of tire sensor

Four tire sensors (red, yellow, green, and blue) have preset location and mount the tire sensor according to color.

Remember the color location that follows the color sequence of rainbow in clockwise.

NOTE: The spare tire sensor has white code.

