
# **Horizontal Adjustability**

IC5220 (ONLY):

8



- a. If you need to make horizontal adjustments, begin by slowly turning the horizontal adjustment screws on the faceplate.

  Do not remove the screws or rotate them more than 3 full turns
- b. Adjust the unit in the frame.
- c. To finish, securely tighten the screws, this allows the K-nut's teeth to dig into the unit's housing to prevent slippage during use.

### Warning: Changes or modification to this device not expressly approved by HES, Inc., could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a class [B] digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This class [B] digital apparatus meets all requirements of the Canadian Interference Causing Equipment Regulations. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Cet appareillage numérique de la classe [B] répond à toutes les exigences de l'inerférencé canadienne causant des réglements d'équipement. L'opération est sujette aux deux conditions suivantes: (1) ce dispositif peut ne pas causer l'interférence nocive, et (2) ce dispositif doit accepter n'importe quelle interférence reçue, y compris l'interférence qui peut causer l'opération peu désirée.

3065006.001 rev A1 © 2010 HES, Inc.



hes

# Installation Instructions IC5020 and IC5220

IC5020 and IC5220: EXTERNAL ANTENNA

HES, Inc. 22630 N. 17th Ave. Phoenix, AZ 85027 800-626-7590

**Product** Electric Strike and Proximity Card Reader with Description Antenna Module Mounted Separately in Frame Dimensions See pages 4-6 Orientation Non-handed Compatibility Open Architecture Access Control Systems Interfaces with Wiegand Protocol Systems Supports HID 26, 32, 34, 37, 40 & 56 Bit Formats Proximity Cards Supports HID 13.56 MHz Credentials Frequency Indicators Red/Green LED and Buzzer Supervision Door Position Switch and Latchbolt Monitor Applications Steel, Aluminum Frames Trim Enhancer Included \_Locks Cylindrical Latchbolts Released\* IC5020: Accomodates up to 5/8" Latchbolt IC5220: Accomodates up to 3/4" Latchbolt \_\_Environment Suitable for Exterior Doors 32°F-150°F(0°C-65°C) Temperature Humidity 5-95%, Non-condensing Electrica Reader Module Operating Voltage 12VDC +/- 20% Operating Current 125 mA Max, @ 12VDC **Electric Strike Module Operating Voltage** 12-24VDC +/- 10% Operating Current 240 mA max. @ 12VDC 120mA max. @ 24VDC Cable detail Reader Module 500 ft. Max. Distance to Host 18–22 AWG (Dependent on Distance) Stranded and Shielded Recommended Type Electric Strike Module Distance to Power See Page 3 Recommended Type See Page 3 Certifications FCC Part 15/IC Class B Compliance ANSI/BHMA 156.31 Grade 1 Security \*Faceplate options accommodate various keeper and latchbolt Warrantv actions. For more detail, contact HES tech support Lifetime Waranty against defects in materials and workmanship

# **Product Components**


IC5020 and IC5220: EXTERNAL ANTENNA

- 1 Hybrid Electric Strike
- (2) Reader/Antenna Body
- (3) #6-32 Reader/Antenna Screws
- 4 Reader/Antenna Mounting Plate
- 5 24" Cable (connecting reader/antenna and strike)
- 6 Door Position Switch, Press-Fit Magnet and 10" Connector Cable (2 pin)
- 7 Pigtail Connectors 2 pin-DPS & LBM 4 pin-12V Strike Power

- 8 Faceplate (sold seperately)
- 9 #12-24 Mounting Screws (included with faceplate)

2

- (included with faceplate)
- 11) Prox & Data Connector (connects to strike)
- 12 Prox & Data Pigtail
- (13) Dielectric Grease (for humid applications)
- 14 Trim Enhancer
- <sup>15</sup> Trim Enhancer Screws



#### Wiring Diagram

Red	(+) Board Power
Black	(–) Board Power
Green	Data 0
White	Data 1
Yellow	LED/Buzzer
Blue	Not Used
Orange	Not Used
Brown	Not Used

2	2 pin Connector (Strike Module)				
	Tan Pink	Common  Door Closed and Latch Engaged			

2 Pin Connector (Door Position Switch)	
Wire plugs into Hybrid Electric Strike	

4 Pin Connect	4 Pin Connector (12V Strike Power)			
Red (+) Black (-)	Strike Power Strike Power	_		
4 Pin Connect	or (24V Strike Power)			
Violet (+) Black (-)	Strike Power Strike Power			

### **Fail Safe Conversion**

IC5020 and IC5220: EXTERNAL ANTENNA

© Fail Safe

### Remove Reader Module

a. In order to change the mode of operation from fail secure (standard) to fail safe, first detach the reader module by removing the two screws on the back of the hybrid electric strike.

### Convert Mode

b. Loosen the two #2-56 screws located on the back of the strike module, as shown above, but do not remove them.

- c. Move screws from the top of the hole to fail safe position.
- d. Tighten screws.

Finish

e. Replace the reader module and tighten the two screws to hold it in place.


7 |

## **Cutout Template**

IC5020 and IC5220: EXTERNAL ANTENNA

### IC5020 or IC5220 with 504 Faceplate

1-3/8" x 10" Radius Corner Faceplate Aluminum Jamb Installations



### **Installation Directions**

IC5020 and IC5220: EXTERNAL ANTENNA

CAUTION! Before connecting any device at the installation site, verify input voltage using a multimeter. Many power supplies and low voltage transformers operate at higher levels than listed. Any input voltage outside the electrical specifications outlined on page 1 may cause severe damage to the unit and will void the warranty. This product contains electrostatic sensitive components. We recommend proper grounding techniques be observed during installation.

#### **Prepare Frame**

6

- 1. Prepare door jamb for hybrid electric strike per the appropriate template detail (see pages 4-6). Be sure to allow enough room behind the strike in the cutout to avoid pinching any wires.
- 2. Drill a 1" diameter hole for reader/antenna per the appropriate template detail (see pages 4-6). Note that the reader/antenna may be positioned as desired, within limits of the 24"cable. If necessary, drill a channel from the reader/antenna to the hybrid electric strike to accomodate the 24" cable.
- 3. Drill a 3/8" hole for the door position switch per the appropriate template detail (see pages 4-6). Note that the door position switch may be positioned as desired, within limits of its 10" connector. If necessary, drill a channel from the door position switch to hybrid electric strike to accomodate the 10" cable. Next, drill a matching 3/8" hole in the door and install the press-fit magnet so that it will contact with the door position switch.
- 4. If applicable (e.g. aluminum frames), install mounting tabs (sold separately as P/N 152) using #10-32 screws.
- 5. Verify that the strike is in the correct mode of operation. This unit ships in fail secure mode. If you need to convert to fail safe, see page 7.

### **Connect Components and Wiring**

- 6. Check that the wires running from the host control panel are adequate wire gauge for the components and distance (see Wire Gauge Diagram below). Connect the wire leads of the three pigtails provided to the host control panel wiring based on the wiring diagram on page 2 and the appropriate termination at the host control panel.
- 7. Mount the door position switch (DPS) into the frame. Route the 10" cable back to the electric strike and connect it to the 2 pin connector coming out of the hybrid electric strike. It does not matter which 2 pin connector is used. Note: the LBM & DPS are wired in series--a 'closed' electrical circuit depicts a closed door and extended latchbolt into the hybrid electric strike.
- 8. Attach the 8, 4 and 2 pin connectors at the hybrid electric strike to the equivalent pigtail connectors routed from the host control panel. Apply grease to the pigtail electrical terminals if used in a humid environment
- 9. Secure the Reader/Antenna Mounting Plate to the frame using the #6-32 screws provided. Connect the 24" cable to the Reader/Antenna, snap the Reader/Antenna to the Reader/Antenna Mounting Plate and pull the 24" cable through to the hybrid electric strike.
- 10. Plug the loose end of the 24" cable into the connector on the side of the hybrid electric strike.

### Finish Installing

- 11. Attach the faceplate to the hybrid electric strike, using the #8-32 screws provided.
- 12. Install the trim enhancer on the hybrid electric strike (if needed to cover any extra space).
- 13. Install the hybrid electric strike unit in jamb cutout, using #12-24 screws provided.
- 14. If needed, see page 8 to make horizontal adjustments in frame (IC5220 only).
- 15. If applicable, tighten the #10-32 screws holding the mounting tabs.

### **Testing and Operation**


- 16. When power is supplied to the hybrid electric strike, the LED will flash green three times, while the beeper simultaneously beeps. The LED will then turn red. This sequence indicates that the micro-controller is operating properly.
- 17. Present a Proximity ID card to the reader/antenna. The LED will turn green, while the beeper beeps once. This indicates that the card was read successfully.
- 18. Simultaneously, the keeper will click open. This indicates that communication between the host and the hybrid electric strike is operational.
- 19. For further testing of communication with the host, consult the manual for the control panel or the site's system administrator.

#### Wire Gauge Diagram

12VDC @ 240 mA					
Max. One-way Distance	Voltage Drop/100'	Recommended AWG			
800'	0.15	12 Gauge			
500′	0.24	14 Gauge			
300′	0.38	16 Gauge			
200'	0.61	18 Gauge			
120'	0.97	20 Gauge			
100' or less	1.53	22 Gauge			


### IC5020 or IC5220 with 501 Faceplate

1-1/4" x 4-7/8" Square Corner Faceplate
ANSI Metal Jamb Installations




### IC5020 or IC5220 with 501-A Faceplate

1-1/4" x 4-7/8" Radius Corner Faceplate
Aluminum Jamb Installations



### IC5020 or IC5220 with 502 Faceplate

1-7/16" x 7-15/16" Radius Corner Faceplate
Aluminum Jamb Installations



### IC5010 or IC5220 with 503 Faceplate

1-1/4" x 6-7/8" Radius Corner Faceplate Aluminum Jamb Installations

