USER'S GUIDE

This page is intentionally left blank



User Manual

FX803C

Dual band wireless local loop phone

WELCOME

Congratulations on the purchase of your Motorola < Model > product!

Please retain your original dated sales receipt for your records.

For warranty service of your Motorola *<Model>* product, you will need to provide a

copy of your dated sales receipt to confirm warranty status.

Thank you for choosing a Motorola product.

Please read important safety instructions before use.

Read and understand all instructions before use.

Please retain this guide for future reference

Index

1	GENERAL INFORMATION8
	1.1 Technical Information
	1.2 Safety Information9
	1.3 Warranty14
	1.4 Regulatory
	1.5 FCC Notice To Users
2	KNOW YOUR PHONE20
	2.1 Unpack
	2.2 Technical Parameters
	2.3 Keypad
	2.4 LCD Screen Description24
	2.5 Battery
	2.5.1 Remove and Installation of Battery24
	2.5.2 Charge the Battery25
	2.6 Connect to the Network
	2.6.1 Power on/off Phone27
	2.6.2 Connect the Network27
3	BASIC OPERATIONS28
	3.1 Make a Call
	3.2 Answer a Call 30

	3.2.1 Answer Automaticlly30
	3.2.2 Set Any Key Answer31
	3.2.3 Incoming Call Silence31
	3.3 During a Call
	3.4 Leash Function
	3.5 Menu Functions
4	NAME
	4.1 View Records
	4.2 Find Records
	4.3 Add New Entry
	4.4 Edit Contacts
	4.5 Delete a Records
	4.6 Delete All Records
	4.7 Edit Group
	4.8 Set Speed Dial
	4.9 View and Make Speed Dial37
	4.10 Capacity
5	MESSAGES38
	5.1 Send a New Message
	5.2 Receive Incoming Call while Editing Message39
	5.3 Read Message
	5.4 View OutBox40
	5.5 Erase Messages

	5.6 Read and Set Voice Mail40
	5.6.1 Read Voice Mail40
	5.6.2 Set Voice Mail Number41
	5.7 Message Settings41
	5.7.1 Auto Save41
	5.7.2 Auto Delete41
	5.7.3 Set Proformatted message41
	5.7.4 Messages Alert42
	5.7.5 Delivery Acknowledge42
	5.7.6 Msg Priority42
	5.7.7 Memory Status42
6	CALL HISTORY43
	6.1 View Recent Calls
	6.2 Erase Recent Calls List
	6.3 Call Timers
7	SETTINGS44
	7.1 Sound45
	7.1.1 Volume45
	7.1.2 Ring45
	7.1.3 Alert Type46
	7.1.4 Key Beep46
	7.2 Display46
	7.2.1 Wall Paper Set46

	7.2.2 Set Backlighting	47
	7.2.3 Set Brightness	47
	7.2.4 Set Contrast	47
	7.2.5 Set Language	47
	7.2.6 Set Time Format	48
	7.2.7 Change Banner	48
	7.3 Call Setting	48
	7.3.1 Answer Automatically	48
	7.3.2 Set Any Key Answer	48
	7.3.3 Voice Privacy	49
	7.3.4 Alert	49
	7.3.5. Supp. Services	49
	7.4 Security Settings	50
	7.4.1 Setting Phone Lock	51
	7.4.2 Restore setting	51
	7.5 Extras	51
8	TOOLKIT	52
	8.1 Calendar	52
	8.2 Alarm Clock	53
	8.3Calculator	53
	8.4 Voice Memo	54
	8.5 Games	55
	8.5.1 Brick attack	55
	8.5.2 Push Box	55

	8.6 Stopwatch	55
9	TEXT INPUT	.55
	9.1 Multitap Input	56
	9.2 Numbers Input	57
	9.3 eZiText Input	57
	9.4 Symbols Input	57
1	TROUBLESHOOTING	.57

1 GENERAL INFORMATION

1.1 Technical Information

Specific Absorption Rate Data

This model meets international guidelines for exposure to radio waves.

Your mobile device is a radio transmitter and receiver. It is designed not to exceed the limits for exposure to radio waves recommended by international guidelines. These guidelines were developed by the independent scientific organization ICNIRP and include safety margins designed to assure the protection of all persons, regardless of age and health.

The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device types FX803C (FCC ID: VH4FX803C) has also been tested against this SAR limit. The highest SAR value reported under this standard during product certification for use at the ear is 0.882 W/kg and when properly worn on the body is 0.605 W/kg. This device was tested for typical body-worn operations with the back of the handset kept 1.5cm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain a 1.5cm separation distance between the user's body and the back of the handset. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.

As SAR is measured utilizing the device's highest transmitting power, the actual SAR of this device while operating is typically below that indicated above. This is

due to automatic changes to the power level of the device to ensure it only uses the minimum level required to reach the network.

While there may be differences between the SAR levels of various phones and at various positions, they all meet the governmental requirements for safe exposure. Please note that improvements to this product model could cause differences in the SAR value for later products; in all cases, products are designed to be within the guidelines.

The World Health Organization has stated that present scientific information does not indicate the need for any special precautions for the use of mobile devices. They note that if you want to reduce your exposure then you can do so by limiting the length of calls or using a "hands-free" device to keep the mobile phone away from the head and body. Additional Information can be found on the websites of the World Health Organization (http://www.who.int/emf) or Motorola, Inc. (http://www.motorola.com/rfhealth).

* The tests are carried out in accordance with international guidelines for testing. The limit incorporates a substantial margin for safety to give additional protection for the public and to account for any variations in measurements. Additional related information includes the Motorola testing protocol, assessment procedure, and measurement uncertainty range for this product.

1.2 Safety Information

Safety Information For Fixed Phones

Important information on safe and efficient operation.

Read this information before using your phone.

- Exposure to Radio Frequency (RF) Energy. Your phone contains a transmitter and a receiver. When it is ON, it receives and also sends out radio frequency (RF) signals. When you communicate with your phone, the system handling your call controls the power level at which your phone transmits.
 - Your Motorola phone is designed to comply with local regulatory requirements in your country concerning exposure of human beings to RF energy.
- Potentially Explosive Atmospheres. Areas with potentially explosive atmospheres are often but not always posted and can include fueling areas such as below decks on boats, fuel or chemical transfer or storage facilities, or areas where the air contains chemicals or particles, such as grain dust, or metal powders. When you are in such an area, turn off your wireless device, and do not remove, install, or change batteries. In such areas, sparks can occur and cause an explosion or fire.
- Operational Precautions. To assure optimal phone performance and make sure human exposure to RF energy is within the guidelines set forth in the relevant standards; always adhere to the following procedures.
 - External Antenna Care. Use only the supplied Motorola approved antenna. Unauthorized antennas, modifications, or attachments could damage the phone. Do NOT hold the antenna when the phone is IN USE. Holding the antenna affects call quality and may cause the phone to operate at a higher power level than needed. In addition, use of unauthorized antennas may result in non-compliance with the local regulatory requirements in your country.

- Phone Operation. When placing or receiving a phone call, hold your phone as you would a wireless telephone. To maintain compliance with RF energy exposure guidelines, ensure the phone antenna is at least 8 inches (20 centimeters) from your body when transmitting.
- Approved Accessories. Use of accessories not approved by Motorola, including but not limited to batteries and antennas, may cause your phone to exceed RF energy exposure guidelines.
- RF Energy Interference / Compatibilities. Nearly every electronic device is susceptible to RF energy interference from external sources if inadequately shielded, designed, or otherwise configured for RF energy compatibility. In some circumstances your phone may cause interference.

Medical Devices

Pacemakers

Pacemaker manufacturers recommend that a minimum separation of 8 inches (20centimeters) be maintained between the fixed wireless phone and a pacemaker. Persons with pacemakers should:

- Always keep the phone more than 8 inches (20 centimeters) from your pacemaker when the phone is turned ON.
- 2) Turn OFF the phone immediately if you have any reason to suspect that interference is taking place.

Hearing Aids

Some digital wireless phones may interfere with some hearing aids. In the

event of such interference, you may want to consult your hearing aid manufacturer to discuss alternatives.

Other Medical Devices

If you use any other personal medical device, consult the manufacturer of your device to determine if it is adequately shielded from RF energy. Your physician may be able to assist you in obtaining this information.

 Batteries. Batteries can cause property damage and / or bodily injury such as burns if a conductive material such as jewelry, keys, or beaded chains touches exposed terminals. The conductive material may complete an electrical circuit (short circuit) and become quite hot. Exercise care in handling any charged battery, particularly when placing it inside a pocket, purse or other container with metal objects. Use only original batteries and chargers.

Your battery or phone may contain symbols, defined as follows.

\triangle	Important safety information will follow
8	Your battery or phone should not be disposed of in a fire
0	Your battery or phone may require recycling in accordance with local laws. Contact your local regulatory authorities for more information.



Your battery or phone should not be thrown in the trash

- Please don't use any damaged battery or charger and use the battery only for its intended purpose.
- Don't apply extreme shock to the battery. It's dangerous to disassemble a
 battery or to apply extreme shock to the battery via nail or heavy metal objects.
- Keep the charger or batteries out of reach of small children or babies. Please instruct children the proper ways of handling phone during usage.
- Shock circuit and breakdown may occur and cause severe danger to user due to improper usage.
- Always try to keep the battery between -10° ~ 55° Celsius.
- Use only manufacturer approved rechargeable batteries and charger designated for this device.

AC/DC Adapter

AC/DC Adapter for this phone has met applicable UL safety requirements. Please adhere to the following safety instructions per UL guidelines.

This power unit is intended to be correctly orientated in a vertical or horizontal or floor mount position,

Important Safety Instructions – Save these instructions

Danger – To reduce the risk of fire or electric shock, carefully follow these instructions

For connection to a supply not in the U.S.A., use an attachment plug adapter

of the proper configuration for the power outlet.

or blackouts. Some people may be susceptible to epileptic seizures or blackouts when exposed to flashing lights, such as when watching television or playing video games. These seizures or blackouts may occur even if a person never had a previous seizure or blackout. If you experienced seizures or blackouts, or if you have a family history of such occurrences, please consult with your doctor.

1.3 Warranty

Limited Warranty for Personal Communication Products, Accessories and Software.

What Does this Warranty Cover? Subject to the exclusions contained below,

BRIGHTSTAR warrants the Motorola branded FX-803C that it manufactures ("Products"), to be free from defects in materials and workmanship under normal consumer usage for the period(s) outlined below. This limited warranty is a consumer's exclusive remedy, and applies as follows to new Motorola branded Products manufactured by BRIGHTSTAR, and purchased by consumers around the world, which are accompanied by this written warranty:

Products Covered

Products as defined above.

- The Fixed Wireless Telephone.
- 2) The accessories included with the Fixed Wireless Telephone.

Length of Coverage

One (1) year from the date of purchase by the original consumer/purchaser of the product.

Exclusions

1) **Batteries.** Only batteries whose fully charged capacity falls below 80%

of their rated capacity and batteries that leak are covered by this limited

warranty.

Abuse & Misuse. Defects or damage that results from: (a) improper

operation, storage, misuse or abuse, accident or neglect, such as

physical damage (cracks, scratches, etc.) to the surface of the product

resulting from misuse; (b) contact with liquid, water, rain, extreme

humidity or heavy perspiration, sand, dirt or the like, extreme heat, or

food; (c) use of the Product for commercial purposes or subjecting the

Product to abnormal usage or conditions; or (d) other acts which are not

the fault of BRIGHTSTAR, are excluded from coverage.

Use of Non-Motorola branded Products and Accessories. Defects or

damage that results from the use of non-Motorola branded or certified

Products, Accessories, Software or other peripheral equipment are

excluded from coverage.

4) Unauthorized Service or Modification. Defects or damages resulting

from service, testing, adjustment, installation, maintenance, alteration,

or modification in any way by someone other than BRIGHTSTAR or its

14

15

authorized service centers are excluded from coverage.

- Altered Products. Products or Accessories with (a) serial numbers or date tags that have been removed altered or obliterated; (b) brOKen seals or those that show evidence of tampering; (c) mismatched board serial numbers; or (d) nonconforming or non-Motorola branded housings, or parts, are excluded from coverage.
- 6) Communication Services. Defects, damages, or the failure of products, due to any communication service or signal you may subscribe to or use with the Products is excluded from coverage.

Who is covered?

This warranty extends only to the first consumer/purchaser, and is not transferable.

What will BRIGHTSTAR Do?

BRIGHTSTAR, at its option, will at no charge repair, replace or refund the purchase price of any Product that does not conform to this warranty. We may use functionally equivalent reconditioned / refurbished / pre-owned or new Products, Accessories or parts. No data, software or applications added to your Product, Accessory or Software, including but not limited to personal contacts, games and ringer tones, will be reinstalled. To avoid losing such data, software and applications please create a back up prior to requesting service.

For information on how to obtain service, contact the place where the product was purchased or a BRIGHTSTAR Service Center in your country.

In order for this Warranty to take effect, take your unit, along with this policy, to the place of purchase or to a BRIGHTSTAR Authorized Service Center.

You will receive instructions on how to ship the Products, at your expense, to a BRIGHTSTAR Authorized Repair Center. To obtain service, you must include: (a) a copy of your receipt, bill of sale or other comparable proof of purchase; (b) a written description of the problem; (c) the name of your service provider, if applicable; (d) the name and location of the installation facility (if applicable) and, most importantly; (e) your address and telephone number.

What Other Limitations Are There?

ANY IMPLIED WARRANTIES, INCLUDING WITHOUT LIMITATION THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED TO THE DURATION OF THIS LIMITED WARRANTY, OTHERWISE THE REPAIR, REPLACEMENT, OR REFUND AS PROVIDED UNDER THIS EXPRESS LIMITED WARRANTY IS THE EXCLUSIVE REMEDY OF THE CONSUMER, AND IS PROVIDED IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED. IN NO EVENT SHALL BRIGHTSTAR BE LIABLE, WHETHER IN CONTRACT OR TORT (INCLUDING NEGLIGENCE) FOR DAMAGES IN EXCESS OF THE PURCHASE PRICE OF THE PRODUCT, OR FOR ANY INDIRECT, INCIDENTAL, SPECIAL OR

CONSEQUENTIAL DAMAGES OF ANY KIND, OR LOSS OF REVENUE OR PROFITS, LOSS OF BUSINESS, LOSS OF INFORMATION OR DATA OR OTHER FINANCIAL LOSS ARISING OUT OF OR IN CONNECTION WITH THE ABILITY OR INABILITY TO USE THE PRODUCTS, TO THE FULL EXTENT THESE DAMAGES MAY BE DISCLAIMED BY LAW.

Some states and jurisdictions do not allow the limitation or exclusion of incidental or consequential damages, or limitation on the length of an implied warranty, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights that vary from state to state or from one jurisdiction to another.

1.4 Regulatory



Brightstar Corp. hereby declares this unit to be in compliance with the relevant Provisions of the Low Voltage Directive 73/23/EEC and the EMC Directive 89 / 336 / EEC.

Brightstar Corp. hereby declares this unit to be in compliance with the essential requirements and other relevant provisions of Directive 1999/519/EC.

1.5 FCC Notice To Users

We have not approved any changes or modifications to this device by the user.

Any changes or modifications could void the user's authority to operate the equipment. See 47 CFR Sec. 15.19(3).

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions

- 1) This device may not cause harmful interference, and
- 2) This device must accept any interference received, including interference that may cause undesired operation. See 47 CFR Sec. 15.19(3).

If your mobile device or accessory has a USB connector, or is otherwise considered a computer peripheral device whereby it can be connected to a computer for purposes of transferring data, then it is considered a Class B device and the following statement applies:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help

2 KNOW YOUR PHONE

2.1 Unpack

Parts	Quantity
Phone set	1
Li-ion Battery	1
External Power Adapter	1
Desk charger	1
User manual	1

2.2 Technical Parameters

Handset	
Туре	FX803C
Dimensions	(Width×Height×Thickness)
	150mm×50mm×23mm
Weight	About 124g(Battery Included)
Battery	
Continuous standby time	About 110h (Subject to Network)

Continuous talk time	More than 2h (Subject to Network)

Other Parameters	
Air Interface Protocol	CDMA 2000 1X
Frequency Range	Uplink
	824-849MHz
	Downlink
	869-894MHz
Power Supply	Input: 100V-240V(AC), 50/60Hz
	Output: Adapter +5V (DC), 0.65A
Voice Coding	4GV,8K EVRC

Note: Refer to the real objects for other relative parameters about the battery and charger.

2.3 Keypad



Key	Description	
Menu/Select	■ Enter main Menu : Select or confirm options in	
key	Menu and left bottom submenu on the display.	
	■ Enter right bottom submenu such as Names	
	on the display.	
Cloor kov	■ Press Clear key to erase character(s) while	
Clear key	editing or dialing.	
	■ Press Clear key to cancel operation and exit	
	to previous pop-up window interface.	

Key	Description
	■ Scrolling key used as selection key
	Up/Down/Left/Right for selecting the
	commands and items shown on screen
Up/Down/Left/	display.
Right key	■ In standby mode, press Up/Down key to enter
(Scrolling key)	Messages /Ring, press Left/Right key to
	enter ToolKit/ Games.
	■ Move the cursor when inputting letters. Scroll
	the cursor in menu option and display.
	■ Make a call or answer an incoming call.
Call key	■ In standby mode, press Call key to enter All
	Recent Calls list.
	■ End an active call or reject calls.
End key	■ Power on/power off.
Liid key	■ Exit from any window interface to standby
	mode.
Speaker/Ok key	■ Hand-free mode(Speaker mode).
	■ Select or confirm options in Menu and left
	bottom submenu on the display.
0~9 Number	■ Use the number keys to enter numbers and
key	characters.
# key, * key	■ Differs in different mode, option or function
	menu.

Note: "Press the key" in manual means pressing certain key once, "Hol d the key" means pressing key for 2 or 3 seconds.

2.4 LCD Screen Description

These icons may appear on screen display of your phone.

Icon	Indication	
Tall	Signal strength	
R	Roaming	
₩	New voice message	
	New message	
×	Silence All	
	Alarm	
-	Power indicator	

2.5 Battery

The attached Li-ion battery along with the phone can be used after unpacking. For the first three times, use up the power and charge it fully for a new battery to perform well.

Power off phone and remove battery if the phone is not in use for a long time.

2.5.1 Remove and Installation of Battery

Remove: (1) Press and push the back-cover of the phone down to release and remove it off the phone. (2) Remove the battery from the battery slot, disconnect the plug.



Installation: (1) Insert the battery into the battery connector, then put the battery down to the battery slot-the side without labels is downward.

(2) Put the back-cover of the phone flatly upon the body of phone. Direct the back cover towards the locking catches on the both sides of the phone and push the back-cover of the phone upward to lock the cover into its place.



2.5.2 Charge the Battery

♦ Connect the lead of the charger to the power jack at the back of phone.

- ◆ Connect the charger to a standard AC socket.
- Meanwhile, the charge LED in front of the phone lights on. And the charging indicator in up-right corner of the display flops cyclically, indicating the charging is going. In power-off mode while charging, the display only shows the charge indicator. If the battery is completely flat in storage or used up, it may take for a while before the charging indicator appears on the display or any calls can be made.
- When the charging indicator on the screen stops flopping, the charging is completed. The charging takes usually up to 4 hours. In the process of charging, it is a normal phenomenon that the battery, phone and charger get into hot accordingly.
- After the completion of charging, disconnect the charger from the phone and AC socket.

Note:

- When it is in charge, place the phone on condition of good ventilation and temperature between -10 $^{\circ}$ C $^{\circ}$ +55 $^{\circ}$ C. Ensure to use the charger offered by the manufacturer. Using unauthorized charger may cause danger and violate the authorization of the phone and the guarantee article.
- When the phone is automatically switched off or indicates the alarm information of power shortage, charge the battery in time.
- The duration time of the standby status or conversation of the phone is based on ideal working environment. In practice, the working time of battery varies with network condition, working environment and application methods.

2.6 Connect to the Network

2.6.1 Power on/off Phone

Press and hold **End key** to power on/off the phone and then follow the indication on the display:

Enter Phone Lock—Key in Phone Lock code of the phone if it is set as on. To set Phone Lock code, see "7.4 Security Settings".

Searching—Search appropriate network connected.

2.6.2 Connect the Network

After powering on and inputting Phone Lock code, the phone automatically searches the network available and in state of standby mode.



Besides sending and receiving calls, you can also do:

- Press Menu/Select key to enter main Menu.
- Press Clear key to enter Names menu.
- Hold Up key to enable the Silence function.
- ◆ Press **Up key** to enter **Messages** menu.
- Press Down key to enter Ring menu.
- Press Left key to enter ToolKit menu.
- ♦ Press **Right key** to enter **Games** menu.

Press Call key to enter All Calls list.

3 BASIC OPERATIONS

3.1 Make a Call

Ensure that you are in the place where the signal can be received. Examine network signal strength icon **Yull** on the screen.



The more the indication bars, the stronger the intensity of receiving signal is. If there is no bar, move to the place where the intensity of receiving signal is better. Sometimes, you only need to change the direction.

Make a Domestic Call


Press **Number key** to key in phone number, and add area code when making a long distance call (no need to add area code when dialing local number in some area). Press **Call key** to call out. Press **End key** to end the call and conversation.

Make an International Call

Enter the country code, area code (without the leading 0) and the complete telephone number you want to dial, press **Call key** to call out.

Before the country code, hold **0 key** to enter the international prefix "+" (the character "+" replaces the international access code) or key in international

prefix e.g. "00" of international call directly.



Make Recent Calls

All calls you recently dialed, received or missed are saved in your phone. All numbers are grouped as Missed Calls, Incoming Calls and Outgoing Calls. When the list is full, the oldest number will be erased automatically when new record is coming.

You can check the list as follows:

- ♦ In standby mode, press Call key to view All Calls.
- The number listed in can be directly dialed by pressing Call key.

Make Pause Calls

You can make use of pause call to dial an extention or voice service call.

E.g. Key in first phone number, press **Speaker/Ok key** to select "**P**" on the display (character "**P**" added accordingly), and then key in second number afterwards. Press **Call key** to dial the first number, when connected, press **Call key** or **Menu/Select key** to dial the second number. "**P**" can be used for not once only.

♦ Make a Three-way Call

The phone supports Three-way Call. When two parties are talking, each party can dial the third party with holding the current call by pressing **Call key**. When the third party is turned on, press **Call key** again to reactive the call on hold and enter the Three-way Call state. If the originating party ends the call, all the calls end; otherwise, two-party talking continues.

Note: This function needs local network's support. Consult with network service provider to get corresponding service application.

Make a conference call

The phone supports conference Call. So you can have a conference with some different parties (the maximum number of conferees rests with the local network) by this phone. You need call the conferees one by one, and then press **Call key** to enter the conference state.

Note: This function needs local network's support. Consult with network service provider to get corresponding service application and detail operation guide.

3.2 Answer a Call

When a call is incoming in standby mode, the phone will offer corresponding ringer to prompt. With the number already saved in Names, the phone also shows the name of caller meanwhile.

- Press Call key to answer an incoming call.
- Press End key to end a call and the call duration is temporarily displayed.

Note: Pulling away and inserting power supply adapter is forbidden during conversation.

3.2.1 Answer Automaticlly

You can set the phone to answer an incoming call automaticlly.

- Select Menu→ Settings→ Call Setting→Auto Answer.
- Select On, and press Speaker/Ok key to confirm.

The phone can be connected in 10 seconds.

3.2.2 Set Any Key Answer

- Select Menu→ Settings→ Call Setting→ One—Touch.
- Select On, and press Speaker/Ok key.

An incoming call can be answered by pressing any key except **End key** or **Clear key**.

3.2.3 Incoming Call Silence

When a call is coming, press Clear key to select Mute to mute the ringer tone.

This function silences the current incoming call only. The phone will ring normally as next call coming.

3.3 During a Call

During a call, press **Speaker/Ok key** to enable/disable the hand-free function; press **Menu/Select key** or **Clear key** to select options of **Option (Names**, **Messages or record)**, **Mute/Unmute**,etc.

- Select Mute/Unmute to let the other party temporarily can or can not hear your voice;
- Select Option for selection in Menu, such as Names, Messages or record, with no worry about the ending of conversation.

You can also press Left/Right key to adjust volume of Earpiece during a call.

3.4 Leash Function

Leash is a distance limitation talking function, developed to Cordless fixed wireless phones. If the Cordless fixed wireless phone, during a conversation, passes any of the limits, the end user will hear a beep and if he stays out of the limit, the call will 31

be dropped. Both of solution the end user do not need to invoke the feature, it depends on the carrier strategy.

When you beyond the scope of service, this phone will be issued every two seconds in a prompt tips and a prompt "PLEASE BACK SERVICE!" will appear on the LCD screen, after five consecutive times you will not be able to use the telephone and a prompt "OUT OF SERVICE!" will appear on the LCD screen. If you couldn't find your phone because of your inadvertence, you can press the button "PAGE" on the desk charge,the phone will be issued a string of so-ling sound then you can find it easily.

3.5 Menu Functions

- Main Menu Function:
 - In standby mode, press Menu/Select key to enter main Menu. Scroll Up/Down or Left/Right key through the menu and select functions according to the prompt on the screen.
- If the menu contains submenus and further submenus, select options and submenu you want according to the prompt on the screen.
- Press Menu/Select key or Speaker/Ok key to confirm. Press Clear key to return to the previous menu level. Press End key to exit to standby mode.

The functions of phone are mainly grouped in main **Menu**: **Names**, **Messages**, **Call History**, **Settings** and **ToolKit**.

Refer to the text hereinafter in this manual in detail.

4 NAMES



You can save contacts in phone. Each contact in phone's memory has three phone numbers: home number, mobile number and work number. There are three groups, **Family**, **Friend** and **Colleague** in phone. Select **Option** → **Other options** → **Capacity** to view memory of phone.

4.1 View Records

All the contacts in **Names** are grouped in **No Group**, **Family**, **Friend** and **Colleague**.

- 1. Press Menu →Names.
- 2. Press **Left/Right key** to view all contacts and all Groups list one by one. If there is no contact in the list, "No item" will be displayed.

Press **Up/Down key** to scroll to the name you are finding, and press **Menu/Select key or Speaker/Ok key**, you can see the details of the name.

4.2 Find Records

You can search for a name in **Names** by choosing:

♦ In All List

- 1. Select **Menu** → **Names**.
- 2. Press Up/Down key to scroll though the corresponding name(s) and records in the list. Scroll to the record you are finding, and press Menu/Select key or Speaker/Ok key to view the details.

Search

- 1. Select **Menu** → **Names**.
- Select one contact record and choose Search in Option. You can key in the whole name or the first part characters of the name you are searching for to view contact directly in All List.
- 3. Press **Up/Down key** to scroll though the corresponding name(s) and records in the list. Scroll to the name you want, and press **Menu/Select key or Speaker/Ok key** to view the details or select Option.

In Standby Mode

To quickly find phone number in **Names** in standby mode, press **Clear key** to enter **Names**, press **Up/Down key** scroll to the name you want.

All the contacts will be listed by the letter of the name. If no contact in the list, "No item" will be displayed.

4.3 Add New Entry

- 1. Select Menu→ Names.
- Select one contact record, and then select Option→ Add new entry. If "No item" in Names, select Add to add new enty.
- 3. Select the position of would-be added information: Phone.
- Press Up/Down key to switch between the information of Name/ Group /Home number/ Mobile number/ Work number (or Name/number). See

- "9 Text Input" more instructions for writing text and character.
- 5. After the completion of writing, press **Menu/Select key** to save the contact. If you save the same number again, the phone will remind you that this number is already exist.
- 6. Scroll to the just-added phone number, press **Speaker/Ok key** to view details. Select **Option**, and then further operation can be executed, such as:
 - Edit: Edit the number.
 - Delete: Delete the number.
 - ♦ Make a call: Make a call to this number.
 - Send message: Send message to this number.
 - Set Speed Dial: Assign a speed dial number to the phone number.

Note: In standby mode, key in phone number, press Menu/Select key to save.

4.4 Edit Contacts

- Select Menu→ Names.
- 2 Scroll to the record you want to edit or **Search** in **Option** to search for would-be edit record.
- 3. Select Option→ Edit. Scroll to the Name/ Group/ Home number/ Mobile number/ Work number to make modification.
 - 4. Press **Clear key** to erase character of the current, and rewrite the new.
 - 5. Select **Save**, "Succeed to save" appears on the display.

4.5 Delete a Records

- 1. Select Menu → Names.
- 2. Scroll to the record you want to erase or Search in Option to search for

would-be erased record.

- 3. Select Option → delete contact, and press Menu/Select key or Speaker/Ok key. "Confirm to delete?" indicated on the display.
- Press Menu/Select key or Menu/Select key to make deletion, press Clear key to Cancel deletion.

4.6 Delete All Records

You can **Delete All** the records in Names.

Select Menu \rightarrow Names \rightarrow Option \rightarrow Delete all.

4.7 Edit Group

There are three groups: **Family, Friend** and **Colleague** preset in you phone, you can rename them and set ringer for the different group.

- 1. Select Menu→ Names.
- 2. Select one record listed in phone's memory, and press Menu/Select key.
- 3. Select Edit group from Option.
- 4. Scroll to the Group you wantd edit, **Family**, **Friend** or **Colleague**. Further operation can be executed, such as:
- ♦ Edit group name: prees OK and you can rename the name of group.
- Select ringer: Set the personal ringer for the group. You can select ring from the list set already in phone or download ring by yourself.

4.8 Set Speed Dial

- 1. Select **Menu**→ **Names**.
- 2. Select one contact record saved in phone's memory and choose $Option \rightarrow$

View details.

- 3. Select one number, then select **Option** \rightarrow **Set speed dial**.
- 4. Press **Menu/Select key** and select an **Empty** slot in list.
- 5. Press Menu/Select key or Speaker/Ok key to confirm.

4.9 View and Make Speed Dial

View:

Select Menu→ Names.

Select one contact record and choose **Other options** and **View speed dial** list.

Dial:

When you select one phone number in the **Speed Dial**, you can press **Call key** to dial. You can also make a call by entering speed dial number in the standby mode.

- Method 1: Enter speed dial number, press Call key to dial.
- Method 2: Directly hold the Speed Dial Number digit key.

4.10 Capacity

- 1. Select **Menu**→**Names**.
- 2. Select one contact record and choose Other options and Capacity.
- 3. View the number of saved entries and maximum number of entries saved in phone.

For example: phone: 8/500, indicating that 500 records entries in Max., out of which 8 have be saved in phone.

5 MESSAGES

This is introduction of how to send, receive and erase the messages in your phone.



Note: The function introduced hereinafter may differ with different service offered in your area. Consult with your service provider for more detailed information.

5.1 Send a New Message

Consult with the service provider to support the network service of sending message. You can only send message to the mobile phone which can receive message.

- 1. Select Menu \rightarrow Messages \rightarrow New SMS.
- 2. Write message text. See "9. Text Input" more instructions for writing text and character.
 - 3. Select **Option** to:
 - Send Message: Send the message.
 - Save: Save the message in OutBox.
 - 4. Input the recipients' Phone Number or select phone number from Names,

and then press **Speaker/Ok key** to send or save the message in outbox.

5.2 Receive Incoming Call while Editing Message

- If you do not want to receive the incoming call, press **End key**.
- If you want to receive the incoming call, press **Call key**. After finishing receiving call, you can continue to edit and send it.

5.3 Read Message

On receipt of a new message, the phone prompts you by ringer. The display indicates "1 Received" and press **Speaker/Ok key** to View. New message is automatically saved in phone. A character on display indicates the memory for message is reaching full. Erase read messages to keep space for new messages.

- 1. Select Menu→ Messages→ Inbox.
- 2. Scroll to the message you want to read.
- Press Speaker/Ok key to read message. You can press Up/Down key to scroll.
- 4. After reading, press **Menu/Select key** to select:
- **Reply:** Reply message to sender.
- **Forward:** Forward the message to other recipients.
- **—Delete:** Erase this message.
- -Voice Call: Call back to sender.
- **—Extract:** Extract the number of the sender or in message text, and save the number to contacts.

5.4 View OutBox

1. Select Menu → Messages → OutBox.

2. Scroll Message List.

Press Speaker/Ok key to read the selected message.

4. Press Clear key to return to the list, or press Menu/Select key to Forward,

Delete or **Send** message.

5.5 Erase Messages

1. Select Menu→ Messages.

2. Select messages location: **Inbox** or **Outbox**.

3. Press **Up/down key** to select to-be-erased messages.

4. Select **Option** → **Delete** or **Delete** all to erase messages. "Delete?" or

"Delete all?" appears.

Select Ok to delete this message.

5.6 Read and Set Voice Mail

5.6.1 Read Voice Mail

Before using Voice Mail, consult with network provider to confirm that the

function of voice mail box has been activated. After your successful setting, network

will automatically divert incoming call(s) to your voice mail box, and send

message(s) to your phone.

Select Menu→ Messages→ Voice Mail→ Call Voicemail to dial voice mail

box number to listen to the leaving message following guide prompt.

40

Note: The function needs network support.

5.6.2 Set Voice Mail Number

1. Select Menu→ Messages→ Voice Mail→ Setting No.

2. Set Voice Mail Number.

5.7 Message Settings

5.7.1 Auto Save

1. Select Menu→ Messages→ Msg Settings→ Auto Save.

2. Select **On** or **Off** for your phone can or can not automatically save the sent

message. Press Speaker/Ok key or Menu/Select key to confirm.

5.7.2 Auto Delete

Set erasing the last read message in Inbox automatically when Inbox is full.

1. Select Menu→ Messages→ Msg Settings→ Auto Delete.

2. Select On or Off and press Speaker/Ok key or Menu/Select key to confirm.

5.7.3 Set Proformatted message

The phone has a group of some common built-in phrases and sentences, such

as, "I'm busy now, call you later" etc.

1. Select Menu→ Messages→ Msg Settings→Set Idiom.

2. Scroll to the message you want to send and press Speaker/Ok key or

Menu/Select key.

3. Select **Edit** to edit the message.

4. Press Menu/Select key or Speaker/Ok key to select Send→ Send

message, key in phone number or select in Names. If you select Save, the

41

message will be saved in Outbox.

Note: In text input, press * key twice to enter Set Idiom.

5.7.4 Messages Alert

- 1. Select Menu→ Messages→ Msg Settings→ Alert Setting.
- 2. Select the mode of alert as **Once** or **Cyclic** when receive a message.

5.7.5 Delivery Acknowledge

- 1. Select Menu→ Messages→Msg Settings→ Delivery Ack.
- 2. Select **On** or **Off** for your phone can or can not automatically receive message from network informing you whether you have sent message successfully.

5.7.6 Msg Priority

- 1. Select Menu→ Messages→ Msg Settings→ Msg Priority.
- 2. Select **Normal**, **Interactive**, **Urgent**, and **Emergency** for sending message. If the priority is **Urgent** or **Emergency**, there is a '!' on the message icon.

5.7.7 Memory Status

Select Menu→ Messages→ Msg Settings→ Memory Status.

View the number of saved messages and maximum number of messages saved in phone.

For example: Phone: 8/200, indicating that 200 records entries in Max., out of which 8 have been saved in phone.

6 CALL HISTORY



6.1 View Recent Calls

Information of All Calls, Received Calls, Dialed Calls, Missed Calls, including name, phone number, and call time and conversation duration is saved in the Call History.

- 1. Select Menu→ Call History.
- 2. Select All Calls, Missed Calls, Received Calls or Dialed Calls, and then press Speaker/Ok key.
- Select one entry of the records and press Menu/Select key or Speaker/Ok key.
 - 4. Select **Option**:
- **Call Information:** Indicate name, phone number, call time and conversation duration informations.
 - Save: Save the number in phone.
 - **Delete**: Delete the number from the list of Call History.
 - Clear all: Delete all numbers from the list of Call History.
 - Call the number: Dial this number.
 - SMS: Send message to this number.

6.2 Erase Recent Calls List

- 1. Select Menu→ Call History→ Clear all.
- Press Menu/Select key or Speaker/Ok key to delete all the numbers from the list.

6.3 Call Timers

Your phone can record the talk time of dialing and receiving call.

- 1. Select Menu→ Call History→ Call timers.
- Select an option from the list and press Menu/Select key or Speaker/Ok key.
- —Incoming Calls: Indicate the talk time of all received call. The timer can be reset.
- —Outgoing Calls: Indicate the talk time of all dialed call. The timer can be reset.
 - —**All Calls:** Indicate the talk time of all dialed and received call. The timer can be reset.

7 SETTINGS

In main Menu pop-up window, select **Settings** to enter into.



Your phone has different functions in Settings to meet your requirement. They are: Sound, Display, Call Setting, Security and Extras.

7.1 Sound

7.1.1 Volume

You can adjust the volume of Ringer, earpiece and key beep.

- 1. Select Menu→ Settings→ Sound→ Volume.
- 2. Select Ringer Volume, Earpiece Volume or Key Beep Volume.
- 3. Press Left/ Right key to adjust volume. Press Menu/Select key or Speaker/Ok key.

7.1.2 Ring

Ring of Incoming Call

The phone offers various Ringers of incoming call for your selection.

- 1. Select Menu→ Settings→ Sound→ Ring→ Ring Type.
- Press Up/Down key to scroll to your selection in Preset Ring or Record Ring.
 - 3. Press Menu/Select key or Speaker/Ok key to confirm.

♦ SMS Ring

You have a choice of various ringing tones for message in phone.

- 1. Select Menu \rightarrow Settings \rightarrow Sound \rightarrow Ring \rightarrow SMS Ring.
- Press Up/Down key to scroll to select and press Menu/Select key or Speaker/Ok key.

◆ Ring of Power On/Off

You can make a choice of various ringing tones when power on/off the phone.

- 1. Select Menu→ Settings→ Sound→ Ring.
- 2. Select **Power On Ring** or **Power Off Ring** and set the phone in Silence or ring when you power on/off the phone.

7.1.3 Alert Type

You can select alert type for an incoming call, earpiece and message.

- 1. Select Menu→ Settings→ Sound→ Alert type.
- 2. Select an option in list:
- **−Ring:** Set phone in Ringer case to prompt.
- -Silence All: Set phone in silence case with backlighting to prompt.

7.1.4 Key Beep

Set phone beep sound or not when you press keys.

- 1. Select Menu→ Settings→ Sound→ Key Beep.
- 2. Select an option:
- **−Off:** Not utter sound when press keys.
- **—Standard:** Utter a fixed- length tone in short when press keys.
- **Long:** Utter tone even longer when press keys.

7.2 Display

7.2.1 Wall Paper Set

You can select different wall papers as background in idle state.

- 1. Select Menu→ Settings→ Display→Wall Paper Set.
- 2. Press **Up/Down key** or **Left/Right key** to scroll the list and press **Menu/Select key or Speaker/Ok key**.

7.2.2 Set Backlighting

During a call or pressing keys, the display lights on. You can set lighting duration.

- 1. Select Menu→ Settings→ Display→ Backlight.
- 2. Select an option in pop-up window:
- **−10 Sec**: Keep backlighting for 10 seconds after last pressing.
- -30 Sec: Keep backlighting for 30 seconds after last pressing.
- 3. Press Menu/Select key or Speaker/Ok key to confirm.

Note: In conversation, backlighting consumes the power quickly and shortens continues conversation and standby time.

7.2.3 Set Brightness

- 1. Select Menu→ Settings→ Display→ Brightness.
- Press Left/Right key to adjust brightness, and press Menu/Select key or Speaker/Ok key.

7.2.4 Set Contrast

- 1. Select Menu→ Settings→ Display→ Contrast.
- Press Left/Right key to adjust contrast, and press Menu/Select key or Speaker/Ok key.

7.2.5 Set Language

- 1. Select Menu→ Settings→ Display→Language.
- 2. Select English or Spanish, and press Menu/Select key or Speaker/Ok key.

7.2.6 Set Time Format

- 1. Select Menu→ Settings→ Display→ Time Format.
- 2. Select AM/PM or 24 HR, and press Menu/Select key or Speaker/Ok key.

7.2.7 Change Banner

View and edit phone's greeting to which appears on the display to your own.

- 1. Select Menu →Settings→ Display→ Banner.
- 2. Press Menu/Select key or Speaker/Ok key to Edit.
- 3. Key in character(s) and press **Clear key** to erase character(s).
- 4. Press Menu/Select key or Speaker/Ok key to Save.

7.3 Call Setting

7.3.1 Answer Automatically

You can set the phone to answer incoming call automatically.

- 1. Select Menu→ Settings→ Call Setting→ Auto Answer.
- 2. Select On/Off to activate or deactivate automatic answering.
- 3. Press Menu/Select key or Speaker/Ok key to confirm.

7.3.2 Set Any Key Answer

- 1. Select Menu→ Settings→ Call Setting→ One-Touch.
- 2. Select On/Off, and press Menu/Select key or Speaker/Ok key.

An incoming call can be answered by pressing any key except **End key** or **Clear key**.

7.3.3 Voice Privacy

- 1. Select Menu→ Settings→ Call Setting→ Voice Privacy.
- Select an option from the list and press Menu/Select key or Speaker/Okkey. Set voice encryption in Standard or set voice encryption Enhanced.

7.3.4 Alert

- 1. Select Menu→ Settings→ Call Setting→ Alert.
- 2. Select an option on display and press Menu/Select key or Speaker/Ok key.
- **Service**: When service available.
- -Remind Minute: During a call, ten seconds ahead of every minute, alert.
- -Missed Call: When there are missed calls, alert.
- —Roaming: When roam in active and handoff between service areas or states occurs, alert.

For the function mentioned above, select **On** to operate; select **Off** to cancel alert.

7.3.5. Supp. Services

All these functions are network services. Consult with network service provider to get corresponding service application.

Call Forwarding

Use Call Forwarding to forward the incoming call to a designated phone number.

- 1. Select Menu→ Settings→ Call Setting→ Supp.Services→ Call Forwarding.
 - 2. Set type of Call Forwarding, press Menu/Select key or Speaker/Ok key.
 - **—All**: All is diverted immediately in all conditions.

- -Busy: When the phone is busy, divert.
- -No Answer: When there is no answer, divert.
- **—Busy/No Answer**: When the phone is busy or there is no answer, divert.
- 3. Select **Enabled** to **Enter Number** (which number you want to forward the incoming call to), and then press **Menu/Select key** or **Speaker/Ok key**, the phone will automatically dial the service center to set the function in active.
 - 4. Select **Disabled** to disable Call Forwarding function.

Call Waiting

During a call, use Call Waiting to answer the waiting call prompted by the network; Or dial another call meanwhile putting the first call on hold. These calls can be shifted while you have calls in conversation.

Call Waiting lets you enjoy three-party conversation without missing call.

- 1. Select Menu→ Settings→ Call Setting→ Supp.Services→ Call Waiting.
- 2. Select Option:
- **Enabled:** To activate the Call Waiting function. The network will notify you of an incoming call while you have a call in progress. You can press **Call key** to get through the waiting call and switch one call to another.
 - **Disabled:** To cancel the Call Waiting function.

7.4 Security Settings

Introduction to phone's security options preventing others to avoid illegal use or acquire your phone's personal information. Input right phone Password to enter.

Note: The default phone password is 1234, change it to your own password as soon as possible.

7.4.1 Setting Phone Lock

- 1. Select Menu→ Settings→ Security.
- 2. Input your phone password, press Menu/Select key or Speaker/Ok key.
- 3. Move to Handset Lock, set On, Off or Change Lock, press Menu/Select key or Speaker/Ok key.

7.4.2 Restore setting

Your phone offers factory default phone setting. You may modify some options when you use phone. You can also Restore Factory Default to renew some modified options to the origin.

- 1. Select Menu→ Settings→ Security.
- 2. Input your phone password, press Menu/Select key or Speaker/Ok key.
- 3. Select Restore Settings.
- 4. Select **Ok** to confirm restoring factory default or select **Cancel** to exit.

Note: Restoring the phone do not influence your phone password, PIN code, Recent Calls, Contacts, InBox and OutBox. Some setting, e.g. alarm, cannot be restored.

7.5 Extras

- 1. Select Menu→ Settings→ Extras→ Key Guard.
- 2. Select Off, 30s auto-guard or 2M auto-guard, and then press Menu/Select key or Speaker/Ok key.

8 TOOLKIT

ToolKit offers two games: Brick Attack and Push Box, as well as tools, such as Calendar, Alarm clock, Calculator, Voice Memo, Games and Stopwatch.



8.1 Calendar

- 1. Select Menu→ ToolKit→ Calendar.
- Press Left/Right key or Up/Down key to select exact date you want to view.
- 3. Select any of the **Option** as follows:
- New schedule: Add new schedule. Press Up/Down key to select different options, press Left/Right key to set different value. Enter number directly. Press Menu/Select key or Speaker/Ok key to save.
- Schedule list: List all schedules. Select Option to View details, Delete or Edit selected schedule.
- Delete: You can delete one record or all records. Select Ok to Delete from list or Delete all.
- Memory information: List Used memory, Spare memory and Total memory.
- ♦ Setting: Set Start day of week. Press Up/Down key to select, and press

Menu/Select key or Speaker/Ok key to confirm.

8.2 Alarm Clock

Set alarm alert at a certain time. You can set 5 alarm clock records in Max.

- 1. Select Menu→ ToolKit→ Alarm clock.
- 2. You can execute the following process:
- Set alarm: Set alarm clock, press Up/Down key to select items, press Left/Right key to set value, and press Menu/Select key or Speaker/Ok key to confirm.
- Alarms List: View the settings, press Left/Right key to view the different alarm records, and press Menu/Select key or Speaker/Ok key to Edit or Delete this record.
- ◆ Set rest day: Set certain day (or days) as the rest day.
- ◆ **Delete all:** Delete all the records.

8.3Calculator

Use calculator to execute basic math calculation.

- 1. Select Menu→ ToolKit→ Calculator.
- Key in digits. And press Up/Down key, Left/Right key, * key or # key to select the symbol you want, press Speaker/Ok key to get result.

1	Division Sign
-	Subtraction Sign
=	Equal Sign
+	Plus Sign
х	Multiply Sign

	Decimal Point	
*	Change digit to positive number or negative	

Press Clear key to erase digit one by one and exit to previous window, Press Menu/Select key to Reaet, press End key to exit to standby mode.

Note: This calculator has a limited accuracy and is designed for simple calculations.

8.4 Voice Memo

FX803C supports Voice Memo function either in or not in conversation with a capacity of saving 5 pcs records in max. When there is no space in Voice Memo or Voice Memo is full, the phone prompts "Records are full!".

- 1. Select Menu→ ToolKit→ Voice Memo.
- 2. Scroll **Up/Down key** to select:
- Record: When you are not in conversation, select Start to begin a new Recording, or Stop/ Pause/ Resume recording.
- Record List: Play or Delete the record listed and named by date and time. Select Back in Option to the previous menu.
- ♦ Memory Space: Show how many percent used.

Note: The record saved in normal (not in conversation) will be listed in **Settings**→ **Sound**→ **Ring Type**→ **Record Ring** as a kind of ringer tone. You can select it or not as you like as ring of the phone. The record can not be deleted as if it is activated as the ringer, unless you cancel the record as the ring of the phone.

8.5 Games

8.5.1 Brick attack

The phone indicates play guide. You can select **Newgame** to start a new game. Make use of the **Left/Right key** to play the game. See the play guide for detail operation.

8.5.2 Push Box

After the greeting, phone indicates play guide. You can select **Newgame** to begin a new game. You can play any stage (1-57) by selecting **Stage**. Make use of the corresponding **Number key** or **Up/Down/Left/Right key** to play the game. See the play guide for detail operation.

8.6 Stopwatch

- 1. Select **Menu**→ **Toolkit**→ **Stopwatch**.
- 2. Select **Start** to make stopwatch timing.
- 3. Select **Stop** to stop timing.
- Select Reset to clear the time record.

9 TEXT INPUT

Your phone offers text input modes: Multitap Input (abc/ABC), Numbers Input (123), eZiText Input (eng), and Symbol Input (Symbols). Input mode includes capital letter and lowercase mode.

You can key in letters, digits, characters and symbols when writing text or editing contact record information in **Names** or **Messages** etc., following the 55

common instruction in hereinafter table.

Operation	Method	
Input Letters	Multitap (abc/ABC) Input—"abc/ABC", press	
	corresponding letter key till the letter appears.	
Input Words	eZiText Input—"eng", press any key once to key	
	in any word.	
Input Digits	Numbers Input—"123", press digit key once.	
Input Symbol	Symbols Input —Press * key to enter the	
	symbols mode, press Up/Down key or	
	Left/Right key to page up/down and press	
	corresponding digit key to enter.	
	Or press "1" key till the symbol (common	
	symbols) appears except for Numbers Input	
	mode.	
Input Space	Press 0 key, except for being in numbers mode.	
Erase Character	Press Clear key.	
Move cursor left or	Press Left/Right key.	
right		
Change input mode	Press # key to select another text mode.	

9.1 Multitap Input

56

Select **Multitap** Input (**abc/ABC**) — Each key stands for multiple letters. Press key till your letter appears. When the cursor moves, enter the next letter.

9.2 Numbers Input

Select **Numbers** Input (**123**) — Press the corresponding key once to input the number. In Numbers input mode, you can not enter space.

9.3 eZiText Input

Select **eZiText** Input (**eng**) — Predictive word input is based on a built-in dictionary.

One letter asks for pressing only once.

Press the digit key corresponding to the letters once till the word appears on the screen.

If the word displayed is not the word you want, press **Left/Right key** or **Up/Down key** to look for another matching word. Then press **Speaker/Ok key** to confirm.

9.4 Symbols Input

-Press **1 key** to input till the symbol appears. Most common punctuation marks and special characters are available.

Or select **Symbols** mode by pressing * **key**:

- Press **Up/Down key** to page up/down. And press digit key to enter corresponding symbol.

Note: in text input, press * key twice will enter **Set Idiom** menu.

10 TROUBLESHOOTING

If your phone appears following phenomenon in the process of application,

read following relative information at first. If the problems still can not be solved, contact with the distributor or service provider.

Problem	Check Point
When switching on the phone, it	Input your phone lock password.
prompts "Input password".	
No key beep on pressing keys.	Check the setting of Key Beep in
	Settings.
When there is an incoming call,	Check the setting of sound Alert
the prompt ringer not rings.	Type and ringer Volume in Settings .
No prompt tone at alarm time.	Check relative sound setting (Alert
	Type and ringer Volume in Settings).
Messages cannot be sent.	Check the signal of network.

Motorola, the Stylized M Logo, and other Motorola trademarks and trade dress are owned by Motorola, Inc. and are used under license from Motorola, Inc.

MOTOROLA and the Stylized M Logo are registered in the U.S. Patent & Trademark Office. All other products or service names are the property of their respective owners. © Motorola, Inc [Respective YEAR]. All rights reserved.

The information contained in the **[MODEL NAME]** user guide is believed to be correct at the time of printing. We reserve the right to change or modify any information, product specifications, features or functionality without notice. The contents of the **[MODEL NAME]** user guide are provided "as is." Certain features may not be activated by your service provider, and/or their network settings may limit the feature's functionality. Additionally, certain features may require a subscription. Contact your service provider for details