

2.4Ghz Wireless Speaker




Thank you very much for purchasing our product, Inorder to safe to use the product, before you using the wireless speaker, Please read this user's guide carefully.

Please Check Carefully If Packaging Accessories All Ready







AC adaptor 3PCS

Instruction Book

3.5Audio Wire

In Order To Safely And Exactly To Operate Product

■ We use illustrate description verius caution item, In order correct to use this product and avoid incorrect operation to happen any accident



Caution: If you ignore the symbol, wrong operate the product, may be will happen suddenness or bodily harm

Notice: If you ignore the symbol, wrong operate the product, may be will make bodily harm or damage other article

Meanings Of Diagrammatic



The symbol is notice mark(included caution mark).the picture had show detail notice content. The left symbol is caution for electricity



The rotundity symbol is forbid behavior mark. Please note the forbid content when the symbol appearance in instruction book.. the left symbol is express that forbid to disassemble this product.



The symbol is caution of force execution, this symbol detail description the content of force execution

2

In Order To Safely And Exactly To Operate Product

Notice For Safety Use

 Use Voltage: According to AC adaptor spec range connect with power. To avoid damage the unit or get an electric shock or fire etc.



The Speaker with rechargeable battery, do not use the unit in high or low temperature place



• Do not use the AC adaptor connect with other machine, to avoid damage other machine.



Do not use the lead wire of AC adaptor connect with other machine, to avoid fire or get an electric shock etc.

Do not use the lead wire of AC adaptor touch other metal, to avoid fire or get an electric shock etc.

Do not cut the wire of AC adaptor, doing so that will be fire

Do not use the lead wire of AC adaptor direct connect with power, to avoid fire or get an electric etc.





• Do not cut the wire of AC adaptor, doing so that will be fire .





Please operate the unit in safety place. Do not operate it when you drive vehicle, to avoid happen traffic accident



• Do not disassemble the unit to analysis, do not change or repair the unit by yourself. Do not disconnect the top cover and bottom cover, that will be happen fire or get an electric shock etc.



Do not turn the speaker loudly, to avoid effect other people



In Order To Safely And Exactly To Operate Product

• Please put battery at safety place that child can not touch it



Please use appointed battery. Do not mix a used battery with a new or mix different type of battery, If doing so that battery will be breakdown, leakage, fire even injure people's body, etc.



• Please note the polarity of battery, if insert the battery wrong that battery will be break, leakage injure People's body, and pollute environment etc.



 Please correct use battery, do not let the battery short circuit, do not disassemble and put it to hot place Or throw battery into fire.



• Do not insert other objects inside of the unit, to avoid fire or get and electricity etc.



 Do not re-make the wire of AC adoptor, do not drag it strengthly distortion or put it on high temperature Do not use heavy goods press the wire, if doing so that wire will be break to fire or get an electric shock etc



• Do not drop the unit into water avoid creepage, fire or electric shock etc. If there is water into the unit Please cut the power immediately and contact with after service center.



Wet hand easy get an electric shock. Do not operate or connect the unit by wet hand.



In Order To Safely And Exactly To Operate Product

• Do not put the product near by window, if water into the unit will be fume, fire or get an electric shock etc.



• Do not use break of cord, if continue use it will be happen fire, get an electric shock etc.



• Do not put the unit on high temperature place, do not put it at kitchen, near warmer or other very high Temperature place. if doing so it will be scald, melting even lead to fire, creepage etc.



 Do not place the unit in the extreme temperature or under strong sunlight to operate the unit. That will lead to... The unit distortion and happen other accident. Use it within a temperature range of +10°C---+65°C



Please cut the power if insert your hand into the product.



 Do not use alcohol clean the unit, if the unit very dirty, please use dry cloth or damp-dry cloth or soft water Wipe it



Do not place the unit in high to avoid drop floor to harm people



• Do not place the unit in shake place, to avoid drop floor to harm human



HANDLE THE DEFECT PROBLEM

• Do not use the unit when the speaker have defect problem, if continue use it that will be happen fire, get an electric shock etc.



• In case the unit fume, peculiar smell, noise, please note that will be happen fire, get an electronic shock etc. Please cut the power and pull out the AC adaptor immediately. After the unit stop fume, please take it to After service center. Do not repair the unit by self, it is very damage.




CONNECTION

Please refer to the instruction book to connect the speaker




6

NAME FOR EACH PART OF UNIT



NAME FOR EACH PART OF UNIT




MONO Indicator Light

Volume Down Button Volume Up Button

Power on/off & Mode switch Right channel indicator light

Left channel indicator light




Wireless transmitter Power on/off & volume control button

audio input 3.5 jack Power indicator light

8

NAME FOR EACH PART OF UNIT



Antenna of transmitter

DV 5V power jack Right channel signal jack left channel signal jack

The antenna is fixed and can not be accessible to the end user.

USER'S GUIDE

Transmitter Connection

- 1. Audio wire connect to transmitter first, after open the audio power, then Play music.
- 2. Ac adaptor connect to transmitter.
- 3. Open power switch, then adjust the volume in proper
- 4. Transmitter can connect RCA audio (RCA wire not include)

Wireless Connection And Play Music

- 1. AC adaptor connect the wireless speaker
- 2. Press one time top cover "MODE" button to open power
- 3. Last time selected indicator light will bright, that means connect power. For example:

 Last time play the unit selected MONO mode, when open the power again, MONO light will bright. If last time selected is R, then the "R" light will bright when you open power next time.
- 4. After open power, transmitter and receiver(fix in speaker) will search channel automatic. when pairing has been completed ,the speaker will play music.
- 5. Press "MODE" button, close speaker power.
- 6. User can press "MODE" button 2-3second to select left/right channel and mono channel. The order as follow: right----mono----left----right, if keep to press MONO button, mode will be continue to cycle as above

Charge

1. The speaker with rechargeable battery .User can charge the battery when play music. this product with full charge protection function, when the battery full charge, it will stop charge automatically. To safety use it, the unit have not fast charge function. Please keep to charge battery over 10 hours, after charge full, it can continue to use over 10 hours

10

VOLUME

MONO

MODE

P E R F O R M A N C E

Tx, Rx

NO.	MEASURING ITEMS	MEASUREMENT CONDITIONS	UNIT	NOMINAL
1	Supply voltage	RX Module	V	4.5∼5
2	Supply current	RX Module	mA	50
1	Supply voltage	TX Module	V	2.7~3.3
2	Supply current	TX Module	mA	80
5	Modulation	GFSK		
8	Module used Frequency range		MHz	2404~2479
9	Module used Channel	16Channels		
10	Module Channel Interval		MHz	5
11	RF Range	50m LOS outdoor		
12	Iput level	TX	Vrms	1
13	Iput impedance	TX	Ohm	10K
14	TX Power	TX	dBm	+10
15	Output Power	RX RL=32 Ω	mW	30
		RL=16 Ω	mW	50

16	Audio Frequency Response	20Hz ~ 20KHz (-3dB)		
17	S/N ratio		dB	80
18	THD	1KHz	%	1. 2
19	Dynamic range		dB	90
20	Channel Separation	1KHz	dB	65

NO.	MEASURING ITEMS	MEASUREMENT CONDITIONS	UNIT	NOMINAL
1	Distortion At Max Volume	1KHz OdB	%	10
2	THD	1KHz OdB	%	1
3	Max output power	1KHz OdB	W	1. 5
4	10%THD output power	1KHz OdB	W	1
5	S/N ratio	1KHz OdB	dB	50
6	Frequency response	30Hz	dB	-3
		100Hz	dB	0
		10KHz	dB	-2
		18KHz	dB	-3
7	Channel Separation	1KHz OdB	dB	45
8	L/R Channel Balance	1KHz OdB	dB	0
9	Supply voltage		V	8~9
10	Supply current		mA	1000~ 1500
11	Charge time		h	12

Guaranty Regulate

- 1. Under manual 's instruct to operate the unit, if any defect problem within guaranty time, then can repair it in free charge.
- 2. Please go to sell point to repair the unit, and bring this guaranty
- 3. It will be pay repair fee as below situation:
- ① Without guaranty 。
- ② Wrong to operate the unit, self disassemble, repair and change the unit to defect.
- ③ It was drop to defect when user transport the unit a
- ④ It was defect by Fire, earthquake, gas leakage, storm, thunder, not stable power etc
- ⑤ The instruction book didn't record purchase time, client name or letter have changed etc.

FCC Caution:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Notes:

The manufacturer is not responsible for and radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.