


Bacini acoustica™

**Wireless Indoor / Outdoor
Music System**



CAUTION

TO HELP PREVENT FIRE OR ELECTRIC SHOCK: DO NOT USE THIS (POLARIZED) PLUG WITH AN EXTENSION CORD, RECEPTACLE OR OTHER OUTLET UNLESS THE PLUG CAN BE FULLY INSERTED WITHOUT EXPOSING ANY PART(S) OF THE BLADES.



This symbol is intended to alert the user to the presence of non-insulated, “dangerous voltage” within the unit’s enclosure that may constitute a risk of electric shock.



This symbol is intended to alert the user to the presence of important operating and maintenance (servicing) instructions.

WARNING

1. Do not disassemble the unit.
2. Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user’s authority to operate the equipment and the warranty.
3. Do not place the speaker near heat sources such as radiators and heating vents.
4. Do not store the speaker in extreme temperatures.
5. Turn the transmitter and speaker power OFF when not in use.
6. Do not submerge the speaker in water or leave out in the rain over extended periods of time as this may cause damage to the speaker’s performance and/or any MP3 player.
7. Do not attempt to disassemble or destroy the battery as it may cause leakage, bursting, and could create acid spills resulting in possible burns and/or damage to the immediate environment.
8. Do not incinerate the battery in a fire or place near heat. The battery may burst or generate a toxic gas.
9. Do not short the battery terminals.

BATTERY PRECAUTION

1. Use only the supplied AC adapter to charge the battery. Use of other adapters may damage the speaker circuitry and/or the rechargeable battery voiding the warranty.
2. When carrying the speaker, do not drop or collide with other objects, as this may cause damage to the speaker and/or battery.
3. Periodically check the battery for any signs of irregularities in appearance. If there is any indication of damage to the battery case such as cracks, deformation or leakage, replace the battery with a new one.
4. Do not operate the speaker with a missing battery. The AC adapter requires the battery to be in place for proper instructions.
5. Please recycle your old lead acid battery. **CALL 1-800-SAV-LEAD - BATTERY MUST BE RECYCLED.**
6. **Note: We recommend that you replace your battery every 3 years (36 months) to insure proper performance.**

FCC INFORMATION

This equipment has been tested and found to comply with the limits for a class B digital Device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the distance between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



This equipment complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This equipment may not cause harmful interference.
2. This equipment must accept any interference received, including interference that may cause undesired operation.

CONTROLS




WIRELESS TRANSMITTER:

1. POWER INDICATOR
2. POWER OFF SWITCH AND CHANNEL SELECTOR
3. AUDIO LEFT IN JACK
4. AUDIO RIGHT IN JACK
5. AC ADAPTER JACK




SPEAKER:

6. VOLUME -
7. VOLUME +
8. BASS BOOST
9. MP3 SOURCE SWITCH
10. WIRELESS TRANSMITTER SOURCE SWITCH
11. DC INPUT JACK (RECHARGE PORT)
12. BATTERY COMPARTMENT
13. CHANNEL SELECTOR
14. SPEAKER POWER SWITCH
15. BATTERY INDICATOR
16. SPEAKER POWER INDICATOR
17. MP3 WEATHER RESISTANT COMPARTMENT DOOR
18. WEATHER RESISTANT COMPARTMENT LOCKING KNOB
19. 3.5MM MP3 PLUG



ACCESSORIES:

20. 3.5MM RCA CABLE
21. DUAL RCA CABLE
22. TRANSMITTER POWER ADAPTER
23. SPEAKER POWER ADAPTER



WIRELESS TRANSMITTER SETUP AND OPERATION

The wireless transmitter may be connected two ways depending on your AUDIO SOURCE.

1. If your AUDIO SOURCE has left and right RCA output jacks, connect the transmitter by using the DUAL RCA CABLE (#21).
2. If your AUDIO SOURCE does not have left and right output jacks, but rather a 3.5mm headphone jack, use the 3.5MM RCA CABLE (#20) and DUAL RCA CABLE (#21) to connect your audio source to the transmitter.

NOTE:

**Wireless transmitter must be in the vertical, upright position to work properly.
Do not lay the transmitter on its side.**

WIRELESS TRANSMITTER AUDIO SOURCE

1. Insert one end of the wireless TRANSMITTER POWER ADAPTER (#22) into the transmitter's AC ADAPTER JACK (#5) and the other end into an electrical outlet. The transmitter's POWER INDICATOR (#1) will illuminate.
2. Insert one end of the DUAL RCA CABLE (#21) into the appropriately colored AUDIO IN R/L JACKS (# 4 and #3) on the back of the wireless transmitter. Connect the other end into your AUDIO SOURCE left and right audio output jacks if you are using the DUAL RCA CABLE (#21) or connect to the 3.5 MM plug if you are using the 3.5 MM RCA CABLE (#20) and DUAL RCA CABLE (#21).
3. Turn on the SPEAKER POWER SWITCH (#14 – located on the inside of the MP3 WEATHER RESISTANT COMPARTMENT #17) and the speaker POWER INDICATOR (#16) illuminates. Press the WIRELESS TRANSMITTER SOURCE SWITCH (#10 – located on the top right of the wireless speaker control panel). Make sure the speaker and the transmitter are set to the same channel (1, 2 or 3). 3 channels allow you to minimize interference, check all 3 channels to find one with no interference. The CHANNEL SELECTOR (#13) is located inside the WEATHER RESISTANT COMPARTMENT (#17) on the speaker. The CHANNEL SELECTOR for the WIRELESS TRANSMITTER (#2) is located on the back of the WIRELESS TRANSMITTER.
4. You can press the VOLUME +/ VOLUME – (#7 and #6) to adjust to your desired volume. Also, you can press the BASS BOOST (#8) to increase the bass output of the music. Higher volume and Bass Boost will drain the battery faster then normal volume with no Bass Boost.

NOTE:

Some 900MHz analog phones and cell phones may cause interference. For best performance, locate the speaker as far away from the phone as possible.

MP3 PLAYER AUDIO SOURCE

You can play your MP3 player directly through your wireless indoor / outdoor speaker:

1. Open the WEATHER RESISTANT COMPARTMENT LOCKING KNOB (#18) by turning the knob LEFT OR RIGHT. Insert 3.5MM PLUG (#19) into your MP3 player's 3.5MM JACK, and turn on your MP3 player.
2. Select MP3 as the input (#9).
3. Press the VOLUME + (#7) / VOLUME – (#6) on your wireless speaker to adjust to your desired listening level. Also, you can press the BASS BOOST (#8) for extra BASS effect.

NOTE:

Your MP3 player's audio volume will also affect the volume output of your wireless speaker. If the MP3 player's volume is turned down to low, there will be little to no volume on your speaker. We recommend that you set the volume on your MP3 player to 75% of the MP3 player's maximum volume.

SPEAKER POWER SOURCES

AC ADAPTER OR RECHARGEABLE BATTERY

AC ADAPTER POWER SOURCE

1. To use AC Adapter power source, insert one end of the SPEAKER POWER ADAPTER (#23) into the speaker's DC INPUT JACK (#11) and the other end into an electrical outlet.
2. Turn on your speaker's SPEAKER POWER SWITCH (#14) and the speaker POWER INDICATOR (#16) will illuminate.

RECHARGE THE BATTERY

1. When the BATTERY INDICATOR (#15) flashes, that means the battery is low and needs to be recharged.
2. Insert one end of the SPEAKER POWER ADAPTER (#23) into the DC INPUT JACK (#11) and the other end into an electrical outlet. When the BATTERY INDICATOR (#15) turns red, the battery is recharging. When the BATTERY INDICATOR (#15) turns off, the battery is fully charged.

REPLACING THE SPEAKER BATTERY

1. Remove the BATTERY COMPARTMENT COVER (#12).
2. Insert a NEW SPEAKER BATTERY (12v/7AH rechargeable Lead-Acid battery) according to polarity indicators inside the compartment.
3. Replace the BATTERY COMPARTMENT COVER.
4. Please recycle the old battery (CALL 1-800-SAV-LEAD) THE BATTERY MUST BE RECYCLED.

NOTE:

A replacement battery is not included with your speaker. Please contact the store where you purchased the speaker to buy a replacement rechargeable battery when necessary. We recommend that you replace your battery every 3 years (36 months) in order to maintain proper performance.

SPECIFICATIONS

TRANSMITTER

Range: 150'
Fine Tuning: Automatic
Number of Channels: 3
Dimensions: 1.5" (W) x 3.0" (L) x 3.5" (H)
Power supply: AC Adapter (included)

SPEAKER

Power On/Off: Yes
Volume Control: Yes
Fine Tuning: Automatic
Speaker Unit: One mid-high frequency driver and one woofer
Frequency Level: 50 Hz to 18k Hz
Dimensions: 6.5" (W) x 6.5" (L) x 24" (H)
Power supply: AC Adapter (included)
..... 12v/7AH rechargeable Lead-Acid battery (included)
Maximum Power: 30 Watts

CARE AND MAINTENANCE

1. To clean your wireless indoor / outdoor speaker, wipe the transmitter and speaker with a damp cloth. Do not use abrasive chemicals.
2. Remember to turn off the Speaker Power Switch (#14) when the speaker is not in use and unplug the Speaker Power Adapter (#23) from the wall outlet.
3. Store in a cool and dry place.

1 year limited warranty

Maxwave Development Limited warrants to the original purchaser of this product, that should the product or any part thereof be proven defective in material or workmanship within one year from the date of original purchase, such defects will be replaced or repaired without charge for parts or labor.

This warranty does not apply to any indirect incidental or consequential damages. The warranty does not apply to any part or product that has been damaged by any misuse, alteration, mishandling, neglect or accident.

This warranty is in lieu of all other warranties, expressed or implied and no person is authorized to assume any other liability in connection with the sale of this product.

Maxwave Development Limited
940 High Street, PMB 388
Westwood, MA. 02090

For questions please contact us at: questions@maxwavedevelopment.com