

Quick Start Guide



Top

Bottom

- 1. Plug the power adapter into the back of the Autonet unit and then into your power source.
- 3. Connect your computer to the wireless network that contains the name "autonet".
- 2. The Blue status light on top will begin to blink. Once this light remains to any web site. Click "Login" after constantly on, your Autonet unit is connected to the Internet.
- 4. Open your web browser and connect you've read the safety policy to connect to the Internet.

For additional information and troubleshooting tips please refer to Autonet Users Guide.

For Technical Support call 1-800-977-2107

Autonet Mobile assumes no responsibility for the configurations, security, or data files on your wireless device resulting from connection to Autonet Mobile's network. Anti-virus, privacy, and security protection is the responsibility of the user.

Do not operate while driving or perform any function that takes your attention away from safely driving your vehicle. Any function that requires prolonged attention should be performed after coming to a complete stop. Always stop the vehicle in a safe location before performing these functions. Failure to do so may result in an accident.

This device complies with Part 15 of FCC rules. Operation is subject to the following two conditions:

- 1) this device may not cause harmful interference and.
- 2) this device must accept any interference received, including interference that may cause undesired operation.

FCC ID: VOI-ANMASPLS-02

If found please call 1-800-977-2107

Confidential and Proprietary

TITLE:	Autonet In-Car Router Labels							
		COMPANY:	Autonet Mobile, Ir	CREATOR:		Doug Moeller		
DATE:	12/12/07	TIME:	11:55:20 PM	PG:	1	OF	1	PGS
FILENAME: Autonet_Router_Label-07.vdx								