

# **User Manual**



**27, Sep, 2007**

## Table of Contents

|          |   |           |
|----------|---|-----------|
| <b>1</b> | <b>About BKS-4800 Series</b>                        | <b>4</b>  |
| <b>2</b> | <b>Setup Console Manager</b>                        | <b>4</b>  |
| 2.1      | Installation - 4 -                                  |           |
| 2.1.1    | Installation PC Capacity - 4 -                      |           |
| 2.1.2    | Console Manger total diagram - 5 -                  |           |
| 2.1.3    | How to install Console Manager on PC - 5 -          |           |
| 2.1.4    | How to uninstall Console Manager on PC - 8 -        |           |
| 2.2      | How to setup Console Manager - 9 -                  |           |
| 2.2.1    | Enter Console Manager - 9 -                         |           |
| 2.2.2    | Main window and basic word - 12 -                   |           |
| 2.3      | How to use Console Tele Manager - 16 -              |           |
| <b>3</b> | <b>How to connect between Terminal &amp; Server</b> | <b>17</b> |
| 3.1      | Select portHow to register - 17 -                   |           |
| 3.2      | Setup terminal - 18 -                               |           |
| 3.3      | Connection of terminal -25-                         |           |
| <b>4</b> | <b>How to enroll User</b>                           | <b>37</b> |
| 4.1      | Enroll company - 37 -                               |           |
| 4.2      | Enroll Group(Department or Branch) - 38 -           |           |
| 4.3      | Enroll position - 39 -                              |           |
| 4.4      | Enroll Userr - 40 -                                 |           |
| <b>5</b> | <b>Set schedule &amp; Role</b>                      | <b>45</b> |
| 5.1      | Set schedule - 55 -                                 |           |
| 5.1.1    | Set Holiday - 55 -                                  |           |
| 5.1.2    | Set Time Zone - 57 -                                |           |
| 5.1.3    | Set Time schedule - 58 -                            |           |
| 5.2      | Transmit Schedule to terminal - 59 -                |           |
| 5.3      | Role - 60 -   |           |
| 5.4      | Schedule control layout -- 58                       |           |
| <b>6</b> | <b>Transmit</b>                                     | <b>63</b> |
| 6.1      | Download & Upload - 63 -                            |           |
| 6.1.1    | Download User - 64 -                                |           |
| 6.1.2    | Delete User - 64 -                                  |           |

|                                      |           |
|--------------------------------------|-----------|
| 6.1.3 Download All user              | - 65 -    |
| 6.1.4 Delete All user                | - 65 -    |
| 6.1.5 Upload FP and EM TYPE          | - 65 -    |
| 6.1.6 Download and delete schedule   | - 66 -    |
| 6.1.7 Download terminal status       | - 66 -    |
| 6.1.8 Firmware update                | - 66 -    |
| <b>7 Monitoring</b>                  | <b>66</b> |
| <b>8 Report</b>                      | <b>67</b> |
| 8.1 User log data view               | - 69 -    |
| 8.2 All log data view                | - 65      |
| <b>9 Time &amp; Attendance</b>       | <b>72</b> |
| 9.1 Enter T&A                        | - 72 -    |
| 9.2 Set T&A condition                | - 78 -    |
| 9.2.1 Data path                      | - 82 -    |
| 9.2.2 Standard time                  | - 83 -    |
| 9.2.3 Holiday                        | - 87 -    |
| 9.2.4 Enroll others                  | - 88 -    |
| 9.3 Trans T&A data                   | - 90 -    |
| 9.4 Query T&A                        | - 90 -    |
| 9.4.1 Daily                          | - 91 -    |
| 9.4.2 Personal                       | - 92 -    |
| 9.4.3 Period                         | - 92 -    |
| <b>10 Other function</b>             | <b>93</b> |
| 10.1 Check enrolled user of terminal | - 93 -    |
| 10.2 Data Utility                    | - 94 -    |
| 10.3 Door Open                       | - 94 -    |
| 10.4 Change window structure         | - 95 -    |
| 10.5 Sliding message on LCD          | - 95 -    |

THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

## 1. About BKS-4800 Series

BKS-4800 security, work place time and attendance, and over-time work verification and other situations requiring the presence of the authorized personnel. Fingerprint identification technology bypasses problems of existing security solutions such as EM TYPEcards and keypad locks. These are prone to security breach from card duplication and misplacement or improper disclosure of password. These accidents allow for proxy authorization and breach of security.

Fingerprints have constancy and uniqueness and its pattern can be easily and cheaply recorded, thus making it the most desirable form of biometric recognition system. The new sensor now enables us to cut costs as well as to miniaturize, both of which will make the technology more practical and more easily mass marketed.

BKS-4800 supports various I/O protocols and is an optimal solution for managing access-controlled points. With 128 X 64 pixels blue LCD screen, 12 regular keys and 5 special function keys, make BKS-4800 user-friendly. Communication is based on TCP/IP is also easy with the included 1 RS232 port, 1 RS485 port, 1 relay signal and 1 external sensor inputs.

## 2. Setup Console Manager

### Installation

#### Installation PC Capacity


BKS-4800 Manager system : suggested PC application

|         |                                       |
|---------|---------------------------------------|
| CPU     | Pentium 4 1.7 GHz over                |
| RAM     | 256MB over (512MB suggest to be over) |
| OS      | Windows 2000 / XP                     |
| HDD     | 40GB over                             |
| Network | LAN                                   |

BKS-4800 Manager system : minimum capacity

|         |                        |
|---------|------------------------|
| CPU     | Pentium 3 1.0 GHz over |
| RAM     | 128MB over             |
| OS      | Windows NT / 2000 / XP |
| HDD     | 20GB over              |
| Network | LAN                    |

#### Console Manager total diagram



#### How to install Console Manager on PC

- Content of installation

- ① Choose the administration PC.
- ② Check the computer installed Window system. (Windows 2000 / XP)
- ③ To install Console Manager as to click "Setup.exe".
- ④ After installation of Console Manager, input BKS-2600 to USB port.
- ⑤ Install BKS-2600 driver.


■ Set Console Manager

Double click the “**setup.exe**” file and then the below installation window will be shown.


**Caution: The Console manager should be set at only C drive.**




Please click the **Next** button.



Click the next button after confirm License Agreement.



Click Next button.




“Console Manager” & “Console Service” Icon created on the desktop.



### How to uninstall Console Manager on PC

- Uninstall Console Manager
- Start – control – Program add/delete – Select **Console Manager** .

Click the delete button and Console Manager will be removed.



## How to setup Console Manager

Console Manager is main control program networked several BIOINSEC terminals on network. It's shown all records of communication between terminal and server, that is the reason can control all LOG related of BKS-4800 terminals.

### Enter Console Manager


- Main log-in window appears after click Console Manager icon on the desktop, Click the Icon and above window appears.




- Initial set value is “ **ID : 1 Pass : 1** ”, please give new Password for reduction of security risk.
- If the administrator enrolled “Admin Fingerprint,” please click the blue man Icon pointing to finger icon and place your finger on BKS-2600 scanner.



< When USB Scanner doesn't be connected to PC, this message appears >



- Setup path : Please click "Set path" and then the below window appears.



4800D : C:\Program Files\Console\ DataBase\4800D.mdb

4800L : C:\Program Files\Console\ DataBase\4800D.mdb

Server IP : Computer IP address or input 127.0.0.1


Server Port : 8009

Setting values are automatically set like above menu.

TCP Application Port and TCP/Terminal Port are automatically opened.

Console Manager & Console Server Manager icon displays on the desktop and “**Start => Program => Console Manager => Console Server Manager**”.

Double click the “Console Server Manager” menu




**TCP Application Port and Console Manager Server port is automatically set 8009.**

**TCP/Terminal Port, 8008 also is automatically set as Terminal Port 8008.**

After checking all data path clearly, click “OK” button for saving. And then main window appears.


## Main window and basic word



### ■ Main window is composed to Menu Bar, Tool, Tree View, Icon .

- ① Menu bar : file, enroll, Setup, View, Transmission, Control, Window, Help.
- ② Tool : New enroll, delete, Information, Delete all, Transform data, Delete terminal user data, Transmit all user data, Delete all user data of system, Get FP data from Terminal, Get all FP data, Get all EM TYPEdata, Monitoring, Report, Time & Attendance, Close etc...
- ③ Position View : Show the position tree view of user and terminal data.
- ④ Event view: Show terminal status and event
- ⑤ Menu bar detail description






| Menu   | Sub menu          | contents                              |
|--------|-------------------|---------------------------------------|
| file   | Set admin         | Set administrator                     |
|        | Close             | Finish Console Manager                |
| Enroll | Company           | Enroll Company                        |
|        | Group             | Enroll department                     |
|        | Position          | Enroll position                       |
|        | Set port          | Enroll terminal port                  |
|        | Terminal          | Add/delete terminal                   |
|        | Role              | Setup user access role                |
|        | User              | Enroll user                           |
| Setup  | Set FP enrollment | Set Fingerprint enrollment.           |
|        | Set data path     | Set DB path                           |
|        | Check Com         | Check the communication with terminal |
| View   | Admin window      | Appear administrator window           |
|        | Position window   | Appear position window                |
|        | Event window      | Appear event window                   |
|        | Document window   | Appear document window                |

| Menu         | Sub menu                    | contents                                       |
|--------------|-----------------------------|--|
| Transmission | Transmit personal data      | Transmit personal data to terminal             |
|              | Delete personal data        | Delete personal data of terminal               |
|              | Transmit all data           | Transmit all user data to terminal             |
|              | Delete all user data        | Delete all user data from terminal             |
|              | Get FP data by personal     | Get fingerprint data from terminal by personal |
|              | Get all user FP data        | Get all fingerprint data from terminal         |
|              | Get all user EM TYPEdata    | Get all user EM TYPEdata from terminal         |
|              | Get EM TYPEdata by personal | Get EM TYPEdata from terminal by personal      |
|              | Check user enroll           | Check the enrollment.                          |
| Control      | Download Terminals          | Download terminal data                         |
|              | Download Schedules          | Download schedule data                         |
|              | Download Holidays           | Download Holiday data to terminal              |
|              | Download Time Zones         | Download time zone to terminal                 |
|              | Door open                   | Door open                                      |
|              | Set door                    | Set door condition                             |
|              | Update Firmware             | Terminal Firmware                              |
| Window       | Horizontally                | Sort horizontal style                          |
|              | Vertically                  | Sort Vertical style                            |
|              | Icon sorting                | Icon sorting                                   |
|              | Cascade                     | Sort cascade                                   |
|              | Window List                 |  |
| Help         | Help                        | Help   |

### ■ Set administrator



Initial admin is set as "Admin ID 1", you can add new administrators as push "Add" button after enrolled new ID and Password. If you want to use fingerprint, please enroll fingerprint as push "Enroll FP" button and place your finger on the sensor of BKS-2600 scanner connected to PC.

### ■ Set enroll method



Select enrollment method between "Enroll by fingerprint scanner" and "Get Fingerprint data from terminal"

Please make sure that "Enroll by FP scanner" should connect of BKS-2600 scanner on PC.

And push "OK" button for saving.


### ■ Useful description of word

- ① **Download : Send data to terminal**
- ② **Upload : Get data from terminal**
- ③ **FP : Fingerprint**

## How to use Console Service

For communication with terminal and Console Manager Software, Window service system should be started.

Click “Bio Tele Manager” Icon on desktop and appears the below window.





Click “Start” button and appears all status of enrolled terminal. Connected state is correct communication with server and terminal. If the state marked to disconnected, please check all condition of terminal set value and terminal set value.


### 3. How to connect between Terminal and Server

#### Select port

It initially input 3 kind of terminal port as **Dial-up, Serial and TCP/IP**.

First choose correct port type and enroll terminal as below.






### Setup TCP/IP Connection

Enroll Terminal by tree menu or menu bar to TCP/IP port

- **TID** : Terminal ID should match as terminal enrolled terminal ID the stage of “3.System=>3.Terminal ID => Shown number”
- **Name** : Input terminal name
- Select port
- Server Match is not available now
- Check Free scan mode if you want to use
- TCP/IP port should input server PC IP address.
- Select Access module
- Check Temper sensor, Door open sensor, exit button if it's available.
- Select Security level applied to terminal.
- Push “OK” button for saving.
- After registration, Stop Console Server Manager and restart and then you can see the terminal



## BKS -4800 Hardware Menu


## System

- 1: Admin PIN
- 2: Admin FP
- 3: Terminal ID



## Terminal ID

New TID(1~999)?

1 =&gt;



- CAUTION : IF YOU SEE RED COLOR BUTTON AND CLOSE STATE, PLEASE GO TO "4. OPEN PORT FOR THE USER OF WINDOW XP SERVICE PACK2"
- Go to " 4. Network Mode => 3. TCP/IP => Select TCP/IP network"



## Network Mode

- 1: Serial
- 2: DialUp
- 3: TCP/IP

### ■ Input TCP/IP value

1. Local IP Address : Input Terminal IP address
2. Subnet Mask : Input Subnet Mask address

## Network

- 1: Network Mode
- 2: Local IP Addr
- 3: Subnet Mask


3. Gateway : Input Gateway address
4. Server Host : Input Server PC's IP address
5. Server Port : Input port number of PC server. It is set, as 8008 initially, please do not change without special cause.

## Network


- 4: Gateway
- 5: Server Host
- 6: Server Port

■ LCD Icon change and network connection state

When you see the TCP/IP network Icon and " X" means Network disconnected.




All setting value is correct and TCP/IP icon disappears "X" mark.



## ■ Console Manager connecting states

When you double click terminal on Console Manager, you can see the rotating icon as follows.




< Terminal IP Address >

```
명령 프롬프트 - ping 192.168.2.21
Microsoft Windows XP [Version 5.1.2600]
(C) Copyright 1985-2001 Microsoft Corp.

C:\Documents and Settings\Administrator>ping 192.168.2.21          Ping + Terminal IP address
Pinging 192.168.2.21 with 32 bytes of data:
Request timed out.
Request timed out.

- It means an wrong IP address or incorrect
  connection.
```

Open “command prompt” program on the server PC, write ping + Terminal IP address, if you got “Request timed out” message, it is the incorrect IP address.



```
Microsoft Windows XP [Version 5.1.2600]
(C) Copyright 1985-2001 Microsoft Corp.

C:\Documents and Settings\Administrator>ping 192.168.2.10

Pinging 192.168.2.10 with 32 bytes of data:

Reply from 192.168.2.10: bytes=32 time<1ms TTL=128


Ping statistics for 192.168.2.10:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
    Approximate round trip times in milli-seconds:
        Minimum = 0ms, Maximum = 0ms, Average = 0ms

C:\Documents and Settings\Administrator>
```

When you receive the above message, it's the correct IP address for terminal.

< Server IP address >

Open “command prompt” program on the server PC, write “ipconfig” and push “Enter” key on the keyboard.



```
Microsoft Windows XP [Version 5.1.2600]
(C) Copyright 1985-2001 Microsoft Corp.

C:\Documents and Settings\Administrator>ipconfig

Windows IP Configuration

For checking server PC's IP address

Ethernet adapter 로컬 영역 연결:

  Connection-specific DNS Suffix  . :
  IP Address. . . . . : 192.168.2.11
  Subnet Mask . . . . . : 255.255.255.0
  Default Gateway . . . . . : 192.168.2.1


C:\Documents and Settings\Administrator>
```

The server PC's network value is appeared.


Change the correct IP setting value, it should restart "Console Server Manager" to be recognized changed value.

## Setup Serial Connection

Enroll Terminal by tree menu or menu bar to Serial port




- TID : Terminal ID should match as terminal enrolled terminal ID the stage of “3.System=>3.Terminal ID => Shown number”( Refer to page 26)
- Set Serial Port, Serial Speed and others at the same value of Window setting. ( System Properties=> Hardware tab =>Device Manager => Ports => Double click “Communication Port” => Communications Port Properties => Port Settings Tab )



■ **Restart “Console Server Manager” and then changed Opened state of port.**

When you push “Start” button on Console Manager, you can see the red box displays blue button, COM1, 115200, Serial Opened states.

If the COM1 port is not connected with terminals, you occur from the incorrect COM Port or different Baud rates.




And go to Console Manager and push “Start” button, you can see the blue button and Serial Opened status.

The first box is for the Port state between terminal and server PC. So it shows blue button of the opened state.

**NOTE: If the port is not opened statuses with the red button, please check your computer is installed SP2. If yes, please refers to page 12~14.**

■ **Add Serial terminal**

Enroll Terminal by tree menu or menu bar to Serial port



- **TID** : Terminal ID should match as terminal enrolled terminal ID the stage of "3.System=>3.Terminal ID => Shown number" (refer to 26 page )
- **Set the hardware setting of serial communication**

Go into the menu of terminal( CFR-3000 : 0 + ↲ ) as to input "1111" as initial password.

Go to "4. Network Mode => 1. Network Mode => 1.Serial mode"

## Administration

### 4: Network

#### Network

1: Network Mode

2: Local IP Addr

3: Subnet Mask

#### Network Mode

1: Serial

2: DialUp

3: TCP/IP

Input Serial Speed as same as Console Manager setting value( Refer to page 34 ).


#### Network

1: Network Mode

2: Serial Speed


Select one value as same as Console Manager setting value. ( Refer to page 33~34 )

1. 9600
2. 19200
3. 38400
4. 57600
5. 115200




LCD Icon change and network connection state.

When you see the Serial network Icon and "X" means Network disconnected.




All setting value is correct and Serial icon disappears "X" mark.




### Setup Dial-Up Connection

Go to “DialUp(D) => DialUp Control” of Menu bar and the above Dial-up setting window appears.


- Click “ADD” button when cursor is on DialUp (telephone image).




- Add port window appears



- Input port name first. Set Serial port and serial speed.(Refer to page 34)
- Click “ADD” button when cursor is on enrolled Port.
- ADD Terminal window appears




- Input "Name" DialUp setting. It should be direct telephone No. extension No is not available.
- If the modem is connected to 485 serial connection, give telephone No and Dial-up time to one terminal only. For enrollment of rest of terminals, Click "ADD" button when cursor is on enrolled Terminal. The below window appears.



- It couldn't input Tel number and time so just input **correct TID & Name**.
- After set, click DialUp on the menu bar and the below window appears.
- The right section is shown enrolled dial-up terminal. For calling to terminal, select terminal and push " Connect(D)" button. All modem connection status is shown in "MODEM" and "SERIAL" section.
- For checking dialing status, please check tick mark of Checking Dialing.
- 10 seconds mean, when terminal doesn't send data to server for 10 seconds, modem disconnected. This setting value can't change in automatic connection, but manual

connection as to click Connect button can give new value 0~ 255 seconds. 0 is continually connection(unlimited connect time) 1 is disconnect after no data for 1 second. 255 is disconnect after no data for 255 seconds.

- If modem connects to several terminals by serial converter, SERIAL section shows all sub terminals of modem.
- After terminal registration, Stop service and restart.




## Connection of terminal

Click to enrolled terminal and appears the below window.

When server connection is well, the mark will be turning, if not, red X mark will be displayed.

If user wants to change setting value, change and click download button for changing terminal setting value.

All enrolled terminal status appears, and modification and deletion is possible by download and upload button.




- Set details :
- Server Match is not available( plan to update this function),
- Free scan mode can set here and terminal
- Access module : possible to check here and terminal.
- Door open time : Door close after 5 seconds.
- Door open schedule : If user wants to keep opening door within given schedule time.
- Door close schedule : If user wants to keep closing door within given schedule time.
- Download : if you change any value, click Download button for applying.
- Holiday, TimeZone, Schedule is shown registered value of terminal, so if you want to apply schedule to user and terminal, it must have schedule value on terminal.

#### 4. How to enroll User


##### Enroll company

Select User and click the right button of mouse as the below picture or go to menu bar of stage (Register=> Company=>New).



### Enroll Group ( Department or Branch )

After enrolled company, enroll group(Company department or branch) as sub menu of enrolled company.




Sub group can be made under upper group.




Enroll position

Select User and click the right button of mouse as the below picture or go to menu bar of stage  
(Register=> Position=>New)




When click enroll position, this window appears. It can be enrolled by company.



### Enroll User

Click the right button of mouse at selected Group or go to menu bar of stage (Register=>User=>New)

**If you want to use Time & Attendance software, should select position, company and group correctly. BMP file is only available for photo upload.**



When BKS-2600 scanner is connected, click "First FP enroll" button for fingerprint enrollment.

| input          | description                                       |
|----------------|---|
| *User ID       | Input User ID the range of 1~8 digit(0~99999999)  |
| *com-ID        | Company ID or employee No, 1~8(0~99999999) digit. |
| *User Name     | Input user name                                   |
| *Social No     | Input user social No.                             |
| *Position      | Select user position.                             |
| *Depart        | Select user department                            |
| *Access mode   | Select FR, RF, PIN, RF+FP, RF+PIN                 |
| *Set role      | Set role by personal                              |
| Security level | Set security level by personal                    |
| Password       | Input 1~8 digit(0~99999999).                      |
| Retry Password | Retry password for confirmation                   |

- Security level

| FP level | description                                     |
|----------|---|
| 0        | Same security level as terminal's setting level |
| 1        | Very low  |
| 2        | Low   |
| 3        | Normal  |
| 4        | High  |
| 5        | Very high                                       |

If not, enroll in Terminal and use “Get FP data” function. Please push “Next” button after enrollment done.

- Manually : Select manually the most optimum image as to click “OK” button.
- Automatically : Select automatically the most optimum image.



This is for EM TYPEenrollment and work type for Time & Attendance. Push “OK” button after input done. Please select “User work time status” if you want to Time & Attendance software and detail information is in Time & Attendance chapter.

| Input                 | Description                                  |
|-----------------------|--|
| RF-CARD enroll        | Enroll RF-CARD by EM TYPEcard reader.        |
| Card status           | Normal, stolen or lost                       |
| *Validity             | User validity period                         |
| User type             | Permanent, yearly contact, temporally, daily |
| User work time status | Set user work time.                          |
| Remark/memo           | Record memo                                  |

Validity mean is the user usage period by set value.

This function is for transmit enrolled user data to terminal, and push "Download" button for saving on terminal.

All enrolled process is done but for using Access limit or Time & Attendance software, please see the corresponding chapter before user enrollment.



**Green color : Dial-up terminal**

**Black color : TCP/IP, Serial**

## 5. Set Schedule & Role

### < Example of How to use >

#### \*Group

A Group : CEO & Executive

B Group : Administrator

C Group : Office Worker

D Group : Factory Worker- Line1

#### \*Access permitted Area

A Group : 1~10 (Terminal ID)

B Group : 4~10 (Terminal ID)

C Group : 4~10 (Terminal ID)

D Group : 7~10 (Terminal ID)

| Group      | Holiday  | Working time                     | Access time                     | Access Area   |
|------------|--|----------------------------------|---------------------------------|---------------|
| A : CEO    | SUN<br>SAT   | 09:00~18:00                      | All day<br>with Holiday         | All terminals |
| B : Admin  | NONE   | 09:00~18:00                      | 06:00~22:00                     | TID :4~10     |
| C : Office | SUN<br>2&4 <sup>th</sup> of SAT<br>1 day of 15 <sup>th</sup> | 09:00~18:00<br>SAT : 09:00~13:00 | 08:00~19:00<br>SAT: 08:00~14:00 | TID:4~10      |
| D : Line1  | SUN<br>3days of 10,20,30 <sup>th</sup>                       | 09:00~15:00<br>16:00~19:00       | 08:00~15:15<br>16:15~20:00      | TID:7~10      |

Other conditions: National Holiday 19<sup>th</sup> , All Groups are applied to holiday

#### Step1

#### Holiday Setting

Go to the stage of “menu => Register => Schedule => Holidays”.

You can select a repeated common holiday on the schedule table.

What is repeated common holiday?

**Every Sunday, Saturday**

Rotating day of week like every 2<sup>nd</sup> & 4<sup>th</sup> of Saturday or every 1<sup>st</sup> of Monday etc...

You don't have to enroll on holiday list all these days.

It can be made the 3 holiday table

1. 19<sup>th</sup> => A,B Group
2. 15<sup>th</sup> , 19<sup>th</sup> => C Group
3. 10<sup>th</sup> , 19<sup>th</sup> , 20<sup>th</sup> , 30<sup>th</sup> => D Group

Select date => Choose Holiday Table => Enroll

**Enroll Holiday**

**HOLIDAY DEFINITION**

| Date     | Holiday          |
|----------|------------------|
| 20070210 | Line 10          |
| 20070213 | C Group          |
| 20070219 | National Holiday |
| 20070223 | Line 30          |
| 20070226 | Line 20          |

Holiday:  Date:

**Holiday Table**

1. Holiday  3. Holiday Period  
 2. Holiday  4. Holiday I

**Set**

2007  YEARS 2  MONTHS

**Enroll** **Delete** **Change** **Close**

| SUN | MON | TUE | WED | THU | FRI | SAT |
|-----|-----|-----|-----|-----|-----|-----|
|     |     |     |     |     |     | 1   |
| 4   | 5   | 6   | 7   | 8   | 9   | 10  |
| 11  | 12  | 13  | 14  | 15  | 16  | 17  |
| 18  | 19  | 20  | 21  | 22  | 23  | 24  |
| 25  | 26  | 27  | 28  |     |     |     |

## Step 2

### Time zone setting

Go to the stage of “menu => Register => Schedule => Time Zones.”

**Note: You don't need to register No entry (All day limited to enter) time zone for default value.**

If the working time is 00:09~20:00, you can give one or half hours more time than working hour for early attend and late leave workers.


**01 Limit Time : 00:00~00:00 => Access granted for all day**

**02 Admin : 06:00~22:00 => This is for B group of 09:00~18:00 working time.**

| ID | Name    |
|----|---------|
| 01 | All day |
| 02 | Admin   |

**03 Office : 08:00~20:00 => This is for ABC Group of 09:00~18:00 working time.**

**04 SAT : 0800~14:00 => This is for C Group of Saturday 09:00~13:00 working time.**



05 Line : 08:00~15:15, 16:15~20:00 => This is for D group of 09:00~19:00 and 15:00~16:30 Break time.

**Totally 5 different time zones are required for it.**

### Step 3

#### Schedule

Go to the stage of “menu => Register => Schedule => Schedules”.

#### A Group setting => Access All day

Select “01 All day” for every setting.

Please be careful of “Enroll Holiday” should be set “Holiday1” and select “01 All day”

**Enroll Schedule**



**ID** 01

**Name** A CEO

**Work schedule**

| Day | Setting    | Start | End     | Setting | Start | End | Setting | Start | End |
|-----|------------|-------|---------|---------|-------|-----|---------|-------|-----|
| SUN | 01 All day | 00:00 | ~ 23:59 |         |       |     |         |       |     |
| MON | 01 All day | 00:00 | ~ 23:59 |         |       |     |         |       |     |
| TUE | 01 All day | 00:00 | ~ 23:59 |         |       |     |         |       |     |
| WED | 01 All day | 00:00 | ~ 23:59 |         |       |     |         |       |     |
| THU | 01 All day | 00:00 | ~ 23:59 |         |       |     |         |       |     |
| FRI | 01 All day | 00:00 | ~ 23:59 |         |       |     |         |       |     |
| SAT | 01 All day | 00:00 | ~ 23:59 |         |       |     |         |       |     |

**Set every other week**

1 week  2 week  3 week  4 week  5 week **Select day**

**Every other week** 32 No Entry

**Enroll Holiday**

01 All day  00:00 ~ 23:59

**Modify timezone** **Modify Holiday**


### C Group setting

Please be careful of 2<sup>nd</sup> and 4<sup>th</sup> Saturday holiday setting and select “32 No Entry” for Sunday.

Week : 03 Office time zone

Set every other week : check 2<sup>nd</sup> & 4<sup>th</sup> of Saturday and select “32 No Entry”

Enroll Holiday : Select “Holiday02” and “32 No Entry”



#### D Group setting

Holiday : Select “Holiday3” and “32 No Entry”

Sunday : Select “32 No Entry”.

**Enroll Schedule**

**SCHEDULE**

ID: 04    Name: Line1    **Modify**    **>>**

**Work schedule**

|       |             |               |               |               |               |               |               |               |               |               |               |
|-------|-------------|---------------|---------------|---------------|---------------|---------------|---------------|---------------|---------------|---------------|---------------|
| SUN : | 32 No Entry | 08:00 ~ 15:15 | 16:15 ~ 20:00 | 08:00 ~ 15:15 | 16:15 ~ 20:00 | 08:00 ~ 15:15 | 16:15 ~ 20:00 | 08:00 ~ 15:15 | 16:15 ~ 20:00 | 08:00 ~ 15:15 | 16:15 ~ 20:00 |
| MON : | 05 Line1    | 08:00 ~ 15:15 | 16:15 ~ 20:00 | 08:00 ~ 15:15 | 16:15 ~ 20:00 | 08:00 ~ 15:15 | 16:15 ~ 20:00 | 08:00 ~ 15:15 | 16:15 ~ 20:00 | 08:00 ~ 15:15 | 16:15 ~ 20:00 |
| TUE : | 05 Line1    | 08:00 ~ 15:15 | 16:15 ~ 20:00 | 08:00 ~ 15:15 | 16:15 ~ 20:00 | 08:00 ~ 15:15 | 16:15 ~ 20:00 | 08:00 ~ 15:15 | 16:15 ~ 20:00 | 08:00 ~ 15:15 | 16:15 ~ 20:00 |
| WED : | 05 Line1    | 08:00 ~ 15:15 | 16:15 ~ 20:00 | 08:00 ~ 15:15 | 16:15 ~ 20:00 | 08:00 ~ 15:15 | 16:15 ~ 20:00 | 08:00 ~ 15:15 | 16:15 ~ 20:00 | 08:00 ~ 15:15 | 16:15 ~ 20:00 |
| THU : | 05 Line1    | 08:00 ~ 15:15 | 16:15 ~ 20:00 | 08:00 ~ 15:15 | 16:15 ~ 20:00 | 08:00 ~ 15:15 | 16:15 ~ 20:00 | 08:00 ~ 15:15 | 16:15 ~ 20:00 | 08:00 ~ 15:15 | 16:15 ~ 20:00 |
| FRI : | 05 Line1    | 08:00 ~ 15:15 | 16:15 ~ 20:00 | 08:00 ~ 15:15 | 16:15 ~ 20:00 | 08:00 ~ 15:15 | 16:15 ~ 20:00 | 08:00 ~ 15:15 | 16:15 ~ 20:00 | 08:00 ~ 15:15 | 16:15 ~ 20:00 |
| SAT : | 05 Line1    | 08:00 ~ 15:15 | 16:15 ~ 20:00 | 08:00 ~ 15:15 | 16:15 ~ 20:00 | 08:00 ~ 15:15 | 16:15 ~ 20:00 | 08:00 ~ 15:15 | 16:15 ~ 20:00 | 08:00 ~ 15:15 | 16:15 ~ 20:00 |

**Set every other week**

1 week    2 week    3 week    4 week    5 week    Select day of week: **SAT**

Every other week: 32 No Entry

**Enroll Holiday**

**Holiday**   **32 No Entry**

**Modify timezone**   **Modify Holiday**   **O.K(O)**   **Close(C)**

All schedules are set as 4 different schedule ID using by time zone and holiday.


### Step 3

#### Role setting

Go to the stage of “menu => Register => Role => New”.


The role setting makes easy access control for several terminals together.

A CEO can pass any door so first you select “01 A CEO” schedule and then add applied terminals. CEO group can pass any door so select all terminals.




D Line1 group can pass 7~10 terminals only, **first select “04 Line1” and add 007~010 TID to Limited terminal field.**

**001~006 terminals: Select “32 No Entry” and then add to limited terminal field.**



**Step 4****Apply to user registration**

Position : Director applies for “01 Free pass” role




## 5.1 Set Schedule

If terminal uses for Access control, it should be set correctly.

This software makes you manage the weekly schedule and base of Role function together.

### 5.1.1 Set Holiday


Go to the stage of ( Register=> Schedule=> Holiday)



The below window appears when push "Holiday" of menu

Holiday table is initially set as "1 Holiday" is for dividing holiday type.

For example, Type 1 is for Sunday, Type 2 is for National Holiday, Type 3 is for Company day off and if 4<sup>th</sup> of July is including Sunday and National Holiday, please check "1 Holiday" & "2 Holiday".



### Holiday Table section

#### (EXAMPLE)

“A” group holiday => All Sunday and Saturday

“B” group holiday => All Sunday

“C” group holiday => All Sunday and 3 days of 10, 20 and 30<sup>th</sup>

EX) “A” group is day off all Sunday and National Holiday

“B” group is day off all Saturday and National Holiday.

“C” group is day off 10,15,20,15,30.

So you can make Holiday 1,2,3 by worker schedule.

For falling on day, check included schedule. For example “A” & “B” group has same holiday as National Holiday. If it is 6<sup>th</sup> of July, click and select “1,Holiday” & “2.Holiday” together.

### 5.1.2 Set Time Zone

Go to the stage of (Register=> Schedule=> Time Zones). And the below window appears.

.Input Name and Time Zone. **It can be input 4 times a day ( 0 ~ 23:59 ).**



For easy comprehension, time zone is divided by working group time as like Morning 1 team & 2 team, Afternoon 1 team & 2 team and Night 1 team.

EX) Whole day : 00:00~24:59

Morning 1team working time : 06:00~ 16:00

Morning 2 team working time : 07:00~10:00, 13:00~19:00

For setting value of time zone.

Morning 1 team : 05:00~17:00

Morning 2 team : 06:00~11:00, 12:00~20:00


You should consider of time gap for enter company and leave company around 30 min~1 hour.

### 5.1.3 Set Time Schedule

After set time zone, set weekly time schedule.

"Set every other week" is for fixed day off, it gets an advantage over the Holiday.

"Enroll "Holiday" should be sleeted of Holiday type and time set by time zone.




- Access control time : Please see the above picture. Sunday Night 1 team only can enter the door during set time(19:00~21:00, 22:00~23:59). When worker try to enter except set time(00:00~18:59, 21:01~21:59), access denied with authentication failed message appears
- Set every other week : This function is for company extra settled day off every other week. For example, "A" company is day off 2,4 Saturday. If you want to give value whole day close door, give time value to 00:00~00:01 or 23:58~23:59.
- Enroll Holiday : Please remember Holiday setting and give holiday value. And select one time zone. For example, you want to open only day time during Holiday, set as 10:00~16:00 or just close whole day set as 00:00~00:01 or 10:00~10:01 (Minimum time gap is 1 min)

## 5.2 Transmit Schedule to terminal

For use of Schedule & Role function, all record should be sent to selected terminal as to click the "Download" button of the window to be shown after saving.

The below window automatically appears when all process finished.

Without transmit to terminal, schedule and role functions can't apply.





\* Green Color is DialUp connection terminal.

\* Black Color is TCP/IP and Serial terminal.

### 5.3Role


Select Role and click the right button of mouse as the below picture or go to menu bar of stage (Register=> Role=>New).


First, give Role Name and select on enrolled Schedules of above “OK” button.

Second, Select terminals to be applied.


Third, push “OK” button for saving.

Apply for each user, please select “Enroll role” on process of “Enroll User”





If this user doesn't include any set Role ID, give Role personally.



Check TID and click "OK" button set personal limit.

## 5.4 Schedule control layout

Holiday : 4 different holiday setting

Time Zone : 4 different time zone a day

Time Zone enrolled ID : 32 time zones are possible


Schedule enrolled ID : 32 schedules are possible

You can management various schedule of access control.

## 6. Transmit


### 6.1 Download & Upload

Go to the process of "Transmission" of menu bar. "Download" means " sending data to terminal" and "Upload" means " Get data from terminal".




### 6.1.1 Download User

This is for transmit selected user data to terminal. First, it should select one user to be transmitted.




### 6.1.2 Delete User

This is for deletion of selected user data from terminal. First, it should select one user to be deleted.




### 6.1.3 Download All user

This is for transmit all user data of selected group or company to terminal. First, it should select one group or company to be transmitted.



### 6.1.4 Delete All user

This is for deletion of all user data from terminal.



### 6.1.5 Upload FP and RF

This is for get Fingerprint & EM TYPEdata stored in Terminal.


The data modify by User ID.

### 6.1.6 Download and delete Schedule

Enrolled schedule should transmit to terminal, if not, schedule function not works.

### 6.1.7 Download terminal

This is for checking terminal status.




### 6.1.8 Firmware update

- Supported binary file named “\* \* \*.bin” by Console System, input to “C:/program/Console” folder and run Console Manager. Select “Control-> Update firmware” of tool bar.
- As to show of patch by Console, click it and wait till small window appears.
- Click the message and close the window.
- Please reset the terminal.

## 7 Monitoring

- After install Console Manager, run as to click icon ‘Monitoring’.
- It can real-time monitoring of Lock, case open, exit button door sensor and call button.
- The below part is shown the terminal and log record at real-time.
- When administrator wants to be off the alarm sound, select ‘Alarm’ of menu bar.



## 8 Report

### <How to use Report>

Search a person the following conditions

**Name : John Smith**


**Group : Line 1**

**Date : 6/1/2006 ~ 6/31/2006**

**Time : AM11:00~ PM02:00**

**Terminal : Terminal 004**


**Purpose : John Smith tried to access the terminal 4 for the above time, even though he doesn't be allowed to enter this time by schedule.**



After choose Access Denied of Event section, it is listed many event ID.

**137 Access Denied : Access Control => Denied by schedule and role function**


**146 Access Denied : Lost Card => Denied by lost and stolen card on user information.**




## 8.1 User log data view

User log data view is set as default window.

This is for user event log record by set period as to push "Query" button.




1. Date : Select the period of date and choose the priority query condition on the scroll list.
2. Time period and Terminal : it can make more details of searching under result of ①.
3. Access Event : It can be searched by log event type as Access Granted, Access Denied, Access Unregistered. After done it, select details by granted method.



4. Search : Check the box required conditions of Name, Group and, Employee ID and then input character or number.
5. Data output by Text, Print, Excel : save by text or excel file and print out.

## 8.2 All log data view

If you need the details of records, not only user data, please select “menu=> Log=> All Log data view”




1. Date : Select the period of date and choose the priority query condition on the scroll list.
2. Terminal : Select terminal ID and then click the “Query” button.
3. Event : Door Event – Please choose one main event and you can see the change of scroll menu by your selection. Select sub query condition of scroll bar.
4. Search : input a words or number for searching on the listed data.
5. Data output by Text, Print, Excel : save by text or excel file and print out.

| All Log data View |                        |                     |                        |                                  |                 |                        |
|-------------------|------------------------|---------------------|------------------------|----------------------------------|-----------------|------------------------|
|                   |                        |                     |                        |                                  |                 |                        |
|                   |                        |                     |                        |                                  |                 |                        |
|                   |                        |                     |                        |                                  |                 |                        |
|                   |                        |                     |                        |                                  |                 |                        |
| 1                 |                        |                     |                        |                                  |                 |                        |
| 2                 |                        |                     |                        |                                  |                 |                        |
| 3                 |                        |                     |                        |                                  |                 |                        |
| 4                 |                        |                     |                        |                                  |                 |                        |
| 5                 | <b>UserID/classify</b> | <b>TID/classify</b> | <b>Terminal Time</b>   | <b>Event</b>                     | <b>SerialNo</b> | <b>Server Time</b>     |
| 6                 | 03,001                 |                     | 2004-06-03 PM 3:00:15  | Normal Unlocked: Request To Exit | 314             | 2004-06-03 PM 2:59:30  |
| 7                 | 03,001                 |                     | 2004-06-03 PM 4:01:17  | Normal Unlocked: Request To Exit | 320             | 2004-06-03 PM 4:00:31  |
| 8                 | 03,001                 |                     | 2004-06-04 PM 5:23:56  | Normal Unlocked: Request To Exit | 377             | 2004-06-04 PM 5:23:09  |
| 9                 | 03,001                 |                     | 2004-06-01 AM 11:41:59 | Normal Unlocked: Request To Exit | 231             | 2004-06-01 PM 1:02:57  |
| 10                | 03,001                 |                     | 2004-06-01 PM 2:54:43  | Normal Unlocked: Request To Exit | 234             | 2004-06-01 PM 2:54:01  |
| 11                | d10                    | 03,001              | 2004-06-02 PM 12:38:37 | Normal Unlocked: Access Granted  | 268             | 2004-06-02 PM 12:37:53 |
| 12                | d10                    | 03,001              | 2004-06-03 PM 8:28:57  | Normal Unlocked: Access Granted  | 348             | 2004-06-03 PM 8:28:10  |
| 13                | d10                    | 03,001              | 2004-06-05 PM 4:46:58  | Normal Unlocked: Access Granted  | 444             | 2004-06-09 PM 4:20:16  |
| 14                | d10                    | 03,001              | 2004-06-05 PM 4:53:46  | Normal Unlocked: Access Granted  | 447             | 2004-06-09 PM 4:20:16  |
| 15                | d10                    | 03,001              | 2004-06-02 AM 11:33:54 | Normal Unlocked: Access Granted  | 262             | 2004-06-02 AM 11:33:10 |
| 16                | d10                    | 03,001              | 2004-06-03 PM 5:43:49  | Normal Unlocked: Access Granted  | 334             | 2004-06-03 PM 5:43:03  |
| 17                | d10                    | 03,001              | 2004-06-05 AM 11:39:08 | Normal Unlocked: Access Granted  | 407             | 2004-06-09 PM 4:20:15  |
| 18                | d11                    | 03,001              | 2004-06-05 PM 6:25:33  | Normal Unlocked: Access Granted  | 471             | 2004-06-09 PM 4:20:16  |
| 19                | d11                    | 03,001              | 2004-06-05 PM 6:25:13  | Normal Unlocked: Access Granted  | 465             | 2004-06-09 PM 4:20:16  |
| 20                | d11                    | 03,001              | 2004-06-05 PM 6:25:01  | Normal Unlocked: Access Granted  | 462             | 2004-06-09 PM 4:20:16  |
| 21                | d11                    | 03,001              | 2004-06-05 PM 6:26:09  | Normal Unlocked: Access Granted  | 481             | 2004-06-09 PM 4:20:16  |
| 22                | d11                    | 03,001              | 2004-06-05 PM 6:24:42  | Normal Unlocked: Access Granted  | 459             | 2004-06-09 PM 4:20:16  |
| 23                | d17                    | 03,001              | 2004-06-03 PM 9:02:34  | Normal Unlocked: Access Granted  | 351             | 2004-06-04 AM 9:41:25  |
| 24                | d17                    | 03,001              | 2004-06-05 PM 1:20:30  | Normal Unlocked: Access Granted  | 438             | 2004-06-09 PM 4:20:16  |
| 25                | d17                    | 03,001              | 2004-06-05 PM 6:28:48  | Normal Unlocked: Access Granted  | 485             | 2004-06-09 PM 4:20:17  |
| 26                | d17                    | 03,001              | 2004-06-05 PM 6:25:46  | Normal Unlocked: Access Granted  | 477             | 2004-06-09 PM 4:20:16  |
| 27                | d17                    | 03,001              | 2004-06-05 PM 6:25:39  | Normal Unlocked: Access Granted  | 474             | 2004-06-09 PM 4:20:16  |
| 28                | d17                    | 03,001              | 2004-06-05 PM 5:14:43  | Normal Unlocked: Access Granted  | 450             | 2004-06-09 PM 4:20:16  |
| 29                | d17                    | 03,001              | 2004-06-04 PM 9:51:52  | Normal Unlocked: Access Granted  | 389             | 2004-06-09 PM 4:20:15  |
| 30                | d17                    | 03,001              | 2004-06-03 PM 6:55:28  | Normal Unlocked: Access Granted  | 340             | 2004-06-03 PM 6:54:42  |
| 31                | d17                    | 03,001              | 2004-06-05 PM 6:25:19  | Normal Unlocked: Access Granted  | 468             | 2004-06-09 PM 4:20:16  |

## 9. Time & Attendance

### 9.1 Enter T&A


After push T&A icon on the menu bar, the below window appears.



When “Attendance Utilities” is shown, click the Path icon of window. And set the data path as like below

- ATTBio =>C:\Program Files\Console DataBase\ATTDB.mdb
- 4800D =>C:\Program Files\Console DataBase\4800D.mdb

You can see that both ATTBio and 4800D paths are automatically set like below.




**Input Company name** and click “OK” button and close the window.

Set “Date Type”

It should be set the same as the window date format on the control panel of Window system as below.


Go to control panel => Regional and Language




Go to Regional Option => Short date

Short Date : 24/10/2005

Date type : DD/MM/YYYY





It should be selected the same date format as the window system and then click "OK" button.



Short Date : 10/24/2005

Date type : MM/DD/YYYY



After All value is set correctly, click "OK" button for saving this setting value.

## 9.2 Set T&A condition

### < How to set Time and Attendance condition >

\*Name : John Smith

\*Work Type

- 1<sup>st</sup> & 3<sup>rd</sup> week : Day work(09:00~18:00)  
Saturday (09:00~14:00)
- 2<sup>nd</sup> & 4<sup>th</sup> week : Night work(14:00~23:00)

\*Over time : Allowed over one hour than working time zone

Not allowed over 3 hours a day


\*Deduction : Being late than working time zone

Minus 30 minutes(Break time) a day


\*Holiday : All Sunday

Go to the "std time" tab for setting working time.

### < Day work >



**<Night Work>**




**Please do not use 24:00 or 00:00 behind mis-calculation of working period of time.  
For correct calculation, must be checked at “Apply night time” for over 24 hour time line.**

**Go to the “enroll day off” tab for holiday enrollment.**

**<Holiday>**

**Click each Sunday and click the “enroll” button.**




Go to the “Schedules” tab for making monthly schedule.

Make schedules 1&3<sup>rd</sup> week is applied to “01” and 2&3<sup>rd</sup> week is applied to “02” and then click “Store” button.




Applies to “User information => EM TYPEinfo tab => T/A Work type => Select T&A Schedule ID”.



### 8.2.1 Data path

Select data path for Time & Attendance data.




- ATTBio : DB for T&A data
- 4800D : Log record DB. This data transforms to T&A data.

### 9.2.2 Standard time

Standard time is set 24 hours from input time. For example, when input 20:00, it calculates 20:00~19:59(Next day) is one day for night workers.

- Input name of work type
- Input standard time and settled work time.
- Set overtime duty and if work time is belong 2 days, please check “Apply night time”.
- Apply overtime duty on day off : if works on Holiday, it becomes same as overtime duty.
- Overtime duty per day : if company policy has limited overtime a day, only input time can be calculated for authorized overtime.
- Apply deduction : input late attend and Early left for minus of working time. If work time is belong 2 days, please check “Apply night time”.
- If company policy has settled deduction time for purpose of lunch time, rest time etc.., input time for minus.



**Work type** : Divide working group by different time schedule.

① Work time

- **Std day work time** – for example, working time is 20:00 ~ next day 05:00, normally it divided 2 days. But when Std day work time is set as 19:00, one day is from 19:00~18:59. This is for normally use for night worker over two days.
- **Weekday** – this is for working time
- **Saturday** – this is for working time on Saturday only.

② Set overtime duty


- **Early attend** – For example, working time starts 08:00 and set Early attend 07:00. if worker starts work from 06:00, company accept overtime. If worker starts work from 20:10, company don't accept overtime as the applied over time is earlier than 20:00.
- **Overtime** – For example, working time finishes 06:00 and set Over time 07:00. If worker does till 08:00, company accepts the overtime for two hours. If worker finishes at 06:30, company don't accept overtime as the applied over time is later than 07:00.
- **Apply night time** – Do not check it for normal working time, Please check the next page for the detail description.
- **Apply overtime duty on day off** : If company applies overtime for work on Holiday, check it.

③ Apply deduction

- **Apply deduction** : this is minus of working time.
- **Late attend** – For example, work starts 21:00, and set late attend as 21:30. A worker starts work from 21:45, it marks to late attendance and minus from work time
- **Early left** – For example, work finish 07:00, and set Early left as 06:30, A worker leaves earlier than 06:30, it marks to early left and minus from work time
- **Apply night time** – it must check for over two days night time working type. If not, it doesn't apply to one day.
- **Always** – If company wants to minus appointed time, ( this is special function and normally use for government employee ) check and input time to be deduction. For example, company input 01:00 Applied and the total working time is 10 hours. T&A data calculates working time is 9 hours for the deduction function.

④ Apply deduction

- **Overtime duty per day** : If company has a rule of the limited overtime, please check it. For example A company only accept 4 hours overtime per day Even though A worker did 5 hours overtime, the T&A data is calculated only 4 hours overtime.



### 1. Apply night time

Working time : 22:00 ~ 06:00

Over time : From 07:00

When working time over the 24 hours like above time setting, Check "Apply night time".

### 2. Apply night time

Working time : 22:00 ~ 06:00

Over time : From 07:00

When working time over the 24 hours like above time setting, Check "Apply night time".

### 3. Always

If the company has special deduction time on working time like lunch time, break time etc., Check it and input the deduction time from the total working time.

For example

Always : 00:30

Total working time ( including overtime ) : 09:00


Calculated working time : 08:30

So this function is used for special company payment policy.

### 9.2.3 Holiday

Please enroll Holiday separately to Schedule Holiday.

Schedule Holiday and T&A Holiday have no connection, please enroll it by purpose.



### 9.2.3 Schedule

Manage monthly T&A schedule selected by “Work Type” ID listed on scroll menu.

**Set T/A condition**

**ATTBio**  
**Time Configuration**

**Schedules**      **Std time**      **Enroll others**

**Schedul ID** **01** **January** **Edit** **Store**

|    |    |    |    |    |    |    |
|----|----|----|----|----|----|----|
| 1  | 2  | 3  | 4  | 5  | 6  | 7  |
| 01 | 01 | 01 | 01 | 01 | 01 | 01 |
| 8  | 9  | 10 | 11 | 12 | 13 | 14 |
| 01 | 01 | 01 | 01 | 01 | 01 | 01 |
| 15 | 16 | 17 | 18 | 19 | 20 | 21 |
| 01 | 01 | 01 | 01 | 01 | 01 | 01 |
| 22 | 23 | 01 | 25 | 26 | 27 | 28 |
| 01 | 01 | 02 | 01 | 01 | 01 | 01 |
| 29 | 30 | 31 | 01 | 01 | 01 | 01 |
| 01 | 01 | 01 |    |    |    |    |

**User\_Schedules**

### 9.2.4 Enroll others

Temporary worker position and set trans-out depart.

Temporary worker : If company policy has special condition for temporary workers as limit overtime, please input the condition.


Transferred to other department : It should set Trans-out Department for keeping previous record.

Without it, previous record before moving out will be deleted.


When department movement happens, please give another User ID for preventing from confusion.

For making this group, please see the 4.2 Enroll group (P17).

**\* All time is set as “ yyyy-MM-dd ”. For using T&A software, you must change the date type on PC and then operate transform data in next step.**



Enrolled Work type Number can apply when user enrollment to select suitable Work type No. When transform to T/A data, the user is calculated automatically by condition of Work type you set. If it's not selected, T&A data can't be applied.



### 9.3Trans T&A data

After saving all T&A condition, push “Trans T/A data”. Select period and push “Run” button.



### 9.4Query T&A

It can be shown by Daily, personal and Period condition.

### 9.4.1 Daily

After input query date and sub conditions, queried data appears.

It's possible to Edit, transform to Excel and Print out.

Query T/A

ATTBio  
Data ListView

**Daily**

**Personal**

**Period**

| Date       | Depart            | Work | Position    | Name        | Classify | Attend             | Leaving            | Late  | Early left | Overtime | ComID    |
|------------|-------------------|------|-------------|-------------|----------|--------------------|--------------------|-------|------------|----------|----------|
| 2004-06-01 | IT strategic team | 01   | Staff       | Park Dain   | Absence  | _____              | _____              | _____ | _____      | _____    | 30204013 |
| 2004-06-01 | IT strategic team | 01   | Section ch  | Kim sunho   | Absence  | _____              | _____              | _____ | _____      | _____    | 20104015 |
| 2004-06-01 | IT strategic team | 01   | assistant d | Choi hin    | Weekday  | 2004-06-01 (08:35) | 2004-06-01 (10:00) | _____ | _____      | _____    | 20104012 |
| 2004-06-01 | IT strategic team | 01   | Action sec  | Kim Sangmi  | Weekday  | 2004-06-01 (08:56) | 2004-06-01 (19:15) | _____ | _____      | _____    | 20101012 |
| 2004-06-01 | IT strategic team | 01   | Section ch  | An Sangsu   | Absence  | _____              | _____              | _____ | _____      | _____    | 20008001 |
| 2004-06-01 | IT strategic team | 01   | Section ch  | Antaksung   | Weekday  | 2004-06-01 (08:40) | 2004-06-01 (18:35) | _____ | _____      | _____    | 20002020 |
| 2004-06-01 | IT strategic team | 01   | Action sec  | Choi jongha | Weekday  | 2004-06-01 (08:01) | 2004-06-01 (20:05) | _____ | _____      | _____    | 20101009 |
| 2004-06-01 | IT strategic team | 01   | Staff       | Kim sunga   | Absence  | _____              | _____              | _____ | _____      | _____    | 19905092 |

**Query condit** Depart 

All  Overtime only  Trans-out only

**Query**

**Case by case**

IT strategic   
  


**Edit/store**

Attend 2004-06-01 (08:56)  
Leaving 2004-06-01 (19:15)  
Classify Weekday 

**Overtime**

Late   
Early left   
Overtime 

**Print**  Print  Excel

\* Edit/Store section

Administrator can be edited the data by "Edit/Store section" and then click the "Store" button for saving.

## 9.4.2 Personal

After input query date and sub conditions, personal queried data appears.

It's possible to Edit, transform to Excel and Print out.

Query T/A

ATTBio Data ListView

Daily Personal Period

Date: 2004-06-01 ~ 2004-06-16 Trans/Query

Search person

Search (All, Include trans-out) Query condit (Depart) Depart

Case by case (IT strategic, Search depart, Search name, Search C-ID) Query

Name: Antaksung

Depart: IT strategic tea

Position: Section chief

Com No: 20002020

Sum late time: 0

Sum early left: 0

Sum overtime: 0

Sum after deduct: 0

Print, Excel, Emplo No

| Date       | Classify | Work | Attend             | Leaving            | Late | Early left | Overtime |
|------------|----------|------|--------------------|--------------------|------|------------|----------|
| 2004-06-01 | Weekday  | 01   | 2004-06-01 (08:40) | 2004-06-01 (18:35) |      |            |          |
| 2004-06-02 | Weekday  | 01   | 2004-06-02 (08:55) | 2004-06-02 (18:20) |      |            |          |
| 2004-06-03 | Weekday  | 01   | 2004-06-03 (08:45) | 2004-06-03 (20:08) |      |            |          |
| 2004-06-04 | Weekday  | 01   | 2004-06-04 (08:28) | 2004-06-04 (18:15) |      |            |          |
| 2004-06-05 | Weekday  | 01   | 2004-06-05 (08:49) | 2004-06-05 (13:16) |      |            |          |
| 2004-06-06 | Holiday  | 01   |                    |                    |      |            |          |
| 2004-06-07 | Absence  | 01   |                    |                    |      |            |          |
| 2004-06-08 | Absence  | 01   |                    |                    |      |            |          |
| 2004-06-09 | Absence  | 01   |                    |                    |      |            |          |
| 2004-06-10 | Absence  | 01   |                    |                    |      |            |          |
| 2004-06-11 | Absence  | 01   |                    |                    |      |            |          |
| 2004-06-12 | Absence  | 01   |                    |                    |      |            |          |
| 2004-06-13 | Holiday  | 01   |                    |                    |      |            |          |
| 2004-06-14 | Absence  | 01   |                    |                    |      |            |          |
| 2004-06-15 | Absence  | 01   |                    |                    |      |            |          |
| 2004-06-16 | Absence  | 01   |                    |                    |      |            |          |

## 9.4.3 Period

After input query date and sub conditions, queried data appears.

It's possible to Edit, transform to Excel and Print out.

Query T/A

ATTBio Data ListView

Daily Personal Period

Date: 2004-06-01 ~ 2004-06-07

Include trans-out Data trans/query

Query condit (Depart) Depart Query

Case by case (Financial Mar) Search


Trans done

| ComID    | Depart         | Position     | Name         | Std | Ovver. T P | Sum Time | Count Time | Sum late | Count late | Sum early | Count early | Sum deduct |
|----------|----------------|--------------|--------------|-----|------------|----------|------------|----------|------------|-----------|-------------|------------|
| 12345    | Financial Mana | Staff        | James Li     | 15  | 0          | 15       | 0          | 0        | 0          | 0         | 0           | 15         |
| 18902045 | Financial Mana | in section c | Youn         | 15  | 0          | 15       | 0          | 0        | 0          | 0         | 0           | 15         |
| 20001039 | Financial Mana | in section c | Yang Dongbin | 15  | 0          | 15       | 0          | 0        | 0          | 0         | 0           | 15         |
| 20106036 | Financial Mana | Staff        | Yu suyoung   | 15  | 0          | 15       | 0          | 0        | 0          | 0         | 0           | 15         |
| 20112069 | Financial Mana | Section chie | Kim Minsung  | 15  | 0          | 15       | 0          | 0        | 0          | 0         | 0           | 15         |
| 20112138 | Financial Mana | Section chie | Kim hyungjoo | 15  | 0          | 15       | 0          | 0        | 0          | 0         | 0           | 15         |
| 21443134 | Financial Mana | Staff        | Seo          | 15  | 0          | 15       | 0          | 0        | 0          | 0         | 0           | 15         |
| 3431413  | Financial Mana | Staff        | Kim John     | 15  | 0          | 15       | 0          | 0        | 0          | 0         | 0           | 15         |


## 10. Other function

### 10.1 Check enrolled user of terminal

Click the mouse of right button at the position of below image.



After select terminal, push "OK" button and enrollment status appears.




## 10.2 Database Utility

This is for optimize database or backup when database files up.

Go to at stage of (Menu bar=> File=> Database=> Data utility).

Before process, all run operation should be closed.



## 10.3 Door open


When visitor call, select the terminal to be opened and push "Open" button.

Go to the stage of (Menu bar=> Control=> Door open)



## 10.4 Change window structure


For change main window structure of Console Manager, double click the outline of window and it separated.



## 10.5 Sliding Message on LCD


This method is for input sliding message as you want to display. It can input to 150 characters only.

Go to Transmission => Download Message => New window appears.



Input message in yellow table within 150 letters. Select terminal and click Download button.

**When you reset or power off of terminal, the message is deleted.**



# BKS-4800 Device Manual



Nov. - 2007



## Table of Contents

|          |  |  |
|----------|--|--|
| <b>5</b> | <b>Introduction</b>                    | -----  |
|          | 4                                      | -  |
| <b>6</b> | <b>Feature</b>                         | -----  |
|          | -- 4                                   | -  |
|          | <b>6.4 Characteristics</b>             | - 4 -  |
|          | <b>2.1.5</b>                           | Level up the security reliability - 4 -                    |
|          | <b>2.1.6</b>                           | Reliable and stable algorithm - 5 -                        |
|          | <b>2.1.7</b>                           | Entrance security - 5 -                                    |
|          | <b>2.1.8</b>                           | Function keys and log records - 8 -                        |
|          | <b>2.1.9</b>                           | Low system maintenance cost - 102 -                        |
|          | <b>2.1.10</b>                          | Control the large number of terminal by one system - 102 - |
|          | <b>6.5 Support functions</b>           | - 9 -  |
|          | <b>6.6 Specification</b>               | - 16 -   |
|          | <b>6.6.1</b>                           | LCD Display - 104 -  |
|          | <b>6.6.2</b>                           | Keypad Instruction - 105 -                                 |
| <b>7</b> | <b>Registration, Edition, Deletion</b> | -----  |
|          | -- 17                                  | -  |
|          | <b>3.2 How to register</b>             | - 17 -   |
|          | <b>3.3.1</b>                           | Fingerprint registration - 106 -                           |
|          | <b>3.3.2</b>                           | EM TYPECard registration - 106 -                           |
|          | <b>3.3.3</b>                           | Password registration - 107 -                              |
|          | <b>3.3.4</b>                           | EM TYPECard + Fingerprint - 108 -                          |
|          | <b>3.3.5</b>                           | EM TYPEcard + Password - 108 -                             |
|          | <b>3.3.6</b>                           | Selective authentication method - 109 -                    |
|          | <b>3.3.7</b>                           | Set personal security level - 109 -                        |
|          | <b>3.4 How to edit</b>                 | - 18 -   |
|          | <b>3.4.1</b>                           | Search for editorial ID - 109 -                            |
|          | <b>3.4.2</b>                           | Change to authentication method - 110 -                    |
|          | <b>3.5 How to delete</b>               | - 36 -   |
|          | <b>3.5.1</b>                           | Delete user - 110 -  |
|          | <b>3.5.2</b>                           | Delete All - 111 -   |
| <b>8</b> | <b>Use &amp; Authentication method</b> | -----  |

|             |   |
|-------------|---|
| 37 -        |   |
| <b>5.5</b>  | Fingerprint user - 37 -                                       |
| <b>5.6</b>  | EM TYPEcard user - 38 -                                       |
| <b>5.7</b>  | Password user - 39 -  |
| <b>5.8</b>  | EM TYPEcard + Fingerprint, EM TYPEcard + Password user - 40 - |
| <b>5.9</b>  | Selectable authentication method user - 113 -                 |
| <b>6</b>    | <b>Free scan and Grouping</b> -----                           |
|             | 45 -  |
| <b>6.5</b>  | Free scan authentication - 55 -                               |
| <b>6.6</b>  | Grouping - 59 -   |
| <b>7</b>    | <b>Terminal registration</b> -----                            |
|             | 63 -  |
| <b>7.2</b>  | <b>Setting the terminal ID</b> - 63 -                         |
| <b>7.3</b>  | <b>Setting network mode upon transmission methods</b> - 114 - |
|             | <b>7.3.1</b> Serial, Dial-Up - 114 -                          |
|             | <b>7.3.2</b> Dial-Up - 115 -                                  |
|             | <b>7.3.3</b> TCP/IP - 115 -                                   |
| <b>7.4</b>  | <b>Setting date and time</b> - 3 -                            |
| <b>8</b>    | <b>The other functions</b> -----                              |
|             | 66 -  |
| <b>7.1</b>  | setting security level - 117 -                                |
| <b>7.2</b>  | Tunes locking time of door - 117 -                            |
| <b>7.3</b>  | Checks all registered user - 118 -                            |
| <b>7.4</b>  | Checks all registered ID - 118 -                              |
| <b>7.5</b>  | Change administrator password - 118 -                         |
| <b>7.6</b>  | Change administrator fingerprint - 118 -                      |
| <b>7.7</b>  | Description of button - 119 -                                 |
| <b>7.8</b>  | Change operations of authentication methods - 119 -           |
| <b>7.9</b>  | Set LCD Back light time - 119 -                               |
| <b>7.10</b> | Exposure - 120 -  |
| <b>7.11</b> | LCD contrast - 121 -  |
| <b>7.12</b> | LCD brightness - 121 -  |
| <b>7.13</b> | Time & Attendance setting - 122 -                             |
| <b>7.14</b> | Mask Event & Delete Event - 124 -                             |
| <b>8</b>    | <b>Tips on cautions use</b> ----- 67 -                        |
| <b>8.1</b>  | First setting in initial use - 69 -                           |

|              |   |         |
|--------------|---|---------|
| <b>8.2</b>   | Incase of fingerprint hard to be processed                    | - 70 -  |
| <b>8.3</b>   | Reset BKS-4800 and back to setting status before latest trial | - 125 - |
| <b>8.4</b>   | Right fingerprint registration position                       | - 125 - |
| <b>9</b>     | <b>Specifications</b>   |         |
|              | - 72 -  |         |
| <b>8.3</b>   | Configuration   | - 72 -  |
| <b>8.4</b>   | Power   | - 78 -  |
| <b>8.5</b>   | Environment   | - 90 -  |
| <b>8.6</b>   | Communication Interface                                       | - 90 -  |
| <b>8.7</b>   | Relay   | - 126 - |
| <b>8.8</b>   | Fingerprint storage   | - 127 - |
| <b>8.9</b>   | Log records   | - 127 - |
| <b>8.10</b>  | Dimension   | - 127 - |
| <b>8.11</b>  | Weight  | - 127 - |
| <b>8.12</b>  | Authentication speed  | - 127 - |
| <b>8.13</b>  | FRR(fault rejection rate)                                     | - 127 - |
| <b>8.14</b>  | FAR(fault acceptance rate)                                    | - 127 - |
| <b>8.15</b>  | Fingerprint data  | - 127 - |
| <b>8.16</b>  | Sensor resolution   | - 127 - |
| <b>10</b>    | <b>Hardware(main board)</b>                                   |         |
|              | 93 -  |         |
| <b>9.5</b>   | Connector description   | - 93 -  |
| <b>11</b>    | <b>Application example</b>                                    |         |
|              | 131 -   |         |
| <b>10.6</b>  | Standalone  | - 131 - |
| <b>10.7</b>  | PC-RS232  | - 134 - |
| <b>10.8</b>  | PC-TCP/IP   | - 137 - |
| <b>10.9</b>  | PC-RS485  | 140     |
| <b>10.10</b> | PC-Modem  | 144     |
| <b>10.11</b> | EM TYPEModule connection                                      | 144     |

## About BKS-4800 Series

**Creative Vision Electronics'** 3<sup>rd</sup> generation biometric Access control system, the BKS-4800, offers superior technology with a competitive price point. The BKS-4800 can be installed as pure standalone or IP integrated system. The simplicity of working inside today's standards of IP connectivity and Microsoft Access as the database give you and your installation an advanced security product that is easy to manage.

BKS-4800 provides an ultimate biometric access control solution for an employer, whose main concern is to controlling of any unauthorized personnel's entry to a secured area and to automatically manage employees' access activities (ins & outs of certain premises) as well as other payroll-related information for any hourly employee (absences, late for work, lunch hour, holidays, overtime, special holidays work, etc.). BKS-4800, the fingerprint solution, can eliminate the current problems of EM TYPEcards and keypad access control systems, which are prone to a several security breaches (card duplication, loss of card, sharing of card or password).

BKS-4800 relies on a new optical sensor which enables us to decrease the cost of BKS-4800 as well as to allow the unit to be more accurate and reliable. BKS-4800 supports various I/O protocols and is an optimal solution for managing access-controlled points. With 128 X 64 pixels blue LCD screen, 12 regular keys and 5 special function keys, make BKS-4800 more user-friendly than our competitors' products. Communication are based on TCP/IP, RS232, RS485, 1 relay signal and 1 external sensor inputs.

## 5. Features

### Characteristics

#### **Level up the security reliability**

Existing security measures such as security card systems and keypad systems are prone to breach by unauthorized persons through card-duplication or disclosure of set security code. Fingerprint ID system can truly restrict security access only to those authorized persons.

#### **Reliable and stable algorithm**

BIOINSEC utilizes its own proprietary algorithm with an outstanding match process and security.

### **Entrance security : Access control, time & attendance, over-time management and other applications**

Fingerprint ID system allows for management of entrance security, work place time and attendance, and over-time work. Also, situations that require the presence of the authorized persons at a secured point can take advantage of our fingerprint ID system.

#### **Function keys and log records.**

Four programmable function keys may be used to manage time and attendance. A single terminal can be adapted to manage many different kinds of work involving site security control and time and attendance.

#### **Low system maintenance cost**

Existing ID cards require new issuance of cards with addition of new users and loss of cards. This becomes unnecessary with fingerprint ID system. System maintenance cost can be lowered to negligible levels when compared to other solutions.

#### **Control the large number of terminal by one system.**

Our fingerprint ID system module may be used as stand-alone units to control entrance traffic or in multiple module configurations utilizing TCP/IP/RS232/RS485/Modem protocol to connect with server. Also, direct connection to program wants to use through bundled SDK. Because BKS-4800 module contain RTC and log management capabilities (up to 10,000 records), entrance security and other event management are possible without an ACU.

#### **Support functions**

- User management
  - Register a user(RF, fingerprint, password)
  - Delete a user or all users
  - Query about registered user number( Console Manager )
  - Query about maximum registerable user number
  - Query about ID allocation( Console Manager )
  - Set a user's time zone
  - View or receive registered ID list( Console Manager )

- Transmit user's data in the terminal( Console Manager )
- System management
  - Configure and read terminal's time and date
  - Change and read security level
  - Change Terminal ID
  - Configure communication mode(TCP/IP, Serial, Dial-up)
  - Serial - Change communication speed
  - Receive firmware version( Console Manager )
  - Change lock operating time
  - Disable/enable free scan mode
- Door mode
  - Configure and read door mode (normal/ forced open/ forced close) and time( Console Manager )
- Log
  - Transmit the log record to server in real-time ( Console Manager )
  - Log data contains the function key, entrance time, user ID( Console Manager )
  - Query log count( Console Manager )
  - Delete all log( Console Manager )
- Authentication
  - Authentication at the terminal( 1 : 1, 1 : N )
  - Various authentication methods(RF, Password, Fingerprint, RF+FP, RF+PIN)
- Auxiliary function
  - Exit button
  - Relay out(Lock driver)
  - Transmit the case status
  - Support voice message
  - Transmit door switch status
  - Visible a condition of relay icon
  - Visible a condition of Network icon

## Specification

### Model number

| Model            | Description   |
|------------------|---|
| <b>BKS-4800</b>  | Fingerprint Access Control and Time/Attendance Management Terminal                            |
| <b>BKS-4800M</b> | Fingerprint Access Control with Mifare card(13.56Mhz) and Time/Attendance Management Terminal |
| <b>BKS-4800E</b> | Fingerprint Access Control with EM card(125Khz) and Time/Attendance Management Terminal       |

### Common Specification

| Features                      | Specification  |
|-------------------------------|--|
| <b>CPU</b>                    | Samsung ARM9 32bit Micro processor                               |
| <b>Memory</b>                 | SDROM 128Mb, NAND FROM 64Mb                                      |
| <b>LCD</b>                    | 128 x 64 pixels, Blue LED 4lines                                 |
| <b>Sensor</b>                 | Optic, 500 DPI   |
| <b>1:1 matching</b>           | Speed: Less than 1 sec<br>Storage : 5,000 User (Finger+RF+PW)    |
| <b>1:N matching(freescan)</b> | Speed : Less than 2.5 sec<br>Storage : 1,000 User (Finger+RF+PW) |
| <b>Size</b>                   | (H)95mm X (L)300mm X (D)35mm                                     |
| <b>Fingerprint Data Size</b>  | 512 Byte   |
| <b>Power</b>                  | DC 12V (provided)  |
| <b>IN/OUT Port</b>            | Exit S/W, Door open sensor, Lock controller                      |
| <b>Protocol</b>               | TCP/IP(10/100BT), Serial (RS232, RS485), Dial-Up                 |
| <b>Language/Voice</b>         | English  |
| <b>Option</b>                 | Mifare Card, EM Card   |

### LCD display

● **Function Key** : F1, F2, F3, F4

● **Door Status** :  =>Door closed  =>Door opened

● **Network Connection** :

- TCP/IP : =>Connected =>Disconnected
- Serial : =>Connected =>Disconnected
- Dial-Up : =>Modem connected(ready to call)  
=>Modem connection failed, Check the connection of the modem and BKS-4800  
=>calling  
=>line is connected, Data transmission

### Keypad Instruction



- Enter to Admin menu : 0 + <→

### Hardware Instruction

## 6. Registration, Edition, Deletion

### How to register

Administrator menu allows new user registration, edition, deletion and system setup.

Press "Menu" button enters the administrator mode and press '1111'.

The initial system password is set as '1111'.

### <Useful description of button>

Arrow key (▲ ▼) : curser scroll down or up

"<→" button: confirm the selection mode and get into the lower menu stage and saved.

“CLR” button: move to the upper menu stage without saving.


“\*” button : 1) in grouping mode to mark all figures in the other place of ID number, 2) browse all user list 3) mark & delete check (✓) and “.” When input IP address at network mode.

#### < How to enter Menu >

Push “0” and “<” button and input ‘1111’ as the initial set value.

First, follow the process “1.User => 1.New User” and “Enter User ID.” message appears.

If entered ID is in use already, “User ID Overlapped” message appears.




#### Fingerprint registration

Fingerprint registration

For registering a fingerprint, place the finger on the red lighting sensor after push “3.FP1”.

The registration can be completely done as to press “1.Save & Exit” to save and back to upper menu stage automatically.

If you want to improve the authentication rate or register another finger for convenience, push “2.FP2” and keep the same process as “1.FP” registration.




.Asterisk (\*) appears in the right of menu by saving.

#### EM TYPECard Registration (Optional function.)

First, select “5. Card” for EM TYPECard registration and “Touch Your Card” message appears.


After close EM TYPECard registered, disclose EM TYPECard after “buzzer” sound.

When “One More Time Please!” message appears, repeat again with same EM TYPECard.



Second, For run EM TYPEcard authentication, follow the process “ 2.Access Mode=>2.Card” with tick mark(✓) by pushing “\*” button or corresponding number.

Back to upper menu stage for saving by pushing “1.Save & Exit”.



### Password registration


First, select “3. PIN” for password registration and “Enter Password.” message appears.

Enter the 4~8 digit password to be registered.

When “One More Time Please!” message appears, repeat again with same password.

When the two entered passwords do not match, “Sorry! Data Mismatched” message is displayed.

After confirming the password, select “1.Save & Exit” to be successfully registered.



Second, For run the password authentication, follow the process “ 2.Access Mode=>3.PIN” with tick mark(✓) by pushing “\*” button or number “3”.

Back to upper menu stage for saving by pushing “1.Save & Exit”.

|   |
|---|
| <b>ID : No.</b>   |
| 1. Save & Exit<br>2. Access Mode<br>3. FP1<br>4. FP2<br>5. Card<br>6. PIN |

|   |
|---|
| <b>ID : No.</b>   |
| <input type="checkbox"/> 1. FP<br><input type="checkbox"/> 2. Card<br><input checked="" type="checkbox"/> 3. PIN<br><input type="checkbox"/> 4. Card+FP<br><input type="checkbox"/> 5. Card+PIN |

|  |
|--|
| <b>ID : No.</b>  |
| 1. Save & Exit<br>2. Access Mode<br>3. FP1<br>4. FP2<br>5. Card<br>6. PIN* |

### Card +FP

It's applied for the user wants to use EM TYPEcard instead of ID or the high security level as it must be matched EM TYPEcard and Fingerprint together.

First, for registering a fingerprint and EM TYPEcard, select and register "3.FP1" and "5.Card" as the same process of "3-1-1" "3-1-2".

Second, For run the this authentication method, follow the process " 2.Access Mode=>4.Card +FP" with tick mark(√) by pushing "\*" button or number "4".

Back to upper menu stage for saving by pushing "1.Save & Exit".

|   |
|---|
| <b>ID : No.</b>   |
| 1. Save & Exit<br>2. Access Mode<br>3. FP1*<br>4. FP2<br>5. Card*<br>6. PIN |

|   |
|---|
| <b>ID : No.</b>   |
| 1. Save & Exit<br>2. Access Mode<br>3. FP1<br>4. FP2<br>5. Card<br>6. PIN |

|   |
|---|
| <b>ID : No.</b>   |
| <input type="checkbox"/> 1. FP<br><input type="checkbox"/> 2. Card<br><input checked="" type="checkbox"/> 3. PIN<br><input type="checkbox"/> 4. Card+FP<br><input type="checkbox"/> 5. Card+PIN |

### Card + Password

It's applied for the user wants to use "EM TYPEcard instead of ID+ Password" or the high security level as it must be matched EM TYPEcard and Password together.

First, for registering a fingerprint and Password, select and register "5.Card" and "6.PIN" as the same process of "3-1-2" "3-1-3".

Second, For run the this authentication method, follow the process " 2.Access Mode=>5.Card +PIN" with tick mark(√) by pushing "\*" button or number "5".

Back to upper menu stage for saving by pushing "1.Save & Exit".

|   |
|---|
| <b>ID : No.</b>   |
| 1. Save & Exit<br>2. Access Mode<br>3. FP1<br>4. FP2<br>5. Card*<br>6. PIN* |

|   |
|---|
| <b>ID : No.</b>   |
| 1. Save & Exit<br>2. Access Mode<br>3. FP1<br>4. FP2<br>5. Card<br>6. PIN |

|   |
|---|
| <b>ID : No.</b>   |
| <input type="checkbox"/> 1. FP<br><input type="checkbox"/> 2. Card<br><input type="checkbox"/> 3. PIN<br><input type="checkbox"/> 4. Card+FP<br><input checked="" type="checkbox"/> 5. Card+PIN |

### Selective authentication method

If you want to choose one authentication method of all registered methods.

First, register all methods want to be used, and then

Select “2.Accss mode” and then choose required numbers with the tick mark(√).

Back to upper menu stage for saving by pushing “1.Save & Exit”.

|   |
|---|
| <b>ID : No.</b>   |
| 1. Save & Exit<br>2. Access Mode<br>3. FP1*<br>4. FP2*<br>5. Card*<br>6. PIN* |

|  |
|--|
| <b>ID : No.</b>  |
| <input checked="" type="checkbox"/> 1. FP<br><input type="checkbox"/> 2. Card<br><input checked="" type="checkbox"/> 3. PIN<br><input type="checkbox"/> 4. Card+FP<br><input type="checkbox"/> 5. Card+PIN |

### Set Personal Security Level

If you want to set the security level by personal, please select level and then click “<J” button and “1.Save & Exit”

|   |
|---|
| <b>ID : No.</b>   |
| Securi Level<br>3 FP1<br>4 FP2<br>5 Card<br>6 PIN<br>7 Securi Level |

|   |
|---|
| <b>ID : No.</b>   |
| Securi Level<br><input checked="" type="radio"/> 1. Normal<br><input type="radio"/> 2. High<br><input type="radio"/> 3. Very High |


### How to change authentication methods.

#### Search for ID of being amended.

For changing the authentication method, follow the process “ 1.User=>2.Edit User” and “Enter User ID:” message appears. Please enter ID of being amended.

If user needs to search ID list, push “\*\*” button for a while as for displaying all ID list and then choose


required ID. Please move curser by “ARROW” button for ID selecting, push “<J” button to go edition mode.



#### Change authentication methods

For change the authentication method, select “2.Edit” user of system initiates the edition process. If it has additional methods, display check(✓), otherwise, for not required method any longer, delete check(✓).

save and back to upper menu stage by pushing “<J” button and select “1.Save & Exit” for saving.



.□Tick mark (✓) appears as to push “\*” button or corresponding number.

#### User Deletion


##### Delete user

When enter ID required to delete, “Enter User ID:” message appears at the stage of “1.User => 3.Delete User).



When “Verify User ID” message appears, input the same ID again to completely delete.


It's matched, “OK! User deleted” message is displayed.



#### Delete all

For delete all input users, follow the process “1.User=>3.Delete User” and “ Enter User ID:” message appears, push “\*” button for a while till “All \*\* Users” message appears.

For completely deleting all registered users, select “1.Yes” and then “OK! All User Deleted” message is displayed.



## 7. Use & Authentication method

### Fingerprint User

Light on the sensor by pushing “<J” button or keeping on the last ID number for a while after input the user ID.

Place your finger on the finger sensor.

Success



Failure




When fail authentication, repeat one more time automatically.

Please try again with second failure message.


#### **EM TYPECard User ( Do not need to input ID )**

Close EM TYPEcard to the below of the fingerprint sensor.

Success



Failure




#### **Password User**


After input User ID, press “<J” button or keep on the last number for a while.

Push password when “Enter Password:” message appears.

Success



Failure



When fail authentication, repeat one more time automatically.

Please try again with second failure message.

### **EM TYPECard + Fingerprint, EM TYPECard + Password User( Do not need to input ID )**

Apply for the place needs high security level.

Authenticate as the fingerprint and password is completely matched.

#### **Selectable authentication method user**

Select one authentication method of all registered methods. When one selected method is matched, "OK! Access Granted" message" appears.


Ex) in case of Fingerprint & Password register

1. Input User ID
2. Apply fingerprint or Password

## **8. Free scan and Grouping**

### **Free scan authentication**

If number of user is less than 50 people, free scan authentication will be helpful to reduce one step of ID input. Follow the process " 2.service =>3.Free Scan" and select " 1.Enable " and save it by "<J" button.



For use of free scan, keep push " \* " button for seconds until sensor emit light or push twice of " \* " button and place your finger on sensor for authentication.

### **Grouping**

If number of user is more than 50 people, free scan authentication with grouping ID input will be helpful to reduce touching time of long ID and can speed up system processing time effectively.

For use of free scan with grouping ID, input first figure number of user ID and keep push “ \* ” button for seconds until sensor emit light and place your finger on sensor for authentication.


User ID grouping process is as follows;

- If user has 12345678 ID with more than 50 people, when try “1” and “ \* ” twice
- Basically processor count only all ID having “1” at first figure place among registered users.
- It means data loading burden on processor will be reduced to one tenth other than free scan.
- As like above wise, user can shorten a long ID number and a number of target user group ID as trying “12” and “ \* ” or “1” and “ \* ” and “8” or “ \* ” and “8” and so on.

## 9. Terminal registration

### Setting the terminal ID

To operate terminals in network must set terminal ID. Follow the process “3.System=>2.Terminal ID=> new TID “ up to 999 terminals and touch “ <J “ button for storage.




### Setting network mode upon transmission methods


#### Serial, Dial-Up

Select this methods when try to connect server PC to terminal by serial line.

First, follow the process “ 4.Network=>1.Network Mode=>1. Serial “ and confirm it by touching “ <J ” button or “ number “ button and then it's saved.



Second, back to upper menu stage by “<J” button and set transmission speed by following this process “4.Network =>2.Serial Speed ” and then it's saved by “<J” button.




### Dial-Up


To be updated within June 2004.

### TCP/IP

Select this methods when make terminal operation over Internet. First, follow this process “ 4.Network =>1.Network Mode=>3. TCP/IP ”, check 3. TCP/IP and then press “ <J ” button for storage or push “ number” button.



Second, go to the upper menu and set the five options;



- Local IP Address (terminal IP)

Input IP address by use of “number” button, “#” button for deletion and “\*” button for “.” And it’s saved by “<J” button.

b. Subnet Mask

Input Subnet Mask address

c. Gateway


Input Gateway address

d. Server Host

Input PC server IP address

e. Server Port


Input port number of PC server. It is set, as 8008 initially, please do not change without special cause.



### Setting date and time

Date and time keep even though power is off. It also can be changed at Console Manager program.


For date setting, follow this process “ 3.System=>5.Set Date” and input current date and save it “<J” button. For the change, please move curser by “ARROW” button and delete it by “#”and input new date and save it.



i.e.) if date is April 23, 2004, input 040423.

For time setting, follow this process “ 3.System=>6.Set Time “ and input current time and save it “<J” button. For the change, please move curser by “ARROW” button and delete it by “#”and input new

time and save it.




i.e.) if time is PM one thirty and five seconds, input 133005.

## 10. The other functions

### Setting security level

Tune security level from 'Very Low(1)' to 'Very High(5)' level. '3. Normal' is set in default.



The higher security level is the lower FAR (fault acceptance rate). Reversely the lower security level is the higher FAR.

There is an inverse proportion between FAR and FRR (fault rejection rate).

### Tunes locking time of door

It can control locking speed of door operation. Five (5) seconds is set in default.




**Checks all registered user**

At the stage of (1.User=>3.Delete User=> Enter User ID) keep push (\*) button for seconds, it shows all number of registered users. And for escape input “NO” or touch “CLR” button.

**Checks all registered ID**

At the stage of (1.User=>2.Edit User=> Enter User ID) keep push (\*) button for seconds, it shows all ID list in BKS-4800.




If you want to change authentication method on target ID, scroll down to the target ID by “ARROW” “button and touch “<J” button and it is ready to change.

**Change administrator password**

The initial password number was set as 1111. Please must change it to your own password number.

Type your new code twice as same number.

Follow this process as “ 2.System=>1.AdminPIN=>Enter New P/W=> Verify New P/W=>OK! Data Saved “

**Change administrator Fingerprint**

After registered Administrator fingerprint, this function can be used instead of P/W.

Process is same as user FP registration..

Follow this process as “ 3.System=>2.Admin FP=>Place finger on the sensor=> OK! Data Saved “

### Description of button

- Arrow key (▲ ▼) : curser scroll down or up
- <┘ button: confirm the selection mode and get into the lower menu stage and saved.
- CLR button: move to the upper menu stage without saving.
- “ \* ” button : 1) in grouping mode to mark all figures in the other place of ID number, 2) browse all user list 3) mark & delete check (✓) and “.” When input IP address at network mode.
- ‘ # ’ Button: to cancel input number as like back space key in PC keyboard.

### Change operations of authentication methods

Initially all authentication methods “Fingerprint, RF-card, Password (PIN)” was set for operation. If you want to delete any method from them, just touch “\*” to delete check (✓) and save it by “<┘” button.

Follow the process “ 3.System=>4.Access Module=>FP, Card, Key “ and select your choice.

| Administration                                       | System  | Access Module   |
|--|---|---|
| <b>1:User</b><br><b>2:Service</b><br><b>3:System</b> | <b>1. Admin PIN</b><br><b>2. Admin FP</b><br><b>3. Terminal ID</b><br><b>4. Access Module</b> | <input checked="" type="radio"/> <b>1: FP Sensor</b><br><input checked="" type="radio"/> <b>2: Card Reader</b><br><input checked="" type="radio"/> <b>3: PIN keypad</b> |

### Set LCD Back Light time

If you want to control LCD back light time how long it's on, input the time from 0 to 255 second.

For light on all the time, select “ 0 “, for power saving, you can select the back light off time.


If 200 second input, back light will be off after 200 second of last push button.

| Administration                                       | System   | Options  | BackLight Time                           |
|--|--|--|--|
| <b>1:User</b><br><b>2:Service</b><br><b>3:System</b> | <b>5 Card Reader</b><br><b>6 Set Date</b><br><b>7 Set Time</b><br><b>8 Options</b> | <b>1. BackLight Time</b><br><b>2. Exposure</b><br><b>3. LCD Contrast</b><br><b>4. LCD Brightness</b> | <b>New Time(0-255)</b><br><b>0 =&gt;</b> |


## Exposure

It can control the sensor exposure time to get more high quality image.

Follow the process “ 3.System=>8. Options=> 2.Exposure=> Select suitable Exposure of 3 levels and save it by “<–” button.



You can check the fingerprint image from Console Manager.





First, check the image remained on terminal and you select the most clear image level.

### LCD Contrast

It can control LCD contrast. To become big number, the background color is dark.

Follow the process “ 3.System=>8.Options=>3.LCDContrast =>Select suitable contrast of “0~63” and save it by “<J” button.

| Administration                                       | System   | Options  | LCD Contrast     |
|--|--|--|------------------|
| <b>1:User</b><br><b>2:Service</b><br><b>3:System</b> | <b>5 Card Reader</b><br><b>6 Set Date</b><br><b>7 Set Time</b><br><b>8 Options</b> | <b>1. BackLight Time</b><br><b>2. Exposure</b><br><b>3. LCD Contrast</b><br><b>4. LCD Brightness</b> | <br><b>5</b><br> |

### LCD Brightness

It's set to 5 levels in initial stage.

Follow the process “ 3.System=>8.Options=>4.LCD Brightness=>Select suitable Brightness level and save it by “<J” button.

| Administration                  | System   | Options  | LCD Brightness |
|---------------------------------|--|--|----------------|
| 1:User<br>2:Service<br>3:System | 5 Card Reader<br>6 Set Date<br>7 Set Time<br>8 Options | 1. BackLight Time<br>2. Exposure<br>3. LCD Contrast<br>4. LCD Brightness | 5<br>△<br>▽    |

### Time & Attendance setting

For being shown Time & Attendance function on LC window, go to the stage (2.Service=>4. Time&Attend) and set details.

| Administration                  | Service   | Time&Attend                     |
|---------------------------------|---|---------------------------------|
| 1:User<br>2:Service<br>3:System | 1. Unlock Time<br>2. Security Level<br>3. Free Scan<br>4. Time&Attend | 1. Key<br>2. Display<br>3. Item |

#### 1. Key

It's set the function key among the 1.Up/Down Arrow Key, 2. NO-F1,F2,F3,F4 and 3. F1,F2,F3,F4,NO

1. Up/Down Arrow Key : Select function by Up&Down arrow key
2. NO-F1,F2,F3,F4 : NO – CLR, F1 - △, F2 - ▽, F3 - <-, F4 - #
3. F1,F2,F3,F4,NO : F1 – CLR, F2 - △, F3 - ▽, F4 - <-, NO - #

| Time & Attend                   | Key   |
|---------------------------------|---|
| 1. Key<br>2. Display<br>3. Item | ○1. Up/down Key<br>○2. NO-F1....-F4<br>○3. F1....-F4-NO |

It's set the function key between 1.Up/Down Arrow Key and 2. or 3( 4 buttons of vertically forth line Arrow, CLR, <- )

If you use over 4 functions, please select to 1.Up/Down Arrow key as to push number "1" or "\*" button

#### 2. Display

When you don't want to use T&A function, just check "1.Disable".

2. Text : display message as IN, OUT, ABSENCE, Break In, Break Out.
3. Icon : display icon as same step as text.

| Time & Attend                   |
|---------------------------------|
| 1. Key<br>2. Display<br>3. Item |

| Display                          |
|----------------------------------|
| 1. Disable<br>2. Text<br>3. Icon |

### 3. Message select

After selecting text or icon, set function key message.

| Time & Attend                   |
|---------------------------------|
| 1. Key<br>2. Display<br>3. Item |

| F1  |
|---|
| 1. No<br>2. F1 <input checked="" type="checkbox"/> IN<br>3. F2 <input checked="" type="checkbox"/> OUT<br>4. F3 |

| F1 : Text   |
|---|
| <input type="radio"/> 1:<br><input checked="" type="radio"/> 2: IN<br><input type="radio"/> 3: OUT<br><input type="radio"/> 4: ABSENCE<br><input type="radio"/> 5: Break In |

| Items                           |
|---------------------------------|
| 1. Enable<br>2. Text<br>3. Icon |

### 4. No display T&A message

For no display T&A message, go to 2.Service => 4.Time & Attend => 2> Display => Select 1.Disable.

And save as click to '←' button

| Time & Attend                   |
|---------------------------------|
| 1. Key<br>2. Display<br>3. Item |

| Display   |
|---|
| <input checked="" type="radio"/> 1. Disable<br><input type="radio"/> 2. Text<br><input type="radio"/> 3. Icon |

### 5. No display function key.

If you want to set 'F1' key is no display, go to 2.Service => 4.Time & Attend => 3.Item => Select no operating button =>1.Enable => remove tick mark.

| Time & Attend                   |
|---------------------------------|
| 1. Key<br>2. Display<br>3. Item |

| F1  |
|---|
| 1. No<br>2. F1 ✓ IN<br>3. F2 ✓ OUT<br>4. F3 |

| F1 : Enable                       |
|-----------------------------------|
| <input type="checkbox"/> 1.Enable |

| Items                           |
|---------------------------------|
| 1. Enable<br>2. Text<br>3. Icon |

### Event setting

For being shown Mast Event & Delete Event function on LCD window, go to the stage (2.Service=>5.Event) and set details.

- **Delete Event** : Delete all event on the memory of BKS-4800
- **Output Type** : **Network** – Standard type data is directly sent to PC

**26 Wiegand, 34 Wiegand** – Directly connect to ACU(Access Control Unit)  
without PC interface

- Mask Event : **Lock Event** – Normal Locked, Normal Unlocked etc  
**Access Event** – Access Granted, ID etc main event  
**Other Event** – Network Status, System Information

**1.Enable** : Send the Event to PC

**1.Enable** : Do not stored on Memory and not sent to PC

BKS-4800 store many event log records included the lock event ( door open/close ), Access Event and Other Event. If you don't want to store "Lock Event" data, disable it.

When BKS-4800 use for standalone mode and no need the Log record, sometimes push "6.Delete Event" stored Event or disables all Events. It helps the fast operation speed to prevent from full memory data.

## 11. Tips on cautions use

### First setting in initial use

- Change system password for your security.
- Default setting password at manufacturing site: 1111
- Power should be supplied after all cablings are completed.

### In case of fingerprint hard to be processed


- Try again, after removing some dirties and water on fingerprint
- Stay more than 1.0 seconds on capture area and don't move your finger during touch.

### Reset BKS-4800 and back to setting status before latest trial


- When BKS-4800 is in disorder without special problem, Just push Reset switch, then it's back to setting status before latest trial.
- You can call anytime to customer support center for your trouble.

### Right fingerprint registration position

- Registration position



- Right finger touching



## 12. Specification

### Configuration

- Main board
- LCD module
- Fingerprint sensor

### Power

- Voltage
  - +12V DC with  $\pm 30\%$  tolerance, less than 150mVp-p ripple voltage
- Power consumption
  - Stand by: average 300mA
  - Maximum on working: average 600mA

### Environment

- Temperature & humidity
  - Operation temperature : -15°C to 60°C
  - Operation humidity: 0% to 90%
- Static electricity
  - 0~4KV contact discharge: No unrecoverable error
  - 0~8KV air discharge: No user detectable error

### Communication Interface

- 1 RS232 port/RS485/Dial-UP
  - Speed: select one among 9600, 19200, 38400 bps
  - Default speed: 19200bps
  - Interface valuable: no flow control, 1 stop bit, 8 data bits
  - Maximum interface span is up to RS232, RS485 specification.
  - Maximum transmission span: 150m
- 1 TCP/IP
- 1 Wigand

### Relay

- 1 Relay Out (COM, NO, NC)  
Rated 1A@24VDC  
Rated 1A@120VAC

### **Fingerprint storage**

- 1:1 : up to 5,000 user (two templates per user)
- 1:N matching : up to 1,000 user (two templates per user)

### **Log records**

- Up to 10,000 events

### **Dimension**

- Device: 155 mm (W) X 35 mm (D) X 155 mm (H)
- LCD module: 75 mm (H) X 52 mm (W)
- Fingerprint capture area in Sensor: 18 mm (H) X 16 mm (W)

### **Weight**

- 400g

### **Authentication speed**

- Less than 1.0 seconds

### **FRR (fault rejection rate)**

- 0.01%

### **FAR (fault acceptance rate)**

- 0.001%

### **Fingerprint data**


- 512 bytes

### **Sensor resolution**


- 500DPI

**Hardware (main board)****Connector description**

- Main board



## - Details on connectors



\* J2

- NO: Normal Open
- NC: Normal Close
- Relay Com: relay common port
- FGND: not used
- GND: ground

- VCC: DC +12V
- \* J3
- GND: ground
- TXD: RS232C transmit port (Dial-up)
- RXD: RS232C receipt port (Dial-up)
- WIG1: Wiegand connection port
- WIG0: Wiegand connection port

\*J9

- EXIT: Exit button port (connect with GND port)
- GND: ground
- 485+: RS485 port
- 485-: RS485 port
- SEN-: connection port for door sensor
- SEN+: connection port for door sensor
- PSB485+: not yet applied
- PSB485-: not yet applied

\*J8 (RS232 / 485 Jumper selectable)


- RS232: must jumper with 1-3,2-4 pin for 232 port use of J3
- RS485: must jumper with 3-5,4-6 pin for RXD/TXD port use of J7

## Application example

- Instruction for power line installation is not explained
- In case of Lock, upon door type of installation site Dead bolt, Striker, EM Lock will be used.

### Standalone – one(1) device



- Installed one unit for only access control without PC.
  - \* Usage: access control
  - \* Configuration: BKS-4800, Lock, inner exit button, S.M.P.S adapter (DC 12V 2A)
- \* Block diagram




- The # in the connection line means count # of line

\* Connection example of BKS-4800 connector

## Step 1



## Step 2




- Initial setting

\* Registration must be done at BKS-4800 terminal as manual 5.1 section shows.




**Standalone for two(2) terminals between wall**

Use both side of wall without exit button.

Please be careful of specific power connection as follows.



- Connection example of BKS-4800 connector




Please be careful of the difference Jumper setting as above picture.

### PC - RS232


- Serial network application: more than one BKS-4800 connected with server PC through RS-232 for access control and Time & Attendance.
  - **Configuration**
    - Access control: BKS-4800, Console-Manager (terminal control & log management), Lock, inner exit button, S.M.P.S adapter (DC12V 2A), BKS-2600 (fingerprint scanner), Server PC, door sensor

- Time & Attendance: BKS-4800, Console-Manager (terminal control & log management), S.M.P.S adapter (DC 12V, 2A), BKS-2600, Server PC
- Door sensor: check on door being open or closed.
- Block diagram




- Connection example of BKS-4800 connector #2


## Step 1



## Step 2



## Step 3



● **Initial setting**

- All setting's available on PC and BKS-4800, but we recommend PC processing for your convenience.

■ Registration

- In case of BKS-4800 (fingerprint scanner), customer can enroll the user's fingerprint by Console-Manger program or server program coded by SDK and transmit it to BKS-4800 terminals.
- Without BKS-4800, directly enroll user's fingerprint at BKS-4800 and download it to PC server by Console program.

■ Time & Attendance

- User's event records should be kept in BKS-4800 and transmitted to PC server.
- At the PC, Console-Manager or server program coded by SDK will handle it along with customer's management format.

■ Door control

- Regardless of terminal authentication, Door can be controlled by use of compulsory mode in Console Manager; open, closed, timeframe for open or closed

■ Restriction on user's admission

- Each user's timeframe for admission can be set in Console-Manager. If he tries to admit to door, LCD window shows " it is not time to use " and also door does not operate.
- Initially all user are not set for time restriction.

■ For more information on Console-Manager, please refer to manual of Console-Manager.


**PC – TCP/IP**

- BKS-4800 has TCP/IP port. So several terminals can be connected through HUB for PC server control network.
- In case of network mode, should set TID (terminal ID) in BKS-4800: 1 ~ 255. For the setting of TID please refer to manual 5.3.2 section.

● **Configuration**



- Access control: BKS-4800, Console-Manager, Lock, inner exit button, S.M.P.S adapter (DC 12V 2A), BKS-2600, Server PC, door sensor

- Time & Attendance: BKS-4800, Console Manager, S.M.P.S adapter (DC12V 2A), BKS-2600, Server PC
- Block diagram




- Connection example of BKS-4800 connector

Step 1




Step 2



Step 3

**LAN CABLE**




**HUB**

## PC – RS 485

You can connect multiple BKS-4800 and PC via RS485. You are required RS232 to RS485 converter additionally. If you want to install several BKS-4800, you must assign unique TID to each BKS-4800. TID range is from 1 to 255. For changing method of TID, please refer to chapter 6.1



### Configuration

- Access control: BKS-4800, RS232 to RS485 converter, Console-Manager(terminal control & log management), Lock, inner exit button, S.M.P.S adaptor (DC 12V, 2A), BKS-2600(fingerprint scanner), Server PC, door sensor
- Time and attendance: BKS-4800, RS232 to RS485 converter, Console-Manager(terminal control & log management), S.M.P.S adaptor (DC 12V, 2A), BKS-2600, Server PC
- Door sensor : check on door being open or closed
- Block diagram



■ Connection example of BKS-4800 connector





✓ Connection example


In this experiment, I use 232/485 converter of ILSHIN Inc.

BKS-4800, converter connection specification

| BKS-4800              | 232 to 485 converter |
|-----------------------|----------------------|
| 485+ (connector #1,4) | 485+ (DSUB 25, 4)    |
| 485- (connector #1,3) | 485- (DSUB 25, 6)    |
| GND (connector #1, 5) | GND (DSUB 25, 2)     |


### Wiegand communication with Access Control Unit ( ACU )

- Connection example of BKS-4800 connector



### PC – Modem


For modem communication, it needs two modems for sender and receiver with fixed telephone number.



Connection example of BKS-4800 connector

zsa

### EM TYPEmodule connection- Mifare Standard Module



1. EM TYPEType

- Voltage TTL (3.3V ~ 5V ) from EM TYPEmodule : TTL RXD type  
( 3-2 connect )
- Voltage RS232( +- 15V) from EM TYPEmodule : RS232 RXD type  
( 1-2 connect )

2. EM TYPEModule

- 1,2 : Supply VCC 5V to module
- 3 : TTL signal
- 4 : RS232 signal

3. Communication Format

9600, N , 8, 1

4. Data storage

Max 8Byte

\*Please inform to BIOINSEC with other type of module.