

FM5801 PS3 wireless controllers

PLEASE READ THE INSTRUCTIONS BEFORE USE

Functions overview:

2.4 GHz RF wireless control compatible PS3 games consoles province electricity sleep function low electric alarm function
With two vibration motor, support double vibrations compulsory attachment to code function support beauty gauges and sundials, ou compasses host has four combinations LED indicator channel selecting state with low electric alarm function

Apower supply:

4.5 V (external 3 quarter 1.5 VAAA battery)

connection and installation:

- (1) through the power supply of main and open the host,
- (2) press wireless controllers "HOME" button, the four combinations LED slow flashing,
- (3) press wireless controllers "the SELECT + L3" button until four combinations LED into flash state;
- (4) will wireless receiver insert the PS3 host, four combinations LED re-enter slow flash state;
- (5)again press wireless controllers "HOME" button, the instructions of the current channel ChangLiang attachment complete LED.

the sleep function:

Entering morpheus

- (1) the boot attachment, when no handle receptors, 55 seconds after entering morpheus condition; automatic
- (2) in the attachment condition, without any axis and the key operation, 10 minutes after entering morpheus condition; automatic

Sleep sensei

sleep mode according to the "HOME" button to awaken, the current working channel LED ChangLiang. effective control of the distance: 8 meters

low electric alarm function

- (1) indicates that power is not enough.
- (2) electricity shortage instructions current channel LED flashing.

(note: the battery power is not enough, please promptly replace new battery, lest affect the normal use of the handle.

LED display

- (-) receiver
 - (1) Link LED: LED flashing for search state, when Changliang for attachment state.
- (<u></u> the handle
 - 1 LED1-4:1-4 respectively instructions channel working condition.
 - 2.LED1 + LED4: indicates that the channel 5 working state.
 - 3 LED2 + LED4: indicates that the channel 6 working state.
 - 4 LED3 + LED4: indicates that the channel 7 working state.

function keys:

- 1) 12 simulate keystrokes: A, s, machine, X, L1 and L2, R1, R2, Up, Down, Left, Right
- 2) 2 simulated 3D rocker
- 3) four basic numeric keys: Start, the Select, L3, R3
- 4) a special function keys: HOME

5) have 1 TURBO keys

the HOME keys function

Press the buttons, 2 seconds after HOME then enter each associated Settings interface in conversion, wireless on grip digital mode will be invalid. In PS3 games, will lock in the simulation model. For each will receiver USB plug and PS3 host USB port after pulling inserted or reset after the PS3 host will click this button, handle controller can normal operation.

compulsory attachment (to) yards compulsory function

- 1) When how to the same wireless handle in the same operation environment, can adopt compulsory for code method to designated exclusive wireless controllers, (mandatory attachment method, please refer to connect with the installation instructions to the first paragraph of article 2 will5 steps)
- 2) if need to exchange the handle or receiver is required to forced code; (mandatory attachment method, please refer to connect with the installation instructions to the first paragraph of article 2 will5 steps)
- 3) attachment complete, in use process, wireless controllers and corresponding wireless receiver will realize automatic matching function;

the vibration feature

Handle in left big right small double motor design, support double vibration feature, simulation on-the-spot vibration effect

Warning:

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.