

Once you entered all factors, the Focus 4W calculates the curve. If the curve length (Len) is too large for a circle of the given radius, the curve is shortened.


Note - Press DSP to switch between display screens. See also page 90.


XYZ

Select this option to specify the stakeout point by coordinates.

- Press 4 or select XYZ in the Layout menu.
- Do one of the following:
 - Enter the point name that you want to establish and then press (ENT).
 - Specify the point by code or radius from the Focus 4W. If several points are found, they are displayed in a list. Press () or (v) to move up and down the list. Use **<** to move up one page, or ≥ to move down one page.
- Highlight a point in the list and then press [ENT]. The delta angle and the distance to the target are shown.
- Rotate the instrument until the dHA is close to $0^{\circ}00'00''$. Press [MSR1] or [MSR2].


dHA Difference in horizontal angle to the target point HD Distance to the target point





Ask the rod person to adjust the target position. When the target is on the 5. intended position, the displayed errors become 0.000 m (0.000 ft).

dHA Difference in horizontal angle to the target point R/L Right/Left (Lateral error) IN/OUT In/Out (Longitudinal error) CUT/FIL Cut/Fill



Once a measurement is taken, the Cut/Fill value and Z coordinate are updated as the VA is changed.

To record the point, press (ENT). The PT field defaults to the specified PT + 1000.




Press (MENU) and then select Settings / Rec.

Use the Add Constant field to specify an integer. The integer is added to the point number that is being laid out to generate a new number for recording the layout point. The default value is 1000. For example, when you stake out PT3 with an Add Constant of 1000, the default value in the SO field (layout record) is 1003.



The display then returns to the observation screen. Press (ESC). The display returns to the PT/CD/R input screen. If you entered the stakeout point using a single point name, the PT defaults to the last PT + 1.

If you selected a point from the list, the display returns to the list, unless all points have been selected. Press ESC to return to the point input screen.







List Stack

Advanced feature: Specifying a layout list by inputting points by range

- Select the Fr/To softkey when the PT field is selected.
 - CD: Fr/To List Enter the start point (Fr) and the end point (To). Input Point Range The range between Fr and To must be less than
 - If existing points are found between Fr and To, a point list appears.
 - To highlight a point in the list, press (^) or (v). To go to the layout observation screen, press ENT).
 - If you have assigned a control job, and additional points are found in the control job, the Ctrl softkey appears under the list.







Programs menu

To access the Programs menu, press [PRG] in the BMS.

To select a command from the Programs menu, press the corresponding number key. Alternatively, press ^ or (v) to highlight the command and then press (ENT).


The last function used is highlighted.

The Programs menu has the following options:

- RDM (Radial), page 77
- RDM (Cont), page 77


1001 points.

- REM, page 78
- Cogo, page 78



Remote distance measurement (RDM) - overview


RDM or "Remote distance measurement" measures the horizontal distance, vertical distance, and slope distance between two points.



rSD	Slope distance between two points
rVD	Vertical distance between two points
rHD	Horizontal distance between two points
rV%	Percentage of grade (rVD/rHD) \times 100%
rGD	Vertical grade (rHD/rVD):1
rAZ	Azimuth from first point to second point

Difference between RDM (Radial) and RDM (Cont) measurement methods


RDM (Radial) calculations are made with reference to the first point. RDM (Cont) calculations are made with reference to the two preceding points.



RDM (Radial)


Choose this option to measure between the current point and the first point measured.

- Press 1 or select RDM (Radial) in the Programs menu.
- Sight the first point and press [MSR1] or [MSR2]. The distance from the station point to the first point appears.




Sight the second point and press MSR1 or MSR2. The distances between the first and second point are displayed.

rSD	Slope distance between two points
rVD	Vertical distance between two points
rHD	Horizontal distance between two points



To change display screens, press DSP.

rHA	Azimuth from first point to second point
rV%	Percentage of grade (rVD/rHD) × 100%
rGD	Vertical grade (rHD/rVD): 1




Press ESC to exit.

RDM (Cont)

Choose this option to measure between the current point and the immediately preceding point.


- Press 2 or select RDM (Cont.) from the Programs menu.
- 2. Follow the procedure as for a radial RDM measurement. See also RDM (Radial), page 77.



REM

Choose this option to measure a remote elevation.


Note – A prism is required only at the sighting (target) point.



- 2. Enter the height of the target.
- 3. Sight the target point and press (MSR1) or (MSR2).
- 4. Loosen the vertical clamp and then turn the telescope to aim at an arbitrary point.

The difference in elevation (Vh) appears.

5. Press (ESC) to exit.




Cogo

Choose the Cogo option to perform coordinate geometry (Cogo) calculations.

There are five items in the Cogo menu:

- Inverse, page 79
- Input, page 81
- Area & Perm, page 83
- Down+Out, page 84
- Intersection, page 85



Inverse

Choose this option from the Cogo menu to calculate angle and distance between two coordinates.

Press 1 or select Inverse in the Cogo menu. The Inverse menu appears.

PT-PT inverse


PT-PT calculates the distance and the angle between two input points.

To calculate a PT-PT inverse:

- Press 1 or select PT-PT in the Inverse menu.
- Enter the first point number or name, and then press ENT).

If you press **ENT** without entering a point name, a coordinate input screen appears, and you can enter

coordinates. These coordinates are *not* stored to the database. If you want to store the point, specify a new point name.




The azimuth, horizontal distance, and vertical distance from the first point to the second point are displayed.


- Do one of the following:
 - To return to the PT input screen, press ESC.
 - To return to the Cogo menu, press [ENT].
 - To change the contents of the result screen, press DSP.


Gd Grade (HD/VD)


٧% 100/Gd


rSD Slope distance PT1 to PT2














3Pt Angle

If you choose 3Pt Angle, the Focus 4W calculates the angle between two lines defined by three points.

To calculate a 3Pt angle:

 Press ② or select ③Pt Angle from the Inverse menu.

P1 is the base point. Two lines are to be defined by P2 and P3, both from P1.


- 2. Enter the P1 point name. Alternatively, use the MSR softkey to take a measurement to the point.
- 3. Enter the second point (P2) to define the baseline, P1–P2. The angle (dHA) is measured from the baseline.
- 4. Enter the third point (P3) to define the second line, P1–P3.


When you press the MSR softkey, a temporary measuring screen appears. Sight the target and press [MSR1] or [MSR2] to take a measurement.


After the measurement, a recording point screen appears. To store the measured point, enter the PT, HT, and CD values and press ENT. To use the point without recording it, press ESC.

When you have entered three points, the instrument calculates the angle and distances.

- 5. Do one of the following:
 - To return to the Inverse menu, press ENT.
 - To return to the Input BasePt screen, press (ESC).







Input

Choose this option from the Cogo menu to calculate and manually input coordinates.

To enter the Input menu, press 2 or select Input from the Cogo menu. There are three functions in this menu for recording new coordinate points.

Azimuth+HD input

To calculate a coordinate by an angle and distance input from the base point (P1), press 1 or select HA+HD from the Input menu.

Enter the base point, P1. Type the point name and press ENT).

Enter the azimuth, horizontal distance, and vertical distance. Then press (ENT).

For example, to enter 123°45'45", type 123.4545 and then press ENT).

If you do not enter a value in the dVD field, the value 0.0000 is used.


A recording point screen with the calculated coordinates appears. The PT field defaults to the last recorded point + 1.

Press ENT to store the point.


Traverse


To calculate a new point based on two defined points and the angle, horizontal and vertical distances from the line defined by those two points, use the Traverse (2Pt Angle) function.


Press 2 or select Traverse in the Input menu.




Input









To enter P1 and P2, enter point names or take measurements to targets.


Enter the plus-minus angle, horizontal distance, and vertical distance from the baseline defined by P1-P2.


If you do not enter a value in the dVD field, the value 0.0000 is used.

When you press [ENT] in the dVD field, a new point is calculated. The name in the PT field defaults to the last recorded point, + 1.

To record the new point and return to the point input screen, press ENT).

P1 (the base point) defaults to the previously recorded point value. P2 defaults to the previous P1 value.







Tip - To continuously calculate a new point, enter +Ang, HD, and dVD from the previous bearing line. This is a convenient way to enter Traverse points.

Entering coordinates


To manually enter the XYZ coordinates, press 3 or select Input XYZ from the Input menu.


The PT name defaults to the last recorded PT + 1.

Enter the coordinates using the numeric keys. To move to the next field, press ENT or v in a field.

To store the point as an MP record and return to the point input screen, press [ENT] in the Z field. The default PT is incremented to the next value.

You can record NE, NEZ, or Z-only data.





Area & Perm

Choose this option from the Cogo menu to calculate area and perimeter.

Press 3 or select Area & Perim in the Cogo menu.

To take a measurement, enter the first point and press ENT), or select the MSR softkey.

In the upper right corner of the screen, a counter indicates how many points you have entered.


To input point numbers consecutively, use the Fr / To softkey. See also Advanced feature: Entering a range of points, page 83.


If you enter a new point name, you can enter new coordinates and record the point. If you do not want to record the point, press [ENT] without entering a value in the PT field. An XY coordinate input screen appears.

Continue to enter points until you have defined all the points in the lot. Then, press v to calculate the area and perimeter.

The first and last points that you enter are joined to close the area. You must enter the points in the order in which they define the lot. You can enter up to 99 points.

Press ENT to exit from the function, or press ESC to return to the previous screens one by one.






MsrPT Calc List

Advanced feature: Entering a range of points

To quickly enter a sequential range of points, use the range input function. To access this function, select the Fr / To softkey in the No. 01 or No. 02 input screens.

Enter the start point name in the Fr field and the end point name in the To field. You can include letters and hyphens in the point names, but the last character must be numeric.




To start searching for matching points, press ENT in the To field. The counter shows the number of matching points found.

Input Point Range
Fr: A-100
Find Points: 1
* Press [ESC] to abort

When the search is complete, you are returned to the Input PT screen.

Select the Calc softkey to calculate the area and perimeter, or enter point names in the PT field.

Press ESC to return to the Input PT screen where the preceding point name appears.



Note – If you search for a point when a control job is specified, and the system cannot find the point in the current job, the control job is also searched. If the point is found in the control job, it is copied to the current job as a UP record. See also Setting the control job, page 95.


Down+Out


Choose this option from the Cogo menu to calculate coordinates from Down and Out.


Press 4 or select Down & Out in the Cogo menu.

Enter the base point (P1).


Specify the azimuth bearing. To do this, enter a value in the HA or P2 field. P2 is a second point on the line.








Enter the horizontal distance along the baseline (Dwn), the horizontal distance perpendicular to the line (Out), and the vertical distance (dVD).







A negative value in the Dwn field means the opposite direction along the defined bearing line.

A negative value in the Out field is for the left-hand side of the bearing line.


To calculate the coordinates of the point (PM), press [ENT] in the dVD field. You can change the Z coordinate here.



To record the point, press ENT in the CD field.




The coordinates are stored as a CC record.



Intersection

Choose this option from the Cogo menu to calculate coordinates using intersection functions.

Press (5) or select Intersection in the Cogo menu. The Intersection menu appears. It has four functions for calculating coordinates.




Calculating a bearing-bearing intersection

A bearing-bearing intersection is the intersection point of two lines. To calculate a bearing-bearing intersection:


- 1. Press 1 or select Brns-Brns in the Intersection menu.
- 2. Enter the first point name and press ENT.


 Alternatively, to measure directly to the point, select the MSR softkey.
- 3. Define the first line by azimuth.




See also Advanced feature: Entering angle and distance offsets, page 89.

- 5. Do one of the following:
 - To return to the previous screen, press ENT. The calculated value appears in the HA field.
 - To go to the next screen, press ENT.
- 6. Define the second line by two points or by P2 and HA.
- 7. To calculate the coordinates of the intersection point, press ENT in the HA field.
 - The calculated coordinates are displayed. You can input a Z coordinate if necessary.
- 8. Enter a value in the PT field and in the CD field.
- 9. To record the point, press ENT).









PT:503 CD:CURB

Calculating a bearing-distance intersection


Press 2 or select Brn=-Dist in the Intersection menu.


Brng-Dist calculates the intersection point formed by one line and one distance (radius).


Enter a point on the line.


The line can be defined by two points or by a point and an azimuth.


- Enter the second point (P2) as the center of the circle.
- 4. Enter the distance from P2:
 - To define the distance (HD) by two points, select the Pts softkey.
 - To calculate the coordinates of the intersection point, press (ENT) in the HD field.
- If there are two results, the first solution appears graphically relative to the P1-P2 line. To display the second solution, press < or >.
- To record the point, press **ENT** when the required solution appears.
- Enter a Z coordinate if necessary. 7.
- To move to the PT and CD fields, press [ENT].




















Calculating a distance-distance intersection

- 1. Press 3 or select Dist-Dist in the Intersection menu.
- 2. Enter the first point name and press ENT, or select the MSR softkey to measure directly to the point.
- 3. Enter the distance from P1 and press ENT.
- 4. To define the distance (HD) by two points, select the Pts softkey.
- 5. Enter P2 and the distance from P2 (HD).
- 6. To calculate the coordinates of the intersection point, press ENT in the HD field.
- 7. Press \triangleleft or \triangleright to display the second solution.
- 8. To record the point, press ENT when the required solution appears.
- 9. Enter a Z coordinate if necessary.
- 10. Press ENT to move to the PT and CD fields.










Calculating a point-line intersection

- 1. Press 4 or select Ft-Line in the Intersection menu.
- 2. Enter the first point name and press ENT, or select the MSR softkey to measure directly to the point.
- 3. Enter the azimuth, or select the Pts softkey to enter another point name on the line.






- Enter the perpendicular point to the line, or select the MSR softkey to take a measurement to the point.
- To calculate the coordinates of the intersection point, press ENT.
 - If P1 and P2 are 3D points, the Z coordinate of the perpendicular point is calculated relative to the P1-P2 slope.
- Enter PT and CD then press ENT to record the point.





Advanced feature: Entering angle and distance offsets

To display the offset input screen, select the O/S softkey.


In the Ang field, enter a positive value to rotate the line clockwise. Enter a negative value to rotate the line counter clockwise.







In the O/S field, enter a positive value to specify an offset to the right. Enter a negative value to specify an offset to the left.



Recording measurement data


To record points from any observation screen, press [ENT].

PT defaults to the last recorded PT, + 1.

You can enter the PT name from the point list or the point stack. See Entering a point from the point list, page 53, and Entering a point from the point stack, page 52.

To record the point, press ENT on the last field.







If HA or VA is moved after you take a measurement, but before you press ENT, the recalculated coordinates will be stored.

If the point name that you want to record already exists in the job, an error message appears. Depending on the type of existing record, you can overwrite the old record with the new data. See Recording data, page 139.

If you do not need to record data, press MENU and set Settines / Rec to OFF.

The default setting is OFF.





Switching between display screens

Press of to switch between display screens. See the of button, page 44. Each time you press of the next screen appears. When you press of in the final screen, the first screen appears.

CHAPTER

Menu Screen

In this chapter:

- Job
- Settings (basic job settings)
- Data
- Communication
- 1sec-Key
- Calibration
- **■** Time


Use the MENU screen to access functions and settings.

To display the MENU screen, press the MENU key.

Job

Use the Job option to open, create, delete, and manage jobs.

To open the Job Manager, press $\ \ \, \ \ \,$ or select $\ \ \, \ \,$ from the MENU screen.



If jobs are stored on the Focus 4 total station, the job

list appears. It shows all the stored jobs with the newest job at the top of the list. See Opening an existing job, page 92.

If no jobs are stored, the Create Job screen appears. See Creating a new job, page 92.

Opening an existing job

The job list shows all the jobs stored on the instrument, in descending date order.

The following symbols provide extra information about jobs:



Symbol	Meaning
*	Current job
@	Control job
!	Some of the job settings are different from the current job

Press riangle to move up or riangle to move down the job list. Press riangle to open the highlighted job.

When you open a job, all job settings are automatically changed to match those used in the open job.

Creating a new job


Select the Creat softkey in the job list.



2. Enter a job name of up to eight characters. Select ENT.



- Do one of the following:
 - To check the job settings, select the Sett softkey.
 - To create a new job using the current job settings, press (ENT) or select the OK softkey.



Job settings

Job settings are separate from other temporary settings.

Job settings are established when a job is created, and cannot be changed. This ensures that the data in a job is correctly stored in the database, and that all necessary corrections are applied when you store each record.

To move between fields, press (^) or (v). Alternatively, to move to the next field, press (ENT).

To change the setting in the selected field, press \triangleleft or \triangleright .

To confirm the job settings and create the job, press (ENT) in the last field.

Screen 1

Scale Factor 0.999600 to 1.000400

T-P correction ON / OFF Sea Level ON / OFF

C&R correction OFF / 0.132 / 0.200



Screen 2

DEG / GON /MIL Angle unit Metre / US-Ft / I-Ft Distance unit

°C/°F Temp unit

Press unit hPa / mmHg / inHg




Screen 3

If you select US-Ft or I-Ft, an additional settings screen appears. Use this screen to specify whether to display values in Decimal-Ft or Ft-Inch.



VA zero Zenith / Horizon
Order NEZ / ENZ



Deleting a job

Note – There is no undelete function in Job Manager. Before you press ENT or select DEL, make sure that the selected job is the one that you want to delete.

1. In the job list, highlight the job to delete.




Job name:YOKOHAMA

* Are you sure?

Delete JOB

- 2. Select the DEL softkey. A confirmation screen appears.
- 3. Do one of the following:
 - To delete the selected job, press ENT or select the DEL softkey.
 - To cancel the deletion and return to the previous screen, press ESC or select the Abrt softkey.

After you delete a job, the job list appears.



Setting the control job

A control job has the same format as a standard job. You can open and modify it like any other job, and you can use it to record any measured data.

To set the control job:

- Highlight the job that you want to use as the control job.
- Select the Ctrl softkey.


A confirmation screen appears.

- 3. Do one of the following:
 - To set the selected job as the control job, press [ENT] or select the Yes softkey.
 - To cancel the process, press ESC or select the No softkey.

If a control job is already assigned, the newly assigned control job replaces it as the control job.

To clear the selected control job, highlight the current control job in the job list and select the Ctrl softkey. Then press (ENT) or select the Yes softkey.





Displaying job information

To display job information, highlight the job name and then select the Info softkey.

The Information screen shows the number of records in the job, the free space, and the date when the job was created. Free space indicates how many points can be stored in the job.

To return to the job list, press any button.




Settings (basic job settings)

Use the Settings menu to configure the basic job settings.


Press 2 or select Settines on the MENU screen.

Some job settings, as identified in the following sections, cannot be changed once a job is created. If you attempt to change any of these settings while a job is open, a confirmation screen appears, asking you to create a new job with the new settings, or to work with the new settings without recording any data. See Settings, page 141.



Angle

To change the angles, press \bigcirc or select $\exists n \exists 1 \in$ in the Settings menu.



VA zero Zenith / Horizon
Resolution 1" / 5" / 10"
0.2 / 1 / 2 mgop

0.2 / 1 / 2 mgon 0.005 / 0.02 / 0.05 mil



The VA zero job setting cannot be changed once a job is created.

Distance

These settings cannot be changed once a job is created.

To change the distance, press ② or select Distance in the Settings menu.

Scale Numeric value between 0.999600 and

1.000400

T-P corr ON / OFF Sea Level ON / OFF

C&R corr OFF / 0.132 / 0.200



Temperature and pressure corrections

$$K = 275 - \frac{106 \times P \times \left(\frac{10000.0}{13.5951 \times 980.665}\right)}{273 + T}$$

$$SD' = \left(1 + \frac{K}{1000000}\right) \times SD$$

SD Slope dist. (before adj.) Slope dist. (after adj.) SD' Κ Compensation coefficient

Pressure (hPa) Т Temperature (°C)

Sea-level corrections

$$HD' = \frac{HD \times R_e}{R_e + Z_{STN}}$$


Horizontal dist. (before adj.) HD

HD' Horizontal dist. (after adj.)

Instrument-Z Z_{STN} 6370 km R_{e}

Curvature and refraction corrections

Because the surface of the earth is curved, the vertical difference (VD and Z) at the measurement point, as referenced to the horizontal plane, inevitably includes some error. This error is called *curvature error*. Also, because the density of the air surrounding the earth decreases with altitude, light is refracted at different rates at different altitudes. The error caused by this change in refraction is called *refraction* error.



$$HD' = HD - \frac{SD^2 \sin(2VA)}{2R_e} \left(1 - \frac{k}{2}\right)$$

$$VD' = VD + \frac{HD^2}{2R_e}(1 - k)$$


HD Horizontal dist. (before adj.) Horizontal dist. (after adj.) HD' Vertical dist. (before adj.) VD Vertical dist. (after adj.) VD' SD Slope dist VA Vertical angle 6370 km R_{e} k C&R constant (0.132 or 0.200)

Coordinate

Press 3 or select Coord. in the Settings menu. The Coordinate menu appears.

Order NEZ / ENZ

Label XYZ / YXZ / NEZ(ENZ)



The Order cannot be changed once a job is created.

Communications

Press [4] or select Comm. in the Settings menu. The Communication menu appears.

Ext.Comm NIKON / SET Port Serial/Bluetooth

> Note - This field appears only when the optional Bluetooth® wireless

technology is on-board.

1200 / 2400 / 4800 / 9600 / 19200 / Baud (bps)

38400

Length 7/8

EVEN / ODD / NONE **Parity**

Stop bit 1/2

See also Chapter 7, Transferring Coordinate Data.



Unit

Note - The Angle, Distance, Temp, and Press job settings cannot be changed once a job is created.

Press (5) or select Unit in the Settings menu. The Unit menu appears.

DEG (Degree) Angle

> GON (GON) MIL (Mil6400)

Meter

Distance


US-Ft I-F

Temp °C (Celsius)

°F (Fahrenheit)

Pressure hPa

> mmHg inHg



If you select US-Ft or I-Ft, an additional settings screen appears. Use this screen to specify whether to display values in Decimal-Ft or Ft-Inch.



Power saving

To open the Power Save menu, press 6 or select Pur Save in the Settings menu.

Main unit OFF / 5 min / 10 min / 30 min

EDM unit OFF / At Once / 0.1 min / 0.5 min / 3 min /

10 min

Sleep OFF / 1 min / 3 min / 5 min




Recording

Press 7 or select Re⊂ in the Settings menu. The Rec Menu appears.

Rec Data ON / OFF
CD field ON / OFF

Add const Integer between 1 and 999,999



- If you need to record data from your observations, set the Rec Data field to ON. Both raw and coordinate data is stored. If you set the Rec Data field to OFF, no record is stored.
- If you would like to record a feature code when you record coordinate data, set the CD field to ON. The CD field appears in the Recording PT screen.
- This field sets the default point number for the observed coordinate data when you select Layout / XYZ.


Other settings

Press (8) or select Other in the Settings menu. The Others menu appears.

<<Sorry, your instructions were not clear to me - do I need to replace the table below and the snap with the

XYZ disp Fast / Normal / Slow / +ENT 2nd Unit None / Meter / US-Ft / I-Ft

CD input 123 / ABC English / Russian Language Owner's Detail Up to 20 characters



XYZ disp defines the speed to move to the next screen after showing XYZ of the input point.

When the secondary unit is set to a unit, an extra display screen is available in the BMS, layout observation screens, and L-O from line screens. The extra screen shows the HD, VD, and SD in the secondary unit.

If you select US-Ft or I-Ft, an additional settings screen appears. Use this screen to specify whether to display values in Decimal-Ft or Ft-Inch.

The CD Input field sets the default input mode when a CD field appears.

In the Language field, use < / > to open the language screen and $\sqrt{\ }$ to select the required language. Press ENT to confirm. In the Reboot confirmation screen, press (ENT) to restart the instrument. The instrument reboots and displays the start-up screen in the selected language.

The Owner's Detail field allows you to enter your name or the name of your company. If you enter a value in this field, it appears when you start the Focus 4 total station.

To provide easier configuration for common regional settings, you can quickly configure the Focus 4 total station to a pre-set combination of default regional settings. See also Regional configuration, page 49.







Data

Use the Data menu to view or edit records. To display the Data menu, press 3 on the MENU screen.

Raw and coordinate data is stored when the Data Rec setting is ON. If the Data Rec setting is OFF, no data is recorded in [MENU] / Data / Data Rec.



Viewing records



Tip – You can view data at any time, even in an observation screen.

Viewing RAW data

To show the raw data records in a list, press 1 in the Data menu.


View/Edit RAW data XYZ data

The newest record is at the bottom of the screen.

To scroll through the records, press or v. To move up or down one page, press < or >.

To view more detailed information for a selected record, press ENT. To return to the record list, press ESC.





SS and F1 records

Raw SS and F1 records contain PT, HT, CD, HA, VA, and SD fields.

SS records are sideshots (topo shots). All shots taken from the Basic Measurement Screen (BMS) are stored as SS records.

F1 records are backsight shots that are taken when you set up a station. Coordinates are not available for an F1 record.

When you take more than one measurement to the same point and choose to overwrite the XYZ data, the old raw *record* becomes raw *data* only. As a result, only one SS (RAW) record keeps its corresponding SS(XYZ) record. Other SS(RAW) records to the same point no longer have a record on their coordinates.

ST records

ST (station) records contain ST, HI, BS, and AZ fields.

Press (DISP) to switch between the screens:

- The first screen shows ST, HI, BS, and AZ
- The second screen shows X, Y, Z, PT, and CD

SO records

SO records are layout (L-O) shots. There shots are recorded in stakeout functions.

Press (DISP) to switch between the screens:

- The first screen shows HA, VA, SD, PT, and HT
- The second screen shows X, Y, Z, PT, and CD
- The third screen shows dX, dY, dZ, PT, and CD


The dX, dY, and dZ fields store the difference between the actual position and the planned position of the stakeout shot. These fields are downloaded as comment records in Nikon RAW format.

CO records

A CO record is a comment that is added to the job by the system.

For example, the system writes a comment record when you use the Remote Benchmark function to change the Stn-Z, or when you use the BSCheck function to reset the horizontal angle.

When you enter a Stn-XYZ by Base-XYZ function, the recorded station appears as a comment record.



Viewing coordinate data


To show the coordinate data records in a list, press [2] in the Data menu.



The newest record is at the bottom of the screen.

To scroll through the records, press ^ or v. To move up or down one page, press < or >.

Press ENT to see more detailed information about the selected record.



The header (XYZ, YXZ, NEZ, or ENZ) depends on the Coord. Label setting in MENU / Settings / Coord. See also Coordinate, page 99.

UP, MP, CC, and RE records

All coordinate records contain PT, CD, X, Y, and Z fields.

- UP records are uploaded point coordinates.
- MP records are manually input point coordinates.
- CC records are points calculated in Cogo.
- RE records are points calculated in Base Line and Resection station setup.

Deleting records

Deleting raw records

- In the RAW screen, use \(\bar{\rm} \) or \(\bar{\rm} \) to highlight the record that you want to delete. Then select the DEL softkey.
- A confirmation screen appears.
 - To delete the selected record, press (ENT) or select the Yes softkey.
 - To cancel the deletion of data, press ESC or select the No softkey.



The system also deletes the corresponding coordinate data when you delete an SS or SO record.


Deleting coordinate records


- In the XYZ screen, use \(\bar{v} \) or \(\bar{v} \) to highlight the record that you want to delete. Then select the DEL softkey.
- A confirmation screen appears.
 - To delete the selected record, press [ENT] or select the Yes softkey.
 - To cancel the deletion of data, press (ESC) or select the No softkey.

Alternatively, delete coordinate data by selecting the DEL softkey in the detailed display screen for the record.

If the record that you want to delete is referred by any ST record, a warning message appears.







Deleting station records



CAUTION – There is no undelete function on the instrument. Before you confirm the deletion by pressing the DEL softkey, make sure that you have selected the correct station record.


- In the Station screen, use \(\cap \) or \(\bar \) to highlight the record that you want to delete. The select the DEL softkey.
- A confirmation screen appears.
 - To delete the selected record, press ENT or select the Yes softkey.
 - To cancel the deletion of data, press ESC or select the No softkey.



3. If you select Yes, a warning screen appears. Select the DEL softkey to confirm the deletion.

Note - You cannot press [ENT] *in this screen.*

All observations from the station that you selected are deleted.



Editing raw records


For any point record, you *can edit* the following:

- Point name (PT)
- Feature code (CD)
- Height of target (HT)
- Height of instrument (HI)
- Backsight point (BS)
- Backsight azimuth (AZ)


You *cannot edit* the following:

- The CD field for SO and F1 records
- HA, VA, or SD values
- 1. Do one of the following:
 - In the RAW screen, use or v to highlight the record to edit. Then select the Edit softkey.
 - In the detailed data screen, select the Edit softkey.
- 2. Use ^ or v to highlight a field. Then modify the value in the selected field.

Note – When you change the HT of an SS or SO measurement record, the Z coordinate is recalculated.



- 3. Press ENT in the last line of the edit screen. A confirmation screen appears.
- Do one of the following:
 - To accept the changes and return to the data view screen, press (ENT) or select the Yes softkey.
 - To return to the Edit screen, press [ESC] or select the No softkey.



Editing coordinate records

You can edit PT, CD, and coordinate values.


You *cannot edit:*


- The coordinate record for the current station
- SS and SO records
- Record referred by Station


To edit coordinate records:

- Do one of the following:
 - In the XYZ screen, use \(\bar{\cap} \) or \(\bar{\cap} \) to highlight the record to edit. Then select the Edit softkey.
 - In the detailed data screen, select the Edit softkey.
- Use or v to highlight a field. Then modify the value in the selected field.
- To finish editing, press ENT in the CD field. A 3. confirmation screen appears.









- 4. Do one of the following:
 - To accept the changes and return to the data view screen, press ENT or select the Yes softkey.
 - To return to the Edit screen, press ESC or select the No softkey.



Editing station records

Note – The system will not recalculate measurements if you change the station record. You will need to recalculate all coordinate and raw data that was collected from an edited station record in your postprocessing software.

- In the RAW screen, use or v to highlight the station record to edit. Then select the Edit softkey.
- 2. Use nor v to highlight a field. Then modify the value in the selected field. You can edit any field in the ST record, but the instrument does not recalculate the measurements from this station.
- 3. To finish editing, press [ENT] in the AZ field.



RAW WOOD

CO.Temp:20 Press:101(

If you change the ST and HI values, the coordinates of observation points are not recalculated. A comment record is stored to record the change. The following is a comment record for a changed HI value: CO, HI changed at ST:9012 Old HI = 1.3456m

If you change the BS or AZ values, raw records are not recalculated. A comment record is stored to record the change.